code

Goodrive390L Series Lift-dedicated VFD

Quick Start Guide

This guide describes the instructions of operating Goodrive390L series lift-dedicated variable frequency drive (VFD), including information about the safety precautions, external wiring, terminal functions, quick startup, keypad, common function parameters, and common faults. Please scan the e-manual platform QR code provided in part 8 or marked on the VFD housing for more information.


1 Safety precautions

1.1 Warning

Sign	Name	Description	Abbreviation
A Danger	Danger	Severe personal injury or even death can result if related requirements are not followed.	A
Marning	Warning	Personal injury or equipment damage can result if related requirements are not followed.	\triangle
Forbid	Electrostatic sensitive	The PCBA may be damaged if related requirements are not followed.	13
<u></u> Hot	Hot sides	Do not touch. The VFD base may become hot.	
<u>^</u>	Electric shock risk	As high voltage still presents in the bus capacitor after power off, wait for at least five minutes (or 15 min / 25 min, depending on the warning symbols on the machine) after power off to prevent electric shock.	<u>^</u>
	Read manual	Read the operation manual before operating the equipment.	
Note	Note	Actions taken to ensure proper running.	Note

1.2 Safety guidelines

	❖	Only	trair	ned and	d qua	lified	orotessi	onals are	allowe	ed to ca	rry out	related
		oper	ation	IS.								
		_										



	1PH 220V	2.2kW	5 minutes
	3PH 220V	2.2kW-18.5kW	5 minutes
	3PH 380V	4kW-37kW	5 minutes
٨	♦ Do not refit the	VFD unless authorized	l: otherwise fire electric shock or

<u> </u>	 Do not refit the VFD unless authorized; otherwise fire, electric shock of other injury may result.
	The base may become hot when the machine is running. Do not touch Otherwise, you may get burnt.

A	♦ The electrical parts and components inside the VFD are electrostatic
6.3	sensitive. Take measurements to prevent electrostatic discharge when
	performing related operations.


1.3 Environment condition

ZIIVII OIIIIIOIIL	o o i di di di
Ambient temperature	 → -10-+50°C → When the ambient temperature exceeds 40°C, derate 1% for every increase of 1°C. → Do not use the VFD when the ambient temperature exceeds 50°C. → In order to improve reliability, do not use the VFD in the places where the temperature changes rapidly. → When the VFD is used in a closed space, such as control cabinet, use a cooling fan or air conditioner for cooling, preventing the internal temperature from exceeding the temperature required. → When the temperature is too low, if you want to use the VFD that has been idled for a long time, install an external heating device before the use to eliminate the freeze inside the VFD. Otherwise, the VFD may be damaged.
Relative humidity (RH)	RH: less than 90% Condensation is not allowed. The max. RH cannot exceed 60% in the environment where there are corrosive gases.
Running environment	Install the VFD in a place:

Environment Lower than 1000 meters When the altitude exceeds 1000m, derate by 1% for every addition When the installation site altitude exceeds 3000m, consult the local INVT dealer or office. Vibration The max. amplitude of vibration cannot exceed 5.8m/s² (0.6g). Install the VFD vertically to ensure good heat dissipation performance.

2 Peripheral wiring

Figure 2-1 Peripheral equipment connection



3 Terminal function

3.1 Main circuit terminal diagram

Figure 3-1 Main circuit wiring diagram





Table 3-1 Main circuit terminal description

Terminal symbol	Terminal name	Function
L1, L2, L3 (or R, S, T)	Main circuit power input	Connect R, S, T terminals when the input is 3PH AC 380V. Connect L1, L2, L3 terminals when the input is 3PH AC 220V. Connect any two of L1, L2, L3 terminals when the input is single phase AC 220V.
PB1, PB2	Reserved terminal to connect to the external braking resistor	To connect the external braking resistor
(+), (-)	DC bus terminal	To connect the DC 48V emergency power supply
A1, A2	Auxiliary power input port	When the DC 48V emergency power supply is used, connecting the UPS AC 220V power supply can enable the normal operation of the internal auxiliary power supply of the VFD.
U, V, W	VFD output	3PH AC output terminals, connected to the motor.
(1)	Grounding terminal	Grounding terminal

3.2 Control circuit wiring diagram

Figure 3-2 Wiring diagram of basic control circuit



Used to externally provide 24V±10% power supply. Max. output current:

+24V	200mA
COM	Reference ground of +24V
	Regular digital input terminals
	1. Internal impedance: 3.3kΩ
	2. 12–30V voltage input is acceptable.
S1 – S10	3. Bi-direction input terminal, supporting both NPN and PNP (Selected
51-510	through the jumper J1)
	4. Max. input frequency: 1kHz
	5. All of them are programmable digital input terminals. Users can set the
	terminal function by function code.
	Open collector outputs
Y1, CME	1. Switch capacity: 50mA/30V
	2. Output frequency range: 0–1kHz
	Three programmable relay outputs
RO1	One group of NC and NO output: RO1A: NO; RO1B: NC; RO1C:
RO2	common
RO3	Two groups of NO output: RO2A, RO2C; RO3A, RO3C
	Contact capacity: 3A/AC250V, 1A/DC30V
	1. Input range: 0–10V or 0–20mA, set through the jumpers J7 and J8.
AI1, AI2	2. Input impedance: $20k\Omega$ for voltage input or 500Ω for current input
AII, AIZ	3. Resolution: 5mV when 10V corresponds to 50Hz.
	4. Error: ±1% at 25°C
	PT100 interfaces
PT+, PT-	1. Resolution: 1°C
1 1 1 , 1 1-	2. Range: -20°C–150°C
	3. Detection precision: ±3°C
	Simple closed-loop encoder signal interfaces
PA, PB	1. Applicable to 5V/12V push-pull, OC encoders
	2. Response frequency: 100kHz
PWR	Encoder power interface. The common terminal is COM which can be set
FVVIX	to 5V or 12V through SW1.
CANH, CANL	CANopen communication interfaces. The terminal matching resistor can
CANTI, CANL	be connected through the jumper J2.
485+, 485-	RS485 communication interfaces
	STO function input terminals
	1. Connected to external NC contacts. When the contacts open, STO
H1, H2	acts and VFD output stops.
П1, П2	2. H1 and H2 are redundant inputs. They are short connected to +24V by
	default. Remove the jumper before using STO function.
	3. Use the shielded cable with a length shorter than 25m.

4 Quick startup

4.1 Check before power-on

Terminal

+24V


Ensure that all terminals have been securely connected Ensure that the motor power matches the VFD power.

4.2 First power-on

After confirming the wiring and power are correct, close the air switch of the AC power supply at the VFD input side to power on the VFD. The keypad displays as the following figure, indicating that the VFD is ready for run.



The quick startup diagram is as follows:



5 Keypad

Table 5-1 LCD keypad

۱o. l	Name			Description
¥0.	Name			Off: The VFD is stopped.
		RU	N/TUNE	On: The VFD is stopped. On: The VFD is running.
				Forward or reverse running indicator
		E\A	/D/REV	Off: The VFD is running forward.
		I- V1	IDINEV	On: The VFD is running forward. On: The VFD is running reversely.
				Indicates whether the VFD is controlled through
	Status			the keypad, terminals, or communication.
1	indicator	1.004	L/REMOT	Off: The VFD is controlled through the keypad.
		LOCA	IL/REMOT	Blinking: The VFD is controlled through terminals.
				On: The VFD is controlled through remote
				communication.
			TDID	Fault indicator
		TRIP		LED on: The VFD is in fault state.
				LED off: The VFD is in normal state.
	Keys	PRG ESC	Programming	Press it to enter or exit level-1 menus.
		200	key	
		DATA	Confirmation	Press it to enter menus in cascading mode or
		ENT	key	confirm the setting of a parameter.
			UP key	Press it to increase data or move upward.
			Or Noy	Trees it to mercuse data of move apward.
			Down key	Press it to decrease data or move downward.
			Down key	Tress it to decrease data of move downward.
				Press it to select display parameters rightward in
2		_ ≫ SHIFT	Right-shifting	the interface for the VFD in stopped or running
		OTHE 1	key	state or to select digits to change during parameter setting.
				i v
			Run key	Press it to run the VFD when using the keypad for control.
				Press it to stop the VFD that is running. The
			Stop/Reset	function of this key is restricted by P07.04.
			key	In fault alarm state, this key can be used for rese
				in any control modes.
		QUICK	Multifunction	The function is determined by DOZ 02
		JOG	shortcut key	The function is determined by P07.02.
			Shortcut key	

6 Common function parameter setup

The following table briefly describes some common function parameters and typical values. "O" indicates that the value of the parameter can be modified when the VFD is in stopped or running state.

"©" indicates that the value of the parameter cannot be modified when the VFD is in running

Description

Sensorless vector control (SVC) mode

"O" indicates that the value of the parameter is detected and recorded, and cannot be modified. (The VFD automatically checks and constrains the modification of parameters, which helps

P00.	Speed control mode	0 1: Reserved 2: VF control 3: Closed-loop vector control	2	0
P00.	Channel of running commands	0–2	0	0
P00.	Communication mode of running commands	0–1 0: Modbus/Modbus TCP communication 1: CANopen	0	0
P00.	frequency	Max(P00.04, 10.00) –200.00Hz	50.00Hz	0
P00.	running frequency	P00.05–P00.03	50.00 Hz	0
P00.	Lower limit of running frequency	0.00 Hz-P00.04	0.00 Hz	0
P00.	Rated speed of the elevator	0.100–4.000m/s	1.000m/s	0
P00.	Speed command channel selection	0-9 0: Keypad 1: Al1 (follow) 2: Al2 (follow) 3: Al1 4: Al2 5: Reserved 6: Multi-step speed running 7-8: Reserved 9: CANopen communication	0	0
P00.	Speed set through keypad		1.000m/s	0
P00.		0-2 0: Run in default direction 1: Run in reverse direction 2: Disable reverse running	0	0
P00.	Carrier frequency setting	carrier frequency will have an ideal current waveform, few current harmonics, and small motor noise, but it will increase the switch loss, increase VFD temperature, and impact the output capacity. At the same time, the VFD current leakage and electrical magnetic interference will increase. On the contrary, an extremely-low a carrier frequency may cause unstable operation at low frequency, decrease the torque, or even lead to oscillation. The carrier frequency has been properly set in the factory before the VFD is delivered. In general, you do not need to modify it. Setting range: 1.0–15.0 kHz Note: When the frequency used exceeds the default carrier frequency, the VFD needs to derate by 10% for each increased of 1kHz.	Model depended (8.0kHz)	©
P00.	Motor parameter autotuning	lox00-0x34 Ones place: Motor basic parameter autotuning 0: No operation 1: Reserved 2: Complete parameter static autotuning 3: Reserved 4: Deadzone compensation autotuning Tens place: Initial pole angle autotuning 0: No operation 1: Reserved 2: Static autotuning 3: Rotary autotuning 2	0x00	©
P00.	Function 18 parameter restoration	0–2 0: No operation 1: Restore to default values (excluding motor parameters) 2: Clear fault records	0	0
P01.	00 Start mode	0–1 0: Direct start 1: Start after DC braking	0	0
P01.	06 ACC/DEC mode	0–1 0: Linear 1: S curve	1	0
P01.	stop	During the deceleration to stop, the VFD starts DC braking for stop when running	0.00Hz	0
P01.	DC braking current	frequency reaches the starting frequency determined by P01.09.	0.0%	0

nction code	Name	Description	Default	Modif
01.12	DC braking time for stop	DC braking current for stop: It indicates the applied DC braking energy. Stronger current indicates greater DC braking effect. DC braking time for stop: It indicates the hold time of DC braking. If the time is 0, DC braking is invalid, and the VFD decelerates to stop within the specified time. Setting range of P01.09: 0.00–P00.03(Hz) Setting range of P01.11: 0.0–100.0% (of the VFD rated output current)	0.00s	0
01.15	Stop inflection	P01.12 setting range: 0.00–50.00s 0.000m/s–P00.06	0.000m/s	0
02.00	speed Motor type	0–1 0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0	0
02.01	Rated power of AM	0.1–3000.0kW	Model depended	0
02.02	Rated frequency of AM	0.01Hz–P00.03(Hz)	(0.4kW) 50.00Hz	0
02.03	Rated speed of AM	1–60000rpm	Model depended (1400rpm)	0
02.04	Rated voltage of AM	0–1200V	Model depended (380V)	0
02.05	Rated current of AM	0.8–6000.0A	Model depended	0
02.06	Stator resistance of AM	0.001–65.535Ω	(1.0A) Model depended	0
02.07	Rotor resistance of AM	0.001–65.535Ω	(0.001Ω) Model depended (0.001Ω)	0
02.08	Leakage inductance of AM	0.1–6553.5mH	Model depended (0.1mH)	0
02.09	Mutual inductance of AM	0.1–6553.5mH	Model depended	0
02.10	No-load current of AM	0.1–6553.5A	(0.1mH) Model depended (0.1A)	0
02.15	Rated power of SM	0.1–3000.0kW	Model depended (0.4kW)	0
02.16	Rated frequency of SM	0.01–P00.03(Hz)	50.00Hz	0
02.17	Number of pole pairs of SM	1–128	2	0
02.18	Rated voltage of SM	0–1200V	Model depended (380V)	0
02.19	Rated current of SM	0.0–6000.0A	Model depended (1.0A)	0
02.20	Stator resistance of SM	0.001–65.535Ω	Model depended (0.001Ω)	0
02.21	Direct-axis inductance of SM	0.01–655.35mH	Model depended (0.1mH)	0
02.22	Quadrature-axis inductance of SM	0.01–655.35mH	Model depended (0.1mH)	0
02.23	Counter-emf of SM	0–10000V	300V	0
02.33 02.34	Pulley diameter DEC ratio	100–2000m 0.50–50.00	500m 1.00	0
02.35	Speed ratio	0–65535	1000	0
03.00	Speed-loop	0.0–200.0	20.0	0
03.01	proportional gain 1 Speed-loop integral time 1	0.000–10.000s	0.600s	0
03.02	Low-point frequency for switching	0.00~P03.05(Hz)	5.0Hz	0
03.03	Speed-loop	0.0–200.0	20.0	0
03.04	Speed-loop	0.000–10.000s	0.600s	0
03.05	High-point frequency for	P03.02–P00.03(Hz)	10.00Hz	0
03.06	switching Speed-loop output filter	0–8	0	0
03.09	Current loop bandwidth	0–2000Hz	400Hz	0
		6		

unction	Name	Description	Default	Mod
code				
P05.01	Function of S1	0–40 0: No function	0	0
P05.02	Function of S2	1: Up running (FWD)	1	0
P05.03	Function of S3	2: Down running (REV)	2	0
P05.04	Function of S4	3: Running in inspection (EXM)	8	0
P05.05	Function of S5	4: Emergency operation (EMER)	9	0
P05.06	Function of S6	5: Coast to stop (FSTP) 6: Fault reset (RET)	10	C
P05.07	Function of S7	7: External fault (EF)	0	0
P05.08	Function of S8	8: Multi-step speed terminal 1 (MS1)	0	0
P05.09	Function of S9	9: Multi-step speed terminal 2 (MS2) 10: Multi-step speed terminal 3 (MS3) 11: Up forced DEC 1 (UFS1)	0	©
P05.10	Function of S10	12: Up forced DEC 2 (UFS2) 13: Up forced DEC 3 (UFS3) 14: Down forced DEC 1 (DFS1) 15: Down forced DEC 2 (DFS2) 16: Down forced DEC 2 (DFS2) 17: Contactor feedback signal (TB) 18: Brake feedback signal (FB) 19: VFD enabling (ENA) 20: Forced decelerate to stop 21: Emergency mode 22: Motor overheating 23: Main power supply input disconnected (for India) 24: UPS input disconnected by main control (for India) 25: Base lockout 26: Brake feedback signal 2 27: Brake travel feedback 1 28: Brake travel feedback 2 29: Brake travel feedback 3 30: Brake travel feedback 3 31: Reserved 32: Upper door zone 33: Middle door zone 34: Lower door zone 35: High-speed trigger point 36: Medium-speed trigger point 37-40: Reserved 0x000-0x3FF bit0: S1	0	C
P05.13	Input terminal polarity	bit1: S2 bit2: S3 bit3: S4 bit4: S5 bit5: S6 bit6: S7 bit7: S8 bit8: S9 bit9: S10	0x000	C
P05.14	Digital input filter time	0.000–1.000s The function code is used to specify the filter time of S1–S10 terminal sampling. In strong interference cases, increase the value to avoid maloperation.	0.010s	C
P06.01	Y1 output	0: No output	1	C
P06.03	Relay output RO1	1: Lift in operation	0	C
P06.04	Relay output RO2	2: Up operation	7	C
P06.05	Relay output RO3	3: Down running 4: Fault output 5: Running at zero speed 6: Ready for running 7: Brake control 8: Contactor control 9: Any frequency reached 10: Frequency level detection FDT1 output 11: Frequency level detection FDT2 output 12: Brake 2 control 13: Light-load direction detection completed 14: Down as the light-load direction detection result 15: Up as the light-load direction detection result 16: Running 1 (excluding current withdrawal) 17: STO action 18: SPI fault output 19: UPS control signal output (India) 20: Star-shorted output 21: Waiting after autonomous rescue leveling 22-30: Reserved	8	C
				1
P06.06	Output terminal polarity selection	0x00-0x0F bit0: Y1 bit1: R01 bit2: R02 bit3: R03 0-4	0x00	C
P06.06		bit0: Y1 bit1: RO1 bit2: RO2 bit3: RO3	0x00	0

Function code	Name	Description	Default	Modify
		Automatic reset, with triggering fault outpout		
		2: Manual reset, without triggering fault		
		output 3: Automatic reset, without triggering fault		
		output triggered		
P10.00	Multi-step speed 0	0.000m/s-P00.06	0.000m/s	0
P10.01	Multi-step speed 1	0.000m/s-P00.06	0.000m/s 0.000m/s	0
P10.02 P10.03	Multi-step speed 2 Multi-step speed 3	0.000m/s-P00.06 0.000m/s-P00.06	0.000m/s	0
P10.04	Multi-step speed 4		0.000m/s	0
P10.05	Multi-step speed 5	0.000m/s-P00.06	0.000m/s	0
P10.06	Multi-step speed 6	0.000m/s-P00.06	0.000m/s	0
P10.07	Multi-step speed 7 S-curve ACC start	0.000m/s-P00.06	0.000m/s	0
P10.38	segment duration	0.1–360.0s	2.0s	0
P10.39	S-curve ACC end segment duration	0.1 – 360.0s	2.0s	0
P10.40	ACC time	0.1–360.0s	2.0s	0
P10.41	S-curve DEC start	0.1–360.0s	2.0s	0
	segment duration S-curve DEC end	0.1 000.00	2.00	
P10.42	segment duration	0.1 – 360.0s	2.0s	0
P10.43	DEC time	0.1–360.0s	2.0s	0
P10.44	S-curve start segment duration	0.1–360.0s	2.0s	0
F 10.44	during stop	0.1–300.05	2.05	
D40.45	S-curve end	0.4.000.0	0.0	
P10.45	segment duration during stop	0.1–360.0s	2.0s	0
P10.46	Running speed at	0.000m/s-P00.06	0.200m/s	0
1 10.40	maintenance ACC/DEC time at	0.00011//3-1 00.00	0.20011//3	
P10.47	maintenance	0.1–360.0s	4.0s	0
P10.48	Forced DEC time	0.1–360.0s	2.0s	0
P10.49	Emergency running speed	0.001-P00.06(m/s)	0.100m/s	0
D10 50	Emergency	0.1.260.00	20.00	0
P10.50	ACC/DEC time	0.1–360.0s	20.0s	0
		0.1–360.0s During deceleration to stop, when the		
P10.53	DEC time for	speed reached the value set in P01.15,	2.0s	0
1 10.00	creeping to stop	the curve of deceleration to stop switches to those set in P10.44, P10.45, and	2.00	
		P10.53.		
	Frequency			
P10.54	threshold for light-load detection	5.00-20.00Hz	5.00Hz	0
	in open-loop	5100 201001.12	0.000.12	
	control	0x000–0x111		
		Ones place:		
		Disable software input phase loss protection.		
		1: Enable software input phase loss		
		protection.		
P11.00	Protection against	Tens place: 0: Output phase loss protection disabled	0x010	0
	phase loss	1: Protection against output phase loss		
		enabled Hundreds place:		
		0: Output phase loss not enabled before		
		startup		
		Output phase loss enabled before startup	l	
P14.00	Local serial	•		_
	communication	1–247	1	0
		•	1	0
	communication	1–247 0–7 0: 1200 bps	1	0
	communication address	1–247 0–7 0: 1200 bps 1: 2400 bps	1	0
P14.01	communication address Communication	1–247 0–7 0: 1200 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps	1	0
P14.01	communication address	1–247 0–7 0: 1200 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps		
P14.01	communication address Communication	1–247 0–7 0: 1200 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps		
P14.01	communication address Communication	1–247 0–7 0: 1200 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps		
P14.01	communication address Communication	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0-5 0: No check (N, 8, 1) for RTU		
	communication address Communication baud rate	1–247 0–7 0: 1200 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0–5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU	4	0
P14.01	communication address Communication	1–247 0–7 0: 1200 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0–5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU		
	communication address Communication baud rate	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0-5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU	4	0
P14.02	communication address Communication baud rate Data bit check	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0-5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU	1	0
	communication address Communication baud rate	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0-5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU	4	0
P14.02	communication address Communication baud rate Data bit check Communication response delay 485	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0-5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU	4 1 5ms	0
P14.02	communication address Communication baud rate Data bit check Communication response delay 485 communication	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0-5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU	1	0
P14.02	communication address Communication baud rate Data bit check Communication response delay 485	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0–5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 0–200ms 0.0–60.0s	4 1 5ms	0
P14.02	communication address Communication baud rate Data bit check Communication response delay 485 communication	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0–5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 0–200ms 0.0–60.0s 0–2 0: Disable	4 1 5ms	0
P14.02	Communication address Communication baud rate Data bit check Communication response delay 485 communication timeout period	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0–5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 0–200ms 0.0–60.0s	4 1 5ms	0
P14.02	Communication address Communication baud rate Data bit check Communication response delay 485 communication timeout period	1–247 0–7 0: 1200 bps 1: 2400 bps 2: 4800 bps 2: 4800 bps 4: 19200 bps 5: 38400 bps 4: 19200 bps 5: 38400 bps 7: 115200 bps 0–5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 0–200ms 0–2 0: Disable 1: Enable OTA upgrade of MCU 2: Enable USB upgrade of MCU Note: The OTA upgrade of DSP does not	4 1 5ms	0
P14.02 P14.03 P14.04	Communication address Communication baud rate Data bit check Communication response delay 485 communication timeout period	1–247 0–7 0: 1200 bps 1: 2400 bps 1: 24800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps 0–5 0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU 6: Even check (E, 8, 2) for RTU 7: Even check (E, 8, 2) for RTU 8: Even check (E, 8, 2) for RTU 9-200ms 0.0–60.0s 0–2 0: Disable 1: Enable OTA upgrade of MCU 2: Enable USB upgrade of MCU	4 1 5ms 0.0s	0 0

INVI 深圳市英威德电气股份有限公司 SHENZHEN INVIT ELECTRIC CO., LTD.

Description	Default	Modify	Function	Name	Description	Default	Modify
Automatic reset, with triggering fault upout Manual reset, without triggering fault utput Automatic reset, without triggering fault utput triggered 000m/s–P00.06	0.000m/s	0	P14.15	Upgrade program information	0–5 0: Not upgraded 1–2: Reserved 3: Successfully upgraded 4–5: Reserved Note: When upgrading, set P14.15 to 0 before setting P14.10. After successful upgrade, P14.15 is automatically set to 3.	0	0
000m/s=P00.06 000m/s=P00.06 000m/s=P00.06	0.000m/s 0.000m/s 0.000m/s	0	P15.01	CANopen communication address	0–127	2	0
000m/s-P00.06 000m/s-P00.06 000m/s-P00.06	0.000m/s 0.000m/s 0.000m/s	0 0	P15.26	CANopen communication timeout period	0.0–60.0s	5.0s	0
000m/s–P00.06 1–360.0s 1–360.0s 1–360.0s	0.000m/s 2.0s 2.0s 2.0s 2.0s 2.0s	0 0 0	P15.27	CANopen communication baud rate	0-7 0: 1000kbps 1: 800kbps 2: 500kbps 3: 250kbps 4: 125kbps 5: 100kbps 6: 50kbps 7: 20kbps	3	0
1–360.0s 1–360.0s	2.0s 2.0s	0			0–6 0: Incremental encoder 1: Reserved		
1–360.0s	2.0s	0	P20.00 Encoder type selection		2: Sin/Cos encoder without CD signal 3: Endat absolute encoder 4: SSI absolute encoder 5: Sin/Cos encoder with CD signal 6: Reserved	0	0
000m/s-P00.06	0.200m/s	©	P20.01	Encoder pulse number	0–16000	1024	0
1–360.0s	4.0s	0			0x000–0x111 Ones place: AB signal direction 0: Forward		
1–360.0s	2.0s	0			1: Reverse		
001–P00.06(m/s)	0.100m/s	0	P20.02	Encoder direction	Tens place: Reserved Hundreds place: CD/absolute position pole signal direction	0x000	
1–360.0s	20.0s	0			0: Forward 1: Reverse		
1–360.0s uring deceleration to stop, when the oeed reached the value set in P01.15, e curve of deceleration to stop switches those set in P10.44, P10.45, and	2.0s	0	P20.06	Speed ratio between encoder mounting shaft and motor	You need to set the function parameter when the encoder is not installed on the motor shaft and the drive ratio is not 1. Setting range: 0.001–65.535	1.000	0
10.53. 00–20.00Hz	5.00Hz	0	P20.09	Initial angle of Z pulse	Relative electric angle between the encoder Z pulse and the motor pole position. Setting range: 0.00–359.99°	0.00°	0
<000-0x111	3.001 12		P20.10	Pole initial angle	Relative electric angle between the encoder position and the motor pole position. Setting range: 0.00–359.99°	0.00°	0

7 Common faults and solutions

The following lists common VFD faults, of which the possible causes and solutions are

described briefly.						
Fault code	Fault type	Possible cause	Solution			
E1	Inverter unit U-phase protection	IGBT module is damaged.	Increase ACC time. Replace the power unit.			
E2	Inverter unit V-phase protection	Misoperation caused by interference.	Check the drive wires.			
E3	Inverter unit W-phase protection	Drive wires are poorly connected. To-ground short circuit occurs.				
E4	Overcurrent during acceleration	ACC/DEC is too fast. The voltage of the grid is too	Increase ACC/DEC time. Check the input power.			
E5	Overcurrent during deceleration	low. VFD power is too small.	Check whether the load is short			
E6	Overcurrent during constant speed running	Load transient or exception occurred. To-ground short circuit or output phase loss occurred. Strong external interference sources. The overvoltage stall protection is not enabled. Phase loss on output side.	or line-to-line short circuit) or the rotation is not smooth. Check the output wiring. Check whether there is strong interference.			
E7	Overvoltage during acceleration	Exception occurred to input	Check the input nower			
E8	Overvoltage during deceleration	voltage. Large energy feedback.	Check whether load DEC time is too short or the motor starts during rotating.			
E9	Overvoltage during constant speed running	Lack of braking units.				
E10	Bus undervoltage fault	low.	Check the grid input power supply. Check the setting of related function codes.			
E11	Motor overload	incorrectly.	Check the grid voltage. Reset the rated current of the motor. Check the load and adjust the torque boost quantity.			

ault ode	Fault type	Possible cause	Solution
E12	VFD overload	restarted. Grid voltage is too low. Load is too large. The motor power is too large.	Increase ACC time. Avoid restart after stop. Check the grid voltage. Select the VFD with larger power. Select a proper motor.
E13	Phase loss on input side	Phase loss or violent fluctuation occurred on input R, S, T.	Check the input power. Check the installation wiring.
E14	side	asymmetrical).	Check the output wiring. Check the motor and cables.
E15	Rectifier module overheating	Air duct is blocked or fan is damaged.	Ventilate the air duct or replace
E16	Inverter module overheat	Ambient temperature is too high. Long-time overload running.	the fan. Lower the ambient temperature.
E17	External fault	SI external faulty input terminal action.	Check external device input.
E18	RS485 communication fault	address.	Set proper baud rate. Check the wiring of communication interfaces. Set the communication address correctly. Change or replace the wire or improve the anti-interference capability.
E19	Current detection fault	Poor contact of the connector of control board. Hall component is damaged. Exception occurred to amplification circuit.	Check the connector and re-plug. Replace the hall component. Replace the main control board.
E20	Motor autotuning fault	match the VFD capacity. Motor parameter is set improperly. Autotuned parameter settings	Change the VFD model. Set proper motor type and nameplate parameters. Empty the motor load and carry out autotuning again. Check the motor wiring and parameter setup. Check whether the upper limit frequency is larger than 2/3 of the rated frequency.
E21	EEPROM operation fault	Error in reading or writing control parameters. EEPROM damaged.	Press STOP/RST to reset. Replace the main control board.
E22	PID feedback offline fault	PID feedback offline. PID feedback source disappears.	Check PID feedback signal wires. Check PID feedback source.
E23	Braking unit fault	damaged. Resistance of the external braking resistor is small.	Check the braking unit, and replace with new braking pipe. Increase the brake resistance.
E24	Running time reached	The actual running time of the VFD is longer than the internal set running time.	the set running time.
E25	Electronic overload fault	The VFD reports overload pre-alarm according to the setting.	overload pre-alarm points.
E26	Keypad communication fault	Keypad cable connected improperly or disconnected. Keypad cable too long, causing strong interference. Keypad or mainboard communication circuit error.	Check the keypad cable to determine whether a fault occurs. Check for and remove the external interference source. Replace the hardware and seek maintenance services.
E27	Parameter upload error	Keypad cable connected improperly or disconnected. Keypad cable too long, causing strong interference. Keypad or mainboard communication circuit error.	Check for and remove the external interference source.
E28	Parameter download error	improperly or disconnected. Keypad cable too long, causing strong interference. Data storage error occurred to the keypad.	Check for and remove the external interference source. Replace the hardware and seek maintenance services. Re-back up the data on the keypad.
E29	PROFIBUS communication fault	Communication address is not correct. The matching resistance is not set well. The master GSD file is not set up. The peripheral interference is too large.	Check the related settings. Check the surrounding environment, and eliminate interference effects.
E30	Ethernet communication fault	The peripheral interference is too large.	Check the communication mode selection. Check the surrounding
E31	CANopen communication fault	Line contact is poor. The matching resistor is not switched on. Communication baud rates do not match. The peripheral interference is too large.	Check the line: switch on the matching resistor. Set the same baud rate. Check the surrounding environment, and eliminate interference effects.

Goodrive390L Series Lift-dedicated VFD Quick Start Guide

Vt ^{深刻而}	英国院电气股份有限公司 EN INVT ELECTRIC CO., LTD.	Goodrive390L Series Lit	ft-dedicated VFD Quick Start Guide
Fault code	Fault type	Possible cause	Solution
E32	To-ground short-circuit fault 1	to the ground. There is a fault in the current	
E33	To-ground short-circuit fault 2	detection circuit. VFD output is short connected to the ground. There is a fault in the current	Replace the main control board. Check whether the motor wiring is normal. Replace the hall component
	Short-circuit fault 2	detection circuit.	Replace the main control board. Check the load to ensure it is proper and increase the
E34	Speed deviation fault	The load is too heavy or stalled. Phase loss occurs to SM output.	detection time.
E35	Mal-adjustment fault	SM control parameters are set incorrectly. Autotuned parameters are not accurate. The VFD is not connected to the motor.	Check the load and ensure the load is normal.
E36	Electronic underload fault	The VFD reports underload pre-alarm according to the setting.	
E37	Encoder offline fault	Incorrect encoder wiring, causes the failure to get the encoder signal. Incorrect encoder parameter settings.	Check encoder parameter settings.
E38	Encoder reversal fault	Incorrect encoder signal direction.	Set the function code to change the direction or reverse the AB signal wires.
E39	Encoder Z pulse offline fault	The Z-pulse signal cable is not connected.	Check the Z-pulse signal cable.
E41	STO card circuit 1 exception	Circuit 1 of the STO card does not work.	Check whether the STO card is in good condition. Check circuit 1 of the STO card. Check whether the STO card is
E42	STO card circuit 2 exception	Circuit 2 of the STO card does not work.	in good condition. Check circuit 2 of the STO card.
E43	STO internal circuit exception	The internal circuits of the STO card do not work.	Check whether the circuits of the VFD control board are in good condition.
E44	Safety code CRC exception	Exceptions occur in the verification of the safety circuit code.	board is in good condition.
E56	Encoder UVW disconnection	There are no U, V, or W signals or there is interference.	wiring.
E59	Motor over-temperature fault	terminal is valid. The temperature detection resistance is abnormal. Long-time overload running or exception occurred.	Check the wiring of the motor overtemperature input terminal. Check whether the temperature sensor is proper. Check the motor, and perform maintenance on the motor.
E82	PT100 overtemperature	The PT100 sensor obtains inaccurate temperature or it is calibrated inaccurately. Device or ambient temperature is too high.	calibrate the sensor through parameter settings. Lower the device or ambient temperature.
E92	Al1 disconnection	Input voltage of AI1 is too low. AI1 wiring is disconnected.	Connect a 5V or 10mA power source to check if the input is normal. Check the wiring or replace the cables.
E93	Al2 disconnection	Input voltage of Al2 is too low. Al2 wiring is disconnected.	Connect a 5V or 10mA power source to check if the input is normal. Check the wiring or replace the cables.
E96	No upgrade bootloader	Upgrade bootloader is missing.	Contact the manufacturer.
Ξ580	Brake fault	Brake signal and control signal are inconsistent. Feedback terminal signal is interfered.	Check whether the brake is in good condition. Check feedback terminal signal.
E581	Contactor fault	Brake signal and control signal are inconsistent. Feedback terminal signal is interfered.	Check whether the contactor is in good condition. Check feedback terminal signal.
=582	No enabling signal	Enabling signal is missing during operation.	timing and connection.
= 583	Braking pipe overcurrent fault	unmatched.	Check the resistance of braking pipe.
E584	AM output without current	The AM is not connected to the motor cable or phase loss occurs.	
Ξ585	No absolute position signal	The absolute-value encoder position signal is lost. The encoder is interfered.	check whether the VFD and encoder are grounded.
≣586	Electronic star shorting fault	during star shorting.	shorting. Check whether the current and speed are normal during star shorting.
Ξ587	Dual-CPU communication fault 1	DSP communication is disconnected in dual CPU structure.	

Goodrive390L Series Lift-dedicated VFD Quick Start Guide invt ﷺ Invt ﷺ Start Guide

Fault code	Fault type	Possible cause	Solution
E588	Dual-CPU communication fault 2	MCU communication is disconnected in dual CPU structure.	Check the MCU communication wiring.
E589	Dual-CPU communication fault 3	Communication disconnected in dual CPU structure.	Check the communication wiring of dual CPU structure.
E590	Sin/Cos encoder CD disconnection	encoder is lost.	Check the wiring of Sin/Cos encoder.
E591	Brake 2 fault	signal for brake 2. Feedback terminal signal is interfered.	Check whether the brake 2 is in good condition. Check feedback terminal signal.
E592	Brake travel 1 fault	inconsistent with the brake control signal.	Check feedback terminal signal
E593	Brake travel 2 fault	The feedback from travel 2 is inconsistent with the brake control signal.	
E594	Brake travel 3 fault	The feedback from travel 3 is inconsistent with the brake control signal.	
E595	Brake travel 4 fault	The feedback from travel 4 is inconsistent with the brake control signal.	
E596	No multi-step speed signal	During multi-step speed mode operation, no speed is set.	Check the multi-step speed settings. Check the multi-step speed terminal signals.
E597	Shaft auto-tuning fault	During the shaft auto-tuning process, the floor detection exceeds the set total number of floors.	Check the total floor settings. Check door zone signals and forced deceleration signals.
E598	False activation of forced deceleration	is incorrect.	Check the forced deceleration signal. Perform maintenance reset check to the bottom floor.
E599	Reverse running height fault	The motor running direction is opposite to the detected height change.	Check the running direction and height change.
E600	PT100 disconnection	PT100 sensor wiring is disconnected.	Check if the wiring of PT100 sensor is normal.

Goodrive390L Series Lift-dedicated VFD Quick Start Guide

8 More information

Please contact us for any information about the product. It is necessary to provide the product model and serial number during consultation. To obtain more information, you can:

- Contact INVT local office.
- Visit www.invt.com or scan the following QR code of INVT official website.



• Scan the e-manual QR code to view the full version of the e-manual.





Manual information may be subject to change without prior notice. 202411 (V1.1)