

# **Operation Manual**

## **Goodrive350 IP55** High-ingress Protection Series VFD



SHENZHEN INVT ELECTRIC CO., LTD.

Change history

No.	Change description		Change date
1	First release	V1.0	September 2020
2	<ul> <li>Updated the preface.</li> <li>Updated the content of function codes.</li> <li>Added the profile and mounting dimensions of 6 power models.</li> </ul>	V1.1	January 2021
3	Updated the section 3.6.	V1.2	April 2021
4	<ul> <li>Added section 2.7.</li> <li>Updated section 3.3.</li> <li>Updated the name of PE terminal in section 4.3.2 and deleted the duplicated COM terminal record in section 4.4.1.</li> <li>Updated the keypad diagrams and content in Chapter 5.</li> <li>Updated the function codes in Chapter 5 and Chapter 6.</li> <li>Updated the table in section 7.5.1.</li> <li>Added IO expansion 2 (EC-IO502-00), Ethernet/IP communication card (EC-TX510), Modbus TCP communication card (EC-TX515), 24V simplified PG card (EC-PG507-24), GPRS card (EC-IC501-2) in Appendix A.</li> <li>Updated the data in Table D-4.</li> <li>Changed the short connection between PW and +24V terminals to PW and COM terminals the in Figure 4-15 and Figure 4-16.</li> <li>Added Appendix G.</li> </ul>	V1.3	March 2022
5	<ul> <li>Added information about -NS models (with EMC filter board and input switch removed) in section 3.5, 3.6; 4.3.2.</li> <li>Added function codes P06.23–P06.26, P17.57–P17.58; updated function code, including P11.08 (value 3, 4 are added for the ones place), P28.25.</li> <li>In Appendix A, added content of 4G expansion card, combine CANopen communication card and CAN master/slave control card to CAN multi-protocol communication card EC-TX505C, updated EC-PG505-24 card to EC-PG505-24B.</li> <li>Changed "IEC 60439-1" to "IEC 61439-1" in Appendix B.</li> <li>Updated dimension information in Appendix C and added dimension information for -NS models.</li> <li>Updated tables in Appendix D and Appendix G.</li> </ul>	V1.4	September 2022

Change history

No.	Change description	Version	Change date
<b>No.</b>	<ul> <li>Change description</li> <li>Revised the nameplate diagram in section 3.4.</li> <li>Updated fuse symbols in all circuit diagrams.</li> <li>Modified the U-shaped jumper position in section 4.4.2, and added cautionary notes.</li> <li>Added a selection table for the flat keypad cable in section 5.2.</li> <li>Updated the diagram for sections 5.5.2, 5.5.5, 5.5.6, 5.5.14, 5.5.15, and 5.5.16.</li> <li>Adjusted the depiction in section 5.5.8.</li> <li>Updated the description for function codes P05.01– P05.06 option 43, revised the explanations for P00.03 and P06.05, updated the depiction for P09.08, and add cautionary notes for P18.00.</li> <li>Modified the UPE fault explanation in section 7.5.1.</li> <li>Removed the Modbus RTU command code: 08H, diagnostic function.</li> <li>Added the expansion card order number and updated the card models in Appendix A: removed EC-TX504, added EC-TX510B; and updated EC-TX505D, EC-TX509C.</li> </ul>	Version V1.5	Change date
	<ul> <li>EC-TX510B; and updated EC-TX503, EC-TX505C, EC-TX509 to EC-TX503D, EC-TX505D, EC-TX509C.</li> <li>Updated the indicators and descriptions in sections A.7.4 and A.7.5.</li> <li>Updated the diagram and descriptions in section D.2, modified sections D.6 and D.7.</li> <li>Revised the data in Table D-4.</li> </ul>		

## Preface

Thank you for choosing Goodrive350 IP55 high-ingress protection series variable-frequency drive (VFD).

If not otherwise specified in this manual, the VFD always indicates Goodrive350 IP55 series VFD, which is a high-performance and multipurpose VFD with the capability to drive both synchronous motors and asynchronous motors, and support torque control, speed control, and position control. Using the most advanced vector control technology in the world and the latest digital processor dedicated for motor control, the VFD has strengthened the reliability and environment adaptability and adapted customized and industrial design to improve the functions, make the application more flexible, and optimize the performance.

To meet the basic needs of customers, VFDs of power range from 4 to 110 kW are developed for Goodrive350 IP55 high-ingress protection series VFDs. In order to meet diversified customer demands, the VFD provides abundant expansion cards including programmable expansion card, PG card, communication card and I/O expansion card to achieve various functions as needed. Each VFD can be installed with three expansion cards at most.

The programmable expansion card adopts the mainstream development environment for customers to carry out secondary development easily, fulfilling varied customized needs and reducing customer cost.

The PG card supports a variety of encoders including incremental encoders and resolver-type encoders. In addition, it also supports pulse reference and frequency-division output. The PG card adopts digital filter technology to improve EMC performance and to realize stable transmission of the encoder signal over a long distance. It is equipped with the encoder disconnection detection function to contain the impact of system faults.

The VFD supports multiple kinds of popular communication modes to realize complicated system solutions. It can be connected to the internet with the optional wireless communication card, by which you can monitor the VFD state anywhere any time through mobile APP.

The VFD uses high power density design. Some power ranges carry built-in DC reactor and braking unit to save installation space. Through overall EMC design, it can satisfy the low noise and low electromagnetic interference requirements to cope with challenging grid, temperature, humidity and dust conditions, thus greatly improving product reliability.

This manual instructs you how to install, wire, set parameters for, diagnose and remove faults for, and maintain the VFD, and also lists related precautions. Before installing the VFD, read through this manual carefully to ensure the proper installation and running with the excellent performance and powerful functions into full play.

If the end user is a military unit or the product is used for weapon manufacturing, please comply with relevant export control regulations in the Foreign Trade Law of the People's Republic of China, and complete necessary formalities.

The manual is subject to change without prior notice.

## Contents

1 Safety precautions	1
1.1 What this chapter contains	1
1.2 Safety definition	1
1.3 Warning symbols	1
1.4 Safety guidelines	2
1.4.1 Delivery and installation	2
1.4.2 Commissioning and running	3
1.4.3 Maintenance and component replacement	4
1.4.4 Disposal	4
2 Quick startup	5
2.1 What this chapter contains	5
2.2 Unpacking inspection	5
2.3 Checking before use	5
2.4 Environment checking	5
2.5 Checking after installation	6
2.6 Basic commissioning	7
2.7 Safety standard related data	7
3 Product overview	1
3.1 What this chapter contains	1
3.2 Basic principles	1
3.3 Product specifications	2
3.4 Product nameplate	4
3.5 Model designation code	5
3.6 Product ratings	5
3.7 Structure	6
4 Installation guidelines	8
4.1 What this chapter contains	8
4.2 Mechanical installation	8
4.2.1 Installation environment	8
4.2.2 Installation direction	9
4.2.3 Installation method1	0
4.2.4 Installing one unit1	0
4.2.5 Multiple-product installation1	1
4.2.6 Vertical installation1	2
4.2.7 Tilted installation1	3
4.3 Standard wiring of the main circuit1	4
4.3.1 Main circuit wiring diagrams1	4
4.3.2 Main circuit terminal diagram1	5

	4.3.3 Wiring procedure of main circuit terminals	18
	4.4 Standard wiring of the control circuit	19
	4.4.1 Wiring diagram of basic control circuit	19
	4.4.2 Input/output signal connection diagram	21
	4.5 Wiring protection	22
	4.5.1 Protecting the VFD and input power cable in case of short circuit	22
	4.5.2 Protecting the motor and motor cable in case of short circuit	23
	4.5.3 Protecting the motor against thermal overload	23
	4.5.4 Bypass connection	23
5 I	Basic operation guidelines	24
	5.1 What this chapter contains	24
	5.2 Keypad introduction	24
	5.3 Keypad display	27
	5.3.1 Displaying stopped-state parameters	27
	5.3.2 Displaying running-state parameters	28
	5.3.3 Displaying fault alarms	29
	5.4 Operation procedure	29
	5.4.1 Entering/Exiting menus	29
	5.4.2 Editing list	34
	5.4.3 Adding parameters to the parameter list displayed in stopped/running state	35
	5.4.4 Adding parameters to the user defined parameter setting list	36
	5.4.5 Editing user defined parameters	36
	5.4.6 Editing parameters in parameter groups	37
	5.4.7 Monitoring states	37
	5.4.8 Autotuning motor parameters	38
	5.4.9 Parameter backup	39
	5.4.10 System settings	39
	5.4.11 Power-on guiding settings	39
	5.5 Basic operation description	40
	5.5.1 What this section describes	40
	5.5.2 Common commissioning procedure	41
	5.5.3 Vector control	44
	5.5.3 Vector control 5.5.4 Space voltage vector control mode	44 50
	5.5.3 Vector control 5.5.4 Space voltage vector control mode 5.5.5 Torque control	44 50 58
	5.5.3 Vector control 5.5.4 Space voltage vector control mode 5.5.5 Torque control 5.5.6 Motor parameters	44 50 58 61
	<ul> <li>5.5.3 Vector control</li> <li>5.5.4 Space voltage vector control mode</li> <li>5.5.5 Torque control</li> <li>5.5.6 Motor parameters</li> <li>5.5.7 Start/stop control</li> </ul>	44 50 58 61 66
	<ul> <li>5.5.3 Vector control</li> <li>5.5.4 Space voltage vector control mode</li> <li>5.5.5 Torque control</li> <li>5.5.6 Motor parameters</li> <li>5.5.7 Start/stop control</li> <li>5.5.8 Frequency setting</li> </ul>	44 50 58 61 66 71
	<ul> <li>5.5.3 Vector control</li> <li>5.5.4 Space voltage vector control mode</li> <li>5.5.5 Torque control</li> <li>5.5.6 Motor parameters</li> <li>5.5.7 Start/stop control</li> <li>5.5.8 Frequency setting</li> <li>5.5.9 Analog input</li> </ul>	44 50 61 66 71 75
	<ul> <li>5.5.3 Vector control</li> <li>5.5.4 Space voltage vector control mode</li> <li>5.5.5 Torque control</li> <li>5.5.6 Motor parameters</li> <li>5.5.7 Start/stop control</li> <li>5.5.8 Frequency setting</li> <li>5.5.9 Analog input</li> <li>5.5.10 Analog output</li> </ul>	44 50 58 61 66 71 75 78

5.5.12 Digital output	91
5.5.13 Simple PLC	
5.5.14 Multi-step speed running	
5.5.15 PID control	
5.5.16 Run at wobbling frequency	
5.5.17 Local encoder input	
5.5.18 Commissioning procedures for closed-loop control, position c	ontrol and spindle
positioning	
5.5.19 Fault handling	115
5.5.20 Tension control solutions	119
6 Function parameter list	
6.1 What this chapter contains	
6.2 Function parameter list	
Group P00—Basic functions	
Group P01—Start and stop control	
Group P02—Parameters of motor 1	
Group P03—Vector control of motor 1	
Group P04—V/F control	145
Group P05—Input terminal functions	
Group P06—Output terminal functions	
Group P07—Human-machine interface	
Group P08—Enhanced functions	
Group P09—PID control	
Group P10—Simple PLC and multi-step speed control	
Group P11—Protection parameters	
Group P12—Parameters of motor 2	
Group P13—SM control	
Group P14—Serial communication	
Group P15—Communication expansion card 1 functions	
Group P16—Communication expansion card 2 functions	
Group P17—Status viewing	214
Group P18—Status viewing in closed-loop control	219
Group P19—Expansion card status viewing	
Group P20—Encoder of motor 1	
Group P21—Position control	
Group P22—Spindle positioning	
Group P23—Vector control of motor 2	
Group P24—Encoder of motor 2	
Group P25—I/O card input functions	
Group P26—I/O card output functions	

Group P27—Programmable expansion card functions	248
Group P28—Master/slave control	251
Group P90—Tension control	255
Group P91—Tension control in torque mode	259
Group P92—Tension control optimization functions	262
Group P93—Tension control status viewing	263
7 Troubleshooting	266
7.1 What this chapter contains	266
7.2 Indications of alarms and faults	266
7.3 Fault reset	266
7.4 Fault history	266
7.5 Faults and solutions	266
7.5.1 Faults and solutions	266
7.5.2 Other status	275
7.6 Analysis on common faults	275
7.6.1 Motor fails to work	275
7.6.2 Motor vibrates	276
7.6.3 Overvoltage	277
7.6.4 Undervoltage	277
7.6.5 Motor overheating	278
7.6.6 VFD overheating	279
7.6.7 Motor stalls during ACC	280
7.6.8 Overcurrent	281
7.7 Countermeasures on common interference	281
7.7.1 Interference on meter switches and sensors	281
7.7.2 Interference on RS485 communication	283
7.7.3 Failure to stop and indicator shimmering due to motor cable coupling	284
7.7.4 Leakage current and interference on RCD	284
7.7.5 Live device chassis	285
8 Maintenance	287
8.1 What this chapter contains	287
8.2 Periodical inspection	287
8.3 Cooling fan	289
8.4 Capacitor	290
8.4.1 Capacitor reforming	290
8.4.2 Electrolytic capacitor replacement	292
8.5 Power cable	292
9 Communication protocol	293
9.1 What this chapter contains	293
9.2 Modbus protocol introduction	293

9 3 Application of Modbus	203
9.3.1 RS485	203
9.3.2 RTI I mode	296
9 4 RTU command code and communication data	299
9.4.1 Command code 03H, reading N words (continuously up to 16 words)	299
9 4 2 Command code 06H, writing a word	
9 4 3 Command code 10H, continuous writing	
9 4 4 Data address definition	303
9 4 5 Fieldbus scale	307
9.4.6 Error message response	
9.4.7 Read/Write operation examples.	
9.5 Common communication faults	
Appendix A Expansion card	
A.1 Model definition	
A.2 Dimensions and installation	
A.3 Wiring	
A.4 I/O expansion cards	
A.4.1 I/O expansion card 1 (EC-IO501-00)	
A.4.2 IO expansion card 2 (EC-IO502-00)	
A.5 Programmable extension card (EC-PC502-00)	
A.6 Communication cards	
A.6.1 Bluetooth communication card (EC-TX501) and WIFI communication card	(EC-TX502)
A.6.2 PROFIBUS-DP communication card (EC-TX503D)	
A.6.3 CAN multi-protocol communication card (EC-TX505D)	
A.6.4 PROFINET communication card (EC-TX509C)	
A.6.5 EtherNet IP multi-protocol communication card (EC-TX510B)	
A.7 PG extension cards	
A.7.1 Sin/Cos PG card (EC-PG502)	
A.7.2 UVW incremental PG card (EC-PG503-05)	
A.7.3 Resolver PG card (EC-PG504-00)	
A.7.4 Multi-function incremental PG card (EC-PG505-12)	353
A.7.5 24V multi-function incremental PG card (EC-PG505-24B)	
A.7.6 Simplified incremental PG card (EC-PG507-12)	359
A.7.7 24V simplified incremental PG card (EC-PG507-24)	
A.8 IoT card	
A.8.1 GPRS IoT card (EC-IC501-2)	
A.8.2 4G card (EC-IC502-2-CN, EC-IC502-2-EU, EC-IC502-2-LA)	
Appendix B Technical data	
B.1 What this chapter contains	

	B.2 Derated application	367
	B.2.1 Capacity	367
	B.2.2 Derating	367
	B.3 Grid specifications	368
	B.4 Motor connection data	368
	B.4.1 EMC compatibility and motor cable length	369
	B.5 Application standards	369
	B.5.1 CE marking	370
	B.5.2 EMC compliance declaration	370
	B.6 EMC regulations	370
	B.6.1 VFD category of C2	370
	B.6.2 VFD category of C3	371
Ap	pendix C Dimension drawings	372
	C.1 What this chapter contains	372
	C.2 VFD structure	372
	C.3 VFD dimension	373
	C.3.1 Wall-mounting dimensions	373
	C.3.2 Flange mounting dimensions	375
Ap	pendix D Optional peripheral accessories	377
	D.1 What this chapter contains	377
	D.2 External wiring	377
	D.3 Power supply	379
	D.4 Cable	379
	D.4.1 Power cable	379
	D.4.2 Control cable	380
	D.4.3 Cable arrangement	385
	D.4.4 Insulation inspection	385
	D.5 Breaker and electromagnetic contactor	386
	D.6 Harmonic filter	387
	D.7 EMC filter	389
	D.8 Braking system	391
	D.8.1 Braking component selection	391
	D.8.2 Braking resistor cable selection	394
	D.8.3 Braking resistor installation	394
Ap	pendix E STO function description	396
	E.1 STO function logic table	396
	E 2 STO channel delay description	307
	E.2 STO channel delay description	001
	E.3 STO function installation checklist	397
Ap	E.3 STO function installation checklist	397 399

F.2 Feedback on INVT VFD manuals	399
F.3 Documents on the Internet	399

## **1 Safety precautions**

## 1.1 What this chapter contains

Read this manual carefully and follow all safety precautions before moving, installing, operating and servicing the product. Otherwise, equipment damage or physical injury or death may be caused.

We shall not be liable or responsible for any equipment damage or physical injury or death caused due to your or your customers' failure to follow the safety precautions.

## 1.2 Safety definition

Danger: Severe personal injury or even death can result if related requirements are not followed.

Warning: Personal injury or equipment damage can result if related requirements are not followed.

Note: Actions taken to ensure proper running.

**Trained and qualified professionals**: People operating the equipment must have received professional electrical and safety training and obtained the certificates, and must be familiar with all steps and requirements of equipment installing, commissioning, running and maintaining and capable to prevent any emergencies.

## 1.3 Warning symbols

Warnings caution you about conditions that can result in severe injury or death and/or equipment damage and advice on how to prevent dangers. The following table lists the warning symbols in this manual.

Symbol	Name	Description	Abbreviation
Danger	Danger	Severe personal injury or even death can result if related requirements are not followed.	4
	Warning	Personal injury or equipment damage can result if related requirements are not followed.	
Forbid	Electrostatic sensitive	The PCBA may be damaged if related requirements are not followed.	
Hot	Hot sides	Do not touch. The VFD pedestal may become hot.	
<u> ()</u> 5 min	Electric shock	As high voltage still presents in the bus capacitor after power off, wait for at least five minutes (or 15 min / 25 min, depending on	5 min

Symbol	Name	Description	Abbreviation
		the warning symbols on the machine) after	
		power off to prevent electric shock.	
	Read	Read the operation manual before operating	
	manual	the equipment.	
Note	Note	Actions taken to ensure proper running.	Note

## 1.4 Safety guidelines

Â	<ul> <li>C</li> <li>C</li></ul>	Only trained and operations. Oo not perform w s applied. Ensur viring or inspecti he DC bus volta ollowing.	qualified professionals are al riring, inspection or component e all the input power supplies on, and wait for at least the ti ge is less than 36V. The minin	lowed to carry out related nt replacement when power sup have been disconnected before me designated on the VFD or u mum waiting time is listed in the	oply e ntil
			VFD model	Minimum waiting time	
		380V	004G/5R5P-110G	5 minutes	
	Do not refit the VFD unless authorized; otherwise fire, electric shock or other injury may result.				
	The base may become hot when the machine is running. Do not touch. Otherwise, you may get burnt.				
	The e	electrical parts a surements to pre	nd components inside the VF vent electrostatic discharge v	D are electrostatic sensitive. Ta when performing related operation	ke ons.

## 1.4.1 Delivery and installation

	•	Do not install the VFD on inflammables. In addition, prevent the VFD from
		contacting or adhering to inflammables.
	•	Connect the optional braking parts (such as braking resistors, braking units or
		feedback units) according to the wiring diagrams.
	•	Do not run the VFD if it is damaged or incomplete.
	•	Do not contact the VFD with damp objects or body parts. Otherwise, electric
		shock may result.

Note:

 Select appropriate tools for VFD delivery and installation to ensure the safe and proper running and avoid physical injury or death. To ensure personal safety, take mechanical protective measures like wearing safety shoes and working uniforms.

- Protect the VFD against physical shock or vibration during the delivery and installation.
- Do not carry the product only by its front cover as the cover may fall off.
- The installation site must be away from children and other public places.
- Use the VFD in proper environments. (For details, see section 4.2.1 "Installation environment".)
- Prevent the screws, cables and other conductive parts from falling into the VFD.
- As leakage current of the drive during running may exceed 3.5mA, ground properly and ensure the grounding resistance is less than 10Ω. The conductivity of PE grounding conductor is the same as that of the phase conductor. The cross-sectional area of the PE grounding conductor for 30kW and higher models can be slightly smaller than the recommended cross-sectional area value.
- R, S and T are the power input terminals, and U, V and W are the output motor terminals. Connect the input power cables and motor cables properly; otherwise, damage to the VFD may occur.

#### 1.4.2 Commissioning and running

	•	Cut off all power supplies connected to the VFD before terminal wiring, and wait						
		for at least the time designated on the VFD after disconnecting the power						
		supplies.						
	•	High voltage presents inside the VFD during running. Do not carry out any						
		operation on the VFD during running except for keypad setup.						
	•	The VFD may start up by itself when P01.21 is set to 1 (restart after power off). Do						
	not get close to the VFD and motor.							
	•	The VFD cannot be used as an "Emergency-stop device".						
	•	The VFD cannot act as an emergency brake for the motor; it is a must to install a						
		mechanical braking device.						
^	•	During driving a permanent magnet SM, besides above-mentioned items, the						
14	following work must be done before installation and maintenance:							
		<ul> <li>All input power supplies have been disconnected, including the main power</li> </ul>						
		and control power.						
		$\diamond$ The permanent-magnet SM has been stopped, and the voltage on output						
		end of the VFD is lower than 36V.						
		$\diamond$ After the permanent-magnet SM has stopped, wait for at least the time						
		designated on the VFD, and ensure the voltage between + and - is lower						
		than 36V.						
		$\diamond$ During operation, it is a must to ensure the permanent-magnet SM cannot						
		run again by the action of external load; it is recommended to install an						
		effective external braking device or cut off the direct electrical connection						
		between the permanent-magnet SM and the VFD.						

#### Note:

- Do not switch on or switch off the input power supplies of the VFD frequently.
- If the VFD has been stored without use for a long time, perform capacitor reforming (as described in chapter 8 "Maintenance"), inspection and pilot run for the VFD before the reuse.
- Close the VFD front cover before running; otherwise, electric shock may occur.

#### 1.4.3 Maintenance and component replacement



#### Note:

- Use proper torque to tighten screws.
- During maintenance and component replacement, keep the VFD and its parts and components away from combustible materials and ensure they have no combustible materials adhered.
- Do not carry out insulation voltage-endurance test on the VFD, or measure the control circuits of the VFD with a megohmmeter.
- During maintenance and component replacement, take proper anti-static measures on the VFD and its internal parts.

#### 1.4.4 Disposal

	The VFD contains heavy metals. Dispose of a scrap VFD as industrial waste.
X	Dispose of a scrap product separately at an appropriate collection point but not place it in the normal waste stream.

## 2 Quick startup

## 2.1 What this chapter contains

This chapter introduces the basic installation and commissioning rules that you need to follow to realize quick installation and commissioning.

## 2.2 Unpacking inspection

Check the following after receiving the product.

- Whether the packing box is damaged or dampened. If any problems are found, contact the local INVT dealer or office.
- Whether the model identifier on the exterior surface of the packing box is consistent with the purchased model. If any problems are found, contact the local INVT dealer or office.
- Whether the interior surface of the packing box is abnormal, for example, in wet condition, or whether the enclosure of the VFD is damaged or cracked. If any problems are found, contact the local INVT dealer or office.
- 4. Whether the product nameplate is consistent with the model identifier on the exterior surface of the packing box. If any problems are found, contact the local INVT dealer or office.
- Whether the accessories (including the manual, keypad, and expansion card) inside the packing box are complete. If any problems are found, contact the local INVT dealer or office.

## 2.3 Checking before use

Check the following before using the VFD.

- 1. Mechanical type of the load to be driven by the VFD to verify whether the VFD will be overloaded during work. Whether the power class of the product needs to be increased.
- 2. Whether the actual running current of the motor is less than the rated current of the product.
- 3. Whether the control accuracy required by the load is the same as that is provided by the VFD.
- 4. Whether the grid voltage is consistent with the rated voltage of the VFD.
- 5. Check whether expansion cards are needed for selected functions.

## 2.4 Environment checking

Check the following before installing the VFD:

Whether the actual ambient temperature exceeds 40°C. When the temperature exceeds 40°C, derate 1% for every increase of 1°C. Do not use the VFD when the ambient temperature exceeds 50°C.

**Note:** When the VFD is built in a cabinet, the ambient temperature is the temperature of air in the cabinet.

 Whether the actual ambient temperature is lower than -10°C. If the temperature is lower than -10°C, use heating devices.

**Note:** When the VFD is built in a cabinet, the ambient temperature is the temperature of air in the cabinet.

- Whether the altitude of the application site exceeds 1000m. When the altitude exceeds 1000m, derate by 1% for each increase of 100m. When the altitude exceeds 3000m, consult the local INVT dealer or office for details.
- Whether the actual environment humidity exceeds 90% or condensation occurs. If yes, take additional protective measures.
- Whether there is direct sunlight or biological invasion in the environment where the VFD is to be used. If yes, take additional protective measures.
- 6. Whether there is dust or inflammable and explosive gas in the environment where the product is to be used. If yes, take additional protective measures.

## 2.5 Checking after installation

Check the following after the VFD installation is complete.

- 1. Whether the input power cables and motor cables meet the current-carrying capacity requirements of the actual load.
- Whether correct accessories are selected for the VFD, the accessories are correctly and properly installed, and the installation cables meet the capacity carrying requirements of all components (including the reactor, input filter, output reactor, output filter, DC reactor, braking unit and braking resistor).
- Whether the product is installed on non-flammable materials and the heat-radiating accessories (such as the reactor and braking resistor) are away from flammable materials.
- 4. Whether all the control cables and power cables are separately routed and whether EMC specification requirements are taken into full account during the routing.
- Whether all grounding systems are properly grounded according to the requirements of the VFD.
- 6. Whether all the installation clearances of the VFD meet the requirements in the manual.
- Whether the installation mode conforms to the instructions in the operation manual. Vertical installation is recommended whenever possible.
- Whether the external connection terminals of the product are tightly fastened and the torque is appropriate.
- Whether there are screws, cables, or other conductive items left in the VFD. If yes, get them out.

## 2.6 Basic commissioning

Complete the basic commissioning as follows before the actual use of the VFD:

1.	According to the actual motor parameters, select the motor type, set motor parameters, and
	select the VFD control mode.
2.	Check whether autotuning is required. If possible, de-couple the VFD from the motor load to
	start dynamic parameter autotuning. If the VFD cannot be de-coupled from the load, perform
	static autotuning.
3.	Adjust the ACC/DEC time according to the actual work condition of the load.
4.	Perform device commissioning by means of jogging and check whether the motor rotational

- Perform device commissioning by means of jogging and check whether the motor rotational direction is correct. If not, change the rotation direction by swapping any two phase wires of the motor.
- 5. Set all control parameters and then perform actual run.

## 2.7 Safety standard related data

	IEC/EN 61508 (Class A system)							ISC	0 13849*	*
SIL	PFH	HFT	SFF	λdu	λdd	PTI*	PL	CCF	DC	Category
2	8.73x10 <sup>-10</sup>	1	71.23%	1.79x10 <sup>-9</sup>	0	1 year	d	57	60%	3

\* PTI: Proof test interval

\*\* Depends on the classification defined on the EN ISO 13849-1.

## **3 Product overview**

#### 3.1 What this chapter contains

This chapter mainly introduces the operation principles, product features, layouts, nameplates and model designation rules.

#### 3.2 Basic principles

The VFD is used to control asynchronous AC induction motors and permanent-magnet synchronous motors. The following lists the main circuit diagrams of different VFD models. The rectifier converts 3PH AC voltage into DC voltage, and the capacitor bank of intermediate circuit stabilizes the DC voltage. The inverter converts DC voltage into AC voltage that can be used by an AC motor. When the circuit voltage exceeds the maximum limit value, external braking resistor will be connected to intermediate DC circuit to consume the feedback energy.

Figure 3-1 Main circuit diagram for 015G/018P and lower VFD models



Figure 3-2 Main circuit diagram for 018G/022P-110G (inclusive) VFD models



Note:

- The VFDs of 018G/022P–110G (inclusive) models are equipped with built-in DC reactors.
- The 037G/045P and lower VFD models carry built-in braking units as a standard configuration. The models with built-in braking units can also be connected to external braking resistors. Braking resistors are optional parts.

 The 045G/055P–110G VFD models can be configured with optional built-in braking units. After a built-in braking unit is configured for the VFD, the VFD model is added with a suffix "-B", for example, GD350-045G/055P-45-AS-B.

## 3.3 Product specifications

Fur	oction description	Specifications			
Power input	Input voltage (V)	-4 model: 3PH 380V (-15%)–440V (+10%)			
	Input current (A)	See section 3.6 Product ratings.			
	Input frequency (Hz)	50Hz or 60Hz; Allowed range: 47–63Hz			
	Output voltage (V)	0–Input voltage (V)			
Power	Output current (A)	See section 3.6 Product ratings.			
output	Output power (kW)	See section 3.6 Product ratings.			
	Output frequency (Hz)	0–599Hz			
		Space voltage vector control mode			
	Control mode	Sensorless vector control (SVC) mode			
		Feedback vector control (FVC) mode			
	Motor type	Asynchronous motor (AM) and permanent magnetic			
	Motor type	synchronous motor (SM)			
	Speed ratio	For asynchronous motor (AM): 1:200 (SVC)			
	Speed Tallo	For SMs: 1: 20 (SVC); 1: 1000 (FVC)			
	Speed control accuracy	±0.2% (SVC)			
	Speed control accuracy	±0.02% (FVC)			
	Speed fluctuation	±0.3% (SVC)			
Technical		<20ms (SVC)			
control	loique response	<10ms (FVC)			
performance	Torque control accuracy	10% (SVC)			
		5% (FVC)			
		For AMs: 0.25Hz/150% (SVC)			
	Starting torque	For SMs: 2.5Hz/150% (SVC)			
		0Hz/200% (FVC)			
		G type:			
		150% of the rated current for 1 minute;			
		180% of the rated current for 10s;			
		200% of the rated current for 1s;			
		P type:			
		120% of the rated current for 1 minute.			
Running		Settings can be implemented through digital, analog,			
control	Frequency setting method	pulse frequency, multi-step speed running, simple			
performance		PLC, PID, Modbus communication, PROFIBUS			

Fu	nction description	Specifications		
		communication and so on.		
		Settings can be combined and the setting channels		
		can be switched.		
	Automatic voltage	The output voltage can be kept constant although the		
	regulation	grid voltage changes.		
		More than 30 protection functions, such as protection		
	Fault protection	against overcurrent, overvoltage, undervoltage,		
		overtemperature, phase loss, and overload		
	-	Used to implement impact-free smooth startup for		
	Speed tracking restart	rotating motors		
	Retension at transient	Keeps running with regenerative energy when the grid		
	voltage drop	transiently drops.		
		Supports two groups of motor parameters to control		
	Motor switchover	motor switchover.		
	Terminal analog input			
	resolution	No more than 20mV		
	Terminal digital input			
	resolution	No more than 2ms		
	Analog input	2 channel		
		AI1: 0–10V/0–20mA, AI2: -10–10V		
		1 channel		
	Analog output	AO1: 0–10V/0–20mA		
		Four regular inputs; max. frequency: 1kHz; internal		
		impedance: 3.3kΩ		
Peripheral	Digital input	Two high-speed inputs; max. frequency: 50kHz;		
interface		supporting quadrature encoder input; with speed		
		measurement function		
	Digital output	One high-speed pulse output; max. frequency: 50kHz		
		One Y terminal open collector output		
		Two programmable relay outputs		
	Relay output	RO1A: NO; RO1B: NC; RO1C: common		
	itelay output	RO2A: NO; RO2B: NC; RO2C: common		
		Contact capacity: 3A/AC250V, 1A/DC30V		
		SLOT1, SLOT2, and SLOT3		
	Extended interfaces	Supporting PG cards, programmable expansion cards,		
		communication cards, I/O cards and so on		
	Installation method	Wall mounting or flange installation		
Other	Temperature of running	-10°C – 50°C. Derating is required when the ambient		
	environment	temperature exceeds 40°C.		

Fur	nction description	Specifications
	Ingress protection (IP) rating	IP55
	Cooling method	Forced air cooling
		Standard built-in part for 380V 37kW and lower VFD
	Braking unit	Optional built-in part for the 045G/055P–110G VFD
	Draking unit	models. For models with a built-in braking unit
		configured, a suffix "-B" is added to the model, for
		example, GD350-045G/055P-45-AS-B.
	EMC filter	Conducted emissions of all models meet the
		requirements of C3 in the IEC/EN 61800-3 standard.
		The -AS models offers the 30m motor cable, meeting
		the C3 requirements.
		Optional external filters can be used to meet
		IEC61800-3 C2.
		Note: It is required to observe the EMC compliance
		required by the appendix of the manual. The motor and
		motor cables shall be selected based on technical
		requirements specified in the appendix of the manual.
	STO certification level	Meet the SIL2 level

## 3.4 Product nameplate



invt(	
Model: GD350-5R5G/7R5P-45-AS	IP55
Power(Output): 5.5kW/7.5kW	
Input: AC 3PH 380V-440V 19.5A/23A 47	Hz-63Hz
Output: AC 3PH 0V-Uinput 14A/17A 0Hz	-400Hz
S/N: Y012101123456 Made	in China
Shenzhen INVT Electric Co.,	Ltd.

**Note:** The preceding are standard product nameplate examples. The CE/TUV/IP55 marking on the top right will be marked according to actual certification conditions.

## 3.5 Model designation code

Figure 3-4 Model description

<u>GD350-022G/030P-4 5-AS-B</u> 1 2 3 4 5 6

Field	Sign	Description	Example
Product	Ð	Product series	GD350: Goodrive350 high-performance multi-function
category	Û	abbreviation	VFD
Rated power	2	Power range + load type	022: 22kW G: Constant torque load P: Fan and water pump
Voltage class	3	Voltage class	4: 3PH 380V(-15%)V-440V(+10%)
Ingress protection (IP) rating	4	Ingress protection (IP) rating	5: IP55 ingress protection rating (It is impossible to completely prevent dust from entering, but the amount of dust from entering will not cause damage to the equipment. It will not cause damage when the product under normal installation state is immersed in water from each direction).
Accessory identifier	5	AC input switch	AS: Standard AC input switch NS: Without AC input switch
Built-in unit	6	Braking unit	B: Optional built-in braking unit

## 3.6 Product ratings

		Constant torque			Variable torque				
Frame code	VFD model	Output power	Input current	Output current	Carrier freq.	Output power	Input current	Output current	Carrier freq.
		(kW)	(A)	(A)	(kHz)	(kW)	(A)	(A)	(kHz)
	GD350-004G/5R5P-45-AS	4	13.5	9.5	8	5.5	19.5	12.5	4
1	GD350-004G/5R5P-45-NS	4	13.5	9.5	8	5.5	19.5	12.5	4
	GD350-5R5G/7R5P-45-AS	5.5	19.5	14	8	7.5	23	17	4
	GD350-5R5G/7R5P-45-NS	5.5	19.5	14	8	7.5	23	17	4
2	GD350-7R5G/011P-45-AS	7.5	25	18.5	8	11	30	23	4
	GD350-7R5G/011P-45-NS	7.5	25	18.5	8	11	30	23	4
	GD350-011G/015P-45-AS	11	32	25	8	15	40	32	4
	GD350-011G/015P-45-NS	11	32	25	8	15	40	32	4
	GD350-015G/018P-45-AS	15	40	32	4	18.5	45	38	2
	GD350-015G/018P-45-NS	15	40	32	4	18.5	45	38	2
3	GD350-018G/022P-45-AS	18.5	45	38	4	22	51	45	2
	GD350-018G/022P-45-NS	18.5	45	38	4	22	51	45	2
	GD350-022G/030P-45-AS	22	51	45	4	30	64	60	2
	GD350-022G/030P-45-NS	22	51	45	4	30	64	60	2

Product overview

		Constant torque			Variable torque				
Frame		Output	Input	Output	Carrier	Output	Input	Output	Carrier
code	VFD model	power	current	current	freq.	power	current	current	freq.
		(kW)	(A)	(A)	(kHz)	(kW)	(A)	(A)	(kHz)
	GD350-030G/037P-45-AS	30	64	60	4	37	80	75	2
	GD350-030G/037P-45-NS	30	64	60	4	37	80	75	2
4	GD350-037G/045P-45-AS	37	80	75	4	45	98	92	2
	GD350-037G/045P-45-NS	37	80	75	4	45	98	92	2
	GD350-045G/055P-45-AS	45	100	92	4	55	128	115	2
	GD350-045G/055P-45-NS	45	100	92	4	55	128	115	2
	GD350-045G/055P-45-AS-B	45	100	92	4	55	128	115	2
	GD350-045G/055P-45-NS-B	45	100	92	4	55	128	115	2
5	GD350-055G/075P-45-AS	55	128	115	4	75	139	150	2
	GD350-055G/075P-45-NS	55	128	115	4	75	139	150	2
	GD350-055G/075P-45-AS-B	55	128	115	4	75	139	150	2
	GD350-055G/075P-45-NS-B	55	128	115	4	75	139	150	2
	GD350-075G/090P-45-AS	75	139	150	2	90	168	170	2
	GD350-075G/090P-45-NS	75	139	150	2	90	168	170	2
	GD350-075G/090P-45-AS-B	75	139	150	2	90	168	170	2
	GD350-075G/090P-45-NS-B	75	139	150	2	90	168	170	2
	GD350-090G/110P-45-AS	90	168	180	2	110	201	215	2
	GD350-090G/110P-45-NS	90	168	180	2	110	201	215	2
6	GD350-090G/110P-45-AS-B	90	168	180	2	110	201	215	2
	GD350-090G/110P-45-NS-B	90	168	180	2	110	201	215	2
	GD350-110G-45-AS	110	201	215	2				
	GD350-110G-45-NS	110	201	215	2				
	GD350-110G-45-AS-B	110	201	215	2				
	GD350-110G-45-NS-B	110	201	215	2				

#### Note:

- There is no P type machine for 110kW models.
- The input current of the 004G/5R5P-055G/075P VFD models is measured in cases where the input voltage is 380V without additional reactors.
- The rated output current is the output current when the output voltage is 380V.
- Within the allowable input voltage range, the output current/power cannot exceed the rated output current/power.

## 3.7 Structure

The VFD structure is shown in the following figure (taking the 015G/018P VFD model as an example).



No.	Name	Description
1	Upper cover	Protects internal components.
2	Keypad	For details, see section 5.4 Operation procedure.
3	Lower cover	Protects internal components.
4	Expansion card	Optional. For details, see Appendix A Expansion card.
5	Baffle of control board	Protects the control board and install extension card.
6	Cooling fan	For details, see chapter 8 Maintenance.
7	Keypad interface	Connects the keypad.
8	Nameplate	For details, see chapter 3 Product overview.
9	Main circuit terminals	For details, see section 4.3 Standard wiring of the main circuit.
10	Control terminals	For details, see section 4.4 Standard wiring of the control circuit.
11	Waterproof connector	Locks and secures connection cables.
12	POWER indicator	Power supply indicator.
40	Label of GD350 IP55	For dataily, and position Q.F.Madal designation and
13	product series	For details, see section 3.5 Model designation code.
14	Baffle of fan	Protects the fan.
15	Switch handle	Controls the main circuit power.

## **4 Installation guidelines**

## 4.1 What this chapter contains

This chapter describes the mechanical installation and electrical installation of the VFD.

Only trained and qualified professionals are allowed to carry out the operations
mentioned in this chapter. Please carry out operations according to instructions
presented in chapter 1 Safety precautions. Ignoring these safety precautions
may lead to physical injury or death, or device damage.
• Ensure the VFD power has been disconnected before installation. If the VFD
has been powered on, disconnect the VFD power and wait for at least the time
specified on the VFD, and ensure the POWER indicator is off. You are
recommended to use a multimeter to check and ensure the VFD DC bus voltage
is below 36V.
• The VFD installation must be designed and done according to applicable local
laws and regulations. INVT does not assume any liability whatsoever for any
VFD installation which breaches local laws or regulations. If recommendations
given by INVT are not followed, the VFD may experience problems that the
warranty does not cover.

## 4.2 Mechanical installation

## 4.2.1 Installation environment

The installation environment is essential for the VFD to operate with best performance in the long run. Install the VFD in an environment that meets the following requirements.

Environment	Condition
Installation site	Indoor
Installation site Ambient temperature	<ul> <li>Indoor</li> <li>-10-+50°C</li> <li>When the ambient temperature exceeds 40°C, derate 1% for every increase of 1°C.</li> <li>Do not use the VFD when the ambient temperature exceeds 50°C.</li> <li>To improve reliability, do not use the VFD in the places where the temperature changes rapidly.</li> <li>When the VFD is used in a closed space, such as control cabinet, use a cooling fan or air conditioner for cooling, preventing the internal temperature from exceeding the temperature required.</li> <li>When the temperature is too low, if you want to use the VFD that has been idled for a long time, install an external heating device before the use to the temperature is too low.</li> </ul>
	eliminate the treeze inside the VFD. Otherwise, the VFD may be damaged.

Environment	Condition					
Humidity	<ul> <li>Less than 90%</li> <li>The max. RH cannot exceed 60% in the environment where there are corrosive gases.</li> </ul>					
Storage temperature	-30–+60°C					
Running environment	<ul> <li>Install the VFD in a place:</li> <li>Away from electromagnetic radiation sources</li> <li>Away from oil mist, corrosive gases, or combustible gases</li> <li>Without the chance for foreign objects such as metal powder to fall into the VFD (do not install the VFD onto combustible objects such as wood)</li> <li>Without radioactive substances or combustible objects</li> <li>Away from corrosive liquid</li> <li>With low salt content</li> <li>Without direct sunlight</li> </ul>					
<ul> <li>Altitude</li> <li>Lower than 1000m</li> <li>When the altitude exceeds 1000m, derate by 1% for every additional 1</li> <li>When the installation site altitude exceeds 3000m, consult the loca dealer or office.</li> </ul>						
Vibration	The max. amplitude of vibration cannot exceed 5.8m/s <sup>2</sup> (0.6g).					
Installation direction	Install the VFD vertically to ensure good heat dissipation performance.					

**Note:** The VFD needs to be installed at a ventilated environment free from corrosive gases and conductive dust.

#### 4.2.2 Installation direction

The VFD can be installed on the wall or in a cabinet.

The VFD must be installed vertically. Check the installation position according to following requirements. For details about the outline dimensions, see Appendix C Dimension drawings.

#### Figure 4-1 Installation direction

NG



a. Vertical installation



b.Horizontal installation



NG

c.Transverse installation

## 4.2.3 Installation method

The VFDs can be installed in two modes, depending on the different VFD dimensions.



Figure 4-2 Mounting method

- Mark the installation hole positions. For details about the installation hole positions, see Appendix C Dimension drawings.
- 2. Mount the screws or bolts onto the marked positions.
- 3. Lean the VFD against the wall.
- 4. Tighten the screws.

**Note:** Flange-mounting plate is a must for 004G/5R5P–110G VFDs that adopt flange-mounting mode.

#### 4.2.4 Installing one unit



Figure 4-3 Single-unit installation

Note: For clearances A, B, and C, each must be 100mm at least.

#### 4.2.5 Multiple-product installation



Figure 4-4 Parallel installation

#### Note:

- When you install VFDs in different sizes, align the top of each VFD before installation for the convenience of future maintenance.
- The min dimensions of A, B, and C are 100mm, and the dimension of D can be 0, which means zero-clearance parallel installation is supported.

## 4.2.6 Vertical installation





**Note:** During vertical installation, you must install windshield, otherwise, the VFD will experience mutual interference, and the heat dissipation effect will be degraded.

#### 4.2.7 Tilted installation



Figure 4-6 Tilted installation

**Note:** During tilted installation, it is a must to ensure the air inlet duct and air outlet duct are separated from each other to avoid mutual interference.

## 4.3 Standard wiring of the main circuit

#### 4.3.1 Main circuit wiring diagrams



Figure 4-7 Wiring diagram of the main circuit

#### Note:

- The fuse, DC reactor, braking unit, braking resistor, input reactor, input filter, output reactor and output filter are optional parts. For details, see Appendix D Optional peripheral accessories.
- Before connecting the braking resistor, remove the yellow warning label with PB, (+) and
   (-) from the terminal block; otherwise, poor contact may occur.

#### 4.3.2 Main circuit terminal diagram

Figure 4-8 Main circuit terminals for the 004G/5R5P-5R5G/7R5P models



## Without AC input switch



Figure 4-9 Main circuit terminals for the 7R5G/011P-015G/018P models



Figure 4-10 Main circuit terminals for the 018G/022P-022G/030P models





Figure 4-11 Main circuit terminals for the 030G/037P-037G/045P models

With AC input switch



Without AC input switch





Figure 4-12 Main circuit terminals for the 045G/055P–055G/075P models





Terminal symbol	Terminal name	Function description
R, S, T	Main circuit power input	3PH AC input terminals, connected to the grid
U, V, W	VFD outputs	3PH AC output terminals, connected to the motor usually
(+)	Braking unit terminal 1/Brake resistor terminal 1	(+) and (-) connect to the external braking unit. PB and (+) connect to external braking resistor
(-)	Braking unit terminal 2	terminal

Terminal symbol	Terminal name	Function description
PB	Braking resistor terminal 2	
PE	Grounding terminal for safe	Each VFD carries two PE terminals and proper
	protection	grounding is required.

Note:

- It is not recommended to use asymmetrical motor cables. If there is a symmetrical grounding conductor in the motor cable besides the conductive shielded layer, ground the grounding conductor on the VFD end and motor end.
- Braking resistor, braking unit and DC reactor are optional parts.
- Route the motor cable, input power cable and control cable separately.
- GD series VFDs cannot share the DC bus with CH series VFDs.
- When sharing the DC bus, the VFDs must be the same in power and must be simultaneously powered on or off.
- In shared DC bus running mode, current balance on the VFD input side must be considered during wiring, and equalizing reactors are recommended to be configured.

#### 4.3.3 Wiring procedure of main circuit terminals

- 1. Connect the grounding line of the input power cable to the grounding terminal (PE) of the VFD, and connect the 3PH input cable to R, S and T terminals and tighten up.
- 2. Connect the ground wire of the motor cable to the PE terminal of the VFD, connect the motor 3PH cable to the U, V and W terminals, and tighten up.
- Connect optional parts such as the braking resistor that carries cables to designated positions.
- 4. Fix all the cables outside the VFD mechanically if allowed.

Figure 4-14 Screw installation diagram





The screw is fastened
# 4.4 Standard wiring of the control circuit

## 4.4.1 Wiring diagram of basic control circuit



Figure 4-15 Wiring diagram of control circuit

**Note:** If wire-passing board outlet space is insufficient when all terminals on the control board are wired, cut the knock-out hole on the lower cover for wire outlet. If a dangerous situation occurs when the knock-out hole is cut for a purpose but not wire outlet, we will not bear any responsibility.

Terminal symbol	Description
+10V	Locally provided +10.5V power supply
Al1	Input range: For AI1, 0–10V or 0–20mA
	For Al2, -10V – +10V
AI2	Input impedance: $20k\Omega$ for voltage input or $250\Omega$ for current input
	Whether voltage or current is used for input of AI1 is set through P05.50.
	Resolution: 5mV when 10V corresponds to 50Hz

Terminal symbol	Description							
- Cymber	Deviation: +0.5% at 25°C, when input is above 5\//10mA							
GND	+10.5V reference around							
0.15	Output range: $0-10V$ or $0-20mA$							
AO1	Whether voltage or current is used for output is set through the switch SW2							
	Deviation: +0.5% when output exceeds 5V or 10mA at 25°C							
RO1A								
RO1B	RO1 output; RO1A: NO; RO1B: NC; RO1C: common							
RO1C	Contact capacity: 3A/AC250V, 1A/DC30V							
RO2A								
RO2B	RO2 output; RO2A: NO; RO2B: NC; RO2C: common							
RO2C	Contact capacity: 3A/AC250V, 1A/DC30V							
	Switch capacity: 50mA/30V							
HDO	Output frequency range: 0–50kHz							
	Duty ratio: 50%							
COM	+24V reference ground							
CME	Common terminal of open collector output; short connected to COM by default.							
Y1	Switch capacity: 50mA/30V							
	Output frequency range: 0–1kHz							
485+	RS485 differential signal communication port. Use shielded twisted pairs for							
	standard RS485 communication interfaces. You can determine whether to connect							
485-	the 120 $\Omega$ terminal matching resistor of RS485 communication through the							
55	corresponding switch SW3.							
PE	Grounding terminal							
PW	External power input terminal for digital input circuits							
	Voltage range: 12–30V							
24V	External power input terminal for digital input circuits							
<b>C1</b>	Digital input 1 • Internal impedance: 2.2k0							
62	Digital input 2							
02 02	Digital input 2 • 12-500 Voltage input is acceptable							
	Max_input frequency: 1kHz							
S4	Digital input 4 • All are programmable digital input terminals, the functions of							
04	which can be set through function codes							
HDIA	Channels for both high frequency pulse input and digital input							
	Max. input frequency: 50kHz							
	Duty ratio: 30%-70%							
HDIB	Supports the input of a quadrature encoder with 24V power supply; equipped with							
	speed-measurement function							
+24V—H1	STO input 1 • Safe torque off (STO) redundant input, connected to the external							
+24V—H2	STO input 2 NC contact. When the contact opens, STO acts and the VFD stops output.							

Terminal symbol	Description								
	<ul> <li>Safety input signal wires use shielded wires whose length is within 25m</li> </ul>								
	<ul> <li>The H1 and H2 terminals are short connected to +24V by default.</li> </ul>								
	Remove the jumper from the terminals before using STO								
	function.								

#### 4.4.2 Input/output signal connection diagram

Set NPN /PNP mode and internal/external power via U-shaped jumper. PNP internal mode is adopted by default.





**Note:** As shown in the figure above, the USB port can be used to upgrade the software, and the keypad port can be used to connect an external keypad. The external keypad cannot be used when the local VFD keypad is used.

If the input signal comes from the NPN transistor, set the U-shaped jumper between +24V and PW based on the power used according to the following figure.



Figure 4-17 NPN mode

If the input signal comes from the PNP transistor, set the U-shaped jumper based on the power used according to the following figure.



### Figure 4-18 PNP mode

# 4.5 Wiring protection

### 4.5.1 Protecting the VFD and input power cable in case of short circuit

The VFD and input power cable can be protected in case of short circuit, avoiding thermal overload. Carry out protective measures according to the following figure.



Figure 4-19 Fuse configuration

**Note:** Select the fuse according to the manual. In case of short circuit, the fuse protects input power cables to avoid damage to the VFD; if internal short-circuit occurs to the VFD, it can protect neighboring equipment from being damaged.

#### 4.5.2 Protecting the motor and motor cable in case of short circuit

If the motor cable is selected based on VFD rated current, the VFD is able to protect the motor cable and motor during short circuit without other protective devices.



If the VFD is connected to multiple motors, use a separated thermal overload switch or breaker to protect the cable and motor, which may require the fuse to cut off the short circuit current.

#### 4.5.3 Protecting the motor against thermal overload

The motor must be protected against thermal overload. Once overload is detected, current must be cut off. The VFD is equipped with the motor thermal overload protection function, which can block output and cut off the current (if necessary) to protect the motor.

## 4.5.4 Bypass connection

In some critical scenarios, the power/variable frequency conversion circuit needs to be configured to ensure proper operation of the system when a fault occurs to the VFD.

In some special scenarios, such as in soft startup, power-frequency running is directly performed after the startup, which requires bypass connection.



Do not connect any power source to the VFD output terminals U, V, and W. The voltage applied to the motor cable may cause permanent damage to the VFD.

If frequent switchover is needed, you can use the switch which carries mechanical interlock or a contactor to ensure motor terminals are not connected to input power cables and VFD output ends simultaneously.

# **5** Basic operation guidelines

# 5.1 What this chapter contains

This chapter instructs you how to use the VFD keypad and commission the VFD common functions.

# 5.2 Keypad introduction

The VFD has been equipped with a LCD keypad as a standard configuration part. You can use the keypad to control the start and stop, read status data, and set parameters of the VFD.



Figure 5-1 Keypad

## Note:

- The LCD keypad is equipped with a real-time clock, which can run properly after being installed with batteries even if the power line is disconnected. The clock battery (type: CR2032) is user purchased.
- The LCD keypad has the parameter copying function.
- The VFDs of the following power ranges must use flat ribbon cables, while for VFDs of other power ranges, both flat and standard keypad cables are acceptable.

Name	Length (m)	Ordering code	Applied to
	1	67004-00053	
	2	67004-00010	
Flat keypad cable	3	67004-00013	18.5-37KVV
	5	67004-00052	

Name	No.			Description
	(1)	RL	JN	Run indicator Off: The VFD is stopped. Blinking: The VFD is in parameter autotuning. On: The VFD is running.
Status indicator	(2)	TR	JP	Fault indicator LED on: The VFD is in fault state. LED off: The VFD is in normal state. LED blinking: The VFD is in pre-alarm state.
	(3)	QUIC	{/JOG	Short-cut key indicator, which displays different state under different functions, see definition of QUICK/JOG key for details.
	(4)	•		The function of function key varies with the menu.
	(5)	-	Function key	The function of the function key is displayed in the
	(6)			footer.
Keys	(7)	QUICK	Short-cut key	Re-definable. It is defined as JOG function by default, namely jogging. The function of short-cut key can be set by the ones of P07.02, as shown in the following: 0: No function 1: Jogging (linkage indicator (3); logic : NO) 2: Reserved 3: FWD/REV switch-over (linkage indicator (3); logic: NC) 4: Clear the UP/DOWN setting (linkage indicator (3) logic: NC) 5: Coast to stop (linkage indicator (3); logic : NC) 6: Switch command channels in sequence (linkage indicator (3); logic: NC) 7: Reserved Note: After restoring to default values, the default function of short-cut key QUICK/JOG is 1.
	(8)	Enter	Confirmation key	The function of confirmation key varies with menus, such as confirming parameter setup, confirming parameter selection, and entering the next menu.
	(9)		Run key	Under keypad operation mode, the running key is used for running operation or autotuning operation.
	(10)	STOP RST	Stop/Reset key	Press it to stop the VFD that is running or autotuning. The function of this key is restricted by P07.04. In fault alarm state, this key can be used for reset in any control modes.

Name	No.		Description						
	(11)	* * *	Direction key UP: DOWN: Left: Right:	UP: The function of UP key varies with interfaces, such as shifting up the displayed item, shifting up the selected item, and changing digits. DOWN: The function of DOWN key varies with interfaces, such as shifting down the displayed item, shifting down the selected item, changing digits. LEFT: The function of LEFT key varies with interfaces, such as switch over the monitoring interface, such as shifting the cursor leftward, exiting current menu and returning to previous menu. RIGHT: The function of RIGHT key varies with interfaces, such as switch over the monitoring interface, such as switch over the monitoring interfaces, such as switch over the monitoring interfaces, such as switch over the monitoring interfaces, such as switch over the monitoring interface, shifting the cursor rightward, enter the next menu etc.					
Display area	(12)	LCD screen	Display screen	240×160 dot-matrix LCD; display three monitoring parameters or six sub-menu items simultaneously.					
	(13)	RJ45 interface	RJ45 interface	Interface to connect to a VFD.					
Other	(14)	Battery holder	Clock battery holder	The battery holder is used for replacing or installing a battery for the clock.					
	(15)	USB terminal	Mini USB terminal	Mini USB terminal is used to connect to the USB flash drive through an adapter.					

The LCD has different display areas, which displays different contents under different interfaces. The following figure is the main interface of stop state.



Area	Name	Display
Hoodor A	Deal time disalary and	Display the real-time; clock battery is not included; the time
Header A	Real-une display area	needs to be reset when powering on the VFD

Area	Name	Display
Header B	VFD running state display area	<ul> <li>Displays the running status of the VFD:</li> <li>Displays motor rotation direction:</li> <li> Fwd" – Run forward during operation; "Rev" – Run reversely during operation; "Forbid" – Reverse running is forbidden; </li> <li>Displays VFD running command channel:</li> <li> "Local" – Keypad; "Terminal"–Terminal; "Remote"–Communication; </li> <li>Displays current running state of the VFD:</li> <li> "Ready" – The VFD is in stop state (no fault); "Run" – The VFD is in running state; "Jog"–The VFD is in jogging state; "Pre-alarm"–the VFD is under pre-alarm state during running; "Fault"–VFD fault occurred.</li></ul>
Header C	Model display area	VFD model display: "GD350" – current VFD is GD350 IP55 series VFD.
Display D	Parameter names and function codes on the VFD homepage	Display a maximum of three parameter names and function codes on the homepage. The parameters displayed on the homepage can be managed.
Display E	Values of parameters on the VFD homepage	Display the values of parameters on the VFD homepage, which are updated in real time.
Footer F	Corresponding menu of function key (4), (5) and (6)	Corresponding menu of function key (4), (5) and (6). The corresponding menu of function key (4), (5) and (6) varies with interfaces, and the contents displayed in this area is also different.

# 5.3 Keypad display

The VFD keypad can display the stopped-state parameters, running-state parameters, function parameter editing status, and fault alarm status.

## 5.3.1 Displaying stopped-state parameters

When the VFD is in stopped state, the keypad displays stopped-state parameters, and this interface is the main interface during power-on by default. Under stop state, parameters in various states can be displayed. Press for  $\checkmark$  to shift the displayed parameter up or down.



Figure 5-3 Displaying stopped-state parameters

Press **(**or **)** to switch between different display styles, including list display style and progress bar display style.

16:02:35 Fwd Lo	ocal Ready	GD350		16:02:35 Fwd	Local	Ready	GD350
Set Freq P17.00 Hz	50.0	00	>	Set Freq		50	.00
DC Bus Volt P17.11 V	540	0.0	$\rightarrow$	Hz			
DigiInputTrmlState P17.12	000	000	<	0.00			599.00
Parameter /	About	Menu		Back	Home		

Figure 5-4 Displaying stopped-state parameters

The stopped-state parameter display list is user defined, and each state variable function code can be added to the list as needed. The state variable which has been added to the list can also be deleted or shifted.

### 5.3.2 Displaying running-state parameters

After receiving valid running command, the VFD will enter running state, and the keypad displays running state parameter with  $\boxed{\text{RUN}}$  indicator on the keypad turning on. Under running state, multiple kinds of state parameters can be displayed. Press  $\checkmark$  or  $\checkmark$  to shift up or down.

	0				•			
16:02:35 Fwd	Local Run	GD350		16:02:35	Fwd	Local	Run	GD350
Output Freq	50	~~	$\sim$	Set Freq			50	~~
P17.01 Hz	50.	.00		P17.00	Hz		50.	00
Set Freq	<b></b>	~~		DC Bus \	/olt		- 40	<u>````</u>
P17.00 Hz	50.	.00		P17.11	V		540	0.0
DC Bus Volt	<b>F</b> 44	<u>~</u> ~		Output V	olt		070	<b>`</b>
P17.11 V	540	J.U	~	P17.03	V		378	5
Parameter	About	Menu	]	Para	meter	About		Menu

Figure 5-5 Displaying running-state parameters

Press **<** or **>** to switch between different display styles, including list display style and progress bar display style.



Figure 5-6 Displaying running-state parameters

Under running state, multiple kinds of state parameters can be displayed. The running display parameter list is user defined, and each state variable function code can be added to the running display parameter list as needed. The state variable which has been added to the running display parameter list can also be deleted or shifted.

## 5.3.3 Displaying fault alarms

The VFD enters fault alarm display state once fault signal is detected, and the keypad displays fault code and fault information with TRIP indicator on the keypad turning on. You can perform fault reset by using the STOP/RST key, control terminals, or communication commands.

If the fault persists, the fault code is continuously displayed.





# 5.4 Operation procedure

Various operations can be performed on the VFD, including entering/exiting menu, parameter selection, list modification and parameter addition.

### 5.4.1 Entering/Exiting menus

Regarding the monitoring menu, the operation relation between entering and exiting is shown as follows.

16:02:35 Fwd	Local	Ready GD350		16:02:35	Fwd	Local	Ready	GD350		16:02:35	Fwd	Local	Ready	GD350
Set Freq P17.00 Hz		50.00	<u> </u>	Function	group:	P0	0			Function co	ode:		P00	.00
DC Bus Volt P17.11 V		540.0		P00: Basic I	unction			Þ		P00.00: S	peed Ctr	l Run Cmo	1	×
DigilnputTrmlState P17.12		000000							<ul><li>✓</li></ul>					
Parameter	About	Menu		Back		Hom	е	Sele		Back		Hom	e	Sele

#### Figure 5-8 Enter/exit menu diagram 1

The following figure shows how to enter or exit different menus step by step.



#### Figure 5-9 Enter/exit menu diagram 2

The keypad menu setup is shown as follows:

Level 1	Level 2	Level 3	Level 4
		P00: Basic functions	P00.xx
		P01: Start and stop control	P01.xx
		P03: Vector control of motor 1	P03.xx
		P04: V/F control	P04.xx
		P07: Human-machine interface	P07.xx
		P08: Enhanced functions	P08.xx
		P09: PID control	P09.xx
	Basic	P10: Simple PLC and multi-step	
	parameters	speed control	P10.xx
		P11: Protection parameters	P11.xx
		P13: SM control parameters	P13.xx
		P14: Serial communication	
		functions	P14.xx
		P21: Position control	P21.xx
		P22: Spindle positioning	P22.xx
		P23: Vector control of motor 2	P23.xx
		P02: Motor 1 parameters	P02.xx
Parameter	Motor and encoder parameters	P12: Motor 2 parameters	P12.xx
aroups		P20: Motor 1 encoder group	P20.xx
groupo		P24: Motor 2 encoder group	P24.xx
	Factory parameters	P99: Factory function group	xxxxx
	Terminal	P05: Input terminal group	P05.xx
	function	P06: Output terminal group	P06.xx
	parameters	P98: AIAO calibration functions	XXXXX
		P15: Communication expansion card 1 functions	P15.xx
		P16: Communication expansion card 2 functions	P16.xx
	Optional card	P25: Expansion I/O card input functions	P25.xx
	parameters	P26: Expansion I/O card output	P26.xx
		P27: Programmable expansion	P27.xx
		P28: Master/slave control	P28 vv
	Factory	P90: Tension control speed mode	P90 xx
	customized	P91: Tension control torque mode	P91.xx
	parameters	P92: Tension control optimization	P92.xx

Basic operation guidelines

Level 1	Level 2	Level 3	Level 4		
		functions			
Lloor defined			P00.00: Speed Ctrl Run Cmd		
	/	/	P00.01: Run Cmd Channel		
parameters			Pxx.xx: Parameter setup xx		
		P07: Human-machine interface	P07.xx		
		P17: Status viewing functions	P17.xx		
	State	P18 group: Closed-loop vector	D18 vv		
	monitoring	state check functions	1 10.22		
	parameters	P19: Status viewing functions of	P19.xx		
	parameters	expansion card			
		P93: Tension control status	P93.xx		
		viewing			
			P07.27: Type of present fault		
			P07.28: Type of the last fault		
			P07.29: Type of the 2nd-last		
			fault		
	Fault types	/	P07.30: Type of the 3rd-last		
		,	fault		
			P07.31: Type of the 4th-last		
			fault		
State			P07.32: Type of the 5th-last		
monitoring			fault		
			P07.33: Running frequency at		
			present fault		
	Fault recording	1	P07.34: Ramp frequency at		
	parameters	7	present fault		
			P07.xx: xx state of the last but		
			xx fault		
	Clear fault	,	Are you sure to clear fault		
	records	1	history?		
			Pxx.xx: Modified parameter 1		
	Modified		Pxx.xx: Modified parameter 2		
	parameters	/	Pxx.xx: Modified parameter		
			xx		
	Customize	Stopped-state parameters	/		
	Home				
	parameters	Running-state parameters	/		
Motor		Ensure motor nameplate	Complete parameter rotary		
parameter	/	parameters are set correctly.	autotuning		

Level 1	Level 2	Level 3	Level 4
autotune			Complete parameter static
			autotuning
			Partial parameter static
			autotuning
			Complete parameter rotary
			autotuning 2 (for AM)
			Complete parameter static
			autotuning 2 (for AM)
			Upload param from local to
			keypad
			Download all param from
		MomAroot: BACKUB01	keypad
		Memaleat. BACKOPUT	Download non motor param
			from keypad
			Download motor param from
			keypad
			Upload param from local to
			keypad
			Download all param from
		MomAroa2: BACKLIP02	keypad
		MeniAleaz. DAGROF 02	Download non motor param
Conv			from keypad
narameter/	/		Download motor param from
Restore default	,		keypad
			Upload param from local to
			keypad
			Download all param from
		MemArea3 <sup>.</sup> BACKUP03	keypad
			Download non motor param
			from keypad
			Download motor param from
			keypad
		Restore default (excl motor para)	Sure to restore defaults (excl
			motor para)?
		Restore default (test mode)	Sure to restore default (test
			mode)?
		Restore default (incl motor para)	Sure to restore default (incl
			motor para)?

Basic operation guidelines

Level 1	Level 2	Level 3	Level 4
			Language
			Time/date
			Backlight brightness
			Backlight time
	,		Enable power-on setup
System		1	wizard
settings	/	7	Power-on setup wizard
			Keypad burning selection
			Enable fault time
			Control board burning
			selection
			Up/down key sensitivity

## 5.4.2 Editing list

16 St

The parameters in the parameter list in stopped state can be added as needed (through the menu of user defined home parameters), and the list can also be edited such as "Move up", "Move down", "Delete from the list", and "Restore default". The edit function is shown in the following.

							Figu	ire 5	-10 E	ditin	g list 1	1					
6:02:35	Fwd	Local	Ready	GD350	1		16:02:35	Fwd	Local	Ready	GD350	1	16:02:35	Fwd	Local	Ready	GD350
opped-st	ate parame	ters		Þ	-	>	P17.00: 9	Set Freq			Þ		Place top				•
unning-st	ate param	eters				· .	P17.11: E	OC Bus Vo	lt				Move up				
						_	P17.12: 0	DigilnputTr	mlState				Move dow	n			
							P17.13: D	DigiOutput	TrmIState				Delete fro	m the list			
							P17.26: 0	Current Op	er Time				Restore d	efault			
					-	<	P17.15: N	Aotor Trq F	Ref			∕ <					
Back		Home		Sele	]		B	Back	Edi	t	ОК		Bac	k	Home		Sele
					-							=	-				

Press 
extended to enter edit interface, select the operation needed, and press 
key,

> key or 💼 key to confirm the edit operation and return to the previous menu

(parameter list), the returned list is the list edited. If 🖉 key or 🧲 key is pressed in edit interface without selecting an edit operation, it will return to the previous menu (parameter list remain unchanged).

Note: For the parameter objects in the list header, move-up operation will be invalid, and the same principle can be applied to the parameter objects in the list footer; after deleting a certain parameter, the parameter objects under it will be moved up automatically.

The items in the parameter list in running state can be added as needed (through the menu of user defined home parameters), and the list can also be edited such as "Place top", "Move up", "Move down", "Delete from the list", and "Restore default parameters". The edit function is shown in the interface below.



The parameters of user defined parameter setting can be added, deleted or adjusted as needed, such as "Place top", "Move up", "Move down", "Delete from the list", and "Restore default parameters"; the adding function can be set in a certain function code in a function group. The edit function is shown in the figure below.



#### 5.4.3 Adding parameters to the parameter list displayed in stopped/running state

You can choose **Menu** > **State monitoring**, choose a submenu, and enter a specific function group and then a specific function code to add the parameter to the list of parameters displayed in stopped state or parameters displayed in running state.



Figure 5-13 Adding a parameter 1

and press skey, key or key to confirm the addition operation. If this parameter is not included in the list of parameters displayed in stopped state or list of parameters displayed in running state, the parameter added will be at the end of the list; if the parameter is already in the list of parameters displayed in stopped state or list of parameters displayed in running state, the addition operation will be invalid. If key or key or key is pressed without selecting addition operation in "Addition" interface, it will return to monitoring

parameter list menu.

Part of the monitoring parameters in P07 HMI group can be added to the "parameter displayed in stop state" list or "parameter displayed in running state" list; all the parameters in P17, P18 and P19 group can be added to the "parameter displayed in stop state" list or "parameter displayed in running state" list.

Up to 16 monitoring parameters can be added to the list of parameters displayed in stopped state; and up to 32 monitoring parameters can be added to the list of parameters displayed in running state.

### 5.4.4 Adding parameters to the user defined parameter setting list

You can choose Menu > Parameter groups, choose a submenu, and enter a specific function group and then a specific function code to add the parameter to the user defined parameter list.



Figure 5-14 Adding a parameter 2

Press e key to enter addition interface, and press key, key or key to confirm the addition operation. If this parameter is not included in the original user defined parameter list, the newly-added parameter will be at the end of the list; if this parameter is already in the user defined parameter list, the addition operation will be invalid. If key or

key is pressed without selecting addition operation, it will return to parameter setup list menu.

All the function code groups under the submenu can be added to user defined parameter list. Up to 64 function codes can be added to the user defined parameter list.

### 5.4.5 Editing user defined parameters

After accessing a specific function code under the **User defined parameters** menu, you can press the  $\checkmark$  key,  $\searrow$  key or key to enter the parameter edit interface. After entering the edit interface, the present value is highlighted. Press the  $\blacktriangle$  key and  $\checkmark$  key to edit the parameter value, and the corresponding parameter item of current value will be highlighted automatically. After the edit operation is completed, press  $\checkmark$  or key to save the selected parameter and return to the previous menu; or press key to maintain the value and return to the previous menu.



#### Figure 5-15 Editing user defined parameters

In parameter selection edit interface, the "Auth" field in the upper right corner indicates whether this parameter is editable or not.

" $\sqrt{}$ " indicates the set value of this parameter can be modified under current state.

"x" indicates the set value of this parameter cannot be modified under the present state.

"Present" indicates the actually selected value.

"Default" indicates the default value of this parameter.

#### 5.4.6 Editing parameters in parameter groups

You can choose Menu > Parameter groups, enter a specific function group and then
specific function code, and then press 💊 key, 🕨 key or 🕎 key to edit the parameter
setting interface. After entering edit interface, set the parameter from low bit to high bit, and th
bit under setting will be highlighted. Press 👗 key or 💙 key to increase or decrease th
parameter value (this operation is valid until the parameter value exceeds the max. value of
min. value); press 🗲 or 🔪 to shift the editing bit. After parameters are set, press 💊

or with key to save the set parameters and return to the previous menu; press of to maintain the original parameter value and return to the previous menu.

Figure 5-16 Editing parameters in parameter groups



In parameter selection edit interface, the "Auth" field in the upper right corner indicates whether this parameter is editable or not.

"v" indicates the set value of this parameter can be modified under current state.

"x" indicates the set value of this parameter cannot be modified under the present state.

"Present" indicates the present value.

"Default" indicates the default value of this parameter.

## 5.4.7 Monitoring states

You can choose **Menu** > **State monitoring** > **State monitoring parameter**, enter a specific function group and then a specific function code, and press key, key, key or get key

to enter the state monitoring interface. After entering the state monitoring interface, the actual parameter value will be displayed in real time, this value is the actually detected value which cannot be modified.

In the state monitoring interface, you can press 🥟 key or 💊 key to return to the previous menu.



#### 5.4.8 Autotuning motor parameters

You can choose Menu > Motor parameter autotune and press 💊 key, 🕨 key or 🧊

key to enter motor parameter autotuning interface. However, before entering the motor parameter autotuning interface, you must set the motor nameplate parameters correctly. After entering the interface, select a motor autotuning type to carry out motor parameter autotuning. In motor parameter autotuning interface, you can press key or key or key to return to the

previous menu.

Figure 5-18 Selecting a parameter autotuning type

16:02:35	Fwd	Local	Ready	GD350	]		16:02:35	Fwd	Local	Ready	GD350			16:02:35	Fwd	Local	Ready	GD350
Parameter	groups					>							•	Complete	para rotar	y autotun	e	
User defin	ed parame	ters				· ·	-							Complete	para stati	c autotune	8	
State mon	itoring						correctly.	or namepi	ate param	eters are	set		-	Partial pa	ira static au	utotune		
Motor para	ameter auto	otune		•	4							4		Complete	e para rotar	y autotun	ie 2 (for A	AM)
Copy para	meter/Res	tore defa	ult			1								Partial pa	ira static ai	itotune 2	(for AM)	
System set	tings				0	<						<i>•</i> <	ί.				(	
Back		Home		Sele			Back		Home		ОК			Bac	*	Home	9	ОК

After selecting a motor autotuning type, enter motor parameter autotuning interface, and press **RUN** key to start motor parameter autotuning. After autotuning is done, a message will pop up indicating autotuning is succeeded, and then it will return to the main interface of stop. During autotuning, you can press **STOP/RST** key to terminate autotuning; if any fault occur during autotuning, the keypad will display a fault interface.

Figure 5-19 Parameter autotuning

16:02:35 Fwd	Local R	un GD350	]	16:02:35	Fwd	Local	Run	GD350
Autotune steps: 0				Autotune :	steps: 3			
Autotuning parame	ters			Parameter	rs autotuned	ł		
Back	Home	OK		Bac	:k	Home	в	ОК

#### 5.4.9 Parameter backup

You can choose Menu > Copy parameter/Restore default, and press skey, b key

or we key to enter the function parameter backup interface and function parameter restoration interface to upload/download VFD parameters, or restore VFD parameters to default values. The keypad has three different storage areas for parameter backup, and each storage area can save the parameters of one VFD, which means the keypad can save parameters of three VFDs in total.

Figure 5-20 Parameter backup

16:02:35 Fwd Local Ready GD350	]	16:02:35 Fwd Local Ready GD350		16:02:35 Fwd Lo	cal Ready GD350
Parameter groups		MemArea 1: BACKUP01		Upload local func para to	o keypad
User defined parameters		MemArea2: BACKUP02		Download all func para f	rom keypad
State monitoring		MemArea3: BACKUP03		Download NonMotor fun	ic para from keypad
Motor parameter autotune	4	Restore default (excl motor para)	4	Download motor func para	a from keypad
Copy parameter/Restore default		Restore default (test mode)			
System settings	∕ ≺	Restore default (incl motor para)	∕ <		
Back Home Sele		Back Home Sele		Back	Home OK

#### 5.4.10 System settings

You can choose Menu > System settings, and press 💊 key, 🕨 key or 📰 key to

enter system setting interface to set the keypad language, time/date, backlight brightness, backlight time and restore parameters.

**Note:** Clock battery is not included, and the keypad time/date needs to be reset after power off. If time-keeping after power off is needed, you should purchase the clock batteries separately.

Figure 5-21 System settings



#### 5.4.11 Power-on guiding settings

The keypad supports the power-on setup wizard function, mainly for the first power-on situation, instructing you to enter the setting menu, and gradually implementing basic functions such as basic parameter setting, direction judgment, mode setting and autotuning.

For first power-on, the keypad automatically enters the setup wizard interface. See the following.



# 5.5 Basic operation description

# 5.5.1 What this section describes

This section introduces the function modules inside the VFD.



Ensure that all terminals have been securely connected.

• Ensure that the motor power matches the VFD power.

### 5.5.2 Common commissioning procedure



The common commissioning procedure is as follows (taking motor 1 as an example).

**Note:** If a fault occurred, find out the fault cause and remove the fault according to chapter 7 Troubleshooting.

The running command channel can be set through terminal commands in addition to P00.01 and P00.02.

Channel of running commands P00.01	Multifunction terminal function 36 Switch the running command channel to	Multifunction terminal function 37 Switch the running command channel to	Multifunction terminal function 38 Switch the running command channel to
	keypad	terminal	communication
Keypad	/	Terminal	Communication
Terminal	Keypad	/	Communication
Communication	Keypad	Terminal	/

Note: "/" indicates this multifunction terminal is invalid under present reference channel.

Related parameter list:

Function code	Name	Description	Default
		0: SVC mode 0	
		1: SVC mode 1	
P00.00	Speed control	2: Space voltage vector control mode	_
	mode	3: Feedback vector control (FVC) mode	2
		Note: Before using a vector control mode, enable the	
		VFD to perform motor parameter autotuning first.	
	Channel of	0: Keypad	
P00.01	running	1: Terminal	0
	commands	2: Communication	
		0: Modbus/Modbus TCP communication	
		1: PROFIBUS/CANopen/DeviceNet	
	Communication	2: Ethernet communication	
P00.02	mode of running	3: EtherCAT/PROFINET/ EtherNet IP communication	0
	commands	4: Programmable expansion card	
		5: Wireless communication card	
		6: Reserved	
		0: No operation	
		1: Rotary autotuning 1	
	Perform motor	Comprehensive motor parameter autotuning. It is	
P00 15	narameter	recommended to use rotating autotuning when high	0
1 00.10	autotuning	control accuracy is required.	0
	autotuning.	2: Static autotuning 1 (comprehensive autotuning)	
		Motor parameter autotuning. It is applicable in scenarios	
		where the motor cannot be disconnected from load.	

Function code	Name	Description	Default
		3: Static autotuning 2 (partial autotuning)	
		When the present motor is motor 1, only P02.06, P02.07	
		and P02.08 are autotuned; when the present motor is	
		motor 2, only P12.06, P12.07 and P12.08 are	
		autotuned.	
		4: Rotary autotuning 2	
		It is similar to rotary autotuning 1 but only valid for AMs.	
		5: Static autotuning 3 (partial autotuning)	
		It is valid only for AMs.	
		0: No operation	
		1: Restore default values	
		2: Clear fault records	
		3: Reserved	
		4: Reserved	
	Function	5: Restore to default values (factory test mode)	
P00.18	parameter	6: Restore to default values (including motor	0
	restoration	parameters)	
		Note: After the selected operation is performed, the	
		function code is automatically restored to 0. Restoring	
		the default values may delete the user password.	
		Exercise caution when using this function.	
		The option 5 can be used only for factory testing.	
D02.00	Tune of motor 1	0: Asynchronous motor (AM)	0
F02.00	Type of motor 1	1: Synchronous motor (SM)	0
B02.01	Rated power of	0.1. 2000 0444	Model
F02.01	AM 1	0.1-3000.0kW	depended
P02.02	Rated frequency of AM 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
<b>D</b> 00.00	Rated speed of	4 00000	Model
P02.03	AM 1	1–60000rpm	depended
D02.04	Rated voltage of	0. 1200)/	Model
P02.04	AM 1	0-12000	depended
D02.05	Rated current of	0.0.000.04	Model
P02.05	AM 1	0.8–6000.0A	depended
D02.1F	Rated power of	0.1. 2000 01/W	Model
FU2.13	SM 1		depended
P02.16	Rated frequency of SM 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz

Function code	Name	Description	Default
P02.17	Number of pole pairs of SM 1	1–50	2
P02.18	Rated voltage of SM 1	0–1200V	Model depended
P02.19	Rated current of SM 1	0.8–6000.0A	Model depended
P05.01– P05.06	Function selection of multifunction digital input terminals (S1–	<ul><li>36: Switch the running command channel to keypad</li><li>37: Switch the running command channel to terminal</li><li>38: Switch the running command channel to communication</li></ul>	See "Group P05— Input terminal
	S4, HDIA, HDIB)		functions"
P07.01	Reserved	Ι	/
P07.02	Function of QUICK/JOG	Range: 0x00–0x27 Ones place: Function of QUICK/JOG 0: No function 1: Jog 2: Reserved 3: Switch between forward and reverse rotating 4: Clear the UP/DOWN setting 5: Coast to stop 6: Switch command channels in sequence 7: Reserved Tens place: Reserved	0x01

### 5.5.3 Vector control

AMs feature high order, nonlinearity, strong coupling and multi-variables, which increase difficulty to control AMs during actual application. The vector control technology solves this situation as follows: measures and controls the stator current vector of the AM, and then decomposes the stator current vector into exciting current (current component that generates internal magnet field) and torque current (current component that generates torque) based on field orientation principle, and therefore controls the amplitude values and phase positions of the two components (namely, controls the stator current vector of the AM) to realize decoupled control on exciting current and torque current, thus achieving high-performance speed regulation of the AM.

The VFD uses the sensor-less vector control algorithm, which can be used to drive AMs and permanent-magnet SMs simultaneously. As the core algorithm of vector control is based on

accurate motor parameter models, the accuracy of motor parameters affects vector control performance. It is recommended to enter accurate motor parameters and autotune motor parameters before executing vector control.

As the vector control algorithm is complicated, exercise caution before modifying vector control function parameters.



Function code	Name	Description	Default
P00.00	Speed control mode	0: SVC mode 0	
		1: SVC mode 1	
		2: Space voltage vector control mode	2
		3: Feedback vector control (FVC) mode	2
		Note: Before using a vector control mode, enable the	
		VFD to perform motor parameter autotuning first.	
P00.15		0: No operation	
		1: Rotary autotuning 1	
		Comprehensive motor parameter autotuning. It is	
	Perform motor	recommended to use rotating autotuning when high	
	parameter	control accuracy is required.	0
	autotuning.	2: Static autotuning 1 (comprehensive autotuning)	
		Motor parameter autotuning. It is applicable in	
		scenarios where the motor cannot be disconnected	
		from load.	

Function code	Name	Description	Default
		3: Static autotuning 2 (partial autotuning) When the present motor is motor 1, only P02.06,	
		motor is motor 2, only P12.06, P12.07 and P12.09 are	
		autotuped	
		4. Rotary autotuning 2	
		It is similar to rotary autotuning 1 but only valid for AMs	
		5: Static autotuning 3 (partial autotuning)	
		It is valid only for AMs.	
		0: Asynchronous motor (AM)	
P02.00	Type of motor 1	1: Synchronous motor (SM)	0
P03.00	Speed-loop proportional gain 1	0–200.0	20.0
P03.01	Speed-loop integral time 1	0.000–10.000s	0.200s
P03.02	Low-point frequency for switching	0.00Hz–P03.05	5.00Hz
P03.03	Speed-loop proportional gain 2	0–200.0	20.0
P03.04	Speed-loop integral time 2	0.000–10.000s	0.200s
P03.05	High-point frequency for switching	P03.02–P00.03 (Max. output frequency)	10.00Hz
P03.06	Speed-loop output filter	0–8 (0–2 <sup>8</sup> /10ms)	0
P03.07	Electromotive slip compensation coefficient of vector control	50%–200%	100%
P03.08	Braking slip compensation coefficient of vector control	50%–200%	100%
P03.09	Current-loop proportional coefficient P	0–65535	1000
P03.10	Current-loop integral coefficient I	0–65535	1000
P03.32	Enabling torque	0: Disable	0

Function code	Name	Description	Default
	control	1: Enable	
P03.11	Torque setting method selection	1: Enable 1: Keypad (P03.12) 2: Al1 3: Al2 4: Al3 5: Pulse frequency HDIA 6: Multi-step torque 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: Pulse frequency HDIB 11: EtherCAT/PROFINET/ EtherNet IP communication 12: Programmable expansion card	0
<b>D</b> 00.40	Torque set through	Note: For these settings, 100% corresponds to the motor rated current.	50.0%
P03.13	keypad Torque reference filter time	0.000–10.000s	0.010s
P03.14	Setting source of forward rotation frequency upper limit in torque control	0: Keypad (P03.16) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: Pulse frequency HDIB 10: EtherCAT/PROFINET/ EtherNet IP communication 11: Programmable expansion card 12: Reserved Note: 100% corresponds to the max. frequency.	0
P03.15	Setting source of reverse rotation	0: Keypad (P03.17) 1–11: Same as those for P03.14	0

Function code	Name	Description	Default
	upper-limit frequency in torque control		
P03.16	Forward rotation frequency upper limit set through keypad in torque control		50.00Hz
P03.17	Reverse rotation upper-limit frequency set through keypad in torque control	Setting range: 0.00 Hz–P00.03 (Max. output frequency)	50.00Hz
P03.18	Setting source of electromotive torque upper limit	0: Keypad (P03.20) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Modbus/Modbus TCP communication 6: PROFIBUS/CANopen/DeviceNet communication 7: Ethernet communication 8: Pulse frequency HDIB 9: EtherCAT/PROFINET/ EtherNet IP communication 10: Programmable expansion card 11: Reserved Note: For these settings, 100% corresponds to the motor rated current.	0
P03.19	Setting source of braking torque upper limit	0: Keypad (P03.21) 1–10: Same as those for P03.18	0
P03.20	Electromotive torque upper limit set through keypad	0.0-300.0% (of the motor rated current)	180.0%
P03.21	Braking torque upper limit set through keypad	0.0-500.0% (of the motor rated current)	180.0%
P03.22	Weakening coefficient in constant power zone	0.1–2.0	0.3
P03.23	Lowest weakening point in constant	10%–100.0%	20%

÷.

Function code	Name	Description	Default
	power zone		
P03.24	Max. voltage limit	0.0–120.0%	100.0%
P03.25	Pre-exciting time	0.000–10.000s	0.300s
D00.00	Enabling torque	0: Disable	0
P03.32	control	1: Enable	0
	Flux-weakening	0.0000	1000
P03.33	integral gain	0-8000	
		0–0x1111	
		Ones place: Torque command selection	
		0: Torque reference	
		1: Torque current reference	
		Tens place: Reserved	
		0: Reserved	
	O and the last time is a time.	1: Reserved	
P03.35		Hundreds place: indicates whether to enable	0x0000
	setting	speed-loop integral separation	
		0: Disable	
		1: Enable	
		Thousands place: Reserved	
		0: Reserved	
		1: Reserved	
		Range: 0x0000–0x1111	
<b>D</b> 22 2 2	Speed-loop		
P03.36	differential gain	0.00–10.00s	0.00s
	Proportional	In the FVC mode (P00.00=3), when the frequency is	
<b>D</b> 00.07	coefficient of	lower than the current-loop high-frequency switching	1000
P03.37	high-frequency	threshold (P03.39), the current-loop PI parameters are	
	current loop	P03.09 and P03.10; and when the frequency is higher	
	Integral coefficient of	than the current-loop high-frequency switching	
P03.38	high-frequency	threshold, the current-loop PI parameters are P03.37	1000
	current loop	and P03.38.	
P03.39	Current-loop	Setting range of P03.37: 0–65535	
	high-frequency	Setting range of P03.38: 0–65535	100.0%
		Setting range of P03.39: 0.0-100.0% (of the max.	
		frequency)	
P17.32	Flux linkage	0.0–200.0%	0.0%

#### 5.5.4 Space voltage vector control mode

The VFD carries built-in SVPWM control function. SVPWM mode can be used in cases where mediocre control precision is enough. In cases where a VFD needs to drive multiple motors, it is also recommended to adopt SVPWM control mode.

The VFD provides multiple V/F curve modes to meet different requirements. You can select V/F curves or set V/F curves as required.

#### Suggestions:

- For the load featuring constant moment, such as conveyor belt which runs in straight line, as the whole running process requires constant moment, it is recommended to adopt the straight line V/F curve.
- For the load featuring decreasing moment, such as fan and water pumps, as there is a power (square or cube) relation between its actual torque and speed, it is recommended to adopt the V/F curve corresponding to the power of 1.3, 1.7 or 2.0.



The VFD also provides multi-point V/F curves. You can change the V/F curves output by the VFD by setting the voltage and frequency of the three points in the middle. A whole curve consists of five points starting from (0Hz, 0V) and ending at (motor fundamental frequency, motor rated voltage). During setting, follow the rule:  $0 \le f1 \le f2 \le f3 \le$  Motor fundamental frequency, and,  $0 \le V1 \le V2 \le V3 \le$  Motor rated voltage



The VFD provides dedicated function codes for the space voltage control mode. You can

improve the space voltage control performance by means of setting.

## (1) Torque boost

The torque boost function can effectively compensate for the low-speed torque performance in space voltage control. Automatic torque boost has been set by default, which enables the VFD to adjust the torque boost value based on actual load conditions.

Note:

- Torque boost takes effect only at the torque boost cut-off frequency.
- If torque boost is too large, the motor may encounter low-frequency vibration or overcurrent. If such a situation occurs, reduce the torque boost value.



## (2) Energy-saving run

During actual running, the VFD can search for the max. efficiency point to keep running in the most efficient state to save energy.

## Note:

- This function is generally used in light load or no-load cases.
- This function is no applicable to the cases where sudden load changes often occur.

## (3) V/F slip compensation gain

Space voltage vector control belongs to an open-loop mode. Sudden motor load changes cause motor speed fluctuation. In cases where strict speed requirements must be met, you can set the slip compensation gain to compensate for the speed change caused by load fluctuation through VFD internal output adjustment.

The setting range of slip compensation gain is 0–200%, in which 100% corresponds to the rated slip frequency.

**Note:** Rated slip frequency = (Rated synchronous rotation speed of motor – Rated rotation speed of motor) x (Number of motor pole pairs)/60

## (4) Oscillation control

Motor oscillation often occurs in space voltage vector control in large-power driving applications. To solve this problem, the VFD provides two oscillation factor function codes. You

can set the function codes based on the oscillation occurrence frequency.

**Note:** A greater value indicates better control effect. However, if the value is too large, the VFD output current may be too large.

Customized V/F curve (V/F separation) function:



When selecting the customized V/F curve function, you can specify the setting channels and acceleration/deceleration time of voltage and frequency respectively, which form a real-time V/F curve in combination manner.

**Note:** This type of V/F curve separation can be applied in various variable-frequency power sources. However, exercise caution when setting parameters as improper settings may cause equipment damage.

Function code	Name	Description	Default
		0: SVC mode 0 1: SVC mode 1 2: Space voltage vector control mode	
P00.00	Speed control mode	3: Feedback vector control (FVC) mode <b>Note:</b> Before using a vector control mode (0, 1, or 3), enable the VFD to perform motor parameter autotuning first.	2
P00.03	Max. output frequency	P00.04–599.00Hz	50.00Hz
P00.04	Upper limit of running frequency	P00.05–P00.03	50.00Hz
P00.05	Lower limit of running frequency	0.00Hz–P00.04	0.00Hz
P00.11	ACC time 1	0.0–3600.0s	Model depended
P00.12	DEC time 1	0.0–3600.0s	Model depended
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0
P02.02	Rated frequency of AM 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
P02.04	Rated voltage of AM 1	0–1200V	Model depended
P04.00	V/F curve setting of motor 1	0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F curve (V/F separation)	0
P04.01	Torque boost of motor 1	0.0%: (automatic); 0.1%–10.0%	0.0%
P04.02	Torque boost cut-off of motor 1	0.0%–50.0% (of the rated frequency of motor 1)	20.0%
P04.03	V/F frequency point 1 of motor 1	0.00Hz–P04.05	0.00Hz
P04.04	V/F voltage point 1 of motor 1	0.0%–110.0%	0.0%

Function code	Name	Description	Default
P04.05	V/F frequency point 2 of motor 1	P04.03–P04.07	0.00Hz
P04.06	V/F voltage point 2 of motor 1	0.0%–110.0%	0.0%
P04.07	V/F frequency point 3 of motor 1	P04.05–P02.02 or P04.05–P02.16	0.00Hz
P04.08	V/F voltage point 3 of motor 1	0.0%–110.0%	0.0%
P04.09	V/F slip compensation gain of motor 1	0.0–200.0%	100.0%
P04.10	Low-frequency oscillation control factor of motor 1	0–100	10
P04.11	High-frequency oscillation control factor of motor 1	0–100	10
P04.12	Oscillation control threshold of motor 1	0.00Hz–P00.03 (Max. output frequency)	30.00Hz
P04.13	V/F curve setting of motor 2	0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F curve (V/F separation)	0
P04.14	Torque boost of motor 2	0.0%: (automatic); 0.1%–10.0%	0.0%
P04.15	Torque boost cut-off of motor 2	0.0%–50.0% (of the rated frequency of motor 1)	20.0%
P04.16	V/F frequency point 1 of motor 2	0.00Hz–P04.18	0.00Hz
P04.17	V/F voltage point 1 of motor 2	0.0%–110.0%	0.0%
P04.18	V/F frequency point 2 of motor 2	P04.16–P04.20	0.00Hz
P04.19	V/F voltage point 2 of motor 2	0.0%–110.0%	0.0%
P04.20	V/F voltage point 3 of motor 2	P04.18–P02.02 or P04.18–P02.16	0.00Hz
P04.21	V/F voltage point 3 of	0.0%–110.0%	0.0%
Function code	Name	Description	Default
---------------	---	--	---------
	motor 2		
P04.22	V/F slip compensation gain of motor 2	0.0–200.0%	100.0%
P04.23	Low-frequency oscillation control factor of motor 2	0–100	10
P04.24	High-frequency oscillation control factor of motor 2	0–100	10
P04.25	Oscillation control threshold of motor 2	0.00Hz–P00.03 (Max. output frequency)	30.00Hz
P04.26	Energy-saving run	0: Disable 1: Automatic energy-saving run	0
P04.27	Voltage setting channel selection	0: Keypad; Output voltage is determined by P04.28. 1: Al1 2: Al2 3: Al3 4: HDIA 5: Multi-step running 6: PID 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: HDIB 11: EtherCAT/PROFINET/ EtherNet IP communication 12: Programmable expansion card 13: Reserved	0
P04.28	Voltage set through keypad	0.0%–100.0% (of the motor rated voltage)	100.0%
P04.29	Voltage increase time	0.0–3600.0s	5.0s
P04.30	Voltage decrease time	0.0–3600.0s	5.0s
P04.31	Max. output voltage	P04.32 –100.0% (of the motor rated voltage)	100.0%
P04.32	Min. output voltage	0.0%–P04.31 (motor rated voltage)	0.0%
P04.33	Weakening coefficient in constant power zone	1.00–1.30	1.00
P04.34	Pull-in current 1 in SM V/F control	When the SM VF control mode is enabled, the function code is used to set the reactive current of the motor when the output frequency is lower	20.0%

Function code	Name	Description	Default
		than the frequency specified by P04.36. Setting range: -100.0%-+100.0% (of the motor rated current)	
P04.35	Pull-in current 2 in SM V/F control	When the SM VF control mode is enabled, the function code is used to set the reactive current of the motor when the output frequency is higher than the frequency specified by P04.36. Setting range: -100.0%-+100.0% (of the motor rated current)	10.0%
P04.36	Frequency threshold for pull-in current switching in SM V/F control	When the SM VF control mode is enabled, the function code is used to set the frequency threshold for the switching between pull-in current 1 and pull-in current 2. Setting range: 0.0%–200.0% (of the motor rated frequency)	20.0%
P04.37	Reactive current closed-loop proportional coefficient in SM V/F control	When the SM VF control mode is enabled, the function code is used to set the proportional coefficient of reactive current closed-loop control. Setting range: 0–3000	50
P04.38	Reactive current closed-loop integral time in SM V/F control	When the SM VF control mode is enabled, the function code is used to set the integral coefficient of reactive current closed-loop control. Setting range: 0–3000	30
P04.39	Reactive current closed-loop output limit in SM VF control	When the SM VF control mode is enabled, the function code is used to set the output limit of the reactive current closed-loop control. A greater value indicates a higher reactive closed-loop compensation voltage and higher output power of the motor. In general, you do not need to modify the function code. Setting range: 0–16000	8000
P04.40	Enabling IF mode for AM 1	0: Disable 1: Enable	0
P04.41	Current setting in IF mode for AM 1	When IF control is adopted for AM 1, the function code is used to set the output current. The value is a percentage in relative to the rated current of the motor.	120.0%

Function code	Name	Description	Default
		Setting range: 0.0–200.0%	
P04.42	Proportional coefficient in IF mode for AM 1	When IF control is adopted for AM 1, the function code is used to set the proportional coefficient of the output current closed-loop control. Setting range: 0–5000	350
P04.43	Integral coefficient in IF mode for AM 1	When IF control is adopted for AM 1, the function code is used to set the integral coefficient of the output current closed-loop control. Setting range: 0–5000	150
P04.44	Starting frequency point for switching off IF mode for AM 1	0.00–P04.50	10.00Hz
P04.45	Enabling IF mode for AM 2	0: Disable 1: Enable	0
P04.46	Current setting in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the output current. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–200.0%	120.0%
P04.47	Proportional coefficient in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the proportional coefficient of output current closed-loop control. Setting range: 0–5000	350
P04.48	Integral coefficient in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the integral coefficient of output current closed-loop control. Setting range: 0–5000	150
P04.49	Starting frequency point for switching off IF mode for AM 2	0.00–P04.51	10.00Hz
P04.50	End frequency point for switching off IF mode for AM 1	P04.44–P00.03	25.00Hz
P04.51	End frequency point for switching off IF mode for AM 2	P04.49–P00.03	25.00Hz

### 5.5.5 Torque control

The VFD supports torque control and speed control. Speed control aims to stabilize the speed to keep the set speed consistent with the actual running speed, meanwhile, the max. load-carrying capacity is restricted by the torque limit. Torque control aims to stabilize the torque to keep the set torque consistent with the actual output torque, meanwhile, the output frequency is restricted by the upper and lower limits.



Function code	Name	Description	Default
P00.00	Speed control mode	0: SVC mode 0 1: SVC mode 1 2: Space voltage vector control mode 3: Feedback vector control (FVC) mode <b>Note:</b> Before using a vector control mode (0, 1, or 3), enable the VFD to perform motor parameter autotuning first.	2
P03.32	Enabling torque control	0: Disable 1: Enable	0
P03.11	Torque setting method selection	0: Keypad (P03.12) 1: Keypad (P03.12) 2: Al1 3: Al2 4: Al3 5: Pulse frequency HDIA 6: Multi-step torque 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: Pulse frequency HDIB 11: EtherCAT/PROFINET/ EtherNet IP communication 12: Programmable expansion card Note: For these settings, 100% corresponds to the motor rated current.	0
P03.12	Torque set through keypad	-300.0%–300.0% (of the motor rated current)	50.0%
P03.13	Torque reference filter time	0.000–10.000s	0.010s
P03.14	Setting source of forward rotation frequency upper limit in torque control	0: Keypad (P03.16) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: Pulse frequency HDIB	0

Function code	Name	Description	Default
		10: EtherCAT/PROFINET/ EtherNet IP communication 11: Programmable expansion card 12: Reserved Note: 100% corresponds to the max_frequency	
P03.15	Setting source of reverse rotation upper-limit frequency in torque control	0: Keypad (P03.17) 1–11: Same as those for P03.14	0
P03.16	Forward rotation frequency upper limit set through keypad in torque control	0.00Hz–P00.03 (Max. output frequency)	50.00 Hz
P03.17	Reverse rotation upper-limit frequency set through keypad in torque control	0.00Hz–P00.03 (Max. output frequency)	50.00 Hz
P03.18	Setting source of electromotive torque upper limit	0: Keypad (P03.20) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Modbus/Modbus TCP communication 6: PROFIBUS/CANopen/DeviceNet communication 7: Ethernet communication 8: Pulse frequency HDIB 9: EtherCAT/PROFINET/ EtherNet IP communication 10: Programmable expansion card 11: Reserved Note: For these settings, 100% corresponds to the motor rated current.	0
P03.19	Setting source of braking torque upper limit	0: Keypad (P03.21) 1–10: Same as those for P03.18	0
P03.20	Electromotive torque upper limit set through keypad	0.0-300.0% (of the motor rated current)	180.0%

Function	Name	Description	Default
code	Nume	Description	Deruun
	Braking torque		
P03.21	upper limit set	0.0–300.0% (of the motor rated current)	180.0%
	through keypad		
P17.09	Output torque	-250.0–250.0%	0.0%
P17.15	Torque reference	200.0. 200.0% (of the motor rated ourrent)	0.09/
	value	-300.0–300.0% (of the motor rated current)	0.0%

## 5.5.6 Motor parameters

	Check the safety conditions surrounding the motor and load machineries before
	autotuning as physical injury may occur due to sudden start of motor during
	autotuning.
<u>7</u>	Although the motor does not run during static autotuning, the motor is still supplied
	with power. Do not touch the motor during autotuning; otherwise, electric shock
	may occur. Do not touch the motor before autotuning is completed.
	If the motor has been connected to a load, do not carry out rotary autotuning.
	Otherwise, the VFD may malfunction or may be damaged. If rotary autotuning is carried
	out on a motor which has been connected to a load, incorrect motor parameter settings
	and motor action exceptions may occur. Disconnect from the load to carry out
	autotuning if necessary.

The VFD can drive both asynchronous motors and synchronous motors, and it supports two sets of motor parameters, which can be switched over by multifunction digital input terminals or communication modes.



The control performance of the VFD is based on accurate motor models. Therefore, you need to carry out motor parameter autotuning before running a motor for the first time (taking motor 1 as an example).



#### Note:

- Motor parameters must be set correctly according to the motor nameplate.
- If rotary autotuning is selected during motor autotuning, disconnect the motor from the load to put the motor in static and no-load state. Otherwise, the motor parameter autotuning results may be incorrect. In addition, autotune P02.06–P02.10 for AMs and autotune P02.20–P02.23 for SMs.

- If static autotuning is selected for motor autotuning, there is no need to disconnect the motor from the load, but the control performance may be impacted as only a part of the motor parameters have been autotuned. In addition, autotune P02.06–P02.10 for AMs and autotune P02.20–P02.22 for SMs. P02.23 can be obtained through calculation.
- Motor autotuning can be carried out on the present motor only. If you need to perform autotuning on the other motor, switch the motor through selecting the switch-over channel of motor 1 and motor 2 by setting the ones place of P08.31.

Function code	Name	Description	Default
	Channel of supping	0: Keypad	
P00.01		1: Terminal	0
	commands	2: Communication	
		0: No operation	
		1: Rotary autotuning 1	
		Comprehensive motor parameter autotuning. It	
		is recommended to use rotating autotuning	
		when high control accuracy is required.	
		2: Static autotuning 1 (comprehensive	
		autotuning)	
		Motor parameter autotuning. It is applicable in	
		scenarios where the motor cannot be	
D00 15	Perform motor parameter disconnected from load.	disconnected from load.	0
P00.15	autotuning.	3: Static autotuning 2 (partial autotuning)	0
		When the present motor is motor 1, only	
		P02.06, P02.07 and P02.08 are autotuned;	
		when the present motor is motor 2, only	
		P12.06, P12.07 and P12.08 are autotuned.	
		4: Rotary autotuning 2	
		It is similar to rotary autotuning 1 but only valid	
		for AMs.	
		5: Static autotuning 3 (partial autotuning)	
		It is valid only for AMs.	
<b>D02 00</b>	Turne of motor 1	0: Asynchronous motor (AM)	0
P02.00	Type of motor 1	1: Synchronous motor (SM)	0
D02.04	Dated power of AM 1	0.1. 2000 0000	Model
P02.01		U. 1-3000.0KW	depended
P02.02	Rated frequency of AM 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
P02.03	Rated speed of AM 1	1–60000rpm	Model

Function code	Name	Description	Default
			depended
D02.04	Deted voltage of AM 1	0.1200\/	Model
PU2.04 Rated Volt	Rated voltage of AW 1	0-12000	depended
D02.05	Doted ourrant of AM 1	0.8, 6000.04	Model
P02.05		0.6-6000.0A	depended
P02.06	Stator resistance of AM 1	0.001 65 5350	Model
F02.00		0.001-05.5552	depended
P02.07	Rotor resistance of AM 1	0 001-65 5350	Model
1 02.07	Notor resistance of Aim T	0.001-00.0002	depended
P02.08	Leakage inductance of	0 1_6553 5mH	Model
1 02.00	AM 1	0.1-0000.0111	depended
P02.09	Mutual inductance of AM	0 1_6553 5mH	Model
1 02.03	1		depended
P02 10	No-load current of AM 1	0 1-6553 54	Model
1 02.10		0.1-0000.0A	depended
P02 15	Rated power of SM 1	0 1–3000 0kW	Model
1 02.10	Rated power of SWI 1	0.1-5000.0kW	depended
P02.16	Rated frequency of SM 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
P02.17	Number of pole pairs of SM 1	1–50	2
D00.40	Detection to a f OM 4	0–1200V	Model
P02.18	Rated voltage of SIVET		depended
D02.40	Detect surrout of CM 4	1       0.1–6553.5A         1       0.1–3000.0kW         Λ1       0.01Hz–P00.03 (Max. output frequency)         of       1–50         1       0–1200V         1       0.8–6000.0A         Λ1       0.001–65.535Ω	Model
P02.19	Rated current of SWT	0.6-8000.0A	depended
<b>D</b> 02.20	Stator registered of SM 1	0.001 65 5350	Model
F02.20		0.001-05.55552	depended
D02 21	Direct-axis inductance of		Model
FU2.21	SM 1	0.01-055.55000	depended
P02 22	Quadrature-axis	0.01 655 35mH	Model
F 02.22	inductance of SM 1	0.01-033.331111	depended
P02.23	Counter-emf constant of SM 1	0–10000	300
	Eurotion selection of		See
P05.01	Function selection of multifunction digital input terminals (S1–S4, HDIA, HDIB)	35: Switch from motor 1 to motor 2	"Group
P05.01– P05.06			P05—
			Input
			terminal

Function code	Name	Description	Default
			functions"
P08.31	Switching between motor 1 and motor 2	0x00–0x14 Ones place: Switchover channel 0: Terminal 1: Modbus/Modbus TCP communication 2: PROFIBUS/CANopen/DeviceNet communication 3: Ethernet communication 4: EtherCAT/PROFINET/ EtherNet IP communication Tens place: indicates whether to enable switchover during running 0: Disable 1: Enable	00
P12.00	Type of motor 2	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0
P12.01	Rated power of AM 2	0.1–3000.0kW	Model depended
P12.02	Rated frequency of AM 2	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
P12.03	Rated speed of AM 2	1–36000rpm	Model depended
P12.04	Rated voltage of AM 2	0–1200V	Model depended
P12.05	Rated current of AM 2	0.8–6000.0A	Model depended
P12.06	Stator resistance of AM 2	0.001–65.535Ω	Model depended
P12.07	Rotor resistance of AM 2	0.001–65.535Ω	Model depended
P12.08	Leakage inductance of AM 2	0.1–6553.5mH	Model depended
P12.09	Mutual inductance of AM 2	0.1–6553.5mH	Model depended
P12.10	No-load current of AM 2	0.1–6553.5A	Model depended
P12.15	Rated power of SM 2	0.1–3000.0kW	Model depended

Function code	Name	Description	Default
P12.16	Rated frequency of SM 2	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
P12.17	Number of pole pairs of SM 2	1–50	2
P12.18	Rated voltage of SM 2	0–1200V	Model depended
P12.19	Rated current of SM 2	0.8–6000.0A	Model depended
P12.20	Stator resistance of SM 2	0.001–65.535Ω	Model depended
P12.21	Direct-axis inductance of SM 2	0.01–655.35mH	Model depended
P12.22	Quadrature-axis inductance of SM 2	0.01–655.35mH	Model depended
P12.23	Counter-emf constant of SM 1	0–10000	300

### 5.5.7 Start/stop control

The start/stop control of the VFD involves three states: start after a running command is given at power-on; start after power-off restart is effective; start after automatic fault reset. The three start/stop control states are described in the following.

There are three start modes for the VFD, which are start at starting frequency, start after DC braking, and start after speed tracking. You can select the proper start mode based on actual conditions.

For large-inertia load, especially in cases where reversal may occur, you can choose to start after DC braking or start after speed tracking.

Note: It is recommended to drive SMs in direct start mode.



1. Logic diagram for start after a running command is given at power-on

## 2. Logic diagram for start after power-off restart is effective



3. Logic diagram for start after automatic fault reset



Function code	Name	Description	Default
P00.01	Channel of running commands	0: Keypad 1: Terminal 2: Communication	0
P00.11	ACC time 1	0.0–3600.0s	Model depended
P00.12	DEC time 1	0.0–3600.0s	Model depended
P01.00	Running mode of start	0: Direct start 1: Start after DC braking 2: Start after speed tracking	0
P01.01	Starting frequency of direct start	0.00–50.00Hz	0.50Hz

Function code	Name	Description	Default
P01.02	Hold time of starting frequency	0.0–50.0s	0.0s
P01.03	Braking current before start	0.0–100.0%	0.0%
P01.04	DC braking time before start	0.00–50.00s	0.00s
P01.05	ACC and DEC mode	0: Linear 1: S curve <b>Note:</b> If mode 1 is selected, set P01.06, P01.07, P01.27 and P01.08 accordingly.	0
P01.08	Stop mode	0: Decelerate to stop 1: Coast to stop	0
P01.09	Starting frequency of braking for stop	0.00Hz–P00.03 (Max. output frequency)	0.00Hz
P01.10	Wait time before DC braking for stop	0.00–50.00s	0.00s
P01.11	DC braking current for stop	0.0–100.0%	0.0%
P01.12	DC braking time for stop	0.00–50.00s	0.00s
P01.13	FWD/REV run deadzone time	0.0–3600.0s	0.0s
P01.14	FWD/REV run switching mode	<ul><li>0: Switch at zero frequency</li><li>1: Switch at the starting frequency</li><li>2: Switch after the speed reaches the stop speed with a delay</li></ul>	1
P01.15	Stop speed	0.00–100.00Hz	0.50 Hz
P01.16	Stop speed detection mode	<ul><li>0: Detect by the set speed (unique in space voltage vector control mode)</li><li>1: Detect according to speed feedback</li></ul>	1
P01.18	Terminal-based running command protection at power-on	0: The terminal running command is invalid at power-on 1: The terminal running command is valid at power-on	0
P01.19	Action selected when running frequency less than frequency lower limit (valid when frequency lower limit greater than 0)	Setting range: 0x00–0x12 Ones place: Action selection 0: Run at the frequency lower limit 1: Stop 2: Sleep Tens place: Stop mode	0x00

Function code	Name	Description	Default
		0: Coast to stop	
		1: Decelerate to stop	
D04.00		0.0-3600.0s (valid only when P01.19 ones	0.0-
P01.20	vvake-up-from-sleep delay	place=2)	0.0s
D04.04	Destart offer a surrant off	0: Disable	0
P01.21	Restart after power off	1: Enable	0
P01.22	Wait time for restart after power-off	0.0–3600.0s (valid when P01.21 is 1)	1.0s
P01.23	Start delay	0.0–60.0s	0.0s
P01.24	Stop speed delay	0.0–100.0s	0.0s
		0: Output without voltage	
P01.25	Open-loop 0Hz output	1: Output with voltage	0
	selection	2: Output with the DC braking current for stop	
P01.26	DEC time for emergency stop	0.0–60.0s	2.0s
P01.27	Time of starting segment of DEC S curve	0.0–50.0s	0.1s
P01.28	Time of ending segment of DEC S curve	0.0–50.0s	0.1s
P01.29	Short-circuit braking current	0.0–150.0% (of the VFD rated Output current)	0.0%
P01.30	Hold time of short-circuit braking for start	0.00–50.00s	0.00s
P01.31	Hold time of short-circuit braking for stop	0.00–50.00s	0.00s
P01.32	Pre-exciting time for jogging	0–10.000s	0.300s
P01.33	Starting frequency of braking for stop in jogging	0–P00.03	0.00Hz
P01.34	Sleep delay	0–3600.0s	0.0s
		1: Run forward	See
		2: Run reversely	"Group
P05.01	Digital input function	4: Jog forward	P05
P05.06	selection	5: Jog reversely	Input
F 00.00	3010011	6: Coast to stop	terminal
		7: Reset faults	functions"
		8: Pause running	10110115

Function code	Name	Description	Default
	21: ACC/DEC time selection 1		
		22: ACC/DEC time selection 2	
		30: Disable ACC/DEC	
P08.06	Running frequency of jog	0.00Hz–P00.03 (Max. output frequency)	5.00Hz
P08.07	ACC time for jogging	0.0–3600.0s	Model
P08.08	DEC time for jogging	0.0–3600.0s	Model
			aepenaea
P08.00	ACC time 2	0.0–3600.0s	Model
			depended
P08.01	DEC time 2	0.0–3600.0s	Model
			depended
P08.02	ACC time 3	0.0–3600.0s	Model
			depended
P08.03	DEC time 3	0.0–3600.0s	Model
			depended
P08.04	ACC time 4	0.0–3600.0s	Model
1 00.01			depended
P08.05	DEC time 4	0.0-3600.0s	Model
1 00.00	DEO time 4	0.0-0000.03	depended
		0.00–P00.03(Max. frequency)	
D09.10	Switching frequency of	0.00Hz: No switchover	0
F00.19	ACC/DEC time	If the running frequency is greater than	0
		P08.19, switch to ACC/DEC time 2.	
		0: Max. output frequency	
D00.04	Reference frequency of	1: Set frequency	0
P08.21	ACC/DEC time	2: 100Hz	0
		Note: Valid for straight-line ACC/DEC only.	
P08.28	Auto fault reset count	0–10	0
P08.29	Auto fault reset interval	0.1–3600.0s	1.0s

## 5.5.8 Frequency setting

The VFD supports multiple kinds of frequency reference modes, which can be categorized into two types: main reference channel and auxiliary reference channel.

There are two main reference channels, namely frequency reference channel A and frequency reference channel B. These two channels support simple arithmetical operation between each other, and they can be switched dynamically by setting multifunction terminals.

There is one input mode for auxiliary reference channel, namely terminal UP/DOWN switch input. By setting function codes, you can enable the corresponding reference mode and the impact made on the VFD frequency reference by this reference mode.

The VFD actual reference is comprised of the main reference channel and auxiliary reference channel.



The VFD supports switch-over between different reference channels, and the rules for channel switch-over are shown as follows.

Present reference channel P00.09	Multifunction terminal function 13 (Switch from channel A to channel B)	Multifunction terminal function 14 (Switch from combined setting to channel A)	Multifunction terminal function 15 (Switch from combined setting to channel B)
А	В	/	/
В	А	/	/
A+B	/	А	В
A-B	/	А	В
Max(A, B)	/	A	В
Min(A, B)	/	A	В

Note: "/" indicates this multifunction terminal is invalid under present reference channel.

When setting the auxiliary frequency inside the VFD via multi-function terminal UP (10) and DOWN (11), you can increase/decrease the frequency quickly by setting P08.45 (Frequency increment integral rate of the UP terminal) and P08.46 (Frequency increment change rate of the DOWN terminal).



Related parameter list:			
Function code	Name	Description	Default
P00.03	Max. output frequency	P00.04–599.00Hz	50.00Hz
P00.04	Upper limit of running frequency	P00.05–P00.03	50.00Hz
P00.05	Lower limit of running frequency	0.00Hz–P00.04	0.00Hz
P00.06	Setting channel of A frequency command	0: Keypad 1: Al1	0
P00.07	Setting channel of B frequency command	2: Al2 3: Al3 4: High-speed pulse HDIA	15

Related	parameter	list
---------	-----------	------

Function code	Name	Description	Default
		5: Simple PLC program 6: Multi-step speed running 7: PID control 8: Modbus/Modbus TCP communication 9: PROFIBUS/CANopen/DeviceNet communication 10: Ethernet communication 11: High-speed pulse HDIB 12: Pulse train AB 13: EtherCAT/PROFINET/ EtherNet IP communication 14: Programmable expansion card 15: Reserved	
P00.08	Reference object of B frequency command	0: Max. output frequency 1: A frequency command	0
P00.09	Combination mode of setting source	0: A 1: B 2: (A+B) 3: (A-B) 4: Max(A, B) 5: Min(A, B)	0
P05.01– P05.06	Function selection of multifunction digital input terminals (S1–S4, HDIA, HDIB)	<ul> <li>10: Increase frequency setting (UP)</li> <li>11: Decrease frequency setting (DOWN)</li> <li>12: Clear the frequency increase/decrease setting</li> <li>13: Switch between A setting and B setting</li> <li>14: Switch between combination setting and A setting</li> <li>15: Switch between combination setting and B setting</li> </ul>	See "Group P05— Input terminal functions"
P08.42	Reserved	/	/
P08.43	Reserved	/	/
P08.44	UP/DOWN terminal control setting	0x000–0x221 Ones place: Frequency setting selection 0: The setting made through UP/DOWN is valid. 1: The setting made through UP/DOWN is invalid.	0x000

Goodrive350 IP55 High-ingress Protection Series VFD

Function	Name	Description	Default
0000		Tens place: Frequency control selection	
		0: Valid only when P00.06=0 or P00.07=0	
		1: Valid for all frequency setting methods	
		2: Invalid for multi-step speed running	
		when multi-step speed running has the	
		priority	
		Hundreds place: Action selection for stop	
		0: Setting is valid.	
		1: Valid during running, cleared after stop	
		2: Valid during running, cleared after a stop	
		command is received	
P08.45	Frequency increment integral rate of the UP terminal	0.01–50.00Hz/s	0.50 Hz/s
D09.46	Frequency integral rate of the		
P00.40	DOWN terminal	0.01-50.00HZ/S	0.50 HZ/S
P17.00	Set frequency	0.00Hz–P00.03 (Max. output frequency)	0.00Hz
P17.02	Ramp reference frequency	0.00Hz–P00.03 (Max. output frequency)	0.00Hz
P17.14	Digital adjustment value	0.00Hz–P00.03 (Max. output frequency)	0.00Hz

# 5.5.9 Analog input

The VFD carries two analog input terminals (AI1 is 0–10V/0–20mA (voltage input or current input can be set by P05.50); AI2 is -10–10V) and two high-speed pulse input terminals. Each input can be filtered separately, and the corresponding reference curve can be set by adjusting the reference corresponds to the max. value and min. value.



Function code	Name	Description	Default	
		0x00–0x11		
		Ones place: HDIA input type		
		0x00-0x11         Ones place: HDIA input type         0: HDIA is high-speed pulse input         1: HDIA is digital input         0x00         Tens place: HDIB input type         0: HDIB is high-speed pulse input         1: HDIB is digital input         0:00V-P05.26         0:00V         1         -300.0%         1         -300.0%         1		
P05.00	HDI input type	1: HDIA is digital input	0x00	
		Tens place: HDIB input type		
		0: HDIB is high-speed pulse input		
		1: HDIB is digital input		
P05.24	Al1 lower limit	0.00V–P05.26	0.00V	
P05.25	Corresponding setting of AI1 lower limit	-300.0%–300.0%	0.0%	
P05.26	AI1 upper limit	P05.24–10.00V	10.00V	
P05 27	Corresponding setting of AI1	-300.0%-300.0%	100.0%	
1 00.21	upper limit		100.070	
P05.28	AI1 input filter time	0.000s–10.000s	0.100s	
P05.29	AI2 lower limit	-10.00V–P05.31	-10.00V	

Function	Name	Description	Default	
coue	Corresponding acting of AID			
P05.30	lower limit	-300.0%–300.0%	-100.0%	
P05.31	AI2 middle value 1	P05.29–P05.33	0.00V	
P05.32	Corresponding setting of AI2 middle value 1	-300.0%–300.0%	0.0%	
P05.33	AI2 middle value 2	P05.31–P05.35	0.00V	
P05.34	Corresponding setting of AI2 middle value 2	-300.0%–300.0%	0.0%	
P05.35	AI2 upper limit	P05.33–10.00V	10.00V	
P05.36	Corresponding setting of AI2 upper limit	-300.0%–300.0%	100.0%	
P05.37	AI2 input filter time	0.000s–10.000s	0.100s	
		0: Input set through frequency		
D05 38	HDIA high-speed pulse input	1: Reserved	0	
F05.50	function selection	2: Input set through encoder, used	0	
		together with HDIB		
P05.39	HDIA frequency lower limit	0.000kHz–P05.41	0.000kHz	
P05.40	Corresponding setting of HDIA frequency lower limit	-300.0%–300.0%	0.0%	
P05.41	HDIA frequency upper limit	P05.39–50.000kHz	50.000kHz	
P05.42	Corresponding setting of HDIA upper limit frequency	-300.0%–300.0%	100.0%	
P05.43	HDIA frequency input filter time	0.000s–10.000s	0.030s	
		0: Input set through frequency		
DOF 14	HDIB high-speed pulse input	1: Reserved	0	
P05.44	function selection	2: Input set through encoder, used	0	
		together with HDIA		
P05.45	HDIB frequency lower limit	0.000kHz–P05.47	0.000kHz	
P05.46	Corresponding setting of HDIB frequency lower limit	-300.0%–300.0%	0.0%	
P05.47	HDIB frequency upper limit	P05.45–50.000kHz	50.000kHz	
P05.48	Corresponding setting of HDIB upper limit frequency	-300.0%–300.0%	100.0%	
P05.49	HDIB frequency input filter time	0.000s–10.000s	0.030s	
		0–1		
P05.50	AI1 input signal type	0: Voltage 1: Current	0	

#### 5.5.10 Analog output

The VFD carries one analog output terminal (0–10V/0–20mA) and one high-speed pulse output terminal. Analog output signals can be filtered separately, and the proportional relation can be adjusted by setting the max. value, min. value, and the percentage of their corresponding output. Analog output signal can output motor speed, output frequency, output current, motor torque and motor power at a certain proportion.



AO output relationship description:

(The min. value and max. value of the output correspond to 0.0% and 100.00% of the pulse or analog default output. The actual output voltage or pulse frequency corresponds to the actual percentage, which can be set through function codes.)

Setting	Function	Description
0	Running frequency	0–Max. output frequency
1	Set frequency	0–Max. output frequency
2	Ramp reference frequency	0–Max. output frequency
3	Rotational speed	0–Synchronous speed corresponding to max. output frequency
4	Output current (relative to the VFD)	0-Twice the VFD rated current
5	Output current (relative to motor)	0-Twice the motor rated current
6	Output voltage	0–1.5 times the VFD rated voltage
7	Output power	0-Twice the motor rated power
8	Set torque value (bipolar)	0-Twice the motor rated current. A negative
0	Set torque value (bipolar)	value corresponds to 0.0% by default.
9	Output torque (absolute value)	0-±(Twice the motor rated torque)
10	AI1 input	0–10V/0–20mA
11	AI2 input	0V–10V. A negative value corresponds to

Setting	Function	Description
		0.0% by default.
12	AI3 input	0–10V/0–20mA
13	High-speed pulse HDIA input	0.00–50.00kHz
	Value 1 set through Modbus/Modbus	0,4000
14	TCP communication	0-1000
15	Value 2 set through Modbus/Modbus	0,1000
15	TCP communication	0-1000
	Value 1 set through	
16	PROFIBUS/CANopen/DeviceNet	0–1000
	communication	
	Set value 2 of	
17	PROFIBUS/CANopen/DeviceNet	0–1000
	communication	
10	Value 1 set through Ethernet	0, 1000
10	communication	0-1000
10	Value 2 set through Ethernet	0, 1000
19	communication	0-1000
20	High-speed pulse HDIA input	0.00–50.00kHz
	Value 1 set through	0, 1000. A pagative value corresponds to
21	EtherCAT/PROFINET/EtherNet IP	
	communication	
		0-Three times the motor rated current. A
22	Torque current (bipolar)	negative value corresponds to 0.0% by
		default.
		0–Three times the motor rated current. A
23	Exciting current	negative value corresponds to 0.0% by
		default.
24	Set frequency (bipolar)	0–Max. output frequency. A negative value
27		corresponds to 0.0% by default.
25	Ramp reference frequency (bipolar)	0–Max. output frequency. A negative value
20		corresponds to 0.0% by default.
		0–Synchronous rotation speed corresponding
26	Rotational speed (bipolar)	to max. output frequency. A negative value
		corresponds to 0.0% by default.
	Value 2 set through	
27	EtherCAT/PROFINET/EtherNet IP	0–1000
	communication	
28	AO1 from the programmable card	0–1000

Setting	Function	Description
29	AO2 from the programmable card	0–1000
20	Detetional an and	0-Twice the motor rated synchronous
30	Rotational speed	rotation speed
04		0-Twice the motor rated torque. A negative
31	Output torque (bipolar)	value corresponds to 0.0% by default.
00		AO output temperature in the AIAO
32	AIAO detected temperature output	temperature detection.
33–47	Reserved	/

Function code	Name	Description	Default
D00.00		0: Open collector high-speed pulse output	0
P06.00	HDO output type	1: Open collector output	0
P06.14	AO1 output selection	0: Running frequency (0–Max. output	0
P06.15	Reserved	frequency)	0
		1: Set frequency (0–Max. output frequency)	
		2: Ramp reference frequency (0–Max. output	
		frequency)	
		3: Rotational speed (0–Speed corresponding to	
		max. output frequency)	
		4: Output (0–Twice the VFD rated current)	
		5: Output current (0–Twice the motor rated	
		current)	
		6: Output (0–1.5 times the VFD rated voltage)	
		7: Output power (0–Twice the motor rated	
		power)	
D06 16	HDO high-speed pulse	8: Set torque (0–Twice the motor rated torque)	0
P00.10	output	9: Output torque (Absolute value, 0-±Twice the	0
		motor rated torque)	
		10: AI1 input (0–10V/0–20mA)	
		11: AI2 input (0–10V)	
		12: AI3 input (0–10V/0–20mA)	
		13: HDIA input (0.00–50.00kHz)	
		14: Value 1 set through Modbus/Modbus TCP	
		communication (0–1000)	
		15: Value 2 set through Modbus/Modbus TCP	
		communication (0–1000)	
		16: Value 1 set through	
		PROFIBUS/CANopen/DeviceNet (0–1000)	

Function code	Name	Description	Default
		17: Value 2 set through	
		PROFIBUS/CANopen/DeviceNet	
		communication (0–1000)	
		18: Value 1 set through Ethernet communication	
		(0–1000)	
		19: Value 2 set through Ethernet communication	
		(0–1000)	
		20: HDIB input (0.00–50.00kHz)	
		21: Value 1 set through	
		EtherCAT/PROFINET/EtherNet IP	
		communication (0–1000)	
		22: Torque current (bipolar, 0–Triple the motor	
		rated current)	
		23: Exciting current (bipolar, 0–Triple the motor	
		rated current)	
		24: Set frequency (bipolar, 0–Max. output	
		frequency)	
		25: Ramp reference frequency (bipolar, 0–Max.	
		output frequency)	
		26: Rotational speed (bipolar, 0–Speed	
		corresponding to max. output frequency)	
		27: Value set through	
		EtherCAT/PROFINET/EtherNet IP (0–1000)	
		28: AO1 from the programmable card (0–1000)	
		29: AO2 from the programmable card (0–1000)	
		30: Rotational speed (0–Twice the motor rated	
		synchronous speed)	
		31: Output torque (Actual value, 0-Twice the	
		motor rated torque)	
		32: AIAO detected temperature output	
		33–63: Reserved	
P06.17	AO1 output lower limit	-300.0%–P06.19	0.0%
	AO1 output		
P06.18	corresponding to lower	0.00V–10.00V	0.00V
	limit		
P06.19	AO1 output upper limit	P06.17–300.0%	100.0%
	AO1 output		
P06.20	corresponding to upper	0.00V–10.00V	10.00V
	limit		

Function code	Name	Description	Default
P06.21	AO1 output filter time	0.000s–10.000s	0.000s
P06.22	Reserved	0–65535	0
P06.23	PTC constant output current setting	0.000–20.000mA	4.000 mA
P06.24	PTC resistance alarm threshold	0–60000Ω	750Ω
P06.25	PTC resistance alarm recovery threshold	0–60000Ω	150Ω
P06.26	Actual PTC resistance	0–60000Ω	0Ω
P06.27	HDO output lower limit	-300.0%–P06.29	0.0%
P06.28	HDO output corresponding to lower limit	0.00–50.00kHz	0.0kHz
P06.29	HDO output upper limit	P06.27–300.0%	100.0%
P06.30	HDO output corresponding to upper limit	0.00–50.00kHz	50.00kHz
P06.31	HDO output filter time	0.000s–10.000s	0.000s

## 5.5.11 Digital input

The VFD carries four programmable digital input terminals and two HDI input terminals. The function of all the digital input terminals can be programmed through function codes. HDI input terminal can be set to act as high-speed pulse input terminal or common digital input terminal; if it is set to act as high-speed pulse input terminal, you can also set HDIA or HDIB high-speed pulse input to serve as the frequency reference and encoder signal input.



This parameter is used to set the corresponding function of digital multi-function input terminals.

Setting	Function	Description
0	No function	The VFD does not act even if there is signal input. Set unused terminals to "no function" to avoid misaction.
1	Run forward	External terminals are used to control the forward/reverse
2	Run reversely	running of the VFD.
3	Three-wire running control	The terminal is used to determine the three-wire running control of the VFD. For details, see the description for P05.11.
4	Jog forward	For details about frequency of jogging running and
5	Jog reverse	ACC/DEC time of jogging running, see the description for P08.06, P08.07, and P08.08.
6	Coast to stop	The VFD blocks output, and the stop process of motor is uncontrolled by the VFD. This mode is applied in the scenarios with large-inertia loads and without stop time requirements. Its definition is the same as P01.08, and it is mainly used in remote control.
7	Fault reset	External fault reset function, same as the reset function of the STOP/RST key on the keypad. You can use this function to reset faults remotely.
8	Pause running	The VFD decelerates to stop, however, all the run parameters are in memory state, such as PLC parameter, wobbling frequency, and PID parameter. After this signal disappears, the VFD will revert to the state before stop.
9	External fault input	When external fault signal is transmitted to the VFD, the VFD releases fault alarm and stops.
10	Increase frequency setting (UP)	Used to change the frequency increase/decrease command when the frequency is given by external terminals.
11	Decrease frequency setting (DOWN)	K1 UP terminal
12	Clear the frequency increase/decrease setting	K2     DOWN terminal       K3     UP/DOWN       Zeroing terminal     COM

Note: Two different multifunction input terminals cannot be configured with a same function.

Setting	Function				Descr	iption		
		se	setting can clear the frequency value of auxiliary channel				nel	
		se	set by UP/DOWN, thus restoring the reference frequency to					
		the	the frequency given by main reference frequency command			and		
		ch	annel.					
13	Switch between A setting	Th	ne funct	ion is	used to sw	itch betwe	en the frequer	ιсу
15	and B setting	se	tting cha	annels				
	Switch between	A	frequend	cy refe	erence channe	el and B fro	equency referer	nce
14	combination setting and A	ng and A channel can be switched				function 13	3; the combinat	ion
	setting	ch	annel s	et by	P00.09 and	the A fre	equency referer	nce
	Switch between	ch	channel can be switched by function 14; the combination					ion
15	combination setting and B	ch	annel s	et by	P00.09 and	the B fre	equency referer	ice
	setting	ch	channel can be switched by function 15.					
16	Multi-step speed terminal 1	A	total of	16-ste	p speeds ca	n be set by	/ combining dig	ital
17	Multi-step speed terminal 2	sta	ates of th	nese fo	our terminals.			
18	Multi-step speed terminal 3	No	ote: Mult	ti-step	speed 1 is th	e low-order	bit, and multi-st	tep
		sp	eed 4 is	the hi	gh-order bit.			
10	Multi-step speed terminal 4		Multi-	step	Multi-step	Multi-step	Multi-step	
19			spee	d 4	speed 3	speed 2	speed 1	
			Bit	3	Bit2	Bit1	Bit0	
00	Pause multi-step speed	Th	ne multi-	step s	peed selection	n function c	an be screened	l to
20	running	ke	ep the s	et valu	ue in the prese	ent state.		
21	ACC/DEC time selection 1	Th	ne status	of the	e two termina	lls can be d	combined to sel	ect
		foi	ur group	s of A	CC/DEC time.			
			T1	T2	ACC/DE	C time	Parameter	
22	ACC/DEC time selection 2		OFF	OFF	ACC/DE	C time 1	P00.11/P00.12	
22			ON	OFF	ACC/DE	C time 2	P08.00/P08.01	
			OFF	ON	ACC/DE	C time 3	P08.02/P08.03	
			ON	ON	ACC/DE	C time 4	P08.04/P08.05	
22	Cimple DI C stan reast	Us	sed to cl	lear th	e previous P	LC state m	emory informat	ion
23	Simple PLC stop reset	and restart the simple PLC process.						
		ปร	sed to	oause	the simple	PLC. Whe	en the function	is
24	Pause simple PLC	revoked, the simple PLC resumes the running.						
		PID is ineffective temporarily, and the VFD maintains						
25	Pause PID control	cu	rrent fre	quenc	y output.			
		Th	ne VFD	pause	es at current	output. Aft	er this function	is
26	Pause wobbling frequency	canceled it continues wobbling-frequency operation at						
-	(stop at current frequency)	cu	rrent fre	quenc	V.	0 1	, , , , , , , , , , , , , , , , , , , ,	
	Reset wobbling frequency				,			
27	(back to center frequency)	Th	The set frequency of VFD reverts to center frequency.					

Setting	Function	Description
28	Reset the counter	The counter is cleared.
	Switch between speed	The VFD switches from torque control mode to speed
29	control and torque control	control mode, or vice versa.
30	Disable ACC/DEC	Used to ensure the VFD is not impacted by external signals (except for stop command), and maintains the present output frequency.
31	Trigger the counter	Used to enable the counter to count pulses.
33	Clear the frequency increase/decrease setting temporarily	When the terminal is closed, the frequency value set by the UP/DOWN key can be cleared and restored to the frequency given by frequency command channel; when the terminal is opened, it is changed to the frequency value after frequency increase/decrease setting
34	DC braking	The VFD starts DC brake immediately after the command becomes valid.
35	Switch between motor 1	When the function is enabled, you can realize switchover
- 55	and motor 2	control of two motors.
36	Switch the running command channel to keypad	When the function is enabled, the running command channel is switched to keypad. When the function is disabled, the running command channel is restored to the previous setting.
37	Switch the running command channel to terminal	When the function is enabled, the running command channel is switched to terminal. When the function is disabled, the running command channel is restored to the previous setting.
38	Switch the running command channel to communication	When the function is enabled, the running command channel is switched to communication. When the function is disabled, the running command channel is restored to the previous setting.
39	Pre-exciting command	When the function is enabled, motor pre-exciting is started until the function becomes invalid.
40	Clear power consumption quantity	After this command becomes valid, the power consumption quantity of the VFD will be zeroed out.
41	Keep power consumption quantity	When the function is enabled, the present operation of the VFD does not impact the power consumption quantity.
42	Switch the setting source of braking torque upper limit to keypad	The torque upper limit is set through the keypad when the command is valid.
43	Position reference point input	Only valid for S1, S2, S3
44	Disable spindle orientation	Spindle positioning is disabled.
45	Spindle zeroing / Local	Trigger the spindle positioning function

Setting	Function	Description
46	Spindle zeroing position	Spindle zeroing position 1 selected through terminal
	selection 1	
47	Spindle zeroing position selection 2	Spindle zeroing position 2 selected through terminal
48	Spindle scale division selection 1	Spindle scale division value 1 selected through terminal
49	Spindle scale division selection 2	Spindle scale division value 2 selected through terminal
50	Spindle scale division selection 3	Spindle scale division value 3 selected through terminal
51	Terminal for switching between position control and speed control	Switch between position control and speed control
52	Disable pulse input	When the terminal is active, the pulse input is invalid
53	Clear position deviation	Clear the input deviation of the position loop
54	Switch position proportional gains	Switch the position proportional gains
	Enable cyclic digital	Enabling cyclic positioning function in digital position
55	positioning	positioning mode
56	Emergency stop	When the function is enabled, the motor decelerates to stop in emergency manner according to the time specified by P01.25.
57	Motor overtemperature fault input	When there is motor overtemperature fault input, the motor stops due to the fault.
59	Switch from VC to space voltage vector control	When the function is enabled in stopped state, space voltage vector control is used.
60	Switch to VC control	When the function is enabled in stopped state, VC is used.
61	Switch PID polarities	Used to switch the output polarity of PID. It is used together with P09.03.
62	Reserved	/
63	Enabling servo	When the thousands place of P21.00 enables servo, the servo enabling terminal is valid, which controls the VFD to enter zero servo control. At this time, the start command is not needed.
64	Limit on forward running	Limit on forward running.
65	Limit on reverse running	Limit on reverse running.
66	Clear encoder counting	Used to clear the position counting value.
67	Increase pulses	If the terminal is valid when the function is selected, the pulse input is increased according to P21.27 (Pulse superposition speed).
68	Enable pulse superposition	Pulse increment and pulse decrement can be valid only after pulse superimposition is enabled.

Setting	Function	Description
69	Decrease pulses	If the terminal is valid when the function is selected, the pulse input is decreased according to P21.27 (Pulse superposition speed).
70	Electronic gear selection	If the terminal is valid when the function is selected, the proportional numerator is switched to P21.30 (Numerator of the 2nd command ratio).
71	Switch to the master	When the function is enabled in stopped state, the unit switches to the master mode.
72	Switch to the slave	When the function is enabled in stopped state, the unit switches to the slave mode.
73	Rolling diameter reset	If the terminal is valid when the tension-specific function is used, the terminal resets the roll diameter.
74	Winding/unwinding switchover	If the terminal is valid when the tension-specific function is used, the terminal switches between the winding mode and unwinding mode.
75	Tension control pre-driving	If the terminal is valid when the tension-specific function is used, the VFD performs tension control pre-driving.
76	Disabling roll diameter calculation	If the terminal is valid when the tension-specific function is used and the terminal is valid, the VFD does not calculate the roll diameter.
77	Clearing alarm display	If the terminal is valid when the tension-specific function is used, tension alarm display is cleared.
78	Manual braking in tension control	If the terminal is valid when the tension-specific function is used, manual braking is allowed.
79	Triggering a forcible material feeding interrupt signal	If the terminal is valid when the tension-specific function is used, the VFD triggers a forcible material feeding interrupt signal.
80	Initial roll diameter selection 1	If the terminal is valid when the tension-specific function is used, initial roll diameters 2 and 2 are combined for different initial roll diameter selection.
81	Initial roll diameter selection 2	If the terminal is valid when the tension-specific function is used, initial roll diameters 1 and 2 are combined for different initial roll diameter selection.
82	Triggering fire control	If the terminal is valid when the fire mode is enabled, the VFD triggers a fire control signal.
83	PID switchover in tension control	If the terminal is valid when the tension-specific function is used, the terminal switches from the first group of PID parameter to the second group. The first group is the default PID parameter group.
84-95	Reserved	/

Function code	Name	Description	Default
		0x00–0x11	
		Ones place: HDIA input type	
		0: HDIA is high-speed pulse input	
P05.00	HDI input type	1: HDIA is digital input	0x00
		Tens place: HDIB input type	
		0: HDIB is high-speed pulse input	
		1: HDIB is digital input	
P05.01	Function of S1	0: No function	1
P05.02	Function of S2	1: Run forward	4
P05.03	Function of S3	2: Run reversely	7
P05.04	Function of S4	3: Three-wire running control	0
P05.05	Function of HDIA	4: Jog forward	0
		5: Jog reversely	
		6: Coast to stop	
		7: Reset faults	
		8: Pause running	
		9: External fault input	
		10: Increase frequency setting (UP)	
		11: Decrease frequency setting (DOWN)	
		12: Clear the frequency increase/decrease	
		setting	
		13: Switch between A setting and B setting	
		14: Switch between combination setting and A	
		setting	
		15: Switch between combination setting and B	
P05.06	Function of HDIB	setting	0
		16: Multi-step speed terminal 1	
		17: Multi-step speed terminal 2	
		18: Multi-step speed terminal 3	
		19: Multi-step speed terminal 4	
		20: Pause multi-step speed running	
		21: ACC/DEC time selection 1	
		22: ACC/DEC time selection 2	
		23: Simple PLC stop reset	
		24: Pause simple PLC	
		25: Pause PID control	
		26: Pause wobbling frequency	
		27: Reset wobbling frequency	

Function code	Name	Description	Default
		28: Counter reset	
		29: Switch between speed control and torque	
		control	
		30: Disable ACC/DEC	
		31: Trigger the counter	
		32: Reserved	
		33: Clear the frequency increase/decrease	
		setting temporarily	
		34: DC braking	
		35: Switch from motor 1 to motor 2	
		36: Switch the running command channel to	
		keypad	
		37: Switch the running command channel to	
		terminal	
		38: Switch the running command channel to	
		communication	
		39: Pre-exciting command	
		40: Clear electricity consumption	
		41: Keep electricity consumption	
		42: Switch the setting source of braking	
		torque upper limit to keypad	
		43: Position reference point input (only valid	
		for S2, S3 and S4)	
		44: Disable spindle orientation	
		45: Spindle zeroing / Local positioning zeroing	
		46: Spindle zeroing position selection 1	
		47: Spindle zeroing position selection 2	
		48: Spindle scale division selection 1	
		49: Spindle scale division selection 2	
		50: Spindle scale division selection 3	
		51: Terminal for switching between position	
		control and speed control	
		52: Disable pulse input	
		53: Clear position deviation	
		54: Switch position proportional gains	
		55: Enable cyclic digital positioning	
		56: Emergency stop	
		57: Motor overtemperature fault input	
		59: Switch to V/F control	
		60: Switch to FVC control	

Function code	Name	Description	Default
		61: Switch PID polarities	
		62: Reserved	
		63: Enable servo	
		64: Limit on forward running	
		65: Limit on reverse running	
		66: Clear encoder counting	
		67: Increase pulses	
		68: Enable pulse superposition	
		69: Decrease pulses	
		70: Electronic gear selection	
		71: Switch to the master	
		72: Switch to the slave	
		73: Roll diameter reset	
		74: Winding/unwinding switchover	
		75: Tension control pre-driving	
		76: Disable roll diameter calculation	
		77: Clear alarm display	
		78: Manual braking in tension control	
		79: Trigger a forcible material feeding	
		interrupt signal	
		80: Initial roll diameter selection 1	
		81: Initial roll diameter selection 2	
		82: Triggering fire control	
		83: Tension PID switchover	
		84–95: Reserved	
P05.08	Input terminal polarity selection	0x00–0x3F	0x00
P05.09	Digital input filter time	0.000–1.000s	0.010s
		0x00–0x3F (0: Disable. 1: Enable)	
		Bit 0: S1 virtual terminal	
		Bit 1: S2 virtual terminal	
P05.10	Virtual terminal setting	Bit 2: S3 virtual terminal	0x00
		Bit 3: S4 virtual terminal	
		Bit4: HDIA virtual terminal	
		Bit5: HDIB virtual terminal	
		0: Two-wire control mode 1	
DOF 11	Torminal control mode	1: Two-wire control mode 2	0
P03.11	reminal control mode	2: Three-wire control mode 1	U
		3: Three-wire control mode 2	
Goodrive350 IP55 High-ingress Protection Series VFD

Function	Name	Description	Default
P05.12	S1 switch-on delay	0.000-50.000s	0.000s
P05.13	S1 switch-off delay	0.000-50.000s	0.000s
P05.14	S2 switch-on delay	0.000–50.000s	0.000s
P05.15	S2 switch-off delay	0.000–50.000s	0.000s
P05.16	S3 switch-on delay	0.000–50.000s	0.000s
P05.17	S3 switch-off delay	0.000–50.000s	0.000s
P05.18	S4 switch-on delay	0.000–50.000s	0.000s
P05.19	S4 switch-off delay	0.000–50.000s	0.000s
P05.20	HDIA switch-on delay	0.000–50.000s	0.000s
P05.21	HDIA switch-off delay	0.000–50.000s	0.000s
P05.22	HDIB switch-on delay	0.000–50.000s	0.000s
P05.23	HDIB switch-off delay	0.000–50.000s	0.000s
P07.39	Input terminal status at present fault	0x0000-0xFFF	0x0000
P17.12	Digital input terminal state	Displays the present digital input terminal state of the VFD. 0x00–0x3F	0x00
		Corresponds to HDIB, HDIA, S4, S3, S2 and S1 respectively.	

## 5.5.12 Digital output

The VFD carries two groups of relay output terminals, one open collector Y output terminal and one high-speed pulse output (HDO) terminal. All the digital output terminal functions can be used for programming through function code setting. The HDO terminals select high-speed pulse output or digital output through function code setting.



The following table lists the function code options. A same output terminal function can be repeatedly selected.

Setting	Function	Description
0	Invalid	The output terminal does not have any function.
		The ON signal is output when there is frequency output
1	Running	during running.
		The ON signal is output when there is frequency output
2	Running forward	during forward running.
_	Durania a anna a bu	The ON signal is output when there is frequency output
3	Running reversely	during reverse running.
4	logging	The ON signal is output when there is frequency output
4	Jogging	during jogging.
5	VFD fault	The ON signal is output when a VFD fault occurred.
6	Frequency level detection FDT1	(Refer to the descriptions for P08.32–P08.33.)
7	Frequency level detection FDT2	(Refer to the descriptions for P08.34, P08.35.)
8	Frequency reached	(Refer to the description for P08.36.)
_	Durania and some second	Output ON signal when the VFD output frequency and
9	Running at zero speed	reference frequency are both zero.
10		The ON signal is output when the running frequency
10	Opper limit frequency reached	reaches the upper limit.
	Lower limit frequency reached	The ON signal is output when the running frequency
11	Lower limit frequency reached	reaches the lower limit frequency.
		The ON signal is output when main circuit and control
12	Ready to run	circuit powers are established, the protection functions
		do not act, and the VFD is ready to run.
13	Pre-exciting	The ON signal is output when the VFD is in
10	T Te-exciting	pre-exciting.
		The ON signal is output when the pre-alarm time
14	Overload pre-alarm	elapsed based on the pre-alarm threshold; for details,
		see descriptions for P11.08–P11.10.
		The ON signal is output after the pre-alarm time
15	Underload pre-alarm	elapsed based on the pre-alarm threshold. For details,
		see the descriptions for P11.11–P11.12.
16	Simple PLC stage completed	When the present state of the simple PLC is
		completed, it outputs a signal.
17	Simple PLC cycle completed	When a single cycle of the simple PLC is completed, it
		outputs a signal.
	Modbus/ Modbus TCP	A signal is output based on the value set through
23	communication virtual terminal	Modbus/Modbus TCP communication. When the value
	output	is 1, the ON signal is output; when the value is 0, the
1	•	OFF signal is output.

Setting	Function	Description
	PROFIBUS/CANopen/DeviceNe	Output corresponding signal based on the set value of
24	t communication virtual terminal	PROFIBUS/CANopen. Output ON signal when it is set
	output	to 1, output OFF signal when it is set to 0.
		A signal is output based on the value set through
25	Ethernet communication virtual	Ethernet communication. When the value is 1, the ON
25	terminal output	signal is output; when the value is 0, the OFF signal is
		output.
26	DC hus voltage established	When the bus voltage is above the inverter
20	DC bus voltage established	undervoltage, the output is valid.
27	Z pulco output	When the encoder Z pulse is reached, the output is
21		valid, which becomes invalid 10 seconds later.
20		When the pulse superposition terminal input function is
20		valid, the output is valid.
29	STO action	When an STO fault occurs, the output is valid.
30	Positioning completed	When positioning is completed, the output is valid.
31	Spindle zeroing completed	When spindle zeroing is completed, the output is valid.
22	Spindle scale division	When spindle scale division is completed, the output is
32	completed	valid.
33	Speed limit reached in torque control	When the frequency is limited, the output is valid.
		A signal is output based on the value set through
24	EtherCAT/PROFINE T/EtherNet	PROFINET communication. When the value is 1, the
34	terminal output	ON signal is output; when the value is 0, the OFF
	terminal output	signal is output.
35	Reserved	/
	Speed/position control	When the mode switchover is completed, the output is
30	switchover completed	valid.
		The frequency reaching signal is output when the ramp
37	Any frequency reached	reference frequency is greater than the detected value
		of frequency reaching.
38–40	Reserved	/
41	Y1	Y1 from the programmable card
42	Y2	Y2 from the programmable card
43	HDO	HDO from the programmable card
44	RO1	RO1 from the programmable card
45	RO2	RO2 from the programmable card
46	RO3	RO3 from the programmable card
47	RO4	RO4 from the programmable card

Setting	Function	Description
40	EC PT100 detected OH	Pre-alarm of overheating (OH) detected by the
48	pre-alarm	expansion card (EC) with PT100.
40	EC PT1000 detected OH	Pre-alarm of overheating (OH) detected by the
49	pre-alarm	expansion card (EC) with PT1000.
50		Overheating detected by the temperature detection AI
50	AIAO detected OH pre-alarm	or AO terminal.
51	Stopped or running in zero	The VED is stopped or rupping at zero speed
51	speed	The VI D is stopped of furning at zero speed.
50	Tancian control disconnection	Disconnection is detected when the tension-specific
52		function disconnection detection is enabled.
50	Specified roll diameter reached	The specified roll diameter is reached when the
55	Specified foil diameter feached	tension-specific function is enabled.
<b>E</b> 4	May roll dispector reschool	The max. roll diameter is reached when the
54	Max. foil diameter reached	tension-specific function is enabled.
<b>FF</b>	Min roll diamator reached	The min. roll diameter is reached when the
55	win. roll diameter reached	tension-specific function is enabled.
56	Fire mode enabled	The fire mode is enabled.
57–63	Reserved	/

## Related parameter list:

Function code	Name	Description	Default
P06.00	HDO output type	0: Open collector high-speed pulse output	0
1 00.00	Name         0: C           HDO output type         0: C           Y1 output         0: C           Y1 output         0: C           HDO output         1: F           HDO output         2: F           RO1 output         2: F           S: F         3: F           4: J         5: V           6: F         7: F           RO2 output         8: F           9: F         10:           11:         12:           13:         13:	1: Open collector output	•
P06.01	Y1 output	0: Disable	0
P06.02	HDO output	1: Running	0
P06.03	RO1 output	2: Running forward	1
		3: Running reversely	
		4: Jogging	
		5: VFD in fault	
		6: Frequency level detection FDT1	
		7: Frequency level detection FDT2	
P06.04	RO2 output	8: Frequency reached	5
		9: Running at zero speed	
		10: Frequency upper limit reached	
		11: Frequency lower limit reached	
		12: Ready for running	
		13: Pre-exciting	

Function code	Name	Description	Default
		14: Overload pre-alarm	
		15: Underload pre-alarm	
		16: Simple PLC stage completed	
		17: Simple PLC cycle completed	
		18: Set counting value reached	
		19: Designated counting value reached	
		20: External fault is valid	
		21: Reserved	
		22: Running time reached	
		23: Modbus/ Modbus TCP communication	
		virtual terminal output	
		24: PROFIBUS/CANopen/DeviceNet	
		communication virtual terminal output	
		25: Ethernet communication virtual terminal	
		output	
		26: DC bus voltage established	
		27: Z pulse output	
		28: Superposing pulses	
		29: STO action	
		30: Positioning completed	
		31: Spindle zeroing completed	
		32: Spindle scale division completed	
		33: Speed limit reached in torque control	
		34: EtherCAT/PROFINET/EtherNet IP	
		communication virtual terminal output	
		35: Reserved	
		36: Speed/position control switchover	
		completed	
		37: Any frequency reached	
		38–40: Reserved	
		41: Y1 from the programmable card	
		42: Y2 from the programmable card	
		43: HDO from the programmable card	
		44: RO1 from the programmable card	
		45: RO2 from the programmable card	
		46: RO3 from the programmable card	
		47: RO4 from the programmable card	
1		48: EC PT100 detected OH pre-alarm	

Goodrive350 IP55 High-ingress Protection Series VFD

Function code	Name	Description	Default
		49: EC PT1000 detected OH pre-alarm	
		50: AIAO detected OT pre-alarm	
		51: Stopped or running in zero speed	
		52: Tension control disconnection	
		53: Specified roll diameter reached	
		54: Max. roll diameter reached	
		55: Min. roll diameter reached	
		56: Fire mode enabled	
		57–63: Reserved	
P06.05	Output terminal polarity		0.00
P06.05	selection	0.00-0.00	0,00
P06.06	Y switch-on delay	0.000–50.000s	0.000s
P06.07	Y switch-off delay	0.000–50.000s	0.000s
P06.08	HDO switch-on delay	0.000–50.000s (valid when P06.00 is 1)	0.000s
P06.09	HDO switch-off delay	0.000–50.000s (valid when P06.00 is 1)	0.000s
P06.10	RO1 switch-on delay	0.000–50.000s	0.000s
P06.11	RO1 switch-off delay	0.000–50.000s	0.000s
P06.12	RO2 switch-on delay	0.000–50.000s	0.000s
P06.13	RO2 switch-off delay	0.000–50.000s	0.000s
P07.40	Output terminal status at present fault	0x0000–0xFFF	0x0000
		Displays the present digital output terminal	
		state of the VFD.	
P17.13	Digital output terminal state	0x00–0x0F	0x00
		The bits correspond to RO2, RO1, HDO, and	
		Y1 respectively.	

## 5.5.13 Simple PLC

Simple PLC is a multi-step speed generator, and the VFD can change the running frequency and direction automatically based on the running time to fulfill process requirements. Previously, such function was realized with external PLC, while now, the VFD itself can achieve this function.

The VFD can realize 16-step speeds control, and provide four groups of acceleration/deceleration time for choose.

After the set PLC completes one cycle (or one step), one ON signal can be output by the multifunction relay.

## Goodrive350 IP55 High-ingress Protection Series VFD



#### Related parameter list:

Function code	Name	Description	Default
P05.01– P05.06	Digital input function selection	23: Simple PLC stop reset 24: Pause simple PLC 25: Pause PID control	See "Group P05— Input terminal functions"
P06.01– P06.04	Digital output function selection	16: Simple PLC stage reached 17: Simple PLC cycle reached	See "Group P06—Outp ut terminal functions"
P10.00	Simple PLC mode	0: Stop after running once 1: Keep running with the final value after running once 2: Cyclic running	0
P10.01	Simple PLC memory selection	0: Do not memorize at power outage 1: Memorize at power off	0
P10.02	Multi-step speed 0	-300.0–300.0%	0.0%
P10.03	Running time of step 0	0.0–6553.5s (min)	0.0s
P10.04	Multi-step speed 1	-300.0–300.0%	0.0%
P10.05	Running time of step 1	0.0–6553.5s (min)	0.0s
P10.06	Multi-step speed 2	-300.0–300.0%	0.0%

Function	Nama	Description	
code	Name	Description	Default
P10.07	Running time of step 2	0.0–6553.5s (min)	0.0s
P10.08	Multi-step speed 3	-300.0–300.0%	0.0%
P10.09	Running time of step 3	0.0–6553.5s (min)	0.0s
P10.10	Multi-step speed 4	-300.0–300.0%	0.0%
P10.11	Running time of step 4	0.0–6553.5s (min)	0.0s
P10.12	Multi-step speed 5	-300.0–300.0%	0.0%
P10.13	Running time of step 5	0.0–6553.5s (min)	0.0s
P10.14	Multi-step speed 6	-300.0–300.0%	0.0%
P10.15	Running time of step 6	0.0–6553.5s (min)	0.0s
P10.16	Multi-step speed 7	-300.0–300.0%	0.0%
P10.17	Running time of step 7	0.0–6553.5s (min)	0.0s
P10.18	Multi-step speed 8	-300.0–300.0%	0.0%
P10.19	Running time of step 8	0.0–6553.5s (min)	0.0s
P10.20	Multi-step speed 9	-300.0–300.0%	0.0%
P10.21	Running time of step 9	0.0–6553.5s (min)	0.0s
P10.22	Multi-step speed 10	-300.0–300.0%	0.0%
P10.23	Running time of step 10	0.0–6553.5s (min)	0.0s
P10.24	Multi-step speed 11	-300.0–300.0%	0.0%
P10.25	Running time of step 11	0.0–6553.5s (min)	0.0s
P10.26	Multi-step speed 12	-300.0–300.0%	0.0%
P10.27	Running time of step 12	0.0–6553.5s (min)	0.0s
P10.28	Multi-step speed 13	-300.0–300.0%	0.0%
P10.29	Running time of step 13	0.0–6553.5s (min)	0.0s
P10.30	Multi-step speed 14	-300.0–300.0%	0.0%
P10.31	Running time of step 14	0.0–6553.5s (min)	0.0s
P10.32	Multi-step speed 15	-300.0–300.0%	0.0%
P10.33	Running time of step 15	0.0–6553.5s (min)	0.0s
P10.36	PLC restart mode	0: Restart from step 1	0
		1: Resume from the paused step	-
P10.34	ACC/DEC time of steps 0–7 of simple PLC	0x0000–0XFFFF	0x0000
P10.35	ACC/DEC time of steps 8–15 of simple PLC	0x0000–0XFFFF	0x0000
P17.00	Set frequency	0.00Hz–P00.03 (Max. output frequency)	0.00Hz
P17.27	Present step of simple PLC	Used to display the present step of the simple PLC function.	0

#### 5.5.14 Multi-step speed running

Set the parameters used in multi-step speed running. The VFD can set 16-step speeds, which are selectable by multi-step speed terminals 1–4, corresponding to multi-step speed 0 to multi-step speed 15.



Related parameter list:

Function code	Name	Description	Default
		16: Multi-step speed terminal 1	
		17: Multi-step speed terminal 2	See "Group
DOE 01 DOE 06	Digital input function	18: Multi-step speed terminal 3	P05—Input
P05.01-P05.06	selection	19: Multi-step speed terminal 4	terminal
		20: Pause multi-step speed	functions"
		running	
P10.02	Multi-step speed 0	-300.0–300.0%	0.0%
P10.03	Running time of step 0	0.0–6553.5s (min)	0.0s
P10.04	Multi-step speed 1	-300.0–300.0%	0.0%
P10.05	Running time of step 1	0.0–6553.5s (min)	0.0s
P10.06	Multi-step speed 2	-300.0–300.0%	0.0%

Function code	Name	Description	Default
P10.07	Running time of step 2	0.0–6553.5s (min)	0.0s
P10.08	Multi-step speed 3	-300.0–300.0%	0.0%
P10.09	Running time of step 3	0.0–6553.5s (min)	0.0s
P10.10	Multi-step speed 4	-300.0–300.0%	0.0%
P10.11	Running time of step 4	0.0–6553.5s (min)	0.0s
P10.12	Multi-step speed 5	-300.0–300.0%	0.0%
P10.13	Running time of step 5	0.0–6553.5s (min)	0.0s
P10.14	Multi-step speed 6	-300.0–300.0%	0.0%
P10.15	Running time of step 6	0.0–6553.5s (min)	0.0s
P10.16	Multi-step speed 7	-300.0–300.0%	0.0%
P10.17	Running time of step 7	0.0–6553.5s (min)	0.0s
P10.18	Multi-step speed 8	-300.0–300.0%	0.0%
P10.19	Running time of step 8	0.0–6553.5s (min)	0.0s
P10.20	Multi-step speed 9	-300.0–300.0%	0.0%
P10.21	Running time of step 9	0.0–6553.5s (min)	0.0s
P10.22	Multi-step speed 10	-300.0–300.0%	0.0%
P10.23	Running time of step 10	0.0–6553.5s (min)	0.0s
P10.24	Multi-step speed 11	-300.0–300.0%	0.0%
P10.25	Running time of step 11	0.0–6553.5s (min)	0.0s
P10.26	Multi-step speed 12	-300.0–300.0%	0.0%
P10.27	Running time of step 12	0.0–6553.5s (min)	0.0s
P10.28	Multi-step speed 13	-300.0–300.0%	0.0%
P10.29	Running time of step 13	0.0–6553.5s (min)	0.0s
P10.30	Multi-step speed 14	-300.0–300.0%	0.0%
P10.31	Running time of step 14	0.0–6553.5s (min)	0.0s
P10.32	Multi-step speed 15	-300.0–300.0%	0.0%
P10.33	Running time of step 15	0.0–6553.5s (min)	0.0s
P10.34	ACC/DEC time of steps 0–7 of simple PLC	0x0000–0XFFFF	0x0000
P10.35	ACC/DEC time of steps 8– 15 of simple PLC	0x0000–0XFFFF	0x0000
P17.27	Present step of simple PLC	Used to display the present step of the simple PLC function.	0

#### 5.5.15 PID control

PID control, a common mode for process control, is mainly used to adjust the VFD output frequency or output voltage by performing scale-division, integral and differential operations on the difference between feedback signal of controlled variables and signal of the target, thus

forming a negative feedback system to keep the controlled variables above the target. It is applicable to flow control, pressure control, temperature control, and so on. The following is the basic schematic block diagram for output frequency regulation.



Introduction to the working principles and control methods for PID control:

#### Proportional control (Kp):

When the feedback is different from the reference, the output will be proportional to the difference. If such a difference is constant, the regulating variable will also be constant. Proportional control can respond to feedback changes rapidly, however, it cannot eliminate the difference by itself. A larger proportional gain indicates a faster regulating speed, but a too large gain will result in oscillation. To solve this problem, set the integral time to a large value and the difference to observe the difference (that is, static difference) between the feedback signal and reference. If the static difference occurs in the direction of reference change (such as reference increase, where the feedback is always less than the reference after system stabilizes), continue increasing the proportional gain; otherwise, decrease the proportional gain. Repeat this process until the static difference becomes small.

## Integral time (Ti):

When feedback is different from reference, the output regulating variable accumulates continuously, if the difference persists, the regulating variable will increase continuously until difference disappears. The integral regulator can be used to eliminate static difference. However, too large regulation may lead to repetitive overshoot, which will cause system instability and oscillation. The feature of oscillation caused by strong integral effect is that the feedback signal fluctuates up and down based on the reference variable, and fluctuation range increases gradually until oscillation occurs. The integral time parameter is generally regulated gradually from large to small until the stabilized system speed fulfills the requirement.

#### Differential time (Td):

When the difference between feedback and reference changes, there is output of the regulating variable that is proportional to the difference variation rate, and this regulating variable is only related to the direction and magnitude of the difference change rather than the direction and magnitude of the difference itself. Differential control is used to control the feedback signal variation based on the change trend. Exercise caution before using the differential regulator since it may enlarge the system interferences, especially those with high change frequency.

When the frequency command selection (P00.06, P00.07) is 7 or the voltage setting channel selection (P04.27) is 6, the VFD is process PID controlled.

#### 5.5.15.1 General procedures for PID parameter setup

Step 1 Determining proportional gain P

When determining proportional gain P, first, remove the integral term and derivative term of PID by making Ti=0 and Td=0 (see PID parameter setup for details), thus turning PID into pure proportional control. Set the input to 60%–70% of the max. allowable value, and increase proportional gain P gradually from 0 until system oscillation occurred, and then in turn, decrease proportional gain P gradually from current value until system oscillation disappears, record the proportional gain P at this point and set the proportional gain P of PID to 60%–70% of current value. This is the entire commissioning procedure of proportional gain P.

Step 2 Determine integral time Ti

After proportional gain P is determined, set the initial value of integral time Ti to a large value, and decrease Ti gradually until system oscillation occurs. Then in reverse, increase Ti until system oscillation disappears. Record the value of Ti at this point. Set the integral time constant Ti of PID to 150%–180% of this value. This is the commissioning procedure of integral time constant Ti.

Step 3 Determining derivative time Td

The differential time Td is generally set to 0.

If you need to set Td to another value, the setting method is similar to that for P and Ti, namely, set Td to 30% of the value when there is no oscillation.

Step 4 Empty system load, perform load-carrying joint debugging, and then fine-tune PID parameter until fulfilling the requirement.

#### 5.5.15.2 How to fine-tune PID

After setting the parameters controlled by PID, you can adjust these parameters by the following means.

Control overshoot: When overshoot occurred, shorten the derivative time (Td) and prolong integral time (Ti).



Stabilize the feedback value as fast as possible: When overshoot occurred, shorten integral time (Ti) and prolong derivative time (Td) to stabilize control as fast as possible.



Control long-term vibration: If the cycle of periodic vibration is longer than the set value of integral time (Ti), it indicates the integral action is too strong, prolong the integral time (Ti) to control vibration.



Control short-term vibration: If the vibration cycle is as short almost the same as the set value of differential time (Td), it indicates the differential action is too strong. Shorten the differential time (Td) to control vibration. When the differential time (Td) is set to 0.00 (namely no differential control), and there is no way to control vibration, decrease the proportional gain.



Related parameter list:

Function code	Name	Description	Default
		0: Set by P09.01	
		1: Al1	
		2: AI2	
		3: AI3	
		4: High-speed pulse HDIA	
		5: Multi-step running	
		6: Modbus/Modbus TCP communication	
P09.00	PID reference source	7: PROFIBUS/CANopen/DeviceNet	0
		communication	
		8: Ethernet communication	
		9: High-speed pulse HDIB	
		10: EtherCAT/PROFINET/ EtherNet IP	
		communication	
		11: Programmable expansion card	
	12: Reserved	12: Reserved	
P09.01	PID digital setting	-100.0%–100.0%	0.0%
		0: Al1	0.0%
		1: AI2	
		2: AI3	
		3: High-speed pulse HDIA	
		4: Modbus/Modbus TCP communication	
		5: PROFIBUS/CANopen/DeviceNet	
P09.02	PID feedback source	communication         11: Programmable expansion card         12: Reserved         g       -100.0%-100.0%       0.0         0: Al1       1: Al2         2: Al3       3: High-speed pulse HDIA         4: Modbus/Modbus TCP communication       5: PROFIBUS/CANopen/DeviceNet         rcce       communication       0         6: Ethernet communication       0         7: High-speed pulse HDIB       8: EtherCAT/PROFINET/ EtherNet IP         communication       9: Programmable expansion card         10: Reserved       10: Reserved	0
		8: EtherCAT/PROFINET/ EtherNet IP	
		communication	
		9: Programmable expansion card	
		10: Reserved	
	PID output		
P09.03	characteristics	0: PID output is positive.	0
	selection	וי סעדש output is negative.	
D00.04	Proportional gain	0.00, 100,00	1.80
P09.04	(Kp)	0.00-100.00	
P09.05	Integral time (Ti)	0.01–10.00s	0.90s
P09.06	Differential time (Td)	0.00–10.00s	0.00s

Function code	Name	Description	Default
P09.07	Sampling cycle (T)	0.000–10.000s	0.100s
P09.08	PID control deviation limit	0.0–100.0%	0.0%
P09.09	PID output upper limit	P09.10–100.0% (Max. frequency or voltage)	100.0%
P09.10	PID output lower limit	-100.0%–P09.09 (Max. frequency or voltage)	0.0%
P09.11	Feedback offline detection value	0.0–100.0%	0.0%
P09.12	Feedback offline detection time	0.0–3600.0s	1.0s
P09.13	PID control selection	0x0000–0x1111 Ones place: 0: Continue integral control after the frequency reaches upper/lower limit 1: Stop integral control after the frequency reaches upper/lower limit Tens place: 0: Same as the main reference direction 1: Contrary to the main reference direction Hundreds place: 0: Limit as per the max. frequency 1: Limit as per A frequency Thousands place: 0: A+B frequency. ACC/DEC of main reference A frequency source precharging is invalid. 1: A+B frequency. Acceleration /deceleration of main reference A frequency source buffering is valid.	0x0001
P09.14	Low frequency proportional gain (Kp)	0.00–100.00	1.00
P09.15	ACC/DEC time of PID command	0.0–1000.0s	0.0s
P09.16	PID output filter time	0.000–10.000s	0.000s
P09.17	Reserved	/	/
P09.18	Low frequency integral time (Ti)	0.00–10.00s	0.90s
P09.19	Low frequency differential time (Td)	0.00–10.00s	0.00s

Function code	Name	Description	Default
P09.20	Low frequency point for PID parameter switching	0.00–P09.21	5.00Hz
P09.21	High frequency point for PID parameter switching	P09.20–P00.04	10.00Hz
P17.00	Set frequency	0.00Hz–P00.03 (Max. output frequency)	0.00Hz
P17.23	PID reference value	-100.0–100.0%	0.0%
P17.24	PID feedback value	-100.0–100.0%	0.0%

## 5.5.16 Run at wobbling frequency

Wobbling frequency is mainly applied in the scenarios where transverse movement and winding functions are needed such as textile and chemical fiber industries. The typical working process is shown as follows.



Function code	Name	Description	Default
P00.03	Max. output frequency	P00.04–599.00Hz	50.00Hz
P00.06	Setting channel of A frequency command	0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDIA 5: Simple PLC program 6: Multi-step speed running	0

Function code	Name	Description	Default
		7: PID control	
		8: Modbus/Modbus TCP communication	
		9: PROFIBUS/CANopen/DeviceNet communication	
		10: Ethernet communication	
		11: High-speed pulse HDIB	
		12: AB pulse train	
		13: EtherCAT/PROFINET/ EtherNet IP	
		communication	
		14: Programmable card	
D00 11	ACC time 1	0.0.2600.00	Model
P00.11	ACC time 1	0.0-3800.05	depended
D00.40	DEC time 1	0.0.0000	Model
P00.12	DEC time 1	0.0–3600.05	depended
			See
		26: Pause wobbling frequency (stopped at the	"Group
P05.01-	Digital input function	present frequency)	P05
P05.06	selection	27: Reset wobbling frequency (returned to the	Input
		center frequency)	terminal
			functions"
D09.15	Amplitude of wobbling	0.0, 100.0% (of the set frequency)	0.0%
F00.15	frequency		0.0%
D09.16	Amplitude of sudden	0.0.50.0% (of the amplitude of webbling frequency)	0.0%
F00.10	jump frequency		0.0%
D09 17	Rise time of wobbling	0.1.2600.0c	5.00
PU0.17	frequency		5.05
P08.18	Fall time of wobbling frequency	0.1–3600.0s	5.0s

## 5.5.17 Local encoder input

The VFD supports pulse count function by inputting the count pulse from HDI high-speed pulse port. When the actual count value is no less than the set value, digital output terminal will output count-value-reached pulse signal, and the corresponding count value will be zeroed out.

Function code	Name	Description	Default
P05.00	HDI input type	0x00–0x11	0x00
		Ones place: HDIA input type	

Function code	Name	Description	Default	
		0: HDIA is high-speed pulse input		
		1: HDIA is digital input		
		Tens place: HDIB input type		
		0: HDIB is high-speed pulse input		
		1: HDIB is digital input		
		0: Input set through frequency		
D05 29	HDIA high-speed pulse input	1: Reserved	0	
P05.30	function selection	2: Input set through encoder, used together	0	
		with HDIB		
		0: Input set through frequency		
DOE 44	HDIB high-speed pulse input	1: Reserved	0	
P05.44	function selection	2: Input set through encoder, used together	0	
		with HDIA		
		0: PG card		
P20.15	Cread measurement mode	1: Locally measured through HDIA and	0	
	Speed measurement mode	HDIB. Only the 24V incremental encoders	U	
		are supported.		
P18.00	Actual frequency of encoder	-999.9–3276.7Hz	0.0Hz	

# 5.5.18 Commissioning procedures for closed-loop control, position control and spindle positioning

## 1. Commissioning procedure for closed-loop vector control on AMs

- (1) Restore to default values through the keypad.
- (2) Set P00.03, P00.04 and motor nameplate parameters in group P02.
- (3) Perform motor parameter autotuning.

Perform rotary parameter autotuning or static parameter autotuning through the keypad. If the motor can be disconnected from load, you can perform rotary parameter autotuning; otherwise, perform static parameter autotuning. The parameters obtained from autotuning are automatically saved to motor parameters in group P02.

- (4) Verify whether the encoder is installed and set properly.
  - a) Determine the encoder direction and parameter settings.

Set P20.01 (encoder PPR), set P00.00=2 and P00.10=20.00Hz, and run the VFD. Then the motor rotates at 20Hz. Check whether the speed measurement value of P18.00 is correct. If the value is negative, it indicates the encoder direction is reversed. In this case, set P20.02 to 1. If the speed measurement value deviates greatly, it indicates P20.01 is set improperly. Check whether P18.02 (encoder Z

pulse count value) fluctuates. If yes, it indicates the encoder suffers interference or P20.01 is set improperly. Then check the wiring and the shield layer.

b) Determine the Z pulse direction.

Set P00.10=20.00Hz, and set P00.13 (running direction) to forward and reverse in turn to check whether the difference in P18.02 is less than 5. If the difference remains greater than 5 after reversing the Z pulse direction through P20.02, power off and swap phase A and phase B of the encoder. Then check the difference in P18.02 between forward rotation and reverse rotation. The Z pulse direction only affects the forward/reverse positioning precision of the spindle positioning carried out with Z pulses.

(5) Perform closed-loop vector pilot-run.

Set P00.00=3, and perform closed-loop vector control, and adjust P00.10 and speed loop and current loop PI parameters in group P03 to implement stable run in the entire range.

(6) Perform flux-weakening control.

Set the flux-weakening regulator gain P03.26 to a value ranging from 0 to 8000, and check the flux-weakening control effect. You can adjust P03.22–P03.24 as needed.

#### 2. Commissioning procedure for closed-loop vector control on SMs

(1) Set P00.18=1 to restore to default settings.

(2) Set P00.00=3 (closed-loop vector control), set P00.03, P00.04, and motor nameplate parameters in group P02.

(3) Set P20.01.

When the encoder is resolver-type encoder, set the encoder pulse count value to (resolver pole pair number x 1024), eg, if pole pair number is 4, set P20.01 to 4096.

(4) Verify whether the encoder is installed and set properly.

When the motor stops, check whether P18.21 (resolver angle) fluctuates. If it fluctuates sharply, check the wiring and grounding. Rotate the motor slowly, and check whether P18.21 changes accordingly. If yes, it indicates that the motor is connected correctly; if the value of P18.02 remains unchanged as a non-zero value after multiple turns of rotation, it indicates that the encoder Z signal is correct.

(5) Autotune the initial position of magnetic pole.

Set P20.11 to 2 (static autotuning) or 3 (rotary autotuning), and press the RUN key to run the VFD.

a) Rotary autotuning (P20.11=3)

Detect the present magnetic pole position when autotuning starts, and then accelerate to 10Hz to autotune the magnetic pole position of encoder Z pulses, and

then decelerate to stop.

During running, if the ENC10 or ENC1d fault occurs, set P20.02=1 and carry out autotuning again.

After autotuning is completed, the angle obtained from autotuning is saved to P20.09 and P20.10 automatically.

b) Static autotuning

In the scenarios where the load can be disconnected, you are recommended to adopt rotary autotuning (P20.11=3) for high angle precision. If the load cannot be disconnected, you can adopt static autotuning (P20.11=2). The magnetic pole position obtained from autotuning is saved to P20.09 and P20.10 automatically.

(6) Perform closed-loop vector pilot-run.

Adjust P00.10 and speed loop and current loop PI parameters in group P03 to implement stable run in the entire range. If oscillation occurs, reduce the value of P03.00, P03.03, P03.09 and P03.10. If current oscillation noise occurs during low speed running, adjust P20.05.

**Note:** You must re-determine P20.02 (encoder direction) and perform magnetic pole position autotuning again if the motor or encoder wires are swapped.

#### 3. Commissioning procedure for pulse train control

Pulse input is operated based on closed-loop vector control; speed detection is needed in the subsequent spindle positioning, zeroing operation and division operation.

- (1) Restore to default values through the keypad.
- (2) Set P00.03, P00.04 and motor nameplate parameters in group P02.
- (3) Motor parameter autotuning: rotary parameter autotuning or static parameter autotuning.
- (4) Verify whether the encoder is installed and set properly. Set P00.00=3 and P00.10=20.00Hz to run the system, and check the control effect and performance of the system.
- (5) Set P21.00=0001 to set positioning mode to position control, namely pulse-train control. There are four kinds of pulse command modes, which can be set by P21.01 (pulse command mode).

In position control mode, you can check the high bit and low bit of position reference and feedback, P18.02 (Encoder Z pulse count value), P18.00 (Actual frequency of encoder), P18.17 (Pulse command frequency), and P18.19 (Position regulator output), through which you can figure out the relation between P18.08 (Pulse command feedforward) and P18.02 (Encoder Z pulse count value), and between P18.17 (Pulse command frequency), P18.18 (Pulse command feedforward) and P18.19 (Position regulator output).

- (6) The position regulator has two gains, namely P21.02 and P21.03, and they can be switched by speed command, torque command and terminals.
- (7) When P21.08 (Output limit of position controller) is set to 0, the position control will be invalid, and at this point, the pulse train acts as frequency source, P21.13 (Position feedforward gain) should be set to 100%, and the speed acceleration/deceleration time is

determined by the acceleration /deceleration time of pulse train, the pulse train acceleration/deceleration time of the system can be adjusted. If the pulse train acts as the frequency source in speed control, you can also set P21.00 to 0000, and set the frequency source reference P00.06 or P00.07 to 12 (Pulse train AB), at this point, the acceleration/deceleration time is determined by the acceleration/deceleration time of the VFD, meanwhile, the parameters of pulse train AB is still set by P21 group. In speed mode, the filter time of pulse train AB is determined by P21.29.

- (8) The input frequency of pulse train is the same with the feedback frequency of encoder pulse, the relation between them can be changed by altering P21.11 (Numerator of position command ratio) and P21.12 (Denominator of position command ratio).
- (9) When running command or servo enabling is valid (by setting P21.00 or terminal function 63), it will enter pulse train servo running mode.

#### 4. Commissioning procedures for spindle positioning

Spindle orientation is to realize orientation functions like zeroing and division based on closed-loop vector control.



(1)–(4) These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control, thus realizing spindle positioning function in either position control or speed control mode.

(5) Set P22.00.bit0=1 to enable spindle positioning, set P22.00.bit1 to select spindle zero input. If the system adopts encoder for speed measurement, set P22.00.bit1 to 0 to select Z pulse input; if the system adopts photoelectric switch for speed measurement, set P22.00.bit1 to 1 to select photoelectric switch as zero input; set P22.00.bit2 to select zero search mode, set P22.00.bit3 to enable or disable zero calibration, and select zero calibration mode by setting P22.00.bit7.

- (6) Spindle zeroing operation
  - a) Select the positioning direction by setting P22.00.bit4;
  - b) There are four zero positions in P22 group, you can choose one out of four zeroing positions by setting zeroing input terminal selection (46, 47) in P05 group. When executing zeroing function, the motor will stop accurately at corresponding zeroing position according to the set positioning direction, which can be viewed via P18.10;

- c) The positioning length of spindle zeroing is determined by the deceleration time of accurate-stop and the speed of accurate-stop;
- (7) Spindle division operation

There are seven scale-division positions in P22 group, you can choose one out of seven scale-division positions by setting scale-division input terminal selection (48, 49, 50) in P05 group. Enable corresponding scale-division terminal after the motor stops accurately, and the motor will check the scale-division position state and switch to corresponding position incrementally, at this point, you can check P18.09.

(8) Priority level of speed control, position control and zeroing

The priority level of speed running is higher than that of the scale division, when the system runs in scale-division mode, if spindle orientation is prohibited, the motor will turn to speed mode or position mode.

The priority level of zeroing is higher than that of the scale division.

Scale-division command is valid when the scale-division terminal is from 000 state to non-000 state, eg, in 000–011, the spindle executes scale division 3. The transition time during terminal switch-over needs to be less than 10ms; otherwise, wrong scale division command may be executed.

(9) Hold positioning

The position loop gain during positioning is P21.03; while the position loop gain in positioning-completion-hold state is P21.02. In order to keep sufficient position-hold force and ensure no system oscillation occurred, adjust P03.00, P03.01, P20.05, and P21.02.

(10) Positioning command selection (bit6 of P22.00)

Electric level signal: Positioning command (zeroing and scale division) can be executed only when there is running command or the servo is enabled.

(11) Spindle reference point selection (bit0 of P22.00)

Encoder Z pulse positioning supports the following spindle positioning modes:

- a) the encoder is installed on the motor shaft, the motor shaft and spindle is 1:1 rigid connection;
- b) the encoder is installed on the motor shaft, the motor shaft and spindle is 1:1 belt connection;

At this point, the belt may slip during high-speed running and cause inaccurate positioning, it is recommended to install proximity switch on the spindle.

c) The encoder is installed on the spindle, and the motor shaft is connected to the spindle with belt, the drive ratio is not necessarily 1:1; At this point, set P20.06 (speed ratio of the mounting shaft between motor and encoder), and set P22.14 (spindle drive ratio) to 1. As the encoder is not installed on the motor, the control performance of closed-loop vector will be affected.

Proximity switch positioning supports the following spindle positioning modes:

The encoder is installed on the spindle, and the motor shaft is connected to the spindle with belt, the drive ratio is not necessarily 1:1;

At this point, it is required to set P22.14 (spindle drive ratio).

#### 5. Commissioning procedures for digital positioning

The diagram for digital positioning is shown as follows.



P21.25 Hold time of positioning completion signal

(1)-(4) These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control.

(5) Set P21.00=0x0011 to enable digital positioning. Set P21.17, P21.11 and P21.12 (set positioning displacement) according to actual needs ; set P21.18 and P21.19 (set positioning speed); set P21.20 and P21.21 (set acceleration/deceleration time of positioning).

(6) Single positioning operation

Set P21.16.bit1=0, and the motor will carry out single positioning action and stay in the positioning position according to the setup in step 5.

(7) Cyclic positioning operation

Set P21.16.bit1=1 to enable cyclic positioning. The cyclic positioning is divided into continuous mode and repetitive mode. You can also carry out cyclic positioning through terminal function (no. 55, enable digital positioning cycle)

## 6. Commissioning procedures for positioning of photoelectric switch

Photoelectric switch positioning is to realize positioning function based on closed-loop vector control.



(1)-(4) These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control.

Set P21.00=0x0021 to enable photoelectric switch positioning, the photoelectric switch signal can be connected to S8 terminal only, and set P05.08=43, meanwhile, set P21.17, P21.11 and P21.12 (set positioning displacement) based on actual needs; set P21.21 (Deceleration time of positioning), however, when present running speed is too fast or the set positioning displacement is too small, the deceleration time of positioning will be invalid, and it will enter direct deceleration positioning mode.

(6) Cyclic positioning operation

After positioning is done, the motor will stay in current position. You can set cyclic positioning through input terminal function selection (55: enable cyclic digital positioning) in P05 group; when the terminal receives cyclic positioning enable signal (pulse signal), the motor will continue running in the set speed as per the speed mode and re-enter positioning state after encountering photoelectric switch.

(7) Hold positioning

The position loop gain during positioning is P21.03; while the position loop gain in positioning-completion-hold state is P21.02. In order to keep sufficient position-hold force and ensure no system oscillation occurred, adjust P03.00, P03.01, P20.05, and P21.02.

#### 5.5.19 Fault handling

The following provides fault handling information.



#### Related parameter list:

Function code	Name	Description	Default
P07.27	Present fault type	0: No fault	0
P07.28	Last fault type	1: Inverter unit U-phase protection (OUt1)	0
P07.29	2nd-last fault type	2: Inverter unit V-phase protection (OUt2)	0
P07.30	3rd-last fault type	3: Inverter unit W-phase protection (OUt3)	0
P07.31	4th-last fault type	4: Overcurrent during ACC (OC1)	0
P07.32	5th-last fault type	<ul> <li>5: Overcurrent during DEC (OC2)</li> <li>6: Overcurrent during constant speed running (OC3)</li> <li>7: Overvoltage during acceleration (OV1)</li> <li>8: Overvoltage during deceleration (OV2)</li> <li>9: Overvoltage during constant speed running (OV3)</li> <li>10: Bus undervoltage fault (UV)</li> <li>11: Motor overload (OL1)</li> <li>12: VFD overload (OL2)</li> </ul>	0

Function code	Name	Description	Default
		13: Phase loss on input side (SPI)	
		14: Phase loss on output side (SPO)	
		15: Rectifier module overheat (OH1)	
		16: Inverter module overheat (OH2)	
		17: External fault (EF)	
		18: Modbus/Modbus TCP communication	
		fault (CE)	
		19: Current detection fault (ItE)	
		20: Motor autotuning fault (tE)	
		21: EEPROM operation fault (EEP)	
		22: PID feedback offline fault (PIDE)	
		23: Braking unit fault (bCE)	
		24: Running time reached (END)	
		25: Electronic overload (OL3)	
		26: Keypad communication error (PCE)	
		27: Parameter upload error (UPE)	
		28: Parameter download error (DNE)	
		29: PROFIBUS DP communication fault	
		(E_dP)	
		30: Ethernet communication fault (E-NET)	
		31: CANopen communication fault (E-CAN)	
		32: To-ground short-circuit fault 1 (ETH1)	
		33: To-ground short-circuit fault 2 (ETH2)	
		34: Speed deviation fault (dEu)	
		35: Mal-adjustment fault (STo)	
		36: Underload fault (LL)	
		37: Encoder disconnection fault (ENC1o)	
		38: Encoder direction reversal fault (ENC1d)	
		39: Encoder Z-pulse disconnection fault	
		(ENC1Z)	
		40: Safe torque off (STO)	
		41: Channel 1 safety circuit exception (STL1)	
		42: Channel 2 safety circuit exception (STL2)	
		43: Exception to both channels 1 and 2	
		(STL3)	
		44: Safety code FLASH CRC fault (CrCE)	
		45: Programmable card customized faults 1	
		(P-E1)	

Function code	Name	Description	Default
		46: Programmable card customized faults 2	
		(P-E2)	
		47: Programmable card customized faults 3	
		(P-E3)	
		48: Programmable card customized faults 4	
		(P-E4)	
		49: Programmable card customized faults 5	
		(P-E5)	
		50: Programmable card customized faults 6	
		(P-E6)	
		51: Programmable card customized faults 7	
		(P-E7)	
		52: Programmable card customized faults 8	
		(P-E8)	
		53: Programmable card customized faults 9	
		(P-E9)	
		54: Programmable card customized faults 10	
		(P-E10)	
		55: Duplicate expansion card type (E-Err)	
		56: Encoder UVW lost (ENCUV)	
		57: PROFINE I communication timeout fault	
		58: CAN communication fault (SECAN)	
		59: Motor overtemperature fault (OT)	
		60: Failure to identify the card at slot 1 (F1-Er)	
		62: Eailure to identify the card at slot 2 (F2-E1)	
		63: Communication timeout of the card at slot	
		1 (C1-Fr)	
		64: Communication timeout of the card at slot	
		2 (C2-Fr)	
		65: Communication timeout of the card at slot	
		3 (C3-Fr)	
		66: EtherCAT communication fault (E-CAT)	
		67: BACnet communication fault (E-BAC)	
		68: DeviceNet communication fault (E-DEV)	
		69: CAN slave fault in master/slave	
		synchronization (S-Err)	

Function code	Name	Description	Default
		70: EC PT100 detected overheating (OtE1)	
		72: EtherNet IP communication timeout fault	
		(E-EIP)	
		73: No upgrade bootload (E-PAO)	
		74: Al1 disconnection (E-Al1)	
		75: AI2 disconnection (E-AI2)	
		76: AI3 disconnection (E-AI3)	
P07.33	Running frequency at present fault	0.00Hz–P00.03	0.00Hz
P07.34	Ramp reference frequency at present fault	0.00Hz–P00.03	0.00Hz
P07.35	Output current at present fault	0–1200V	0V
P07.36	Output current at present fault	0.0–6300.0A	0.0A
P07.37	Bus voltage at present fault	0.0–2000.0V	0.0V
P07.38	Max. temperature at present fault	-20.0–120.0°C	0.0°C
P07.39	Input terminal status at present fault	0x0000-0xFFF	0x0000
P07.40	Output terminal status at present fault	0x0000-0xFFFF	0x0000
P07.41	Running frequency at last fault	0.00Hz–P00.03	0.00Hz
P07.42	Ramp reference frequency at last fault	0.00Hz–P00.03	0.00Hz
P07.43	Output voltage at last fault	0–1200V	0V
P07.44	Output current at last fault	0.0–6300.0A	0.0A
P07.45	Bus voltage at last fault	0.0–2000.0V	0.0V
P07.46	Max. temperature at last fault	-20.0–120.0°C	0.0°C
P07.47	Input terminal state at last fault	0x0000–0xFFFF	0x0000
P07.48	Output terminal state at last fault	0x0000-0xFFFF	0x0000

Function code	Name	Description	Default
P07.49	Running frequency at 2nd-last fault	0.00Hz–P00.03	0.00Hz
P07.50	Ramp reference frequency at 2nd-last fault	0.00Hz–P00.03	0.00Hz
P07.51	Output voltage at 2nd-last fault	0–1200V	0V
P07.52	Output current at 2nd-last fault	0.0–6300.0A	0.0A
P07.53	Bus voltage at 2nd-last fault	0.0–2000.0V	0.0V
P07.54	Temperature at 2nd-last fault	-20.0–120.0°C	0.0°C
P07.55	Input terminal state at 2nd-last fault	0x0000–0xFFF	0x0000
P07.56	Output terminal state at 2nd-last fault	0x0000–0xFFFF	0x0000

#### 5.5.20 Tension control solutions

In many fields of industrial production, precise tension control is needed to maintain a constant output tension of the drive equipment, in order to improve the quality of the products. In the winding and unwinding of some industries such as paper processing, printing and dyeing, packing, wire and cable manufacturing, textile, fiber, optic cable, leather, metal foil material processing and so on, tension needs to keep constant.

The VFD controls the tension through the output torque or speed of the motor. There are three kinds of control modes: tension speed control mode, open loop tension torque control mode and close-loop tension torque control mode.

#### 5.5.20.1 Sketch map of tension control



In some special situations, if the coil diameter can be counted through thickness, the following modes are available:



#### 5.5.20.2 Tension speed control mode

The detection feedback signal is needed in the close loop adjustment. PID calculation is carried out according to the feedback signal for the motor speed adjustment, linear speed and stable tension control. If tension rod or floating roller is used for feedback, changing the setting value (PID reference) may change the actual tension, at the same time, changing the mechanical configuration such as tension rocker or floating roller weight can also change the tension.

The control principle is:



Relevant modes:

(1) Input module of linear speed: this part is important for the calculation of the basic setting frequency according to the linear speed and the calculation of coil diameter according to the linear speed.

(2) Calculation module of the real-time coil diameter: the calculation of coil diameter determines the control performance. The coil diameter can be calculated according to the

output frequency of the VFD and the linear speed or be calculated through the thickness or sensor, of which, the linear speed is widely used for the calculation and if using this method, it is necessary to select whether enable the function of coil diameter limiting.

(3) PID adjustment module: mainly set in P09 group, with two sets of PID parameters available. The linear speed synchronization and stable tension can be kept through PID adjustment, but PID parameters can be adjusted according to the site commissioning. Parameters can be switched between two groups of PID parameters to PID improvement.

(4) Detection and processing module of materials break. The function is valid when enabling the materials detection.

(5) Pre-drive: if the pre-drive function terminal is valid, when automatic volume-changing, after starting the VFD, the drum will run at the setting linear speed, if the terminal is invalid, the VFD will automatically switch to the corresponding control mode.

#### 5.5.20.3 Open-loop tension torque control mode

Open loop means no tension feedback signal; the mode controls the tension through the motor torque control directly. The rotation speed changes with the linear speed of the material automatically. The basic is: in frizzy control system, the relationship between the tension F of the roller with materials, current coil diameter D and output torque of the shaft is:  $T = F \times D/2$ . If the output torque can be adjusted according to the variation of coil diameter, the tension can be controlled. In order to ensure the constant tension in the process of acceleration and deceleration, there is internal friction compensation module and inertia compensation module in the VFD to calculate the real time the moment of inertia, and compensate the torque according to the current speed rate of change. The control principle is:



#### Relevant modes:

(1) Linear speed input modes: Linear speed input modes: two functions, one is used to count the synchronous frequency in torque control system according to the linear speed; the other is used to count the coil diameter according to the linear speed.

(2) Tension setting modes: Set the tension with the control system, need to adjust according to the actual situation. After confirmation, the value remains the same, and for some need to improve the winding, tension taper function can be selected to raise the tension with the

increasing coil diameter.

(3) Coil diameter real time calculation module: Coil diameter calculation directly determines the effect of the control. There are several kinds of coil diameter calculation methods. Linear speed, output frequency, thickness and sensor are available. The most convenient is to calculate through the thickness. And it is necessary to enable the coil diameter changing limit when using linear speed to calculate the coil diameter.

(4) Torque compensation module: include friction torque compensation and inertia torque compensation. Of which, the friction torque compensation is used to eliminate the impact of friction and tension, and it needs to be adjusted according to actual requirements; the inertia torque compensation includes the moment of inertia moment of mechanical systems and materials. In order to keep the tension stable in ACC/DEC, the compensation torque is required. But in some cases which do not need tension control, disabling the inertia torque compensation can also meet the requirements.

(5) Detection and processing module of materials break. The function is valid when enabling the materials detection.

(6) Pre-drive: if the pre-drive function terminal is valid, when automatic volume-changing, after starting the VFD, the drum will run at the setting linear speed, if the terminal is invalid, the VFD will automatically switch to the corresponding control mode.

#### 5.5.20.4 Closed-loop tension torque control mode

Close-loop tension torque control mode is similar to open-loop tension torque control mode, the difference is that the former has tension detection sensor installed on wind/unwind side. This mode supports all the function modules of open-loop tension torque control, in additional, it is added with an additional tension feedback PID close-loop regulator module. The control principle is:



## **6** Function parameter list

## 6.1 What this chapter contains

This chapter lists all the function codes and corresponding description of each function code.

## 6.2 Function parameter list

The function parameters of the VFD are divided into groups by function. Among the function parameter groups, the P98 group is the analog input and output calibration group, while the P99 group contains the factory function parameters, which are user inaccessible. Each group includes several function codes (each function code identifies a function parameter). A three-level menu style is applied to function codes. For example, "P08.08" indicates the 8th function code in the P08 group.

The function group numbers correspond to the level-1 menus, the function codes correspond to the level-2 menus, and the function parameters correspond to the level-3 menus.

1. The content of the function code table is as follows:

Column 1 "Function code": Code of the function group and parameter.

Column 2 "Name": Full name of the function parameter.

Column 3 "Description": Detailed description of the function parameter.

Column 4 "Default": Initial value set in factory.

Column 5 "Modify": Whether the function parameter can be modified, and conditions for the modification.

"O" indicates that the value of the parameter can be modified when the VFD is in stopped or running state.

" $\ensuremath{\mathbb{O}}$ " indicates that the value of the parameter cannot be modified when the VFD is in running state.

"●" indicates that the value of the parameter is detected and recorded, and cannot be modified.

(The VFD automatically checks and constrains the modification of parameters, which helps prevent incorrect modifications.)

- The parameters adopt the decimal system (DEC). If the hexadecimal system is adopted, all bits are mutually independent on data during parameter editing, and the setting ranges at some bits can be hexadecimal (0–F).
- "Default" indicates the factory setting of the function parameter. If the value of the parameter is detected or recorded, the value cannot be restored to the factory setting.
- 4. To better protect parameters, the VFD provides the password protection function. After a password is set (that is, P07.00 is set to a non-zero value), "0.0.0.0.0" is displayed when

you press the **PRG/ESC** key to enter the function code editing interface. You need to enter the correct user password to enter the interface. For the factory parameters, you need to enter the correct factory password to enter the interface. (You are not advised to modify the factory parameters. Incorrect parameter setting may cause operation exceptions or even damage to the VFD.) If password protection is not in locked state, you can change the password any time. You can set P07.00 to 0 to cancel the user password. When P07.00 is set to a non-zero value during power-on, parameters are prevented from being modified by using the user password function. When you modify function parameters through serial communication, the user password protection function is also applicable and compliant with the same rule.

#### Group P00—Basic functions

Function code	Name	Description	Default	Modify
P00.00	Speed control mode	0: SVC mode 0 1: SVC mode 1 2: Space voltage vector control mode 3: Feedback vector control (FVC) mode <b>Note:</b> Before using a vector control mode (0, 1, or 3), enable the VFD to perform motor parameter autotuning first.	2	Ø
P00.01	Channel of running commands	0: Keypad 1: Terminal 2: Communication	0	0
P00.02	Communication mode of running commands	0: Modbus/Modbus TCP communication 1: PROFIBUS/CANopen/DeviceNet 2: Ethernet communication 3: EtherCAT/ PROFINET/ EtherNet IP communication 4: Programmable expansion card 5: Wireless communication card 6: Reserved Note: Modbus TCP in option 0 and options 1, 2, 3, 4, and 5 are add-on functions and are available only when corresponding expansion cards are configured.	0	0
P00.03	Max. output frequency	The function code is used to set the max. output frequency of the VFD. Pay attention to the function code because it is the foundation of the frequency setting and the speed of acceleration	50.00Hz	O

Function code	Name	Description	Default	Modify
		(ACC) and deceleration (DEC).		
		Setting range: Max (P00.04, 10.00)–599.00Hz		
P00.04	Upper limit of running frequency	The upper limit of the running frequency is the	50.00Hz	٥
		upper limit of the output frequency of the VFD,		
		which is lower than or equal to the max. output		
		frequency.		
		When the set frequency is higher than the		
		upper limit of the running frequency, the upper		
		limit of the running frequency is used for		
		running.		
		Setting range: P00.05–P00.03 (Max. output		
		The lower limit of the running frequency is the		
P00.05	Lower limit of running frequency	Ine lower limit of the output frequency of the VED	0.00Hz	٥
		N/her the set frequency is lower than the lower		
		Vinen the set frequency is lower than the lower		
		limit of the running frequency, the lower limit of		
		the running frequency is used for running.		
		<b>Note:</b> Max. output frequency $\geq$ Upper limit of		
		frequency ≥ Lower limit of frequency.		
		Setting range: 0.00Hz–P00.04 (Upper limit of		
		running frequency)		
P00.06	Setting channel of	0: Keypad		
	A frequency	1: Al1	0	0
	command	2: AI2		
P00.07	Setting channel of B frequency command	3: AI3	15	0
		4: High-speed pulse HDIA		
		5: Simple PLC program		
		6: Multi-step speed running		
		7: PID control		
		8: Modbus/Modbus TCP communication		
		9: PROFIBUS/CANopen/DeviceNet		
		communication		
		10: Ethernet communication		
		11: High-speed pulse HDIB		
		12: Pulse train AB		
		13: EtherCAT/PROFINET/ EtherNet IP		
		communication		
		14: Programmable expansion card		
Function code	Name	Description	Default	Modify
------------------	---	--	-------------------	--------
		15: Reserved		
P00.08	Reference object of B frequency command	0: Max. output frequency 1: A frequency command	0	0
P00.09	Combination mode of setting source	0: A 1: B 2: (A+B) 3: (A-B) 4: Max(A, B) 5: Min(A, B)	0	0
P00.10	Frequency set through keypad	When A and B frequency commands select the keypad for setting, the value of the function code is the original setting one of the frequency data of the VFD. Setting range: 0.00 Hz–P00.03 (Max. output frequency)	50.00Hz	0
P00.11	ACC time 1	ACC time means the time needed if the VFD speeds up from 0Hz to the max. output	Model depended	0
P00.12	DEC time 1	frequency (P00.03). DEC time means the time needed if the VFD speeds down from the max. output frequency (P00.03) to 0Hz. The VFD has four groups of ACC/DEC time, which can be selected by P05. The factory default ACC/DEC time of the VFD is the first group. P00.11 and P00.12 setting range: 0.0–3600.0s	Model depended	0
P00.13	Running direction	0: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running.	0	0
P00.14	Carrier frequency setting	Carrier frequency     Electro magnetic noise     Noise and leakage current     Cooling level       1kHz <ul> <li>High</li> <li>Low</li> <li>High</li> <li>High</li></ul>	Model depended	0

Function code	Name	Description		Default	Modify
		frequencies is as follows:			
			Default		
		VFD model	carrier		
			frequency		
		004G/5R5P-011G/015P	8kHz		
		380V 015G/018P-055G/075P	4kHz		
		075G/090P and higher	2kHz		
		Advantage of high carrier frequence	cy: ideal		
		current waveform, little current har	monic wave		
		and motor noise.			
		Disadvantage of high carrier frequ	ency:		
		increasing the switch loss, increas	ing VFD		
		temperature and the impact to the	output		
		capacity. The VFD needs to derate	e on high		
		carrier frequency. At the same time	e, the leakage		
		and electrical magnetic interference	e will		
		increase.			
		On the contrary, an extremely-low	a carrier		
		frequency may cause unstable op	eration at low		
		frequency, decrease the torque, or	r even lead to		
		oscillation.			
		The carrier frequency has been pr	operly set in		
		the factory before the VFD is deliv	ered. In		
		general, you do not need to modify	y it.		
		When the frequency used exceeds	s the default		
		carrier frequency, the VFD needs	to derate by		
		10% for each increase of 1k carrie	er frequency.		
		Setting range: 1.0–15.0kHz			
		0: No operation			
		1: Rotary autotuning 1			
		Comprehensive motor parameter	autotuning. It		
	Perform motor	is recommended to use rotating at	utotuning		
P00.15	5 parameter	when high control accuracy is requ	uired.	0	O
	autotunina.	2: Static autotuning 1 (comprehen	sive	-	-
		autotuning)			
		Motor parameter autotuning. It is a	applicable in		
		scenarios where the motor cannot	be		
		disconnected from load.			

Function code	Name	Description	Default	Modify
		3: Static autotuning 2 (partial autotuning)		
		When the present motor is motor 1, only		
		P02.06, P02.07, and P02.08 are autotuned;		
		when the present motor is motor 2, only		
		P12.06, P12.07, and P12.08 are autotuned.		
		4: Rotary autotuning 2		
		It is similar to rotary autotuning 1 but only valid		
		for AMs.		
		5: Static autotuning 3 (partial autotuning)		
		It is valid only for AMs.		
		0: Disable		
P00.16	AVR function selection	1: Valid during the whole process		
		The auto-adjusting function of the VFD can	1	0
		eliminate the impact on the output voltage of		
		the VFD because of the bus voltage fluctuation.		
D00 17		0: G type		
P00.17	vно туре	1: P type		
		0: No operation		
		1: Restore default values		
		2: Clear fault records		
		3: Reserved		
		4: Reserved		
		5: Restore to default values (factory test mode)		
	Function parameter	6: Restore to default values (including motor		
P00.18	restoration	parameters)	0	O
	restoration	Note: After the selected operation is performed,		
		the function code is automatically restored to 0.		
		Restoring the default values may delete the		
		user password. Exercise caution when using		
		this function.		
		The option 5 can be used only for factory		
		testing.		

# Group P01--Start and stop control

Function code	Name	Description	Default	Modify
D01.00	Running mode of	0: Direct start	0	
F01.00	start	1: Start after DC braking	0	0

Function code	Name	Description	Default	Modify
		2: Start after speed tracking		
P01.01	Starting frequency of direct start	The function code indicates the initial frequency during VFD start. See P01.02 (Starting frequency hold time) for detailed information. Setting range: 0.00–50.00Hz	0.50Hz	0
P01.02	Hold time of starting frequency	Output frequency fmax f1 set by P01.01 f1 set by P01.02 f1 set by P01.02 ft set by P01 s	0.0s	Ø
P01.03	Braking current before start	The VFD performs DC braking with the braking current before start and it speeds up after the	0.0%	Ø
P01.04	Braking time before start	DC braking time. If the set DC braking time is 0, DC braking is invalid. Stronger braking current indicates larger braking power. The DC braking current before start is a percentage of the VFD rated output current. Setting range of P01.03: 0.0–100.0% Setting range of P01.04: 0.00–50.00s	0.00s	O
P01.05	ACC and DEC mode	The function code is used to indicate the changing mode of the frequency during start and running. 0: Linear type. The output frequency increases or decreases linearly.	0	0

Function code	Name	Description	Default	Modify
		▲ Output frequency f		
		fmax 		
		1: S curve. The output frequency increases or		
		decreases according to the S curve.		
		The S curve is generally applied to elevators,		
		conveyors, and other application scenarios		
		where smoother start or stop is required.		
		<ul> <li>Output frequency f</li> </ul>		
		fmax t1 - t2 - t2 - t2		
		Note: If mode 1 is selected, set P01.06.		
		P01.07, P01.27, and P01.28 accordingly.		
	Time of starting	The curvature of S curve is determined by the		
P01.06	segment of ACC S	ACC range and ACC/DEC time.	0.1s	O
	curve	Output frequency f		
P01.07	Time of ending segment of ACC S curve	t1=P01.06 t2=P01.07 t3=P01.27 t4=P01.28	0.1s	0
		Setting range: 0.0–50.0s		
		0: Decelerate to stop. After a stop command		
		based on the DEC mode and the defined DEC		
		time: after the frequency drops to the stop		
P01 08	Stop mode	speed (P01 15) the VED stops	0	0
101.00	otop mode	1: Coast to stop. After a stop command takes	U	U
		effect, the VED stops output immediately: and		
		the load coasts to stop according to mechanical		
		inertia.		
P01.09	Starting frequency	Starting frequency of DC braking for stop:	0.00Hz	0

Name	Description	Default	Modify
of braking for stop	During the deceleration to stop, the VFD starts		
Demagnetization time	DC braking for stop when running frequency reaches the starting frequency determined by	0.00s	0
DC braking current for stop	P01.09. Wait time before DC braking: The VFD blocks	0.0%	0
DC braking time for stop	the output before starting DC braking. After this wait time, DC braking is started so as to prevent overcurrent caused by DC braking at high speed. DC braking current for stop: It indicates the applied DC braking energy. Stronger current indicates greater DC braking effect. DC braking time for stop: It indicates the hold time of DC braking. If the time is 0, DC braking is invalid, and the VFD decelerates to stop within the specified time.	0.00s	0
FWD/REV run deadzone time	This function code indicates the transition time specified in P01.14 during FWD/REV rotation switching. See the figure.	0.0s	0
	Name         of braking for stop         Demagnetization         time         DC braking current         for stop         DC braking time for         stop         FWD/REV run         deadzone time	NameDescriptionof braking for stopDuring the deceleration to stop, the VFD startsDemagnetization timeDC braking for stop when running frequency reaches the starting frequency determined by PO1.09.DC braking current for stopP01.09.Wait time before DC braking: The VFD blocks the output before starting DC braking. After this wait time, DC braking is started so as to prevent overcurrent caused by DC braking at high speed. DC braking current for stop: It indicates the applied DC braking energy. Stronger current indicates greater DC braking effect. DC braking time for stop it indicates the hold time of DC braking. If the time is 0, DC braking is invalid, and the VFD decelerates to stop within the specified time.DC braking time for stopSetting range of P01.09: 0.00Hz–P00.03 (Max. output frequency) Setting range of P01.10: 0.00–30.00s Setting range of P01.10: 0.00–30.00s Setting range of P01.11: 0.0–100.0% (of the rated VFD output current) Setting range of P01.12: 0.0–50.0sFWD/REV run deadzone timeSetting range of P01.12: 0.0–50.0sFWD/REV run deadzone timeSetting range of P01.12: 0.0–50.0sFWD/REV run deadzone timeSetting range of P01.12: 0.0–50.0s	Name         Description         Default           of braking for stop         During the deceleration to stop, the VFD starts DC braking for stop when running frequency reaches the starting frequency determined by P01.09.         0.00s           DC braking current for stop         Wait time before DC braking: The VFD blocks the output before starting DC braking. After this wait time, DC braking energy. Stronger current indicates greater DC braking effect. DC braking time for stop         0.0%           DC braking time for stop         OC braking is prevent overcurrent caused by DC braking at high speed. DC braking time for stop: It indicates the applied DC braking energy. Stronger current indicates greater DC braking effect. DC braking time for stop: It indicates the hold time of DC braking. If the time is 0, DC braking is invalid, and the VFD decelerates to stop within the specified time.         0.00s           DC braking time for stop         Setting range of P01.09: 0.00Hz–P00.03 (Max. output frequency)         0.00s           Setting range of P01.11: 0.0–30.00s Setting range of P01.12: 0.0–50.0s         This function code indicates the transition time specified in P01.14 during FWD/REV rotation switching. See the figure.         0.0s

Function code	Name	Description	Default	Modify
P01.14	FWD/REV run switching mode	0: Switch at zero frequency 1: Switch at the starting frequency 2: Switch after the speed reaches the stop speed with a delay	1	O
P01.15	Stop speed	0.00–100.00Hz	0.50Hz	O
P01.16	Stop speed detection mode	0: Detect by the set speed (unique in space voltage vector control mode) 1: Detect according to speed feedback	0	O
P01.17	Stop speed detection time	0.00–100.00s	0.50s	O
P01.18	Terminal-based running command protection at power-on	When the channel of running commands is terminal control, the system detects the state of the running terminal during power-on. 0: The terminal running command is invalid at power-on. Even the running command is considered as valid during power-on, the VFD does not run and it keeps the protection state until the running command is canceled and enabled again. 1: The terminal running command is valid at power-on. If the running command is considered as valid during power-on, the VFD is started automatically after the initialization. <b>Note: Exercise caution before using this function. Otherwise, serious result may follow.</b>	0	0
P01.19	Action selected when running frequency less than frequency lower limit (valid when frequency lower limit greater than 0)	The function code determines the running state of the VFD when the set frequency is lower than the lower-limit one. Setting range: 0x00–0x12 Ones place: Action selection 0: Run at the frequency lower limit 1: Stop 2: Sleep Tens place: Stop mode 0: Coast to stop 1: Decelerate to stop The VFD stops as set in the tens place if the	0x00	0

Function code	Name	Description	Default	Modify
		action selection is stop or sleep when the set frequency is lower than the lower limit. The VFD resumes the running state automatically when the set frequency is above the lower limit again and this situation lasts for the time set by P01.20.		
P01.20	Wake-up-from-slee p delay	The function code specifies the wake-up-from-sleep delay time. When the running frequency of the VFD is lower than the lower limit, the VFD becomes standby. When the set frequency exceeds the lower limit one again and it lasts for the time set by P01.20, the VFD runs automatically.	0.0s	0
P01.21	Restart after power off	The function code indicates whether the VFD automatically runs after re-power on. 0: Disable 1: Enable. If the restart condition is met, the VFD will run automatically after waiting the time defined by P01.22.	0	0
P01.22	Wait time for restart after power-off	The function code indicates the wait time before the automatic running of the VFD that is re-powered on. Output frequency t1=P01.22 t2=P01.23	1.0s	0

Function code	Name	Description	Default	Modify
		Setting range: 0.0–3600.0s (valid only when P01.21 = 1)		
P01.23	Start delay	After a VFD running command is given, the VFD restarts running output with the delay defined by P01.23 from the standby state, to implement brake release. Setting range: 0.0–600.0s	0.0s	0
P01.24	Stop speed delay	0.0–600.0s	0.0s	0
P01.25	Open-loop 0Hz output selection	0: Output without voltage 1: Output with voltage 2: Output with the DC braking current for stop	0	0
P01.26	DEC time for emergency stop	0.0–60.0s	2.0s	0
P01.27	Time of starting segment of DEC S curve	0.0–50.0s	0.1s	O
P01.28	Time of ending segment of DEC S curve	0.0–50.0s	0.1s	O
P01.29	Short-circuit braking current	When the VFD starts in direct start mode (P01.00 = 0), set P01.30 to a non-zero value to	0.0%	0
P01.30	Hold time of short-circuit braking for start	enter short-circuit braking. During stop, if the running frequency of VFD is lower than the starting frequency of brake for	0.00s	0
P01.31	Hold time of short-circuit braking for stop	stop (P01.09), set P01.31 to a non-zero value to enter short-circuit braking for stop, and then carry out DC braking in the time specified by P01.12. (See descriptions for P01.09–P01.12.) P01.29 setting range: 0.0–150.0% (of the rated VFD output current) Setting range of P01.30: 0.0–50.0s Setting range of P01.31: 0.0–50.0s	0.00s	0
P01.32	Pre-exciting time for jogging	0.000s–10.000s	0.300s	0
P01.33	Starting frequency of braking for stop in jogging	0.00Hz–P00.03	0.00Hz	0
P01.34	Sleep delay	0.0s-3600.0s	0.0s	0

## Group P02—Parameters of motor 1

Function code	Name	Description	Default	Modify
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0	O
P02.01	Rated power of AM 1	0.1–3000.0kW	Model depended	O
P02.02	Rated frequency of AM 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz	O
P02.03	Rated speed of AM 1	1–60000rpm	Model depended	0
P02.04	Rated voltage of AM 1	0–1200V	Model depended	O
P02.05	Rated current of AM 1	0.8–6000.0A	Model depended	O
P02.06	Stator resistance of AM 1	0.001–65.535Ω	Model depended	0
P02.07	Rotor resistance of AM 1	0.001–65.535Ω	Model depended	0
P02.08	Leakage inductance of AM 1	0.1–6553.5mH	Model depended	0
P02.09	Mutual inductance of AM 1	0.1–6553.5mH	Model depended	0
P02.10	No-load current of AM 1	0.1–6553.5A	Model depended	0
P02.11	Magnetic saturation coefficient 1 of iron core of AM 1	0.0–100.0%	80.0%	0
P02.12	Magnetic saturation coefficient 1 of iron core of AM 2	0.0–100.0%	68.0%	0
P02.13	Magnetic saturation coefficient 1 of iron core of AM 3	0.0–100.0%	57.0%	0
P02.14	Magnetic saturation coefficient 1 of iron core of AM 4	0.0–100.0%	40.0%	0
P02.15	Rated power of SM 1	0.1–3000.0kW	Model depended	O

Function code	Name	Description	Default	Modify
P02.16	Rated frequency of SM 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz	O
P02.17	Number of pole pairs of SM 1	1–128	2	O
P02.18	Rated voltage of SM 1	0–1200V	Model depended	O
P02.19	Rated current of SM 1	0.8–6000.0A	Model depended	O
P02.20	Stator resistance of SM 1	0.001–65.535Ω	Model depended	0
P02.21	Direct-axis inductance of SM 1	0.01–655.35mH	Model depended	0
P02.22	Quadrature-axis inductance of SM 1	0.01–655.35mH	Model depended	0
P02.23	Counter-emf of SM 1	0–10000	300	0
P02.24	Initial pole position of SM 1	0x0000–0xFFFF	0x0000	•
P02.25	Identification current of SM 1	0–50% (of the motor rated current)	10%	•
P02.26	Overload protection selection of motor 1	<ul> <li>0: No protection</li> <li>1: Common motor protection (with low-speed compensation). As the cooling effect of a common motor is degraded at low speed running, the corresponding electronic thermal protection value needs to be adjusted properly, the low compensation indicates lowering the overload protection threshold of the motor whose running frequency is lower than 30Hz.</li> <li>2: Variable-frequency motor protection (without low speed compensation). Because the heat dissipation function for a variable-frequency motor is not impacted by the rotation speed, it is not necessary to adjust the protection value at low speed running.</li> </ul>	2	٥
P02.27	Overload protection coefficient of motor 1	Motor overload multiples M=lout/(In*K) In is rated motor current, lout is VFD output current, K is motor overload protection	100.0%	0

Function code	Name	Description	Default	Modify
		coefficient. A smaller value of "K" indicates a bigger value of "M". When M=116%, protection is performed after motor overload lasts for 1 hour; when M=150%, protection is performed after motor overload lasts for 12 minutes; when M=200%, protection is performed after motor overload lasts for 1 minute; and when M≥400%, protection is performed immediately.		
		Time (min) 60 12 5 1 16% 150% 180% 200% Setting range: 20.0% 10.0%		
P02.28	Power display calibration coefficient of motor 1	The function code can be used to adjust the power display value of motor 1. However, it does not affect the control performance of the VFD. Setting range: 0.00–3.00	1.00	0
P02.29	Parameter display of motor 1	<ol> <li>Display by motor type. In this mode, only parameters related to the present motor type are displayed.</li> <li>Display all. In this mode, all the motor parameters are displayed.</li> </ol>	0	0
P02.30	System inertia of motor 1	0.000–30.000kg·m²	0.000 kg⋅m²	0
P02.31- P02.32	Reserved	-	-	-

# Group P03—Vector control of motor 1

Function code	Name	Description	Default	Modify
P03.00	Speed-loop proportional gain 1	The parameters P03.00–P03.05 are applicable only to vector control mode. Below the	20.0	0
P03.01	Speed-loop integral time 1	switching frequency 1 (P03.02), the speed-loop PI parameters are: P03.00 and P03.01. Above	0.200s	0
P03.02	Low-point frequency for switching	the switching frequency 2 (P03.05), the speed-loop PI parameters are: P03.03 and P03.04. PI parameters are obtained according	5.00Hz	0
P03.03	Speed-loop proportional gain 2	to the linear change of two groups of parameters. See the following figure:	20.0	0
P03.04	Speed-loop integral time 2	► PI parameter <u>P03.00, P03.01</u>	0.200s	0
P03.05	High-point frequency for switching	P03.03, P03.04 <u>Dutput frequency f</u> P03.02 P03.05 The speed loop dynamic response characteristics of vector control can be adjusted by setting the proportional coefficient and integral time of speed regulator. Increasing proportional gain or reducing integral time can accelerate dynamic response of speed loop; however, if the proportional gain is too large or integral time is too small, system oscillation and overshoot may occur; If proportional gain is too small, stable oscillation or speed offset may occur. PI parameters have a close relationship with the inertia of the system. Adjust PI parameters depending on different loads to meet various demands. Setting range of P03.00: 0.0–200.0 Setting range of P03.02: 0.00Hz–P03.05 Setting range of P03.03: 0.0–200.0 Setting range of P03.04: 0.000–10.000s Setting range of P03.05: P03.02–P00.03 (Max. output frequency)	10.00Hz	0

Function code	Name	Description	Default	Modify
P03.06	Speed-loop output filter	0–8 (corresponding to 0–2 <sup>8</sup> /10ms)	0	0
P03.07	Electromotive slip compensation coefficient of vector control	Slip compensation coefficient is used to adjust the slip frequency of the vector control and improve the speed control accuracy of the	100%	0
P03.08	Vector control slip compensation coefficient (for power generation)	system. Adjusting the parameter properly can control the speed steady-state error. Setting range: 50–200%	100%	0
P03.09	Current-loop proportional coefficient P	<ul> <li>Note:</li> <li>The two function codes impact the dynamic response speed and control accuracy of</li> </ul>	1000	0
P03.10	Current-loop integral coefficient I	<ul> <li>the system. Generally, you do not need to modify the two function codes.</li> <li>Applicable to SVC mode 0 (P00.00=0), SVC mode 1 (P00.00=1), and FVC mode (P00.00=3).</li> <li>Setting range: 0–65535</li> </ul>	1000	0
P03.11	Torque setting method selection	0–1: Keypad (P03.12) 2: Al1 3: Al2 4: Al3 5: Pulse frequency HDIA 6: Multi-step torque 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: Pulse frequency HDIB 11: EtherCAT/PROFINET/ EtherNet IP communication 12: Programmable expansion card Note: 100% corresponds to the motor rated current.	0	0
P03.12	Torque set through keypad	-300.0%–300.0% (of the motor rated current)	20.0%	0
P03.13	Torque reference	0.000–10.000s	0.010s	0

Function code	Name	Description	Default	Modify
	filter time			
P03.14	Setting source of forward rotation frequency upper limit in torque control	0: Keypad (P03.16) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: Pulse frequency HDIB 10: EtherCAT/PROFINET/ EtherNet IP communication 11: Programmable expansion card 12: Reserved Note: 100% corresponds to the max. frequency.	0	0
P03.15	Setting source of reverse rotation upper-limit frequency in torque control	0: Keypad (P03.17) 1–11: Same as those for P03.14	0	0
P03.16	Forward rotation frequency upper limit set through keypad in torque control	Used to set the frequency upper limits. 100% corresponds to the max. frequency. P03.16 specifies the value when P03.14=1, while	50.00Hz	0
P03.17	Reverse rotation upper-limit frequency set through keypad in torque control	P03.17 specifies the value when P03.15=1. Setting range: 0.00Hz–P00.03 (Max. output frequency)	50.00Hz	0
P03.18	Setting source of electromotive torque upper limit	0: Keypad (P03.20) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA	0	0

Function code	Name	Description	Default	Modify
		5: Modbus/Modbus TCP communication 6: PROFIBUS/CANopen/DeviceNet communication 7: Ethernet communication 8: Pulse frequency HDIB 9: EtherCAT/PROFINET/ EtherNet IP communication 10: Programmable expansion card 11: Reserved Note: 100% corresponds to the motor rated current.		
P03.19	Setting source of braking torque upper limit	0: Keypad (P03.21) 1–10: Same as those for P03.18	0	0
P03.20	Electromotive torque upper limit set through keypad	Used to set torque limits. Setting range: 0.0–300.0% (of the motor rated	180.0%	0
P03.21	Braking torque upper limit set through keypad	current)	180.0%	0
P03.22	Weakening coefficient in constant power zone	Used when the AM is in flux-weakening control.	0.3	0
P03.23	Lowest weakening point in constant power zone	Coefficient of motor 0.1 1.0 2.0 Min. flux-weakening limit of motor The function codes P03.22 and P03.23 are valid at constant power. The motor enters the flux-weakening state when the motor runs above the rated speed. Change the flux-weakening curvature by modifying the flux-weakening control coefficient. The larger the coefficient, the steeper the curve, the smaller the coefficient, the smoother the curve. Setting range of P03.22: 0.1–2.0	20%	0

Function code	Name	Description	Default	Modify
		Setting range of P03.23: 10%–100.0%		
P03.24	Max. voltage limit	P03.24 sets the max. output voltage of the VFD, which is the percentage of motor rated voltage. Set the value according to onsite conditions. Setting range: 0.0–120.0%	100.0%	0
P03.25	Pre-exciting time	Pre-exciting is performed for the motor when the VFD starts up. A magnetic field is built up inside the motor to improve the torque performance during the start process. Setting range: 0.000–10.000s	0.300s	0
P03.26	Flux-weakening proportional gain	0–8000	1000	0
P03.27	Speed display selection in vector control	0: Display the actual value 1: Display the set value	0	0
P03.28	Static friction compensation coefficient	0.0–100.0%	0.0%	0
P03.29	Corresponding frequency point of static friction	0.50–P03.31	1.00Hz	0
P03.30	High speed friction compensation coefficient	0.0–100.0%	0.0%	0
P03.31	Corresponding frequency of high speed friction torque	P03.29–400.00Hz	50.00Hz	0
P03.32	Enabling torque control	0: Disable 1: Enable	0	O
P03.33	Flux-weakening integral gain	0–8000	1200	0
P03.34	Flux-weakening control mode	0x000–0x112 Ones place: Control mode selection 0: Mode 0 1: Mode 1 2: Mode 2	0x000	0

Function code	Name	Description	Default	Modify
		Tens place: Compensation of inductance saturation coefficient 0: Yes 1: No Hundreds place: Reserved 0: Reserved 1: Reserved		
P03.35	Control mode optimization selection	0–0x1111 Ones place: Torque command selection 0: Torque reference 1: Torque current reference Tens place: Reserved 0: Reserved 1: Reserved Hundreds place: indicates whether to enable speed-loop integral separation 0: Disable 1: Enable Thousands place: Reserved 0: Reserved 1: Reserved Range: 0x0000–0x1111	0x0000	0
P03.36	Speed-loop differential gain	0.00–10.00s	0.00s	0
P03.37	Proportional coefficient of high-frequency current loop	In the FVC mode (P00.00=3), when the frequency is lower than the current-loop high-frequency switching threshold (P03.39), the current-loop PI parameters are P03.09 and	1000	0
P03.38	Integral coefficient of high-frequency current loop	P03.10; and when the frequency is higher than the current-loop high-frequency switching threshold, the current-loop PI parameters are	1000	0
P03.39	Current-loop high-frequency switching threshold	P03.37 and P03.38. Setting range of P03.37: 0–65535 Setting range of P03.38: 0–65535 Setting range of P03.39: 0.0–100.0% (of the max. frequency)	100.0%	0
P03.40	Enabling inertia compensation	0: Disable 1: Enable	0	0
P03.41	Upper limit of	The max. inertia compensation torque is limited	10.0%	0

Function code	Name	Description	Default	Modify
	inertia	to prevent inertia compensation torque from		
	compensation	being too large.		
	torque	Setting range: 0.0-150.0% (of the motor rated		
		torque)		
	Inertia	Filter times of inertia compensation torque,		
P03.42	compensation filter	used to smooth inertia compensation torque.	7	0
	times	Setting range: 0–10		
		Due to friction force, it is required to set certain		
P03.43	Inertia identification	identification torque for the inertia identification	10.0%	0
	torque	to be performed properly.	10.078	0
		0.0–100.0% (of the motor rated torque)		
P03 44	Enabling inertia	0: No operation	0	0
1 00.44	identification	1: Enable	0	•
		Automatic update will be performed after motor		
	Current-loop	parameter autotuning. In the FVC mode for		
	proportional	synchronous motors, you can set the value of		
P03.45	coefficient after	this function code to P03.09.	0	•
	autotuning	Setting range: 0–65535		
	autoturning	Note: Set the value to 0 if motor parameter		
		autotuning is not performed.		
		Automatic update will be performed after motor		
	Current-loop	parameter autotuning. In the FVC mode for		
	integral	synchronous motors, you can set the value of		
P03.46	proportional	this function code to P03.10.	0	•
	coefficient after	Setting range: 0–65535		
	autotuning	Note: Set the value to 0 if motor parameter		
		autotuning is not performed.		

### Group P04-V/F control

Function code	Name	Description	Default	Modify
P04.00	V/F curve setting of motor 1	The function code defines the V/F curve of motor 1 to meet the needs of different loads. 0: Straight-line V/F curve, applicable to constant torque loads 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7)	0	Ø

Function code	Name	Description	Default	Modify
		4: Torque-down V/F curve (power of 2.0) Curves 2 – 4 are applicable to the torque loads such as fans and water pumps. You can adjust according to the characteristics of the loads to achieve best performance. 5: Customized V/F (V/F separation); in this mode, V can be separated from F, and F can be adjusted through the frequency setting channel specified by P00.06 or the voltage setting channel specified by P04.27 to change the characteristics of the curve. Note: In the following figure, V <sub>b</sub> is the motor rated voltage and $f_b$ is the motor rated frequency.		
		Output voltage Union of the step-down V/F curve (power of 1.3) Linear type Square type torque step-down V/F curve (power of 1.7) Torque step-down V/F curve (power of 2.0) Square type to the step-down V/F curve (power of 2.0)		
P04.01	Torque boost of motor 1	In order to compensate for low-frequency torque characteristics, you can make some	0.0%	0
P04.02	Torque boost cut-off of motor 1	boost compensation for the output voltage. P04.01 is relative to the max. output voltage $V_b$ . P04.02 defines the percentage of cut-off frequency of manual torque boost to the rated motor frequency $f_b$ . Torque boost can improve the low-frequency torque characteristics of V/F. You need to select torque boost based on the load. For example, larger load requires larger torque boost, however, if the torque boost is too large, the motor will run at over-excitation, which may cause increased output current and motor overheating, thus decreasing the efficiency. When torque boost is set to 0.0%, the VFD uses automatic torque boost. Torque boost cut-off threshold: Below this frequency threshold, torque boost is valid.	20.0%	0

Function code	Name	Description	Default	Modify
		exceeding this threshold will invalidate torque boost.		
		0.1%–10.0% Setting range of P04.02: 0.0%–50.0%		
P04.03	V/F frequency point 1 of motor 1	When P04.00=1 (multi-dot V/F curve), you can set the V/F curve through P04.03–P04.08.	0.00Hz	0
P04.04	V/F voltage point 1 of motor 1	The V/F curve is generally set according to the load characteristics of the motor.	0.0%	0
P04.05	V/F frequency point 2 of motor 1	Note: V1 < V2 < V3, f1 < f2 < f3 Too high voltage for low frequency will cause motor	0.00Hz	0
P04.06	V/F voltage point 2 of motor 1	overheat or damage and cause VFD overcurrent stall or overcurrent protection.	0.0%	0
P04.07	V/F frequency point 3 of motor 1	Output voltage	0.00Hz	0
P04.08	V/F voltage point 3 of motor 1	Setting range of P04.03: 0.00Hz–P04.05 Setting range of P04.04: 0.0%–110.0% (of the rated voltage of motor 1) Setting range of P04.06: 0.0%–110.0% (of the rated voltage of motor 1) Setting range of P04.06: 0.0%–110.0% (of the rated voltage of motor 1) Setting range of P04.06: 0.0%–110.0% (of the rated voltage of motor 1) Setting range of P04.07: P04.05–P02.02 (Rated frequency of motor 1) or P04.05– P02.16 (Rated frequency of motor 1) Setting range of P04.08: 0.0%–110.0% (of the rated voltage of motor 1)	0.0%	0
P04.09	V/F slip	Used to compensate for the motor rotating	100.0%	0

Function code	Name	Description	Default	Modify
code	compensation gain of motor 1	speed change caused by load change in the space voltage vector mode, and thus improve the rigidity of the mechanical characteristics of the motor. You need to calculate the rated slip frequency of the motor as follows: $\Delta f=f_b-n^*p/60$ Of which, $f_b$ is the rated frequency of the motor, corresponding to function code P02.02. n is the rated rotating speed of the motor, corresponding to function code P02.03. p is the number of pole pairs of the motor. 100.0% corresponds to the rated slip frequency $\Delta$ f of the motor.		
P04.10	Low-frequency oscillation control	Setting range: 0.0–200.0% In space voltage vector control mode, the motor, especially the large-power motor, may	10	0
P04.11	factor of motor 1 High-frequency oscillation control factor of motor 1	experience current oscillation at certain frequencies, which may cause unstable motor running, or even VFD overcurrent. Eliminate the results by adjusting the parameters properly.	10	0
P04.12	Oscillation control threshold of motor 1	Setting range of P04.10: 0–100 Setting range of P04.11: 0–100 Setting range of P04.12: 0.00Hz–P00.03 (Max. output frequency)	30.00Hz	0
P04.13	V/F curve setting of motor 2	0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F curve (V/F separation)	0	Ø
P04.14	Torque boost of motor 2	0.0%: (automatic); 0.1%–10.0%	0.0%	0
P04.15	Torque boost cut-off of motor 2	0.0%–50.0% (of the rated frequency of motor 2)	20.0%	0
P04.16	V/F frequency point 1 of motor 2	0.00Hz- P04.18	0.00Hz	0
P04.17	V/F voltage point 1 of motor 2	0.0%–110.0% (of the rated voltage of motor 2)	0.0%	0

Function code	Name	Description	Default	Modify
P04.18	V/F frequency point 2 of motor 2	P04.16– P04.20	0.00Hz	0
P04.19	V/F voltage point 2 of motor 2	0.0%–110.0% (of the rated voltage of motor 2)	0.0%	0
P04.20	V/F voltage point 3 of motor 2	P04.18 –P12.02 (Rated frequency of AM 2) P04.18 –P12.16 (Rated frequency of SM 2)	0.00Hz	0
P04.21	V/F voltage point 3 of motor 2	0.0%–110.0% (of the motor rated voltage)	0.0%	0
P04.22	V/F slip compensation gain of motor 2	0.0–200.0%	0.0%	0
P04.23	Low-frequency oscillation control factor of motor 2	In space voltage vector control mode, the motor, especially the large-power motor, may experience current oscillation at certain	10	0
P04.24	High-frequency oscillation control factor of motor 2	frequencies, which may cause unstable motor running, or even VFD overcurrent. Eliminate the results by adjusting the parameters properly.	10	0
P04.25	Oscillation control threshold of motor 2	Setting range of P04.23: 0–100 Setting range of P04.24: 0–100 Setting range of P04.25: 0.00Hz–P00.03 (Max. output frequency)	30.00Hz	0
P04.26	Energy-saving run	0: Disable 1: Automatic energy-saving run In light-load state, the motor can adjust the output voltage automatically to achieve energy saving.	0	Ø
P04.27	Voltage setting channel selection	0: Keypad (determined by P04.28) 1: Al1 2: Al2 3: Al3 4: HDIA 5: Multi-step speed running (The setting is determined by related parameters in group P10.) 6: PID 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication	0	0

Function code	Name	Description	Default	Modify
		9: Ethernet communication 10: HDIB		
		11: EtherCAT/PROFINE I/ EtherNet IP		
		12: Programmable expansion card		
		13: Reserved		
P04.28	Voltage set through keypad	The function code is the voltage digital setting when "keypad" is selected as the voltage setting channel. Setting range: 0.0%–100.0%	100.0%	0
P04.29	Voltage increase time	Voltage increase time means the time needed for the VFD to accelerate from min. output	5.0s	0
P04.30	Voltage decrease time	voltage to the max. output frequency. Voltage decrease time means the time needed for the VFD to decelerate from the max. output frequency to min. output voltage. Setting range: 0.0–3600.0s	5.0s	0
P04.31	Max. output voltage	The function codes are used to set the upper	100.0%	O
P04.32	Min. output voltage	And lower limits of output voltage. Vmax V set V set Vmin vitieP04.29 V set Vmin vitieP04.30 VitieP04.30 VitieP04.30 VitieP04.30 VitieP04.30 VitieP04.32 VitieP04.33 VitieP04.32 VitieP04.33 VitieP0	0.0%	O
P04.33	Weakening coefficient in constant power zone	1.00–1.30	1.00	0
P04.34	Pull-in current 1 in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the reactive current of the motor when the output frequency is lower than the frequency specified by P04.36. Setting range: -100.0%–100.0% (of the motor rated current)	20.0%	0
P04.35	Pull-in current 2 in SM VF control	When the SM VF control mode is enabled, the function code is used to set the reactive current	10.0%	0

Function code	Name	Description	Default	Modify
		of the motor when the output frequency is higher than the frequency specified by P04.36. Setting range: -100.0%–100.0% (of the motor rated current)		
P04.36	Frequency threshold for pull-in current switching in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the frequency threshold for the switching between pull-in current 1 and pull-in current 2. Setting range: 0.0%–200.0% (of the motor rated frequency).	20.0%	0
P04.37	Reactive current closed-loop proportional coefficient in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the proportional coefficient of reactive current closed-loop control. Setting range: 0–3000	50	0
P04.38	Reactive current closed-loop integral time in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the integral coefficient of reactive current closed-loop control. Setting range: 0–3000	30	0
P04.39	Reactive current closed-loop output limit in SM VF control	When the SM V/F control mode is enabled, the function code is used to set the output limit of the reactive current closed-loop control. A greater value indicates a higher reactive closed-loop compensation voltage and higher output power of the motor. In general, you do not need to modify the function code. Setting range: 0–16000	8000	0
P04.40	Enabling IF mode for AM 1	0: Disable 1: Enable	0	O
P04.41	Current setting in IF mode for AM 1	When IF control is adopted for AM 1, the function code is used to set the output current. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–200.0%	120.0%	0
P04.42	Proportional coefficient in IF mode for AM 1	When IF control is adopted for AM 1, the function code is used to set the proportional coefficient of the output current closed-loop	350	0

Function code	Name	Description	Default	Modify
		control.		
		Setting range: 0–5000 When IF control is adopted for AM 1, the function code is used to set the integral		
P04.43	Integral coefficient in IF mode for AM 1	coefficient of the output current closed-loop control. Setting range: 0–5000	150	0
P04.44	Starting frequency point for switching off IF mode for AM 1	0.00–P04.50	10.00Hz	0
P04.45	Enabling IF mode for AM 2	0: Disable 1: Enable	0	O
P04.46	Current setting in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the output current. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–200.0%	120.0%	0
P04.47	Proportional coefficient in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the proportional coefficient of output current closed-loop control. Setting range: 0–5000	350	0
P04.48	Integral coefficient in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the integral coefficient of output current closed-loop control. Setting range: 0–5000	150	0
P04.49	Starting frequency point for switching off IF mode for AM 2	0.00–P04.51	10.00Hz	0
P04.50	End frequency point for switching off IF mode for AM 1	P04.44–P00.03	25.00Hz	0
P04.51	End frequency point for switching off IF mode for AM 2	P04.49–P00.03	25.00Hz	0

#### Group P05--Input terminal functions

Function code	Name	Description	Default	Modify
		0x00–0x11		
		Ones place: HDIA input type		
		0: HDIA is high-speed pulse input		
P05.00	HDI input type	1: HDIA is digital input	0x00	O
		Tens place: HDIB input type		
		0: HDIB is high-speed pulse input		
		1: HDIB is digital input		
P05.01	Function of S1	0: No function	1	O
P05.02	Function of S2	1: Run forward	4	O
P05.03	Function of S3	2: Run reversely	7	O
P05.04	Function of S4	3: Three-wire running control	0	O
P05.05	Function of HDIA	4: Jog forward	0	0
		5: Jog reversely		0
		6: Coast to stop		
		7: Reset faults		
		8: Pause running		
		9: External fault input		
		10: Increase frequency setting (UP)		
		11: Decrease frequency setting (DOWN)		
		12: Clear the frequency increase/decrease		
		setting		
		13: Switch between A setting and B setting		
		14: Switch between combination setting and A		
		setting		
P05.06	Function of HDIB	15: Switch between combination setting and B	0	O
		setting	-	_
		16: Multi-step speed terminal 1		
		17: Multi-step speed terminal 2		
		18: Multi-step speed terminal 3		
		19: Multi-step speed terminal 4		
		20: Pause multi-step speed running		
		21: ACC/DEC time selection 1		
		22: ACC/DEC time selection 2		
		23: Simple PLC stop reset		
		24: Pause simple PLC		
		25: Pause PID control		
		26: Pause wobbling frequency		

Function code	Name	Description	Default	Modify
		27: Reset wobbling frequency		
		28: Counter reset		
		29: Switch between speed control and torque		
		control		
		30: Disable ACC/DEC		
		31: Trigger the counter		
		32: Reserved		
		33: Clear the frequency increase/decrease		
		setting temporarily		
		34: DC braking		
		35: Switch from motor 1 to motor 2		
		36: Switch the running command channel to		
		keypad		
		37: Switch the running command channel to		
		terminal		
		38: Switch the running command channel to		
		communication		
		39: Pre-exciting command		
		40: Clear electricity consumption		
		41: Keep electricity consumption		
		42: Switch the setting source of braking torque		
		upper limit to keypad		
		43: Position reference point input (only valid for		
		S2, S3 and S4)		
		44: Disable spindle orientation		
		45: Spindle zeroing / Local positioning zeroing		
		46: Spindle zeroing position selection 1		
		47: Spindle zeroing position selection 2		
		48: Spindle scale division selection 1		
		49: Spindle scale division selection 2		
		50: Spindle scale division selection 3		
		51: Terminal for switching between position		
		control and speed control		
		52: Disable pulse input		
		53: Clear position deviation		
		54: Switch position proportional gains		
		55: Enable cyclic digital positioning		
		56: Emergency stop		

Function code	Name	Description	Default	Modify
		57: Motor overtemperature fault input		
		58: Enable rigid tapping		
		59: Switch to V/F control		
		60: Switch to FVC control		
		61: Switch PID polarities		
		62: Reserved		
		63: Enable servo		
		64: Limit on forward running		
		65: Limit on reverse running		
		66: Clear encoder counting		
		67: Increase pulses		
		68: Enable pulse superposition		
		69: Decrease pulses		
		70: Electronic gear selection		
		71: Switch to the master		
		72: Switch to the slave		
		73: Roll diameter reset		
		74: Winding/unwinding switchover		
		75: Tension control pre-driving		
		76: Disable roll diameter calculation		
		77: Clear alarm display		
		78: Manual braking in tension control		
		79: Trigger a forcible material feeding interrupt		
		signal		
		80: Initial roll diameter selection 1		
		81: Initial roll diameter selection 2		
		82: Triggering fire control		
		83: Tension PID switchover		
		84–95: Reserved		
P05.07	Reserved	-	-	-
		The function code is used to set the polarity of		
	Input terminal	input terminals.		
P05.08		When a bit is 0, the input terminal is positive.	0x00	0
	polarity selection	When a bit is 1, the input terminal is negative.		
		0x00–0x3F		
	Digital input filter	Used to specify the sampling filter time of the		
P05.09	time	S1–S4 and HDI terminals. In strong	0.010s	0
		interference cases, increase the value to avoid		

Function code	Name	Description	Default	Modify
		maloperation. 0.000–1.000s		
P05.10	Virtual terminal setting	0x00–0x3F (0: Disable. 1: Enable) Bit 0: S1 virtual terminal Bit 1: S2 virtual terminal Bit 2: S3 virtual terminal Bit 3: S4 virtual terminal Bit4: HDIA virtual terminal	0x00	O
P05.11	Terminal control mode	Bit4: HDIA virtual terminal Bit5: HDIB virtual terminal Used to set the terminal control mode. 0: Two-wire control 1, the enabling consistent with the direction. This mode is widely used. The defined FWD/REV terminal command determines the motor rotation direction. $ \frac{K_{1}}{K_{2}} = \frac{FWD}{COM} $ $ \frac{FWD}{K_{2}} = \frac{FWD}{K_{2}} $ $ \frac{FWD}{K_{2}} = \frac{FWD}{K_{2}$	0	٥
		on indicates reverse running.). When S <sub>In</sub> switches off, the system will stop.		

Function code	Name	Description	Default	Modify
code	Name	Description         Image: State of the state of the stop command stop of the stop command disappears even if the control terminal Stop Stop Stop of the stop command disappears even if the control terminal Stop Stop Stop of the stop command disappears even if the control terminal Stop Stop Stop of the stop command disappears even if the control terminal Stop Stop Stop of the stop command stop of the stop command disappears even if the control terminal Stop Stop Stop of the stop command stop of the stop command disappears even if the control terminal Stop Stop Stop Stop Stop Stop Stop Stop	Default	Modify
P05.12	S1 switch-on delay	control. (See P07.04.) The function codes specify the delay time	0.000s	0
P05 13	S1 switch-off delay	corresponding to the electrical level changes	0.000s	0
DOF 14	ST Switch on delay	when the programmable input terminals switch	0.0005	0
P05.14	S∠ switch-on delay	when the programmable input terminals switch	0.000s	0
P05.15	S2 switch-off delay	on or switch off.	0.000s	0

Function code	Name	Description	Default	Modify
P05.16	S3 switch-on delay		0.000s	0
P05.17	S3 switch-off delay	Si electrical level	0.000s	0
P05.18	S4 switch-on delay	Si valid invalid vali	0.000s	0
P05.19	S4 switch-off delay	Switch-on Switch-off delay delay	0.000s	0
P05.20	HDIA switch-on delay	Setting range: 0.000–50.000s <b>Note:</b> After a virtual terminal is enabled, the	0.000s	0
P05.21	HDIA switch-off delay	state of the terminal can be changed only in communication mode. The communication	0.000s	0
P05.22	HDIB switch-on delay	address is 0x200A.	0.000s	0
P05.23	HDIB switch-off delay		0.000s	0
P05.24	AI1 lower limit		0.00V	0
P05.25	Corresponding setting of AI1 lower limit	The function codes define the relationship	0.0%	0
P05.26	AI1 upper limit	corresponding setting. When the analog input	10.00V	0
P05.27	Corresponding setting of AI1 upper limit	voltage exceeds the range from the upper limit to the lower limit, the upper limit or lower limit is used	100.0%	0
P05.28	Al1 input filter time	When the analog input is current input. 0mA-	0.030s	0
P05.29	AI2 lower limit	20mA current corresponds to 0V–10V voltage.	-10.00V	0
P05.30	Corresponding setting of AI2 lower limit	In different applications, 100.0% of the analog setting corresponds to different nominal values. See the descriptions of each application section	-100.0%	0
P05.31	Al2 middle value 1	for details.	0.00V	0
P05.32	Corresponding setting of Al2 middle value 1	The following figure illustrates the cases of several settings:	0.0%	0
P05.33	Al2 middle value 2	100%	0.00V	0
P05.34	Corresponding setting of AI2 middle value 2	0 Ai1 10V 20mA	0.0%	0
P05.35	AI2 upper limit		10.00V	0
P05.36	Corresponding setting of AI2 upper limit		100.0%	0

Function code	Name	Description	Default	Modify
code	Al2 input filter time	Description	0.030s	o
		Setting range of P05.28: 0.0005–10.0005 Setting range of P05.29: -10.00V–P05.31 Setting range of P05.30: -300.0%–300.0% Setting range of P05.31: P05.29–P05.33 Setting range of P05.32: -300.0%–300.0% Setting range of P05.34: -300.0%–300.0% Setting range of P05.35: P05.33–10.00V Setting range of P05.36: -300.0%–300.0% Setting range of P05.37: 0.0005–10.000s		
P05.38	HDIA high-speed pulse input function selection	0: Input set through frequency 1: Reserved 2: Input set through encoder, used together with HDIB	0	0
P05.39	HDIA frequency lower limit	0.000kHz – P05.41	0.000 kHz	0
P05.40	Corresponding setting of HDIA frequency lower	-300.0%–300.0%	0.0%	0

Function code	Name	Description	Default	Modify
	limit			
P05.41	HDIA frequency upper limit	P05.39–50.000kHz	50.000 kHz	0
P05.42	Corresponding setting of HDIA upper limit frequency	-300.0%–300.0%	100.0%	0
P05.43	HDIA frequency input filter time	0.000s–10.000s	0.030s	0
P05.44	HDIB high-speed pulse input function selection	0: Input set through frequency 1: Reserved 2: Input set through encoder, used together with HDIA	0	O
P05.45	HDIB frequency lower limit	0.000kHz – P05.47	0.000 kHz	0
P05.46	Corresponding setting of HDIB frequency lower limit	-300.0%–300.0%	0.0%	0
P05.47	HDIB frequency upper limit	P05.45–50.000kHz	50.000 kHz	0
P05.48	Corresponding setting of HDIB upper limit frequency	-300.0%–300.0%	100.0%	0
P05.49	HDIB frequency input filter time	0.000s–10.000s	0.030s	0
P05.50	Al1 input signal type	0–1 0: Voltage 1: Current <b>Note:</b> You can set the Al1 input signal type through the corresponding function code.	0	Ø
P05.51- P05.52	Reserved	-	-	-

### Group P06—Output terminal functions

Function code	Name	Description	Default	Modify
P06.00	HDO output type	<ul> <li>0: Open collector high-speed pulse output</li> <li>The max. frequency of pulse is 50.00kHz. For details about the related functions, see P06.27–P06.31.</li> <li>1: Open collector output</li> <li>See P06.02 for related function codes</li> </ul>	0	O
P06.01	Y1 output	0: Disable	0	0
P06.02	HDO output	1: Running	0	0
P06.03	RO1 output	2: Running forward	1	0
P06.03	RO1 output	<ul> <li>2: Running forward</li> <li>3: Running reversely</li> <li>4: Jogging</li> <li>5: VFD in fault</li> <li>6: Frequency level detection FDT1</li> <li>7: Frequency level detection FDT2</li> <li>8: Frequency reached</li> <li>9: Running at zero speed</li> <li>10: Frequency upper limit reached</li> <li>11: Frequency lower limit reached</li> <li>12: Ready for running</li> <li>13: Pre-exciting</li> <li>14: Overload pre-alarm</li> <li>15: Underload pre-alarm</li> <li>16: Simple PLC stage completed</li> <li>17: Simple PLC cycle completed</li> <li>18: Set counting value reached</li> <li>19: Designated counting value reached</li> <li>20: External fault is valid</li> <li>21: Reserved</li> <li>22: Running time reached</li> <li>23: Modbus/ Modbus TCP communication virtual terminal output</li> <li>24: PROFIBUS/CANopen/DeviceNet</li> <li>communication virtual terminal output</li> <li>25: Ethernet communication virtual terminal output</li> <li>26: DC bus voltage established</li> <li>27: Z pulse output</li> </ul>	5	0

Function code	Name	Description	Default	Modify
		28: Superposing pulses		
		29: STO action		
		30: Positioning completed		
		31: Spindle zeroing completed		
		32: Spindle scale division completed		
		33: Speed limit reached in torque control		
		34 <sup>·</sup> EtherCAT/PROFINET/EtherNet IP		
		communication virtual terminal output		
		35: Reserved		
		36: Speed/position control switchover		
		completed		
		37: Any frequency reached		
		38–40: Reserved		
		41: Y1 from the programmable card		
		42: Y2 from the programmable card		
		43: HDO from the programmable card		
		44: RO1 from the programmable card		
		45: RO2 from the programmable card		
		46: RO3 from the programmable card 47: RO4		
		from the programmable card		
		48: EC PT100 detected OH pre-alarm		
		49: EC PT1000 detected OH pre-alarm		
		50: AIAO detected OT pre-alarm		
		51: Stopped or running in zero speed		
		52: Tension control disconnection		
		53: Specified roll diameter reached		
		54: Max. roll diameter reached		
		55: Min. roll diameter reached		
		56: Fire mode enabled		
		57–63: Reserved		
P06.05		Used to set the output terminal polarity.		
		When a bit is 0, the output terminal is positive.		
	Output terminal	When a bit is 1, the output terminal is negative.	0.00	0
	polarity selection	Bit3 Bit2 Bit1 Bit0	0x00	0
		RO2 RO1 HDO Y		
		Setting range: 0x00–0x0F		
P06.06	Y1 switch-on delay	Used to specify the delay time corresponding to	0.000s	0
P06.07	Y1 switch-off delay	the electrical level changes when the	0.000s	0
Function code	Name	Description	Default	Modify
------------------	--------------------------------	--	---------	--------
P06.08	HDO switch-on delay	programmable output terminals switch on or switch off.	0.000s	0
P06.09	HDO switch-off delay	Y electric level	0.000s	0
P06.10	RO1 switch-on delay	Y valid	0.000s	0
P06.11	RO1 switch-off delay	Setting range: 0.000–50.000s Note: P06.08 and P06.09 are valid only when	0.000s	0
P06.12	RO2 switch-on delay	1206.00=1.	0.000s	0
P06.13	RO2 switch-off delay		0.000s	0
P06.14	AO1 output selection	0: Running frequency (0–Max. output frequency)	0	0
P06.15	Reserved	1: Set frequency (0–Max. output frequency)		
P06.16	HDO high-speed pulse output	<ul> <li>2: Ramp reference frequency (U-Max. output frequency)</li> <li>3: Rotational speed (0-Speed corresponding to max. output frequency)</li> <li>4: Output (0-Twice the VFD rated current)</li> <li>5: Output current (0-Twice the motor rated current)</li> <li>6: Output (0-1.5 times the VFD rated voltage)</li> <li>7: Output power (0-Twice the motor rated power)</li> <li>8: Set torque (0-Twice the motor rated torque)</li> <li>9: Output torque (Absolute value, 0-±Twice the motor rated torque)</li> <li>10: Al1 input (0-10V/0-20mA)</li> <li>11: Al2 input (0-10V/0-20mA)</li> <li>13: HDIA input (0.00-50.00kHz)</li> <li>14: Value 1 set through Modbus/Modbus TCP communication (0-1000)</li> <li>15: Value 2 set through Modbus/Modbus TCP communication (0-1000)</li> <li>16: Value 1 set through</li> </ul>	0	0

Function code	Name	Description	Default	Modify
		17: Value 2 set through		
		PROFIBUS/CANopen/DeviceNet		
		communication (0–1000)		
		18: Value 1 set through Ethernet		
		communication (0–1000)		
		19: Value 2 set through Ethernet		
		communication (0–1000)		
		20: HDIB input (0.00–50.00kHz)		
		21: Value 1 set through		
		EtherCAT/PROFINET/EtherNet IP		
		communication (0–1000)		
		22: Torque current (bipolar, 0–Triple the motor		
		rated current)		
		23: Exciting current (bipolar, 0–Triple the motor		
		rated current)		
		24: Set frequency (bipolar, 0–Max. output		
		frequency)		
		25: Ramp reference frequency (bipolar, 0–Max.		
		output frequency)		
		26: Rotational speed (bipolar, 0–Speed		
		corresponding to max. output frequency)		
		27: Value set through		
		EtherCAT/PROFINET/EtherNet IP (0–1000)		
		28: AO1 from the programmable card (0–1000)		
		29: AO2 from the programmable card (0–1000)		
		30: Rotational speed (0–Twice the motor rated		
		synchronous speed)		
		31: Output torque (Actual value, 0–Twice the		
		motor rated torque)		
		32: AIAO detected temperature output		
		33–63: Reserved		
P06 17	AO1 output lower	The function codes define the relationship	0.0%	0
	limit	between the output value and analog output.	0.070	
	AO1 output	When the output value exceeds the allowed		
P06.18	corresponding to	range, the output uses the lower limit or upper	0.00V	0
	lower limit	limit.		
P06.19	AO1 output upper	When the analog output is current output, 1mA	100.0%	0
1 00.13	limit	equals 0.5V.	100.070	$\sim$

Function code	Name	Description	Default	Modify
P06.20	AO1 output corresponding to upper limit	In different cases, the corresponding analog output of 100% of the output value is different.	10.00V	0
P06.21	AO1 output filter time	Setting range of P06.17: -300.0%–P06.19 Setting range of P06.18: 0.00V–10.00V Setting range of P06.19: P06.17–300.0% Setting range of P06.20: 0.00V–10.00V Setting range of P06.21: 0.000s–10.000s	0.000s	0
P06.22	Reserved	-	-	-
P06.23	PTC constant output current setting	0.000–20.000mA	4.000 mA	0
P06.24	PTC resistance alarm threshold	0–60000Ω	750Ω	0
P06.25	PTC resistance alarm recovery threshold	0–60000Ω	150Ω	0
P06.26	Actual PTC resistance	0–60000Ω	0Ω	•
P06.27	HDO output lower limit	-300.0%– <del>P</del> 06.29	0.00%	0
P06.28	HDO output corresponding to lower limit	0.00–50.00kHz	0.00kHz	0
P06.29	HDO output upper limit	P06.27–300.0%	100.0%	0
P06.30	HDO output corresponding to upper limit	0.00–50.00kHz	50.00 kHz	0
P06.31	HDO output filter time	0.000s–10.000s	0.000s	0
P06.32	Reserved	-	-	-
P06.33	Detection value for	0.00Hz-P00.03	1.00Hz	0

Function code	Name	Description	Default	Modify
	frequency being			
	reached			
	Frequency			
P06.34	reaching detection	0.0s–3600.0s	0.5s	0
	time			

# Group P07-Human-machine interface

÷.

Function code	Name	Description	Default	Modify
P07.00	User password	0–65535 When you set the function code to a non-zero number, password protection is enabled. If you set the function code to 00000, the previous user password is cleared and password protection is disabled. After the user password is set and takes effect, you cannot enter the parameter menu if you enter an incorrect password. Please remember your password and save it in a secure place. After you exit the function code editing interface, the password protection function is enabled within 1 minute. If password protection is enabled, "D.D.D.D." is displayed when you press the <b>PRG/ESC</b> key again to enter the function code editing interface. You need to enter the correct user password to enter the interface. <b>Note:</b> Restoring the default values may delete the user password. Exercise caution when using this function.	0	0
P07.01	Reserved	-	-	-
P07.02	Key function selection	Range: 0x00–0x27 Ones place: Function of QUICK/JOG 0: No function 1: Jog 2: Reserved 3: Switch between forward and reverse rotating 4: Clear the UP/DOWN setting	0x01	O

Function code	Name	Description	Default	Modify
		5: Coast to stop 6: Switch command channels in sequence 7: Reserved Tens place: Reserved		
P07.03	Sequence of switching running-command channels by pressing QUICK	When P07.02 ones place=6, set the sequence of switching running-command channels by pressing this key. 0: Keypad→Terminal→Communication 1: Keypad←→Terminal 2: Keypad←→Communication 3: Terminal←→Communication	0	0
P07.04	Stop function validity of STOP/RST	Used to specify the stop function validity of <u>STOP/RST</u> . For fault reset, <u>STOP/RST</u> is valid in any conditions. 0: Valid for keypad control only 1: Valid both for keypad and terminal control 2: Valid both for keypad and communication control 3: Valid for all control modes	0	0
P07.05- P07.07	Reserved	-	-	-
P07.08	Frequency display coefficient	0.01–10.00 Display frequency = Running frequency * P07.08	1.00	0
P07.09	Rotational speed display coefficient	0.1–999.9% Mechanical rotation speed = 120 × (Displayed running frequency) × P07.09/(Number of motor pole pairs)	100.0%	0
P07.10	Linear speed display coefficient	0.1–999.9% Linear speed = Mechanical rotation speed × P07.10	1.0%	0
P07.11	Rectifier bridge temperature	-20.0–120.0°C	0.0°C	•
P07.12	Inverter module temperature	-20.0–120.0°C	0.0°C	•
P07.13	Control board software version	1.00–655.35	Version depended	•
P07.14	Local accumulative	0–65535h	0h	•

Function code	Name	Description	Default	Modify
	running time			
	VFD electricity	Used to display the electricity consumption of		
P07.15	consumption	the VFD.	0kWh	•
	high-order bits	VFD electricity consumption = P07.15*1000 +		
	VFD electricity	P07.16		
P07.16	consumption	Setting range of P07.15: 0–65535 kWh (*1000)	0.0kWh	•
	low-order bits	Setting range of P07.16: 0.0–999.9 kWh		
		0x0000–0xFFF1		
		Bit0–bit3: G type or P type		
		0x0: G type		
P07.17		0x1: P type		
		Bit4-bit11: Chip type and manufacturer		
		0x00: DSP(TI)		
		0x01–0x20: Reserved	Marial	
	VFD model	0x21: MCU(ST)	Model depended	•
		0x22–0xFF: Reserved		
		Bit12–bit15: VFD series		
		0x0: GD350		
		0x1: GD350A		
		0x2: GD350-UL		
		0x3: GD350IP55		
		0x4–0xF: Reserved		
D07.40		0.4.0000.0144	Model	
P07.18	VFD rated power	0.4–3000.0kvv	depended	•
D07.40	VED roted valtage	50 40001/	Model	
P07.19	VFD rated voltage	50-12000	depended	•
B07 20	VED rated ourrept	0.1.6000.04	Model	
F07.20	VFD Tated cutterit	0.1-0000.0A	depended	•
P07 21	Factory bar code 1		Model	•
1 07.21			depended	•
P07 22	Factory bar code 2		Model	•
1 07.22			depended	•
P07 23	Factory bar code 3		Model	•
1 07.20			depended	•
P07 24	Factory bar code 4		Model	•
1 07.24			depended	-
P07 25	Factory bar code 5		Model	
107.23	i actory bar coue o		depended	•

Function code	Name	Description	Default	Modify
<b>D</b> 07.26	Eastony bar and 6		Model	
F07.20	Factory bar code o		depended	•
P07.27	Present fault type	0: No fault	0	•
P07.28	Last fault type	1: Inverter unit U-phase protection (OUt1)	0	•
P07.29	2nd-last fault type	2: Inverter unit V-phase protection (OUt2)	0	•
P07.30	3rd-last fault type	3: Inverter unit W-phase protection (OUt3)	0	•
P07.31	4th-last fault type	4: Overcurrent during ACC (OC1)	0	•
		5: Overcurrent during DEC (OC2)		
		6: Overcurrent during constant speed running		
		(OC3)		
		7: Overvoltage during acceleration (OV1)		
		8: Overvoltage during deceleration (OV2)		
		9: Overvoltage during constant speed running		
		(OV3)		
		10: Bus undervoltage fault (UV)		
		11: Motor overload (OL1)		
		12: VFD overload (OL2)		
		13: Phase loss on input side (SPI)		
		14: Phase loss on output side (SPO)		
		15: Rectifier module overheat (OH1)		
		16: Inverter module overheat (OH2)		
		17: External fault (EF)		
P07.32	5th-last fault type	18: Modbus/Modbus TCP communication fault	0	•
		(CE)		
		19: Current detection fault (ItE)		
		20: Motor autotuning fault (tE)		
		21: EEPROM operation fault (EEP)		
		22: PID feedback offline fault (PIDE)		
		23: Braking unit fault (bCE)		
		24: Running time reached (END)		
		25: Electronic overload (OL3)		
		26: Keypad communication error (PCE)		
		27: Parameter upload error (UPE)		
		28: Parameter download error (DNE)		
		29: PROFIBUS communication fault (E-DP)		
		30: Ethernet communication fault (E-NET)		
		31: CANopen communication fault (E-CAN)		
		32 <sup>.</sup> To-ground short-circuit fault 1 (FTH1)		

Function code	Name	Description	Default	Modify
		33: To-ground short-circuit fault 2 (ETH2)		
		34: Speed deviation fault (dEu)		
		35: Mal-adjustment fault (STo)		
		36: Underload fault (LL)		
		37: Encoder disconnection fault (ENC1o)		
		38: Encoder direction reversal fault (ENC1d)		
		39: Encoder Z-pulse disconnection fault		
		(ENC1Z)		
		40: Safe torque off (STO)		
		41: Channel 1 safety circuit exception (STL1)		
		42: Channel 2 safety circuit exception (STL2)		
		43: Exception to both channels 1 and 2 (STL3)		
		44: Safety code FLASH CRC fault (CrCE)		
		45: Programmable card customized faults 1		
		(P-E1)		
		46: Programmable card customized faults 2		
		(P-E2)		
		47: Programmable card customized faults 3		
		(P-E3)		
		48: Programmable card customized faults 4		
		(P-E4)		
		49: Programmable card customized faults 5		
		(P-E5)		
		50: Programmable card customized faults 6		
		(P-E6)		
		51: Programmable card customized faults 7		
		(P-E7)		
		52: Programmable card customized faults 8		
		(P-E8)		
		53: Programmable card customized faults 9		
		(P-E9)		
		54: Programmable card customized faults 10 (P-F10)		
		55: Duplicate expansion card type (F-Frr)		
		56: Encoder UVW lost (ENCUV)		
		57: PROFINET communication timeout fault		
		(E-PN)		
		58: CAN communication fault (SECAN)		

Function code	Name	Description	Default	Modify
		<ul> <li>59: Motor overtemperature fault (OT)</li> <li>60: Failure to identify the card at slot 1 (F1-Er)</li> <li>61: Failure to identify the card at slot 2 (F2-Er)</li> <li>62: Failure to identify the card at slot 3 (F3-Er)</li> <li>63: Communication timeout of the card at slot 1 (C1-Er)</li> <li>64: Communication timeout of the card at slot 2 (C2-Er)</li> <li>65: Communication timeout of the card at slot 3 (C3-Er)</li> <li>65: Communication timeout of the card at slot 3 (C3-Er)</li> <li>66: EtherCAT communication fault (E-CAT)</li> <li>67: BACnet communication fault (E-BAC)</li> <li>68: DeviceNet communication fault (E-DEV)</li> <li>69: CAN slave fault in master/slave synchronization (S-Err)</li> <li>70: EC PT1000 detected overheating (OtE1)</li> <li>71: EC PT1000 detected overheating (OtE2)</li> <li>72: EtherNet IP communication timeout fault (E-EIP)</li> <li>73: No upgrade bootload (E-PAO)</li> <li>74: Al1 disconnection (E-AI1)</li> <li>75: Al2 disconnection (E-AI2)</li> <li>76: Al3 disconnection (E-AI3)</li> </ul>		
P07.33	Running frequency at present fault	0.00Hz–P00.03	0.00Hz	•
P07.34	Ramp reference frequency at present fault	0.00Hz–P00.03	0.00Hz	•
P07.35	Output current at present fault	0–1200V	0V	•
P07.36	Output current at present fault	0.0–6300.0A	0.0A	•
P07.37	Bus voltage at present fault	0.0–2000.0V	0.0V	•
P07.38	Max. temperature at present fault	-20.0–120.0°C	0.0°C	•
P07.39	Input terminal status at present fault	0x0000–0xFFFF	0x0000	•

Function code	Name	Description	Default	Modify
P07.40	Output terminal status at present fault	0x0000-0xFFFF	0x0000	•
P07.41	Running frequency at last fault	0.00Hz–P00.03	0.00Hz	•
P07.42	Ramp reference frequency at last fault	0.00Hz–P00.03	0.00Hz	•
P07.43	Output voltage at last fault	0–1200V	0V	•
P07.44	Output current at last fault	0.0–6300.0A	0.0A	•
P07.45	Bus voltage at last fault	0.0–2000.0V	0.0V	•
P07.46	Temperature at last fault	-20.0–120.0°C	0.0°C	•
P07.47	Input terminal state at last fault	0x0000–0xFFFF	0x0000	•
P07.48	Output terminal state at last fault	0x0000–0xFFFF	0x0000	•
P07.49	Running frequency at 2nd-last fault	0.00Hz–P00.03	0.00Hz	•
P07.50	Ramp reference frequency at 2nd-last fault	0.00Hz–P00.03	0.00Hz	•
P07.51	Output voltage at 2nd-last fault	0–1200V	0V	•
P07.52	Output current at 2nd-last fault	0.0–6300.0A	0.0A	•
P07.53	Bus voltage at 2nd-last fault	0.0–2000.0V	0.0V	•
P07.54	Max. temperature at 2nd-last fault	-20.0–120.0°C	0.0°C	•
P07.55	Input terminal state at 2nd-last fault	0x0000–0xFFFF	0x0000	•
P07.56	Output terminal state at 2nd-last fault	0x0000–0xFFFF	0x0000	•

### Group P08—Enhanced functions

Function code	Name	Description	Default	Modify
<b>B08 00</b>	ACC time 2		Model	0
F06.00	ACC time 2		depended	0
P08.01	DEC time 2		Model	0
1 00.01	DEO time 2	For details, see P00.11 and P00.12.	depended	0
P08.02	ACC time 3	The VFD has four groups of ACC/DEC time,	Model	0
1 00.02	Add time 3	which can be selected by P05. The factory	depended	0
P08.03	DEC time 3	default ACC/DEC time of the VFD is the first	Model	0
1 00.00	DEC time 5	group.	depended	0
P08.04	ACC time 4	Setting range: 0.0–3600.0s	Model	0
1 00.04			depended	<u> </u>
P08.05	DEC time 4		Model	0
1 00.00	DEC time 4		depended	0
P08.06	Running frequency of jog	The function code is used to define the reference frequency during jogging. Setting range: 0.00Hz–P00.03 (Max. output frequency)	5.00Hz	0
P08.07	ACC time for jogging	ACC time for jogging means the time needed for the VFD to accelerate from 0Hz to the max.	Model depended	0
P08.08	DEC time for jogging	output frequency (P00.03). DEC time for jogging means the time needed for the VFD to decelerate from the max. output frequency (P00.03) to 0Hz. Setting range: 0.0–3600.0s	Model depended	0
P08.09	Jump frequency 1		0.00Hz	0
P08.10	Jump frequency amplitude 1	jump frequency, the VFD runs at the boundary	0.00Hz	0
P08.11	Jump frequency 2	The VED can avoid machanical recompose	0.00Hz	0
P08.12	Jump frequency amplitude 2	points by setting jump frequencies. The VFD	0.00Hz	0
P08.13	Jump frequency 3	If the jump frequency points are set to 0 this	0.00Hz	0
P08.14	Jump frequency amplitude 3	function is invalid.	0.00Hz	0

Function code	Name	Description	Default	Modify
		Setting range: 0.00Hz-P00.03 (Max. output frequency)		
P08.15	Amplitude of wobbling frequency	0.0–100.0% (of the set frequency)	0.0%	0
P08.16	Amplitude of sudden jump frequency	0.0–50.0% (of the amplitude of wobbling frequency)	0.0%	0
P08.17	Rise time of wobbling frequency	0.1–3600.0s	5.0s	0
P08.18	Fall time of wobbling frequency	0.1–3600.0s	5.0s	0
P08.19	Switching frequency of ACC/DEC time	0.00–P00.03 (Max. output frequency) 0.00Hz: No switchover If the running frequency is greater than P08.19, switch to ACC/DEC time 2.	0.00Hz	0
P08.20	Frequency threshold of the start of droop control	0.00–50.00Hz	2.00Hz	0
P08.21	Reference frequency of ACC/DEC time	0: Max. output frequency 1: Set frequency 2: 100Hz <b>Note:</b> Valid only for straight-line ACC/DEC.	0	O
P08.22	Output torque calculation method	0: Based on torque current 1: Based on output power	0	0
P08.23	Number of decimal points of frequency	0: Two 1: One	0	0
P08.24	Number of decimal places of linear speed	0: No decimal point 1: One 2: Two	0	0

Function code	Name	Description	Default	Modify
		3: Three		
P08.25	Set counting value	P08.26-65535	0	0
P08.26	Designated counting value	0–P08.25	0	0
P08.27	Set running time	0–65535min	0min	0
P08.28	Auto fault reset count	Auto fault reset count: When the VFD uses automatic fault reset, it is used to set the	0	0
P08.29	Auto fault reset interval	number of automatic fault reset times. When the number of continuous reset times exceeds the value, the VFD reports a fault and stops. Auto fault reset interval: Time interval from when a fault occurred to when automatic fault reset takes effect. After VFD starts, If no fault occurred within 600s after the VFD starts, the number of automatic fault reset times is cleared. Setting range of P08.28: 0–10 Setting range of P08.29: 0.1–3600.0s	1.0s	0
P08.30	Frequency decrease ratio in droop control	The output frequency of the VFD changes as the load changes. The function code is mainly used to balance the power when several motors drive a same load. Setting range: 0.00–50.00Hz	0.00Hz	0
P08.31	Channel for switching between motor 1 and motor 2	0x00–0x14 Ones place: Switchover channel 0: Terminal 1: Modbus/Modbus TCP communication 2: PROFIBUS/CANopen/DeviceNet communication 3: Ethernet communication 4: EtherCAT/PROFINET/ EtherNet IP communication Tens place: indicates whether to enable switchover during running 0: Disable 1: Enable	0x00	٥
P08.32	FDT1 electrical level detection	When the output frequency exceeds the corresponding frequency of FDT electrical level,	50.00Hz	0

Function code	Name	Description	Default	Modify
	value	the multifunction digital output terminal		
P08.33	FDT1 lagging detection value	continuously outputs the signal of "Frequency level detection FDT". The signal is invalid only	5.0%	0
	FDT2 electrical	when the output frequency decreases to a		
P08.34	level detection	value lower than the frequency corresponding	50.00Hz	0
	value	to (FDT electrical level—FDT lagging detection		
P08.35	FDT2 lagging detection value	value). FDT level FDT level FDT level FDT lag Time t Setting range of P08.32: 0.00Hz–P00.03 (Max. output frequency) Setting range of P08.33: 0.0–100.0% (FDT1 electrical level) Setting range of P08.34: 0.00Hz–P00.03 (Max. output frequency) Setting range of P08.35: 0.0–100.0% (FDT2 electrical level)	5.0%	0
P08.36	Detection value for frequency being reached	When the output frequency is within the detection range, the multifunction digital output terminal outputs the signal of "Frequency reached".	0.00Hz	0

Function code	Name	Description	Default	Modify
P08.37	Enabling dynamic	0: Disable	1	0
	Draking	The function code is used to set the starting bus voltage of dynamic braking. Adjust this value	For 220V: 380.0V	
P08.38	Dynamic braking threshold voltage	properly to achieve effective braking for the load. The default value varies depending on the voltage class. Setting range: 200.0–2000.0V	For 380V: 700.0V	0
P08.39	Fan operating mode	0: Normal mode 1: The fan keeps running after power-on 2: Run mode 2	0	0
P08.40	PWM selection	0x0000–0x1121 Ones place: PWM mode selection 0: PWM mode 1, 3PH modulation and 2PH modulation 1: PWM mode 2, 3PH modulation Tens place: PWM low-speed carrier frequency limit 0: Low-speed carrier frequency limit mode 1 1: Low-speed carrier frequency limit mode 2 2: No limit on low-speed carrier frequency Hundreds place: Deadzone compensation method 0: Compensation method 1 1: Compensation method 2 Thousands place: PWM loading mode selection 0: Interruptive loading 1: Normal loading	0x1101	O
P08.41	Overmodulation selection	0x0000–0x1111 Ones place: 0: Disable 1: Enable Tens place: 0: Mild overmodulation 1: Deepened overmodulation Hundreds place: Carrier frequency limit 0:Yes 1:No	0x1001	Ø

÷.

Function code	Name	Description	Default	Modify
		Thousands place: Output voltage compensation 0: No 1: Yes		
P08.42	Reserved	-	-	-
P08.43	Reserved	-	-	-
P08.44	UP/DOWN terminal control setting	0x000–0x221 Ones place: Frequency setting selection 0: The setting made through UP/DOWN is valid. 1: The setting made through UP/DOWN is invalid. Tens place: Frequency control selection 0: Valid only when P00.06 = 0 or P00.07 = 0 1: Valid for all frequency setting methods 2: Invalid for multi-step speed running when multi-step speed running has the priority Hundreds place: Action selection for stop 0: Setting is valid. 1: Valid during running, cleared after stop 2: Valid during running, cleared after a stop command is received	0x000	0
P08.45	Frequency increment integral rate of the UP terminal	0.01–50.00Hz/s	0.50Hz/s	0
P08.46	Frequency integral rate of the DOWN terminal	0.01–50.00Hz/s	0.50Hz/s	0
P08.47	Action selection at power-off during frequency setting	0x000–0x111 Ones place: Action selection at power-off during frequency adjusting through digitals. 0: Save the setting at power-off. 1: Clear the setting at power-off. Tens place: Action selection at power-off during frequency setting through Modbus/Modbus TCP communication 0: Save the setting at power-off. 1: Clear the setting at power-off.	0x000	0

Function code	Name	Description	Default	Modify
		Hundreds place: Action selection at power-off during frequency setting through DP communication 0: Save the setting at power-off. 1: Clear the setting at power-off.		
P08.48	Initial electricity consumption MSB	Used to set the initial electricity consumption. Initial electricity consumption = P08.48 × 1000	0kWh	0
P08.49	Initial electricity consumption LSB	+ P08.49 Setting range of P08.48: 0–59999 kWh (k) Setting range of P08.49: 0.0–999.9 kWh	0.0kWh	0
P08.50	Magnetic flux braking	The function code is used to enable magnetic flux braking. 0: Disable 100–150: A greater coefficient indicates greater braking strength. The VFD can quickly slow down the motor by increasing the magnetic flux. The energy generated by the motor during braking can be transformed into heat energy by increasing the magnetic flux. The VFD monitors the state of the motor continuously even during the magnetic flux period. Magnetic flux braking can be used for motor stop, as well as for motor rotation speed change. The other advantages include: Braking is performed immediately after the stop command is given. The braking can be started without waiting for magnetic flux weakening. The cooling is better. The current of the stator other than the rotor increases during magnetic flux braking, while the cooling of the stator is more effective than the rotor.	0	0
P08.51	VFD input power factor	This function code is used to adjust the current display value on the AC input side. 0.00–1.00	0.56	0
P08.52	STO lock selection	0: Lock upon STO alarm Lock upon STO alarm indicates resetting is required after state restoration if STO occurs.	0	0

Function code	Name	Description	Default	Modify
		1: No lock on STO alarm No lock on STO alarm indicates STO alarm disappears automatically after state restoration if STO occurs.		
P08.53	Upper limit frequency bias value in torque control	0.00 Hz–P00.03 (Max. output frequency)	0.00Hz	0
P08.54	Upper limit frequency ACC/DEC selection in torque control	0: No limit on acceleration or deceleration 1: ACC/DEC time 1 2: ACC/DEC time 2 3: ACC/DEC time 3 4: ACC/DEC time 4	0	0
P08.55	Enabling auto carrier frequency reduction	0: Disable 1: Enable <b>Note:</b> Automatic carrier frequency reduction indicates that the VFD automatically reduces the carrier frequency when detecting the heat sink temperature exceeds the rated temperature. When the temperature decreases to a specified value, the carrier frequency restores to the setting. This function reduces the chance of VFD overheat alarm.	0	0
P08.56	Min. carrier frequency	0.0–15.0kHz	Model depended	•
P08.57	Temperature point of auto carrier frequency reduction	40.0–85.0°C	70.0°C	0
P08.58	Interval of carrier frequency reduction	0–30min	10min	0
P08.59	Al1 disconnection detection threshold	0–100%	0%	0
P08.60	AI2 disconnection detection threshold	0–100%	0%	0
P08.61	AI3 disconnection detection threshold	0–100%	0%	0
P08.62	Output current filter time	0.000–10.000s	0.000s	0

Function code	Name	Description	Default	Modify
P08.63	Output torque filter times	0–8	8	0

# Group P09—PID control

Function code	Name	Description	Default	Modify
P09.00	PID reference source	When frequency command selection (P00.06, P00. 07) is 7, or voltage setting channel (P04.27) is 6, the running mode of VFD is process PID control. The function code determines the target given channel during the PID process. 0: Set by P09.01 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDIA 5: Multi-step running 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: High-speed pulse HDIB 10: EtherCAT/PROFINET/ EtherNet IP communication 11: Programmable expansion card 12: Reserved The set target of process PID is a relative value, for which 100% equals 100% of the feedback signal of the controlled system. The system always calculates a related value (0–100.0%).	0	0
P09.01	PID digital setting	The function code is mandatory when P09.00=0. The base value of The function code is the feedback of the system. Setting range: -100.0%-100.0%	0.0%	0
P09.02	PID feedback source	The function code is used to select the PID feedback channel.	0	0

Function code	Name	Description	Default	Modify
		0: Al1		
		1: AI2		
		2: AI3		
		3: High-speed pulse HDIA		
		4: Modbus/Modbus TCP communication		
		5: PROFIBUS/CANopen/DeviceNet		
		communication		
		6: Ethernet communication		
		7: High-speed pulse HDIB		
		8: EtherCAT/PROFINET/ EtherNet IP		
		communication		
		9: Programmable expansion card		
		10: Reserved		
		Note: The reference channel and feedback		
		channel cannot be duplicate. Otherwise,		
		effective PID control cannot be achieved.		
	PID output characteristics selection	0: PID output is positive. When the feedback		
		signal is greater than the PID reference value,		
		the output frequency of the VFD will decrease		
		to balance the PID. Example: PID control on		
D00.00		strain during unwinding.	0	0
P09.03		1: PID output is negative. When the feedback	0	0
		signal is greater than the PID reference value,		
		the output frequency of the VFD will increase to		
		balance the PID. Example: PID control on		
		tension during unwinding.		
		The function is applied to the proportional gain		
		P of PID input.		
		P determines the strength of the whole PID		
		adjuster. The larger the value of P, the stronger		
		the adjustment intensity. The value 100		
P00.04	Proportional gain	indicates that when the difference between the	1 90	$\circ$
F09.04	(Kp)	PID feedback value and given value is 100%,	1.00	0
		the range within which the PID regulator can		
		regulate the output frequency command is the		
		max. frequency (ignoring integral function and differential function).		
		Setting range: 0.00–100.00		

Function code	Name	Description	Default	Modify
P09.05	Integral time (Ti)	Used to determine the speed of the integral adjustment on the deviation of PID feedback and reference from the PID regulator. When the deviation of PID feedback and reference is 100%, the integral adjuster works continuously during the time (ignoring proportional and differential function) to achieve the max. output frequency (P00.03) or the max. voltage (P04.31). Shorter integral time indicates stronger adjustment. Setting range: 0.00–10.00s	0.90s	0
P09.06	Differential time (Td)	Used to determine the strength of the change ratio adjustment on the deviation of PID feedback and reference from the PID regulator. If the PID feedback changes 100% during the time, the adjustment of the differential regulator (ignoring proportional and integral function) is the max. output frequency (P00.03) or the max. voltage (P04.31). Longer differential time indicates stronger adjustment. Setting range: 0.00–10.00s	0.00s	0
P09.07	Sampling cycle (T)	Used to indicate the sampling cycle of feedback. The regulator calculates in each sampling cycle. A longer sampling cycle indicates slower response. Setting range: 0.001–10.000s	0.001s	0
P09.08	PID control deviation limit	The output of the PID system is relative to the max. deviation of the closed loop reference. As shown in the following figure, the PID regulator stops regulating in the range of deviation limit. Set the function parameter properly to adjust the accuracy and stability of the PID system.	0.0%	0

Function code	Name	Description	Default	Modify
		Reference		
P09.09	PID output upper limit	Used to set the upper and lower limits of PID regulator output values.	100.0%	0
P09.10	PID output lower limit	100.0% corresponds to the max. output frequency (P00.03) or max. voltage (P04.31). Setting range of P09.09: P09.10—100.0% Setting range of P09.10: -100.0%–P09.09	0.0%	0
P09.11	Feedback offline detection value	Used to set the PID feedback offline detection value. When the feedback value is smaller than	0.0%	0
P09.12	Feedback offline detection time	or equal to the feedback offline detection value, and the duration exceeds the value specified by P09.12, the VFD reports "PID feedback offline fault" and the keypad displays PIDE. Output frequency 11 < T2, so the VFD continues running 12=P09.12 P09.11 P09.11 P09.11 P09.11 P09.11 P09.11 P09.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.12 P00.00 P00.12 P00.00 P00.00 P00.12 P00.00 P00.00 P00.00 P00.12 P00.00 P	1.0s	0
P09.13	PID control selection	0x0000–0x1111 Ones place: 0: Continue integral control after the frequency reaches upper/lower limit 1: Stop integral control after the frequency reaches upper/lower limit Tens place:	0x0001	0

Function code	Name	Description	Default	Modify
		<ul> <li>0: Same as the main reference direction</li> <li>1: Contrary to the main reference direction</li> <li>Hundreds place:</li> <li>0: Limit as per the max. frequency</li> <li>1: Limit as per A frequency</li> <li>Thousands place:</li> <li>0: A+B frequency. ACC/DEC of main reference</li> <li>A frequency source precharging is invalid.</li> <li>1: A+B frequency. ACC/DEC of main reference</li> <li>A frequency source precharging is valid.</li> <li>1: A+B frequency. ACC/DEC of main reference</li> <li>A frequency source precharging is valid. The</li> <li>ACC/DEC is determined by P08.04 (ACC time</li> <li>4).</li> </ul>		
P09.14	Low frequency proportional gain (Kp)	0.00–100.00 Low-frequency switching point: 5.00Hz, high-frequency switching point: 10.00Hz (P09.04 corresponds to high-frequency parameter), and the middle is the linear interpolation between these two points.	1.00	0
P09.15	ACC/DEC time of PID command	0.0–1000.0s	0.0s	0
P09.16	PID output filter time	0.000–10.000s	0.000s	0
P09.17	Reserved	-	-	-
P09.18	Low frequency integral time (Ti)	0.00–10.00s	0.90s	0
P09.19	Low frequency differential time (Td)	0.00–10.00s	0.00s	0
P09.20	Low frequency point for PID parameter switching	0.00–P09.21	5.00Hz	0
P09.21	High frequency point for PID parameter switching	P09.20–P00.04	10.00Hz	0
P09.22- P09.28	Reserved	-	-	-

### Group P10—Simple PLC and multi-step speed control

Function code	Name	Description	Default	Modify
P10.00	Simple PLC mode	0: Stop after running once The VFD stops automatically after running for one cycle, and it can be started only after receiving the running command. 1: Keep running with the final value after running once The VFD keeps the running frequency and direction of the last section after a single cycle. 2: Cyclic running The VFD enters the next cycle after completing one cycle until receiving the stop command.	0	0
P10.01	Simple PLC memory selection	0: Do not memorize at power outage 1: Memorize at power outage. The PLC memories its running stage and running frequency before power-off.	0	0
P10.02	Multi-step speed 0	Frequency setting range for steps from step 0	0.0%	0
P10.03	Running time of step 0	to step 15: -300.0–100.0%. 300.0%	0.0s	0
P10.04	Multi-step speed 1	P00.03.	0.0%	0
P10.05	Running time of step 1	Running time setting range for steps from step 0 to step 15: 0.0–6553.5s(min). The time unit is	0.0s	0
P10.06	Multi-step speed 2	specified by P10.37.	0.0%	0
P10.07	Running time of step 2	When simple PLC operation is selected, it is required to set P10.02–P10.33 to determine the	0.0s	0
P10.08	Multi-step speed 3	running frequency and running time of each	0.0%	0
P10.09	Running time of step 3	step. <b>Note:</b> The symbol of multi-step speed	0.0s	0
P10.10	Multi-step speed 4	determines the running direction of simple PLC,	0.0%	0
P10.11	Running time of step 4	and the negative value means reverse running.	0.0s	0
P10.12	Multi-step speed 5	P10.02	0.0%	0
P10.13	Running time of step 5	Acceleration jime (two sections) P10.06	0.0s	0
P10.14	Multi-step speed 6		0.0%	0
P10.15	Running time of step 6	When selecting multi-step speed running, the	0.0s	0
P10.16	Multi-step speed 7	multi-step speed is within the range of -fmax-	0.0%	0

Function code	Name	Description	Default	Modify
P10.17	Running time of step 7	fmax, and it can be set continuously. The start/stop of multi-step stop running is also	0.0s	0
P10.18	Multi-step speed 8	determined by P00.01.	0.0%	0
P10.19	Running time of step 8	The VFD supports the setting of 16-step speed, which are set by combined codes of multi-step	0.0s	0
P10.20	Multi-step speed 9	terminals 1–4 set by S terminals, corresponding	0.0%	0
P10.21	Running time of step 9	to function code P05.01–P05.06) and correspond to multi-step speed 0 to multi-step	0.0s	0
P10.22	Multi-step speed 10	speed 15.	0.0%	0
P10.23	Running time of step 10		0.0s	0
P10.24	Multi-step speed 11		0.0%	0
P10.25	Running time of step 11	<u>ен</u> , ко ко ко ко ко ко ко	0.0s	0
P10.26	Multi-step speed 12	terminal 1 dN dN dN t	0.0%	0
P10.27	Running time of step 12	terminal 2 terminal 3	0.0s	0
P10.28	Multi-step speed 13	terminal 4	0.0%	0
P10.29	Running time of step 13	When terminal 1, terminal 2, terminal 3 and terminal 4 are OFF, the frequency input mode is	0.0s	0
P10.30	Multi-step speed 14	set by P00.06 or P00.07. When terminal 1,	0.0%	0
P10.31	Running time of step 14	terminal 2, terminal 3 and terminal 4 are not all OFF, the frequency set by multi-step speed will	0.0s	0
P10.32	Multi-step speed 15	prevail, and the priority of multi-step setting is	0.0%	0
P10.33	Running time of step 15	higher than that of the keypad, analog, high-speed pulse, PID, and communication settings. The relation between terminal 1, terminal 2, terminal 3 and terminal 4 are shown in the following (T indicates terminal). T1 OFF ON OFF ON OFF ON OFF ON T2 OFF OFF ON ON OFF ON ON T3 OFF OFF OFF OFF OFF OFF OFF OFF Step 0 1 2 3 4 5 6 7 T1 OFF ON OFF ON OFF ON OFF ON T2 OFF OFF OFF OFF OFF OFF OFF Step 0 1 2 3 4 5 6 7 T1 OFF ON OFF ON OFF ON OFF ON T2 OFF OFF ON OFF ON OFF ON T2 OFF OFF ON ON OFF ON OFF ON T3 OFF OFF OFF OFF OFF OFF ON ON T3 OFF OFF OFF ON OFF ON OFF ON T3 OFF OFF OFF ON ON OFF ON ON	0.0s	0

Function code	Name				De	scri	otion				Default	Modify
		T4	ON	ON	OI	N O	10 N	N ON	I ON	ON		
		Step	8	9	1(	) 1 <sup>.</sup>	1 12	2 13	14	15		
	ACC/DEC time of	The de	scrip	tion i	s as	s follo	ws:					
P10.34	steps 0–7 of simple						ACC/	ACC/	ACC/	ACC/	0x0000	0
	PLC	Functi	0			_	DEC	DEC	DEC	DEC		
		n code	, E	Binary	'	Step	time	time	time	time		
							1	2	3	4		
			Bit	1 Bi	itO	0	00	01	10	11		
			Bit	3 Bi	it2	1	00	01	10	11		
			Bit	5 Bi	it4	2	00	01	10	11		
		P10.34	1 Bit	7 B	it6	3	00	01	10	11		
			Bit	9 Bi	it8	4	00	01	10	11		
			Bit	11 Bit	10	5	00	01	10	11		
			Bit	13 Bit	12	6	00	01	10	11		
			BIt		14 i+0	/	00	01	10	11		
			Bit	ן א B	it2	0 Q	00	01	10	11		
			Bit	5 B	it4	10	00	01	10	11		
	ACC/DEC time of		Bit	7 B	it6	11	00	01	10	11		
P10.35	steps 8–15 of	P10.35	Bit	9 Bi	it8	12	00	01	10	11	0x0000	0
	simple PLC		Bit	11 Bit	t10	13	00	01	10	11		
			Bit	13 Bit	t <b>12</b>	14	00	01	10	11		
			Bit	15 Bit	t14	15	00	01	10	11		
		Select	corre	spor	ndin	g ac	celera	ation/o	decele	ration		
		time, a	nd th	en co	nve	ert 16	i-bit b	inary	numb	er into	)	
		hexade	cima	ıl nu	ımb	er, f	inally	, and	the	n set		
		corresp	ondi	ng fu	ncti	ion co	odes.					
		ACC/D	EC ti	me 1	is :	set b	y <mark>P00</mark>	.11 ar	nd <mark>P0</mark>	0.12;		
		ACC/D	EC ti	me 2	is :	set b	v P08	.00 a	nd P0	8.01:		
		ACC/D	EC ti	me 3	is :	set b	v P08	.02 a	nd P0	8.03:		
		ACC/D	EC ti	me 4	is e	set b	v P08	04 a	nd P0	8 05		
		Setting	rano		000	טייסט. 10–0י		=		0.00.		
			ort fr	0. 07	1000	1	~					
		U: Resi	an ir	oms	tep							
		If the V	FDS	tops	dur	ing ru	inninę	g (cau	ised b	y stop		
		comma	and, f	ault d	or p	ower	dow	n), it v	vill rui	n from		
P10.36	PLC restart mode	the firs	t step	o afte	r re	start.					0	O
		1: Res	ume f	rom	the	paus	ed st	ер			-	
		If the V	FDs	tops	dur	ing ru	unning	g (cau	sed b	y stop		
		comma	and c	or fau	ult),	it w	ill re	cord	the ru	Inning		
		time o	f cu	rrent	st	ep, a	and	enters	s this	step		

Function code	Name	Description	Default	Modify
		automatically after restart, then continue running at the frequency defined by this step in the remaining time.		
P10.37	Multi-step time unit	0: second The running time of each step is counted in seconds. 1: minute The running time of each step is counted in minutes.	0	Ø

#### Group P11—Protection parameters

Function code	Name	Description	Default	Modify
P11.00	Protection against phase loss	0x000–0x111 Ones place: 0: Disable software input phase loss protection. 1: Enable software input phase loss protection. Tens place: 0: Disable protection against output phase loss. 1: Enable protection against output phase loss. Hundreds place: 0: Disable hardware input phase loss protection. 1: Enable hardware input phase loss protection.	0x110	0
P11.01	Frequency drop at transient power-off	0: Disable 1: Enable	0	0
P11.02	Enabling dynamic braking in standby mode	0: Enable 1: Disable	0	O
P11.03	Overvoltage stall protection	0: Disable 1: Enable DC bus voltage V Overvoltage stall threshold Output frequency Time t	1	0

Function code	Name	Description	Default	Modify
D11 04	Overvoltage stall	120–150% (standard bus voltage) (380V)	136%	0
P11.04	protection voltage	120–150% (standard bus voltage) (220V)	120%	0
P11.05	Current limit selection	During accelerated running, as the load is too large, the actual acceleration rate of motor is lower than that of output frequency, if no measures are taken, the VFD may trip due to overcurrent during acceleration. 0x00–0x11 Ones place: Current limit action 0: Invalid 1: Always valid Tens place: Hardware current limit overload alarm 0: Valid 1: Invalid	0x01	٥
P11.06	Automatic current limit threshold	Current-limit protection function detects output current during running, and compares it with the current-limit level defined by P11.06, if it exceeds the current-limit level, the VFD will run	G type: 160.0% P type: 120.0%	O
P11.07	Frequency decrease ratio in current limiting	at stable frequency during accelerated running, or run in decreased frequency during constant-speed running; if it exceeds the current-limit level continuously, the VFD output frequency will drop continuously until reaching lower limit frequency. When the output current is detected to be lower than the current-limit level again, it will continue accelerated running.	10.00 Hz/s	Ø

Function code	Name	Description	Default	Modify
P11.08	Pre-alarm selection for VFD/motor OL/UL	<ul> <li>0x0000–0x1134</li> <li>Ones place:</li> <li>0: Motor OL/UL pre-alarm, relative to the motor rated current.</li> <li>1: VFD OL/UL pre-alarm, relative to rated VFD output current.</li> <li>2: Motor output torque OL/UL pre-alarm, relative to motor rated torque.</li> <li>3: Motor OL/UL pre-alarm. The overload is relative to the motor rated current; while the underload is relative to the motor rated power.</li> <li>4: VFD OL/UL pre-alarm. The overload is relative to the VFD rated current; while the underload is relative to the VFD rated power.</li> <li>4: VFD OL/UL pre-alarm. The overload is relative to the VFD rated current; while the underload is relative to the VFD rated power.</li> <li>Tens place:</li> <li>0: The VFD continues to work for an OL/UL alarm</li> <li>1: The VFD continues to work for a UL alarm but stops running for an OL fault.</li> <li>2: The VFD stops running for an OL/UL alarm. Hundreds place:</li> <li>0: Detect all the time.</li> <li>1: Detect during constant speed running</li> <li>Thousands place: VFD overload current reference selection</li> <li>0: Related to current calibration coefficient</li> <li>1: Irrelated to current calibration coefficient</li> </ul>	0x0000	0
P11.09	Overload pre-alarm detection threshold	If the VFD or motor output current is larger than the overload pre-alarm detection level (P11.09), and the duration exceeds the overload	G type: 150% P type: 120%	0
P11.10	Overload pre-alarm detection time	pre-alarm detection time (P11.10), overload pre-alarm signal will be outputted.	1.0s	0

Function code	Name	Description	Default	Modify
		Overload pre-alarm threahold Y1, R01, R02		
		P11.09 setting range: P11.11–200% (relative value determined by the ones place of P11.08) Setting range of P11.10: 0.1–3600.0s		
P11.11	Underload pre-alarm detection threshold	Underload pre-alarm signal will be outputted if the output current of the VFD or motor is lower than underload pre-alarm detection level	50%	0
P11.12	Underload pre-alarm detection time	(P11.11), and the duration exceeds underload pre-alarm detection time (P11.12). P11.11 setting range: 0–P11.09 (relative value determined by the ones place of P11.08) Setting range of P11.12: 0.1–3600.0s	1.0s	0
P11.13	Fault output terminal action upon fault occurring	Used to set the action of fault output terminals at undervoltage and fault reset. 0x00–0x11 Ones place: 0: Act at undervoltage 1: Do not act at undervoltage Tens place: 0: Act during automatic reset 1: Do not act during the automatic reset period	0x00	0
P11.14	Speed deviation detection value	0.0–50.0% Used to set the speed deviation detection value.	10.0%	0
P11.15	Speed deviation detection time	Setting range: 0.0–10.0s (0.0 indicates no speed deviation protection) Used to set the speed deviation detection time. <b>Note:</b> Speed deviation protection is invalid when P11.15=0.0.	2.0s	0

Function code	Name	Description	Default	Modify
		Actual detection value Set detection value It1 t2 <u>Fault outputdEu</u> t1 <t2, continues="" running<br="" so="" the="" vfd="">t2=P11.15</t2,>		
P11.16	Automatic frequency-reduction during voltage drop	0–1 0: Disable 1: Enable	0	0
P11.17	Proportional coefficient of voltage regulator during undervoltage stall	This parameter is used to set the proportional coefficient of the bus voltage regulator during undervoltage stall. Setting range: 0–1000	100	0
P11.18	Integral coefficient of voltage regulator during undervoltage stall	This parameter is used to set the integral coefficient of the bus voltage regulator during undervoltage stall. Setting range: 0–1000	40	0
P11.19	Proportional coefficient of current regulator during undervoltage stall	This parameter is used to set the proportional coefficient of the active current regulator during undervoltage stall. Setting range: 0–1000	25	0
P11.20	Integral coefficient of current regulator during undervoltage stall	This parameter is used to set the integral coefficient of the active current regulator during undervoltage stall. Setting range: 0–2000	150	0
P11.21	Proportional coefficient of voltage regulator during overvoltage stall	This parameter is used to set the proportional coefficient of the bus voltage regulator during overvoltage stall. Setting range: 0–1000	60	0
P11.22	Integral coefficient of voltage regulator during overvoltage stall	This parameter is used to set the integral coefficient of the bus voltage regulator during overvoltage stall. Setting range: 0–1000	10	0

Function code	Name	Description	Default	Modify
P11.23	Proportional coefficient of current regulator during overvoltage stall	This parameter is used to set the proportional coefficient of the active current regulator during overvoltage stall. Setting range: 0–1000	60	0
P11.24	Integral coefficient of current regulator during overvoltage stall	This parameter is used to set the integral coefficient of the active current regulator during overvoltage stall. Setting range: 0–2000	250	0
P11.25	Enabling VFD overload integral	0: Disable 1: Enable When this parameter is set to 0, the overload timing value is reset to zero after the VFD is stopped. In this case, the determination of VFD overload takes more time, and therefore the effective protection over the VFD is weakened. When this parameter is set to 1, the overload timing value is not reset, and the overload timing value is accumulative. In this case, the determination of VFD overload takes less time, and therefore the protection over the VFD can be performed more quickly.	0	٥
P11.26	Reserved	-	-	-
P11.27	VF oscillation control method	0x00–0x11 Ones place: 0: Method 1 1: Method 2 Tens place: 0: Reserved 1: Reserved	0x00	Ø
P11.28	SPO switch-on detection delay time	0.0–60.0s <b>Note:</b> The SPO detection is started only after the VFD runs for the delay time P11.28 to avoid false alarms caused by the unstable frequency.	5.0	0
P11.29	SPO unbalance factor	0–10	6	0
P11.30	Reserved	-	-	-

Function code	Name	Description	Default	Modify
P11.31	Fault severity group 1	0x0000–0x3333	0x0000	0
P11.32	Fault severity group 2	place/ones place:	0x0000	0
P11.33	Fault severity group 3	1: Report a fault after deceleration to stop     2: Pre-alarm, with the action executed	0x0000	0
P11.34	Fault severity group 4	according to P11.51 3: Screen out fault	0x0000	0
P11.35	Fault severity group 5	Note: Different fault actions are taken for different fault severities.	0x0000	0
P11.36	Fault severity group 6	The first 10 faults are not grouped by severity, but each four of the subsequent faults are	0x0000	0
P11.37	Fault severity group 7	grouped by severity in ascending order from right to left in hexadecimal format, that is, from	0x0000	0
P11.38	Fault severity group 8	the ones place to the thousands place (for example, the ones place of fault severity group	0x0000	0
P11.39	Fault severity group 9	1 corresponds to fault 11). Group 1: Faults 11–14 (OL1, OL2, SPI, SPO)	0x0000	0
P11.40	Fault severity group 10	Group 2: Faults 15–18 (OH1, OH2, EF, CE) Group 3: Faults 19–22 (ItE, tE, EEP, PIDE)	0x0000	0
P11.41	Fault severity group 11	Group 4: Faults 23–26 (DCE, END, OL3, PCE) Group 5: Faults 27–30 (UPE, DNE, E-DP, E-NET)	0x0000	0
P11.42	Fault severity group 12	Group 6: Faults 31–34 (E-CAN, ETH1, ETH2, dEu)	0x0000	0
P11.43	Fault severity group 13	Group 7: Faults 35–38 (STo, LL, ENC1o, ENC1d)	0x0000	0
P11.44	Fault severity group 14	Group 8: Faults 39–42 (ENC1Z, STO, STL1, STL2)	0x0000	0
P11.45	Fault severity group 15	Group 9: Faults 43–46 (STL3, CrCE, P-E1, P-E2)	0x0000	0
P11.46	Fault severity group 16	Group 10: Faults 47–50 (P-E3, P-E4, P-E5, P-E6)	0x0000	0
P11.47	Fault severity group 17	Group 11: Faults 51–54 (P-E7, P-E8, P-E9, P-E10)	0x0000	0
P11.48	Fault severity group 18	Group 12: Faults 55–58 (E-Err, ENCU, E-PN, SECAN)	0x0000	0

Function code	Name	Description	Default	Modify
P11.49	Fault severity group 19	Group 13: Faults 59–62 (OT, F1-Er, F2-Er, F3-Er)	0x0000	0
P11.50	Fault severity group 20	Group 14: Faults 63–66 (C1-Er, C2-Er, C3-Er, E-CAT) Group 15: Faults 67–70 (E-BAC, E-DEV, S-Err, OtE1) Group 16: Faults 71–75 (OtE2, E-EIP, E-PAO, E-Al1) Group 17: Faults 75–78 (E-Al2, E-Al3, Reserved, Reserved) Group 18: Faults 79–82 (Reserved, Reserved, Reserved, Reserved) Group 19: Faults 83–86 (Reserved, Reserved, Reserved, Reserved) Group 20: Faults 87–90 (Reserved, Reserved,	0x0000	0
P11.51	Action for fault pre-alarm	Reserved, Reserved) 0–4 0: Run at the set frequency 1: Run at the output frequency at the time of failure 2: Run at the upper limit frequency 3: Run at the lower limit frequency 4: Run at the frequency reserved for exception	0	0
P11.52	Frequency reserved for exception	0.00–630.00Hz	0.00 Hz	0
P11.53	Fire mode function	0–2 0: Disable 1: Fire mode 1 2: Fire mode 2 <b>Note:</b> When P11.53=0, the fire mode is invalid. In this case, the VFD runs in normal mode and stops when encountering a fault. When the fire mode function is valid, the VFD runs at the speed specified by P11.54. In fire mode 1, the VFD keeps running except when the VFD has been damaged. In fire mode 2, the VFD keeps running. but	0	0

Function code	Name	Description	Default	Modify
		stops upon the following faults: OUT1, OUT2, OUT3, OC1, OC2, OC3, OV1, OV2, OV3, and SPO.		
		Terminal control must be used for a fire mode. <b>Note:</b> After the fire mode is active for 5 minutes, P11.55 is reset, and the warranty is no longer valid. Please use with caution.		
P11.54	Running frequency in fire mode	0.00Hz–P00.03	50.00Hz	0
P11.55	Fire mode flag	0–1 <b>Note:</b> If the fire mode has lasted 5 minutes, this flag is reset to 1, and no warranty of repair is granted.	0	•
P11.56– P11.69	Reserved	-	-	-

# Group P12--Parameters of motor 2

Function code	Name	Description	Default	Modify
P12.00	Type of motor 2	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0	O
P12.01	Rated power of AM 2	0.1–3000.0kW	Model depended	O
P12.02	Rated frequency of AM 2	0.01Hz–P00.03 (Max. output frequency)	50.00Hz	O
P12.03	Rated speed of AM 2	1–60000rpm	Model depended	O
P12.04	Rated voltage of AM 2	0–1200V	Model depended	O
P12.05	Rated current of AM 2	0.8–6000.0A	Model depended	O
P12.06	Stator resistance of AM 2	0.001–65.535Ω	Model depended	0
P12.07	Rotor resistance of AM 2	0.001–65.535Ω	Model depended	0
P12.08	Leakage inductance of AM 2	0.1–6553.5mH	Model depended	0

Function code	Name	Description	Default	Modify
P12.09	Mutual inductance of AM 2	0.1–6553.5mH	Model depended	0
P12.10	No-load current of AM 2	0.1–6553.5A	Model depended	0
P12.11	Magnetic saturation coefficient 2 of iron core of AM 1	0.0–100.0%	80%	0
P12.12	Magnetic saturation coefficient 2 of iron core of AM 2	0.0–100.0%	68%	0
P12.13	Magnetic saturation coefficient 2 of iron core of AM 3	0.0–100.0%	57%	0
P12.14	Magnetic saturation coefficient 2 of iron core of AM 4	0.0–100.0%	40%	0
P12.15	Rated power of SM 2	0.1–3000.0kW	Model depended	O
P12.16	Rated frequency of SM 2	0.01Hz–P00.03 (Max. output frequency)	50.00Hz	O
P12.17	Number of pole pairs of SM 2	1–128	2	O
P12.18	Rated voltage of SM 2	0–1200V	Model depended	O
P12.19	Rated current of SM 2	0.8–6000.0A	Model depended	O
P12.20	Stator resistance of SM 2	0.001–65.535Ω	Model depended	0
P12.21	Direct-axis inductance of SM 2	0.01–655.35mH	Model depended	0
P12.22	Quadrature-axis inductance of SM 2	0.01–655.35mH	Model depended	0
P12.23	Counter-emf constant of SM 2	0–10000V	300	0
P12.24	Initial pole position of SM 2	0x0000–0xFFFF	0x0000	/●
P12.25	Identification current of SM 2	0–50% (of the motor rated current)	10%	/●
Function code	Name	Description	Default	Modify
-------------------	---	---	----------------	--------
P12.26	Overload protection selection of motor 2	0: No protection 1: Common motor (with low-speed compensation) 2: Frequency-variable motor (without low-speed compensation)	2	O
P12.27	Overload protection coefficient of motor 2	Motor overload multiples M=lout/(In*K) In is rated motor current, lout is VFD output current, K is motor overload protection coefficient. A smaller value of "K" indicates a bigger value of "M". When M=116%, protection is performed after motor overload lasts for 1 hour; when M=150%, protection is performed after motor overload lasts for 12 minutes; when M=200%, protection is performed after motor overload lasts for 1 minute; and when M≥400%, protection is performed immediately.	100.0%	0
P12.28	Power display calibration coefficient of motor 2	0.00–3.00	1.00	0
P12.29	Parameter display of motor 2	<ol> <li>Display by motor type. In this mode, only parameters related to the present motor type are displayed.</li> <li>Display all. In this mode, all the motor parameters are displayed.</li> </ol>	0	0
P12.30	System inertia of motor 2	0–30.000kg·m <sup>2</sup>	0.000 kg∙m²	0
P12.31– P12.32	Reserved	-	-	-

#### Group P13—SM control

Function code	Name	Description	Default	Modify
P13.00	SM injected-current decrease ratio	0.0%-100.0% (of the motor rated current)	80.0%	0
P13.01	Initial pole detection method	0: No detection 1: High-frequency superposition 2: Pulse superposition	0	O
P13.02	Pull-in current 1	Pull-in current is the pole position orientation current; pull-in current 1 is valid within the lower limit of pull-in current switch-over frequency threshold. If you need to increase the start torque, increase the value of this function parameter properly. Setting range: 0.0%–100.0% (of the motor rated current)	20.0%	0
P13.03	Pull-in current 2	Pull-in current is the pole position orientation current; pull-in current 2 is valid within the upper limit of pull-in current switch-over frequency threshold. You do not need to change the value in most cases. Setting range: 0.0%–100.0% (of the motor rated current)	10.0%	0
P13.04	Pull-in current switching frequency	0.0–200.0% Note: Relative to the motor rated frequency.	20.0%	0
P13.05	High frequency superimposed frequency	200–1000Hz	500	O
P13.06	High-frequency superposition voltage	0.0–300.0% (of the motor rated voltage)	100.0%	O
P13.07	Control parameter 0	0.0–400.0	0.0	0
P13.08	Control parameter 1	0x0000–0xFFFF	0x0000	0
P13.09	Frequency threshold of phase-lock loop switch-in	Used to set the frequency threshold for enabling the counter-electromotive force phase-locked loop in SVC 0. When the running frequency is lower than the value of the function code, the phase-locked loop is disabled; and	2.00	0

Function code	Name	Description	Default	Modify
		when the running frequency is higher than that, the phase-locked loop is enabled. Setting range: 0.00–655.35		
P13.10	Initial compensation angle of SM	0.0–359.9	0.0	0
P13.11	Maladjustment detection time	Used to adjust the responsiveness of anti-maladjustment function. If the load inertia is large, increase the value of this parameter properly, however, the responsiveness may slow down accordingly. Setting range: 0.0–10.0s	0.5s	0
P13.12	SM high-frequency compensation coefficient	Valid when the motor speed exceeds the rated speed. If oscillation occurred to the motor, adjust this parameter properly. Setting range: 0.0–100.0%	0.0%	0
P13.13	High-frequency pull-in current	0–300.0% (of the rated VFD output current)	20.0%	O

# Group P14—Serial communication

Function code	Name	Description	Default	Modify
P14.00	Local communication address	Setting range: 1–247 When the master writes the slave communication address to 0 indicating a broadcast address in a frame, all the salves on the Modbus/Modbus TCP bus receive the frame but do not respond to it. The communication addresses on the communication network are unique, which is the basis of the point-to-point communication. <b>Note:</b> The communication address of a slave cannot be set to 0.	1	0
P14.01	Communication baud rate setting	Used to set the rate of data transmission between the upper computer and the VFD. 0: 1200bps 1: 2400bps 2: 4800bps	4	0

Function code	Name	Description	Default	Modify
		3: 9600bps		
		4: 19200bps		
		5: 38400bps		
		6: 57600bps		
		7: 115200bps		
		Note: The baud rate set on the VFD must be		
		consistent with that on the upper computer.		
		Otherwise, the communication fails. A greater		
		baud rate indicates faster communication.		
		The data format set on the VFD must be		
		consistent with that on the upper computer.		
		Otherwise, the communication fails.		
		0: No check (N, 8, 1) for RTU		
P14.02	Data bit check	1: Even check (E, 8, 1) for RTU	1	0
		2: Odd check (O, 8, 1) for RTU		
		3: No check (N, 8, 2) for RTU		
		4: Even check (E, 8, 2) for RTU		
		5: Odd check (O, 8, 2) for RTU		
		0–200ms		
		The function code indicates the communication		
		response delay, that is, the interval from when		
		the VFD completes receiving data to when it		
		sends response data to the upper computer. If		
	Communication	the response delay is shorter than the rectifier		
P14.03	communication response delay	processing time, the rectifier sends response	5ms	0
		data to the host controller after processing data.		
		If the delay is longer than the rectifier		
		processing time, the rectifier does not send		
		response data to the host controller until the		
		delay is reached although data has been		
		processed.		
		0.0 (invalid)–60.0s		
		When the function code is set to 0.0, the		
	485 communication	communication timeout time is invalid.		
P14.04		When the function code is set to a non-zero	0.0s	0
	aneout period	value, the system reports the "Modbus/Modbus		
		TCP communication fault" (CE) if the		
		communication interval exceeds the value.		

Function code	Name	Description	Default	Modify
		In general, the function code is set to 0.0. When continuous communication is required, you can set the function code to monitor communication status.		
P14.05	Transmission error processing	<ul> <li>0: Report an alarm and coast to stop</li> <li>1: Keep running without reporting an alarm</li> <li>2: Stop according to the stop mode without generating alarms</li> <li>(only in the communication-based control mode)</li> <li>3: Stop according to the stop mode without generating alarms</li> <li>(in all control modes)</li> </ul>	0	0
P14.06	Modbus communication processing action selection	0x000–0x111 Ones place: 0: Respond to write operations 1: Not respond to write operations Tens place: 0: Communication password protection is invalid. 1: Communication password protection is valid. Hundreds place: (valid for RS485 communication only) 0: User-defined addresses specified by P14.07 and P14.08 are invalid. 1: User-defined addresses specified by P14.07 and P14.08 are valid.	0x000	0
P14.07	User-defined running command address	0x0000–0xFFFF	0x2000	0
P14.08	User-defined frequency setting address	0x0000–0xFFFF	0x2001	0
P14.09	Modbus TCP communication timeout period	0.0–60.0s	5.0s	0
P14.10	Enabling 485 upgrade program	0–1 0: Disable	0	O

Function code	Name	Description	Default	Modify
		1: Enable		
P14.11	Bootload software version	0.00–655.35	0.00	•
P14.12	Display of no upgrade bootload fault	0–1 0: Display 1: Do not display	0	0
P14.13– P14.47	Reserved	-	-	-
P14.48	Channel selection for mapping between PZDs and function codes	0x00–0x12 Ones place: Channel for mapping function codes to PZDs 0: Reserved 1: Group P15 2: Group P16 Tens place: Save function at power off 0: Disable 1: Enable	0x12	0
P14.49	Mapped function code of received PZD2	0x0000–0xFFFF	0x0000	0
P14.50	Mapped function code of received PZD3	0x0000–0xFFFF	0x0000	0
P14.51	Mapped function code of received PZD4	0x0000–0xFFFF	0x0000	0
P14.52	Mapped function code of received PZD5	0x0000–0xFFFF	0x0000	0
P14.53	Mapped function code of received PZD6	0x0000–0xFFFF	0x0000	0
P14.54	Mapped function code of received PZD7	0x0000–0xFFFF	0x0000	0
P14.55	Mapped function code of received PZD8	0x0000-0xFFFF	0x0000	0

Function code	Name	Description	Default	Modify
P14.56	Mapped function code of received PZD9	0x0000–0xFFFF	0x0000	0
P14.57	Mapped function code of received PZD10	0x0000–0xFFFF	0x0000	0
P14.58	Mapped function code of received PZD11	0x0000–0xFFFF	0x0000	0
P14.59	Mapped function code of received PZD12	0x0000–0xFFFF	0x0000	0
P14.60	PZD2 sends mapping function code	0x0000–0xFFFF	0x0000	0
P14.61	Mapped function code of sent PZD3	0x0000–0xFFFF	0x0000	0
P14.62	Mapped function code of sent PZD4	0x0000–0xFFFF	0x0000	0
P14.63	Mapped function code of sent PZD5	0x0000–0xFFFF	0x0000	0
P14.64	Mapped function code of sent PZD6	0x0000–0xFFFF	0x0000	0
P14.65	Mapped function code of sent PZD7	0x0000–0xFFFF	0x0000	0
P14.66	Mapped function code of sent PZD8	0x0000–0xFFFF	0x0000	0
P14.67	Mapped function code of sent PZD9	0x0000–0xFFFF	0x0000	0
P14.68	Mapped function code of sent PZD10	0x0000–0xFFFF	0x0000	0
P14.69	Mapped function code of sent PZD11	0x0000–0xFFFF	0x0000	0
P14.70	Mapped function code of sent PZD12	0x0000–0xFFFF	0x0000	0

-

Function code	Name	Description	Default	Modify
P15.00	Reserved	-	-	-
P15.01	Module address	0–127	2	O
P15.02	Received PZD2	0–31	0	0
P15.03	Received PZD3	0: Disable	0	0
P15.04	Received PZD4	1: Set frequency (0–Fmax, unit: 0.01Hz)	0	0
P15.05	Received PZD5	2: PID reference (-1000–1000, in which 1000	0	0
P15.06	Received PZD6	corresponds to 100.0%)	0	0
P15.07	Received PZD7	3: PID feedback (-1000–1000, in which 1000	0	0
P15.08	Received PZD8	corresponds to 100.0%)	0	0
P15.09	Received PZD9	4: Torque setting (-3000-+3000, in which 1000	0	0
P15.10	Received PZD10	corresponds to 100.0% of the motor rated	0	0
P15.11	Received PZD11	current)	0	0
P15.12	Received PZD12	<ul> <li>Setting of the upper limit of forward furning frequency (0–Fmax, unit: 0.01 Hz)</li> <li>Setting of the upper limit of reverse running frequency (0–Fmax, unit: 0.01 Hz)</li> <li>Upper limit of the electromotive torque (0–3000, in which 1000 corresponds to 100.0% of the motor rated current)</li> <li>Upper limit of braking torque (0–3000, in which 1000 corresponds to 100% of the motor rated current)</li> <li>Upper limit of braking torque (0–3000, in which 1000 corresponds to 100% of the motor rated current)</li> <li>Virtual input terminal command (range: 0x000–0x3FF, corresponding to S8/S7/S6/S5/HDIB/ HDIA/S4/S3/S2/S1)</li> <li>Virtual output terminal command (range: 0x00–0x0F, corresponding to RO2/RO1/HDO/Y1)</li> <li>Voltage setting (special for V/F separation) (0–1000, in which 1000 corresponds to 100% of the motor rated voltage)</li> <li>AO1 output setting 1 (-1000–+1000, in which 1000 corresponds to 100.0%)</li> <li>AO2 output setting 2 (-1000–+1000, in which 1000 corresponds to 100.0%)</li> <li>LSB of position reference (signed)</li> </ul>	0	0

#### Group P15—Communication expansion card 1 functions

Function code	Name	Description	Default	Modify
		16: MSB of position feedback (signed)		
		17: LSB of position feedback (unsigned)		
		18: Position feedback setting flag (position		
		feedback can be set only after this flag is set to		
		1 and then to 0)		
		19: Function parameter mapping (PZD2-		
		PZD12 correspond to P14.49–P14.59)		
		20–31: Reserved		
P15.13	Sent PZD2	0–31	0	0
P15.14	Sent PZD3	0: Disable	0	0
P15.15	Sent PZD4	1: Running frequency (×100, Hz)	0	0
P15.16	Sent PZD5	2: Set frequency (×100, Hz)	0	0
P15.17	Sent PZD6	3: Bus voltage (×10, V)	0	0
P15.18	Sent PZD7	4: Output voltage (×1, V)	0	0
P15.19	Sent PZD8	5: Output current (×10, A)	0	0
P15.20	Sent PZD9	6: Actual output torque (×10, %)	0	0
P15.21	Sent PZD10	7: Actual output power (×10, %)	0	0
P15.22	Sent PZD11	8: Rotation speed of running (x1, RPM)	0	0
-		9: Linear speed of running (x1, m/s)	-	
		10: Ramp reference frequency		
		11: Fault code		
		12: Al1 input (×100, V)		
		13: Al2 input (×100, V)		
		14: Al3 input (×100, V)		
		15: HDIA frequency value (×100, kHz)		
		16: Terminal input status		
		17: Terminal output status		
		18: PID reference (×100, %)		
P15.23	Sent PZD12	19: PID feedback (×100, %)	0	0
		20: Motor rated torque		
		21: MSB of position reference (signed)		
		22: LSB of position reference (unsigned)		
		23: MSB of position feedback (signed)		
		24: LSB of position feedback (unsigned)		
		25: Status word		
		26: HDIB frequency value (*100, kHz)		
		27: PG card pulse feedback count high bit		
		28: PG card pulse feedback count low bit		

Function code	Name	Description	Default	Modify
		29: PG card pulse reference count MSB 30: PG card pulse reference count LSB 31: Function parameter mapping (PZD2– PZD12 correspond to P14.60–P14.70)		
P15.24	Reserved	-	-	-
P15.25	DP communication timeout period	0.0 (invalid)–60.0s	5.0	0
P15.26	CANopen communication timeout period	0.0 (invalid)–60.0s	5.0	0
P15.27	CANopen communication baud rate	0–7 0: 1000kbps 1: 800kbps 2: 500kbps 3: 250kbps 4: 125kbps 5: 100kbps 6: 50kbps 7: 20kbps	3	٥
P15.28	Master/slave CAN communication address	0–127	1	O
P15.29	Master/slave CAN communication baud rate	0: 50Kbps 1: 100kbps 2: 125kbps 3: 250kbps 4: 500kbps 5: 1Mbps	2	0
P15.30	Master/slave CAN communication timeout period	0.0 (invalid)–300.0s	5.0s	0
P15.31– P15.42	Reserved	-	-	-
P15.43	Communication control word expression format	0–1 0: Decimal format 1: Binary format	0	Ø

## Group P16—Communication expansion card 2 functions

Function code	Name	Description	Default	Modify
P16.00- P16.01	Reserved	-	-	-
P16.02	Ethernet monitoring card IP address 1	0–255	192	O
P16.03	Ethernet monitoring card IP address 2	0–255	168	O
P16.04	Ethernet monitoring card IP address 3	0–255	0	O
P16.05	Ethernet monitoring card IP address 4	0–255	1	O
P16.06	Ethernet monitoring card subnet mask 1	0–255	255	O
P16.07	Ethernet monitoring card subnet mask 2	0–255	255	O
P16.08	Ethernet monitoring card subnet mask 3	0–255	255	O
P16.09	Ethernet monitoring card subnet mask 4	0–255	0	O
P16.10	Ethernet monitoring card gateway 1	0–255	192	O
P16.11	Ethernet monitoring card gateway 2	0–255	168	O
P16.12	Ethernet monitoring card gateway 3	0–255	0	O
P16.13	Ethernet monitoring card gateway 4	0–255	1	O
P16.14	Ethernet card monitoring variable address 1	0x0000–0xFFFF	0x0000	0
P16.15	Ethernet card monitoring variable address 2	0x0000–0xFFFF	0x0000	0
P16.16	Ethernet card monitoring variable address 3	0x0000–0xFFFF	0x0000	0
P16.17	Ethernet card	0x0000–0xFFFF	0x0000	0

Function code	Name	Description	Default	Modify
	monitoring variable address 4			
P16.18– P16.23	Reserved	-	-	-
P16.24	Time to identify expansion card in card slot 1	0.0–600.0s The value 0.0 indicates that identification fault will not be detected.	0.0s	0
P16.25	Time to identify expansion card in card slot 2	0.0–600.0s The value 0.0 indicates offline fault will not be detected.	0.0s	0
P16.26	Time to identify expansion card in card slot 3	0.0–600.0s The value 0.0 indicates offline fault will not be detected.	0.0s	0
P16.27	Communication timeout period of expansion card in card slot 1	0.0–600.0s The value 0.0 indicates offline fault will not be detected.	0.0s	0
P16.28	Communication timeout period of expansion card in card slot 2	0.0–600.0s The value 0.0 indicates offline fault will not be detected.	0.0s	0
P16.29	Communication timeout period of expansion card in card slot 3	0.0–600.0s The value 0.0 indicates offline fault will not be detected.	0.0s	0
P16.30	Reserved	-	-	-
P16.31	PROFINET communication timeout time	0.0–60.0s	5.0s	0
P16.32	Received PZD2	0–31	0	0
P16.33	Received PZD3	0: Disable	0	0
P16.34	Received PZD4	1: Set frequency (0–Fmax, unit: 0.01Hz)	0	0
P16.35	Received PZD5	2: PID reference (-1000-1000, in which 1000	0	0
P16.36	Received PZD6	corresponds to 100.0%)	0	0
P16.37	Received PZD7	3: PID feedback (-1000–1000, in which 1000	0	0
P16.38	Received PZD8	corresponds to 100.0%)	0	0
P16.39	Received PZD9	4: Torque setting (-3000–+3000, in which 1000	0	0

P16.40         Received PZD10         correst           P16.41         Received PZD11         currest	expands to 100.0% of the motor rated		
P16.41 Received PZD11 current	sponds to 100.0% of the motor rated	0	0
	ent)	0	0
5: Se           frequi           6: Se           frequi           7: Up           3000,           the m           8: Up           which           rated           9. V           0x000           S8/SI           10: V           0x000           13: A           which           13: A           which           14: M           15: Li           16: M           17: Li           18: I           19:	etting of the upper limit of forward running ency (0–Fmax, unit: 0.01 Hz) etting of the upper limit of reverse running ency (0–Fmax, unit: 0.01 Hz) pper limit of the electromotive torque (0– , in which 1000 corresponds to 100.0% of notor rated current) pper limit of braking torque (0–3000, in h 1000 corresponds to 100% of the motor I current) (ritual input terminal command (range: 0–0x3FF, corresponding to 7/S6/S5/HDIB/ HDIA/S4/S3/S2/S1) Virtual output terminal command (range: –0x0F, corresponding to (RO1/HDO/Y1) /oltage setting (special for V/F separation) 000, in which 1000 corresponds to 100% of notor rated voltage) AO1 output setting 1 (-1000–+1000, in h 1000 corresponds to 100.0%) AO2 output setting 2 (-1000–+1000, in h 1000 corresponds to 100.0%) ASB of position reference (signed) SB of position reference (unsigned) ASB of position feedback (signed) SB of position feedback (unsigned) Position feedback setting flag (position pack can be set only after this flag is set to d then to 0) function parameter mapping (PZD2– 12 correspond to P14.49–P14.59) i1: Reserved	0	0
D16.44 Cont.D7D2 0-31	rolid	0	0
P16.45 Sent D7D4 1. Du	valiu Inning frequency (x100 Hz)	0	0

Function code	Name	Description	Default	Modify
P16.46	Sent PZD5	2: Set frequency (×100, Hz)	0	0
P16.47	Sent PZD6	3: Bus voltage (×10, V)	0	0
P16.48	Sent PZD7	4: Output voltage (×1, V)	0	0
P16.49	Sent PZD8	5: Output current (×10, A)	0	0
P16.50	Sent PZD9	6: Actual output torque (×10, %)	0	0
P16.51	Sent PZD10	7: Actual output power (×10, %)	0	0
P16.52	Sent PZD11	8: Rotation speed of running (x1, RPM)	0	0
		9: Linear speed of running (x1, m/s)		
		10: Ramp reference frequency		
		11: Fault code		
		12: Al1 input (×100, V)		
		13: Al2 input (×100, V)	Default         M           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0           0         0	
		14: AI3 input (×100, V)		
		15: HDIA frequency value (×100, kHz)	Default         Ma           0         0         0           0         0         0         0           0         0         0         0           0         0         0         0         0           0         0         0         0         0         0           0<	
		16: Terminal input status		
		17: Terminal output status		
		18: PID reference (×100, %)		
		19: PID feedback (×100, %)		
		20: Motor rated torque 21: MSB of position reference (signed) 22: LSB of position reference (unsigned)		
P16.53	Sent PZD12		0	0
		23: MSB of position feedback (signed)		
		24: LSB of position feedback (unsigned)		
		25: Status word	0 0 0 0 0 0 0 0 0 0 5.0s	
		26: HDIB frequency value (×100, kHz)		
		27: PG card pulse feedback count high bit		
		28: PG card pulse feedback count low bit		
		29: PG card pulse reference count MSB		
		30: PG card pulse reference count LSB		
		31: Function parameter mapping (PZD2-		
		PZD12 correspond to P14.60–P14.70)		
	EtherNet IP			
P16.54	communication	0.0–60.0s	5.0s	0
	timeout period			
	·	0–4		
<b>D</b> 40 <b>D</b> =	EtherNet IP	0: Self adaptive		
P16.55	communication rate	1: 100M full duplex	0	Ø
		2 <sup>.</sup> 100M half duplex		

Function code	Name	Description	Default	Modify
		3: 10M full duplex		
		4: 10M half duplex		
P16.56	Bluetooth pairing code	0–65535	0	•
<b>D</b> 40 57		0–65535 0: No host connection		
P16.57	Bluetooth host type	1: Mobile App 2: Bluetooth box 3–65535: Reserved	0	•
	Industrial Ethernet			
P16.58	communication	0–255	192	O
	card IP address 1			
	Industrial Ethernet			
P16.59	communication	0–255	168	O
	Laduatrial Ethernat			
P16 60	communication	0–255	0	Ø
1 10.00	card IP address 3	0 200	Ū	٢
	Industrial Ethernet			
P16.61	communication	0–255	20	O
	card IP address 4			
	Industrial Ethernet			
P16.62	communication	0–255	255	O
	card subnet mask 1			
	Industrial Ethernet			
P16.63	communication	0–255	255	O
	card subnet mask 2			
<b>B</b> / <b>a a</b> /	Industrial Ethernet			
P16.64	communication	0–255	255	Ø
	card subnet mask 3			
D10.05	Industrial Ethernet	0.055	0	
P16.65	communication	0–255	0	U
	Industrial Ethernet			
P16.66		0255	102	0
1 10.00	card gateway 1		132	9
P16.67	Industrial Ethernet communication	0–255	168	O

Function code	Name	Description	Default	Modify
	card gateway 2			
	Industrial Ethernet			
P16.68	communication	0–255	0	O
	card gateway 3			
	Industrial Ethernet			
P16.69	communication	0–255	1	O
	card gateway 4			

## Group P17—Status viewing

Function code	Name	Description	Default	Modify
P17.00	Set frequency	Displays the present set frequency of the VFD. Range: 0.00Hz–P00.03	0.00Hz	•
P17.01	Output frequency	Displays the present output frequency of the VFD. Range: 0.00Hz–P00.03	0.00Hz	•
P17.02	Ramp reference frequency	Displays the present ramp reference frequency of the VFD. Range: 0.00Hz-P00.03	0.00Hz	•
P17.03	Output voltage	Displays the present output voltage of the VFD. Range: 0–1200V	0V	•
P17.04	Output current	Displays the valid value of present output current of the VFD. Range: 0.0–5000.0A	0.0A	•
P17.05	Motor rotation speed	Displays the present motor rotation speed. Range: 0–65535rpm	0rpm	•
P17.06	Torque current	Displays the present torque current of the VFD. Range: -3000.0–3000.0A	0.0A	•
P17.07	Exciting current	Displays the present exciting current of the VFD. Range: -3000.0–3000.0A	0.0A	•
P17.08	Motor power	Displays the present motor power. 100% corresponds to the rated motor power. The positive value is the motoring state while the negative value is the generating state. Range: -300.0–300.0% (relative to the rated motor power)	0.0%	•

Function code	Name	Description	Default	Modify
P17.09	Motor output torque	Displays the present output torque of the VFD; 100% relative to the rated motor torque. During forward running, the positive value is the motoring state while the negative value is generating state. During reverse running, the positive value is the generating state while the negative value is the motoring state. Range: -250.0–250.0%	0.0%	•
P17.10	Estimated motor frequency	Displays the estimated motor rotor frequency under the open-loop vector condition. Range: 0.00–P00.03	0.00Hz	•
P17.11	DC bus voltage	Displays the present DC bus voltage of the VFD. Range: 0.0–2000.0 V	0.0V	•
P17.12	Digital input terminal state	Displays the present digital input terminal state of the VFD. 0x00–0x3F Corresponds to HDIB, HDIA, S4, S3, S2 and S1 respectively.	0x00	•
P17.13	Digital output terminal state	Displays the present digital output terminal state of the VFD. 0x00–0x0F The bits correspond to RO2, RO1, HDO, and Y1 respectively.	0x00	•
P17.14	Digital adjustment value	Displays the adjustment on the VFD through the UP/DOWN terminal. Range: 0.00Hz–P00.03	0.00Hz	•
P17.15	Torque reference value	Relative to the percentage of the rated torque of the present motor, displaying the torque reference. Range: -300.0%–300.0% (of the motor rated current)	0.0%	•
P17.16	Linear speed	0–65535	0	•
P17.17	Reserved		-	-
P17.18	Count value	0–65535	0	•
P17.19	AI1 input voltage	Displays the Al1 input signal. Range: 0.00–10.00V	0.00V	•
P17.20	AI 2 input voltage	Displays the AI2 input signal.	0.00V	

Function code	Name	Description	Default	Modify
		Range: -10.00V–10.00V		
D47.04	HDIA input	Display HDIA input frequency.	0.000	
P17.21	frequency	Range: 0.000–50.000kHz	kHz	•
D47.00	HDIB input	Display HDIB input frequency.	0.000 1411-	
P17.22	frequency	Range: 0.000–50.000kHz	0.000 KHZ	•
D17 22	PID reference	Displays the PID reference value.	0.09/	
P17.23	value	Range: -100.0–100.0%	0.0%	•
D17 04		Displays the PID feedback value.	0.00/	
P17.24	PID leedback value	Range: -100.0–100.0%	0.0%	•
D47.05	Motor nouver feator	Displays the power factor of the current motor.	0.00	
P17.25	Motor power lactor	Range: -1.00–1.00	0.00	•
D17.06	Duration of this run	Displays the duration of this run of the VFD.	Omin	
P17.20	Duration of this run	Range: 0–65535min	Umm	•
D47.07	Present step of	Used to display the present step of the simple	0	
P17.27	simple PLC	PLC function.	0	•
		Displays the ASR controller output value under		
	Motor ASR	the vector control mode, relative to the		
P17.28		percentage of rated motor torque.	0.0%	•
	controller output	Range: -300.0%-300.0% (of the motor rated		
		current)		
D17 20	Open-loop SM pole	Displays the initial identification angle of SM.	0.0	
P17.29	angle	Range: 0.0–360.0	0.0	•
	Phase	Displays the phase companyation of SM		
P17.30	compensation of	Pange: -180.0. 180.0	0.0	•
	SM	Kange 100.0-100.0		
	High-frequency			
P17.31	superposition	0.0%–200.0% (of the motor rated current)	0.0	•
	current of SM			
P17.32	Motor flux linkage	0.0%–200.0%	0.0%	•
	Exciting current	Displays the exciting current reference value		
P17.33	reference	under the vector control mode.	0.0A	•
	Telefence	Range: -3000.0–3000.0A		
		Displays the torque current reference value		
P17.34	reference	under the vector control mode.	0.0A	•
	Tererence	Range: -3000.0–3000.0A		
P17 35	AC incoming	Displays the valid value of incoming current on	0.04	•
P17.35	current	AC side.	0.04	-

Function code	Name	Description	Default	Modify
		Range: 0.0–5000.0A		
P17.36	Output torque	Displays the output torque value. During forward running, the positive value is the motoring state while the negative value is generating state. During reverse running, the positive value is the generating state while the negative value is the motoring state. Range: -3000.0Nm–3000.0Nm	0.0Nm	•
P17.37	Motor overload count value	0–65535	0	•
P17.38	Process PID output	-100.0%–100.0%	0.0%	•
P17.39	Function codes in parameter download error	0.00–99.00	0.00	•
P17.40	Motor control mode	0x000–0x123 Ones place: Control mode 0: Vector 0 1: Vector 1 2: V/F control 3: Closed-loop vector Tens place: Control status 0: Speed control 1: Torque control 2: Position control Hundreds place: Motor number 0: Motor 1 1: Motor2	0x000	•
P17.41	Electromotive torque upper limit	0.0%–300.0% (of the motor rated current)	0.0%	•
P17.42	Braking torque upper limit	0.0%-300.0% (of the motor rated current)	0.0%	•
P17.43	Forward rotation upper-limit frequency in torque control	0.00–P00.03	0.00Hz	•
P17.44	Reverse rotation upper-limit frequency in torque	0.00-P00.03	0.00Hz	•

Function code	Name	Description	Default	Modify
	control			
P17.45	Inertia compensation	-100.0%–100.0%	0.0%	•
	torque			
P17.46	Friction compensation torque	-100.0%–100.0%	0.0%	•
P17.47	Motor pole pairs	0–65535	0	•
P17.48	VFD overload count value	0–65535	0	•
P17.49	Frequency set by A source	0.00–P00.03	0.00Hz	•
P17.50	Frequency set by B source	0.00–P00.03	0.00Hz	•
P17.51	PID proportional output	-100.0%–100.0%	0.0%	•
P17.52	PID integral output	-100.0%–100.0%	0.0%	•
P17.53	PID differential output	-100.0%–100.0%	0.0%	•
P17.54	PID present proportional gain	0.00–100.00	0.00	•
P17.55	PID present integral gain	0.00–10.00s	0.00s	•
P17.56	PID present differential time	0.00–10.00s	0.00s	•
P17.57	Actual steps of multi-step speed	0–15	0	•
P17.58	100Hz component peak value (square waves quadrature)	0.0–300.0(V) <b>Note:</b> Peak-to-peak value of bus voltage fluctuation at 100Hz frequency component, which is detected by using a square-wave orthogonal function.	0.0	•
P17.59	100Hz component peak value (sin quadrature)	0.0–300.0(V) <b>Note:</b> Peak-to-peak value of bus voltage fluctuation at 100Hz frequency component, which is detected by using a sin-wave orthogonal function.	0.0	•

## Group P18—Status viewing in closed-loop control

Function code	Name	Description	Default	Modify
P18.00	Actual frequency of encoder	Used to indicate the actual-measured encoder frequency. The value of forward running is positive; the value of reverse running is negative. Range: -999.9–3276.7Hz <b>Note:</b> P18.00 is only displayed in V/F and closed-loop modes. In open loop mode, it is not displayed.	0.0Hz	•
P18.01	Encoder position count value	Encoder count value, quadruple frequency. Range: 0–65535	0	•
P18.02	Encoder Z pulse count value	Corresponding count value of encoder Z pulse. Range: 0–65535	0	•
P18.03	High bit of position reference value	It is cleared after stop. Setting range: 0–30000	0	•
P18.04	Low bit of position reference value	It is cleared after stop. Range: 0–65535	0	•
P18.05	High bit of position feedback value	It is cleared after stop. Setting range: 0–30000	0	•
P18.06	Low bit of position feedback value	It is cleared after stop. Range: 0–65535	0	•
P18.07	Position deviation	Deviation between the reference position and actual running position. Setting range: -32768–32767	0	•
P18.08	Position of position reference point	Position of reference point of Z pulse when the spindle stops accurately. Range: 0–65535	0	•
P18.09	Present position setting of spindle	Present position setup when the spindle stops accurately. Setting range: 0–359.99	0.00	•
P18.10	Present position when spindle stops accurately	Present position when the spindle stops accurately. Range: 0–65535	0	•
P18.11	Encoder Z pulse direction	Z pulse direction display. When the spindle stops accurately, there may be a couple of pulses' error between the position of forward and reverse orientation, which can be	0	•

Function code	Name	Description	Default	Modify
		eliminated by adjusting Z pulse direction of P20.02 or exchanging phase AB of encoder. 0: Forward 1: Reverse		
P18.12	Encoder Z pulse angle	Reserved. Setting range: 0.00–359.99	0.00	•
P18.13	Encoder Z pulse error times	Reserved. Range: 0–65535	0	•
P18.14	High bit of encoder pulse count value	0–65535	0	•
P18.15	Low bit of encoder pulse count value	0–65535	0	•
P18.16	Speed measured by main control board	-3276.8–3276.7Hz	0.0Hz	•
P18.17	Pulse command frequency	The pulse command (A2/B2 terminal) is converted to the set frequency, and it is valid under the pulse position mode and pulse speed mode. Range: -3276.8–3276.7Hz	0.0Hz	•
P18.18	Pulse command feedforward	The pulse command (A2/B2 terminal) is converted to the set frequency, and it is valid under the pulse position mode and pulse speed mode. Range: -3276.8–3276.7Hz	0.0Hz	•
P18.19	Position regulator output	-327.68–327.67Hz	0.00Hz	•
P18.20	Count value of resolver	Count value of the resolver. Range: 0–65535	0	•
P18.21	Resolver angle	Pole position angle read by the resolver-type encoder. Setting range: 0.00–359.99	0.00	•
P18.22	Closed-loop SM pole angle	Present pole position. Setting range: 0.00–359.99	0.00	•
P18.23	SW 2	0x0000–0xFFFF	0x0000	•
P18.24	High-order bit of count value of	0–65535	0	•

Function code	Name	Description	Default	Modify
	pulse reference			
	Low-order bit of			
P18.25	count value of	0–65535	0	•
	pulse reference			
D18 26	Speed measured	-3276 8 3276 747	이 이니-7	
F 10.20	by PG card	-3270.0-3270.7112	0.0112	•
P18 27	Encoder UVW	0_7	0	
F 10.27	sectors	0-1	0	•
P18 28	Encoder PPR	0_65535	0	•
1 10.20	display	0-00000	0	•
	Angle			
P18.29	compensation	-180.0–180.0	0.0	•
	value of SM			
P18 30	Z pulse angle of	0 00-655 35	0.00	
1 10.50	SM	0.00-000.00	0.00	•
P18 31	Z pulse value of	0_65535	0	
F 10.51	pulse reference	0-00000	0	•
	Main control board			
P18.32	measured value of	-3276.8–3276.7Hz	0.0Hz	•
	pulse reference			
	PG card measured			
P18.33	value of pulse	-3276.8–3276.7Hz	0.0Hz	•
	reference			
P18.34	Present encoder filter width	0–63	0	•
P18.35	8k test duration	0–65535	0	•

# Group P19—Expansion card status viewing

Function code	Name	Description	Default	Modify
P19.00	Expansion card type of card slot 1	0–65535 0: No card	0	•
P19.01	Expansion card type of card slot 2	1: Programmable card 2: I/O card	0	•
P19.02	Expansion card type of card slot 3	<ol> <li>Incremental PG card</li> <li>Incremental PG card with UVW</li> <li>Ethernet communication card</li> </ol>	0	•

Function code	Name	Description	Default	Modify
		6: DP communication card		
		7: Bluetooth card 1		
		8: Resolver PG card		
		9: CANopen communication card		
		10: WIFI card		
		11: PROFINET communication card		
		12: Sine-cosine PG card without CD signals		
		13: Sine-cosine PG card with CD signals		
		14: Absolute encoder PG card		
		15: CAN master/slave communication card		
		16: Modbus TCP communication card		
		17: EtherCAT communication card		
		18: BACnet communication card		
		19: DeviceNet communication card		
		20: PT100/PT1000 temperature detection card		
		21: EtherNet IP card		
		22: MECHATROLINK communication card		
		23: Bluetooth card 2		
		24–65535: Reserved		
	Software version of			
P19.03	expansion card at	0.00–655.35	0.00	•
	slot 1			
	Software version of			
P19.04	expansion card at	0.00–655.35	0.00	•
	slot 2			
	Software version of			
P19.05	expansion card at	0.00–655.35	0.00	•
	slot 3			
	Terminal input			
P19.06	status of I/O card	0x0000–0xFFFF	0x0000	•
	Terminal output			
P19.07	status of I/O card	0x0000–0xFFFF	0x0000	•
P19.08	Reserved	-	-	-
	AI3 input voltage of			
P19.09	I/O card	0.00–10.00V	0.00V	•
	EC PT100 detected			
P19.10	temperature	-50.0–150.0°C	0.0°C	
P19.11	EC PT100 detected	0–4096	0	

Function code	Name	Description	Default	Modify
	digital			
	EC PT1000			
P19.12	detected	-50.0–150.0°C	0.0°C	•
	temperature			
P19 13	EC PT1000	0-4096	0	•
1 10.10	detected digital		0	•
		0–4		
		0: None		
<b>P10 1</b> 4	Warning display	1: PT100 detected OH alarm (A-Ot1)	0	
P19.14	warning display	2: PT1000 detected OH alarm (A-Ot2)	0	•
		3: PT100 disconnection alarm (A-Pt1)		
		4: PT1000 disconnection alarm (A-Pt2)		
D10.15	Communication	0x0000–0xFFFF	0,0000	
P19.15	card control word		00000	•
P10.16	Communication		0×0000	
F 19.10	card status word		0x0000	•
P19 17	Ethernet monitoring	0-65535	0	
1 10.17	variable 1		0	•
P10 18	Ethernet monitoring	0_65535	0	
1 13.10	variable 2		0	•
P10 10	Ethernet monitoring	0_65535	0	
1 13.13	variable 3		0	
P19 20	Ethernet monitoring	0-65535	0	
1 13.20	variable 4		0	
P19.21	AIAO temperature	-20.0–200.0°C	0.0°C	

# Group P20—Encoder of motor 1

Function code	Name	Description	Default	Modify
P20.00	Encoder type display	0: Incremental encoder 1: Resolver-type encoder 2: Sin/Cos encoder 3: Endat absolute encoder	0	•
P20.01	Encoder pulse count	Number of pulses generated when the encoder revolves for one circle. Setting range: 0–60000	1024	O
P20.02	Encoder direction	0x000–0x111	0x000	O

Function code	Name	Description	Default	Modify
		Ones place: AB direction		
		0: Forward		
		1: Reverse		
		Tens place: Z pulse direction (reserved)		
		0: Forward		
		1: Reverse		
		Hundreds place: CD/UVW pole signal direction		
		0: Forward		
		1: Reverse		
	Encoder			
P20.03	disconnection fault	0.0–10.0s	2.0s	0
	detection time			
P20.04	Encoder reversal	0.0–100.0s	0.8s	0
	Tault delection time	Sotting range: 0x00, 0x00		
		Setting range: 0x00–0x99		
P20.05	Filter times of encoder detection	Ones place: Low-speed litter time,	000	0
		corresponding to $2^{\prime\prime}(0-9)^{\times}125\mu$ s.	0X33	0
		Tens place: High-speed filter times,		
	0	corresponding to 2/(0–9)×125µs.		
	Speed ratio	You need to set the function parameter when		
P20.06	between encoder	the encoder is not installed on the motor shaft	1.000	0
	mounting shaft and	and the drive ratio is not 1.		
	motor	Setting range: 0.001–65.535		
		0x0000–0xFFFF		
		Bit0: Enable Z pulse calibration		
		Bit1: Enable encoder angle calibration		
		Bit2: Enable SVC speed measurement		
		Bit3: Resolver based speed measurement		
		mode selection		
	Control parameters	Bit4: Z pulse capture mode		
P20.07	of SM	Bit5: Do not detect the encoder initial angle in	0x0003	0
		V/F control		
		Bit6: Enable the CD signal calibration		
		Bit7: Disable sin/cos subdivision speed		
		measurement		
		Bit8: Do not detect encoder faults during		
		autotuning		
		Bit 9: Enable Z pulse detection optimization		

Function code	Name	Description	Default	Modify
		Bit10: Enable the initial Z pulse calibration		
		Bit12: Clear the 7 nulse arrival signal after ston		
		Bit13: Reserved		
		Bit14: Detect 7 pulse after one rotation		
		Bit15: Reserved		
		0x00-0x11		
		Ones place: Z pulse detection		
		0. No detection		
P20.08	Enable Z pulse	1: Enable	0x10	0
0.00	offline detection	Tens place: UVW pulse detection (for SM)	0,110	0
		0. No detection		
		1: Enable		
		Relative electric angle between the encoder Z		
P20.09	Initial angle of Z pulse	pulse and the motor pole position	0.00	0
1 20.00		Setting range: 0.00–359.99	0.00	
		Relative electric angle between the encoder		
P20 10	Pole initial angle	position and the motor pole position	0.00	0
P20.10	Fole Initial angle	Setting range: 0.00-359.99	0.00	
		0: No operation		
	Initial polo apolo	1: Rotary autotuning (DC braking)		
P20.11	autotuning	2: Static autotuning (suitable for resolver-type	0	O
	autoturning	encoder sin/cos with CD signal feedback)		
		3: Rotary autotuning (initial angle identification)		
	Speed			
	measurement	0: No optimization		
P20.12	ontimization	1: Optimization mode 1	1	O
	selection	2: Optimization mode 2		
	CD signal zero			
P20.13	offset gain	0–65535	0	0
		0x00–0x11		
		Ones place: Incremental encoder		
	Encoderture	0: Without UVW		
P20.14		1: with UVW	0x00	O
	Selection	Tens place: Sin/Cos encoder		
		0: Without CD signal		
		1: with CD signal		

Function code	Name	Description	Default	Modify
P20.15	Speed measurement mode	0: PG card 1: Locally measured through HDIA and HDIB. Only the 24V incremental encoders are supported.	0	O
P20.16	Frequency division coefficient	0–255	0	0
P20.17	Pulse filter handling selection	0x0000–0xFFFF Bit0: Enable/disable encoder input filter 0: Disable 1: Enable Bit1: Encoder signal filter mode (set bit0 or bit2 to 1) 0: Self-adaptive filter 1: Use P20.18 as the filter parameter Bit2: Enable/disable encoder frequency-division output filter 0: Disable 1: Enable Bit3: Reserved Bit4: Enable/disable pulse reference filter 0: Disable 1: Enable Bit5: Pulse reference filter mode (valid when bit4 is set to 1) 0: Self-adaptive filter 1: Use P20.19 as the filter parameter Bit6–15: Reserved	0x0033	0
P20.18	Encoder pulse filter width	0–63 0 indicates 0.25µs.	2	0
P20.19	Pulse reference filter width	0–63 0 indicates 0.25µs.	2	0
P20.20	Pulse number of pulse reference	0–65535	1024	O
P20.21	Enabling SM angle compensation	0–1	1	0
P20.22	Frequency point of speed measurement	0–630.00Hz	1.00Hz	0

Function code	Name	Description	Default	Modify
	mode switchover			
	SM angle			
P20.23	compensation	-200.0–200.0%	100.0%	0
	coefficient			
	Number of pole			
P20.24	pairs in initial pole	1–128	2	O
	angle autotuning			

## Group P21-Position control

Function code	Name	Description	Default	Modify
P21.00	Positioning mode	0x0000–0x7121 Ones place: Control mode selection (only for closed-loop vector control) 0: Speed control 1: Position control Tens place: Position command source 0: Pulse train, using PG card terminal (A2, B2) pulse giving signal for position control 1: Digital position. The setting of P21.17 is used for positioning, while the positioning mode can be set through P21.16. 2: Positioning of photoelectric switch during stop. When a terminal receives a photoelectric switch signal (terminal function 43 selected), the VFD starts positioning for stop, and the stop distance can be set through P21.17. Hundred place: Position feedback source 0: PG1 1: PG2 Thousands place: Servo mode 0: Disable servo, without position deviation 1: Disable servo, without position deviation 2: Enable servo, with position deviation 3: Enable servo, with position deviation 4–7: Reserved <b>Note:</b> In the pulse train or spindle positioning mode, the VFD enters the servo operation	0×0000	0

Function code	Name	Description	Default	Modify
Function code	Pulse command	Description mode when there is a valid servo enabling signal. If there is no servo enabling signal, the VFD enter the servo operation mode only after it receives a forward running or reverse running command. 0x0000–0x3133 Ones place: Pulse mode 0: A/B quadrature pulse; A leads B 1: A is PULSE and B is SIGN If channel B is of low electric level, the edge counts up; if channel B is of high electric level, the edge counts down. 2: A is positive pulse Channel A is positive pulse; channel B needs no wiring 3: A/B dual-channel pulse; channel A pulse edge counts up, channel B pulse edge counts down Tens place: Pulse direction	Ox0000	Modify
	mode	Bit0: Set pulse direction 0: Forward 1: Reverse Bit1: Set pulse direction by running direction 0: Disable, and bit0 is valid 1: Enable Hundreds place: Reserved Thousands place: Pulse control selection Bit0: Pulse filter selection 0: Inertia filter 1: Moving average filter Bit1: Overspeed control 0: No control 1: Control		
P21.02	Position loop gain 1	The two automatic position regulator (APR)	20.0	0
P21.03	Position loop gain 2	gains are switched based on the switching mode set through P21.04. When the spindle orientation function is used, the gains are switched automatically regardless of the setting	30.0	0

Function code	Name	Description	Default	Modify
		of P21.04. P21.03 is used for dynamic running, and P21.02 is used for maintaining the locked state. Setting range: 0.0–400.0		
P21.04	Position loop gain switchover mode	Used to select the mode for switching between APR gains. To use torque command-based switching, you need to set P21.05; and to use speed command-based switching, you need to set P21.06. 0: No switchover 1: Torque command 2: Speed command 3–5: Reserved	0	0
P21.05	Position gain switchover threshold in torque command	0.0–100.0% (of the motor rated torque)	10.0%	0
P21.06	Position gain switchover threshold in speed command	0.0–100.0% (of the motor rated speed)	10.0%	0
P21.07	Smooth filter coefficient for gain switchover	Smooth filter coefficient for APR gain switchover. Setting range: 0–15	5	0
P21.08	Position controller output limit	Position regulator output Value. When the output limit is 0, the position regulator is invalid, and no position control can be performed, however, speed control is valid. Setting range: 0.0–100.0% (of max. output frequency P00.03)	20.0%	0
P21.09	Positioning completion zone	When the position deviation is less than P21.09, and the duration is greater than P21.10, positioning completion signal will be outputted. Setting range: 0–1000	10	0
P21.10	Detection time for positioning completion	0.0–1000.0ms	10.0ms	0
P21.11	Numerator of	Electronic gear ratio, used to adjust the	1000	0

Function code	Name	Description	Default	Modify
	position command ratio	corresponding relation between position command and actual running displacement. Setting range: 1–65535		
P21.12	Denominator of position command ratio	Setting range: 1–65535	1000	0
P21.13	Position feedforward gain	0.00–120.00% For pulse train reference only (position control)	100.00	0
P21.14	Position feedforward filter time constant	0.0–3200.0ms For pulse train reference only (position control)	3.0ms	0
P21.15	Position command filter time constant	Position feedforward filter time constant during the pulse train positioning. 0.0–3200.0ms	0.0ms	O
P21.16	Digital positioning mode	0x0000–0xFFFF Bit 0: Positioning mode 0: Relative position 1: Absolute position (Origin mode. This function is reserved.) Bit 1: Cyclic positioning setting. You can enable positioning through a terminal (function 55) or choose automatic cyclic positioning. Terminals support only the enabling of continuous positioning, and automatic cyclic positioning can be set to cyclic positioning or reciprocating positioning through bit2 of P21.16. 0: Terminal-based cyclic positioning 1: Automatic cyclic positioning Bit2: Cyclic mode 0: Continuous 1: Reciprocating (support the automatic cyclic positioning) Bit 3: P21.17 based digital setting mode. You can select incremental or position type. The incremental type indicates that P21.17 needs to be conducted again after each positioning is enabled. The position type indicates that the displacement is set through P21.17, and the	0x0000	0

Function code	Name	Description	Default	Modify
		new position is be located automatically if		
		P21.17 is changed.		
		0: Incremental		
		1: Position type (do not support the continuous		
		mode)		
		Bit4: Origin searching mode. This function is		
		reserved.		
		0: Search for the origin only for once		
		1: Search for the origin in every time of running		
		Bit5: Origin calibration mode. This function is		
		reserved.		
		0: Calibration in real time		
		1: One-time calibration		
		Bit 6: Positioning completion signal setting. You		
		can set the positioning completion signal in the		
		pulse or electrical level form. The positioning		
		completion signal is valid in the positioning		
		completion signal holding time set in P21.25.		
		0: Valid in the positioning completion signal		
		holding time (P21.25)		
		1: Always valid		
		Bit 7: First positioning setting. You can set		
		whether the first positioning is performed when		
		a running command is received. If no, the first		
		positioning is performed only after the		
		positioning enabling terminal or automatic cyclic		
		positioning is enabled.		
		0: Disable		
		1: Enable		
		Bit 8: Positioning enabling signal setting (for		
		terminal-based cyclic positioning). In the pulse		
		form, after positioning is completed or in the		
		first positioning, the jump edge of the		
		positioning enabling terminal needs to be		
		detected for performing positioning. In the		
		electrical level mode, after positioning is		
		completed or in the first positioning, positioning		
		is performed after it is detected that the		

Function code	Name	Description	Default	Modify
code		positioning enabling terminal is switched on. 0: Pulse signal 1: Electrical level signal Bit 9: Position source 0: Set by P21.17 1: PROFIBUS/CANopen setting Bit 10: Indicates whether to save encoder pulse count value at power-off 0: No 1: Yes Bit11: Reserved Bit 12: Positioning curve setting (Reserved) 0: Straight line 1: S curve		
P21.17	Position set in digital mode	Used to set the position for digital positioning. Actual position=P21.17xP21.11/P21.12 0–65535	0	0
P21.18	Positioning speed setting selection	0: Set by P21.19 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDIA 5: High-speed pulse HDIB	0	0
P21.19	Positioning speed set in digital mode	0–100.0% (of the max. frequency)	20.0%	0
P21.20	Positioning ACC time	Used to set the ACC/DEC time in the positioning process.	3.00s	0
P21.21	Positioning DEC time	Positioning ACC time means the time needed if the VFD speeds up from 0Hz to the max. output frequency (P00.03). Positioning DEC time means the time needed if the VFD speeds down from the max. output frequency (P00.03) to 0Hz. Setting range of P21.20: 0.01–300.00s Setting range of P21.21: 0.01–300.00s	3.00s	0
P21.22	Positioning holding time	The function code is used to set the holding time after the destination position is reached. Setting range: 0.000–60.000s	0.100s	0

Function code	Name	Description	Default	Modify
P21.23	Origin searching speed	0.00–50.00Hz	2.00Hz	0
P21.24	Origin bias	0–65535	0	0
P21.25	Positioning completion signal holding time	Time for holding the positioning completion signal. This parameter is also valid for the positioning in spindle orientation. Setting range: 0.000–60.000s	0.200s	0
P21.26	Pulse superposition	Setting range of P21.26: -9999–32767	0	0
P21.27	Pulse superposition rate	Setting range of P21.27: 0–3000.0 pulse/ms The function is valid in the pulse speed	8.0 pulse/ms	0
P21.28	ACC/DEC time after pulse inhibition	<ul> <li>(P21.00=1).</li> <li>1. Input terminal function 68 (Enable the pulse superimposition)</li> <li>When the rising edge of the terminal is detected, add the value set in P21.26 to the set pulse value, and compensate to the pulse reference channel based on the pulse superposition speed set in P21.27.</li> <li>2. Input terminal function 67 (pulse increase)</li> <li>When the terminal is valid, superpose the pulse value to the pulse reference channel based on the pulse value to the pulse reference channel based on the pulse superposition speed set in P21.27.</li> <li>Note: Terminal filter P05.09 may affect the actual superposed value.</li> <li>For example:</li> <li>P21.27 = 1.0 pulse/ms</li> <li>P05.05 = 67</li> <li>When the S5 terminal input signal is 0.5s, the actual superposed pulses = 500 pulses.</li> <li>Input terminal function 69 (pulse decrease)</li> <li>The time sequence of this function is same as the above. The difference is that this terminal is the pulse number that is superposed degressively.</li> <li>Note: The pulses mentioned above are superposed to A2 and B2 of pulse reference channel. Functions such as filtering and</li> </ul>	5.0s	0

Function code	Name	Description	Default	Modify
		electronic gear are still valid for superposed pulses. 4. Output terminal function 28 (during pulse superposition) During the pulse superposition, the output terminal is valid. After the pulse superposition is completed, the output terminal is invalid.		
P21.29	Speed feedforward filtering time constant (pulse train-based speed mode)	Filter time constant detected by the pulse train when the speed reference source is set to the pulse train (P00.06=12 or P00.07=12). Setting range: 0–3200.0ms	10.0ms	0
P21.30	Numerator of the 2nd command ratio	1–65535	1000	0
P21.31	Speed measuring method of pulse reference	0–2 0: By main control board 1: By PG card 2: Hybrid method	0	0
P21.32	Pulse reference feedforward source	0x0–0x1	0x0	O
P21.33	Setting of encoder count value clearing	0–65535	0	O

## Group P22---Spindle positioning

Function code	Name	Description	Default	Modify
P22.00	Spindle positioning mode selection	0x0000–0xFFFF Bit0: Enable/disable spindle positioning 0: Disable 1: Enable Bit1: Spindle positioning reference point selection 0: Z pulse input 1: S2/S3/S4 terminal input Bit2: Search for reference point 0: Search the reference point only once 1: Search the reference point every time	0x0000	0
Function code	Name	Description	Default	Modify
------------------	---------------------	--	---------	--------
		Bit3: Enable reference point calibration		
		0: Disable		
		1: Enable		
		Bit4: Positioning mode selection 1		
		0: Set direction positioning		
		1: Near-by direction positioning		
		Bit5: Positioning mode selection 2		
		0: Forward positioning		
		1: Reverse positioning		
		Bit6: Zeroing command selection		
		0: Electric level mode		
		1: Pulse mode		
		Bit7: Reference point calibration mode		
		0: Calibrate at the first time		
		1: Calibration in real time		
		Bit8: Action selection after zeroing signal		
		cancellation (electric level type)		
		0: Switch to speed mode		
		1: Position lock mode		
		Bit9: Positioning completion signal selection		
		0: Electrical level signal		
		1: Pulse signal		
		Bit10: Z pulse signal source		
		0: Motor		
		1: Spindle		
		Bit11–15: Reserved		
		During spindle orientation, the speed of the		
		position point of orientation will be searched,		
P22.01	Speed of spindle	and then it will switch over to position control	10.00Hz	0
	orientation	orientation.		
		Setting range: 0.00–100.00Hz		
		DEC time of spindle orientation.		
		Spindle orientation deceleration time means the		
P22.02	DEC time of spinale	time needed for the VFD to decelerate from	3.0s	0
	orientation	Max. output frequency (P00.03) to 0Hz.		
		Setting range: 0.0–100.0s		
<b>D</b> 00.00	Spindle zeroing	You can select four spindle zeroing positions by	0	
P22.03	position 0	terminals (functions 46 and 47).	0	0

Setting range: 0-65535         O           P22.04         Spindle zeroing position 1         Setting range: 0-65535         0         O           P22.05         Spindle zeroing position 2         Setting range: 0-65535         0         O         O           P22.06         Spindle zeroing position 3         Setting range: 0-65535         0         O         O           P22.07         Spindle zeroing position 3         Setting range: 0.065535         0         O         O           P22.07         scale-division angle angles by terminals (functions 48, 49, and 50).         15.00         O         O           P22.08         scale-division angle scale-division angle Setting range: 0.00–359.99         30.00         O         O           P22.09         Spindle scale-division angle Setting range: 0.00–359.99         45.00         O         O           P22.09         Spindle scale-division angle Setting range: 0.00–359.99         90.00         O         O           P22.10         scale-division angle Setting range: 0.00–359.99         90.00         O         O           4         Spindle         Spindle         Setting range: 0.00–359.99         120.00         O           5         Spindle         Spindle         Setting range: 0.00–359.99         180.00         O     <	Function code	Name	Description	Default	Modify
P22.04       Spindle zeroing position 1       Setting range: 0–65535       0       0         P22.05       Spindle zeroing position 2       Setting range: 0–65535       0       0         P22.06       Spindle zeroing position 3       Setting range: 0–65535       0       0         P22.07       Spindle zeroing position 3       Setting range: 0–65535       0       0         P22.07       Spindle       You can select seven spindle scale-division scale-division angle       Setting range: 0.00–359.99       15.00       0         P22.08       Scale-division angle       Setting range: 0.00–359.99       30.00       0         P22.09       Spindle scale-division angle       Setting range: 0.00–359.99       45.00       0         P22.10       scale-division angle       Setting range: 0.00–359.99       60.00       0         Spindle       Spindle       Setting range: 0.00–359.99       90.00       0         P22.10       scale-division angle       Setting range: 0.00–359.99       90.00       0         Spindle       Spindle       Setting range: 0.00–359.99       120.00       0         Spindle       Spindle       Setting range: 0.00–359.99       120.00       0         6        1       0       0       0 <td></td> <td></td> <td>Setting range: 0–65535</td> <td></td> <td></td>			Setting range: 0–65535		
P22.05Spindle zeroing position 2Setting range: 0-655350P22.06Spindle zeroing position 3Setting range: 0-655350P22.07Scale-division angle scale-division angle scale-division angle scale-division angle SpindleYou can select seven spindle scale-division angles by terminals (functions 48, 49, and 50).15.00P22.07Scale-division angle SpindleSetting range: 0.00-359.9930.000P22.08Scale-division angle SpindleSetting range: 0.00-359.9930.000P22.09Scale-division angle SpindleSetting range: 0.00-359.9945.000P22.10scale-division angle SpindleSetting range: 0.00-359.9960.000P22.11scale-division angle SpindleSetting range: 0.00-359.9990.000P22.12scale-division angle SpindleSetting range: 0.00-359.9990.000Spindle P22.11Scale-division angle Setting range: 0.00-359.99120.000Spindle P22.12Scale-division angle Setting range: 0.00-359.99120.000Spindle P22.13Scale-division angle Setting range: 0.00-359.99120.000P22.14Spindle Spindle P22.15Setting range: 0.00-359.99180.000P22.14Spindle drive ratio ANue to set the reduction ratio of the spindle and the mounting shaft of the encoder. Setting range: 0.000-30.0001.000P22.15Spindle zero-point Setting range: 0.300-30.000P22.150P22.15Spindle z	P22.04	Spindle zeroing position 1	Setting range: 0–65535	0	0
P22.06Spindle zeroing position 3Setting range: 0-655350P22.07SpindleYou can select seven spindle scale-division angles by terminals (functions 48, 49, and 50).15.00P22.07Scale-division angle SpindleSetting range: 0.00–359.990P22.08Scale-division angle SpindleSetting range: 0.00–359.9930.00P22.09scale-division angle Scale-division angle SpindleSetting range: 0.00–359.9945.00P22.09scale-division angle Scale-division angle SpindleSetting range: 0.00–359.9945.00P22.10scale-division angle Scale-division angle Scale-division angle Setting range: 0.00–359.9960.0004Spindle P22.11Scale-division angle Scale-division angle Setting range: 0.00–359.9990.0005Spindle P22.12Scale-division angle Scale-division angle Setting range: 0.00–359.99120.0006Spindle P22.12Scale-division angle Setting range: 0.00–359.99120.0006Spindle P22.13Scale-division angle Setting range: 0.00–359.99180.0007Used to set the reduction ratio of the spindle and the mounting shaft of the encoder. Setting range: 0.000–30.0001.0000922.14Spindle drive ratio And the mounting shaft of the encoder. Setting range: 0.000–30.0001.0000922.15Sus ed to set spindle zero point is P22.03, the communication setting P22.15P22.15. Setting range: 0-399990	P22.05	Spindle zeroing position 2	Setting range: 0–65535	0	0
SpindleYou can select seven spindle scale-division angles by terminals (functions 48, 49, and 50). 115.00P22.07Scale-division angle scale-division angle 2Setting range: 0.00–359.9930.00P22.08Scale-division angle Scale-division angle Scale-division angle 3Setting range: 0.00–359.9930.00P22.09Scale-division angle Scale-division angle Spindle Scale-division angle Setting range: 0.00–359.9945.000P22.09Scale-division angle Spindle Scale-division angle Spindle Scale-division angle Setting range: 0.00–359.9960.000P22.10Scale-division angle Spindle Scale-division angle Spindle Scale-division angle Setting range: 0.00–359.9990.000P22.11Scale-division angle Spindle Spindle Scale-division angle Setting range: 0.00–359.9990.000P22.12Scale-division angle Spindle Spindle P22.13Setting range: 0.00–359.99120.000P22.14Spindle Spindle Spindle P22.14Setting range: 0.00–359.99180.000P22.14Spindle drive ratio Spindle drive ratio communication setting range: 0.000–30.000180.000P22.15Spindle zero-point final spindle zero point is P22.03, the final spindle zero point will be the sum of P22.03 and P22.15. Setting range: 0.399990	P22.06	Spindle zeroing position 3	Setting range: 0–65535	0	0
Spindle P22.08Spindle scale-division angleSetting range: 0.00–359.9930.0002Spindle P22.09Scale-division angleSetting range: 0.00–359.9945.000333000333009330093000330003300093000940004300043300940004330094000105300113330012333001233330012333300123333333123333333123333333123333333123333333123333333123333333<	P22.07	Spindle scale-division angle 1	You can select seven spindle scale-division angles by terminals (functions 48, 49, and 50). Setting range: 0.00–359.99	15.00	0
Spindle P22.09Spindle scale-division angle SpindleSetting range: 0.00-359.9945.00P22.10Spindle scale-division angle 4Setting range: 0.00-359.9960.0004Spindle P22.11Spindle scale-division angle 5Setting range: 0.00-359.9990.0005Spindle P22.12Scale-division angle scale-division angle 5Setting range: 0.00-359.9990.000650007Spindle P22.13Setting range: 0.00-359.99120.000670007Used to set the reduction ratio of the spindle 	P22.08	Spindle scale-division angle 2	Setting range: 0.00–359.99	30.00	0
Spindle P22.10Spindle scale-division angle 4Setting range: 0.00–359.9960.00O4Spindle P22.11Spindle scale-division angle 5Setting range: 0.00–359.9990.00O55Spindle 	P22.09	Spindle scale-division angle 3	Setting range: 0.00–359.99	45.00	0
Spindle       Spindle         P22.11       scale-division angle       Setting range: 0.00–359.99       90.00       0         5       Spindle       Spindle       120.00       0         P22.12       scale-division angle       Setting range: 0.00–359.99       120.00       0         6       6       120.00       0       0         P22.13       scale-division angle       Setting range: 0.00–359.99       180.00       0         7       Vised to set the reduction ratio of the spindle and the mounting shaft of the encoder.       1.000       0         P22.14       Spindle drive ratio       Used to set the reduction ratio of the spindle and the mounting shaft of the encoder.       1.000       0         P22.15       Spindle zero-point       If the selected spindle zero point is P22.03, the final spindle zero point will be the sum of 0       0       0         P22.15       Setting range: 0.39999       0       0       0	P22.10	Spindle scale-division angle 4	Setting range: 0.00–359.99	60.00	0
Spindle       Spindle         P22.12       scale-division angle       Setting range: 0.00–359.99       120.00       0         6       Spindle       Spindle       120.00       0         P22.13       scale-division angle       Setting range: 0.00–359.99       180.00       0         7       Vised to set the reduction ratio of the spindle       180.00       0         P22.14       Spindle drive ratio       Used to set the reduction ratio of the spindle       1.000       0         P22.14       Spindle drive ratio       Setting range: 0.000–30.000       0       0       0         P22.15       is used to set spindle zero-point offset.       If the selected spindle zero point is P22.03, the       0       0         P22.15       Setting range: 0–39999       Setting range: 0–39999       0       0       0	P22.11	Spindle scale-division angle 5	Setting range: 0.00–359.99	90.00	0
Spindle       Spindle         P22.13       scale-division angle       Setting range: 0.00–359.99       180.00       0         7       Velocity       Used to set the reduction ratio of the spindle and the mounting shaft of the encoder.       1.000       0         P22.14       Spindle drive ratio       used to set the reduction ratio of the spindle and the mounting shaft of the encoder.       1.000       0         Spindle zero-point       F22.15 is used to set spindle zero-point offset.       If the selected spindle zero point is P22.03, the final spindle zero point will be the sum of 0       0         P22.15       Setting range: 0–39999       0       0	P22.12	Spindle scale-division angle 6	Setting range: 0.00–359.99	120.00	0
P22.14       Spindle drive ratio       Used to set the reduction ratio of the spindle and the mounting shaft of the encoder.       1.000       0         Setting range: 0.000–30.000       Setting range: 0.000–30.000       P22.15 is used to set spindle zero-point offset.       1       If the selected spindle zero point is P22.03, the final spindle zero point will be the sum of 0       0       0         P22.15       Setting range: 0-39999       Setting range: 0-39999       0       0       0	P22.13	Spindle scale-division angle 7	Setting range: 0.00–359.99	180.00	0
P22.15 is used to set spindle zero-point offset.         Spindle zero-point       If the selected spindle zero point is P22.03, the final spindle zero point will be the sum of 0         P22.15       Setting         P22.03 and P22.15.         Setting range: 0–39999	P22.14	Spindle drive ratio	Used to set the reduction ratio of the spindle and the mounting shaft of the encoder. Setting range: 0.000–30.000	1.000	0
P22.16 Percented	P22.15	Spindle zero-point communication setting	P22.15 is used to set spindle zero-point offset. If the selected spindle zero point is P22.03, the final spindle zero point will be the sum of P22.03 and P22.15. Setting range: 0–39999	0	0

Function	Name	Description	Default	Modify
code				
P22.17	Reserved	-	-	-
P22.18	Rigid tapping selection	0x00–0x31 Ones place: Enabling selection 0: Disable 1: Enable Tens place: Analog port selection 0: Disable 1: Al1 2: Al2 3: Al3	0x00	Ø
P22.19	Analog filter time of rigid tapping	0.0ms–1000.0ms	1.0ms	0
P22.20	Max. frequency of rigid tapping	0.00–400.00Hz	50.00Hz	0
P22.21	Corresponding frequency of analog zero drift of rigid tapping	0.00–10.00Hz	0.00Hz	0
P22.22- P22.24	Reserved	-	-	-

## Group P23—Vector control of motor 2

Function code	Name	Description	Default	Modify
P23.00	Speed-loop proportional gain 1		20.0	0
P23.01	Speed-loop integral time 1	The parameters P23.00-P23.05 are applicable	0.200s	0
P23.02	Low-point frequency for switching	only to vector control mode. Below the switching frequency 1 (P23.02), the speed-loop PI parameters are: P23.00 and P23.01. Above	5.00Hz	0
P23.03	Speed-loop proportional gain 2	speed-loop PI parameters are: P23.03 and	20.0	0
P23.04	Speed-loop integral time 2	to the linear change of two groups of	0.200s	0
P23.05	High-point frequency for switching		10.00Hz	0

Function code	Name	Description	Default	Modify
		PI parameters (P23.00,P23.01) P23.02 P23.05 Output frequency f The speed loop dynamic response characteristics of vector control can be adjusted by setting the proportional coefficient and integral time of speed regulator. Increasing proportional gain or reducing integral time can accelerate dynamic response of speed loop; however, if the proportional gain is too large or integral time is too small, system oscillation and overshoot may occur; If proportional gain is too small, stable oscillation or speed offset may occur. PI parameters have a close relationship with the inertia of the system. Adjust PI parameters depending on different loads to meet various demands. Setting range of P23.02: 0.00Hz–P23.05 Setting range of P23.03: 0.0–200.0 Setting range of P23.04: 0.000–10.000s Setting range of P23.05: P23.02–P00.03 (Max. output frequency)		
P23.06	Speed-loop output filter	0–8 (corresponding to 0–2 <sup>8</sup> /10ms)	0	0
P23.07	Electromotive slip compensation coefficient of vector control	Slip compensation coefficient is used to adjust the slip frequency of the vector control and improve the speed control accuracy of the system. Adjusting the parameter property can	100%	0
P23.08	Vector control slip compensation coefficient (for	control the speed steady-state error. Setting range: 50–200%	100%	0

Function code	Name	Description	Default	Modify
	power generation)			
	Current-loop	Note:		
P23.09	proportional	• The two function codes impact the dynamic	1000	0
	coefficient P	response speed and control accuracy of		
P23.10	Current-loop integral coefficient l	<ul> <li>the system. Generally, you do not need to modify the two function codes.</li> <li>Applicable to SVC mode 0 (P00.00=0), SVC mode 1 (P00.00=1), and FVC mode (P00.00=3).</li> <li>Setting range: 0–65535</li> </ul>	1000	0
P23.11	Speed-loop differential gain	0.00–10.00s	0.00s	0
P23.12	Proportional coefficient of high-frequency current loop	In the FVC mode (P00.00=3), when the frequency is lower than the current-loop high-frequency switching threshold (P23.14), the current-loop PI parameters are P23.09 and	1000	0
P23.13	Integral coefficient of high-frequency current loop	P23.10; and when the frequency is higher than the current-loop high-frequency switching threshold, the current-loop PI parameters are	1000	0
P23.14	Current-loop high-frequency switching threshold	P23.12 and P23.13. Setting range of P23.12: 0–65535 Setting range of P23.13: 0–65535 Setting range of P23.14: 0.0–100.0% (of the max. frequency)	100.0%	0
P23.15– P23.19	Reserved	-	-	-

## Group P24—Encoder of motor 2

Function code	Name	Description	Default	Modify
P24.00	Encoder type display	0: Incremental encoder 1: Resolver-type encoder 2: Sin/Cos encoder 3: Endat absolute encoder	0	•
P24.01	Encoder pulse count	Number of pulses generated when the encoder revolves for one circle. Setting range: 0–60000	1024	O
P24.02	Encoder direction	0x000–0x111	0x000	O

Function code	Name	Description	Default	Modify
		Ones place: AB direction 0: Forward		
		1: Reverse		
		Tens place: Z pulse direction (reserved)		
		0: Forward		
		1: Reverse		
		Hundreds place: CD/UVW pole signal direction		
		0: Forward		
		1: Reverse		
	Encoder			
P24.03	disconnection fault detection time	0.0–10.0s	2.0s	0
P24.04	Encoder reversal fault detection time	0.0–100.0s	0.8s	0
P24.05	Filter times of encoder detection	Setting range: 0x00–0x99 Ones place: Low-speed filter time, corresponding to 2^(0–9)×125µs. Tens place: High-speed filter times, corresponding to 2^(0–9)×125µs.	0x33	0
	Speed ratio	You need to set the function parameter when		
	between encoder	the encoder is not installed on the motor shaft		
P24.06	mounting shaft and	and the drive ratio is not 1.	1.000	0
	motor	Setting range: 0.001–65.535		
P24.07	motor Control parameters of SM	Setting range: 0.001–65.535 0x0000–0xFFFF Bit0: Enable Z pulse calibration Bit1: Enable encoder angle calibration Bit2: Enable SVC speed measurement Bit3: Reserved Bit4: Reserved Bit5: Reserved Bit6: Enable the CD signal calibration Bit7: Reserved Bit8: Do not detect encoder faults during autotuning Bit 9: Enable Z pulse detection optimization Bit10: Enable the initial Z pulse calibration optimization Bit11: Reserved	0x0003	0

Function code	Name	Description	Default	Modify
		Bit12: Clear the Z pulse arrival signal after stop Bit13: Reserved Bit14: Detect Z pulse after one rotation Bit15: Reserved		
P24.08	Enable Z pulse offline detection	0x00–0x11 Ones place: Z pulse detection 0: No detection 1: Enable Tens place: UVW pulse detection (for SM) 0: No detection 1: Enable	0x10	0
P24.09	Initial angle of Z pulse	Relative electric angle between the encoder Z pulse and the motor pole position. Setting range: 0.00–359.99	0.00	0
P24.10	Pole initial angle	Relative electric angle between the encoder position and the motor pole position. Setting range: 0.00–359.99	0.00	0
P24.11	Initial pole angle autotuning	<ul> <li>0-3</li> <li>1: Rotary autotuning (DC braking)</li> <li>2: Static autotuning (suitable for resolver-type encoder, sin/cos with CD signal feedback)</li> <li>3: Rotary autotuning (initial angle identification)</li> </ul>	0	Ø
P24.12	Speed measurement optimization selection	0: No optimization 1: Optimization mode 1 2: Optimization mode 2	1	Ø
P24.13	CD signal zero offset gain	0–65535	0	0
P24.14	Encoder type selection	0x00–0x11 Ones place: Incremental encoder 0: Without UVW 1: with UVW Tens place: Sin/Cos encoder 0: Without CD signal 1: with CD signal	0x00	Ø
P24.15	Speed measurement mode	0: PG card 1: Locally measured through HDIA and HDIB. Only the 24V incremental encoders are	0	O

Function code	Name	Description	Default	Modify
		supported.		
P24.16	Frequency division coefficient	0–255	0	0
P24.17	Pulse filter handling selection	0x0000–0xFFFF Bit0: Enable/disable encoder input filter 0: Disable 1: Enable Bit1: Encoder signal filter mode (set bit0 or bit2 to 1) 0: Self-adaptive filter 1: Use P24.18 as the filter parameter Bit2: Enable/disable encoder frequency-division output filter 0: Disable 1: Enable Bit3: Reserved Bit4: Enable/disable pulse reference filter 0: Disable 1: Enable Bit5: Pulse reference filter mode (valid when bit4 is set to 1) 0: Self-adaptive filter 1: Use P24.19 as the filter parameter Bit6–15: Reserved	0x0033	0
P24.18	Encoder pulse filter width	0–63 The filter time is P24.18*0.25µs. The value 0 or 1 indicates 0.25µs.	2	0
P24.19	Pulse reference filter width	0–63 The filter time is P24.19*0.25µs. The value 0 or 1 indicates 0.25µs.	2	0
P24.20	Pulse number of pulse reference	0–16000	1024	O
P24.21	Enabling SM angle compensation	0–1	1	0
P24.22	Frequency point of speed measurement mode switchover	0–630.00Hz	1.00Hz	0

Function code	Name	Description	Default	Modify
P24.23	SM angle compensation coefficient	-200.0–200.0%	100.0%	0
P24.24	Number of pole pairs in initial pole angle autotuning	1–128	2	O

## Group P25---I/O card input functions

Function code	Name	Description	Default	Modify
P25.00	HDI3 input type	0: HDI3 is high-speed pulse input 1: HDI3 is digital input	0	O
P25.01	Function of S5		0	O
P25.02	Function of S6		0	O
P25.03	Function of S7		0	O
P25.04	Function of S8	Same as the description for P05	0	O
P25.05	Function of S9		0	O
P25.06	Function of S10		0	O
P25.07	Function of HDI3		0	O
P25.08	Expansion card input terminal polarity	0x00–0x7F	0x00	0
P25.09	Expansion card virtual terminal setting	0x00–0x7F (0: Disable. 1: Enable) Bit0: S5 virtual terminal Bit1: S6 virtual terminal Bit2: S7 virtual terminal Bit3: S8 virtual terminal Bit4: S9 virtual terminal Bit5: S10 virtual terminal Bit6: HDI3 virtual terminal	0x00	O
P25.10	HDI3 switch-on delay		0.000s	0
P25.11	HDI3 switch-off delay	The tunction codes specify the delay time corresponding to the electrical level changes	0.000s	0
P25.12	S5 switch-on delay	when the programmable input terminals switch	0.000s	0
P25.13	S5 switch-off delay	on or switch off.	0.000s	0
P25.14	S6 switch-on delay		0.000s	0

Function	Name	Description	Default	Modify
Dos 15	S6 quitab off dolou		0.000a	0
P25.15	So switch on delay		0.0005	0
P25.10	S7 switch off delay	Si valid i invalid /// valid////////////////////////////////////	0.0005	0
P20.17	S7 Switch on delay	delay delay	0.000s	0
P25.10	S8 switch off dolay	Setting range: 0.000–50.000s	0.0005	0
P25.19	So switch on delay		0.0005	0
P25.20	S9 switch off delay		0.0005	0
F23.21	S10 cwitch on		0.0005	0
P25.22	delay		0.000s	0
P25.23	S10 switch-off delay		0.000s	0
P25.24	Lower limit value of Al3	The function codes define the relationship between the analog input voltage and its	0.00V	0
P25.25	Corresponding setting of AI2 lower limit	corresponding setting. When the analog input voltage exceeds the range from the upper limit to the lower limit, the upper limit or lower limit is	0.0%	0
P25.26	Upper limit value of Al3	used. When the analog input is current input, 0mA–	10.00V	0
P25.27	Corresponding setting of AI3 upper limit	20mA current corresponds to 0V–10V voltage. In different applications, 100.0% of the analog setting corresponds to different nominal values.	100.0%	0
P25.28	AI3 input filter time	See the descriptions of each application section	0.030s	0
P25.29	Lower limit value of Al4	for details. The following figure illustrates the cases of	0.00V	0
P25.30	Corresponding setting of AI4 lower limit	Several settings: 100% Al3/Al4	0.0%	0
P25.31	Upper limit value of Al4		10.00V	0
P25.32	Corresponding setting of AI4 upper limit	-100%	100.0%	0
P25.33	Al4 input filter time	Input filter time: to adjust the sensitivity of analog input. Increasing the value properly can enhance analog input anti-interference but may reduce the sensitivity of analog input.	0.030s	0

Function code	Name	Description	Default	Modify
code		Note: Al3 and Al4 can support 0–10V/0–20mA input. When Al3 and Al4 select 0–20mA input, the corresponding voltage of 20mA is 10V. Setting range of P25.24: 0.00V–P25.26 Setting range of P25.25: -300.0%–300.0% Setting range of P25.26: P25.24–10.00V Setting range of P25.27: -300.0%–300.0% Setting range of P25.28: 0.000S–10.000S Setting range of P25.29: 0.00V–P25.31 Setting range of P25.30: -300.0%–300.0% Setting range of P25.31: P25.29–10.00V Setting range of P25.32: -300.0%–300.0% Setting range of P25.33: 0.000S–10.000S		
P25.34	HDI3 high-speed pulse input function selection	0: Input set through frequency 1: Counting function	0	O
P25.35	HDI3 lower limit frequency	0.000 kHz – P25.37	0.000 kHz	0
P25.36	Corresponding setting of HDI3 lower limit frequency	-300.0%–300.0%	0.0%	0
P25.37	HDI3 upper limit frequency	P25.35–50.000kHz	50.000 kHz	0
P25.38	Corresponding setting of HDI3 upper limit frequency	-300.0%–300.0%	100.0%	0
P25.39	HDI3 frequency input filter time	0.000s–10.000s	0.030s	0
P25.40	Al3 input signal type	Range: 0–1 0: Voltage 1: Current	0	0
P25.41	Al4 input signal type	Range: 0–1 0: Voltage 1: Current	0	0
P25.42- P25.45	Reserved	-	-	-

Function code	Name	Description	Default	Modify
P26.00	HDO2 output type	0: Open collector high-speed pulse output 1: Open collector output	0	O
P26.01	HDO2 output selection		0	0
P26.02	Y2 output		0	0
P26.03	Y3 output		0	0
P26.04	RO3 output		0	0
P26.05	RO4 output		0	0
P26.06	RO5 output	Same as the description for P06.01	0	0
P26.07	RO6 output		0	0
P26.08	RO7 output		0	0
P26.09	RO8 output		0	0
P26.10	RO9 output		0	0
P26.11	RO10 output		0	0
P26.12	Expansion card output terminal polarity	Bit0: Y2 Bit1: Y3 Bit2: HDO2 Bit3: RO3 Bit4: RO4 Bit5: RO5 Bit6: RO6 Bit7: RO7 Bit8: RO8 Bit9: RO9 Bit10: RO10 Bit11: RO11 Bit12: RO12	0x0000	0
P26.13	HDO2 switch-on delay	Used to specify the delay time corresponding to	0.000s	0
P26.14	HDO2 switch-off delay	the electrical level changes when the programmable output terminals switch on or	0.000s	0
P26.15	Y2 switch-on delay	switch off.	0.000s	0
P26.16	Y2 switch-off delay	Y electric level	0.000s	0
P26.17	Y3 switch-on delay	Y validIvalidValid	0.000s	0
P26.18	Y3 switch-off delay	delay delay	0.000s	0
P26.19	RO3 switch-on	Setting range: 0.000–50.000s	0.000s	0

Function code	Name	Description	Default	Modify
	delay	Note: P26.13 and P26.14 are valid only when		
P26.20	RO3 switch-off delay	P26.00=1.	0.000s	0
P26.21	RO4 switch-on delay		0.000s	0
P26.22	RO4 switch-off delay		0.000s	0
P26.23	RO5 switch-on delay		0.000s	0
P26.24	RO5 switch-off delay		0.000s	0
P26.25	RO6 switch-on delay		0.000s	0
P26.26	RO6 switch-off delay		0.000s	0
P26.27	RO7 switch-on delay		0.000s	0
P26.28	RO7 switch-off delay		0.000s	0
P26.29	RO8 switch-on delay		0.000s	0
P26.30	RO8 switch-off delay		0.000s	0
P26.31	RO9 switch-on delay		0.000s	0
P26.32	RO9 switch-off delay		0.000s	0
P26.33	RO10 switch-on delay		0.000s	0
P26.34	RO10 switch-off delay		0.000s	0
P26.35	AO2 output		0	0
P26.36	AO3 output selection	Same as the description for P06.14	0	0
P26.38	AO2 output lower limit	The function codes define the relationship	0.0%	0
P26.39	AO2 output corresponding to lower limit	When the output value exceeds the allowed range, the output uses the lower limit or upper	0.00V	0

Function code	Name	Description	Default	Modify
P26.40	AO2 output upper limit	limit. When the analog output is current output, 1mA	100.0%	0
P26.41	AO2 output corresponding to upper limit	equals 0.5V. In different cases, the corresponding analog output of 100% of the output value is different.	10.00V	0
P26.42	AO2 output filter time	▲ 10V (20mA) AO	0.000s	0
P26.43	AO3 output lower limit		0.0%	0
P26.44	AO3 output corresponding to lower limit	0.0%	0.00V	0
P26.45	AO3 output upper limit	Setting range of P26.38: -300.0%–P26.40 Setting range of P26.39: 0.00V–10.00V	100.0%	0
P26.46	AO3 output corresponding to upper limit	Setting range of P26.40: P26.38–300.0% Setting range of P26.41: 0.00V–10.00V Setting range of P26.42: 0.000s–10.000s	10.00V	0
P26.47	AO3 output filter time	Setting range of P26.43: -300.0%–P26.45 Setting range of P26.44: 0.00V–10.00V Setting range of P26.45: P26.43–300.0% Setting range of P26.46: 0.00V–10.00V Setting range of P26.47: 0.000s–10.000s	0.000s	0
P26.48- P26.52	Reserved	-	-	-

## Group P27—Programmable expansion card functions

Function code	Name	Description	Default	Modify
P27.00	Enabling programmable card	0–1 The function code is used to enable the programmable card function. This function is reserved.	0	O
P27.01	I_WrP1	0–65535 The function code is used for the VFD to write a value to WrP1 of the programmable card.	0	0
P27.02	I_WrP2	0–65535 The function code is used for the VFD to write a value to WrP2 of the programmable card.	0	0

Function code	Name	Description	Default	Modify
		0–65535		
P27.03	I_WrP3	The function code is used for the VFD to write	0	0
		a value to WrP3 of the programmable card.		
		0–65535		
P27.04	I_WrP4	The function code is used for the VFD to write	0	0
		a value to WrP4 of the programmable card.		
		0–65535		
P27.05	I_WrP5	The function code is used for the VFD to write	0	0
		a value to WrP5 of the programmable card.		
		0–65535		
P27.06	I_WrP6	The function code is used for the VFD to write	0	0
	_	a value to WrP6 of the programmable card.		
		0–65535		
P27.07	I WrP7	The function code is used for the VFD to write	0	0
	_	a value to WrP7 of the programmable card.		
		0–65535		
P27.08	I WrP8	The function code is used for the VFD to write	0	0
		a value to WrP8 of the programmable card.		-
		0–65535		
P27.09	I WrP9	The function code is used for the VFD to write	0	0
	1_001 3	a value to WrP9 of the programmable card.	-	-
		0-65535		
P27 10	I WrP10	The function code is used for the VED to write	0	0
12/110	1_11110	a value to WrP10 of the programmable card	Ŭ	0
		I lsed to display the status of the programmable		
P27 11	Programmable card	card	0	•
	status	0: Stop	Ŭ	•
		1: Bun		
		0–65535		
P27.12	C_MoP1	The function code is used for the VFD to	0	•
	_	monitor/view the MoP1 value of the PLC.		
		0–65535		
P27.13	C_MoP2	The function code is used for the VFD to	0	•
		monitor/view the MoP2 value of the PLC.		
D07.4.4	C MaD2	0-65535	0	
P27.14	C_IVIOP3	monitor/view the MoP3 value of the PLC	U	
P27.15	C MoP4	0–65535	0	•

Function code	Name	Description	Default	Modify
		The function code is used for the VFD to monitor/view the MoP4 value of the PLC.		
P27.16	C_MoP5	0–65535 The function code is used for the VFD to monitor/view the MoP5 value of the PLC.	0	•
P27.17	C_MoP6	0–65535 The function code is used for the VFD to monitor/view the MoP6 value of the PLC.	0	•
P27.18	C_MoP7	0–65535 The function code is used for the VFD to monitor/view the MoP7 value of the PLC.	0	•
P27.19	C_MoP8	0–65535 The function code is used for the VFD to monitor/view the MoP8 value of the PLC.	0	•
P27.20	C_MoP9	0–65535 The function code is used for the VFD to monitor/view the MoP9 value of the PLC.	0	•
P27.21	C_MoP10	0–65535 The function code is used for the VFD to monitor/view the MoP10 value of the PLC.	0	•
P27.22	Digital input terminal state of programmable card	0x00–0x3F The function code is used to display the input terminal status on the programmable card. Bit5–bit0 indicate PS6–PS1.	0x00	•
P27.23	Digital output terminal state of programmable card	0x0–0x3 The function code is used to display the output terminal status on the programmable card. Bit0 indicates PRO1, and bit1 indicates PRO2.	0x0	•
P27.24	AI1 of the programmable card	0–10.00V/0.00–20.00mA The function code is used to display the Al1 value from the programmable card.	0	•
P27.25	AO1 of the programmable card	0–10.00V/0.00–20.00mA The function code is used to display the AO1 value from the programmable card.	0	•
P27.26	Length of data sent by programmable card and PZD communication object	0x00–0x28 Ones place: Quantity of data sent from the programmable card and VFD (that is, quantity of data sent from the programmable card + from VFD sending table 1 + from VFD sending table 2)	0x03	0

## Goodrive350 IP55 High-ingress Protection Series VFD

Function code	Name	Description	Default	Modify
		0: 0+24+60		
		1: 12+24+60		
		2: 24+24+60		
		3: 36+24+60		
		4: 48+24+60		
		5: 60+48+60		
		6: 72+24+60		
		7: 84+24+60		
		8: 96+96+96		
		Tens place: Card that communicates with the		
		programmable card through PZD (valid only		
		when the ones place of P27.26 is 5)		
		0: DP card		
		1: CANopen card		
		2: PN card		
		Note: P27.26 can be changed at any time, but		
		the change will only take effect after the		
		re-power on.		
	Programmable card	0–1		
P27.27	save function at	0: Disable	1	O
	power off	1: Enable		

## Group P28---Master/slave control

Function code	Name	Description	Default	Modify
P28.00	Master/slave mode	0: Master/slave control is invalid. 1: The local device is the master. 2: The local device is the slave.	0	O
P28.01	Master/slave communication data selection	0: CAN 1: Reserved	0	O
P28.02	Master/slave control mode	0x000–0x112 Ones place: Master/slave running mode selection 0: Master/slave mode 0 (The master and slave adopt speed control and maintain the power balance by droop control.) 1: Master/slave mode 1	0x001	Ø

Function code	Name	Description	Default	Modify
		(The master and slave must be in the same type of vector control mode. When the master is in speed control, the slave is forced into torque control.) 2: Master/slave mode 2 The slave switches from speed mode (master/slave mode 0) to torque mode (master/slave mode 1) at a frequency point. Tens place: Slave start command source 0: Master 1: Determined by P00.01 Hundreds place: Whether to enable master/slave to send/receive data 0: Enable 1: Disable		
P28.03	Slave speed gain	0.0–500.0%	100.0%	0
P28.04	Slave torque gain	0.0–500.0%	100.0%	0
P28.05	Frequency point for switching between speed mode and torque mode in master/slave mode 2	0.00–10.00Hz	5.00Hz	0
P28.06	Slave count	0–15	1	O
P28.07- P28.08	Reserved	-	-	-
P28.09	CAN slave torque offset	-100.0–100.0(%)	0.0%	0
P28.10	Enabling EC PT100/PT1000 to detect temperature	0x00–0x11 Ones place: PT100 temperature detection 0: Disable 1: Enable Tens place: PT1000 temperature detection 0: Disable 1: Enable	0x00	0
P28.11	EC PT100 detected OH protection threshold	0.0–150.0°C	120.0°C	0

Function code	Name	Description	Default	Modify
	EC PT100 detected			
P28.12	OH pre-alarm	0.0–150.0°C	100.0°C	0
	threshold			
	EC PT100 detected			
D00.40	temperature	50.0.450.000	400.000	$\sim$
P28.13	calibration upper	50.0-150.0°C	120.0°C	0
	limit			
	EC PT100 detected			
P28 1/	temperature	-20.0.50.0°C	10.0%	$\cap$
1 20.14	calibration lower	-20.0-30.0 C	10.0 C	U
	limit			
	EC PT100			
P28.15	calibration upper	0–4096	2950	0
	limit digital			
500.40	EC PT100			
P28.16	calibration lower	0–4096	1270	0
	limit digital			
D00.47	EC PT1000	0.0.450.000	400.000	$\sim$
P28.17	detected OH	0.0-150.0°C	120.0°C	0
D20 10	ec PT1000	0.0.150.0%	100.000	$\sim$
F20.10	Dre-alarm threshold	0.0–150.0 C	100.0 C	0
	FC PT1000			
	detected			
P28.19	temperature	50.0–150.0°C	120.0°C	0
	calibration upper		.20.0 0	Ũ
	limit			
	EC PT1000			
	detected			
P28.20	temperature	-20.0–50.0°C	10.0°C	0
	calibration lower			
	limit			
	EC PT1000			
P28.21	calibration upper	0–4096	3100	0
	limit digital			
	EC PT1000			
P28.22	calibration lower	0–4096	1100	0
	limit digital			

Function code	Name	Description	Default	Modify
P28.23	Detecting for PT100/PT1000 disconnection from EC	0x00–0x11 Ones place: PT100 disconnection detection 0: Disable 1: Enable Tens place: PT1000 disconnection detection 0: Disable 1: Enable	0x00	Ø
P28.24	Enabling digital calibration in EC PT100/PT1000 temperature detection	0–4 0: Disable 1: Enable PT100 lower limit digital calibration 2: Enable PT100 upper limit digital calibration 3: Enable PT1000 lower limit digital calibration 4: Enable PT1000 upper limit digital calibration	0	0
P28.25	Type of sensor for Al/AO to detect motor temperature	0-4 0: No temperature sensor 1: PT100 2: PT1000 3: KTY84 4: PTC Note: Temperature is displayed through P19.21. To measure temperature, switch the output of AO1 to current, and connect one end of the temperature resistor to Al1 and AO1, and the other end to GND.	0	٥
P28.26	AIAO detected motor OT protection threshold	0.0–200.0°C <b>Note:</b> When the motor temperature exceeds the threshold, the VFD releases the OT alarm.	110.0°C	0
P28.27	AIAO detected motor OT pre-alarm threshold	0.0–200.0°C <b>Note:</b> When the motor temperature exceeds the value, the DO terminal with function 48 (AI detected motor OH pre-alarm) outputs a valid signal.	90.0°C	0

## Group P90--Tension control

Function code	Name	Description	Default	Modify
P90.00	Tension control mode	<ul> <li>0: Disable</li> <li>1: Tension speed control</li> <li>2: Open loop tension torque control</li> <li>3: Close-loop tension torque control</li> <li>Note: The value 0 indicates invalid and the</li> <li>VFD implements the general function. A non-zero value indicates enabling the tension control function.</li> </ul>	0	Ø
P90.01	Winding/unwinding mode	0: Winding 1: Unwinding <b>Note:</b> The motor forward rotation direction is the winding direction. When using the tension control mode, check whether the motor rotation direction is correct in the winding mode; if not, change the rotation direction by swapping two phase wires of the motor. After the rotation direction is corrected, the winding mode can be switched to the unwinding mode by setting P90.01 to 1 or changing the winding/unwinding switchover terminals.	0	0
P90.02	Reel mechanical transmission rate	0.01–600.00 =Motor rotation speed/reel rotation speed=Reel diameter/motor shaft diameter	1.00	0
P90.03	Max. linear speed	0.0–6000.0m/min	1000.0 m/min	0
P90.04	Linear speed input source selection	0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI 5: Main traction encoder frequency-division input	0	Ø
P90.05	Linear speed set through keypad	0.0–100.0%	20.0%	0
P90.06	Diameter of main traction	0.0–6000.0mm	99.0mm	0
P90.07	Main traction drive	0.000–60.000	1.000	0

Function code	Name	Description	Default	Modify
	ratio			
P90.08	Linear speed ACC time	0.00–600.00s	0.00s	0
P90.09	Linear speed DEC time	0.00–600.00s	0.00s	0
P90.10	Tension setting source selection	0x00–0x14 Ones place: Tension setting source 0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI Tens place: Multiplication selection of max. tension P90.12 0: 1 1: 10	0x00	٥
P90.11	Tension set through keypad	0.0–100.0%	10.0%	0
P90.12	Max. tension	0–60000 (N, tens place of P90.10=0) When the tens place of P90.10 is 1, the setting range is (0–60000)*10N.	1000	0
P90.13	Roll diameter calculation method selection	0: Not calculated 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI 5: Linear speed 6: Thickness (wire) 7: Thickness (strip)	0	O
P90.14	Roll diameter calculation delay time	0.0–100.0s	1.0s	0
P90.15	Min. rolling diameter	0.0mm–P90.16	50.0mm	0
P90.16	Max. roll diameter	P90.15–5000.0 mm	1000.0 mm	0
P90.17	Initial roll diameter 1	P90.15–P90.16	100.0 mm	0

Function code	Name	Description	Default	Modify
P90.18	Initial roll diameter 2	P90.15–P90.16	100.0 mm	0
P90.19	Initial roll diameter 3	P90.15–P90.16	100.0 mm	0
P90.20	Linear speed roll diameter calculation filter time	0.000–60.000s	2.000s	0
P90.21	Linear speed roll diameter calculation restriction	0x00–0x11 Ones place: 0:No 1: Restrict changes in reverse direction Tens place: 0:No 1: Automatic restriction according to running frequency and material thickness	0x00	0
P90.22	Material thickness	0.001–65.535mm	0.010 mm	0
P90.23	Number of coils per layer	1–10000	1	O
P90.24	Revolution counting function selection	<ul><li>0: Digital terminal input</li><li>1: PG card input (applicable to thickness calculation method)</li><li>2: Running frequency (no input automatic revolution counting)</li></ul>	0	0
P90.25	Number of pulses per revolution	1–60	1	O
P90.26	Roll diameter set value	0.0–100.0%	80.0%	0
P90.27	Roll diameter reset setting	0x0000–0x1111 Ones place: At stop 0: Remain current roll diameter 1: Restore to initial roll diameter Tens place: Power off at running 0: Remain current roll diameter 1: Restore to initial roll diameter Hundreds place: Reach the roll diameter set value	0x1000	0

Function code	Name	Description	Default	Modify
		0: Remain current roll diameter		
		1: Restore to initial roll diameter		
		Thousands place: Terminal reset limitation		
		0: Reset allowed at running		
		1: Reset only allowed at stop		
P90.28	Tension PID output	0: Maximum value	0	0
	reference	1: Given value		
		0: First group of P90		
		1: Roll diameter (max. roll diameter)		
P90.29	Tension PID	2: Main reference frequency (max. Frequency)	0	0
	parameter source	3: Running linear speed (max. linear speed)	-	-
		4: Deviation (Reference 100%)		
		5: Terminal		
P90.30	Group 1 proportional gain	0.000–30.000	0.030	0
P90.31	Group 1 integral	0.00-30.00s	5.00s	0
	time		0.000	Ŭ
P90.32	Group 1 differential time	0.00–10.00s	0.00s	0
P90.33	Group 2	0.000–30.000	0.030	0
	proportional gain			
P90.34	Group 2 integral time	0.00–30.00s	5.00s	0
P90.35	Group 2 differential time	0.00–10.00s	0.00s	0
	PID parameter			
P90.36	adjustment	0.0–P90.37%	10.0%	0
	reference point 1			-
	PID parameter			
P90.37	adjustment	P90.36–100.0%	50.0%	0
	reference point 2			
	Min. frequency for	0.00–50.00Hz		
P90.38	roll diameter	Note: Valid only for linear speed calculation	0.30Hz	0
	calculation	with roll diameter.		
		0.0–100.0%		
P90.39	Min. linear speed	Note: Relative to the max. linear speed.	3.0%	0
1 00.00	calculation	Note: Valid only for linear speed calculation with roll diameter.	0.070	

Group P9	1Tension	control in	torque mode
----------	----------	------------	-------------

Function code	Name	Description	Default	Modify
	Tension control	0–1		
P91.00	zero speed	0: Max. linear speed	0	O
	reference	1: Reserved		
	Tension control			
P91.01	zero speed threshold	0.0–50.0%	0.5%	0
P91.02	Zero speed offset	0.0–50.0%	2.0%	0
		0: P03.14. P03.15		
	Upper-limit	1: Forward rotation limit set by line speed		
P91.03	frequency source of	2: Reverse rotation limit set by line speed	3	O
	torque control	3: Forward and reverse rotations limit set by		_
		line speed		
	Running frequency			
P91.04	upper limit offset of	0.0–100.0%	5.0%	0
	tension control			-
	Differential			
P91.05	separation	0.0–100.0%	5.0%	0
	threshold			
	PID restricts			
P91.06	reverse limit at zero	0: Enable	0	O
	speed	1: Disable		
		0x000–0x111		
		Ones place: Frictional torque compensation		
		0: No		
		1: Yes		
	Torque	Tens place: Inertia compensation		
P91.07	compensation	0: No	0x000	O
	selection	1: Yes		
		Hundreds place: Compensation direction		
		0. In line with torque direction		
		1: Different from torque direction		
		0: No operation		
	System mechanical	1: Enabling system mechanical inertia		
P91.08	parameters	identification	0	O
	identification	2: Enabling mechanical friction torque	-	-
		identification		
P91.09	Static friction	0.0–100.0%	0.0%	0

Function code	Name	Description	Default	Modify
	torque compensation coefficient			
	Sliding friction			
P91.10	torque compensation coefficient 1	0.0–100.0%	0.0%	0
P91.11	Sliding friction torque compensation coefficient 2	0.0–100.0%	0.0%	0
P91.12	Sliding friction torque compensation coefficient 3	0.0–100.0%	0.0%	0
P91.13	High speed torque compensation coefficient	0.0–100.0%	0.0%	0
P91.14	Compensation frequency point of static friction torque	0.0%–P91.15	1.0%	0
P91.15	Compensation frequency point of sliding friction torque 1	P91.14–P91.16%	20.0%	0
P91.16	Compensation frequency point of sliding friction torque 2	P91.15–P91.17%	50.0%	0
P91.17	Compensation frequency point of sliding friction torque 3	P91.16–P91.18%	80.0%	0
P91.18	High-speed friction torque compensation frequency point	P91.17–100.0%	100.0%	0
P91.19	ACC and DEC	0: Linear speed	0	O

Function code	Name	Description	Default	Modify
	frequency source	1: Running frequency		
P91.20	Material density	0–3000kg/m <sup>3</sup>	0kg/m <sup>3</sup>	0
P91.21	Reel width	0.000–60.000m	0.000m	0
P91.22	ACC inertia compensation coefficient	0.0–100.0%	10.0%	0
P91.23	DEC inertia compensation coefficient	0.0–100.0%	10.0%	0
P91.24	Tension taper coefficient source	0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI	0	0
P91.25	Tension taper set through keypad	0.0–100.0%	30.0%	0
P91.26	Tension taper compensation correction	0.0–5000.0mm	0.0mm	0
P91.27	Tension taper curve selection	0: Inverse proportional curve 1: Multi-point curve	0	0
P91.28	Roll diameter value 1	0.0–5000.0mm	200.0 mm	0
P91.29	Tension taper coefficient for roll diameter value 1	0.0–50.0%	3.0%	0
P91.30	Roll diameter value 2	0.0–5000.0mm	500.0 mm	0
P91.31	Tension taper coefficient for roll diameter value 2	0.0–50.0%	7.0%	0
P91.32	Tension offset value at zero speed	0.0–300.0%	0.0%	0
P91.33	Present roll diameter setting	0.0–5000.0mm	0.0mm	O

## Group P92---Tension control optimization functions

Function code	Name	Description	Default	Modify
P92.00	Pre-drive speed gain	0.0–100.0%	100.0%	0
P92.01	Pre-drive torque limit	0–2 0: Set based on P03.20, P03.21 1: Set based on P93.02 2: Set based on the set tension	2	0
P92.02	Pre-drive torque limit setting	0.0–200.0%	100.0%	0
P92.03	Zero bit conversion enabling	0–1 0: Disable 1: Enable	0	O
P92.04	Initial zero bit	0.0–100.0%	10.0%	0
P92.05	Final zero bit	0.0–100.0%	50.0%	0
P92.06	Conversion time from initial zero bit to final zero bit	0.00–60.00s	5.00s	0
P92.07	Conversion time from final zero bit to initial zero bit	0.00–60.00s	5.00s	0
P92.08	Feeding interrupt detection mode	0–3 0: No detection 1: Detect based on digital value 2: Detect based on roll diameter calculation value 3: Detect based on feedback position	0	0
P92.09	Feeding interrupt detection start delay time	0.0–200.0s	20.0s	0
P92.10	Frequency lower limit of feeding interrupt detection	0.00–300.00Hz	10.00Hz	0
P92.11	Error range of feeding interrupt detection	0.1–50.0%	10.0%	0
P92.12	Determination delay time of	0.1–60.0s	1.0s	0

Function code	Name	Description	Default	Modify
	feeding interrupt			
P92.13	Handling mode of feeding interrupt	0x000–0x111 Ones place: Stop mode 0: Decelerate to stop in emergency manner 1: Coast to stop Tens place: Alarm mode 0: Stop in enabled stop mode without reporting an alarm 1: Report an alarm and coast to stop Hundreds place: Roll diameter memory function of feeding interrupt 0: Disable 1: Enable	0x000	0
P92.14	Stop braking frequency	0.00–300.00Hz	1.50Hz	0
P92.15	Stop braking time	0.0–600.0s	0.0s	0

#### Group P93-Tension control status viewing

Function code	Name	Description	Default	Modify
P93.00	Actual control mode	0: Invalid tension control 1: Close-loop tension speed control 2: Open loop tension torque control 3: Close-loop tension torque control	0	•
P93.01	Actual winding/unwinding mode	0: Winding 1: Unwinding	0	•
P93.02	Initial roll diameter	0.0–5000.0mm	0.0mm	
P93.03	Reset roll diameter	0.0–5000.0mm	0.0mm	
P93.04	Roll diameter change rate	0.00–655.35mm/s	0.00 mm/s	•
P93.05	Present roll diameter	0.0–5000.0mm	0.0mm	•
P93.06	Roll diameter for linear speed calculation	0.0–5000.0mm	0.0mm	•

Function code	Name	Description	Default	Modify
P93.07	Set linear speed	0.0–6000.0m/min	0.0m/min	•
P93.08	Present linear speed	0.0–6000.0m/min	0.0m/min	•
P93.09	Main reference frequency	0.00–600.00Hz	0.00Hz	•
P93.10	Actual proportional gain	0.00–30.00	0.00	•
P93.11	Actual integral time	0.00–30.00s	0.00s	•
P93.12	Proportional output value	0–65535	0	•
P93.13	Integral output value	0–65535	0	•
P93.14	PID upper limit	-100.0–100.0%	0.0%	•
P93.15	PID lower limit	-100.0–100.0%	0.0%	•
P93.16	PID output frequency	-99.99–99.99Hz	0.00Hz	•
P93.17	Main traction running frequency	-300.0–300.0Hz	0.0Hz	•
P93.18	Set tension	0–30000N	0N	•
P93.19	Tension taper coefficient	0.0–100.0%	0.0%	•
P93.20	Actual set tension	0–30000N	0N	•
P93.21	Basic torque reference value	-300.0–300.0%	0.0%	•
P93.22	Friction compensation torque value	-300.0–300.0%	0.0%	•
P93.23	System rotational inertia	0.00–655.35kg·m²	0.00 kg⋅m²	•
P93.24	Frequency change rate	-99.99–327.67Hz/s	0.00Hz/s	•
P93.25	Torque compensation value of system rotational inertia	-300.0–300.0%	0.0%	•
P93.26	Reference value after torque	-300.0–300.0%	0.0%	•

Function	Name	Description	Default	Modify
code				
	compensation			
P93.27	PID output torque	-300.0–300.0%	0.0%	•
P93.28	Final output torque	-300.0–300.0%	0.0%	•
P93.29	Measured tension	0–30000N	0N	•
<b>DOD 00</b>	Number of material	400 20707	0	•
P93.30	turns on the reel	-100-32767		
D02.24	Length of material	0.05525-	0.00	
P93.31	on the reel	0-0000011	om	-
P93.32	Length increment	0.0–6553.5m	0.0m	•

# 7 Troubleshooting

### 7.1 What this chapter contains

The chapter tells you how to reset faults and check faults history. A complete list of alarms and fault information as well as possible causes and corrective measures are presented in this chapter.



Only trained and qualified professionals are allowed to carry out the operations mentioned in this chapter. Please carry out operations according to instructions presented in chapter 1 "Safety precautions".

### 7.2 Indications of alarms and faults

The fault is indicated by indicators. See section 5.4 "Operation procedure". When the **TRIP** indicator is on, the alarm or fault code displayed on the keypad indicates the VFD is in abnormal state. This chapter covers most of the alarms and faults, and their possible causes and corrective measures. If you cannot find out the causes of alarms or faults, contact local INVT office.

### 7.3 Fault reset

The VFD can be reset by pressing the keypad key **STOP/RST**, digital inputs, or by cutting off the VFD power. After faults are removed, the motor can be started again.

### 7.4 Fault history

The function codes from P07.27 to P07.32 record the types of the last six faults. The function codes P07.33–P07.40, P07.41–P07.48, and P07.49–P07.56 record the running data of the VFD at the last three faults.

### 7.5 Faults and solutions

When a fault occurred, handle the fault as follows:

- 1. Check whether there is any exception on the keypad. If yes, contact the local INVT office.
- If no, check the function codes in P07 group to determine the real state when the fault occurred.
- 3. Check the following table for the exception and solution.
- 4. Rectify the fault or ask for help.
- 5. After confirming the fault is removed, perform fault reset, and start running.

#### 7.5.1 Faults and solutions

**Note:** The numbers enclosed in square brackets such as [1], [2] and [3] in the Fault type column in the following table indicate the VFD fault type codes read through communication.

Troubleshooting

Fault code	Fault type	Possible cause	Solution
OUt1 OUt2 OUt3	<ul> <li>[1] Inverter unit</li> <li>U-phase</li> <li>protection</li> <li>[2] Inverter unit</li> <li>V-phase</li> <li>protection</li> <li>[3] Inverter unit</li> <li>W-phase</li> <li>protection</li> </ul>	ACC is too fast. IGBT module is damaged. Misoperation caused by interference. Drive wires are poorly connected. To-ground short circuit occurs.	Increase ACC time. Replace the power unit. Check drive wires. Check whether there is strong interference surrounding the peripheral device.
OC1	[4] Overcurrent during ACC	ACC/DEC is too fast.	Increase ACC/DEC time. Check the input power.
OC2	[5] Overcurrent during DEC	The grid voltage is too low. VFD power is too small.	Select a VFD with larger power. Check whether the load is short
OC3	[6] Overcurrent during constant speed running	occurred. To-ground short circuit or output phase loss occurred. Strong external interference sources existed. The overcurrent stall protection is not enabled.	circuited (to-ground short circuit or line-to-line short circuit) or the rotation is not smooth. Check the output wiring. Check whether there is strong interference. Check the settings of related function codes.
OV1	[7] Overvoltage during ACC	Deceleration time is too short.	Check the input power. Check whether load DEC time is
OV2	[8] Overvoltage during DEC	Abnormal input voltage. Large energy feedback. Lack of braking units. Energy-consumption braking disabled. Deceleration time is too short.	too short; or the motor starts during rotating.
OV3	[9] Overvoltage during constant speed running		Install dynamic brake components. Check the settings of related function codes.
UV	[10] Bus undervoltage	The grid voltage is too low. The overvoltage stall protection is not enabled.	Check the grid input power. Check the settings of related function codes.
OL1	[11] Motor overload	Grid voltage too low. Motor rated current is set incorrectly. The motor stall occurs or the load transient is too large.	Check the grid voltage. Reset the rated current of the motor. Check the load and adjust the torque boost quantity.
ULZ		AUU 15 100 1ast.	Increase ACC UITE.

Fault code	Fault type	Possible cause	Solution
	overload	The motor is restarted during rotating. Grid voltage too low. Load is too heavy. Power is too small.	Avoid restart after stop. Check the grid voltage. Select a VFD with larger power. Select a proper motor.
SPI	[13] Phase loss on input side	Phase loss or violent fluctuation occurred on input R, S, T.	Check the input power. Check the installation wiring.
SPO	[14] Phase loss on output side	output (or the three phases of motor is asymmetrical).	Check the output wiring. Check the motor and cable.
OH1	[15] Rectifier module overheating	Air duct blocked or fan damaged. Ambient temperature is too	Ventilate the air duct or replace the fan.
OH2	[16] Inverter module overheat	high. Long-time overload running.	Lower the ambient temperature.
EF	[17] External fault	SI external faulty input terminal action.	Check external device input.
CE	[18] Modbus/Modbus TCP communication fault	Incorrect baud rate. Communication line fault. Incorrect communication address. Communication suffers from strong interference.	Set a proper baud rate. Check the communication port cable. Set the communication address correctly. Replace or change the wiring to enhance the anti-interference capacity.
ltE	[19] Current detection fault	Poor contact of the connector of control board. The Hall component is damaged. Exception occurred to amplification circuit.	Check the connector and re-plug. Replace the hall component. Replace the main control board.
tΕ	[20] Motor autotuning fault	Motor capacity does not match with the VFD capacity. This fault may occur if the capacity difference exceeds five power classes. Incorrect motor parameter setting.	Change the VFD model, or adopt V/F mode for control; Set proper motor type and nameplate parameters. Empty the motor load and re-perform autotuning. Check motor wiring and

Troubleshooting

Fault code	Fault type	Possible cause	Solution
		The parameters gained from autotuning deviate sharply from the standard parameters. Autotuning timeout.	parameter settings. Check whether the upper limit frequency is larger than 2/3 of the rated frequency.
EEP	[21] EEPROM operation fault	Control parameter reading/writing error. EEPROM damaged.	Press STOP/RST to reset. Replace the main control board.
PIDE	[22] PID feedback offline fault	PID feedback offline. PID feedback source disappears.	Check PID feedback signal wires. Check PID feedback source.
bCE	[23] Braking unit fault	Fault occurred to the braking circuit or the braking pipe is damaged. Resistance of the external braking resistor is small.	Check the braking unit, and replace with new braking pipe; Increase the brake resistance.
END	[24] Running time reached	The actual running time of the VFD is longer than the internal set running time.	Ask for the supplier and adjust the set running time.
OL3	[25] Electronic overload fault	The VFD reports overload pre-alarm according to the setting.	Check the load and overload pre-alarm threshold.
PCE	[26] Keypad communication fault	Keypad cable connected improperly or disconnected. Keypad cable too long, causing strong interference. Keypad or mainboard communication circuit error.	Check the keypad cable and re-plug to determine whether a fault occurs. Check for and remove the external interference source. Replace the hardware and seek maintenance services.
UPE	[27] Parameter upload error	Keypad cable connected improperly or disconnected. Keypad cable too long, causing strong interference. Keypad or mainboard communication circuit error.	Check the keypad cable and re-plug to determine whether a fault occurs. Check for and remove the external interference source. Replace the hardware and seek maintenance services.
DNE	[28] Parameter download error	Keypad cable connected improperly or disconnected. Keypad cable too long, causing	Check for and remove the external interference source. Replace the hardware and seek

Fault code	Fault type	Possible cause	Solution	
		strong interference. Data storage error occurred to the keypad.	maintenance services. Re-back up the data on the keypad.	
E-DP	[29] PROFIBUS card communication timeout fault	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped.	
E-NET	[30] Ethernet card communication timeout fault	There is no data transmission between the communication card and the host controller.	Check whether the communication card wiring is loose or dropped.	
E-CAN	[31] CANopen card communication timeout fault	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped.	
ETH1	[32] To-ground short-circuit fault 1	The output of the VFD is short circuited to the ground. Current detection circuit is faulty. Actual motor power setup deviates sharply from the VFD power.	Check whether the motor wiring is normal. Replace the hall component. Replace the main control board. Reset the motor parameters properly.	
ETH2	[33] To-ground short-circuit fault 2	The output of the VFD is short circuited to the ground. Current detection circuit is faulty. Actual motor power setup deviates sharply from the VFD power.	Check whether the motor wiring is normal. Replace the hall component. Replace the main control board. Reset the motor parameters properly.	
dEu	[34] Speed deviation fault	The load is too heavy or stalled.	Check the load to ensure it is proper, and increase the detection time. Check whether the control parameters are set properly.	
STo	[35] Mal-adjustment fault	Control parameters of the synchronous motor are set improperly. Autotuned parameters are not accurate.	Check the load and ensure the load is normal. Check whether control parameters are set correctly. Increase the mal-adjustment	
Fault code	Fault type	Possible cause	Solution	
----------------	--	--	--	--
		The VFD is not connected to the motor.	detection time.	
LL	[36] Electronic underload fault	The VFD reports underload pre-alarm according to the setting.	Check the load and the underload pre-alarm points.	
ENC10	[37] Encoder disconnection fault	Encoder line sequence is wrong, or signal wires are poorly connected.	Check the encoder wiring.	
ENC1d	[38] Encoder reversal fault	The encoder speed signal is contrary to the motor running direction.	Reset encoder direction.	
ENC1Z	[39] Encoder Z pulse disconnection fault	Z signal wires are disconnected.	Check the wiring of Z signal.	
STO	[40] Safe torque off	Safe torque off function is enabled by external forces.	/	
STL1	[41] Exception occurred to safe circuit of channel 1	The wiring of STO is improper; Fault occurred to external switch of STO; Hardware fault occurred to safety circuit of channel 1.	Check whether terminal wiring of STO is proper and firm enough; Check whether the external switch of STO can work properly; Replace the control board.	
STL2	[42] Exception occurred to safe circuit of channel 2	The wiring of STO is improper; Fault occurred to external switch of STO; Hardware fault occurred to safety circuit of channel 2.	Check whether terminal wiring of STO is proper and firm enough; Check whether the external switch of STO can work properly; Replace the control board.	
STL3	[43] Exception occurred to both channel 1 and channel 2	Hardware fault occurred to STO circuit.	d to STO Replace the control board.	
CrCE	[44] Safety code FLASH CRC check fault	Control board is faulty.	Replace the control board.	
P-E1– P-E10	[45]–[54]: Programmable card customized faults 1–10	User program logic error in the programmable card. A fault of the custom type occurred.	Check the user program logic. Perform troubleshooting based on actual custom faults.	

Fault code	Fault type	Possible cause	Solution
E-Err	[55] Repetitive expansion card type	The two inserted expansion cards are of the same type.	You should not insert two cards with the same type. Check the type of expansion card, and remove one card after power-off.
ENCUV	[56] Encoder UVW loss fault	No electric level variation occurred to UVW signal.	Check the wiring of UVW; Encoder is damaged.
E-PN	[57] PROFITNET card communication timeout fault	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped.
SECAN	[58] CAN master/slave card communication timeout fault	There is no data transmission between the CAN master and slave communication cards.	Check whether the communication card wiring is loose or dropped.
от	[59] Motor overtemperature fault	Motor overtemperature input terminal is valid. The temperature detection resistance is abnormal. Long-time overload running or exception occurred.	Check the wiring of the motor overtemperature input terminal (terminal function 57). Check whether the temperature sensor is proper; Check the motor, and perform maintenance on the motor.
F1-Er	[60] Failure to identify the card at slot 1	There is data transmission in interfaces of card slot 1, however, it cannot read the card type.	Confirm whether the expansion card inserted can be supported. Stabilize the expansion card interfaces after power-off, and check whether the fault persists at next power-on. Check whether the insertion port is damaged, if yes, replace the insertion port after power-off.
F2-Er	[61] Failure to identify the card at slot 2	There is data transmission in interfaces of card slot 2, however, it cannot read the card type.	Confirm whether the expansion card inserted can be supported. Stabilize the expansion card interfaces after power-off, and check whether the fault persists at next power-on. Check whether the insertion port is damaged, if yes, replace the

Fault code	Fault type	Possible cause	Solution
			insertion port after power-off.
F3-Er	[62] Failure to identify the card at slot 3	There is data transmission in interfaces of card slot 3, however, it cannot read the card type.	Confirm whether the expansion card inserted can be supported. Stabilize the expansion card interfaces after power-off, and check whether the fault persists at next power-on. Check whether the insertion port is damaged, if yes, replace the insertion port after power-off.
C1-Er	[63] Communication timeout of the card at slot 1	There is no data transmission in in interfaces of card slot 1.	Confirm whether the expansion card inserted can be supported. Stabilize the expansion card interfaces after power-off, and check whether the fault persists at next power-on. Check whether the insertion port is damaged, if yes, replace the insertion port after power-off.
C2-Er	[64] Communication timeout of the card at slot 2	There is no data transmission in interfaces of card slot 2.	Confirm whether the expansion card inserted can be supported. Stabilize the expansion card interfaces after power-off, and check whether the fault persists at next power-on. Check whether the insertion port is damaged, if yes, replace the insertion port after power-off.
C3-Er	[65] Communication timeout of the card at slot 3	There is no data transmission in in interfaces of card slot 3.	Confirm whether the expansion card inserted can be supported. Stabilize the expansion card interfaces after power-off, and check whether the fault persists at next power-on. Check whether the insertion port is damaged, if yes, replace the insertion port after power-off.
E-CAT	[66] EtherCAT	No data transmission between	Check whether the

Fault code	Fault type	Possible cause	Solution	
	card communication timeout	the communication card and the host controller (or PLC).	communication card wiring is loose or dropped.	
E-BAC	[67] BACnet card communication timeout fault	No data transmission between the communication card and the host controller (or PLC).	smission between       Check whether the         cation card and the communication card wiring is         er (or PLC).	
E-DEV	[68] DeviceNet card communication timeout fault	No data transmission between Check whether the communication card and the communication card wiring host controller (or PLC).		
S-Err	[69] Master/slave synchronous CAN slave fault	Fault occurred to one of the CAN slave VFDs.	Detect the CAN slave VFD and analyze the corresponding fault cause of the VFD.	
OtE1	[70]: PT100 overtemperature	The PT100 temperature sensor is inaccurate or not calibrated. Device or ambient temperature is too high.	Calibrate the sensor through parameter settings. Lower the device or ambient temperature.	
OtE2	[71] PT1000 overtemperature	The PT1000 temperature sensor is inaccurate or not calibrated. Device or ambient temperature is too high.	Calibrate the sensor through parameter settings. Lower the device or ambient temperature.	
E-EIP	[72] EtherNet IP communication timeout	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped.	
E-PAO	[73] No upgrade bootloader	The upgrade bootload is missing.	Contact us.	
E-Al1	[74] Al1 disconnection	Input voltage of AI1 is too low; AI1 wiring is disconnected.	Connect a 5V or 10mA power source to check if the input is normal; Check the wiring or replace the cables.	
E-Al2	[75] AI2 disconnection	Input voltage of AI2 is too low. AI2 wiring is disconnected.	Connect a 5V or 10mA power source to check if the input is normal; Check the wiring or replace the cables.	
E-AI3	[76] AI3	Input voltage of AI3 is too low.	Connect a 5V or 10mA power	

Fault code	Fault type	Possible cause	Solution
	disconnection	AI3 wiring is disconnected.	source to check if the input is normal; Check the wiring or replace the cables.

### 7.5.2 Other status

Displayed code	Status type	Possible cause	Solution
PoFF	System power failure	The system is powered off or the bus voltage is too low.	Check the grid conditions.

# 7.6 Analysis on common faults

### 7.6.1 Motor fails to work



#### 7.6.2 Motor vibrates



#### 7.6.3 Overvoltage



#### 7.6.5 Motor overheating



#### 7.6.6 VFD overheating



#### 7.6.7 Motor stalls during ACC



#### 7.6.8 Overcurrent



## 7.7 Countermeasures on common interference

#### 7.7.1 Interference on meter switches and sensors

#### Interference phenomenon

Pressure, temperature, displacement, and other signals of a sensor are collected and

displayed by a human-machine interaction device. The values are incorrectly displayed as follows after the VFD is started:

- 1. The upper or lower limit is wrongly displayed, for example, 999 or -999.
- 2. The display of values jumps (usually occurring on pressure transmitters).
- The display of values is stable, but there is a large deviation, for example, the temperature is dozens of degrees higher than the common temperature (usually occurring on thermocouples).
- 4. A signal collected by a sensor is not displayed but functions as a drive system running feedback signal. For example, the VFD is expected to decelerate when the upper pressure limit of the compressor is reached, but in actual running, it starts to decelerate before the upper pressure limit is reached.
- After the VFD is started, the display of all kinds of meters (such as frequency meter and current meter) that are connected to the analog output (AO) terminal of the VFD is severely affected, displaying the values incorrectly.
- Proximity switches are used in the system. After the VFD is started, the indicator of a proximity switch flickers, and the output level flips.

#### Solution

- 1. Check and ensure that the feedback cable of the sensor is 20 cm or farther away from the motor cable.
- 2. Check and ensure that the ground wire of the motor is connected to the PE terminal of the VFD (if the ground wire of the motor has been connected to the ground block, you need to use a multimeter to measure and ensure that the resistance between the ground block and PE terminal is lower than 1.5  $\Omega$ ).
- Try to add a safety capacitor of 0.1µF to the signal end of the feedback signal terminal of the sensor.
- Try to add a safety capacitor of 0.1µF to the power end of the sensor meter (pay attention to the voltage of the power supply and the voltage endurance of the capacitor).
- 5. For interference on meters connected to the VFD AO terminal, if AO uses current signals of 0 to 20 mA, add a capacitor of 0.47  $\mu$ F between the AO and GND terminals; and if AO uses voltage signals of 0 to 10 V, add a capacitor of 0.1  $\mu$ F between the AO and GND terminals.

#### Note:

 When a decoupling capacitor is required, add it to the terminal of the device connected to the sensor. For example, if a thermocouple is to transmit signals of 0 to 20 mA to a temperature meter, the capacitor needs to be added on the terminal of the temperature meter.; if an electronic ruler is to transmit signals of 0 to 30 V to a PLC signal terminal, the capacitor needs to be added on the terminal of the PLC.

If a large number of meters or sensors are disturbed, it is recommended that you configure an external C2 filter on the VFD input power end. For details, see section D.7 EMC filter.

### 7.7.2 Interference on RS485 communication

The interference described in this section on RS485 communication mainly includes communication delay, out of synchronization, occasional power-off, or complete power-off that occurs after the VFD is started.

If the communication cannot be implemented properly, regardless of whether the VFD is running, the exception is not necessarily caused by interference. You can find out the causes as follows:

- 1. Check whether the RS485 communication bus is disconnected or in poor contact.
- Check whether the A and B wires of the RS485 communication bus are connected reversely.
- Check whether the communication protocol of the VFD is consistent with that of the host controller. Check whether the communication protocol (such as the baud rate, data bits, and check bit) of the VFD is consistent with that of the upper computer.

If you are sure that communication exceptions are caused by interference, you can resolve the problem through the following measures:

- 1. Simple inspection
- 2. Arrange the communication cables and motor cables in different cable trays.
- In multi-VFD application scenarios, adopt the chrysanthemum connection mode to connect the communication cables between VFDs, which can improve the anti-interference capability.
- In multi-VFD application scenarios, check and ensure that the driving capacity of the master is sufficient.
- 5. In the connection of multiple VFDs, you need to configure one 120  $\Omega$  terminal resistor at both ends.

#### Solution

- 1. Check and ensure that the ground wire of the motor is connected to the PE terminal of the VFD (if the ground wire of the motor has been connected to the ground block, you need to use a multimeter to measure and ensure that the resistance between the ground block and PE terminal is lower than  $1.5 \Omega$ ).
- Do not connect the VFD and motor to the same ground terminal as the upper computer (PLC, HMI, and touch screen). It is recommended that you connect the VFD and motor

to the power ground, and connect the upper computer separately to a ground stud.

- Try to short the signal reference ground terminal (GND) of the VFD with that of the upper computer controller to ensure that ground potential of the communication chip on the control board of the VFD is consistent with that of the communication chip of the upper computer.
- 4. Try to short GND of the VFD to its ground terminal (PE).
- 5. Try to add a safety capacitor of 0.1 μF on the power terminal of the upper computer (PLC, HMI, and touch screen). During this process, pay attention to the voltage of the power supply and the voltage endurance capability of the capacitor. Alternatively, you can use a magnet ring (Fe-based nanocrystalline magnet rings are recommended). Put the power L/N line or +/- line of the upper computer through the magnet ring in the same direction and wind 8 coils around the magnet ring.

#### 7.7.3 Failure to stop and indicator shimmering due to motor cable coupling

### Interference phenomenon

1. Unable to stop

In a VFD system where an S terminal is used to control the start and stop, the motor cable and control cable are arranged in the same cable tray. After the system is started properly, the S terminal cannot be used to stop the VFD.

2. Indicator shimmering

After the VFD is started, the relay indicator, power distribution box indicator, PLC indicator, and indication buzzer shimmer, blink, or emit unusual sounds unexpectedly.

#### Solution

- 1. Check and ensure that the exception signal cable is arranged 20 cm or farther away from the motor cable.
- 2. Add a safety capacitor of 0.1µF between the digital input terminal (S) and the COM.
- Connect the digital input terminal (S) that controls the start and stop to other idle digital input terminals in parallel. For example, if S1 is used to control the start and stop and S4 is idle, you can try to short connect S1 to S4 in parallel.

**Note:** If the controller (such as PLC) in the system controls more than 5 VFDs at the same time through digital input terminals (S), this scheme is not applicable.

#### 7.7.4 Leakage current and interference on RCD

VFDs output high-frequency PWM voltage to drive motors. In this process, the distributed capacitance between the internal IGBT of a VFD and the heat sink and that between the stator and rotor of a motor may inevitably cause the VFD to generate high-frequency leakage current to the ground. A residual current operated protective device (RCD) is used to detect the

power-frequency leakage current when a grounding fault occurs on a circuit. The application of a VFD may cause misoperation of a RCD.

- 1. Rules for selecting RCDs
  - A. VFD systems are special. In these systems, it is required that the rated residual current of common RCDs at all levels is larger than 200 mA, and the VFDs are grounded reliably.
  - B. For RCDs, the time limit of an action needs to be longer than that of a next action, and the time difference between two actions need to be longer than 20ms, for example, 1s, 0.5s, or 0.2s.
  - C. For circuits in VFD systems, electromagnetic RCDs are recommended. Electromagnetic RCDs have strong anti-interference capability, and thus can prevent the impact of high-frequency leakage current.

Electronic RCD	Electromagnetic RCD
	Requiring highly sensitive, accurate, and stable
Low cost, high sensitivity, small in volume,	zero-phase sequence current transformer, using
susceptible to voltage fluctuation of the grid and	permalloy high-permeability materials, complex
ambient temperature, and weak	process, high cost, not susceptible to voltage
anti-interference capability	fluctuation of the power supply and ambient
	temperature, strong anti- interference capability

- 2. Solution to RCD misoperation (handling the VFD)
  - A. Try to remove the jumper cap at "EMC/J10" from the middle casing of the VFD.
  - B. Try to decrease the carrier frequency to 1.5kHz (P00.14=1.5).
  - C. Try to modify the modulation method to "3PH modulation and 2PH modulation" (P08.40=00).
- 3. Solution to RCD misoperation (handling the system power distribution)
  - A. Check and ensure that the power cable is not soaking in water.
  - B. Check and ensure that the cables are not damaged or.
  - C. Check and ensure that no secondary grounding is performed on the neutral wire.
  - D. Check and ensure that the main power cable terminal is in good contact with the air switch or contactor (all screws are tightened).
  - E. Check 1PH powered devices, and ensure that no earth wires are used as neutral wires by these devices.
  - F. Do not use shielded cables as VFD power cables and motor cables.

# 7.7.5 Live device chassis

After the VFD is started, there is sensible voltage on the chassis, and you may feel an electric

shock when touching the chassis. The chassis, however, is not live (or the voltage is far lower than the human safety voltage) when the VFD is powered on but not running.

Solution:

- 1. If there is power distribution grounding or ground stud on the site, ground the cabinet chassis of the VFD through the power ground or stud.
- If there is no grounding on the site, you need to connect the motor chassis to the ground terminal PE of the VFD, and ensure that the jumper at "EMC/J10" on the middle casing of the VFD is shorted.

# 8 Maintenance

# 8.1 What this chapter contains

This chapter describes how to carry out preventive maintenance on the VFD.

# 8.2 Periodical inspection

Little maintenance is required when the VFD is installed in an environment that meets requirements. The following table describes the routine maintenance periods recommended by INVT. The following table describes the routine maintenance periods recommended by INVT.

Ch	eck scope	Check item	Method	Expected result
Ambie	nt environment	Check the temperature, and humidity, and whether there is vibration, dust, gas, oil spray, and water droplets in the environment.	Visual inspection, and use instruments for measurement.	The requirements stated in this manual are met.
		Check whether there are foreign matters, such as tools, or dangerous substances placed nearby.	Visual inspection	There are no tools or dangerous substances placed nearby.
	Voltage	Check the voltage of the main circuit and control circuit.	Use multimeters or other instruments for measurement.	The requirements stated in this manual are met.
		Check the display of information.	Visual inspection	The characters are displayed properly.
	Keypad	Check whether characters are not completely displayed.	Visual inspection	The requirements stated in this manual are met.
		Check whether the bolts loose or come off.	Screw them up.	No exception occurs.
Main circuit	Common	Check whether the machine is deformed, cracked, or damaged, or their color changes due to overheating and aging.	Visual inspection	No exception occurs.
		Check whether there are stains and dust attached.	Visual inspection	No exception occurs. Note: Discoloration of copper and aluminum bars does

Maintenance

Check scope	Check item	Method	Expected result
			not mean that they
			cannot work properly.
Conductor and	Check whether conductors are deformed or color change for overheat.	Visual inspection	No exception occurs.
wire	Check whether the wire sheaths are cracked or their color changes.	Visual inspection	No exception occurs.
Terminal block	Check whether there is damage.	Visual inspection	No exception occurs.
	Check whether there is electrolyte leakage, discoloration, cracks, and chassis expansion.	Visual inspection	No exception occurs.
Filter capacitor	Check whether the safety valves are released.	Determine the service life based on the maintenance information, or measure them through electrostatic capacity.	No exception occurs.
	Check whether the electrostatic capacity is measured as required.	Use instruments to measure the capacity.	Electrostatic capacity ≥ initial value x 0.85
	Check whether there is displacement caused due to overheat.	Olfactory and visual inspection	No exception occurs.
Resistor	Check whether the resistors are disconnected.	Visual inspection, or remove one end of the connection cable and use a multimeter for measurement.	Resistance range: ±10% (of the standard resistance)
Transformer and reactor	Check whether there is unusual vibration sounds or smells.	Auditory, olfactory, and visual inspection	No exception occurs.
Electromagnetic contactor and	Check whether there are vibration sounds in the	Auditory inspection	No exception occurs.

Check scope		Check item	Method	Expected result
	relay	workshop.		
		Check whether the contacts are in good contact.	Visual inspection	No exception occurs.
		Check whether the screws and connectors loose.	Screw them up.	No exception occurs.
		Check whether there is unusual smell or discoloration.	Olfactory and visual inspection	No exception occurs.
Control circuit	Control PCB and connector	Check whether there are cracks, damage, deformation, or rust.	Visual inspection	No exception occurs.
		Check whether there is electrolyte leakage or deformation.	Visual inspection, and determine the service life based on the maintenance information.	No exception occurs.
		Check whether there are unusual sounds or vibration.	Auditory and visual inspection, and turn the fan blades with your hand.	The rotation is smooth.
	Cooling fan	Check whether the bolts loose.	Screw them up.	No exception occurs.
Cooling system		Check whether there is decoloration caused due to overheat.	Visual inspection, and determine the service life based on the maintenance information.	No exception occurs.
	Ventilation duct	Check whether there are foreign matters blocking or attached to the cooling fan, air inlets, or air outlets.	Visual inspection	No exception occurs.

For more details about maintenance, contact the local INVT office, or visit our website www.invt.com, and choose **Support > Services**.

# 8.3 Cooling fan

The service life of the cooling fan of the VFD is more than 25,000 hours. The actual service life of the cooling fan is related to the use of the VFD and the temperature in the ambient environment.

You can view the running duration of the VFD through P07.14 (Accumulated running time).

The increase of the bearing noise indicates a fan fault. If the VFD is applied in a key position, replace the fan once the fan starts to generate unusual noise. You can purchase spares of fans from INVT.

Cooling fan replacement:



Read chapter 1 Safety precautions carefully and follow the instructions to perform operations. Ignoring these safety precautions may lead to physical injury or death, or device damage.

- Stop the VFD, disconnect the AC power supply, and wait for a time no shorter than the waiting time designated on the VFD.
- Open the cable clamp to loose the fan cable (for the 004G/5R5P-030G/037P VFD models, the middle casing needs to be removed).
- 3. Disconnect the fan cable.
- 4. Remove the fan with a screwdriver.
- 5. Install a new fan in the VFD in the reverse steps. Assemble the VFD. Ensure that the air direction of the fan is consistent with that of the VFD, as shown in Figure 8-1.
- 6. Connect to the power supply.

Figure 8-1 Fan maintenance for the 7R5G/011P and higher VFD models



# 8.4 Capacitor

# 8.4.1 Capacitor reforming

If the VFD has been left unused for a long time, you need to follow the instructions to reform the DC bus capacitor before using it. The storage time is calculated from the date the VFD is delivered.

Storage time	Operation principle		
Less than 1 year	No charging operation is required.		
1 to 2 years	The VFD needs to be powered on for 1 hour before the first running		
T to 2 years	command.		
	Use a voltage controlled power supply to charge the VFD:		
	Charge the VFD at 25% of the rated voltage for 30 minutes,		
2 to 3 years	<ul> <li>and then charge it at 50% of the rated voltage for 30 minutes,</li> </ul>		
	• at 75% for another 30 minutes,		
	<ul> <li>and finally charge it at 100% of the rated voltage for 30 minutes.</li> </ul>		
	Use a voltage controlled power supply to charge the VFD:		
	<ul> <li>Charge the VFD at 25% of the rated voltage for 2 hours,</li> </ul>		
More than 3 years	<ul> <li>and then charge it at 50% of the rated voltage for 2 hours,</li> </ul>		
	<ul> <li>at 75% for another 2 hours,</li> </ul>		
	<ul> <li>and finally charge it at 100% of the rated voltage for 2 hours.</li> </ul>		

The method for using a voltage controlled power supply to charge the VFD is described as follows:

The selection of a voltage controlled power supply depends on the power supply of the VFD. For VFDs with an incoming voltage of 1PH/3PH 230 V AC, you can use a 230 V AC/2 A voltage regulator. Both 1PH and 3PH VFDs can be charged with a 1PH voltage controlled power supply (connect L+ to R, and N to S or T). All the DC bus capacitors share one rectifier, and therefore they are all charged.

For VFDs of a high voltage class, ensure that the voltage requirement (for example, 380 V) is met during charging. Capacitor changing requires little current, and therefore you can use a small-capacity power supply (2 A is sufficient).

The method for using a resistor (incandescent lamp) to charge the drive is described as follows:

If you directly connect the drive device to a power supply to charge the DC bus capacitor, it needs to be charged for a minimum of 60 minutes. The charging operation must be performed at a normal indoor temperature without load, and you must connect a resistor in series mode in the 3PH circuit of the power supply.

For a 380V drive device, use a resistor of  $1k\Omega/100W$ . If the voltage of the power supply is no higher than 380 V, you can also use an incandescent lamp of 100W. If an incandescent lamp is used, it may go off or the light may become very weak.





### 8.4.2 Electrolytic capacitor replacement



Read chapter 1 Safety precautions carefully and follow the instructions to perform operations. Ignoring these safety precautions may lead to physical injury or death, or device damage.

The electrolytic capacitor of a VFD must be replaced if it has been used for more than 35,000 hours. For details about the replacement, contact the local INVT office.

### 8.5 Power cable



- 1. Stop the VFD, disconnect the power supply, and wait for a time no shorter than the waiting time designated on the VFD.
- 2. Check the connection of the power cables. Ensure that they are firmly connected.
- 3. Connect to the power.

# 9 Communication protocol

## 9.1 What this chapter contains

This chapter describes the communication of the VFD.

The VFD provides RS485 communication interfaces and adopts the master-slave communication based on the international standard Modbus communication protocol. You can implement centralized control (setting commands for controlling the VFD, modifying the running frequency and related function code parameters, and monitoring the working state and fault information of the VFD) through PC/PLC, upper control computer, or other devices to meet specific application requirements.

### 9.2 Modbus protocol introduction

Modbus is a communication protocol for use with electronic controllers. By using this protocol, a controller can communicate with other devices through transmission lines. It is a general industrial standard. With this standard, control devices produced by different manufacturers can be connected to form an industrial network and be monitored in a centralized way.

The Modbus protocol provides two transmission modes, namely American Standard Code for Information Interchange (ASCII) and remote terminal units (RTU). On one Modbus network, all the device transmission modes, baud rates, data bits, check bits, end bits, and other basic parameters must be set consistently.

A Modbus network is a control network with one master and multiple slaves, that is, on one Modbus network, there is only one device serving as the master, and other devices are the slaves. The master can communicate with any single slave or with all slaves. For separate access commands, a slave needs to return a response. For broadcast information, slaves do not need to return responses.

# 9.3 Application of Modbus

The VFD uses the Modbus RTU mode and communicates through RS485 interfaces.

### 9.3.1 RS485

RS485 interfaces work in half-duplex mode and transmit data signals in the differential transmission way, which is also referred to as balanced transmission. The two-wire RS485 interface uses a twisted pair, in which one wire is defined as A (+), and the other B (-). Generally, if the positive electrical level between the transmission drives A and B ranges from +2V to +6V, the logic is "1"; and if it ranges from -2V to -6V, the logic is "0".

The 485+ terminal on the terminal block of the VFD corresponds to A, and 485- corresponds to B.

The communication baud rate (P14.01) indicates the number of bits sent in a second, and the unit is bit/s (bps). A higher baud rate indicates faster transmission and poorer anti-interference

capability. When a twisted pair of 0.56mm (24AWG) is used, the maximum transmission distance varies according to the baud rate, as described in the following table.

Baud rate	Max. transmission distance	Baud rate	Max. transmission distance
2400bps	1800m	9600bps	800m
4800bps	1200m	19200bps	600m

In long-distance RS485 communication, it is recommended that you use shielded cables, and use the shielding layer as the ground wire.

When there are fewer devices and the transmission distance is short, the whole network works well without terminal load resistors. The performance, however, degrades as the distance increases. Therefore, it is recommended that you use a  $120\Omega$  terminal resistor when the transmission distance is long.

#### 9.3.1.1 Application to one VFD

Figure 9-1 is the Modbus wiring diagram of one VFD and a PC. Generally, PCs do not provide RS485 interfaces, and therefore you need to convert an RS232 interface or USB port of a PC to an RS485 interface. Connect end A of the RS485 communication cable to the 485+ port on the terminal block of the VFD, and connect end B to the 485- port. It is recommended that you use shielded twisted pairs. When an RS232-RS485 converter is used, the cable used to connect the RS232 interface of the PC and the converter cannot be longer than 15 m. Use a short cable when possible. It is recommended that you insert the converter directly into the PC. Similarly, when a USB-RS485 converter is used, use a short cable when possible.

When the wiring is completed, select the correct port (for example, COM1 to connect to the RS232-RS485 adapter) for the upper computer of the PC, and keep the settings of basic parameters such as communication baud rate and data check bit consistent with those of the VFD.



Figure 9-1 Wiring of RS485 applied to one VFD

### 9.3.1.2 Application to multiple VFDs

In practical application to multiple VFDs, chrysanthemum connection and star connection are commonly used.

According to the requirements of the RS485 industrial bus standards, all the devices need to be connected in chrysanthemum mode with one 120  $\Omega$  terminal resistor on each end, as shown in Figure 9-2. Figure 9-3 is the simplified wiring diagram, and Figure 9-4 is the practical application diagram.

Figure 9-2 On-site chrysanthemum connection diagram



Figure 9-3 Simplified chrysanthemum connection diagram



Figure 9-4 Practical application diagram of chrysanthemum connection



Figure 9-5 shows the start connection diagram. When this connection mode is adopted, the two devices that are farthest away from each other on the line must be connected with a terminal resistor (the two devices are devices #1 and #15).



Use shielded cables, if possible, in multi-device connection. The baud rates, data bit check settings, and other basic parameters of all the devices on the RS485 line must be set consistently, and addresses cannot be repeated.

#### 9.3.2 RTU mode

### 9.3.2.1 RTU communication frame structure

When a controller is set to use the RTU communication mode on a Modbus network, every byte (8 bits) in the message includes 2 hexadecimal characters (each includes 4 bits). Compared with the ASCII mode, the RTU mode achieves transmission of more data at the same baud rate.

#### Code system

1 start bit

• 7 or 8 data bits; the minimum valid bit is transmitted first. Each frame domain of 8 bits includes 2 hexadecimal characters (0–9, A–F).

- 1 odd/even check bit; this bit is not provided if no check is needed.
- 1 stop bit (with check performed), 2 bits (without check)

#### Error detection domain

Cyclic redundancy check (CRC)

The following table describes the data format.

11-bit character frame (bits 1 to 8 are data bits):

Start bit   Bit1   Bit2   Bit3   Bit4   Bit5   Bit6   Bit7   Bit8   Check bit   Stop bit	Start bit Bit1	Bit2	Bit3	Bit4	Bit5	Bit6	Bit7	Bit8	Check bit	Stop bit
--	----------------	------	------	------	------	------	------	------	-----------	----------

10-bit character frame (bits 1 to 7 are data bits):

Start bit   Bit1   Bit2   Bit3   Bit4   Bit5   Bit6   Bit7   Check bit   Stop bit
---

In a character frame, only the data bits carry information. The start bit, check bit, and end bit are used to facilitate the transmission of the data bits to the destination device. In practical applications, you must set the data bits, parity check bits, and stop bits consistently.

In RTU mode, the transmission of a new frame always starts from an idle time (the transmission time of 3.5 bytes). On a network where the transmission rate is calculated based on the baud rate, the transmission time of 3.5 bytes can be easily obtained. After the idle time ends, the data domains are transmitted in the following sequence: slave address, operation command code, data, and CRC check character. Each byte transmitted in each domain includes 2 hexadecimal characters (0–9, A–F). The network devices always monitor the communication bus. After receiving the first domain (address information), each network device identifies the byte. After the last byte is transmitted, a similar transmission interval (the transmission time of 3.5 bytes) is used to indicate that the transmission of the frame ends. Then, the transmission of a new frame starts.



The information of a frame must be sent in a continuous data flow. If there is an interval greater than the transmission time of 1.5 bytes before the transmission of the entire frame is complete, the receiving device deletes the incomplete information, and mistakes the subsequent byte for the address domain of a new frame. Similarly, if the transmission interval between two frames is shorter than the transmission time of 3.5 bytes, the receiving device mistakes it for the data of the last frame. The CRC check value is incorrect due to the disorder of the frames, and thus a communication fault occurs.

START (frame header)	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR (slave address	Communication address: 0-247 (decimal system) (0 is the broadcast
domain)	address)
CMD (function domain)	03H: read slave parameters
CMD (function domain)	06H: write slave parameters
Data domain	
DATA (N-1)	Data of 2*N main content of the communication as well as the core of
	data exchanging.
DATA (0)	
CRC CHK LSB	
CRC CHK MSB	Detection value: CRC verification value (16 bits)
END (frame tail)	T1-T2-T3-T4 (transmission time of 3.5 bytes)

The following table describes the standard structure of an RTU frame.

#### 9.3.2.2 RTU communication frame error check modes

During the transmission of data, errors may occur due to various factors. Without error check,

the data receiving device cannot identify data errors and may make an incorrect response. The incorrect response may cause severe problems. Therefore, the data must be checked.

The check is implemented as follows: The transmitter calculates the to-be-transmitted data based on a specific algorithm to obtain a result, adds the result to the rear of the message, and transmits them together. After receiving the message, the receiver calculates the data based on the same algorithm to obtain a result, and compares the result with that transmitted by the transmitter. If the results are the same, the message is correct. Otherwise, the message is considered incorrect.

The error check of a frame includes two parts, namely, bit check on individual bytes (that is, odd/even check using the check bit in the character frame), and whole data check (CRC check).

#### Bit check on individual bytes (odd/even check)

You can select the bit check mode as required, or you can choose not to perform the check, which will affect the check bit setting of each byte.

Definition of even check: Before the data is transmitted, an even check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is even, the check bit is set to "0, and if it is odd, the check bit is set to "1".

Definition of odd check: Before the data is transmitted, an odd check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is odd, the check bit is set to "0",; and if it is even, the check bit is set to "1",

For example, the data bits to be sent are "11001110", including five "1". If the even check is applied, the even check bit is set to "1"; and if the odd check is applied, the odd check bit is set to "0". During the transmission of the data, the odd/even check bit is calculated and placed in the check bit of the frame. The receiving device performs the odd/even check after receiving the data. If it finds that the odd/even parity of the data is inconsistent with the preset information, it determines that a communication error occurs.

#### Cyclic redundancy check (CRC)

A frame in the RTU format includes an error detection domain based on the CRC calculation. The CRC domain checks all the content of the frame. The CRC domain consists of two bytes, including 16 binary bits. It is calculated by the transmitter and added to the frame. The receiver calculates the CRC of the received frame, and compares the result with the value in the received CRC domain. If the two CRC values are not equal to each other, errors occur in the transmission.

During CRC, 0xFFFF is stored first, and then a process is invoked to process a minimum of 6 contiguous bytes in the frame based on the content in the current register. CRC is valid only for the 8-bit data in each character. It is invalid for the start, stop, and check bits.

During the generation of the CRC values, the "exclusive or" (XOR) operation is performed on

the each 8-bit character and the content in the register. The result is placed in the bits from the least significant bit (LSB) to the most significant bit (MSB), and 0 is placed in the MSB. Then, LSB is detected. If LSB is 1, the XOR operation is performed on the current value in the register and the preset value. If LSB is 0, no operation is performed. This process is repeated for 8 times. After the last bit (8th bit) is detected and processed, the XOR operation is performed on the next 8-bit byte and the current content in the register. The final values in the register are the CRC values obtained after operations are performed on all the bytes in the frame.

The calculation adopts the international standard CRC check rule. You can refer to the related standard CRC algorithm to compile the CRC calculation program as required.

The following example is a simple CRC calculation function for your reference (using the C programming language):

```
unsigned int crc_cal_value(unsigned char*data_value, unsigned char
data length)
ł
    int i:
    unsigned int crc value=0xffff;
    while(data length--)
    {
         crc value^=*data value++;
         for(i=0;i<8;i++)</pre>
         £
              if(crc value&0x0001)
                   crc value=(crc value>>1)^0xa001;
              else
                   crc value=crc value>>1;
    }
    return(crc value);
}
```

In the ladder logic, CKSM uses the table look-up method to calculate the CRC value according to the content in the frame. The program of this method is simple, and the calculation is fast, but the ROM space occupied is large. Use this program with caution in scenarios where there are space occupation requirements on programs.

# 9.4 RTU command code and communication data

### 9.4.1 Command code 03H, reading N words (continuously up to 16 words)

The command code 03H is used by the master to read data from the VFD. The count of data to be read depends on the "data count" in the command. A maximum of 16 pieces of data can be

read. The addresses of the read parameters must be contiguous. Each piece of data occupies 2 bytes, that is, one word. The command format is presented using the hexadecimal system (a number followed by "H" indicates a hexadecimal value). One hexadecimal value occupies one byte.

The 03H command is used to read information including the parameters and running status of the VFD.

For example, if the master reads two contiguous pieces of data (that is, to read content from the data addresses 0004 H and 0005 H) from the VFD whose address is 01H, the command frame structure is described in the following.

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR (address)	01H
CMD (command code)	03H
Start address MSB	00H
Start address LSB	04H
Data count MSB	00H
Data count LSB	02H
CRC LSB	85H
CRC MSB	САН
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)

RTU master command (from the master to the VFD)

The value in START and END is "T1-T2-T3-T4 (transmission time of 3.5 bytes)", indicating that the RS485 needs to stay idle for at least the transmission time of 3.5 bytes. An idle time is required to distinguish on message from another to ensure that the two messages are not regarded as one.

"ADDR" is "01H", indicating that the command is sent to the VFD whose address is 01H. "ADDR" occupies one byte.

"CMD" is "03H", indicating that the command is used to read data from the VFD. "CMD" occupies one byte.

"Start address" means the address from which data reading starts. and it occupies two bytes with the MSB on the left and LSB on the right.

"Data count" indicates the count of data to be read (unit: word). "Start address" is "0004H" and "Data count" is "0002H", which indicates reading data from the addresses 0004H and 0005H.

CRC check occupies two bytes, with the LSB on the left, and MSB on the right.

RTU slave response (from the VFD to the master)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR	01H

CMD	03H
Number of bytes	04H
MSB of data in 0004H	13H
LSB of data in 0004H	88H
MSB of data in 0005H	00H
LSB of data in 0005H	00H
CRC LSB	7EH
CRC MSB	9DH
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)

The definition of the response information is described as follows:

"ADDR" is "01H", indicating that the command is sent from the VFD whose address is 01H. "ADDR" occupies one byte.

"CMD" is "03H", indicating that the message is a VFD response to the 03H command from the master for reading data. "CMD" occupies one byte.

"Number of bytes" indicates the number of bytes between a byte (not included) and the CRC byte (not included). The value "04" indicates that there are four bytes of data between "Number of bytes" and "CRC LSB", that is, "MSB of data in 0004H", "LSB of data in 0004H", "MSB of data in 0005H", and "LSB of data in 0005H".

A piece of data contains two bytes, with the MSB on the left and LSB on the right. From the response, the data in 0004H is 1388H, and that in 0005H is 0000H.

CRC check occupies two bytes, with the LSB on the left, and MSB on the right.

### 9.4.2 Command code 06H, writing a word

This command is used by the master to write data to the VFD. One command can be used to write only one piece of data. It is used to modify the parameters and running mode of the VFD.

For example, to write 5000 (1388H) to 0004H of the VFD whose address is 02H, the frame structure is as follows.

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR	02H
CMD	06H
MSB of data writing address	00H
LSB of data writing address	04H
MSB of data content	13H
LSB of data content	88H
CRC LSB	C5H
CRC MSB	6EH

RTU master command (from the master to the VFD)

END

T1-T2-T3-T4 (transmission time of 3.5 bytes)

RTU slave response (from the VFD to the master)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR	02H
CMD	06H
MSB of data writing address	00H
LSB of data writing address	04H
MSB of data content	13H
LSB of data content	88H
CRC LSB	C5H
CRC MSB	6EH
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)

**Note:** The sections 9.4.1 and 9.4.2 mainly describe the command formats. For the detailed application, see the examples in section 9.4.7.

### 9.4.3 Command code 10H, continuous writing

The command code 10H is used by the master to write data to the VFD. The quantity of data to be written is determined by "Data quantity", and a maximum of 16 pieces of data can be written.

For example, if the master writes 5000 (1388H) and 50 (0032H) to 0004H and 0005H of the VFD whose address is 02H, the frame structure is as follows.

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR	02H
CMD	10H
MSB of data writing address	00H
LSB of data writing address	04H
Data count MSB	00H
Data count LSB	02H
Bytes	04H
MSB of data to be written to 0004H	13H
LSB of data to be written to 0004H	88H
MSB of data to be written to 0005H	00H
LSB of data to be written to 0005H	32H
CRC LSB	C5H
CRC MSB	6EH

RTU master command (from the master to the VFD)

END

T1-T2-T3-T4 (transmission time of 3.5 bytes)

RTU slave response (from the VFD to the master)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR	02H
CMD	10H
MSB of data writing address	00H
LSB of data writing address	04H
Data count MSB	00H
Data count LSB	02H
CRC LSB	C5H
CRC MSB	6EH
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)

### 9.4.4 Data address definition

This section describes the address definition of communication data. The addresses are used for controlling the running, obtaining the state information, and setting related function parameters of the VFD.

### 9.4.4.1 Function code address format rules

The address of a function code consists of two bytes, with the high-order byte on the left and low-order byte on the right. The MSB ranges from 00 to FFH, and the LSB also ranges from 00 to FFH. The MSB is the hexadecimal form of the group number before the dot mark, and LSB is that of the number behind the dot mark. Take P05.06 as an example. The group number is 05, that is, the MSB of the parameter address is the hexadecimal form of 05; and the number behind the dot mark is 06, that is, the LSB is the hexadecimal form of 05. Therefore, the function code address is 0506H in the hexadecimal form. For P10.01, the parameter address is 0A01H.

Function code	Name	Description	Setting range	Default	Modify
P10.00	Simple PLC mode	0: Stop after running once 1: Keep running with the final value after running once 2: Cyclic running	0–2	0	0
P10.01	Simple PLC memory selection	0: Do not memorize at power outage 1: Memorize at power off	0–1	0	0

#### Note:

 The parameters in the P99 group are set by the manufacturer and cannot be read or modified. Some parameters cannot be modified when the VFD is running; some cannot be modified regardless of the VFD status. Pay attention to the setting range, unit, and description of a parameter when modifying it. The service life of the Electrically Erasable Programmable Read-Only Memory (EEPROM) may be reduced if it is frequently used for storage. Some function codes do not need to be stored during communication. The application requirements can be met by modifying the value of the on-chip RAM, that is, modifying the MSB of the corresponding function code address from 0 to 1. For example, if P00.07 is not to be stored in the EEPROM, you need only to modify the value of the RAM, that is, set the address to 8007H. The address can be used only for writing data to the on-chip RAM, and it is invalid when used for reading data.

# 9.4.4.2 Addresses of other Modbus functions

In addition to modifying the parameters of the VFD, the master can also control the VFD, such as starting and stopping the VFD, and monitoring the running status of the VFD. The following table lists other function parameters.

Function description	Address	Data description	R/W	
		0001H: Run forward		
Communication- based control command	2000H	0002H: Run reversely		
		0003H: Jog forward		
		0004H: Jog reversely	R/W	
		0005H: Stop		
		0006H: Coast to stop		
		0007H: Fault reset		
		0008H: Jogging stop		
	2001H	Communication-based frequency setting (0-Fmax;	R/W	
Communication- based setting		PID reference (0, 1000, in which 1000 corresponds to		
	2002H	100.0%)		
	2003H	PID feedback (0-1000, in which 1000 corresponds to	R/W	
		100.0%)		
	2004H	Torque setting (-3000–3000, in which 1000 corresponds to 100.0% of the motor rated current)	R/W	
	2005H	05H Upper limit setting of forward running frequency (0-		
address		Fmax; unit: 0.01 Hz)	1.7.00	
	2006H	Upper limit setting of reverse running frequency (0– Fmax: unit: 0.01Hz)	R/W	
		Electromotive torque upper limit (0-3000, in which		
	2007H	1000 corresponds to 100.0% of the motor rated	R/W	
		current)		
	2008	Braking torque upper limit (0–3000, in which 1000	DAM	
	2008H	corresponds to 100.0% of the motor rated current)	R/W	

Function description	Address	Data description	R/W
	2009H	Special control command word Bit1-2: = 00: Motor 1 =01: Motor 0 Bit2: =1: Enable speed/torque control switchover =0: Disable speed/torque control switchover Bit3: =1: Clear electricity consumption data =0: Keep electricity consumption data Bit4: =1: Enable pre-excitation =0: Disable pre-excitation Bit5: =1: Enable DC braking =0: Disable DC braking	R/W
	200AH	Virtual input terminal command. Range: 0x000–0x3FF (corresponding to S8/S7/S6/S5/HDIB/ HDIA/S4/S3/S2/S1 in sequence)	R/W
	200BH	Virtual output terminal command (range: 0x00–0x0F) (corresponding to local RO2/RO1/HDO/Y1)	R/W
	200CH	Voltage setting (used when V/F separation is implemented) (0–1000, in which 1000 corresponds to 100.0% of the motor rated voltage)	R/W
	200DH	AO setting 1 (-1000–+1000, in which 1000 corresponding to 100.0%)	R/W
	200EH AO setting 2 (-1000-+1000, in which corresponding to 100.0%)		R/W
VFD status word	2100H	0001H: Forward running 0002H: Reverse running 0003H: Stopped 0004H: Faulty 0005H: POFF state	R
VFD status word 2	2101H	Bit0: =0: Not ready to run =1: Ready to run Bit2-2: = 00: Motor 1 =01: Motor 1 Bit3: =0: AM =1: SM Bit4: = 0: No pre-alarm upon overload =1: Overload pre-alarm Bit6-bit5=00: Keypad-based control =01: Terminal-based control =10: Communication-based control Bit7: Reserved	R

Function description	Address	Data description	R/W	
		Bit8=0: Speed control =1: Torque contro		
		Bit9=0: Non position control		
		=1: Position control		
		Bit11–Bit10=0: Vector 0		
		=1: Vector 1		
		=2: Closed-loop vector		
		= 3: Space voltage vector		
VFD fault code	2102H	See the description of fault types.		R
VFD				
identification	2103H	GD3500x01A0		R
code				
Running	3000H	0–Fmax (Unit: 0.01Hz)		R
Trequency	000411	0. En en (1 heite 0.041 he)		
Set frequency	3001H			ĸ
Bus voltage	3002H	0.0–2000.0V (Unit: 0.1V)		R
Output voltage	3003H	0–1200V (Unit: 1V)	Compatible with CHF100A and CHV100 communicati on	R
Output current	3004H	0.0–3000.0A (Unit: 0.1A)		R
Rotational speed	3005H	0–65535 (Unit: 1RPM)		R
Output power	3006H	-300.0–300.0% (Unit: 0.1%)		R
Output torque	3007H	-250.0–250.0% (Unit: 0.1%)		R
Closed-loop setting	3008H	-100.0–100.0% (Unit: 0.1%)		R
Closed-loop	3009H	-100.0–100.0% (Unit: 0.1%)		R
Teeuback				
Input IO state	300AH	Corresponding to the least HDIP(		Р
Input IO state				ĸ
		HDIA/34/33/32/31	addresses	
Output IO state	300BH	Corresponding to local		D
				ĸ
Analog input 1	300CH	0.00–10.00V (Unit: 0.01V)		R
Analog input 2	300DH	0.00-10.00V (Unit: 0.01V)		R
Analog input 3	300FH	-10.00–10.00V (Unit: 0.01V)	-	R
Analog input 4	300FH			R
Read input of	500111			
HDIA high-speed	3010H	0.00–50.00kHz (Unit: 0.01Hz)		R
pulse		······		-
Function description	Address	Data description	R/W	
--	---------	----------------------------	-----	
Read input of HDIB high-speed pulse	3011H		R	
Read the actual step of multi-step speed	3012H	0–15	R	
External length value	3013H	0–65535	R	
External counting value	3014H	0–65535	R	
Torque set value	3015H	-300.0–300.0% (Unit: 0.1%)	R	
VFD identification code	3016H		R	
Fault code	5000H		R	

The Read/Write (R/W) characteristics indicate whether a function code can be read and written. For example, "Communication-based control command" can be written, and therefore the command code 06H is used to control the VFD. The R characteristic indicates that a function parameter can only be read, and W indicates that a function parameter can only be written.

**Note:** Some parameters in the preceding table are valid only after they are enabled. Take the running and stop operations as examples, you need to set "Running command channel" (P00.01) to "Communication", and set "Communication mode of running commands" (P00.02) to Modbus/Modbus TCP. For another example, when modifying "PID reference", you need to set "PID reference source" (P09.00) to Modbus/Modbus TCP communication.

The following table describes the encoding rules of device codes (corresponding to the VFD identification code 2103H).

8 MSBs	Meaning	8 LSBs	Meaning	
0x01	Goodrive	0x08	Goodrive35 vector VFD	
		0x09	Goodrive35-H1 vector VFD	
		0x0a	Goodrive300 vector VFD	
		0xa0	Goodrive350 vector VFD	

#### 9.4.5 Fieldbus scale

In practical applications, communication data is represented in the hexadecimal form, but hexadecimal values cannot represent decimals. For example, 50.12 Hz cannot be represented in the hexadecimal form. In such cases, multiply 50.12 by 100 to obtain an integer 5012, and

then 50.12 can be represented as 1394H in the hexadecimal form (5012 in the decimal form).

In the process of multiplying a non-integer by a multiple to obtain an integer, the multiple is referred to as a fieldbus scale.

The fieldbus scale depends on the number of decimal places in the value specified in "Setting range" or "Default". If there are n (for example, 1) decimal places in the value, the fieldbus scale m (then m=10) is the result of 10 to the power of n. Take the following as an example.

Function code	Name	Description	Setting range	Default	Modify
P01.20	Wake-up-from-sleep delay	0.0–3600.0s (valid only when P01.19 ones place=2)	0.00–3600.0	0.0s	0
P01.21	Power-off restart selection	0: Disable restart 1: Enable restart	0–1	0	0

The value specified in "Setting range" or "Default" contains one decimal place, and therefore the fieldbus scale is 10. If the value received by the upper computer is 50, "Delay of auto fault reset" of the rectifier is 5.0 (5.0=50÷10).

To set "Wake-up-from-sleep delay" to 5.0s through Modbus communication, you need first to multiply 5.0 by 10 according to the scale to obtain an integer 50, that is, 32H in the hexadecimal form, and then send the following write command:

#### 06 01 14 00 32 49 E7

VFD	Write	Parameter	Parameter	CRC
address	command	address	data	

After receiving the command, the VFD converts 50 into 5.0 based on the fieldbus scale, and then sets "Wake-up-from-sleep delay" to 5.0s.

For another example, after the upper computer sends the "Wake-up-from-sleep delay" parameter read command, the master receives the following response from the VFD:



command



data



The parameter data is 0032H, that is, 50, and therefore 5.0 is obtained based on the fieldbus scale (50/10=5.0). In this case, the master identifies that "Wake-up-from-sleep delay" is 5.0s.

#### 9.4.6 Error message response

Operation errors may occur in communication-based control. For example, some parameters can only be read, but a write command is sent. In this case, the VFD returns an error message response.

Error message responses are sent from the VFD to the master. The following table lists the

codes and definitions of the error message responses.

Code	Name	Description
		The command code received by the upper computer is not allowed to be
	Invalid	executed. The possible causes are as follows:
01H	command	• The function code is applicable only on new devices and is not
	oonnana	implemented on this device.
		• The slave is in the faulty state when processing this request.
	Invalid data	For the VFD, the data address in the request of the upper computer is
02H	addross	not allowed. In particular, the combination of the register address and
	audress	the number of the to-be-sent bytes is invalid.
		The received data domain contains a value that is not allowed. The
	Invalid data	value indicates the error of the remaining structure in the combined
03H		request.
	value	Note: It does not mean that the data item submitted for storage in the
		register includes a value unexpected by the program.
Operation		The parameter is set to an invalid value in the write operation. For
04⊓	failure	example, a function input terminal cannot be set repeatedly.
0511	Incorrect	The password entered in the password verification address is different
051	password	from that set in P07.00.
	Data frama	The data frame sent from the host controller is incorrect in the length, or
06H	Data frame	in the RTU format, the value of the CRC check bit is inconsistent with
	error	the CRC value calculated by the lower computer.
0711	Parameter	The parameter to be modified in the write operation of the host controller
07H	read-only	is a read-only parameter.
	Parameter	
0011	cannot be	The parameter to be modified in the write operation of the host controller
08H	modified in	cannot be modified during the running of the VFD.
	running	
	- ·	If the host controller does not provide the correct password to unlock the
09H	Password	system to perform a read or write operation, the error of "system being
	protection	locked" is reported.

When returning a response, the slave uses a function code domain and fault address to indicate whether it is a normal response (no error) or exception response (an error occurs). In a normal response, the slave returns the corresponding function code and data address or sub-function code. In an exception response, the slave returns a code that is equal to a normal code, but the first bit is logic 1.

For example, if the master sends a request message to a slave for reading a group of function code address data, the following code is generated:

0 0 0 0 0 0 1 1 (03H in the hexadecimal form)

In a normal response, the slave returns the same function code. In an exception response, the slave returns the following code:

1 0 0 0 0 1 1 (83H in the hexadecimal form)

In addition to the modification of the code, the slave returns a byte of exception code that describes the cause of the exception. After receiving the exception response, the typical processing of the master is to send the request message again or modify the command based on the fault information.

For example, to set the "Channel of running commands" (P00.01, the parameter address is 0001H) to 03 for the VFD whose address is 01H, the command is as follows:

01<br/>VFD06<br/>Write00 01<br/>Parameter<br/>address00 03<br/>Parameter<br/>data98 0B<br/>CRC

However, the "Running command channel" ranges from 0 to 2. The value 3 is out of the setting range. In this case, the VFD returns an error message response as shown in the following:



The exception response code 86H (generated based on the highest-order bit "1" of the write command 06H) indicates that it is an exception response to the write command (06H). The error code is 04H, which indicates "Operation failure".

#### 9.4.7 Read/Write operation examples

For the formats of the read and write commands, see section 9.4.1 and 9.4.2.

#### 9.4.7.1 Example of reading command 03H

Example 1: Read SW 1 of the VFD whose address is 01H. According to the table of other Modbus function addresses in section 9.4.4.2 Addresses of other Modbus functions, the parameter address of state word 1 of the VFD is 2100H.

The read command transmitted to the VFD is as follows:

01 VED

address

\_\_\_\_\_

<u>U3</u> Read

command

Parameter address

00

Data quantity

00 01

CRC

8E 36

Assume that the following response is returned:



The data content returned by the VFD is 0003H, which indicates that the VFD is in the stopped state.

Example 2: View information about the VFD whose address is 03H, including "Type of present fault" (P07.27) to "Type of 5th-last fault" (P07.32) of which the parameter addresses are 071BH to 0720H (contiguous 6 parameter addresses starting from 071BH).

The command transmitted to the VFD is as follows:

<u>03</u>	<u>03</u>	<u>07 1B</u>	<u>00 06</u>	<u>B5 59</u>
VFD address	Read command	Start address	6 parameters in total	CRC

Assume that the following response is returned:

fault type

type



type

According to the returned data, all the fault types are 0023H, that is, 35 in the decimal form, which means the STo fault.

type

type

type

#### 9.4.7.2 Example of writing command 06H

address command bytes

Example 1: Set the VFD whose address is 03H to run forward. According to the table of address description of other function codes in section 9.4.4.2 Addresses of other Modbus functions, the parameter address of "communication-based control command" is 2000H and forward running is 0001H. See the following figure.

Function description	Address	Data description	R/W
		0001H: Run forward	
		0002H: Run reversely	
Communication	000011	0003H: Jog forward	
		0004H: Jog reversely	DAM
-based control	2000H	0005H: Stop	K/W
	0006H: Coast to stop 0007H: Fault reset	0006H: Coast to stop	
		0007H: Fault reset	
		0008H: Jogging stop	

The command sent from the master is as follows:



If the operation is successful, the following response (same as the command transmitted from the master) is returned:

03	
VFF	1

address



20 00 Parameter Write address

command

00 01 Forward running

12 28

CRC

Example 2: Set the max. output frequency to 100Hz for the VFD with the address of 03H.

Function code	Name	Description	Setting range	Default	Modify
P00.03	Max. output frequency	P00.04–599.00Hz	P00.04– 599.00	50.00Hz	O

According to the number of decimal places, the fieldbus scale of the "Max. output frequency" (P00.03) is 100. Multiply 100kHz by 100. The value 10000 is obtained, and it is 2710H in the hexadecimal form.

The command sent from the master is as follows:

06







Parameter

address

27 10 Parameter data

62 14

VFD address

Write command

CRC

If the operation is successful, the following response (same as the command transmitted from the master) is returned:

VFD

address

00 03 16 Write Parameter command address

27 10 Parameter data

CRC

Note: In the preceding command description, spaces are added to a command just for explanatory purposes. In practical applications, no space is required in the commands.

## 9.4.7.3 Example of continuous writing command 10H

Example 1: Set the VFD whose address is 01H to be forward running at the frequency of 10 Hz. Refer to section 9.4.4.2 Addresses of other Modbus functions, the address of "Communication-based control command" is 2000H, 0001H indicates forward running, and the address of "Communication-based value setting" is 2001H, as shown in the following figure. 10 Hz is 03F8H in the hexadecimal form.

Function description	Address	Data description	R/W
		0001H: Run forward	
		0002H: Run reversely	
		0003H: Jog forward	
Communication-	200011	0004H: Jog reversely	R/W
based control	2000	0005H: Stop	
command		0006H: Coast to stop	
		0007H: Fault reset	
		0008H: Jogging stop	
Communication	200411	Communication-based frequency setting (0–Fmax; unit:	
based setting address	2001H	0.01 Hz)	
	2002	PID reference (0-1000, in which 1000 corresponds to	r///
	2002H	100.0%)	

In the actual operation, set P00.01 to 2 and P00.06 to 8.

The command sent from the master is as follows:



If the operation is successful, the following response is returned:

01 VED

address



command

20 00 Parameter address

Parameter guantity

00 02

4A 08 CRC

Example 2: Set "Acceleration time" of the VFD whose address is 01H to 10s, and "Deceleration time" to 20s.

Function code	Name	Description	Default	Modify
P00.11	ACC time 1	P00.11 and P00.12 setting range: 0.0-	Model depended	0
P00.12	DEC time 1	3600.0s	Model depended	0

The address of P00.11 is 000B, 10s is 0064H in the hexadecimal form, and 20s is 00C8H in the hexadecimal form.

The command sent from the master is as follows:



If the operation is successful, the following response is returned:



**Note:** In the preceding command description, spaces are added to a command just for explanatory purposes. In practical applications, no space is required in the commands.

#### 9.4.7.4 Example of Modbus communication commissioning

In the following example, a PC is used as the master, an RS232-RS485 converter is used for signal conversion, and the PC serial port used by the converter is COM1 (an RS232 port). The host controller commissioning software is the serial port commissioning assistant Commix, which can be downloaded from the Internet. Download a version that can automatically execute the CRC check function. The following figure shows the interface of Commix.

🕿 Commix 1.4		
Port: COM1 -	BaudRate: 9600 - Apply DTR RTS	Open Port
DataBits: 8 💌	Parity: None StopBits: 1 V No CRC	Pause
Input HEX Show HEX Input ASC Show ASC	Ignore Space IV New Line IV Show Interval	Clear
		(ѯ) Send ▼ by Enter

First, set the serial port to **COM1**. Then, set the baud rate consistently with P14.01. The data bits, check bits, and stop bits must be set consistently with P14.02. If the RTU mode is selected, you need to select the hexadecimal form **Input HEX**. To set the software to automatically execute the CRC function, you need to select **ModbusRTU**, select **CRC16** (MODBU SRTU), and set the start byte to 1. After the auto CRC check function is enabled, do not enter CRC information in commands. Otherwise, command errors may occur due to repeated CRC check.

The commissioning command to set the VFD whose address is 03H to run forward is as follows:



Write

20 00

VFD address Parameter address

command

Forward running

00 01

CRC

Note:

- Set the address (P14.00) of the VFD to 03. •
- Set P00.01 (Running command channel) to "Communication", and set P00.02 (Communication running command channel) to "Modbus/Modbus TCP".
- After you click Send, if the line configuration and settings are correct, a response transmitted by the VFD is received.



# 9.5 Common communication faults

Common communication faults include the following:

- No response is returned.
- The VFD returns an exception response.

Possible causes of no response include the following:

- 1. The serial port is set incorrectly. For example, the adapter uses the serial port COM1, but COM2 is selected for the communication.
- 2. The settings of the baud rates, data bits, end bits, and check bits are inconsistent with those set on the VFD.
- 3. The positive pole (+) and negative pole (-) of the RS485 bus are connected reversely.
- 4. The resistor connected to 485 terminals on the terminal block of the VFD is set incorrectly.

# Appendix A Expansion card

# A.1 Model definition

<u>EC-</u>	PG	<u>5</u>	<u>01</u> ·	- <u>05</u>	<u>B</u>
(1)	2	3	4	5	6

Symbol	Description	Naming example			
1	Product category	EC expansion card			
		IC: IoT card IO: IO expansion card			
	Board card	PC: Programmable card			
(2)	category	PG: PG card			
		PS: Power supply card			
		TX: communication extension card			
	Technology	Indicates the generation of a technical version by using odd			
3	version	numbers, for example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd			
	Version	and 4th generations of the technical version.			
		02: Sine/Cosine PG card + pulse direction setting +			
		frequency-divided output			
		03: UVW PG interface + pulse direction setting +			
		frequency-divided output			
	Distinguishing	04: Resolver PG interface + pulse direction setting +			
4	code	frequency-divided output			
		05: Incremental PG card + pulse direction setting +			
		frequency-divided output			
		06: Absolute PG interface + pulse direction setting +			
		frequency-divided output			
		07: Simplified incremental PG card			
		00: Passive			
5	Working power	05: 5V			
	from any porton	12: 12–15V			
		24: 24V			
	Expansion card	Empty: Version A			
6	version	B: Version B			
	10101011	C: Version C			

# EC-PC 5 02-00 1 2 3 4 5

Symbol	Description	Naming example
1	Product category	EC expansion card
2	Board card category	IC: IoT card IO: IO expansion card PC: Programmable card PG: PG card PS: Power supply card TX: communication extension card
3	Technology version	Indicates the generation of a technical version by using odd numbers, for example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd and 4th generations of the technical version.
(4)	Distinguishin	01: 10 points, with 6 inputs and 4 outputs (2 transistor outputs + 2 relay outputs) 02: 8 points of IQ 1 point of AL 1 point of AQ, and 1 point of
(4)	g code	RS485 communication 03: Reserved
5	Special requirement	Reserved

# EC-TX 5 01 B 1 2 3 4 5

Symbol	Description	Naming example
1	Product category	EC expansion card
2	Board card category	IC: IoT card IO: IO expansion card PC: Programmable card PG: PG card PS: Power supply card
		TX: communication extension card
3	Technology version	Indicates the generation of a technical version by using odd numbers, for example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd and 4th generations of the technical version.
4	Distinguishing	01: Bluetooth communication card

Symbol	Description	Naming example
	code	02: Wi-Fi communication card
		03: PROFIBUS communication card
		04: Ethernet communication card
		05: CAN multi-protocol communication card
		06: DeviceNet communication card
		07: BACnet communication card
		08: EtherCAT communication card
		09: PROFINET communication card
		10: 485 communication card
		15: Modbus TCP communication card
		Empty: Version A
5	Expansion card	B: Version B
	version	C: Version C

# <u>EC-IO 5 01-00</u>

1 2 3 4 5

Symbol	Description	Naming example
1	Product category	EC expansion card
		IC: IoT card
		IO: IO expansion card
0	Board card	PC: Programmable card
2	category	PG: PG card
		PS: Power supply card
		TX: communication extension card
	Technology	Indicates the generation of a technical version by using odd
3	Technology	numbers, for example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd
	version	and 4th generations of the technical version.
		01: Multiple-function I/O expansion card (four digital inputs, one
		digital output, one analog input, one analog output, and two
	Diatis suriatis s	relay outputs)
(4)	Distinguisning	02: Digital I/O card
	code	03: Analog I/O card
		04: Reserved 1
		05: Reserved 2
	Special	
(5)	requirement	

<u>EC</u> -	<u>IC</u>	<u>5</u>	<u>01</u>	-	<u>2</u>	<u>1</u>	<u>G</u>
1	2	3	4		5	6	$\bigcirc$

Symbol	Description	Naming example
1)	Product category	EC expansion card
		TX: communication extension card
	Deerd cord	PG: PG card
2	Board card	PC: PLC programmable card
	category	IO: IO expansion card
		IC: IoT card
	Technology	Indicates the generation of a technical version by using odd
3	version	numbers, for example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd
	VEISION	and 4th generations of the technical version.
	Product code	01: GPRS card
4	(IoT cord)	02: 4G card
	(IUT calu)	03: Reserved
	Antenna types	
6	for wireless	1: Built in
9	communication	2: External
	cards	
		0: Plug-in card (Standard, default)
6	SIM card type	1: Embedded SIM card
	Silvi card type	Note: When this field is 0 or omitted, the SIM card type is
		plug-in.
		G: With GPS
	Special function	S: Surface mounted SIM card
U	Special function	Note: When this field is omitted, the expansion card does not
		have special functions.

# $\underline{EC}_{1} - \underline{IC}_{2} \underbrace{5}_{3} \underbrace{02}_{4} - \underbrace{2}_{5} \underbrace{1}_{6} \underbrace{G}_{7} - \underbrace{CN}_{8}$

Symbol	Description	Naming example
1	Product category	EC expansion card
2	Board card category	TX: communication extension card PG: PG card PC: PLC programmable card IO: IO expansion card IC: IoT card

Symbol	Description	Naming example
	Tachnalag	Indicates the generation of a technical version by using odd
③ version	Technology	numbers, for example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd
	and 4th generations of the technical version.	
	Droduct code	01: GPRS card
4		02: 4G card
	(IOT card)	03: Reserved
	Antenna types	
ē	for wireless	1: Built in
(5)	communication	2: External
	cards	
		0: Plug-in
	SIM card type	1: Surface mounted
0		Note: When this field is 0 or omitted, the SIM card type is
		plug-in.
		G: With GPS
$\bigcirc$	Special function	Note: When this field is omitted, the expansion card does not
		have special functions.
		CN: China version
8	International	EU: Europe version
		LA: Latin America version
	version	Note: A 4G SIM card is a standard configuration for the CN
		version, but not for the EU or LA version.

The following table describes expansion cards that the VFD supports. The expansion cards are optional and need to be purchased separately.

Name	Model	Specification	Ordering code
IO expansion card	EC-IO501-00	<ul> <li>Four digital inputs</li> <li>One digital output</li> <li>One analog input</li> <li>One analog output</li> <li>Two relay outputs: one double-contact output, and one single-contact output.</li> </ul>	11023-00083
I/O expansion card 2	EC-10502-00	<ul> <li>Four digital inputs</li> <li>One PT100</li> <li>One PT1000</li> <li>Two relay outputs: single-contact NO.</li> </ul>	11023-00119
Programmable card	EC-PC502-00	<ul> <li>Adopting the global mainstream programmable card development environment, supporting multiple</li> </ul>	11023-00146

Name	Model	Specification	Ordering code
		<ul> <li>programming languages such as the instruction language, ladder diagram, and sequential function chart.</li> <li>Supporting resumable commissioning and task period execution mode selection;</li> <li>Providing a user program storage space of 16K steps and data storage space of 8K words;</li> <li>Six digital inputs:</li> <li>Two relay outputs;</li> <li>One analog input and 1 output;</li> <li>One RS485 communication channel, master/slave switchover by upper computer;</li> <li>Supporting saving data of 1K words at power failure.</li> </ul>	
	EC-TX501-1	Supporting Bluetooth 4.0	11023-00101
Bluetooth communication card	EC-TX501-2	<ul> <li>With INVT's mobile phone APP, you can set the parameters and monitor the states of the VFD through Bluetooth.</li> <li>Maximum communication distance in open environments: 30m</li> <li>EC-TX501-1 is equipped with a built-in antenna and applicable to molded case machines.</li> <li>EC-TX501-2 is equipped with an external sucker antenna and applicable to sheet metal machines.</li> </ul>	11023-00102
	EC-TX502-1	• Meeting requirements of IEEE802.11b/g/n.	11023-00101
WIFI communication card	EC-TX502-2	<ul> <li>With INVT's mobile phone APP, you can monitor the VFD locally or remotely through WIFI</li> <li>Maximum communication distance in open environments: 30m</li> <li>EC-TX502-1 is equipped with a built-in antenna and applicable to molded case machines</li> <li>EC-TX502-2 is equipped with an external sucker antenna and applicable to sheet</li> </ul>	11023-00102

Expansion card

Name	Model	Specification	Ordering code
		metal machines	
PROFIBUS-DP communication card	EC-TX503D	Supporting the PROFIBUS-DP protocol	11023-00151
CAN multi-protocol communication card	EC-TX505D	<ul> <li>Based on the CAN2.0A and CAN2.0B physical layer</li> <li>Supporting the CANopen protocol.</li> <li>Adopting INVT's master-slave control proprietary protocol.</li> </ul>	11023-00164
PROFINET communication card	EC-TX509C	Supporting the PROFINET protocol	11023-00149
EtherNet IP multi-protocol communication card	EC-TX510B	<ul> <li>Set the switch to EtherNet IP:</li> <li>\$ Supporting the EtherNet IP protocol and EtherNet IP slaves</li> <li>\$ Equipped with two EtherNet IP ports, supporting 10/100M half/full duplex operating</li> <li>\$ Equipped with two standard RJ45 interfaces, which do not distinguish the direction and can be swappable</li> <li>\$ Supporting star and line IP network topologies</li> <li>Set the switch to Modbus TCP:</li> <li>\$ Supporting the Modbus TCP protocol and Modbus TCP secondary nodes</li> <li>\$ Equipped with two Modbus TCP ports, supporting 10/100M half/full duplex operating</li> <li>\$ Supporting star and line TCP network topologies</li> <li>Set the switch to Ethernet:</li> <li>\$ Supporting INVT Ethernet protocol</li> <li>\$ Supporting the connection to INVT's host controller monitoring and oscillography, allowing multi-card networking monitoring</li> </ul>	11023-00197

Name Model Specification					
Sin/Cos PG card	EC-PG502	<ul> <li>Applicable to Sin/Cos encoders with or without CD signals.</li> <li>Supporting A, B, Z frequency-divided output;</li> <li>Supporting input of pulse train reference</li> </ul>	11023-00109		
Incremental PG card with UVW	EC-PG503-05	<ul> <li>Applicable to differential encoders of 5V.</li> <li>Supporting the orthogonal input of A, B, and Z</li> <li>Supporting pulse input of phase U, V, and W;</li> <li>Supporting the frequency-divided output of A, B, and Z.</li> <li>Supporting input of pulse train reference</li> </ul>	11023-00085		
Resolver PG card	EC-PG504-00	<ul> <li>Applicable to resolver encoders</li> <li>Supporting frequency-divided output of resolver-simulated A, B, Z</li> <li>Supporting input of pulse train reference</li> </ul>	11023-00086		
Multi-function incremental PG card	EC-PG505-12	<ul> <li>Applicable to OC encoders of 5 V or 12 V</li> <li>Applicable to push-pull encoders of 5 V or 12V;</li> <li>Applicable to differential encoders of 5V.</li> <li>Supporting the orthogonal input of A, B, and Z</li> <li>Supporting the frequency-divided output of A, B, and Z.</li> <li>Supporting input of pulse train reference</li> </ul>	11023-00087		
24V incremental PG card	EC-PG505-24B	<ul> <li>Applicable to OC encoders of 24V.</li> <li>Applicable to push-pull encoders of 24V;</li> <li>Supporting the orthogonal input of A, B, and Z</li> <li>Supporting the frequency-divided output of A, B, and Z.</li> <li>Supporting input of pulse train reference</li> </ul>	11023-00139		
Simplified incremental PG card	EC-PG507-12	<ul> <li>Applicable to OC encoders of 5 V or 12 V</li> <li>Applicable to push-pull encoders of 5 V or 12V;</li> <li>Applicable to differential encoders of 5V.</li> </ul>	11023-00115		
24V simplified incremental PG card	EC-PG507-24	<ul> <li>Applicable to OC encoders of 24V.</li> <li>Applicable to push-pull encoders of 24V;</li> <li>Applicable to differential encoders of 24V.</li> </ul>	11023-00121		

Goodrive350 IP55 High-ingress Protection Series VFD

Expansion card

Name	Model	Specification	Ordering code
GPRS extension card	EC-IC501-2	<ul><li>Supporting IoT monitoring</li><li>Supporting remote VFD upgrade</li></ul>	11023-00130
10	EC-IC502-2-CN		11095-00009
4G expansion	EC-IC502-2-EU	Supporting standard RS485 interface	11095-00017
card	EC-IC502-2-LA	<ul> <li>Supporting 4G communication</li> </ul>	11095-00018

**Note:** Please contact us for details about the EtherCAT communication card, 24V power supply card, and the shockproof GPRS card with high-precision GPS positioning.









IO extension card EC-IO501-00

IO extension card 2 EC-IO502-00

Programmable extension card EC-PC502-00

Bluetooth/WIFI communication card EC-TX501/502

Goodrive350 IP55 High-ingress Protection Series VFD

Expansion card



PROFIBUS-DP communication card EC-TX503D



CAN multi-protocol communication card EC-TX505D



PROFINET communication card EC-TX509C



EtherNet IP multi-protocol communication card EC-TX510B



Sin/Cos PG card EC-PG502



Incremental PG card with UVW EC-PG503-05



Resolver PG card EC-PG504-00



Multi-function incremental PG card EC-PG505-12

#### Goodrive350 IP55 High-ingress Protection Series VFD

#### Expansion card



24V incremental PG card EC-PG505-24B



Simplified incremental PG card EC-PG507-12



24V simplified incremental PG card EC-PG507-24



GPRS IoT card EC-IC501-2



4G expansion card EC-IC502-2-CN EC-IC502-2-EU EC-IC502-2-LA

#### A.2 Dimensions and installation

All expansion cards are of the same dimensions (108×39mm) and can be installed in the same way.

Comply with the following rules when installing or removing an expansion card:

- 1. Ensure that no power is applied before installing the extension card.
- The extension card can be installed in any one of the SLOT1, SLOT2, and SLOT3 card slots.
- 3. The VFD supports the simultaneous installation of three expansion cards.
- 4. If interference occurs on the external wires after the expansion card is installed, change the installation slot flexibly to facilitate the wiring. For example, the connector of the connection cable of the DP card is large, and you are recommended to install the card at SLOT1.

The following figure shows the installation diagram and the VFD with expansion cards installed.

Figure A-1 VFD of 7R5G/011P or higher models with expansion cards installed



EC installation diagram

Diagram of ECs installed

Expansion card installation procedure:





# A.3 Wiring

1. Ground a shielded cable as follows:

#### Figure A-3 Expansion card grounding diagram



2. Wire an expansion card as follows:

Figure A-4 Expansion card wiring diagram



# A.4 I/O expansion cards

## A.4.1 I/O expansion card 1 (EC-IO501-00)



The terminals are arranged as follows:

CME and COM are shorted through J3 before delivery, and J5 is the jumper for selecting the output type (voltage or current) of AO2.

AI3			AO2		G	SND				
COM	CME	Y2	S5		RO3A	ROS	3B	RC	)3C	
PW	+24V	S6	S7	S8	I	RO4A			RO	4C

Indicator definition:

Indicator	Definition	Function
		On: The expansion card is establishing a connection with the
LED1		control board.
	Status indicator	Blinks periodically: The expansion card is properly connected to
		the control board (the period is 1s, on for 0.5s, and off for the
		other 0.5s).
		Off: The expansion card is disconnected from the control board.
LED4		This indicator is on after the IO extension card is powered on by
	Power indicator	the control board.

The EC-IO501-00 extension card can be used in scenarios where the I/O interfaces of a VFD cannot meet the application requirements. It can provide 4 digital inputs, 1 digital output, 1 analog input, 1 analog output, and two relay outputs. It is user-friendly, providing relay outputs through European-type screw terminals and other inputs and outputs through spring terminals.

Category	Terminal symbol	Terminal name	Description						
Power	PW	External power	External	power	input	terminal	for	digital	input
supply	ΓVV	External power	circuits						

EC-IO501-00 terminal function description

Expansion card

Category	Terminal symbol	Terminal name	Description				
			Voltage range: 12–30V				
			PW and +24V have been short connected before				
			delivery.				
			<ul> <li>Input range: For AI3, 0–10V or 0–20mA</li> </ul>				
			<ul> <li>Input impedance: 20kΩ for voltage input or</li> </ul>				
			$250\Omega$ for current input				
			<ul> <li>Whether voltage or current is used for input is</li> </ul>				
	AI3—GND	Analog input 1	set through the corresponding function code.				
Analog			<ul> <li>Resolution: 5mV when 10V corresponds to</li> </ul>				
			50Hz				
input/output			<ul> <li>Deviation: ±0.5%; input of 5V or 10mA or</li> </ul>				
			higher at the temperature of 25°C.				
			<ul> <li>Output range: 0–10V or 0–20mA</li> </ul>				
			<ul> <li>Whether voltage or current is used for output</li> </ul>				
	AO2—GND	Analog output 1	is set through the jumper J5				
			<ul> <li>Deviation: ±0.5%; output of 5 V or 10 mA or</li> </ul>				
			higher at the temperature of 25°C				
	S5—COM	Digital input 1	<ul> <li>Internal impedance: 3.3kΩ</li> </ul>				
	S6—COM	Digital input 2	<ul> <li>12–30V voltage input is acceptable</li> </ul>				
	S7—COM	Digital input 3	<ul> <li>Bi-direction input terminal</li> </ul>				
Digital	S8—COM	Digital input 4	Max. input frequency: 1kHz				
input/output			<ul> <li>Switch capacity: 50mA/30V</li> </ul>				
	V2 CME	Digital output	<ul> <li>Output frequency range: 0–1kHz</li> </ul>				
		Digital Output	<ul> <li>The terminals CME and COM are shorted</li> </ul>				
			through J3 before delivery.				
	RO3A	NO contact of relay 3					
	RO3B	NC contact of relay 3					
Relay	RO3C	Common contact of	<ul> <li>Contact capacity: 3A/AC250V, 1A/DC30V</li> </ul>				
	1000	relay 3	<ul> <li>Cannot be used as high frequency digital</li> </ul>				
oupur	RO4A	NO contact of relay 4	output.				
	RO4C	Common contact of					
	11040	relay 4					

#### A.4.2 IO expansion card 2 (EC-IO502-00)



The terminals are arranged as follows:

PT1+ PT-				P	Г2+			
S5	S6	S7	S8	RO4A	<b>۱</b>	RO4	C	
+24V	PW	СОМ	COM	RO3A		O3A	RO	3C

Indicator definition:

Indicator	Definition	Function
LED1	Status indicator	On: The expansion card is establishing a connection with the control board. Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s). Off: The communication card is disconnected from the control board.
LED4	Power indicator	This indicator is on after the IO extension card is powered on by the control board.

EC-IO502-00 can be used in scenarios where the I/O interfaces of a VFD cannot meet the application requirements. It can provide four digital inputs, one PT100 temperature measuring input (PT1+), one PT1000 temperature measuring input (PT2+), and two relay outputs. It is user-friendly, providing relay outputs and digital inputs through European-type screw terminals and temperature measuring inputs through spring terminals.

Category	Terminal symbol	Terminal name	Description
Power supply	PW	External power	External power input terminal for digital input circuits Voltage range: 24(-20%)–48VDC(+10%), 24(-10%)–48VAC(+10%) voltage input

EC-IO502-00 terminal function description

Category	Terminal symbol	Terminal name	Description					
	+24V	Internal power	User power supply provided by the VFD. Max. output current: 200mA					
	COM	Power reference	Reference ground of +24V					
	S5—COM	Digital input 5	<ul> <li>Internal impedance: 6.6kΩ</li> </ul>					
	S6—COM	Digital input 6	<ul> <li>Supporting the voltage input of external</li> </ul>					
	S7—COM	Digital input 7	power 24(-20%)–48VDC(+10%) and					
Digital input	S8—COM	Digital input 8	<ul> <li>24(-10%)–48VAC(+10%) voltage input</li> <li>Supporting the internal power 24V</li> <li>Bi-direction input terminal, supporting both NPN and PNP</li> <li>Max. input frequency: 1kHz</li> <li>All are programmable digital input terminals, the functions of which can be set through function codes</li> </ul>					
	PT1+	PT100 resistor input	Independent PT100 and PT1000 inputs:					
Temperatu re detection input	PT2+	PT1000 resistor input	<ul> <li>PT1+ connects to PT100 resistor, while PT2+ connects to PT1000 resistor.</li> <li>Resolution rate: 1°C</li> <li>Range -20°C-150°C</li> <li>Detection precision: 3°C</li> <li>Supporting offline protection</li> </ul>					
	PT-	Reference input of PT100/PT1000	Reference zero potential of PT100/PT1000					
	RO3A	Contact A of NO relay 3	RO3 outputs. RO3A: NO; RO3C: common					
Relay	RO3C	Contact C of NO relay 3	Contact capacity: 3A/AC250V, 1A/DC30V					
output	RO4A	Contact A of NO relay 4	RO4 outputs. RO4A: NO; RO4C: common					
	RO4C	Contact C of NO relay 4	Contact capacity: 3A/AC250V, 1A/DC30V					



#### Figure A-5 Control circuit wiring of I/O expansion card 2

# A.5 Programmable extension card (EC-PC502-00)



SW1 indicates the run-stop switch of the programmable expansion card, CN1 indicates the PE, 485-, 485+, GND, AI1, AO1 terminals with corresponding jumpers next to them. "AI" and "AV" are the current type input selection and voltage type input selection of AI1, and they can be selected through J2. "AIO" and "AVO" are the current type output selection and voltage type output selection of AO1, and they can be selected through J5. "120" indicates 120 $\Omega$  terminal resistor, and it can connect to J1. By default, J1 connects to NC, J2 to AV, and J5 to AVO. The terminals are arranged as follows.

PE	48	5-	485+	GND		Al1	Al1		AO1
COM	COM	PS1	PS2	PS3		PF	RO1A F		PRO1C
PW	24V	PS4	PS5	PS6			PRO2A		PRO2C

Indicator	Definition	Function
LED1	PWR power indicator (green)	The indicator is on when the expansion card is powered on.
LED3	COMM communication indicator (green)	On: The expansion card is establishing a connection with the control board. Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s). Off: The communication card is disconnected from the control board.
LED4	ERR fault indicator (red)	Blinks: an error occurs (the period is 1s, on for 0.5s, and off for the other 0.5s), and the error type can be queries through the host controller Auto Station; Off: no fault.
LED5	PWR power indicator (green)	The indicator is on when the expansion card is powered on.
LED6	RUN status indicator (green)	On: PLC program is running Off: PLC program stops

Indicator definition:

The EC-PC502-00 programmable expansion card can replace some micro PLC applications and utilizes an internationally mainstream programmable card development environment. It supports the instruction language (IL), ladder diagram (LD), and sequential function chart (SFC). It provides a user program storage space of 16K steps and data storage space of 8K words, and supports saving data of 1K words at power failure, facilitating secondary development for customers and meeting customization requirements.

The EC-PC502-00 programmable extension card provides 6 digital inputs, 2 relay outputs, 1 analog input, 1 analog output, 1 RS485 communication channel (supports master/slave switchover). It is user-friendly, providing relay outputs through European-type screw terminals and other inputs and outputs through spring terminals.

Category	Terminal symbol	Terminal name	Description
Power supply	PW	External power	External power input terminal for digital input circuits Voltage range: 12–24V PW and +24V should be short-connected.
	24V	Internal power	Internal output power, 100mA
Digital	PS1—COM	Digital input 1	<ul> <li>Internal impedance: 4kΩ</li> </ul>

EC-PC502-00 terminal function description

Category	Terminal symbol	Terminal name	Description
input/out	PS2—COM	Digital input 2	<ul> <li>12–30V voltage input is acceptable</li> </ul>
put	PS3—COM	Digital input 3	Bi-direction input terminal
	PS4—COM	Digital input 4	<ul> <li>Max. input frequency: 1kHz</li> </ul>
	PS5—COM	Digital input 5	<ul> <li>Source/sink inputs, and the input type should</li> </ul>
	PS6—COM	Digital input 6	be consistent
Analog input/out put	AI1	Analog input 1	<ul> <li>Input range: For Al1, 0–10V or 0–20mA</li> <li>Input impedance: 20kΩ for voltage input; 250Ω for current input</li> <li>Whether voltage or current is used for input is set through the jumper</li> <li>Resolution: 5mV when 10V corresponds to 50Hz</li> <li>Deviation: ±1%, 25°C, full measuring range</li> <li>Output range: 0–10V or 0–20mA</li> </ul>
	AO1	Analog output 1	<ul> <li>Whether voltage or current is used for output is set through the jumper</li> <li>Deviation: ±1%, 25°C, full measuring range</li> </ul>
	PRO1A	NO contact of relay 1	
Relay	PRO1C	Common contact of relay 1	<ul> <li>Contact capacity: 2A/AC250V, 1A/DC30V</li> <li>Cannot be used as high frequency digital</li> </ul>
output	PRO2A	NO contact of relay 2	output.
	PRO2C	Common contact of relay 2	

For details about how to use the programmable card, see the Goodrive350 series AutoStation programmable card manual.

## A.6 Communication cards

#### A.6.1 Bluetooth communication card (EC-TX501) and WIFI communication card (EC-TX502)



Definition of indicators and function keys:

Indicator	Definition	Function
LED1/LED3	Bluetooth/WIFI status indicator	This indicator is on when the expansion card is establishing a connection with the control board; it blinks periodically after the expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the expansion card is disconnected from the control board.
LED2	Bluetooth communication state indicator	This indicator is on when the communication card is online and data exchange can be performed. It is off when the Bluetooth communication card is not in the online state.
LED5	Power indicator	It is off when Bluetooth communication is not in the online state.
SW1	WIFI factory reset button	It is restored to default values and returned to the local monitoring mode.
SW2	WIFI hardware reset button	It is used to reboot the extension card.

The wireless communication card is especially useful for scenarios where you cannot directly use the keypad to operate the VFD due to the restriction of the installation space. With a mobile phone APP, you can operate the VFD in a maximum distance of 30 m. You can choose a PCB antenna or an external sucker antenna. If the VFD is located in an open space and is a molded case machine, you can use a built-in PCB antenna; and if it is a sheetmetal machine and located in a metal cabinet, you need to use an external sucker antenna.

When installing a sucker antenna, install a wireless communication card on the VFD first, and then lead the SMA connector of the sucker antenna into the VFD and screw it to CN2, as shown in the following figure. Place the antenna base on the chassis and expose the upper





The wireless communication card must be used with the INVT VFD APP. Scan the QR code of the VFD nameplate to download it. For details, refer to the wireless communication card manual provided with the extension card. The main interface is shown as follows.



#### A.6.2 PROFIBUS-DP communication card (EC-TX503D)



CN1 is a 9-pin D-type connector, as shown in the following figure.



Con	nector pin	Description
1	-	Unused
2	-	Unused
3	B-Line	Data+ (twisted pair 1)
4	RTS	Request sending
5	GND_BUS	Isolation ground
6	+5V BUS	Isolated power supply of 5 V DC
7	-	Unused
8	A-Line	Data- (twisted pair 2)
9	-	Unused
Housing	SHLD	PROFIBUS cable shielding line

+5V and GND\_BUS are bus terminators. Some devices, such as the optical transceiver (RS485), may need to obtain power through these pins.

On some devices, the transmission and receiving directions are determined by RTS. In normal applications, only A-Line, B-Line, and the shield layer need to be used.

Indicator definition:

Indicator	Definition	Function
		On: The expansion card is establishing a connection with the control
		board.
LED1	Status indicator	Blinks periodically: The expansion card is properly connected to the
		control board (the period is 1s, on for 0.5s, and off for the other 0.5s).
		Off: The expansion card is disconnected from the control board.
LED2	Online indicator	On: The communication card is online and data exchange can be

Indicator	Definition	Function
		performed.
		Off: The communication card is not in the online state.
		On: The communication card is offline and data exchange cannot be
		performed.
		Blinks: The communication card is not in the offline state.
		Blinks at the frequency of 1 Hz: A configuration error occurs: The
		length of the user parameter data set during the initialization of the
		communication card is different from that during the network
	Offline/Fault	configuration.
LED3	indicator	Blinks at the frequency of 2 Hz: User parameter data is incorrect. The
		length or content of the user parameter data set during the
		initialization of the communication card is different from that during
		the network configuration.
		Blinks at the frequency of 4 Hz: An error occurs in the ASIC
		initialization of PROFIBUS communication.
		Off: The diagnosis function is disabled.
LED4	Power indicator	On: The control board feeds power to the communication card.

For details, see the manual of the communication card.

#### A.6.3 CAN multi-protocol communication card (EC-TX505D)

	PWK
RUN ERR CTRL	

The communication card EC-TX505C is user-friendly, adopting European-type screw terminals.

Signal	Description	Description
PGND	Isolation ground	Isolation ground
PE	Shielded cable	CAN bus shielding
CANH	CAN positive input	CAN bus high level signal
CANL	CAN negative input	CAN bus low level signal
485	RS485 terminal resistor	No terminal resistor is connected between RS485+
	switch	and RS485

Signal	Description	Description
		A 120 $\Omega$ terminal resistor is connected between
		RS485+ and RS485
CAN	CAN terminal resistor switch	No terminal resistor is connected between CAN_H
		and CAN_L.
		CAN_H and CAN_L are connected to a terminal
		resistor of 120Ω.

**Note:** To select the protocol of this expansion card, please set the switch SW2 according to the following relationship before power on.

SW2			
1	2	Protocol type	
OFF	OFF	CANopen	
ON	OFF	CAN master/slave	

Indicator definition:

Indicator	Definition	Function
		On: The expansion card is establishing a connection
		with the control board.
		it blinks periodically after the expansion card is properly
CTRL	Status indicator	connected to the control board (the period is 1s, on for
		0.5s, and off for the other 0.5s);
		Off: The expansion card is disconnected from the
		control board.
	Run indicator	On: The communication card is running.
		Off: A fault occurs. Check whether the reset pin of the
DUN		communication card and the power supply are properly
RUN		connected. The expansion card is in a stopped state.
		Blinking: The communication card is in the
		pre-operation state.
		On: The CAN controller bus is off, a fault occurs on the
ERR	Fault indicator	VFD, or the received frame is lost or incorrect.
		Off: The communication card is in the working state.
DW/D	Dowor indicator	On: The control board feeds power to the
FVVR	Power indicator	communication card.

For details, see the manual of the communication card.

#### A.6.4 PROFINET communication card (EC-TX509C)



The terminal CN2 adopts standard RJ45 interfaces, which are in the dual design, and the two RJ45 interfaces are not distinguished from each other and can be interchangeably inserted. They are arranged as follows:

Pin	Name	Description
1	n/c	Not connected
2	n/c	Not connected
3	RX-	Receive Data-
4	n/c	Not connected
5	n/c	Not connected
6	RX+	Receive Data+
7	TX-	Transmit Data-
8	TX+	Transmit Data+

Indicator definition:

The PROFINET communication card has 9 indicators, among which LED1 is the power indicator, LED2–5 are the communication status indicators of the communication card, and LED6–9 are the status indicators of the network port.

LED	Color	State	Description
LED1	Green		3.3V power indicator
		On	No network connection
		Blinking	The connection to the network cable between the
LED2 (Bus status	Dad		PROFINET controller is normal, but the
indicator)	Rea		communication is not established.
		Off	Communication with the PROFINET controller
			has been established.
LED3 (System fault	Green	On	PROFINET diagnosis exists.
indicator)		Off	No PROFINET diagnosis.
	Green	On	TPS-1 protocol stack has started.
LED4 (Slave ready		Blinking	TPS-1 waits for MCU initialization.
indicator)		Off	TPS-1 protocol stack does not start.
LED	Color	State	Description
--	-------	----------	---
LED5 (Maintenance status	Crear		Manufacturer-specific, depending on the
indicator)	Green		characteristics of the device
			The PROFINET communication card and
		On	PC/PLC have been connected by using a network
LED6/7 (Network port status indicator)	Green		cable.
		Off	The connection between the PROFINET
			communication card and PC/PLC has not been
			established.
		Dlinking	The PROFINET communication card and
LED8/9 (Network port communication indicator)		Blinking	PC/PLC are communicating.
	Green	0"	The PROFINET communication card and
		Off	PC/PLC have no communication yet.

Electrical connection:

The PROFINET communication card adopts standard RJ45 interfaces, which can be used in a linear network topology and a star network topology. The linear network topology electrical connection diagram is shown as follows.

Figure A-6 Linear network topology electrical connection diagram



Note: For the star network topology, you need to prepare PROFINET switches.

The star network topology electrical connection diagram is shown as follows.

Figure A-7 Star network topology electrical connection diagram



#### A.6.5 EtherNet IP multi-protocol communication card (EC-TX510B)



The communication terminals CN1 and CN2 of the expansion card adopts standard the RJ45 interfaces, which can be interchangeably inserted. You can select a protocol via the switch before power-on, with EtherNet IP as the default and options for Modbus TCP and Ethernet communication.

**Note:** To select the protocol of this expansion card, please set the switch SW2 according to the following relationship before power on.

	Protocol type	1	2	3
	EtherNet IP	ON	ON	ON
SW1	Ethernet	OFF	ON	ON
	Modbus TCP	ON	OFF	ON
	Reserved	Other	Other	Other

#### Table A-1 Switch

#### Table A-2 EtherNet IP LED description

Indicator	Color	Definition	Function
		On	The card is shaking hands with the VFD.
LED1	Green	Blinking (1Hz)	The card and VFD communicate normally.
		Off	The card and VFD communicate improperly.
		On	The communication between the card and the PLC is
	Green		online and data exchange is allowed.
LEDZ		Off	The communication between the card and PLC is
	Oli	offline.	
		On	Failed to set up I/O between the card and the PLC.
LED3 Red		Blinking (1Hz)	Incorrect PLC configuration.
	Red	Blinking (2Hz)	The card failed to send data to the PLC.
		Blinking (4Hz)	The connection between the card and PLC timed out.
		Off	No fault
LED4	Red	On	3.3V power indicator

Indicator	Color	Definition	Function
		On	The card is shaking hands with the VFD.
LED1	Green	Blinking (1Hz)	The card and VFD communicate normally.
		Off	The card and VFD communicate improperly.
		0.5	The communication between the card and the PLC is
	0	On	online and data exchange is allowed.
LEDZ	Green	0"	The communication between the card and PLC is
	Oli	offline.	
		On	The card has no valid data received.
LED3 R	Red	Blinking (1Hz)	The message function code is not used or defined.
		Blinking (8Hz)	Message address error
		Off	No fault
LED4	Red	On	3.3V power indicator

Table A-3 Modbus TCP LED description

Table A-4 Ethernet LED description

Indicator	Color	Definition	Function
		On	The card is shaking hands with the VFD.
	Orean		The card and VFD communicate normally (handshake
LEDI	Green	Blinking (TH2)	successful).
		Off	The card and VFD communicate improperly.
		0.5	The connection between the card and the PC is
	Crean	On	successful.
LED2 Green	0"	The connection between the card and the PC has failed	
	Oli	(network cable issue).	
			The connection between the card and the PC is
LED3	Ded	Blinking (4Hz)	successful, but communication has failed (IP address
	Reu		issue).
		Off	No fault
LED4	Red	On	3.3V power indicator

#### **Electrical connection:**

The communication card adopts standard RJ45 interfaces, which can be used in a linear and star network topologies. The electrical connection diagram is shown as follows.

Use CAT5, CAT5e, and CAT6 network cables for electrical wiring. When the communication distance is greater than 50m, use high-quality network cables that meet the high-quality standards.



Figure A-8 Linear network topology electrical connection diagram



Figure A-9 Star network topology electrical connection diagram

Note: For the star network topology, you need to prepare Ethernet switches.

### A.7 PG extension cards

#### A.7.1 Sin/Cos PG card (EC-PG502)



The terminals are arranged as follows:

_							C1+	C1-	D1+	D1-
PE	AO+	BO+	ZO+	A1+	B1+	R1+	A2+	B2+	Z2+	PWR
GND	AO-	BO-	ZO-	A1-	B1-	R1-	A2-	B2-	Z2-	GND

Indicator definition:

Indicator	Definition	Function
LED1	Disconnection	Off: A1 or B1 of the encoder is disconnected.

Indicator	Definition	Function
	indicator	Blinking: C1 or D1 of the encoder is disconnected.
		On: Encoder signals are normal.
	Dower indicator	This indicator is on after the control board feeds power to the PG
LEDZ	Power Indicator	card.
		On: The expansion card is connecting with the control board.
		Blinking periodically (the period is 1s, on for 0.5s, and off for the
LED3	LED3 Status indicator	other 0.5s): The expansion card is properly connected to the
		control board.
		Off: The expansion card is disconnected from the control board.

EC-PG502 terminal function:

Signal	Description	Description
PWR	Encodernower	Voltage: 5V ± 5%
GND	Encoder power	Max. output current: 150mA
A1+		
A1-		
B1+		
B1-		Supporting Sin/Cos encoders
R1+	Encoder interface	<ul> <li>SINA/SINB/SINC/SIND 0.6–1.2Vpp; SINR 0.2–0.85Vpp</li> </ul>
R1-		Max. frequency response of A/B signals: 200 kHz
C1+		Max. frequency response of C/D signals: 1 kHz
C1-		
D1+		
D1-		
A2+		
A2-	Pulse reference	
B2+		<ul> <li>Supporting 5V differential signal</li> </ul>
B2-		Response frequency: 200 kHz
Z2+		
Z2-		
AO+		
AO-		<ul> <li>Differential output of 5 V</li> </ul>
BO+	Frequency-divide	• Supporting frequency division of 1–255, which can be
BO-	d output	set through P20.16 or P24.16 Max. output frequency:
ZO+		200 kHz
ZO-		

The following figure shows the external wiring of the PG card when it is used in combination with an encoder without CD signals.



The following figure shows the external wiring of the PG card when it is used in combination with an encoder with CD signals.



### A.7.2 UVW incremental PG card (EC-PG503-05)



The terminals are arranged as follows:

					A2+	A2-	B2+	B2-	Z2+	Z2-
PE	AO+	BO+	ZO+	A1+	B1+	Z1+	U+	V+	W+	PWR
GND	AO-	BO-	ZO-	A1-	B1-	Z1-	U-	V-	W-	PGND

Indicator definition:

Indicator	Definition	Function
LED1	Disconnectio n indicator	Blinking: A1 or B1 signal is disconnected during encoder rotating. On: Other cases
LED2	Status indicator	On: The expansion card is connecting with the control board. Blinking periodically (the period is 1s, on for 0.5s, and off for the other 0.5s): The expansion card is properly connected to the control board. Off: The expansion card is disconnected from the control board.
LED3	Power indicator	This indicator is on after the control board feeds power to the PG card.

The EC-PG503-05 expansion card supports the input of absolute position signals, integrating the advantages of absolute and incremental encoders and adopts spring-loaded terminals for easy use.

Signal	Description	Description
PWR	Freedornower	<ul> <li>Voltage: 5V ± 5%</li> </ul>
PGND	Encoder power	Max. current: 200mA
A1+		
A1-	Encoder interface	Differential incremental PG interface of 5 V
B1+		Response frequency: 400kHz
B1-		

EC-PG503-05 terminal function description:

Signal	Description	Description
Z1+		
Z1-		
A2+		
A2-		
B2+	Dulas reference	<ul> <li>Differential input of 5V</li> </ul>
B2-	Puise reierence	<ul> <li>Response frequency: 200 kHz</li> </ul>
Z2+		
Z2-		
AO+		
AO-		
BO+	Frequency-divided	Differential output of 5V
BO-	output	<ul> <li>Supporting frequency division of 1–255, which can be pet through D20.16 or D24.16</li> </ul>
ZO+		be set through P20.16 of P24.16
ZO-		
U+		
U-		
V+	UVW encoder interface	<ul> <li>Absolute position (UVVV information) of the hybrid encoder differential input of 51/</li> </ul>
V-		Bosponso frequency: 40kHz
W+		
W-		



### The following figure shows the external wiring when EC-PG503-05 is used.

# A.7.3 Resolver PG card (EC-PG504-00)



PE	AO+	BO+	ZO+	EX+	SI+	CO+	A2+	B2+	Z2+	PWR
GND	AO-	BO-	ZO-	EX-	SI-	CO-	A2-	B2-	Z2-	GND

### Indicator definition:

Indicator	Definition	Function
		On: The expansion card is connecting with the control board.
	Status indicator	Blinking periodically (the period is 1s, on for 0.5s, and off for
LEDI		the other 0.5s): The expansion card is properly connected to
		the control board.

Indicator	Definition Function						
		Off: The expansion card is disconnected from the control					
		board.					
	Disconnection	On: Encoder signals are normal.					
LED2	Disconnection	Blinking: Encoder signals are not stable.					
	Indicator	Off: The encoder is disconnected.					
	6	This indicator is on after the control board feeds power to the					
LED3	Power indicator	PG card.					

EC-PG504-00 can be used in combination with a resolver of excitation voltage 7Vrms. It is user-friendly, adopting spring-loaded terminals. EC-PG504-00 terminal function description

Signal	Description	Description
SI+		
SI-	Encodor signal input	Recommended reach/or transformation ratio: 0.5
CO+	Encoder signal input	Recommended resolver transformation ratio. 0.5
CO-		
EX+	Encodor ovoitation	<ul> <li>Factory setting of excitation: 10kHz</li> </ul>
EX-	signal	<ul> <li>Supporting resolvers with an excitation voltage of 7Vrms</li> </ul>
A2+		
A2-		
B2+	Dulas reference	<ul> <li>Differential input of 5V</li> </ul>
B2-	Puise relefence	Response frequency: 200 kHz
Z2+		
Z2-		
AO+		<ul> <li>Differential output of 5 V</li> </ul>
AO-		• Frequency-divided output of resolver simulated A1,
BO+	Frequency-divided	B1, and Z1, which is equal to an incremental PG card
BO-		of 1024 pps.
ZO+	υτιραί	• Supporting frequency division of 1–255, which can be
70		set through P20.16 or P24.16
20-		<ul> <li>Max. output frequency: 200 kHz</li> </ul>

The following figure shows the external wiring when EC-PG504-00 is used.



#### A.7.4 Multi-function incremental PG card (EC-PG505-12)



The terminals are arranged as follows:

The SW1 switch is used to set the voltage class (5V or 12V) of the power supply of the encoder. The switch can be operated with an auxiliary tool.

PE	AO+	BO+	ZO+	A1+	B1+	Z1+	A2+	B2+	Z2+	PWR
GND	AO-	BO-	ZO-	A1-	B1-	Z1-	A2-	B2-	Z2-	PGND

Indicator definition:

Indicator	Definition				Fu	nction					
	Signal indicator	Blinking	(On:	500ms;	Off:	500ms):	A1	or	B1	signal	is
LLDI	Signal indicator	disconne	cted d	uring enc	oder i	otating.					

Goodrive350 IP55 High-ingress Protection Series VFD

Indicator	Definition	Function
		On: Other cases
	Power indicator	On: The expansion card is powered on.
LED2		Off: The expansion card is not powered on.
		On: The expansion card is connecting with the control board.
	Ctatus indiastar	Blinking (On: 500ms; Off: 500ms): The expansion card is
LED3	Status Indicator	connected with the control board.
		Off: The expansion card is disconnected from the control board.

The EC-PG505-12 expansion card can be used in combination with multiple types of incremental encoders through different modes of wiring. It is user-friendly, adopting spring-loaded terminals. EC-PG505-12 terminal function description:

Signal	Description	Description
PWR		<ul> <li>Voltage: 5V/12V ± 5%</li> </ul>
		<ul> <li>Max. output: 150 mA</li> </ul>
DOND	Encoder power	• Select the voltage class through SW1 based on the
PGND		voltage class of the used encoder. (PGND is the
		isolation power ground.)
A1+		
A1-		Applicable to 5V/12V push-pull encoders
B1+	. En codor interfoco	Applicable to 5V/12V OC encoders
B1-	Encoder Interface	Applicable to 5V differential encoders
Z1+	·	Response frequency: 400kHz
Z1-		
A2+		
A2-		
B2+		• Supporting the same signal types as the encoder
B2-	Pulse reference	signal types
Z2+		<ul> <li>Response frequency: 400kHz</li> </ul>
Z2-		
AO+		
AO-		
BO+	Frequency-divided output	Differential output of 5V
BO-		<ul> <li>Supporting frequency division of 1–255, which can be act through D20 40 or D24 40</li> </ul>
ZO+	]	set through P20.16 or P24.16
ZO-		

The following figure shows the external wiring when the expansion card is used in combination with an open collector encoder. A pull-up resistor is configured inside the PG card.



The following figure shows the external wiring when the expansion card is used in combination with a push-pull encoder.



The following figure shows the external wiring when the expansion card is used in combination



with a differential encoder.

# A.7.5 24V multi-function incremental PG card (EC-PG505-24B)



The terminals are arranged as follows:

PE	AO+	BO+	ZO+	A1+	B1+	Z1+	A2+	B2+	Z2+	PWR
GND				A1-	B1-	Z1-	A2-	B2-	Z2-	PGND

Indicator definition:

Indicator	Definition				Fu	nction					
		Blinking	(On:	500ms;	Off:	500ms):	A1	or	B1	signal	is
LED1	Signal indicator disconnected during encoder rotating.										
		On: Othe	er case	S							
LED2	Power indicator	On: The	expan	sion card	is pov	vered on.					

Indicator	Definition	Function
		Off: The expansion card is not powered on.
		On: The expansion card is connecting with the control board.
	Status indicator	Blinking (On: 500ms; Off: 500ms): The expansion card is
LED3	Status indicator	connected with the control board.
		Off: The expansion card is disconnected from the control board.

The EC-PG505-24B expansion card can be used in combination with multiple types of incremental encoders through different modes of wiring. It is user-friendly, adopting spring-loaded terminals. AO-, BO-, and ZO- are internally short connected to PGND.

Signal	Description	Description
PWR	Freedornewer	<ul> <li>Voltage: 24V ± 5%</li> </ul>
PGND	Encoder power	<ul> <li>Max. output current: 150mA</li> </ul>
A1+		
A1-		Applicable to 24V push-pull encoders
B1+	En opdan interfece	Applicable to 24V OC encoders
B1-	Encoder Intenace	<ul> <li>Applicable to 24V differential encoders</li> </ul>
Z1+		Response frequency: 400kHz
Z1-		
A2+		
A2-		<ul> <li>Supporting 24 V push-pull and open collector</li> </ul>
B2+	Dulas reference	interfaces
B2-	Puise reference	<ul> <li>Supporting 5V differential interfaces</li> </ul>
Z2+		Response frequency: 400kHz
Z2-		
AO+		<ul> <li>Supporting open collector output with a pull-up</li> </ul>
BO+		resistor externally connected to the input port
	Frequency-divided	<ul> <li>Supporting frequency division of 1–255, which can be</li> </ul>
70.	output	set through P20.16 or P24.16
20+		<ul> <li>Supporting frequency-divided output source selection,</li> </ul>
		which can be set through P20.17 or P24.17

EC-PG505-24 terminal function description:



The following figure shows the external wiring when the expansion card is used in combination with an open collector encoder. A pull-up resistor is configured inside the PG card.

The following figure shows the external wiring when the expansion card is used in combination with a push-pull encoder.



A.7.6 Simplified incremental PG card (EC-PG507-12)



The terminals are arranged as follows:

The SW1 switch is used to set the voltage class (5V or 12V) of the power supply of the encoder. The switch can be operated with an auxiliary tool.

PE	A1+	B1+	Z1+	PWR
PGND	A1-	B1-	Z1-	PGND

Indicator	Definition	Function
		On: The expansion card is connecting with the control board.
	Status indicator	Blinking periodically (the period is 1s, on for 0.5s, and off for the
LED1		other 0.5s): The expansion card is properly connected to the
		control board.
		Off: The expansion card is disconnected from the control board.
	Disconnection	Off: A1 or B1 of the encoder is disconnected.
LED2	indicator	On: Encoder pulses are normal.
LED3	Deven in die sten	This indicator is on after the control board feeds power to the PG
	Power indicator	card.

Indicator definition:

EC-PG507-12 can work in combination with multiple types of incremental encoders through various external wiring modes. The wiring configuration for the encoder interface is the same as that of the EC-PG505-12 PG card.

Signal	Description	Description
PWR		<ul> <li>Voltage: 5V/12V ± 5%</li> </ul>
	Encodor power	<ul> <li>Max. output: 150 mA</li> </ul>
PGND	Encoder power	<ul> <li>Select the voltage class through SW1 based on the</li> </ul>
		voltage class of the used encoder.
A1+		
A1-	Encoder interface	<ul> <li>Applicable to 5V/12V push-pull encoders</li> </ul>
P1		<ul> <li>Applicable to 5V/12V OC encoders</li> </ul>
DIT		<ul> <li>Applicable to 5V differential encoders</li> </ul>
B1-		<ul> <li>Response frequency: 400kHz</li> </ul>
Z1+		
Z1-		<ul> <li>Supporting the encoder cable length of up to 50m</li> </ul>

EC-PG507-12 terminal function description:

### A.7.7 24V simplified incremental PG card (EC-PG507-24)

•	SV GND TXD RXD		

The terminals are arranged as follows:

PE	A1+	B1+	Z1+	PWR
PGND	A1-	B1-	Z1-	PGND

Indicator definition:

Indicator	Definition	Function
	On: The expansion card is connecting with the control board.	
		Blinking periodically (the period is 1s, on for 0.5s, and off for
	Ctatus indicator	the other 0.5s): The expansion card is properly connected to
LEDI	Status Indicator	the control board.
		Off: The expansion card is disconnected from the control
		board.
	Disconnection	Off: A1 or B1 of the encoder is disconnected.
LED2	indicator	On: Encoder pulses are normal.
	Devenindiates	This indicator is on after the control board feeds power to the
LED3	Power indicator	PG card.

The EC-PG507-24 extension card can be used in combination with multiple types of incremental encoders through different modes of wiring. It is user-friendly, adopting 5.08mm pitch terminals.

EC-PG507-24 terminal function description:

Signal	Description	Description
DE	One we die entermaine d	It is connected to the ground for enhancing the
FE	Grounding terminal	anti-interference performance.
PWR		Voltage: 24V ± 5%
PCND	Encoder power	Max. output current: 150mA
PGND		(PGND is the isolation power ground.)
A1+		
A1-		Applicable to 24V push-pull encoders
B1+		<ul> <li>Applicable to 24V OC encoders</li> </ul>
B1-	Encoder interface	<ul> <li>Applicable to 24V differential encoders</li> </ul>
71+		<ul> <li>Response frequency: 200kHz</li> </ul>
21+		• Supporting the encoder cable length of up to 100m.
∠1-		

The following figure shows the external wiring when the expansion card is used in combination with an open collector encoder. A pull-up resistor is configured inside the PG card.



The following figure shows the external wiring when the expansion card is used in combination with a push-pull encoder.



The following figure shows the external wiring when the expansion card is used in combination with a differential encoder.



# A.8 IoT card

# A.8.1 GPRS IoT card (EC-IC501-2)



## CN6 pin definition

Pin	Name	Description
1	485-	485B
2	485+	485A
3	GND	Power ground
4	24V	24V power supply

Indicator definition:

Indicator	Definition	Description
		Blinking with an interval of 1s: The expansion card is
LEDI	Handshaking indicator	connected with the control board.
	Dewer indicator	On: The expansion card is powered on.
LED2	Power Indicator	Off: The expansion card is not powered on.
LED3	Running indicator	On: The expansion card communicates properly.
LED4	GPRS state indicator	Blinking (On: 64ms; Off: 300ms): GPRS connects to
		the network.
		Blinking (On: 64ms; Off: 800ms): The network is not
		registered.
LED5	Status indicator	On: The GPRS module is turned on.

For details about the operation, see the manual of the EC series GPRS expansion card.

## A.8.2 4G card (EC-IC502-2-CN, EC-IC502-2-EU, EC-IC502-2-LA)



#### Terminal description

Port identifier	Description
24V	Power supply +
GND	Power supply -
485+	485A
485-	485B
4G	4G antenna
CN3	SIM card socket

#### Indicator description

Indicator identifier	Description
	Network indicator
	Blinking (ON: 600ms; OFF: 600ms): No SIM card/Network
NE I	registration in progress/Registration failed.
	Blinking (On: 75ms; Off: 75ms): Data link established.
	Run indicator
RUN	Blinking (On: 1s; Off: 1s): The system runs properly.
	On or Off: System exceptions occurred.
	Blinking (ON: 1s; OFF: 1s): Handshake between expansion card and
SPI	VFD control board succeed.
	ON: Handshake failed or no handshake.
POWER	Power supply indicator

Note: For details, see the manual of the EC series 4G expansion card.

# **Appendix B Technical data**

### B.1 What this chapter contains

This chapter describes the technical data of the VFD and its compliance to CE and other quality certification systems.

## **B.2 Derated application**

### B.2.1 Capacity

Choose a VFD model based on the rated current and power of the motor. To ensure the rated power of the motor, the rated output current of the VFD must be larger or equal to the rated current of the motor. The rated power of the VFD must be higher or equal to that of the motor.

Note:

- The maximum allowable shaft power of the motor is limited to 1.5 times the rated power of the motor. If the limit is exceeded, the VFD automatically restricts the torque and current of the motor. This function effectively protects the input shaft against overload.
- The rated capacity is the capacity at the ambient temperature of 40°C.
- You need to check and ensure that the power flowing through the common DC connection in the common DC system does not exceed the rated power of the motor.

#### B.2.2 Derating

If the ambient temperature at the VFD installation site exceeds 40°C, the VFD installation site altitude exceeds 1000m, a cover with heat dissipation vents is used, or the carrier frequency is higher than the recommended (for the recommended frequency, see P00.14), the VFD needs to be derated.

#### B.2.2.1 Derating due to temperature

When the temperature ranges from 40°C to 50°C, the rated output current is derated by 1% for each increased 1°C. For the actual derating, see the following figure.



#### Figure B-1 Temperature-based derating diagram

**Note:** It is not recommended to use the VFD at an environment with the temperature higher than 50°C. If you do, we shall not hold accountable for the consequences caused.

#### B.2.2.2 Derating due to altitude

When the VFD installation site altitude is lower than 1000m, the VFD can run at the rated power. When the altitude exceeds 1000m, derate by 1% for each increase of 100m. When the altitude exceeds 3000m, consult the local INVT dealer or office for details.

#### B.2.2.3 Derating due to carrier frequency

The VFDs in different power classes are different in carrier frequency. The rated power of a VFD is defined based on the carrier frequency set in factory. If the carrier frequency exceeds the factory setting, the power of the VFD is derated by 10% for each increased 1 kHz.

### **B.3 Grid specifications**

Grid voltage	AC 3PH 380V(-15%) – 440V(+10%)
	According to the definition in IEC 61439-1, the maximum allowable short-circuit
Short-circuit	current at the incoming end is 100 kA. Therefore, the VFD is applicable to
capacity	scenarios where the transmitted current in the circuit is no larger than 100kA when
	the VFD runs at the maximum rated voltage.
Frequency	50/60Hz±5%, with a maximum change rate of 20%/s

# **B.4 Motor connection data**

Motor type	Asynchronous induction motor or permanent-magnet synchronous motor											
	-U1 (motor rated voltage), 3PH symmetrical, Umax (VFD rated voltage) at the											
voltage	field-weakening point											
Short-circuit	The motor output short-circuit protection meets the requirements of IEC											
protection	61800-5-1.											
Frequency	0–599Hz											
Frequency												
resolution	0.01HZ											

Current	See section 3.6 "Product ratings".
Power limit	1.5 times of the motor rated power
Field-weakeni	
ng point	10-400H2
Carrier	
frequency	14, 8, 12, 01 15KHZ

#### B.4.1 EMC compatibility and motor cable length

To meet the requirements of the EU EMC Directive (2014/30/EU), the maximum length of motor cables for the -AS model is as follows:

All models	Maximum motor cable length (m)
Environment category II (C3)	30

You can learn the maximum length of the motor cable through the running parameters of the VFD. To understand the accurate maximum cable length for using an external EMC filter, contact the local INVT office.

For details about the environment categories, see section B.6 "EMC regulations".

## **B.5 Application standards**

The following table describes the standards that VFDs comply with.

EN/ISO 13849-1	Safety of machinery-Safety-related parts of control systems-Part 1:											
	General principles for design											
IEC/EN 60204-1	Safety of machinery. Electrical equipment of machines. Part 1: General											
	requirements											
IEC/EN 62061	Safety of machinery-Safety-related functional safety of electrical,											
	electronic, and programmable electronic control systems											
IEC/EN 61800-3	Adjustable speed electrical power drive systems. Part 3: EMC requirements											
120/2110100000	and specific test methods											
IEC/EN 61800-5-1	Adjustable speed electrical power drive systems—Part 5-1: Safety											
120/21101000-3-1	requirements—Electrical, thermal and energy											
	Adjustable speed electrical power drive systems—Part 5-2: Safety											
1EC/EN 01000-3-2	requirements—Function											
CP/T 20944 1	General-purpose variable-frequency adjustable-speed equipment of 1 kV											
GD/1 30044.1	and lower—Part 1: Technical conditions											
CP/T 20944 2	General-purpose variable-frequency adjustable-speed equipment of 1 kV											
GB/1 30644.2	and lower—Part 2: Test methods											
CP/T 20944 2	General-purpose variable-frequency adjustable-speed equipment of 1 kV											
GD/1 30844.3	and lower—Part 3: Safety requirements											

#### B.5.1 CE marking

The CE marking on the VFD nameplate indicates that the VFD is CE-compliant, meeting the regulations of the European low-voltage directive (2014/35/EU) and EMC directive (2014/30/EU).

#### B.5.2 EMC compliance declaration

European union (EU) stipulates that the electric and electrical devices sold in Europe cannot generate electromagnetic disturbance that exceeds the limits stipulated in related standards, and can work properly in environments with certain electromagnetic interference. The EMC product standard (EN 61800-3) describes the EMC standards and specific test methods for adjustable speed electrical power drive systems. Our products have been compliant with these regulations.

#### **B.6 EMC regulations**

The EMC product standard (EN 61800-3) describes the EMC requirements on VFDs.

Application environment categories:

First environment: Civilian environment, including application scenarios where VFDs are directly connected to the civil power supply low-voltage grids without intermediate transformers.

Second environment: All environments except those in Category I.

VFD categories:

Category C1: VFD of rated voltage lower than 1000V, applied to the first environment.

C2: Rated voltage lower than 1000V, non-plug, socket, or mobile devices; power drive systems that must be installed and operated by specialized personnel when applied to environments of Category I.

**Note:** The EMC standard IEC/EN 61800-3 no longer restricts the power distribution of VFDs, but it specifies their use, installation, and commissioning. Specialized personnel or organizations must have the necessary skills (including the EMC-related knowledge) for installing and/or performing commissioning on the electrical drive systems.

C3: Rated voltage lower than 1000V, applied to environments of Category II. They cannot be applied to environments of Category I.

Category C4: VFD of rated voltage higher than 1000V, or rated current higher or equal to 400A, applied to complex systems in the second environment.

#### B.6.1 VFD category of C2

The induction disturbance limit meets the following stipulations:

 Select an optional EMC filter according to Appendix D Optional peripheral accessories and install it following the description in the EMC filter manual.

- 2. Select the motor and control cables according to the description in the manual.
- 3. Install the VFD according to the description in the manual.
- For the maximum length of the motor cable, see section B.4.1 "EMC compatibility and motor cable length".



#### B.6.2 VFD category of C3

The anti-interference performance of the VFD meets the requirements of the second environment in the IEC/EN 61800-3 standard.

The induction disturbance limit meets the following stipulations:

- 1. Select an optional EMC filter according to Appendix D Optional peripheral accessories and install it following the description in the EMC filter manual.
- 2. Select the motor and control cables according to the description in the manual.
- 3. Install the VFD according to the description in the manual.
- For the maximum length of the motor cable, see section B.4.1 "EMC compatibility and motor cable length".



VFDs of category C3 cannot be applied to civilian low-voltage common grids. When applied to such grids, the VFD may generate radio frequency electromagnetic interference.

# Appendix C Dimension drawings

# C.1 What this chapter contains

This chapter provides the dimension drawings of the VFD. which use millimeter (mm) as the unit.

# C.2 VFD structure

Figure C-1 VFD structure



# C.3 VFD dimension

# C.3.1 Wall-mounting dimensions



Figure C-2 Wall-mounting diagram for the 004G/5R5P–037G/045P models

Table C-1 Wall-mounting dimensions

VFD model	W1	W2	H1	H2	H3	D1	D2	Hole diameter	Fixing screw	Net weight (kg)	Gross weight (kg)
GD350-004G/5R5P-45-AS						262.0				0	11
GD350-5R5G/7R5P-45-AS	106	164	100 E	102	200	202.0	227	ØE	ME	9	
GD350-004G/5R5P-45-NS	190	104	420.5	403	309		221	20	IVIO	0 5	10 F
GD350-5R5G/7R5P-45-NS						-				0.0	10.5
GD350-7R5G/011P-45-AS											
GD350-011G/015P-45-AS						289.4				13	16
GD350-015G/018P-45-AS	000	187	503.8	475	458.5		050 7	<i>a</i> 7			
GD350-7R5G/011P-45-NS	223						200.7	Øĩ	IVIb		
GD350-011G/015P-45-NS						-				12.5	15
GD350-015G/018P-45-NS											
GD350-018G/022P-45-AS						201 0				21	04 E
GD350-022G/030P-45-AS	074	004	A	500	504	201.0	0.40	07	MC	21	24.5
GD350-018G/022P-45-NS	274	234	551.5	522	504		246	Øï	IVID	20	22
GD350-022G/030P-45-NS						-				20	23
GD350-030G/037P-45-AS						000				07	04.5
GD350-037G/045P-45-AS	210	262	610	E07	EGG E	290	242.0	<i>a</i> 0	MO	27	31.5
GD350-030G/037P-45-NS	318	203	019	587	566.5		242.9	.9 Ø9	IVI8	06 F	20
GD350-037G/045P-45-NS						-				20.5	30



# Figure C-3 Wall-mounting diagram for the 045G/055P-110G models

Table	C-2	Wall-r	nounting	dimension	เร
Table	0-2	vvaii-i	nounting	unitension	13

VFD model	W1	W2	H1	H2	H3	D1	D2	Hole diameter	Fixing screw	Net weight (kg)	Gross weight (kg)
GD350-045G/055P-45-AS											
GD350-045G/055P-45-AS-B						000 7				40	
GD350-055G/075P-45-AS						336.7				48	55
GD350-055G/075P-45-AS-B	220	202	000.0	000	770 5		000 7	<i>a</i> 0	MO		
GD350-045G/055P-45-NS	338	283	829.8	800	//8.5		289.7	Ø9	IVI8		
GD350-045G/055P-45-NS-B										40.40	40.24
GD350-055G/075P-45-NS						-				42.12	40.34
GD350-055G/075P-45-NS-B											
GD350-075G/090P-45-AS											
GD350-075G/090P-45-AS-B											
GD350-090G/110P-45-AS						202				64	00.0
GD350-090G/110P-45-AS-B	370	310	825.3	788	764.5	382	335	Ø11	M10	64	82.8
GD350-110G-45-AS											
GD350-110G-45-AS-B											
GD350-075G/090P-45-NS						-				63.65	82.45

VFD model	W1	W2	H1	H2	H3	D1	D2	Hole diameter	Fixing screw	Net weight (kg)	Gross weight (kg)
GD350-075G/090P-45-NS-B											
GD350-090G/110P-45-NS											
GD350-090G/110P-45-NS-B											
GD350-110G-45-NS											
GD350-110G-45-NS-B											

# C.3.2 Flange mounting dimensions

Figure C-4 Flange installation diagram for the 004G/5R5P-037G/045P models





Table C-3 Flange mounting dimensions for 004G/5R5P-037G/045P models (unit: mm)

VFD model	W1	W2	W3	H1	H2	НЗ	H4	D1	D2	D3	Hole diameter	Fixing screw
GD350-004G/5R5P-45-AS												
GD350-5R5G/7R5P-45-AS	055.5	005	040	450	004	405		262.8	0.07	70.5	<i>a</i> 0	145
GD350-004G/5R5P-45-NS	255.5	225	212	456	321	405	29		227	78.5	Ø6	M5
GD350-5R5G/7R5P-45-NS								-				
GD350-7R5G/011P-45-AS												
GD350-011G/015P-45-AS								289.4				
GD350-015G/018P-45-AS	000 F	050 5	000	500	000 F	477	50 F		050 7	400 5	07	MC
GD350-7R5G/011P-45-NS	282.5	258.5	239	520	333.5	477	58.5		250.7	100.5	10	Mb
GD350-011G/015P-45-NS								-				
GD350-015G/018P-45-NS												
GD350-018G/022P-45-AS	0.40	040 5	004	500	074 5	504	00	004.0	0.40	100 5	<i>a</i> 7	
GD350-022G/030P-45-AS	346	310.5	291	560	371.5	524	63	281.8	246	100.5	107	MG

#### Goodrive350 IP55 High-ingress Protection Series VFD

**Dimension drawings** 

VFD model	W1	W2	W3	H1	H2	НЗ	H4	D1	D2	D3	Hole diameter	Fixing screw
GD350-018G/022P-45-NS												
GD350-022G/030P-45-NS								-				
GD350-030G/037P-45-AS												
GD350-037G/045P-45-AS								290			~~	
GD350-030G/037P-45-NS	382	354	336	624	457	589	49.5		242.9	101.5	69	M8
GD350-037G/045P-45-NS								-				

Figure C-5 Flange installation diagram for the 045G/055P-055G/075P models



Table C-4 Flange mounting dimensions for 045G/055P-055G/075P models (unit: mm)

VFD model	W1	W2	W3	W4	H1	H2	НЗ	H4	D1	D2	D3	Hole diameter	Fixing screw
GD350-045G/055P-45-AS													
GD350-045G/055P-45-AS-B									000 7				
GD350-055G/075P-45-AS									336.7				
GD350-055G/075P-45-AS-B			055.0	10.0	004	007		100		000 7	400 5	<i>a</i> 0	
GD350-045G/055P-45-NS	410	380	355.6	12.2	834	397	802	186		289.7	126.5	69	INI8
GD350-045G/055P-45-NS-B													
GD350-055G/075P-45-NS									-				
GD350-055G/075P-45-NS-B													

# Appendix D Optional peripheral accessories

### D.1 What this chapter contains

This chapter describes how to select optional accessories of the VFD.

## **D.2 External wiring**

The following figure shows the external wiring of the VFD.



#### Note:

- The 037G/045P and lower models are equipped with built-in braking units, and the 045G/055P–110G models can be configured with optional built-in braking units.
- The 018G/022P–110G models are equipped with built-in DC reactors.
- The braking units are INVT DBU series standard braking units. For details, see the DBU operation manual.

Image	Name	Description						
	Cable	Accessory for signal transmission.						
	Breaker	Device for electric shock prevention and protection against short-to-ground that may cause current leakage and fire. Select residual-current circuit breakers (RCCBs) that are applicable to VFDs and can restrict high-order harmonics, and of which the rated sensitive current for one VFD is larger than 30 mA.						
	Passive harmonic filters	Device used to reduce the current distortion rate and harmonic content, thereby improving the power factor.						
	Input reactors	Accessories used to improve the power factor on the input side of the VFD, and thus restrict high-order harmonic currents.						
<b>1</b> 000	Input filter	Accessory that restricts the electromagnetic interference generated by the VFD and transmitted to the public grid through the power cable. Try to install the input filter near the input terminal side of the VFD.						
or v	Braking unit or braking resistor	Accessories used to consume the regenerative energy of the motor to reduce the DEC time. For 037G/045P and lower VFD models, only the installation of a braking resistor is required. The 045G/055P–110G models can be configured with optional built-in braking units.						
600	Output filter	Accessory used to restrict interference generated in the wiring area on the output side of the VFD. Try to install the output filter near the output terminal side of the VFD.						
	Output reactors	Accessory used to lengthen the valid transmission distance of the VFD, which effectively restrict the transient high voltage generated during the switch-on and switch-off of the IGBT module of the VFD.						
	dv/dt decrement filters	Device used to suppress voltage spikes, reduce traveling waves in long cables, and reflect dv/dt transient voltages, thereby reducing motor eddy current losses and noise, and providing motor insulation protection.						
	Sine-wave filter	currents derived from switching frequency ripple currents, correcting the waveform to approximate a sine wave						
Image	Name	Description						
-------	------	---	--	--	--	--	--	--
		significantly extending the length of the output cable,						
		reducing motor eddy current losses and noise, and						
		protecting motor insulation.						

### **D.3 Power supply**

See chapter 4 "Installation guidelines".

Ensure that the voltage class of the VFD is consistent with that of the grid.

# D.4 Cable

### D.4.1 Power cable

The sizes of the input power cables and motor cables must comply with local regulations.

- The input power cables and motor cables must be able to carry the corresponding load currents.
- The maximum temperature margin of the motor cables in continuous working cannot be lower than 70°C.
- The conductivity of PE grounding conductor is the same as that of the phase conductor. The cross-sectional area of the PE grounding conductor for 30kW and higher models can be slightly smaller than the recommended cross-sectional area value.
- For details about the EMC requirements, see Appendix B "Technical data".

To meet the EMC requirements stipulated in the CE standards, you must use symmetrical shielded cables as motor cables (as shown in the following figure).

Four-core cables can be used as input cables, but symmetrical shielded cables are recommended. Compared with four-core cables, symmetrical shielded cables can reduce electromagnetic radiation as well as the current and loss of the motor cables.



**Note:** If the electrical conductivity of the motor cable shield layer does not meet the requirements, a separate PE conductor must be used.

To protect the conductors, the cross-sectional area of the shielded cables must be the same as that of the phase conductors if the cable and conductor are made of materials of the same type.

This reduces grounding resistance, and thus improves impedance continuity.

To effectively restrict the emission and conduction of radio frequency (RF) interference, the conductivity of the shielded cable must at least be 1/10 of the conductivity of the phase conductor. This requirement can be well met by a copper or aluminum shield layer. The following figure shows the minimum requirement on motor cables of a VFD. The cable must consist of a layer of spiral-shaped copper strips. The denser the shield layer is, the more effectively the electromagnetic interference is restricted.

Figure D-1 Cross-section of the cable



#### D.4.2 Control cable

All analog control cables and cables used for frequency input must be shielded cables. Analog signal cables need to be double-shielded twisted-pair cables (as shown in figure a). Use one separate shielded twisted pair for each signal. Do not use the same ground wire for different analog signals.





For low-voltage digital signals, double-shielded cables are recommended, but shielded or unshielded twisted pairs (as shown in figure b) also can be used. For frequency signals, however, only shielded cables can be used.

A relay cable needs to carry the metal braided shield layer.

The keypad needs to be connected by using a network cable. In complicated electromagnetic environments, a shielded network cable is recommended.

**Note:** Analog signals and digital signals cannot share a same cable, and their cables must be routed separately.

Do not perform any voltage endurance or insulation resistance tests, such as high-voltage insulation tests or using a megameter to measure the insulation resistance, on the VFD or its components. Insulation and voltage endurance tests have been performed between the main

circuit and chassis of each VFD before delivery. In addition, voltage limiting circuits that can automatically cut off the test voltage are configured inside the VFDs.

**Note:** Before connecting the input power cable of the VFD, check the insulation conditions of the cable according to local regulations.

	Recommended ca (mm²)	able size	Fixing screw		
VFD model	R, S, T U, V, W,	PE	Terminal screw	Fastening torque (Nm)	
GD350-004G/5R5P-45-AS	04 E/00 E	1 5/0 5			
GD350-004G/5R5P-45-NS	3×1.5/3×2.5	1.5/2.5	N/4	1.2	
GD350-5R5G/7R5P-45-AS	22.5/24	0.5/4	1014	1.2	
GD350-5R5G/7R5P-45-NS	3x2.5/3x4	2.5/4			
GD350-7R5G/011P-45-AS	2.4/2.46	1/6			
GD350-7R5G/011P-45-NS	3×4/3×0	4/0			
GD350-011G/015P-45-AS	2	6/10			
GD350-011G/015P-45-NS	3×0/3×10	6/10	ME	2.2	
GD350-015G/018P-45-AS	2.10/2.10	10/10	Mb	2.3	
GD350-015G/018P-45-NS	3×10/3×10	10/10			
GD350-018G/022P-45-AS	2.10/2.16	10/16			
GD350-018G/022P-45-NS	3×10/3×16	10/16			
GD350-022G/030P-45-AS	2.16/2.16	16/16			
GD350-022G/030P-45-NS	3×10/3×10	10/10			
GD350-030G/037P-45-AS	2.16/2.25	16/16	MG	2.5	
GD350-030G/037P-45-NS	3×10/3×25	10/10	IVIO	2.5	
GD350-037G/045P-45-AS	225/225	16/16			
GD350-037G/045P-45-NS	3×25/3×35	16/16			
GD350-045G/055P-45-AS					
GD350-045G/055P-45-NS	225/250	10/05			
GD350-045G/055P-45-AS-B	3×35/3×50	16/25			
GD350-045G/055P-45-NS-B			MO	10	
GD350-055G/075P-45-AS			IVIO	10	
GD350-055G/075P-45-NS	2.50/2.70	25/25			
GD350-055G/075P-45-AS-B	3X30/3X70	20/00			
GD350-055G/075P-45-NS-B					
GD350-075G/090P-45-AS					
GD350-075G/090P-45-NS	3×70/3×95	35/50	M12	35	
GD350-075G/090P-45-AS-B					

Table D-1 Recommended cable size

VED model	Recommended ca (mm²)	able size	Fixing screw		
VFD model	R, S, T U, V, W,	PE	Terminal screw	Fastening torque (Nm)	
GD350-075G/090P-45-NS-B					
GD350-090G/110P-45-AS		50/70			
GD350-090G/110P-45-NS	2.05/2.120				
GD350-090G/110P-45-AS-B	3×95/3×120				
GD350-090G/110P-45-NS-B					
GD350-110G-45-AS					
GD350-110G-45-NS	2120	70			
GD350-110G-45-AS-B	3×120	70			
GD350-110G-45-NS-B					

### Note:

- The numbers on the left and right of "/" indicate the recommended device parameters for G and P models respectively.
- The cables recommended for the main circuit can be used in scenarios where the ambient temperature is lower than 40°C, the wiring distance is shorter than 100m, and the current is the rated current.
- The terminals PB, (+), and (-) are used to connect to braking accessories.

	Recommended copper tube terminal					
VFD model	R, S, T	Terminal U, V, W Terminal PE		PE	Terminal screw	
GD350-004G/5R5P-45-AS	DBN1.25-14/		GTNR1.25-4/		GTNR1.25-4/	
GD350-004G/5R5P-45-NS	DBN2-14	,	GTNR2.5-4		GTNR1.25-4	
GD350-5R5G/7R5P-45-AS	DBN2-14/	/	GTNR2.5-4/	M4	GTNR2.5-4/	M4
GD350-5R5G/7R5P-45-NS	DBN5.5-14		GTNR4-4		GTNR4-4	
GD350-7R5G/011P-45-AS	DBN5.5-14/		GTNR4-4/		GTNR4-4/	
GD350-7R5G/011P-45-NS	DBN5.5-14		GTNR6-4		GTNR6-4	M4
GD350-011G/015P-45-AS	DBN5.5-14/	,	GTNR6-4/		GTNR6-4/	
GD350-011G/015P-45-NS	DBN8-14	/	GTNR10-4	M6	GTNR10-4	
GD350-015G/018P-45-AS	DBN8-14/		GTNR10-4/		GTNR10-4/	
GD350-015G/018P-45-NS	DBN8-14		GTNR10-4		GTNR10-4	
GD350-018G/022P-45-AS	DBN8-14/	,	GTNR10-5/	MG	GTNR10-5/	145
GD350-018G/022P-45-NS	DBN14-16	/	GTNR16-5	IM6	GTNR16-5	M5

Table D-2 Recommended terminal model

	Recommended copper tube terminal					
VFD model	R, S, T	Terminal	U, V, W	Terminal	PE	Terminal
		screw		screw		screw
GD350-022G/030P-45-AS	DBN14-16/		GTNR16-5/		GTNR16-5/	
GD350-022G/030P-45-NS	DBN14-16		GTNR16-5		GTNR16-5	
GD350-030G/037P-45-AS	DBN14-16/		GTNR16-5/		GTNR16-5/	
GD350-030G/037P-45-NS	DBN22-16	,	GTNR25-5	MG	GTNR16-5	ME
GD350-037G/045P-45-AS	DBN22-16/	/	GTNR25-5/	IVIO	GTNR16-5/	CIVI
GD350-037G/045P-45-NS	DBN38-16		GTNR35-5		GTNR16-5	
GD350-045G/055P-45-AS	GTNR35-8/		GTNR35-8/		GTNR16-8/	
GD350-045G/055P-45-NS	GTNR50-8		GTNR50-8		GTNR25-8	M6
GD350-045G/055P-45-AS-B	GTNR35-8/		GTNR35-8/	M8	GTNR16-8/	
GD350-045G/055P-45-NS-B	GTNR50-8		GTNR50-8		GTNR25-8	
GD350-055G/075P-45-AS	GTNR50-8/	M8	GTNR50-8/		GTNR25-8/	
GD350-055G/075P-45-NS	GTNR70-8		GTNR70-8		GTNR35-8	
GD350-055G/075P-45-AS-B	GTNR50-8/		GTNR50-8/		GTNR25-8/	
GD350-055G/075P-45-NS-B	GTNR70-8		GTNR70-8		GTNR35-8	
GD350-075G/090P-45-AS	GTNR70-12/		GTNR70-12/		GTNR35-8/	
GD350-075G/090P-45-NS	GTNR95-12		GTNR95-12		GTNR50-8	
GD350-075G/090P-45-AS-B	GTNR70-12/		GTNR70-12/		GTNR35-8/	
GD350-075G/090P-45-NS-B	GTNR95-12		GTNR95-12		GTNR50-8	
GD350-090G/110P-45-AS	GTNR95-12/		GTNR95-12/		GTNR50-8/	
GD350-090G/110P-45-NS	GTNR120-12		GTNR120-12		GTNR70-8	
GD350-090G/110P-45-AS-B	GTNR95-12/	M12	GTNR95-12/	M12	GTNR50-8/	M8
GD350-090G/110P-45-NS-B	GTNR120-12		GTNR120-12		GTNR70-8	
GD350-110G-45-AS						
GD350-110G-45-NS	GTNR120-12		GTNR120-12		GINR70-8	
GD350-110G-45-AS-B						
GD350-110G-45-NS-B	GINR120-12		GTNR120-12		GINR70-8	

# Figure D-3 Terminal drawing





GTNR series terminal

DBN series terminal

DBN1.25-14 DBN2-14 DBN5.5-14	DBN8-14	DBN14-16	DBN22-16	DBN38-16
------------------------------	---------	----------	----------	----------

Optional peripheral accessories

L=14mm

L=16mm

	R, S, T		U, V, W		PE	
VFD model	Terminal screw	Fastening torque (Nm)	Terminal screw	Fastenin g torque (Nm)	Terminal screw	Fastenin g torque (Nm)
GD350-004G/5R5P-45-AS						
GD350-004G/5R5P-45-NS	,	0.0		10		4.0
GD350-5R5G/7R5P-45-AS	/	0.8	1014	1.2	1014	1.2
GD350-5R5G/7R5P-45-NS						
GD350-7R5G/011P-45-AS						
GD350-7R5G/011P-45-NS						
GD350-011G/015P-45-AS	,	2.0	MG	2.0	MA	1.0
GD350-011G/015P-45-NS	/	2.0	IVIO	2.0	1014	1.2
GD350-015G/018P-45-AS						
GD350-015G/018P-45-NS						
GD350-018G/022P-45-AS		2.0		2.0	M5	
GD350-018G/022P-45-NS	,		MG			25
GD350-022G/030P-45-AS	/	2.0	IVIO	2.0	IVID	2.5
GD350-022G/030P-45-NS						
GD350-030G/037P-45-AS		6.0				
GD350-030G/037P-45-NS	,		M6	2.0	ME	2.5
GD350-037G/045P-45-AS	/			2.0	MO	2.5
GD350-037G/045P-45-NS						
GD350-045G/055P-45-AS						
GD350-045G/055P-45-NS						
GD350-045G/055P-45-AS-B						
GD350-045G/055P-45-NS-B	M8	4.0	M8	4.0	Me	4.0
GD350-055G/075P-45-AS	INIO	4.0	WIO	4.0	INIO	4.0
GD350-055G/075P-45-NS						
GD350-055G/075P-45-AS-B						
GD350-055G/075P-45-NS-B						
GD350-075G/090P-45-AS						
GD350-075G/090P-45-NS						
GD350-075G/090P-45-AS-B	M12	35	M12	35	MR	10
GD350-075G/090P-45-NS-B		30		30	IVIO	10
GD350-090G/110P-45-AS						
GD350-090G/110P-45-NS						

Table D-3 Recommended terminal model and torque

Goodrive350 IP55 High-ingress Protection Series VFD

Optional peripheral accessories

	R, S, T		U, V	/, W	PE	
VFD model	Terminal screw	Fastening torque (Nm)	Terminal screw	Fastenin g torque (Nm)	Terminal screw	Fastenin g torque (Nm)
GD350-090G/110P-45-AS-B						
GD350-090G/110P-45-NS-B						
GD350-110G-45-AS						
GD350-110G-45-NS						
GD350-110G-45-AS-B						
GD350-110G-45-NS-B						

### D.4.3 Cable arrangement

Motor cables must be arranged away from other cables. The motor cables of several VFDs can be arranged in parallel. It is recommended that you arrange the motor cables, input power cables, and control cables separately in different trays. The output dU/dt of the VFDs may increase electromagnetic interference on other cables. Do not arrange other cables and the motor cables in parallel.

If a control cable and power cable must cross each other, ensure that the angle between them is 90 degrees.

The cable trays must be connected properly and well grounded. Aluminum trays can implement local equipotential.

The following figure shows the cable arrangement.



Figure D-4 Cable routing distance

#### **D.4.4 Insulation inspection**

Check the motor and the insulation conditions of the motor cable before running the motor.

- 1. Ensure that the motor cable is connected to the motor, and then remove the motor cable from the U, V, and W output terminals of the VFD.
- 2. Use a megohmmeter of 500V DC to measure the insulation resistance between each phase conductor and the protection grounding conductor. For details about the insulation

resistance of the motor, see the description provided by the manufacturer.

**Note:** If the inside of motor is moist, the insulation resistance is reduced. If it may be damp, you need to dry the motor and then measure the insulation resistance again.

### D.5 Breaker and electromagnetic contactor

The circuit breaker is mainly used to prevent electric shock accidents and short circuits to the ground that may cause leakage current fire. The electromagnetic contactor is mainly used to control the main circuit power on and off, which can effectively cut off the input power of the VFD in case of system failure to ensure safety.



According to the working principle and structure of breakers, if the manufacturer's regulation is not followed, hot ionized gases may escape from the breaker enclosure when a short-circuit occurs. To ensure safe use, exercise extra caution when installing and placing the breaker. Follow the manufacturer's instructions.

VED model	Breaker rated	Fast-acting fuse rated	Contactor rated	
VFD model	current (A)	current (A)	current AC-3 (A)	
GD350-004G/5R5P-45-AS	05	22	10	
GD350-004G/5R5P-45-NS	25	32	10	
GD350-5R5G/7R5P-45-AS	22	40	26	
GD350-5R5G/7R5P-45-NS	32	40	20	
GD350-7R5G/011P-45-AS	40	50	26	
GD350-7R5G/011P-45-NS	40	50	20	
GD350-011G/015P-45-AS	50	62	20	
GD350-011G/015P-45-NS	50	03	38	
GD350-015G/018P-45-AS	62	80	40	
GD350-015G/018P-45-NS	03	00	40	
GD350-018G/022P-45-AS	62	80	50	
GD350-018G/022P-45-NS	03	00	50	
GD350-022G/030P-45-AS	80	100	62	
GD350-022G/030P-45-NS	80	100	05	
GD350-030G/037P-45-AS	100	125	75	
GD350-030G/037P-45-NS	100	125	75	
GD350-037G/045P-45-AS	105	160	05	
GD350-037G/045P-45-NS	125	100	90	
GD350-045G/055P-45-AS				
GD350-045G/055P-45-NS	160	200	110	
GD350-045G/055P-45-AS-B	100	200	110	
GD350-045G/055P-45-NS-B				
GD350-055G/075P-45-AS	160	200	145	
GD350-055G/075P-45-NS	100	200	140	

Table D-4 Fuse, breaker, and contactor model selection

Goodrive350 IP55 High-ingress Protection Series VFD

VFD model	Breaker rated	Fast-acting fuse rated	Contactor rated	
	current (A)	current (A)	current AC-3 (A)	
GD350-055G/075P-45-AS-B				
GD350-055G/075P-45-NS-B				
GD350-075G/090P-45-AS				
GD350-075G/090P-45-NS	000	050	4.45	
GD350-075G/090P-45-AS-B	200	250	145	
GD350-075G/090P-45-NS-B				
GD350-090G/110P-45-AS				
GD350-090G/110P-45-NS	250	215	105	
GD350-090G/110P-45-AS-B	250	315	100	
GD350-090G/110P-45-NS-B				
GD350-110G-45-AS				
GD350-110G-45-NS	045	255	24.0	
GD350-110G-45-AS-B	315	300	210	
GD350-110G-45-NS-B				

**Note:** The accessory specifications described in the preceding table are ideal values. You can select accessories based on the actual market conditions, but try not to use those with lower values.

# **D.6 Harmonic filter**

To enhance grid protection, reduce harmonic interference from the VFD to the grid, and improve input power factor, consider configuring external DC reactors, input reactors, or passive harmonic filters based on your specific application needs.

If you want to use long cables between the VFD and the motor, select external output reactors, dv/dt attenuation filters, or sine-wave filters based on the motor cable length. This helps mitigate excessive dv/dt, reducing voltage stress on the motor windings as well as protecting them, and extending the motor's lifespan. Refer to the table below for recommended output filter selections according to motor cable length.

Output filter category	Shielded cable length	Non-shielded cable length	
Output reactor (1%)	30m–100m	50m–150m	
dv/dt decrement filters	100m–230m	150m–450m	
Sine-wave filter	230m–500m	450m–1000m	

Table D-5	Output	filter	selection	for	motor	cable	lengths
-----------	--------	--------	-----------	-----	-------	-------	---------

### Table D-6 Reactor model selection

VFD power	Input reactors	Output reactors
4kW	GDL-ACL0014-4CU	GDL-OCL0010-4CU
5.5kW	GDL-ACL0020-4CU	GDL-OCL0014-4CU

Goodrive350 IP55 High-ingress Protection Series VFD

Optional peripheral accessories

VFD power	Input reactors	Output reactors		
7.5kW	GDL-ACL0025-4CU	GDL-OCL0020-4CU		
11kW	GDL-ACL0035-4AL	GDL-OCL0025-4CU		
15kW	GDL-ACL0040-4AL	GDL-OCL0035-4AL		
18.5kW	GDL-ACL0051-4AL	GDL-OCL0040-4AL		
22kW	GDL-ACL0051-4AL	GDL-OCL0050-4AL		
30kW	GDL-ACL0070-4AL	GDL-OCL0060-4AL		
37kW	GDL-ACL0090-4AL	GDL-OCL0075-4AL		
45kW	GDL-ACL0110-4AL	GDL-OCL0092-4AL		
55kW	GDL-ACL0150-4AL	GDL-OCL0115-4AL		
75kW	GDL-ACL0150-4AL	GDL-OCL0150-4AL		
90kW	GDL-ACL0220-4AL	GDL-OCL0220-4AL		
110kW	GDL-ACL0220-4AL	GDL-OCL0220-4AL		

Note:

- The rated input voltage drop of input reactor is designed to  $\geq 1.5\%$ .
- The rated output voltage drop of output reactor is designed to 1%.
- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

Table D-7	Filter mode	I selection
-----------	-------------	-------------

VED	Input filter	Output filter			
VFD power	Passive harmonic filters	dv/dt decrement filters	Sine-wave filter		
4kW	GDL-H0014-4AL	GDL-DUL0010-4CU	GDL-OSF0010-4AL		
5.5kW	GDL-H0020-4AL	GDL-DUL0014-4CU	GDL-OSF0014-4AL		
7.5kW	GDL-H0025-4AL	GDL-DUL0020-4CU	GDL-OSF0020-4AL		
11kW	GDL-H0032-4AL	GDL-DUL0025-4CU	GDL-OSF0025-4AL		
15kW	GDL-H0040-4AL	GDL-DUL0032-4CU	GDL-OSF0032-4AL		
18.5kW	GDL-H0047-4AL	GDL-DUL0040-4AL	GDL-OSF0040-4AL		
22kW	GDL-H0056-4AL	GDL-DUL0045-4AL	GDL-OSF0045-4AL		
30kW	GDL-H0070-4AL	GDL-DUL0060-4AL	GDL-OSF0060-4AL		
37kW	GDL-H0080-4AL	GDL-DUL0075-4AL	GDL-OSF0075-4AL		
45kW	GDL-H0100-4AL	GDL-DUL0100-4AL	GDL-OSF0095-4AL		
55kW	GDL-H0130-4AL	GDL-DUL0120-4AL	GDL-OSF0120-4AL		
75kW	GDL-H0160-4A	GDL-DUL0150-4AL	GDL-OSF0150-4AL		
90kW	GDL-H0190-4AL	GDL-DUL0180-4AL	GDL-OSF0180-4AL		
110kW	GDL-H0225-4AL	GDL-DUL0220-4AL	GDL-OSF0220-4AL		

Note:

- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.
- For the selection of accessories with different material requirements than those listed above, please refer to the low-voltage VFD GDL series filter option brochure.

# D.7 EMC filter

The product is shipped with J10 jumper pre-installed.

### Note: Disconnect J10 in the following situations:

- The EMC filter is applicable to the neutral-grounded grid system. If it is used for the IT grid system (that is, non-neutral grounded grid system), disconnect J10.
- If leakage protection occurs during configuration of a residual-current circuit breaker, disconnect J10.



**Note:** Do not connect C3 filters in IT power systems.

Figure D-5 Filter model



Table D-8 Model description

Field identifier	Description
А	FLT: EMC filter series

Field identifier	Description
	EMC filter type
В	P: Power input filter
	L: Output filter
0	Voltage class
C	04: AC 3PH 380V (-15%)–440V (+10%)
D	3-digit code indicating the rated current. For example, 015 indicates 15 A.
	EMC filter performance
E	L: General
	H: High-performance
	EMC filter application environment
F	A: First environment (IEC61800-3), category C1 (EN 61800-3)
	B: First environment (IEC61800-3), category C2 (EN 61800-3)
	C: Second environment (IEC61800-3), category C3 (EN 61800-3)

# Table D-9 EMC filter model selection

VFD model	Input filter	Output filter		
GD350-004G/5R5P-45-AS		FLT-L04016L-B		
GD350-004G/5R5P-45-NS	FLT-P04016L-B			
GD350-5R5G/7R5P-45-AS				
GD350-5R5G/7R5P-45-NS				
GD350-7R5G/011P-45-AS				
GD350-7R5G/011P-45-NS				
GD350-011G/015P-45-AS	FLI-P04032L-D	FLI-L04032L-B		
GD350-011G/015P-45-NS				
GD350-015G/018P-45-AS				
GD350-015G/018P-45-NS				
GD350-018G/022P-45-AS	FLI-P04045L-D	FLI-LU4U43L-B		
GD350-018G/022P-45-NS				
GD350-022G/030P-45-AS				
GD350-022G/030P-45-NS		FLT-L04065L-B		
GD350-030G/037P-45-AS	FLI-P04005L-D			
GD350-030G/037P-45-NS				
GD350-037G/045P-45-AS				
GD350-037G/045P-45-NS				
GD350-045G/055P-45-AS				
GD350-045G/055P-45-NS	FLI-P04100L-B	FLI-L04100L-B		
GD350-045G/055P-45-AS-B				
GD350-045G/055P-45-NS-B				

VFD model	Input filter	Output filter			
GD350-055G/075P-45-AS					
GD350-055G/075P-45-NS					
GD350-055G/075P-45-AS-B					
GD350-055G/075P-45-NS-B					
GD350-075G/090P-45-AS	FLT-P04150L-B	FLI-L04150L-B			
GD350-075G/090P-45-NS					
GD350-075G/090P-45-AS-B					
GD350-075G/090P-45-NS-B					
GD350-090G/110P-45-AS					
GD350-090G/110P-45-NS					
GD350-090G/110P-45-AS-B					
GD350-090G/110P-45-NS-B					
GD350-110G-45-AS	FLI-P04240L-B	FLI-L04240L-B			
GD350-110G-45-NS					
GD350-110G-45-AS-B					
GD350-110G-45-NS-B					

Note:

- The input EMI meets the C2 requirements after an EMC input filter is configured.
- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

# D.8 Braking system

### D.8.1 Braking component selection

When the VFD driving a high-inertia load decelerates or needs to decelerate abruptly, the motor runs in the power generation state and transmits the load-carrying energy to the DC circuit of the VFD, causing the bus voltage of the VFD to rise. If the bus voltage exceeds a specific value, the VFD reports an overvoltage fault. To prevent this from happening, you need to configure braking components.

<b>A</b>
----------

	• Connect braking resistors only to the terminals PB and (+), and braking units
	only to the terminals (+) and (-). Do not connect them to other terminals.
	Otherwise, damage to the braking circuit and VFD and fire may be caused.
•	Connect the braking components to the VFD according to the wiring diagram. If the
/!\	wiring is not properly performed, damage to the VFD or other devices may be
	caused.

The 037G/045P and lower models are equipped with built-in braking units, and the 045G/055P–110G models can be configured with optional built-in braking units. Select braking resistors according to the specific requirements (such as the braking torque and braking usage) on site.

		Resistance	Bra	king resis	tor	Min.
	Braking	applicable	dissipa	tion powe	er (kW)	allowed
VFD model	unit	for 100%	10%	50%	80%	braking
	model	braking	braking	braking	braking	resistance
		torque (Ω)	ratio	ratio	ratio	(Ω)
GD350-004G/5R5P-45-AS		122	0.6	3	1.8	80
GD350-004G/5R5P-45-NS		122	0.0	3	4.0	80
GD350-5R5G/7R5P-45-AS		90	0.75	4.4	6.6	60
GD350-5R5G/7R5P-45-NS		09	0.75	4.1	0.0	60
GD350-7R5G/011P-45-AS		65	1 1	5.6	0	47
GD350-7R5G/011P-45-NS		05	1.1	5.0	9	47
GD350-011G/015P-45-AS			17	0.0	12.2	21
GD350-011G/015P-45-NS	Duilt	44	1.7	8.3	13.2	31
GD350-015G/018P-45-AS	Built-In	22	2	44	10	22
GD350-015G/018P-45-NS	unit	32	2	11	18	23
GD350-018G/022P-45-AS	unit	27	3	14	22	10
GD350-018G/022P-45-NS		21	5	14	22	19
GD350-022G/030P-45-AS		22	2	17	26	17
GD350-022G/030P-45-NS		22	3	17	20	17
GD350-030G/037P-45-AS		17	F	22	26	17
GD350-030G/037P-45-NS		17	5	23	- 30	17
GD350-037G/045P-45-AS		40	0	20	4.4	44 7
GD350-037G/045P-45-NS		13	Ö	28	44	11.7
GD350-045G/055P-45-AS						
GD350-045G/055P-45-NS	DBU100 H-110-4	10	7	34	54	
GD350-045G/055P-45-AS-B		10	, '	54	54	6.4
GD350-045G/055P-45-NS-B						
GD350-055G/075P-45-AS		8	8	41	66	

#### Table D-10 Braking unit model

	Res Braking app		sistance Braking resistor policable dissipation power (kW)			Min. allowed
VFD model	unit model	for 100% braking	10% braking	50% braking	80% braking	braking resistance
GD350-055G/075P-45-NS		torque (12)	ratio	ratio	ratio	(12)
GD350-055G/075P-45-AS-B						
GD350-055G/075P-45-NS-B						
GD350-075G/090P-45-AS						
GD350-075G/090P-45-NS		0.5	44	50	00	
GD350-075G/090P-45-AS-B		0.0	11	00	90	
GD350-075G/090P-45-NS-B						
GD350-090G/110P-45-AS						
GD350-090G/110P-45-NS		E 4	4.4	<u></u>	100	
GD350-090G/110P-45-AS-B		5.4	14	60	108	
GD350-090G/110P-45-NS-B	DBU100					
GD350-110G-45-AS	H-160-4					4.4
GD350-110G-45-NS		4.5	47		100	
GD350-110G-45-AS-B		4.5	17	83	132	
GD350-110G-45-NS-B						

Note:

- Select braking resistors according to the resistance and power data provided by INVT.
- The braking resistor may increase the braking torque of the VFD. The above table describes the resistance and power for 100% braking torque, 10% braking ratio, 50% braking ratio and 80% braking ratio. You can select the braking system based on the actual operation conditions.
- When using an external braking unit, set the brake voltage class of the braking unit properly by referring to the manual of the DBU100H dynamic braking unit. If the voltage class is set incorrectly, the VFD may not run properly.

A	Do not use braking resistors whose resistance is lower than the specified minimum resistance. The VFD does not provide protection against overcurrent caused by resistors with low resistance.
	In scenarios where braking is frequently implemented, that is, the braking usage is greater than 10%, you need to select a braking resistor with higher power as required by the operation conditions according to the preceding table.

#### D.8.2 Braking resistor cable selection

Braking resistor cables should be shielded cables.

#### **D.8.3 Braking resistor installation**

All resistors must be installed in places with good cooling conditions.



The materials near the braking resistor or braking unit must be flame resistant. since the surface temperature of the resistor is high and air flowing from the resistor is of hundreds of degrees Celsius. Prevent any materials from coming into contact with the resistor.

Braking resistor installation



The 037G/045P and lower VFD models need only internal braking resistors. PB and (+) are the terminals for connecting braking resistors.



Braking unit installation



Single unit connection:



# Appendix E STO function description

Reference standards: IEC 61508-1, IEC 61508-2, IEC 61508-3, IEC 61508-4, IEC 62061, ISO 13849-1, and IEC 61800-5-2.

You can enable the safe torque off (STO) function to prevent unexpected startups when the main power supply of the drive is not switched off. The STO function switches off the drive output by turning off the drive signals to prevent unexpected startups of the motor (see the following figure). After the STO function is enabled, you can perform some-time operations (such as non-electrical cleaning in the lathe industry) and maintain the non-electrical components of the device without switching off the drive.



# E.1 STO function logic table

The following table describes the input states and corresponding faults of the STO function.

STO input state	Corresponding fault
	The STO function is triggered, and the drive stops running.
H1 and H2 opened simultaneously	Fault code:
	40: Safe torque off (STO)
H1 and H2 closed simultaneously	The STOP function is not triggered, and the drive runs
	properly.
	STL1, STL2, or STL3 fault occurred.
One of H1 and H2 opened, and the	Fault code:
other closed	41: Channel H1 exception (STL1)
other closed	42: Channel H2 exception (STL2)
	43: Exception to both channel H1 and H2 (STL3)

# E.2 STO channel delay description

STO mode	STO trigger delay <sup>1</sup> and indication delay <sup>2</sup>
STO foulty STI 1	Trigger delay < 10ms
STO fault: STET	Indication delay < 280ms
	Trigger delay < 10ms
STO fault: STL2	Indication delay < 280ms
	Trigger delay < 10ms
STO fault: STL3	Indication delay < 280ms
	Trigger delay < 10ms
STO fault: STO	Indication delay < 100ms

The following table describes the trigger and indication delay of the STO channels.

1: STO trigger delay: time interval between trigger the STO function and switching off the drive output

2: STO instruction delay: Time interval between trigger the STO function and STO output state indication

# E.3 STO function installation checklist

Before installing the STO, check the items described in the following table to ensure that the STO function can be properly used.

	Item
	Ensure that the drive can be run or stopped randomly during commissioning.
	Stop the drive (if it is running), disconnect the input power supply, and isolate the drive
	from the power cable through the switch.
	Check the STO circuit connection according to the circuit diagram.
	Check whether the shielding layer of the STO input cable is connected to the +24 V
	reference ground COM.
	Connect to the power supply.
	Test the STO function as follows after the motor stops running:
	• If the drive is running, send a stop command to it and wait until the shaft of the
	motor stops rotating.
	<ul> <li>Activate the STO circuit and send a start command to the drive. Ensure that the</li> </ul>
	motor does not start.
	Deactivate the STO circuit.
	Restart the drive, and check whether the motor is running properly.
	Test the STO function as follows when the motor is running:
	<ul> <li>Start the drive. Ensure that the motor is running properly.</li> </ul>
	Activate the STO circuit.

•	The drive reports an STO fault (for details, see section 5.5.19 Fault handling).		
	Ensure that the motor coasts to stop rotating.		
•	Deactivate the STO circuit.		
Restart the drive, and check whether the motor is running properly.			

# **Appendix F Further information**

### F.1 Product and service queries

If you have any queries about the product, contact the local INVT office. Please provide the model and serial number of the product you query about. You can visit www.invt.com to find a list of INVT offices.

# F.2 Feedback on INVT VFD manuals

Your comments on our manuals are welcome. Visit www.invt.com, directly contact online service personnel or choose **Contact Us** to obtain contact information.

## F.3 Documents on the Internet

You can find manuals and other product documents in the PDF format on the Internet. Visit www.invt.com and choose **Support** > **Download**.



E-mail:overseas@invt.com.cn Website:www.invt.com

The products are owned by Shenzhen INVT Electric Co.,Ltd. Two companies are commissioned to manufacture: (For product code, refer to the 2nd/3rd place of S/N on the name plate.)

Shenzhen INVT Electric Co., Ltd. (origin code: 01) Address: INVT Guangming Technology Building, Songbai Road, Matian, Guangming District, Shenzhen, China

**UPS** 

INVT Power Electronics (Suzhou) Co., Ltd. (origin code: 06) Address: 1# Kunlun Mountain Road, Science&Technology Town, Gaoxin District, Suzhou, Jiangsu, China

Rail Transit Traction System

New Energy Vehicle Charging System

VFD

Solar Inverter

Industrial Automation:

HMI PLC

Elevator Intelligent Control System

Energy & Power:

New Energy Vehicle Powertrain System

DCIM

New Energy Vehicle Motor



Copyright© INVT.

Manual information may be subject to change without prior notice.

202412 (V1.5)

Servo System

SVG