




# Operation **Manual**

## Communication Card



SHENZHEN INVT ELECTRIC CO., LTD.



## Safety precautions

The expansion card can be installed and operated only by people who have taken part in professional training on electrical operation and safety knowledge, obtained the certification, and been familiar with all steps and requirements for installing, performing commissioning on, operating, and maintaining the device, and are capable of preventing all kinds of emergencies.

Before installing, removing, or operating the communication card, read the safety precautions described in this manual and the variable-frequency drive (VFD) operation manual carefully to ensure safe operation.

For any physical injuries or damage to the device caused due to your neglect of the safety precautions described in this manual and the VFD operation manual, our company shall not be held liable.

- You need to open the housing of the VFD when installing or removing the communication card. Therefore, you must disconnect all power supplies of the VFD and ensure that the voltage inside the VFD is safe. For details, see the description in the VFD operation manual. Severe physical injuries or even death may be caused if you do not follow the instructions.
- Store the communication card in a place that is dustproof and damp-proof without electric shocks or mechanical pressure.
- The communication card is electrostatic sensitive. Take measurements to prevent electrostatic discharge when performing operations involving it.
- Tighten the screws up when installing the communication card. Ensure that it is firmly fixed and properly grounded.

**Terminology and abbreviations**

CAN	Controller Area Network
COB	Communication object, a transmitted unit on a CAN network. Communication objects (COBs) carry data and can be transmitted through the whole network. A COB is part of a CAN message frame.
EDS	Electronic datasheet, an ASCII file for node configuration, required when a CANopen network is configured. An EDS file contains general information about nodes and their dictionary objects (parameters).
NMT	Network management, one of the CAN application-layer service elements in the CAN reference model. It is used for the initialization, configuration, and fault handling of a CAN network.
Object dictionary	Stores information about all COBs identified by a device.
PDO	Process data object, a type of COBs, used to transmit process data, such as control command, set values, state values, and actual values.
PDO <sub>n</sub> Tx	PDO command transmitted by a slave to the master, where n refers to 1, 2, 3, 4.
PDO <sub>n</sub> Rx	PDO command transmitted by the master and received by a slave, where n refers to 1, 2, 3, 4.
SDO	Service data object, a type of COB, used to transmit non-time key data, such as parameter values.
RO	Indicates read-only access.
RW	Indicates the read and write access.
SYNC	Indicates synchronous transmission.
Node-ID	Node ID, that is, address of a communication card.
0x	Indicates that a number with this prefix is a hexadecimal value, for example, 0x10 indicates the decimal value 16.

## Contents

<b>Chapter 1 Product confirmation .....</b>	<b>1</b>
<b>Chapter 2 PROFIBUS communication card .....</b>	<b>2</b>
2.1 Overview .....	2
2.2 Features .....	2
2.3 Electrical connection .....	3
2.4 Bus network connection .....	3
2.5 System configuration .....	6
2.6 PROFIBUS-DP communication .....	7
2.7 Example of PROFIBUS-DP communication networking .....	17
<b>Chapter 3 CANopen communication card .....</b>	<b>29</b>
3.1 Overview .....	29
3.2 Features .....	29
3.3 Electrical wiring .....	31
3.4 Terminal wiring .....	31
3.5 Communication .....	32
3.6 Process data object (PDO) .....	43
3.7 Monitoring process data through SDO commands .....	53
3.8 Baud rate and communication address setting .....	56
3.9 Example of communication between CANopen and IVC3 .....	59
3.10 Example of communication between CANopen and AX70 .....	65
<b>Chapter 4 BACnet MSTP communication card .....</b>	<b>74</b>
4.1 Overview .....	74
4.2 Features .....	74
4.3 Electrical wiring .....	75
4.4 Terminal wiring .....	76
4.5 Connecting the BACnet MSTP card to the PLC .....	77
<b>Chapter 5 CAN master/slave expansion card .....</b>	<b>103</b>
5.1 CAN master/slave expansion card operation .....	103
5.2 Related function parameters .....	106
<b>Appendix A CANopen object dictionary .....</b>	<b>109</b>
<b>Appendix B Related function codes .....</b>	<b>116</b>

## Chapter 1 Product confirmation

Check the following after receiving a communication expansion card product:

- Whether the communication card is damaged.
- Whether the received communication card is the one you purchase according to the bar code label on the PCB.
- Whether all the following items are contained in the product package:
- One communication card, one tie wrap, one tie, one M3 screw, and one manual.
- If the communication card is damaged, a wrong model is delivered, or some items are missing, contact the supplier in a timely manner.
- Obtain the EDS file of the communication card from INVT. The file is named *communication card model.eds*.
- Confirm the environmental requirements for application.

Table 1-1 Environmental requirements

Item	Requirement
Operation temperature	-10—+50°C
Storage temperature	-20—+60°C
Relative humidity	5%—95%
Other weather conditions	No condensation, ice, rain, snow, or hail; solar radiation < 700 W/m <sup>2</sup>
Air pressure	70—106 kPa
Vibration and impact	5.8m/s <sup>2</sup> (0.6g) at the sine vibration of 9 Hz to 200 Hz

## Chapter 2 PROFIBUS communication card

### 2.1 Overview

PROFIBUS communication cards are optional accessories for VFDs. They can be used to connect VFDs to PROFIBUS networks. On a PROFIBUS network, VFDs are slave devices. The following functions can be performed by using a PROFIBUS communication card:

- Transmit control commands (such as start, stop, and fault reset) to a VFD.
- Transmit speed or torque reference signals to a VFD.
- Obtain state values and actual values from a VFD.
- Modify parameter values of a VFD.

### 2.2 Features

1. PROFIBUS is an international open fieldbus standard that can implement data exchange between various automation components. It is widely applicable to automation in various industries, such as the manufacturing, process, building, transportation, and power industries. It provides effective solutions for implementing integrated automation and intelligentization of field devices.
2. PROFIBUS consists of three mutually compatible components, namely PROFIBUS-Decentralised Peripherals (DP), PROFIBUS-Process Automation (PA), and PROFIBUS-Fieldbus Message Specification (FMS). It adopts the master-slave mode and is generally used for periodic data exchange between VFD devices. PRNV PROFIBUS-DP adapter modules support only the PROFIBUS-DP protocol.
3. The transmission media of a PROFIBUS field bus are twisted pairs (complying with the RS-485 standard), paired cables, or optical cables. The maximum length of a fieldbus cable must be within the range of 100 m to 1200 m, and the specific length depends on the selected transmission rate (see the chapter of "Technical Data" in the VFD manual). A maximum of 31 nodes can be connected to one PROFIBUS network segment when no repeater is used. If repeaters are used, a maximum of 127 nodes (including the repeaters and master stations) can be connected.
4. In PROFIBUS communication, tokens are transmitted between master stations or by master stations to slave stations. Single-master or multi-master systems are supported. The node to respond to the command of a master is selected by the master station, generally a programmable logic controller (PLC). For cyclic master-slave user data transmission and non-cyclic master-master data transmission, a master can also transmit commands to multiple nodes in broadcast mode. When the broadcast mode is adopted, the nodes do not need to transmit feedback signals to the master. On PROFIBUS networks, nodes cannot communicate with each other.

5. The PROFIBUS protocol is described in details in the EN50170 standard. For more information about PROFIBUS, refer to the EN50170 standard.

## 2.3 Electrical connection

1. Node selection

The node address of a device is unique on a PROFIBUS bus. The node address is set through the function parameter P15.01, and the value ranges from 0 to 127.

2. Fieldbus terminator

Each fieldbus segment is configured with two bus terminators, one on each end, to prevent operation errors. Bus terminators can protect the fieldbus signal against electrical reflections. The dual in-line package (DIP) switch on the printed circuit board (PCB) of a communication card is used to connect to the fieldbus terminator. If the communication card is the last or first module on the network, the bus terminator must be set to ON. When a PROFIBUS D-sub connector with a built-in terminator is used, you must disconnect the communication card from the terminator.

## 2.4 Bus network connection

1. Bus communication interfaces

The most common PROFIBUS transmission mode is the shielded twisted-pair copper cable transmission, in which shielded twisted-pair copper cables (complying with the RS-485 standard) are used.

The basic characteristics of this transmission technology are described as follows:

- Network topology: Linear bus with one active fieldbus terminal resistor on each end
- Media: Shielded or unshielded twisted-pair cables, depending on the EMC environmental conditions
- Number of stations: 32 on each network segment (without repeater); a maximum of 127 (with repeaters)
- Plug connection: 9-pin D-type plug. The following figure shows the pins of the connector.




Figure 2-1 Plug of the connector

Table 2-1 Connector pins

Connector pin		Description
1	-	Unused
2	-	Unused
3	B-Line	Data+ (twisted-pair wire 1)
4	RTS	Transmitting requests
5	GND_BUS	Isolation ground
6	+5V BUS	Isolated 5 V DC power supply
7	-	Unused
8	A-Line	Data- (twisted-pair wire 2)
9	-	Unused
Housing	SHLD	PROFIBUS cable shielding wire

The +5V and GND\_BUS pins are used for bus terminators. Optical transceivers (RS-485) and some other devices may need to obtain external power supplies through these pins.

For some devices, the transmission direction is determined by using the RTS pin. In regular application, only the A-Line, B-Line, and SHLD pins are used.

It is recommended that you use the standard DB9 connectors manufactured by Siemens. If the communication baud rate is required to be higher than 187.5 kbps, strictly follow the wiring standards stipulated by Siemens.

## 2. Repeaters

A maximum of 32 stations (including the master station and slave station) can be connected to each fieldbus segment. If the number of stations to be connected to a fieldbus segment exceeds 32, you need to use repeaters to connect the fieldbus segments. Generally, the number of repeaters connected in series cannot exceed 3.

**Note:** No station address is provided for repeaters, but they are calculated as stations.




Figure 2-2 Repeaters

### 3. Transmission rates and maximum transmission distances

The maximum length of a cable depends on the transmission rate. Table 2-2 describes the transmission rates and corresponding transmission distances.

Table 2-2 Transmission rates and corresponding transmission distances

Transmission rate (kbps)	A-type wire (m)	B-type wire (m)
9.6	1200	1200
19.2	1200	1200
93.75	1200	1200
187.5	1000	600
500	400	200
1500	200	-----

Table 2-3 Transmission wire parameters

Parameter	A-type wire	B-type wire
Impedance ( $\Omega$ )	135–165	100–130
Capacitance of a unit length (pF/m)	< 30	< 60
Circuit resistance ( $\Omega$ /km)	110	-----
Wire core diameter (mm)	0.64	> 0.53
Sectional area of wire core (mm <sup>2</sup> )	> 0.34	> 0.22

Besides the shielded twisted-pair copper cables, you can also use optical fibers for transmission in a PROFIBUS system. When a PROFIBUS system is applied in an environment with strong electromagnetic interference, you can use optical fiber conductors to increase the high-speed transmission distance. Two types of optical fiber conductors can be used. One is low-cost plastic fiber conductors that can be used when the transmission distance is shorter than 50 m; and the other is glass fiber conductors that can be used when the transmission distance is shorter than 1 km.

### 4. PROFIBUS bus connection diagram




Figure 2-3 PROFIBUS bus connection

Figure 2-3 shows the terminal wiring. The cables are standard PROFIBUS cables, each

consisting of a twisted pair and shielding layer. The shielding layers of PROFIBUS cables are directly grounded on all nodes. You can select a proper grounding mode based on the actual situation on site.

**Note:**

1. When connecting the stations, ensure that the data cables are not twisted together. For systems to be used in environments with strong electromagnetic radiation, you need to use cables with shielding layers. The shielding layers can improve electromagnetic compatibility (EMC).
2. If shielding braid or shielding foil is used, connect the two ends of it to the protective ground and cover an area as large as possible to ensure high conductivity. In addition, data cables need to be separated from high-voltage cables.
3. When the data transmission rate is higher than 500 kbit/s, do not use short stub. Use the plugs available in the market. Data input and output cables can be directly connected to those plugs, and the plug of the communication card can be connected or disconnected at any time without interrupting data communication of other stations.

## 2.5 System configuration

### 1. System configuration

After the communication card is properly installed, you need to configure the master station and VFD to enable the communication between the master station and communication card.

One device description file named GSD file is required for each PROFIBUS slave station on the PROFIBUS bus. The GSD file is used to describe the characteristics of the PROFIBUS-DP device. The software we provide for users includes information about the GSD file of the VFD. You can obtain the type definition files (GSD files) of various masters from us.

Table 2-4 Communication card configuration parameters

Parameter No.	Parameter name	Setting options	Default setting	
0	Module type	Read-only	PROFIBUS-DP	
1	Node address	0-99	2	
2	Baud rate setting	kbit/s	0: 9.6	6
			1: 19.2	
			2: 45.45	
			3: 93.75	
			4: 187.5	

Parameter No.	Parameter name	Setting options	Default setting
		5: 500	
		Mbit/s	
		6: 1.5	
		7: 3	
		8: 6	
		9: 9	
		10: 12	
3	PZD3	0–65535	0
4	PZD4	0–65535	0
...	...	0–65535	0
10	PZD12	0–65535	0

## 2. Module type

This parameter displays the model of the communication card detected by the VFD. You cannot modify the value of this parameter. If the parameter is not defined, communication between the communication card and VFD cannot be established.

## 3. Node address

On the PROFIBUS network, each device corresponds to one unique node address. The node address is set through P15.01.

## 4. GSD file

One device description file named GSD file is required for each PROFIBUS slave station on the PROFIBUS bus. The GSD file is used to describe the characteristics of the PROFIBUS-DP device. The GSD file includes all parameters defined for the device, including the supported baud rate, supported information length, input/output data amount, and definitions of diagnosis data.

You can obtain the type definition files (GSD files) of various masters from INVT's official website and copy the GSD files to the corresponding subdirectories on the configuration tool software. For details about the operation and how to configure the PROFIBUS system, see the instructions for the related system configuration software.

## 2.6 PROFIBUS-DP communication

### 1. PROFIBUS-DP

PROFIBUS-DP is a distributed input/output (I/O) system. It enables a master to use a large number of peripheral modules and on-site devices. Data transmission is periodic: The master reads information input from a slave and then transmits a feedback signal to the slave.

## 2. SAP

The PROFIBUS-DP system uses the services at the data link layer (Layer 2) through service access points (SAPs). Functions of each SAP are clearly defined. For more information about SAPs, see the related PROFIBUS master user manuals, that is, PROFIdrive—PROFIBUS models or EN50170 standards (PROFIBUS protocol) for variable-speed drives.

## 3. PROFIBUS-DP information frame data structure

The PROFIBUS-DP system allows fast data exchange between the master and VFD devices. For VFD devices, data is always read and written in the master/slave mode. VFDs always function as slave stations, and one address is clearly defined for each slave station. PROFIBUS transmits sixteen 16-bit words packets periodically. Figure 2-4 shows the structure of the packet.




Figure 2-4 PROFIBUS-DP information frame data structure

Parameter zone:

PKW1—Parameter identification

PKW2—Array index number

PKW3—Parameter value 1

PKW4—Parameter value 2

Process data:

CW—Control word (transmitted from the master to a slave. For description, see Table 2-5)

SW—State word (transmitted from a slave to the master. For description, see Table 2-7.)

PZD—Process data (defined by users)

(When the process data is output by the master to a slave, it is a set values; and when the process data is input by a slave to the master, it is an actual value.)

PZD zone (process data zone): The PZD zone in a communication packet is designed for controlling and monitoring a VFD. The master and slave stations always process the received PZD with the highest priority. The processing of PZD takes priority over that of PKW, and the master and slave stations always transmit the latest valid data on the interfaces.

## CWs and SWs

Using CWs is the basic method of the fieldbus system to control VFDs. A CW is transmitted by the fieldbus master station to a VFD device. In this case, the EC-TX-503 communication card functions as a gateway. The VFD device responds to the bit code information of the CW and feeds state information back to the master through an SW.

set values: A VFD device may receive control information in multiple channels, including analog and digital input terminals, VFD control panel, and communication modules (such as RS485 and EC-TX-503 communication cards). To enable the control over VFD devices through PROFIBUS, you need to set the communication module as the controller of the VFD device.

Actual value: An actual value is a 16-bit word that includes information about VFD device operation. The monitoring function is defined through VFD parameters. The conversion scale of an integer transmitted as an actual value from the VFD device to the master depends on the set function. For more description, see the related VFD operation manual.

**Note:** A VFD device always checks the bytes of a CW and set values.

Task packet (master station -> VFD)

CW: The first word in a PZD task packet is a VFD CW. Table 2-5 describes Goodrive350 series VFD CWs.

Table 2-5 Goodrive350 series VFD CWs

Bit	Name	Value	State to be entered/description
0-7	Communication-based control command	1	Forward running
		2	Reverse running
		3	Forward jogging
		4	Reverse jogging
		5	Decelerating to stop
		6	Coasting to stop
		7	Fault reset
		8	Jogging stopped
		9	Emergency stop
8	Enabling writing	1	Enabling writing (mainly through PKW1 to PKW4)
9-10	Motor group setting	00	Motor 1
		01	Motor 2
11	Control mode switching	1	Enabling the switching between torque control and speed control
		0	No switching

Bit	Name	Value	State to be entered/description
12	Resetting power consumption to zero	1	Enabling the function for resetting power consumption to zero
		0	Disabling the function for resetting power consumption to zero
13	Pre-excitation	1	Enabling pre-excitation
		0	Disabling pre-excitation
14	DC braking	1	Enabling DC braking
		0	Disabling DC braking
15	Heartbeat reference	1	Enabling heartbeat
		0	Disabling heartbeat

Reference value (REF): The second to twelfth words in a PZD task packet are the main settings. The main frequency settings are provided by the main setting signal source. Table 2-6 describes the settings of Goodrive350 series VFD.

Table 2-6 Settings of Goodrive350 series VFD

Function code	Word	Value range	Default value
P15.02	Received PZD2	0-31	0
P15.03	Received PZD3	0: Invalid	0
P15.04	Received PZD4	1: Set frequency (0-Fmax, unit: 0.01 Hz)	0
P15.05	Received PZD5	2: PID reference (0-1000, in which 1000 corresponds to 100.0%)	0
P15.06	Received PZD6	3: PID feedback (0-1000, in which 1000 corresponds to 100.0%)	0
P15.07	Received PZD7	4: Torque setting (-3000+3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0
P15.08	Received PZD8	5: Setting of the upper limit of forward running frequency (0-Fmax, unit: 0.01 Hz)	0
P15.09	Received PZD9	6: Setting of the upper limit of reverse running frequency (0-Fmax, unit: 0.01 Hz)	0
P15.10	Received PZD10	7: Upper limit of the electromotive torque (0-3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0
		8: Upper limit of the brake torque (0-3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0
		9: Virtual input terminal command, 0x000-0x3FF	0

Function code	Word	Value range	Default value
P15.11	Received PZD11	(corresponding to S8, S7, S6, S5, HDIB, HDIA, S4, S3, S2, and S1 in sequence)	0
P15.12	Received PZD12	10: Virtual output terminal command, 0x00–0x0F (corresponding to RO2, RO1, HDO, and Y1 in sequence) 11: Voltage setting (for V/F separation) (0–1000, in which 1000 corresponds to 100.0% of the rated voltage of the motor) 12: AO output setting 1 (-1000–+1000, in which 1000 corresponds to 100.0%) 13: AO output setting 2 (-1000–+1000, in which 1000 corresponds to 100.0%) 14: MSB of position reference (signed number) 15: LSB of position reference (unsigned number) 16: MSB of position feedback (signed number) 17: LSB of position feedback (unsigned number) 18: Position feedback setting flag (position feedback can be set only after this flag is set to 1 and then to 0) 19: Function parameter mapping (PZD2–PZD12 correspond to P14.49–P14.59) 20–31: Reserved	0

Response packet (VFD -> master station)

SW: The first word in a PZD response packet is a VFD SW. Table 2-7 describes the VFD SWs.

Table 2-7 Goodrive350 series VFD SWs

Bit	Name	Value	State to be entered/description
0–7	Running state	1	In forward running
		2	In reverse running
		3	Stopped
		4	Faulty
		5	POFF
		6	In pre-excitation
8	Bus voltage established	1	Ready to run
		0	Not ready to run
9–10	Motor group feedback	0	Motor 1
		1	Motor 2
11	Motor type feedback	1	Synchronous motor
		0	Asynchronous motor

Bit	Name	Value	State to be entered/description
12	Overload pre-alarm feedback	1	Overload pre-alarm generated
		0	No overload pre-alarm generated
13	Run/Stop mode	0	Keypad-based control
		1	Terminal-based control
		2	Communication-based control
14	Run/Stop mode	3	Reserved
		1	Heartbeat feedback
15	Heartbeat feedback	0	No heartbeat feedback

Actual value (ACT): The second to twelfth words in a PZD task packet are the main actual values. The main actual frequency values are provided by the main actual value signal source.

Table 2-8 Actual state values of Goodrive350 series VFD

Function code	Word	Value range	Default value
P15.13	Transmitted PZD2	0–31	0
P15.14	Transmitted PZD3	0: Invalid	0
P15.15	Transmitted PZD4	1: Running frequency (×100, Hz)	0
P15.16	Transmitted PZD5	2: Set frequency (×100, Hz)	0
P15.17	Transmitted PZD6	3: Bus voltage (×10, V)	0
P15.18	Transmitted PZD7	4: Output voltage (×1, V)	0
P15.19	Transmitted PZD8	5: Output current (×10, A)	0
P15.20	Transmitted PZD9	6: Actual output torque (×10, %)	0
P15.21	Transmitted PZD10	7: Actual output power (×10, %)	0
P15.22	Transmitted PZD11	8: Rotating speed of the running (×1, RPM)	0
		9: Linear speed of the running (×1, m/s)	
		10: Ramp frequency reference	
		11: Fault code	
		12: AI1 value (×100, V)	
		13: AI2 value (×100, V)	
		14: AI3 value (×100, V)	
		15: HDIA frequency (×100, kHz)	
		16: Terminal input state	
		17: Terminal output state	
		18: PID reference (×100, %)	
		19: PID feedback (×100, %)	
P15.23	Transmitted PZD12	20: Rated torque of the motor	0
		21: MSB of position reference (signed number)	
		22: LSB of position reference (unsigned number)	

Function code	Word	Value range	Default value
		23: MSB of position feedback (signed number) 24: LSB of position feedback (unsigned number) 25: State word 2 26: HDIB frequency value (×100, kHz) 27: High-order bit of PG card pulse feedback 28: Low-order bit of PG card pulse feedback 29: High-order bit of PG card pulse reference 30: Low-order bit of PG card pulse reference 31: Function parameter mapping (PZD2–PZD12 correspond to P14.60–P14.70)	

PKW zone (parameter identification flag PKW1—numerical zone): The PKW zone describes the processing mode of the parameter identification interface. A PKW interface is not a physical interface but a mechanism that defines the transmission mode (such reading and writing a parameter value) of a parameter between two communication ends.




Figure 2-5 Parameter identification zone

In the periodic PROFIBUS-DP communication, the PKW zone consists of four 16-bit words. Table 2-9 describes each word in the PKW zone.

Table 2-9 Each word in the PKW zone

First word PKW 1 (16 bits)		
Bits 15–00	Task or response identification flag	0–7
Second word PKW2 (16 bits)		
Bits 15–00	Basic parameter address	0–247
Third word PKW3 (16 bits)		
Bits 15–00	Value (most significant word) of a parameter or error code of the returned value	00
Fourth word PKW4 (16 bits)		
Bits 15–00	Value (least significant word) of a parameter	0–65535

**Note:** If the master station requests the value of a parameter, the values in PKW3 and PKW4 of the packet that the master station transmits to the VFD are no longer valid.

Task request and response: When transmitting data to a slave, the master uses a request number, and the slave uses a response number to accept or reject the request.

Table 2-10 describes the request and response functions.

Table 2-10 Task identification flag PKW1

Request No. (from the master to a slave)		Response signal	
Request No.	Function	Acceptance	Rejection
0	No task	0	–
1	Requesting the value of a parameter	1, 2	3
2	Modifying a parameter value (one word) [modifying the value only on RAM]	1	3 or 4
3	Modifying a parameter value (two words) [modifying the value only on RAM]	2	3 or 4
4	Modifying a parameter value (one word) [modifying the value on both RAM and EEPROM]	1	3 or 4
5	Modifying a parameter value (two words) [modifying the value only on both RAM and EEPROM]	2	3 or 4

The requests #2, #3, and #5 are not supported currently.

Table 2-11 Response identification flag PKW1

Response No. (from a slave to the master)	
Response No.	Function
0	No response
1	Transmitting the value of a parameter (one word)
2	Transmitting the value of a parameter (two words)
3	The task cannot be executed and one of the following error number is returned: 1: Invalid command 2: Invalid data address 3: Invalid data value 4: Operation failure 5: Password error 6: Data frame error 7: Parameter read only 8: Parameter cannot be modified during VFD running 9: Password protection 10: Function code mapping failed
4	Reserved


## PKW examples

## Example 1: Reading the value of a parameter

You can set PKW1 to 1 and PKW2 to 0A to read a frequency set through keypad (the address of the frequency set through keypad is 10), and the value is returned in PKW4. The following data is in hexadecimal format.

Request (master station -> VFD)

	PKW1		PKW2		PKW3		PKW4		CW		PZD2		PZD3		...	PZD12	
Request	00	01	00	0A	00	00	00	00	xx	xx	xx	xx	xx	xx	...	xx	xx



Response (VFD -&gt; master station)

	PKW1		PKW2		PKW3		PKW4		CW		PZD2		PZD3		...	PZD12	
Response	00	01	00	0A	00	00	13	88	xx	xx	xx	xx	xx	xx	...	xx	xx

0001: Response (parameter value updated)

5000: Parameter value in address 10

Example 2: Modifying the value of a parameter (on both RAM and EEPROM)

You can set PKW1 to 4 and PKW2 to 10 to modify a frequency set through keypad (the address of the frequency set through keypad is 10), and the value to be modified (50.00) is in PKW4.

Request (master station -&gt; VFD)

	PKW1		PKW2		PKW3		PKW4		CW		PZD2		PZD3		...	PZD12	
Request	00	04	00	0A	00	00	13	88	xx	xx	xx	xx	xx	xx	...	xx	xx

0004: Parameter value to be modified

5000: Parameter value in address 10

Response (VFD-&gt; master station)

	PKW1		PKW2		PKW3		PKW4		CW		PZD2		PZD3		...	PZD12	
Response	00	01	00	0A	00	00	13	88	xx	xx	xx	xx	xx	xx	...	xx	xx

0001: Response (parameter value updated)

PZD examples: The transmission of the PZD zone is implemented through VFD function code settings. For the function codes, see the related INVT VFD operation manual.

Example 1: Reading the process data of a VFD

In this example, PZD3 is set to "8: Rotating speed of the running" through the VFD parameter P15.14. This operation sets the parameter forcibly. The setting remains until the parameter is set to another option.

Response (VFD -&gt; master station)

	PKW1		PKW2		PKW3		PKW4		CW		PZD2		PZD3		...	PZD12	
Response	xx	xx	xx	xx	xx	xx	xx	xx	xx	xx	xx	xx	00	0A	...	xx	xx

### Example 2: Writing process data to a VFD device

In this example, PZD3 is set to "2: PID reference" through the VFD parameter P15.03. The parameter specified in each request frame is updated with the information contained in PZD3 until another parameter is specified.

Request (master station -> VFD)

	PKW1		PKW2		PKW3		PKW4		CW		PZD2		PZD3		...	PZD12	
Response	xx	xx	xx	xx	xx	xx	xx	xx	xx	xx	xx	xx	00	00	...	xx	xx

Subsequently, the information contained in PZD3 is used as tractive force reference in each request frame until another parameter is specified.

## 2.7 Example of PROFIBUS-DP communication networking

### 1. Preparation before networking

Hardware: One PC, three PPROFIBUS communication cards, three GD350 VFDs, and one Siemens PLC S7-300.

Software: Win10 system and Siemens TIAPORTAL V13.

### 2. GD350 VFD parameter configuration

Set P00.01 (Channel of running commands) to 2 (Communication).

Set P00.02 (Communication channel of running commands) to 1 (PROFIBUS communication).

Set P00.06 (Frequency A command setting mode) to 9 (PROFIBUS communication).

Module address (P15.01) of three VFDs are set to 3, 4, and 5 respectively.

Set P15.02 (Received PZD2) to 1 (Set frequency).


Set P15.13 (Transmitted PZD2) to 1 (Running frequency).

Set P15.14 (Transmitted PZD3) to 3 (Bus voltage).

### 3. PLC configuration


(1) Create a project.


Click **Create new project**, fill in **Project name**, and select the path where the project is stored, as shown in the following figure.




## (2) Add GSD files.

In the following project view, choose **Options** on the toolbar, and choose **Manage general station description files (GSD)** from the drop-down list. Enter the directory where the INVT GSD file is located in the source path, select the GSD file, and click the **Install** button to start the installation.






After the installation was complete successfully, a prompt pops up, indicating that the GSD file has been installed successfully.




(3) Add the project device and PROFIBUS network.



In the **Hardware catalog** on the right sidebar, choose **Controllers > SIMATIC S7-300 > CPU > CPU 315-2 PN/DP > 6ES7 315-2EH14-0A0B**, and double click the **6ES7 315-2EH14-0A0B** icon or drag it to the project.



In the **Hardware catalog** pane, choose **Other field devices > PROFIBUS DP > General > INVT ELECTRIC CO.,LTD > INVT > INVT-6SE70**, and double click the **INVT-6SE70** icon or drag it to the view of **Devices & networks**. The communication card is displayed as **Not assigned**. The example shows three slave bus networking, thus you need to add two slaves.



As shown in the following figure, click the **Not assigned** option of **INVT-6SE70** and select **PLC\_1.MPI/DP interface\_1**, and CPU and INVT-6SE70 in the network view are connected to the same PROFIBUS network. Click the **Not assigned** option of the remaining two PROFIBUS slaves and select **PLC\_1.MPI/DP interface\_1**, then PROFIBUS master and three slaves are connected to the same PROFIBUS network.







(4) Perform PROFIBUS master and slave setting.

#### PROFIBUS master setting


Click **PROFINET interface\_1** network interface position in the PLC icon to enter the PROFINET interface\_1 property editing interface of the PLC, as shown in the following figure. Click the **Ethernet addresses** option in the **General** list to set the IP address of the PLC and the IP address of the PC to be in the same subnet.

Click **MPI/DP interface\_1** in the PLC icon to enter the MPI/DP interface\_1 property editing interface of PLC. Click the **PROFIBUS address** option in the **General** list to set PROFIBUS address of PLC to 2.




## PROFIBUS slave setting

Double click the network interface position in the **INVT-6SE70** slave icon to enter the PROFIBUS interface editing interface. Click the **PROFIBUS address** option in the **General** list, set the slave address to 3, and set addresses of the remaining two slaves to 4 and 5 respectively.




## PROFIBUS slave module setting

Double click the **INVT-6SE70** slave icon in the **Devices & networks** view to enter the INVT device view interface. Double click the **IN/OUT:32Byte(16word)** module or drag it to the blank space in **Device view**. After **IN/OUT:32Byte(16word)** module is added to the project, you need to set I address and Q address of **IN/OUT:32Byte(16word)** to **0...31**. The remaining two slaves repeat this operation, and the addresses are increased by degrees.




#### 4. Save, compile, and download the project.

After PLC configuration is completed, you need to download the project configuration information to PLC S7-300, as shown in the following figure. Click **Save project** to save the entire project, and right click **PLC\_1[CPU 315-2 PN/DP]** and choose **Compile > Hardware and software (change only)** to compile the entire project. Click the **Download to device** icon to download the project configuration to the PLC controller.




Select **PN/IE** from the drop-down list of **Type of the PG/PC interface**, and Click the **Start search** button in the lower right corner to start scanning and detecting PLC devices in the subnet, as shown in the following figure. After searching is completed, the PLCs that are connected to the PC will be displayed in the list of **Compatible devices in target subnet**. Click the **Download** button to download the configuration information and PLC program to the selected PLC.



## 5. View VFD parameters.

Double click **Add new watch table** to create three watch tables for monitoring three VFD parameters respectively, as shown in the following figure.



Create target watch variables—PZD, PKW, control word and status word variables of the VFD in the newly created **Watch table\_1**, and click **Watch all** and **Modify selected values at one time immediately**, as shown in the following figure. Operations in **Watch table\_2** and **Watch table\_3** are similar to those in **Watch table\_1**.

	Name	Address	Display format	Monitor value	Modify value		Comment
1		%QW0	Hex	16#0001	16#0001	<input checked="" type="checkbox"/> <input type="checkbox"/>	PKW1
2		%QW2	Hex	16#000A	16#000A	<input checked="" type="checkbox"/> <input type="checkbox"/>	PKW2
3		%QW4	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PKW3
4		%QW6	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PKW4
5		%QW8	Hex	16#0101	16#0101	<input checked="" type="checkbox"/> <input type="checkbox"/>	CW
6		%QW10	DEC	5000	5000	<input checked="" type="checkbox"/> <input type="checkbox"/>	PZD2(INPUT)
7		%QW12	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD3(INPUT)
8		%QW14	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD4(INPUT)
9		%QW16	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD5(INPUT)
10		%QW18	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD6(INPUT)
11		%QW20	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD7(INPUT)
12		%QW22	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD8(INPUT)
13		%QW24	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD9(INPUT)
14		%QW26	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD10(INPUT)
15		%QW28	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD11(INPUT)
16		%QW30	Hex	16#0000		<input type="checkbox"/> <input type="checkbox"/>	PZD12(INPUT)

The above figure shows the examples of setting PKW read parameters and PZD.

- Set PKW1 to 0001 and PKW2 to 000A, indicating the request to read the value of P00.10 (set frequency through keypad).
- Set CW to 0101, indicating that PKW reading and writing function is enabled, and the VFD is controlled to run forward.
- Received PZD2 is set to 5000, indicating that the running frequency of the VFD is set to 50.00Hz.

17	%IW0	Hex	16#0001			PKW1
18	%IW2	Hex	16#000A			PKW2
19	%IW4	Hex	16#0000			PKW3
20	%IW6	DEC	5000			PKW4
21	%IW8	Hex	16#4101			SW
22	%IW10	DEC	5000			PZD2(OUTPUT)
23	%IW12	DEC	5656			PZD3(OUTPUT)
24	%IW14	Hex	16#0000			PZD4(OUTPUT)
25	%IW16	Hex	16#0000			PZD5(OUTPUT)
26	%IW18	Hex	16#0000			PZD6(OUTPUT)
27	%IW20	Hex	16#0000			PZD7(OUTPUT)
28	%IW22	Hex	16#0000			PZD8(OUTPUT)
29	%IW24	Hex	16#0000			PZD9(OUTPUT)
30	%IW26	Hex	16#0000			PZD10(OUTPUT)
31	%IW28	Hex	16#0000			PZD11(OUTPUT)
32	%IW30	Hex	16#0000			PZD12(OUTPUT)

The above figure shows the response results after setting PKW read parameters and PZD.

- PKW1: 0001, PKW2: 000A, PKW4: 5000, indicating that the value read from P00.10 is 5000, and 5000 indicates that the frequency set by keypad is 50.00Hz.
- SW: 4101, indicating that the running mode is set to communication control, the bus voltage is established, the VFD is ready to run, and the VFD is in forward running.
- Transmitted PZD2: 5000, indicating that the running frequency of the VFD is 50.00Hz.
- Transmitted PZD3: 5656, indicating that the bus voltage of the VFD is 565.6V.

1	%QW0	Hex	16#0004	16#0004	<input checked="" type="checkbox"/>		PKW1
2	%QW2	Hex	16#000A	16#000A	<input checked="" type="checkbox"/>		PKW2
3	%QW4	Hex	16#0000		<input type="checkbox"/>		PKW3
4	%QW6	DEC	4000	4000	<input checked="" type="checkbox"/>		PKW4
5	%QW8	Hex	16#0105	16#0105	<input checked="" type="checkbox"/>		CW
6	%QW10	DEC	5000	5000	<input checked="" type="checkbox"/>		PZD2(INPUT)
7	%QW12	Hex	16#0000		<input type="checkbox"/>		PZD3(INPUT)
8	%QW14	Hex	16#0000		<input type="checkbox"/>		PZD4(INPUT)
9	%QW16	Hex	16#0000		<input type="checkbox"/>		PZD5(INPUT)
10	%QW18	Hex	16#0000		<input type="checkbox"/>		PZD6(INPUT)
11	%QW20	Hex	16#0000		<input type="checkbox"/>		PZD7(INPUT)
12	%QW22	Hex	16#0000		<input type="checkbox"/>		PZD8(INPUT)
13	%QW24	Hex	16#0000		<input type="checkbox"/>		PZD9(INPUT)
14	%QW26	Hex	16#0000		<input type="checkbox"/>		PZD10(INPUT)
15	%QW28	Hex	16#0000		<input type="checkbox"/>		PZD11(INPUT)
16	%QW30	Hex	16#0000		<input type="checkbox"/>		PZD12(INPUT)

The above figure shows the examples of setting PKW write parameters and PZD.

- Set PKW1 to 0004, PKW2 to 000A and PKW4 to 4000, indicating that the value of P00.10 (set frequency through keypad) is changed to 40.00Hz.
- Set CW to 0105, indicating that PKW reading and writing function is enabled, and the VFD is controlled to decelerate to stop.
- Received PZD2 is set to 5000, indicating that the running frequency of the VFD is set to 50.00Hz.

17		%IW0	Hex	16#0001	<input type="checkbox"/>	PKW1
18		%IW2	Hex	16#000A	<input type="checkbox"/>	PKW2
19		%IW4	Hex	16#0000	<input type="checkbox"/>	PKW3
20		%IW6	DEC	4000	<input type="checkbox"/>	PKW4
21		%IW8	Hex	16#4103	<input type="checkbox"/>	SW
22		%IW10	DEC	0	<input type="checkbox"/>	PZD2(OUTPUT)
23		%IW12	DEC	5683	<input type="checkbox"/>	PZD3(OUTPUT)
24		%IW14	Hex	16#0000	<input type="checkbox"/>	PZD4(OUTPUT)
25		%IW16	Hex	16#0000	<input type="checkbox"/>	PZD5(OUTPUT)
26		%IW18	Hex	16#0000	<input type="checkbox"/>	PZD6(OUTPUT)
27		%IW20	Hex	16#0000	<input type="checkbox"/>	PZD7(OUTPUT)
28		%IW22	Hex	16#0000	<input type="checkbox"/>	PZD8(OUTPUT)
29		%IW24	Hex	16#0000	<input type="checkbox"/>	PZD9(OUTPUT)
30		%IW26	Hex	16#0000	<input type="checkbox"/>	PZD10(OUTPUT)
31		%IW28	Hex	16#0000	<input type="checkbox"/>	PZD11(OUTPUT)
32		%IW30	Hex	16#0000	<input type="checkbox"/>	PZD12(OUTPUT)

The above figure shows the response results after setting PKW write parameters and PZD.

- PKW1: 0001, PKW2: 000A, PKW4: 4000, indicating that the value read from P00.10 is 4000, and 4000 indicates that the frequency set by keypad is 40.00Hz.
- SW: 4103, indicating that the running mode is set to communication control, the bus voltage is established, the VFD is ready to run, and the VFD is in stopping.
- Transmitted PZD2: 0, indicating that the running frequency of the VFD is 0.00Hz.
- Transmitted PZD3: 5683, indicating that the bus voltage of the VFD is 568.3V.

## Chapter 3 CANopen communication card

### 3.1 Overview

1. Thanks for choosing INVT CANopen communication cards. This manual describes the function specifications, installation, basic operation and settings, and information about the network protocol. To ensure that you install and operate the product properly, read this manual and the communication protocol section in the VFD operation manual carefully before you use the product.
2. This manual only describes how to operate the CANopen communication card and the related commands but does not provide details about the CANopen protocol. For more information about the CANopen protocol, read the related specialized articles or books.
3. This communication card is defined as a CANopen slave station communication card and is used on a VFD that supports CANopen communication.
4. The CANopen communication of this communication card supports access to VFDs through process data objects (PDOs) and service data objects (SDOs). PDOs and SDOs are used to read the object dictionary defined by the manufacturer.

Table 3-1 Protocol selection relationship for switch SW2

Switch SW2		
1	2	Protocol
OFF	OFF	CANopen
ON	OFF	CAN master/slave

**Note:** For EC-TX505C, before power-on, set the switch according to the protocol selection relationship to correspond to the actually used protocol.

### 3.2 Features

1. Supported functions
  - Supports the CAN2.0A protocol.
  - Supports CANopen DS301.
2. Supported CANopen services
  - PDO: Supports four pairs of PDO services (PDO1 TX to PDO4 TX, and PDO1 RX to PDO4 RX), where the PDO1 pair is used to read and write parameters of a VFD, and the PDO2 to PDO4 pairs are used to control and obtain the actual parameter values of the VFD in real time.
  - SDO: SDO information adopts the "client/server" mode and is used to configure slave nodes and provide access to the object dictionary of each node.

- Supports the emergency service.
  - Supports node protection (NMT Node Guarding).
  - Supports heartbeat packets (Heartbeat Producer).
  - Supports network management (NMT).
    - Supports NMT module control.
    - Supports NMT broadcast addresses.
    - Supports NMT error control.
    - Supports boot-up.
  - Supports SYNC (1–240).
  - Supports asynchronous transmission of 254 and 255.
  - Supports disabled time.
  - Supports event timers.
  - Supports manufacturer-defined object dictionary. You can use SDOs to control and obtain the actual parameter values of a VFD in real time.
3. Non-supported CANopen services
- Saves object dictionary parameters at power outage
  - Time stamp service
4. Supported CANopen addresses and baud rates

Table 3-1 Supported addresses and baud rates

Item	Supported specification
Address	1–127 (decimal)
Baud rate	1000 kbps
	800 kbps
	500 kbps
	250 kbps
	125 kbps
	100 kbps
	50 kbps
	20 kbps

**Note:** To enable the CANopen functions (except the CANopen communication timeout fault time and baud rate), you need only to select the related CANopen channels. If modification is made on the VFD operation manual, the operation is subject to the CANopen channel, without

prior notice in this manual.

### 3.3 Electrical wiring

Use shielding wires as the bus cable, if possible. It is recommended that you connect the shielding wire to the PE terminal of the communication card. When there are only two devices for CAN master-slave communication, both devices shall be connected to the terminal resistor. When there are more than two devices, the starting device and terminal device shall be connected to the terminal resistor. The terminal resistor of the communication card can be connected through its terminal resistor switch. Figure 3-1 shows the electrical wiring.




Figure 3-1 Electrical wiring diagram

### 3.4 Terminal wiring

#### 3.4.1 Terminal layout

Table 3-2 CANopen card terminal layout

		PGND	PE	CANH	CANL

#### 3.4.2 Terminal functions

Table 3-3 CANopen card terminal functions

Signal	Port	Terminal function
PGND	/	Isolation ground
PE	/	CAN bus shield
CANH	/	CAN bus high-level signal
CANL	/	CAN bus low-level signal
Terminal resistor	OFF-bounced up	No terminal resistor is connected between CAN_H and CAN_L.
	ON-pressed	A 120Ω terminal resistor is connected between CAN_H and CAN_L.
Switch applicable to cards	00	CANopen
	10	CAN master/slave
	01	Reserved
	11	Reserved

Table 3-4 Indicator functions

Indicator	Definition	Function
LED1	Status indicator	On: The expansion card is establishing a connection with the control board. Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s). Off: The expansion card is disconnected from the control board.
LED2	Run indicator	On: The communication card is running. Off: A fault occurs. Check whether the reset pin of the communication card and the power supply are properly connected. The communication card is in the stopped state. Blinks: The communication card is in the pre-operation state. Blinks once: The communication card is in the stopped state.
LED3	Alarm indicator	On: The CAN controller bus is off or the VFD has a fault. Off: The communication card is in the working state.
LED4	Power indicator	It is on since the control board feeds power to the communication card.

## 3.5 Communication

### 3.5.1 Packet format

CAN2.0A packets are used to transmit data between the master station and bus nodes through data frames.




Figure 3-2 Packet structure

Communication object	Function code (binary)	COB-ID (hexadecimal)
NMT	0	0x00

Communication object	Function code (binary)	COB-ID (hexadecimal)
SYNC	1	0x80
EMERGENCY	1	0x81–0xFF
PDO1 Tx	11	0x181–0x1FF
PDO1 Rx	100	0x201–0x27F
PDO2 Tx	101	0x281–0x2FF
PDO2 Rx	110	0x301–0x37F
PDO3 Tx	111	0x381–0x3FF
PDO3 Rx	1000	0x401–0x47F
PDO4 Tx	1001	0x481–0x4FF
PDO4 Rx	1010	0x501–0x57F
SDO Tx	1011	0x581–0x5FF
SDO Rx	1100	0x601–0x67F
Node protection	1110	0x701–0x77F

COB-IDs vary according to communication address, but for one command, the COB-IDs are within a certain range.

**Note:** The commands described in this manual are all data frames if it is not specified that they are remote frames.

### 3.5.2 CANopen state transition

The start sequence defined in the CANopen communication protocol is supported. Figure 3-3 shows the NMT state transition diagram.




Figure 3-3 NMT state diagram

Table 3-2 NMT state transition

State transition	Required triggering event
(1)	Automatic initialization after power-on
(2)	Automatic change after initialization
(3), (6)	Command of the NMT master station for starting a remote node
(4), (7)	Command of the NMT master station for entering the pre-operation state
(5), (8)	Command of the NMT master station for entering the stopped state
(9), (10), (11)	Command of the NMT master station for resetting a remote node
(12), (13), (14)	Command of the NMT master station for resetting a remote node communication parameter

Different services are supported in different states, as described in Table 3-3.

Table 3-3 Services supported in various NMT states

Service	Pre-operation state	Operation state	Stopped state
PDOs	No	Yes	No
SDOs	Yes	Yes	No
SYNC packets	Yes	Yes	No
Emergency packets	Yes	Yes	No
Network management	Yes	Yes	No
Error control	Yes	Yes	Yes

### 3.5.3 Management service command (NMT)

This function is used by the master station to control the NMT states of slave station nodes.

- Command

Master station -> slave station

COB-ID	Byte0	Byte1
0x000	Command specifier (CS)	Node-ID (Node ID)

- Description

In this command, the COB-ID is 0x00. If Node-ID is set to 0, the command is broadcast to all CANopen slave stations, and each slave station must execute the NMT command. Table 3-4 describes the function of each CS.

Table 3-4 Function of each CS

NMT CS	NMT service (control action)
0x01	Starts a slave station device.
0x02	Stops a slave station device.
0x80	Enables a slave station to enter the pre-operation state.
0x81	Resets a slave station.
0x82	Resets communication of a node.

- Example

For example, the command to enable EC-TX505, whose node ID is 3, to enter the pre-operation state is described as follow.

COB-ID	Byte0	Byte1
0x000	0x80	0x03

For another example, the command to start all EC-TX505 nodes on the CANopen network is described as follows.

COB-ID	Byte0	Byte1
0x000	0x01	0x00

### 3.5.4 Node protection (NMT Node Guarding)

By using the node protection service, the NMT master node can detect the current state of each node.

- Command

Request: Master station (remote frame) → slave station

COB-ID	No data
0x700 + Node-ID	

Response: Slave station → master station

COB-ID	Byte0 (state value)
0x700 + Node-ID	Bit 7: Triggering bit; Bits 0 to 6: State

- Description

The most significant bit (MSB) bit 7 of Byte0 (state value) in the response command is the triggering bit, that is, the value of bit 7 is alternated between 0 and 1 each time when the slave station transmits a response frame to distinguish frames. Bits 0 to 6 indicate the state of the slave station. Table 3-5 describes the state values and their corresponding state.

Table 3-5 State values and their corresponding states

State value (Byte0: Bits 0–6)	State
0x00	Initializing
0x04	Stopped
0x05	Operation
0x7F	Pre-operational

- Example

For example, the command for the master station to detect the state of slave station 3.

Master station (remote frame) -> slave station

COB-ID	No data
0x703	/

After receiving the node protection command transmitted by the master station, the slave station transmits the following command response to the master station.

COB-ID	Byte0 (state value)
0x703	0x85

In the command, bit 7 of Byte0 is 1, and the state value is 0x05, indicating that slave station 3 is in the operation state. If receiving another node protection command, the slave station transmits a command frame in which the state value is 0x05 to the master station, and the value of bit 7 is alternated to 0.

### 3.5.5 Heartbeat packet (Heartbeat Producer)

In some cases, the master station requires that a slave station automatically transmits a frame of heartbeat packets at an interval, so that it can learn the state of the slave station in real time. The interval parameter (data length: 16 bits; unit: ms) is defined in the object dictionary 0x1017. If the interval is set to 0, the slave station does not transmit heartbeat packets. For this CANopen communication card, the interval is set to 0 by default.

- Command

Slave station -> master station

COB-ID	Byte0
0x700 + Node-ID	State value

- Description

The heartbeat packets are in the same format with the node protection response frames. The difference between them is that no triggering bit alternation is performed for heartbeat packets (the triggering bit is always 0). Table 3-5 describes the state values.

- Example

For example, if slave station 3 is in the operation state and the interval parameter in 0x1017 is set to 100, slave station 3 transmits a frame of heartbeat packets every 100 ms.

COB-ID	Byte0
0x703	0x05

SDOs can be used to disable heartbeat packets, transmitting 2B 17 10 00 00 00 00 00 (setting the interval to 0).

**Note:** On the communication card, node protection and heartbeat packets cannot be used simultaneously.

### 3.5.6 Start packet (NMT Boot-up)

After being initialized (booted up), the communication card transmits a start packet.

- Command

Slave station -> master station

COB-ID	Byte0
0x700 +Node-ID	0x00

- Example

For example, after being initialized, the communication card whose node ID is 3 transmits the following start packet.

COB-ID	Byte0
0x703	0x00

### 3.5.7 Synchronous packet object (SYNC)

Generally, SYNC signals are transmitted by the CANopen master station cyclically. A SYNC signal does not contain any data and is used mainly to request PDO Tx of a slave station node of the synchronous transmission type. 0x1005 in the object dictionary defines COB-IDs of the objects that receive synchronous packets, and they are set to 0x80 in the CANopen pre-defined connection set. For PDO Tx, the transmission types of 1 to 240 indicate synchronous transmission.

- Command

Master station -> slave station

COB-ID	No data
0x80	/

### 3.5.8 Emergency packet object (EMCY)

This packet is transmitted when an internal error occurs on the communication card or VFD, or an error is deleted.

- Command

Slave station -> master station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x80 + Node-ID	Emergency error code		Error register	VFD error code				
	LSB	MSB		bit7-0	bit15-8	bit23-16	bit31-24	bit39-32

- Description

An emergency error code is two bytes. Byte0 is the least significant byte (LSB), and Byte1 is the most significant byte (MSB). A VFD error code is five bytes. Byte3 is the LSB, and Byte7 is the MSB.

An emergency error code indicates the type of the current error, as described in Table 3-6. The error register stores the type of the current error. You can determine the error type indicated by the current emergency packet according to the value stored in the register. Table 3-7 describes the indication of the bits of the error register. For information about the VFD error codes, see the VFD operation manual. The function code P07.27 in Appendix B describes the error codes of Goodrive350 VFD.

Table 3-6 Emergency error codes

Emergency error code (hex)	Code function description
00xx	Error reset or no error
10xx	Generic error
20xx	Current
21xx	Current error on the, device input side
22xx	Current error inside the device
23xx	Current error on the device output side
30xx	Voltage error
31xx	Mains voltage
32xx	Voltage inside the device
33xx	Output voltage
40xx	Temperature
41xx	Ambient temperature
42xx	Device temperature
50xx	Device hardware
60xx	Device software
61xx	Internal software
62xx	User software
63xx	Data set

Emergency error code (hex)	Code function description
70xx	Additional modules
80xx	Monitoring
81xx	Communication error
8110	CAN overrun
8120	Error passive
8130	Life guard Error or heartbeat error
8140	Recovered from Bus-Off
82xx	Protocol error
8210	PDO not processed due to length error
8220	Length exceeded
90xx	External error
F0xx	Additional functions
FFxx	Device specific

Table 3-7 Error register bits

Error register bit	Error type
0	Generic error or no error
1	Current error
2	Voltage error
3	Temperature error
4	Communication error
5	Device description error
6	Reserved (=0)
7	Manufacturer-defined error

- Example

For example, if the "inverter unit phase U protection (OUT1)" fault occurs on the Goodrive350 VFD whose node ID is 3, and the fault type is 1 (that is, the VFD error code is 1), the communication card transmits the following emergency packet.

COB-ID	Emergency error code		Error register	VFD error code				
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x83	0x00	0x30	0x04	0x01	0x00	0x00	0x00	0x00

As you can see in the command, the emergency error code is 0x3000, indicating a voltage error. The error register is 0x04, that is, the second bit is "1", indicating a voltage error. The device error code is 0x0000000001. See the Goodrive350 VFD operation manual, and you can find that the error code 1 indicates the "inverter unit phase U protection (OUT1)" fault.

After the fault is reset, the communication card transmits the following emergency packet to notify the master station that the slave station is no longer faulty.

COB-ID	Emergency error code		Error register	VFD error code				
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x83	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00

### 3.5.9 Service data object (SDO)

SDOs are mainly used to transmit non-time key data. By using SDOs, the master station can read data from and write data to the object dictionary of a device.

- Command

Request: master station -> slave station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x600+NodeID	Request code	Object index		Subindex	Request data			
		LSB	MSB		bit7-0	bit15-8	bit23-16	bit31-24

Response: Slave station -> master station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x580+NodeID	Response code	Object index		Subindex	Response data			
		LSB	MSB		bit7-0	bit15-8	bit23-16	bit31-24

- Description

An object index is two bytes. Byte1 is the LSB, and byte2 is the MSB. For information about the indexes and subindexes, see the object dictionary in the appendix. Request codes include request codes for reading and those for writing.

Request codes for writing vary according to the character length of items in the object dictionary, and the request code for reading are 0x40. See Table 3-8.

Response codes indicating successful reading vary according to the character length of items in the object dictionary, and the response code indicating successful writing are 0x60. The response codes indicating reading failure and writing failure are both 0x80. See Table 3-9.

Table 3-8 SDO request codes and requested data

Request code type	Request code	Command description	Requested data			
			Byte4	Byte5	Byte6	Byte7
Write	0x23	Writes 4-byte data	bit7-0	bit15-8	bit23-16	bit31-24
	0x2B	Writes 2-byte data	bit7-0	bit15-8	-	-
	0x2F	Writes 1-byte data	bit7-0	-	-	-
Read	0x40	Reads data	-	-	-	-

Table 3-9 SDO response codes and response data

Response code type	Response code	Command description	Response data			
			Byte4	Byte5	Byte6	Byte7
Read	0x43	Reads 4-byte data	bit7-0	bit15-8	bit23-16	bit31-24
	0x4B	Reads 2-byte data	bit7-0	bit15-8	-	-
	0x4F	Reads 1-byte data	bit7-0	-	-	-
Write	0x60	Writing succeeds	-	-	-	-
Read/write	0x80	Reading/writing fails	Interruption error code			
			bit7-0	bit15-8	bit23-16	bit31-24

**Note:** The symbol "-" in Table 3-8 and Table 3-9 indicates that the byte is reserved and provides no function.

Table 3-10 describes the interruption error codes.

Table 3-10 Interruption error codes

Interruption code	Code function description
0503 0000	Triggering bit not alternated
0504 0000	SDO protocol times out
0504 0001	Invalid or unknown client/server
0504 0002	Invalid block size
0504 0003	Invalid sequence number
0504 0004	CRC error
0504 0005	Memory overflow
0601 0000	No access to the object
0601 0001	Attempts to read a write-only object
0601 0002	Attempts to write information to a read-only object
0602 0000	Object cannot be found in the object dictionary
0604 0041	Object cannot be mapped to PDO
0604 0042	Number and length of the object to be mapped exceeds the PDO length
0604 0043	Common parameter incompatibility
0604 0047	Common internal incompatibility of the device
0606 0000	Object access failure caused by hardware error
0607 0010	Data type not matched; service parameter length not matched
0609 0011	Subindex cannot be found in the object dictionary
0609 0030	Parameter value range exceeded
0609 0031	Written parameter value too large
0609 0032	Written parameter value too small

Interruption code	Code function description
0609 0036	Max. value less than Min. value
0800 0000	Common error
0800 0020	Data failed to be transmitted or stored in the application
0800 0021	Data failed to be transmitted or stored in the application due to device control
0800 0022	Data failed to be transmitted or stored in the application due to the current state of the device
0800 0023	Error occurs dynamically on the object dictionary or object dictionary cannot be found

● Example

For example, slave station 3 reads data from and writes data to the object whose index is 0x1801 and subindex is 03. (The object whose index is 0x1801 and subindex is 03 indicates the disabled time of PDO2 Tx. For more information, see Chapter 4.)

Write operation example: To modify the disabled time of PDO2 Tx to 1000 ms, the master station transmits the following write operation command.

COB-ID	Request code	Object index			Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	
0x603	0x2B	0x01	0x18	0x03	0xe8	0x03	0x00	0x00	

After receiving the command transmitted by the master station, the slave station transmits the following command response if the modification is successful.

COB-ID	Response code	Object index			Subindex	Response data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	
0x583	0x60	0x01	0x18	0x03	0x00	0x00	0x00	0x00	

Read operation example: To read the disabled time of PDO2 Tx, the master station transmits the following read operation command.

COB-ID	Request code	Object index			Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	
0x603	0x40	0x01	0x18	0x03	0x00	0x00	0x00	0x00	

After receiving the command transmitted by the master station, the slave station transmits the following command response if the current disabled time of PDO2 Tx is 1000 ms.

COB-ID	Response code	Object index		Subindex	Response data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x583	0x43	0x01	0x18	0x03	0xe8	0x03	0x00	0x00

Read/write error example: The master station transmits the following read operation command to read an object (whose index is 0x6000 and subindex is 0x00) that cannot be found.

COB-ID	Request code	Object index		Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x603	0x40	0x00	0x60	0x00	0x00	0x00	0x00	0x00

The object cannot be found, and therefore the slave station transmits the following read/write error command response.

COB-ID	Response code	Object index		Subindex	Response data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x583	0x80	0x00	0x60	0x00	0x00	0x00	0x02	0x06

The error code in the response is 0x06020000, indicating that "Object cannot be found in the object dictionary".

### 3.6 Process data object (PDO)

The communication card provides four PDO Tx commands (whose indexes are 0x1800 to 0x1803) and four PDO Rx commands (whose indexes are 0x1400 to 0x1403). PDO Rx is a PDO command transmitted by the master station to a slave station, that is, it is a master station command. PDO Tx is a PDO command transmitted by a slave station to the master station.

The CW, SW, setting, and return value of each PDO of the communication card are all defined with a "manufacturer-defined object dictionary". In this way, the process data of a VFD can be monitored not only through PDOs but also through SDOs. For more information, see the next chapter. Each PDO command is labeled with "manufacturer-defined object dictionary" in the format of 0xXXXX.HH, where XXXX indicates an index, HH indicates a subindex, and both of them are hexadecimal.

#### 3.6.1 Triggering mode of PDO Tx

Each PDO Tx is defined with a transmission type, disabled time, and event timer. The corresponding subindex of the transmission type is 0x02, that of the disabled time is 0x03, and that of the event timer is 0x05. Therefore, the object dictionary index corresponding to PDO2 Tx is 0x1801, and the subindex is 0x02. The same principle applies to other PDO Tx commands. For more information, see Appendix A.

**Synchronous triggering:** When the transmission type is set to 1 to 240, PDO Tx is synchronous transmission. For example, if you set the transmission type of PDO2 Tx to  $n$  ( $1 \leq n \leq 240$ ), a slave station transmits one PDO2 Tx command every time after it receives  $n$  synchronous packet objects. The same principle applies to other PDO Tx commands.

**Asynchronous triggering (254):** When the value of the event timer is not zero, a slave station transmits PDO Tx commands periodically. For example, if the event timer of PDO2 Tx is set to 200, the slave station transmits a PDO2 Tx command at the interval of 200 ms. When the value of the event timer is zero, the slave station transmits a PDO Tx command once the corresponding PDO Tx data changes, and the transmission interval is subject to the disabled time. A PDO Tx packet can be transmitted only once in the disabled time, which effectively reduces the load of the bus. When the disabled time is set to a period shorter than 50 ms, 50 ms is used as the disabled time.

**Asynchronous triggering (255):** When the value of the event timer is not zero, a slave station transmits PDO Tx commands periodically. For example, if the event timer of PDO2 Tx is set to 200, the slave station transmits a PDO2 Tx command at the interval of 200 ms. When the value of the event timer is zero, the slave station transmits a PDO Tx command once a corresponding PDO Rx command is received. For example, after receiving a PDO2 Rx command, the slave station transmits a PDO2 Tx command.

Table 3-11 Triggering modes supported by the communication card

Triggering mode	Transmission type (decimal)	Event triggering	PDO1 TX	PDO2 TX	PDO3 TX	PDO4 TX
Synchronous	1-240	/	Non-supported	Supported	Supported	Supported
Asynchronous	254	Event timer	Non-supported	Supported	Supported	Supported
		Disabled time	Non-supported	Supported	Supported	Supported
	255	Event timer=0	Supported	Supported	Supported	Supported
		Event timer=0	Non-supported	Supported	Supported	Supported
		Disabled time	Supported	Supported	Supported	Supported

Table 3-12 Default PDO Tx settings of the communication card

	PDO1 TX	PDO2 TX	PDO3 TX	PDO4 TX
<b>Transmission type</b>	255	254	254	254
<b>Event timer (ms)</b>	0	0	0	0
<b>Disabled time (ms)</b>	500	500	500	500

For how to set the triggering type of PDO Tx, see the description of SDO commands.

### 3.6.2 PDO1

PDO1 is used to read and write parameters of the VFD. The function of PDO1 is similar to that

of an SDO. SDOs are used to read and write objects of an object dictionary, and PDO1 is used to read and write parameters of the VFD.

**Note:** PDO1 Tx support only the transmission type of asynchronous transmission 255. Do not set it to other transmission types, and do not try to set the event timer to periodically transmits PDO1 Tx to the master station.

### 3.6.2.1 PDO1 Rx

- Command

Request: Master station → slave station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5
0x200+Node-ID	Request code		Parameter address		Requested data	
	0x2100.00		0x2100.01		0x2100.02	

- Description

A request code is two bytes. Byte0 is the LSB, and Byte1 is the MSB. The manufacturer defines the index 0x2100 and subindex 0x00 for the request codes. Table 3-13 describes the functions of the request codes.

Table 3-13 Request codes

Request code	Function
0	No task
1	Reading the value of a parameter
2	Modifying a parameter value [modifying the value only on RAM]
4	Modifying a parameter value [modifying the value only on both RAM and EEPROM] (reserved)

A parameter address is two bytes. Byte2 is the LSB, and Byte3 is the MSB. It indicates the address of the parameter to be read or modified.

Goodrive350 series VFD function code address representation rules: The MSB is the hexadecimal form of the number before the dot mark, and LSB is that of the number behind the dot mark. Take P10.01 as an example, the number before the dot mark is 10, that is, the MSB of the parameter address is 0x0A; and the number behind the dot mark is 01, that is, the LSB is 0x01. Therefore, the function code address is 0x0A01.

Table 3-14 Goodrive350 series VFD parameter addresses

Function code	Name	Detailed parameter description	Default value	Modify
P10.00	Simple PLC mode	0: Stops after running once 1: Keeps running in the final value after running once 2: Cyclic running	0	<input type="radio"/>
P10.01	Simple PLC memory selection	0: Not saving data at power outage 1: Saving data at power outage	0	<input type="radio"/>

A piece of requested data is two bytes. Byte4 is the LSB, and Byte5 is the MSB. It indicates the data to be modified. When the command is transmitted for reading data, the requested data is not used.

**Note:** The data domain of PDO1 Rx must be six bytes. Otherwise, the communication card reports an emergency packet.

### 3.6.2.2 PDO1 Tx

- Command

Response: Slave station -> master station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x180+Node-ID	Response code		Error code		Response data		0x00	0x00
	0x2000.00		0x2000.01		0x2000.02		-	-

- Description

Byte6 and Byte7 are reserved and both are 0x00.

A response code is two bytes. Byte0 is the LSB, and Byte1 is the MSB. Table 3-15 describes the functions of the response codes.

Table 3-15 Response codes

Response code	Function
0	No response
1	Reading or writing succeeds
3	A reading or writing error occurs. Table 3-16 describes the error codes.

A piece of response data is four bytes. Byte4 is the LSB, and Byte7 is the MSB. When a write command is responded, the response data is the data to be modified; and when a read command is responded, the response data is the data to be read.

An error code is two bytes. Byte2 is the LSB, and Byte3 is the MSB. Error codes are valid only when the response code is 3. An error code indicates the reason why it fails to respond to

PDO1 Rx. Table 3-16 describes the definitions of the error codes.

Table 3-16 Error codes

Code	Name	Definition
00H	No error	/
01H	Invalid command	The operation corresponding to the request code is not allowed to be executed. The possible causes are as follows: <ul style="list-style-type: none"> <li>• The function code is applicable only on new devices and is not implemented on this device.</li> <li>• The slave station is in the faulty state when processing this request.</li> </ul>
02H	Invalid data address	For a slave device, the data address in the request of the master station is not allowed. In particular, the combination of the register address and the number of the to-be-transmitted bytes is invalid.
03H	Invalid data value	The received data domain contains a value that is not allowed. The value indicates the error of the remaining structure in the combined request. <b>Note:</b> It does not mean that the data item submitted for storage in the register includes a value unexpected by the program.
04H	Operation failure	The parameter is set to an invalid value in the write operation. For example, a function input terminal cannot be set repeatedly.
05H	Password error	The password entered in the password verification address is different from that set by the user.
06H	Data frame error	The length of the data frame transmitted by the upper computer is incorrect, or in the RTU format, the value of the CRC check bit is inconsistent with the CRC value calculated by the lower computer.
07H	Parameter read-only	The parameter to be modified in the write operation of the master station is a read-only parameter.
08H	Parameter cannot be modified in running	The parameter to be modified in the write operation of the master station cannot be modified during the running of the VFD.
09H	Password protection	A user password is set, and the master station does not provide the password to unlock the system when

Code	Name	Definition
		performing a read or write operation. The error of system locked is reported.

- Example of PDO1

The VFD is a Goodrive350 series VFD, and the slave station address is 3. Assume that you want to set the function code P15.13 of the VFD to 1.

Command analysis: The parameter address of P15.13 is 0x0F0D. According to the protocol, the request code of PDO1 Rx is 0x02, the parameter address is 0x0F0D, and the requested data is 0x01, and therefore PDO1 Rx transmitted by the master station is as follows.

COB-ID	Request code		Parameter address		Requested data	
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5
0x203	0x02	0x00	0x0D	0x0F	0x01	0x00

If the VFD parameter is successfully modified, the following PDO1 Tx command is returned.

COB-ID	Response code		Error code		Response data		-	
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x183	0x01	0x00	0x00	0x00	0x01	0x00	0x00	0x00

### 3.6.3 PDO2 Rx

PDO2 Rx is used to modify CWs and real-time process data (setting 1, setting 2, and setting 3) of a VFD. A CW is used to control the start and stop of a VFD, and settings are used to control the real-time running values of the VFD, such as set frequency.

- Command

Master station -> slave station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x300+Node-ID	CW		Setting 1		Setting 2		Setting 3	
	0x2101.00		0x2100.03		0x2100.04		0x2100.05	

- Description

A CW is two bytes. Byte0 is the LSB, and Byte1 is the MSB. Table 3-17 describes Goodrive350 series VFD CWs.

Table 3-17 Goodrive350 series VFD CWs

Bit	Name	Value	Description
0-7	Communication-based control command	1	Forward running
		2	Reverse running

Bit	Name	Value	Description
		3	Forward jogging
		4	Reverse jogging
		5	Stop
		6	Coast to stop
		7	Fault reset
		8	Stop jogging
		9	Emergency stop
8	Enable write	1	Enable writing (mainly through PKW1 to PKW4)
		0	Disable
9–10	Motor group setting	00	Motor 1
		01	Motor 2
11	Control mode switching	1	Enable torque/speed control switching
		0	Disable switching
12	Reset power consumption to zero	1	Enable
		0	Disable
13	Pre-excitation	1	Enable
		0	Disable
14	DC braking	1	Enable
		0	Disable
15	Heartbeat reference	1	Enable
		0	Disable

The function of each setting can be set through the corresponding function code of the VFD. The setting method is the same as that for "received PZD" in PROFIBUS communication. For details, see the VFD operation manual. Setting 1, setting 2, and setting 3 correspond to received PZD2, received PZD3, and received PZD4, respectively. To set the function of setting 1 to "Set frequency", you need only to set "Received PZD2" to "1: Set frequency". The same principle applies to other settings. When multiple settings are enabled, the failure to set one setting (for example, the set value exceeds the setting range) does not affect the setting of other settings.

● Example

Assume that the VFD is a Goodrive350 series VFD, the slave station address is 3, you control the running of the VFD through CANopen communication, and you want to set the running frequency to 50 Hz through CANopen communication.

Command analysis: You need to set the VFD start mode and frequency reference mode to

CANopen communication (P00.01=2, P00.02=1, P00.06=9) first. In this example, use Setting 2 to set the running frequency (P15.03=1, that is, set Received PZD3 to "1: Set frequency").

When a CW is 0x01, it indicates that the VFD is to be run. To set the frequency to 50.00 Hz, you need to set Setting 2 to 5000, that is, 0x1388.

The PDO2 Rx command transmitted by the master station is as follows.

COB-ID	CW		Setting 1		Setting 2		Setting 3	
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x303	0x01	0x00	0x00	0x00	0x88	0x13	0x00	0x00

### 3.6.4 PDO2 Tx

PDO2 Tx is a command transmitted by a VFD to the master station. It contains a SW and real-time process data (Returned value 1, returned value 2, and returned value 3). A SW is used to notify of the state of the VFD, and returned values are used to transmit the real-time running values of VFD, such as running frequency.

The default transmission type of PDO2 Tx is 254, and therefore PDO2 Tx is transmitted once data corresponding to a SW or returned value changes.

- Command

Slave station -> master station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x280+NODEID	SW		Returned value 1		Returned value 2		Returned value 3	
	0x2001.00		0x2000.03		0x2000.04		0x2000.05	

- Description

A SW is two bytes. Byte0 is the LSB, and Byte1 is the MSB. Table 3-18 describes the definitions of the Goodrive350 series VFD SWs. For VFD of other series, see the corresponding VFD operation manual.

Table 3-18 Goodrive350 series VFD SWs

Bit	Name	Value	Description
0-7	Running state	1	In forward running
		2	In reverse running
		3	Stopped
		4	Faulty
		5	POFF
8	Bus voltage established	1	Ready to run
		0	Not ready to run
9-10	Motor group feedback	0	Motor 1

Bit	Name	Value	Description
		1	Motor 2
11	Motor type feedback	1	Synchronous motor
		0	Asynchronous motor
12	Overload pre-alarm feedback	1	Overload pre-alarm generated
		0	No overload pre-alarm generated
13–14	Run/stop mode	0	Keypad-based control
		1	Terminal-based control
		2	Communication-based control
		3	Reserved
15	Heartbeat feedback	1	Heartbeat feedback
		0	No heartbeat feedback

The function of each returned value can be set through the corresponding function code of the VFD. The setting method is the same as that for "Transmitted PZD" in PROFIBUS communication. For details, see the VFD operation manual. Returned value 1, returned value 2, and returned value 3 correspond to transmitted PZD2, transmitted PZD3, and transmitted PZD4, respectively. To set the function of returned value 1 to "Running frequency", you need only to set "Transmitted PZD2" to "1: Running frequency". The same principle applies to other returned values. Multiple returned values can be enabled simultaneously.

#### ● Example

Assume that the VFD is a Goodrive350 series VFD, the slave station address is 3, the VFD is running, and the running frequency is 50.00 Hz. Returned value 1 is set to "Running frequency", returned value 2 is set to "Output voltage", and returned value 3 is set to no function.

Command analysis: You need to set returned value 1 to the running frequency of the VFD (P15.13=1), returned value 2 to the output voltage of the VFD (P15.14=4), and returned value 3 to invalid (P15.15=0) first.

The VFD is running and the bus voltage has been established, and therefore the SW is 0x0101. The running frequency is 50.00 Hz, and therefore returned value 1 is 5000, that is, 0x1388. If the output voltage is 380 V, returned value 2 is 0x017C.

The PDO2 Tx command transmitted by the VFD is as follows.

COB-ID	SW		Returned value 1		Returned value 2		Returned value 3	
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x283	0x01	0x01	0x88	0x13	0x7C	0x01	0x00	0x00

### 3.6.5 PDO3 Rx and PDO4 Rx

PDO3 Rx and PDO4 Rx are used to modify the real-time process data of a VFD, such as set frequency.

- PDO3 Rx command

Master station -> slave station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x400+NODEID	Setting 4		Setting 5		Setting 6		Setting 7	
	0x2100.06		0x2100.07		0x2100.08		0x2100.09	

- PDO4 Rx command

Master station -> slave station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x500+NODEID	Setting 8		Setting 9		Setting 10		Setting 11	
	0x2100.0a		0x2100.0b		0x2100.0c		0x2100.0d	

- Description

The application methods for PDO3 Rx and PDO4 Rx are the same as that for PDO2 Rx. For the relationship between the settings and PZD in PROFIBUS communication, see Table 3-19.

### 3.6.6 PDO3 Tx and PDO4 Tx

PDO3 Tx and PDO4 Tx are used by the VFD to transmit real-time process data to the master station, such as running frequency.

The default transmission type of PDO3 Tx and PDO4 Tx is 254, and therefore PDO3 Tx or PDO4 Tx is transmitted once data corresponding to a returned value in the same command changes.

- PDO3 Tx command

Slave station -> master station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x380+NODEID	Returned value 4		Returned value 5		Returned value 6		Returned value 7	
	0x2000.06		0x2000.07		0x2000.08		0x2000.09	

- PDO4 Tx command

Slave station -> master station

COB-ID	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x480+NODEID	Returned value 8		Returned value 9		Returned value 10		Returned value 11	
	0x2000.0a		0x2000.0b		0x2000.0c		0x2000.0d	

- Description

The application methods for PDO3 Tx and PDO4 Tx are the same as that for PDO2 Tx. For the relationship between the returned values and PZD in PROFIBUS communication, see Table 3-20.

### 3.7 Monitoring process data through SDO commands

The communication can use SDOs as well as PDOs to monitor the process data of a VFD. You can select a monitoring mode as required. You can monitor the VFD by using SDOs to read the manufacturer-defined object dictionary.

For the definition and application of the CWs, SWs, settings, and returned values in the manufacturer-defined object dictionary, see the PDO description section. For application of SDOs, see the SDO description section. Do not try to use SDOs to read and write VFD parameters.

Table 3-19 and Table 3-20 describe the manufacturer-defined object dictionary.

Table 3-19 Objects with the control function in the manufacturer-defined object dictionary

Index (hexadecimal)	Subindex (hexadecimal)	Function	Access permission	Data length	Corresponding to
2100	0	Request code (do not use it)	RW	2 bytes	/
	1	Parameter address (do not use it)	RW	2 bytes	/
	2	Requested data (do not use it)	RW	2 bytes	/
	3	Setting 1	RW	2 bytes	Received PZD2
	4	Setting 2	RW	2 bytes	Received PZD3
	5	Setting 3	RW	2 bytes	Received PZD4
	6	Setting 4	RW	2 bytes	Received PZD5
	7	Setting 5	RW	2 bytes	Received PZD6
	8	Setting 6	RW	2 bytes	Received PZD7
	9	Setting 7	RW	2 bytes	Received PZD8
	A	Setting 8	RW	2 bytes	Received PZD9
	B	Setting 9	RW	2 bytes	Received PZD10
	C	Setting 10	RW	2 bytes	Received PZD11
	D	Setting 11	RW	2 bytes	Received PZD12
E	Reserved	RW	2 bytes	/	
F	Reserved	RW	2 bytes	/	
2101	0	CW	RW	2 bytes	/

Table 3-20 Objects with the monitoring function in the manufacturer-defined object dictionary

Index (hexadecimal)	Subindex (hexadecimal)	Function	Access permission	Data length	Corresponding to
2000	0	Response code (do not use it)	RO	2 bytes	/
	1	Error code (do not use it)	RO	2 bytes	/
	2	Response data (do not use it)	RO	2 bytes	/
	3	Returned value 1	RO	2 bytes	Transmitted PZD2
	4	Returned value 2	RO	2 bytes	Transmitted PZD3
	5	Returned value 3	RO	2 bytes	Transmitted PZD4
	6	Returned value 4	RO	2 bytes	Transmitted PZD5
	7	Returned value 5	RO	2 bytes	Transmitted PZD6
	8	Returned value 6	RO	2 bytes	Transmitted PZD7
	9	Returned value 7	RO	2 bytes	Transmitted PZD8
	A	Returned value 8	RO	2 bytes	Transmitted PZD9
	B	Returned value 9	RO	2 bytes	Transmitted PZD10
	C	Returned value 10	RO	2 bytes	Transmitted PZD11
	D	Returned value 11	RO	2 bytes	Transmitted PZD12
	E	Reserved	RO	2 bytes	/
F	Reserved	RO	2 bytes	/	
2001	0	SW	RO	2 bytes	/

- Examples

Example 1: To instruct the VFD whose address is 3 to run forwardly, the master station transmits the following SDO command.

COB-ID	Request code	Object index		Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x603	0x2B	0x01	0x21	0x00	0x01	0x00	0x00	0x00

Example 2: Assume that the address of the VFD slave station is 3, and the function of setting 1 is defined as "Set frequency". To set the frequency to 50.00 Hz (that is, setting 1=0x1388), the master station transmits the following SDO command.

COB-ID	Request code	Object index		Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x603	0x2B	0x00	0x21	0x03	0x88	0x13	0x00	0x00

Example 3: To read the running state of the VFD whose address is 3, the master station transmits the following SDO command.

COB-ID	Request code	Object index		Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x603	0x40	0x01	0x20	0x00	0x00	0x00	0x00	0x00

If the VFD is running forward, the following SDO command is returned to the master station.

COB-ID	Request code	Object index		Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x583	0x4B	0x01	0x20	0x00	0x01	0x01	0x00	0x00

Example 4: Assume that the address of the VFD slave station is 3, and the function of setting 1 is defined as "Set frequency". To set the frequency to 50.00 Hz (that is, setting 1=0x1388), the master station transmits the following SDO command.

COB-ID	Request code	Object index		Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x603	0x40	0x00	0x20	0x03	0x00	0x00	0x00	0x00

If the running frequency of the VFD is 50.00 Hz, the following SDO command is returned to the master station.

COB-ID	Request code	Object index		Subindex	Requested data			
	Byte0	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7
0x583	0x4B	0x00	0x20	0x03	0x88	0x13	0x00	0x00

### 3.8 Baud rate and communication address setting

#### 3.8.1 Baud rate setting

After setting the CANopen baud rate and communication address, you need to restart the VFD to enable the settings to take effect.

The CANopen baud rate is set through the corresponding VFD function parameter. For description of function code addresses, see the VFD operation manual. Table 3-21 describes the values of the function parameter and their corresponding baud rates.

Table 3-21 Baud rate setting

Function parameter value	Baud rate (bit/s)
0	1000 k
1	800 k
2	500 k
3	250 k
4	125 k
5	100 k
6	50 k
7	20 k

#### 3.8.2 Communication address setting

The CANopen communication address is set through the function parameter P15.01.

#### 3.8.3 Function codes related to transmitted and received PZD

Table 3-22 Received PZD

Function code	Word	Value range	Default value
P15.02	Received PZD2	0–31 0: Invalid	0
P15.03	Received PZD3	1: Set frequency (0–Fmax, unit: 0.01 Hz) 2: PID reference (0–1000, in which 1000 corresponds to 100.0%)	0
P15.04	Received PZD4	3: PID feedback (0–1000, in which 1000 corresponds to 100.0%)	0
P15.05	Received PZD5	4: Torque setting (-3000+3000, in which 1000	0

Function code	Word	Value range	Default value
P15.06	Received PZD6	corresponds to 100.0% of the rated current of the motor)	0
P15.07	Received PZD7	5: Setting of the upper limit of forward running frequency (0–Fmax, unit: 0.01 Hz)	0
P15.08	Received PZD8	6: Setting of the upper limit of reverse running frequency (0–Fmax, unit: 0.01 Hz)	0
P15.09	Received PZD9	7: Upper limit of the electromotive torque (0–3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0
P15.10	Received PZD10	8: Upper limit of the brake torque (0–2000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0
P15.11	Received PZD11	9: Virtual input terminal command, 0x000–0x3FF (corresponding to S8, S7, S6, S5, HDIB, HDIA, S4, S3, S2, and S1 in sequence)	0
P15.12	Received PZD12	10: Virtual output terminal command, 0x00–0x0F (corresponding to RO2, RO1, HDO, and Y1 in sequence) 11: Voltage setting (for V/F separation) (0–1000, in which 1000 corresponds to 100.0% of the rated voltage of the motor) 12: AO output setting 1 (-1000→+1000, in which 1000 corresponds to 100.0%) 13: AO output setting 2 (-1000→+1000, in which 1000 corresponds to 100.0%) 14: MSB of position reference (signed number) 15: LSB of position reference (unsigned number) 16: MSB of position feedback (signed number) 17: LSB of position feedback (unsigned number) 18: Position feedback setting flag (position feedback can be set only after this flag is set to 1 and then to 0) 19: Function parameter mapping (PZD2–PZD12 correspond to P14.49–P14.59) 20–31: Reserved	0

Table 3-23 Transmitted PZD


Function code	Word	Value range	Default value
P15.13	Transmitted PZD2	0–31	0
P15.14	Transmitted PZD3	0: Invalid	0
P15.15	Transmitted PZD4	1: Running frequency (x100, Hz)	0

Function code	Word	Value range	Default value
P15.16	Transmitted PZD5	2: Set frequency ( $\times 100$ , Hz)	0
P15.17	Transmitted PZD6	3: Bus voltage ( $\times 10$ , V)	0
P15.18	Transmitted PZD7	4: Output voltage ( $\times 1$ , V)	0
P15.19	Transmitted PZD8	5: Output current ( $\times 10$ , A)	0
P15.20	Transmitted PZD9	6: Actual output torque ( $\times 10$ , %)	0
P15.21	Transmitted PZD10	7: Actual output power ( $\times 10$ , %)	0
P15.22	Transmitted PZD11	8: Rotating speed of the running ( $\times 1$ , RPM)	0
P15.23	Transmitted PZD12	9: Linear speed of the running ( $\times 1$ , m/s) 10: Ramp frequency reference 11: Fault code 12: AI1 value ( $\times 100$ , V) 13: AI2 value ( $\times 100$ , V) 14: AI3 value ( $\times 100$ , V) 15: HDIA frequency ( $\times 100$ , kHz) 16: Terminal input state 17: Terminal output state 18: PID reference ( $\times 100$ , %) 19: PID feedback ( $\times 100$ , %) 20: Rated torque of the motor 21: MSB of position reference (signed number) 22: LSB of position reference (unsigned number) 23: MSB of position feedback (signed number) 24: LSB of position feedback (unsigned number) 25: State word 26: HDIB frequency value ( $\times 100$ , kHz) 27: High-order bit of PG card pulse feedback 28: Low-order bit of PG card pulse feedback 29: High-order bit of PG card pulse reference 30: Low-order bit of PG card pulse reference	0


Function code	Word	Value range	Default value
		31: Function parameter mapping (PZD2–PZD12 correspond to P14.60–P14.70)	

### 3.9 Example of communication between CANopen and IVC3

Step 1 Create a project. Open INVT small PLC programming software Auto Station, choose **File > New project** and then fill in a program name, location, PLC type, and other required information. The interface is shown as follows.




Step 2 Complete the CANopen configuration. Choose **Project manager > System block > CANopen configuration** to enter PLC master station setting. The interface is shown as follows.




PLC station number and baud rate can be set through the software and dial-up. In this example, PLC station number and baud rate are set to 10 and 250K respectively through the software (by default).

Step 3 Import the EDS file for the slave node. Choose **Master configuration > Import** to import the EDS file **EC-TX505.edb** of GD350 series high performance vector VFD, select slave station number, set transmission speed and interval time of synchronous messages, and other information. The interface is shown as follows.




In this example, the slave number is 1, baud rate is 250k, and synchronization cycle period is 20ms.

Step 4 Configure the slave PDO data. Each slave station has four received PDOs and four transmitted PDOs. Since each PDO has multiple transmission modes, you can configure the response data and transmission modes according to the actual communication situation. Take transmitted PDO 1, transmitted PDO 2, received PDO 1 and received PDO 2 for example. The interface is shown as follows.




Double click one PDO to set the transmission mode, such as **sync** (mode 1–240) and **asyn** (mode 254 and 255). The interface is shown as follows.




Refer to the description of CANopen communication of GD350 VFD, transmitted PDO 1 only supports 255 transmission mode, and does not support event timer mode. Therefore, received PDO 1 mode is configured as asynchronous 255 mode, and event timer is configured as 0ms, inhibition time is configured as 50ms, that is, transmitted PDO 1 message is sent at most once within 50ms.

Transmitted PDO 2 supports all transmission modes. Generally, it is configured as 254


mode with an appropriate inhibition time. Transmitted PDO 2 message is sent upon data change, but it can be only sent once in each inhibition time so as to use bus resources reasonably. In the following interface, transmission mode is configured as 254, and inhibition time is configured as 50ms.




Received PDOs support all transmission modes. Generally, received PDO 1 is configured as 254 mode with an appropriate inhibition time while received PDO 2–4 are configured as synchronous mode. Different synchronous modes are configured according to real-time requirements of communication data. In the following interface, transmission mode of received PDO 1 is configured as 254, and inhibition time is configured as 50ms.



In the following interface, transmission mode of received PDO 2 is configured as 1, that is, the master transmits received PDO 2 once per sync cycle period. The sync cycle period is configured as 20ms, that is, the master transmits received PDO 2 once every 20ms.



Step 5 Perform symbol mapping. Map the configuration data to the internal storage area of the PLC. Choose **Symbol > Reset > Generate global variables**. The interface is shown as follows.



Step 6 Set VFD function parameters. The parameters are set as follows.

Function code	Setting	Description
P00.01	2	Start/stop through communication
P00.02	1	CANopen communication mode
P00.06	9	Set frequency through CANopen communication
P15.01	1	Communication node number
P15.02	1	Set frequency
P15.13	1	Running frequency
P15.14	3	Bus voltage
P15.15	4	Output voltage
P15.16	5	Output current
P15.27	3	Communication baud rate 250kbps

The configuration is completed. The data variables corresponding to transmitted PDO 1 are D5000–D5002, data variables corresponding to transmitted PDO 2 are D5003–D5006, data variables corresponding to received PDO 1 are D5512–D5514, and data variables corresponding to received PDO 2 are D5515–D5518.

Of which, D5000 is a request code for reading and writing, D5001 is parameter address, D5002 is request data. Set D5000=1, indicating a request for reading the value of a parameter. Set D5001=11, namely, P00.11 (Acceleration time) address, indicating that received PDO 1 is to read the acceleration time of slave 1.

Return data D5512=1, indicating that the parameter is read successfully. D5514=400, indicating P00.11 is set to 40.0.

Set D5515=1, indicating that the VFD starts in the forward direction. Set D5516=264, indicating that communication frequency of the VFD is set to 2.64Hz.

Transmitted PDO 2 returns the running state and data regularly, in which the state word is D5003=16#4101 (heartbeat feedback, ready to run, VFD is in forward running), D5004=264 (running frequency 2.64Hz), D5005=5793 (bus voltage 579.3V), D5006=18 (output Voltage 18V), and D5007=0 (output current 0.0A). The interface is shown as follows.


	Element Name	data type	display format	current value	new value
1	D5512	WORD	Decimal		1
2	D5513	WORD	Decimal		11
3	D5514	WORD	Decimal		5
4	D5515	WORD	Decimal		1
5	D5516	WORD	Decimal		264
6	D5000	WORD	Decimal		
7	D5001	WORD	Decimal		
8	D5002	WORD	Decimal		
9	D5003	WORD	Hexadecimal		
10	D5004	WORD	Decimal		
11	D5005	WORD	Decimal		
12	D5006	WORD	Decimal		
13	D5007	WORD	Decimal		

### 3.10 Example of communication between CANopen and AX70


1. Set parameters of the VFD.

Function code	Setting value	Description
P00.01	2	Start/stop through communication
P00.02	1	CANopen communication mode
P00.06	9	Set frequency through CANopen communication
P15.01	1	Communication node number
P15.02	1	Set frequency
P15.13	1	Running frequency
P15.14	3	Bus voltage
P15.15	4	Output voltage
P15.16	5	Output current
P15.27	3	Communication baud rate 250kbps


2. Open CODESYS V3.5 SP15 Patch 1, click **New project**, select **Templates**, and fill in **Name** and **Location**.




3. Select the device and programming language.




4. Click **Tools** in the menu bar and select **System Repository** as shown in the following figure. Click **Install** to import the EDS file.




5. Right click **Device (INVT AX7X)** in the **Devices** pane, and choose **Add Device... > CANbus > Add Device**.




6. Right click **CANbus** in the **Devices** pane, and choose **Add Device... > CANopen\_Manager > Add Device**.




7. Right click **CANopen\_Manager** in the **Devices** pane, and choose **Add Device... > EC-TX505 > Add Device**.




After devices are added completely, the interface is shown as follows.



8. Double click **CANbus** in the **Devices** pane to set the baud rate of the network.



9. Double click **EC\_TX505** in the **Devices** pane to set the node ID of the slave station.



10. Double click **PDOs** in the above figure, and double click PDO mapping to set the PDO as shown in the following figure.

Receive PDOs (Master => Slave)				Transmit PDOs (Slave => Master)	
Name	Object	Bit length		Name	Object
✓ 16#1400: Receive PDO1 p	16#201 (\$NODEID+16	48		✓ 16#1800: Transmit PDO1	16#181 (\$NODEID+1
read or write	16#2100:16#00	16		CANopen resp	16#2000:16#00
CANopen function	16#2100:16#01	16		CANopen read fuction	16#2000:16#01
CANopen write fuction	16#2100:16#02	16		error resp	16#2000:16#02
✓ 16#1401: Receive PDO2 p	16#301 (\$NODEID+16	64		✓ 16#1801: Transmit PDO2	16#281 (\$NODEID+1
Operation Command	16#2101:16#00	16		Operation Statusword	16#2001:16#00
set_value1	16#2100:16#03	16		return_value1	16#2000:16#03
set_value2	16#2100:16#04	16		return_value2	16#2000:16#04
set_value3	16#2100:16#05	16		return_value3	16#2000:16#05
✓ 16#1402: Receive PDO3 p	16#401 (\$NODEID+16	64		✓ 16#1802: Transmit PDO3	16#281 (\$NODEID+1
set_value4	16#2100:16#06	16		return_value4	16#2000:16#06
set_value5	16#2100:16#07	16		return_value5	16#2000:16#07
set_value6	16#2100:16#08	16		return_value6	16#2000:16#08
set_value7	16#2100:16#09	16		return_value7	16#2000:16#09
✓ 16#1403: Receive PDO4 p	16#501 (\$NODEID+16	64		✓ 16#1803: Transmit PDO4	16#481 (\$NODEID+1
set_value8	16#2100:16#0A	16		return_value8	16#2000:16#0A
set_value9	16#2100:16#0B	16		return_value9	16#2000:16#0B
set_value10	16#2100:16#0C	16		return_value10	16#2000:16#0C
set_value11	16#2100:16#0D	16		return_value11	16#2000:16#0D

**PDO Properties**

COB ID:   RTR  
 = 16#181 (385)

Inhibit time (x 100µs):

Transmission type:

Number of syncs:

Event time (x 1ms):

Process by CANopenManager

11. Double click **CANopen I/O Mapping** and select **Enabled 2 (always in bus cycle task)**.

Variable	Mapping	Channel	Address	Type	Unit	Description
#		read or write	%QW22	UINT		
#		CANopen function	%QW23	UINT		
#		CANopen write function	%QW24	UINT		
#		Operation Command	%QW25	UINT		
#		set_value1	%QW26	UINT		
#		set_value2	%QW27	UINT		
#		set_value3	%QW28	UINT		
#		set_value4	%QW29	UINT		
#		set_value5	%QW30	UINT		
#		set_value6	%QW31	UINT		
#		set_value7	%QW32	UINT		
#		set_value8	%QW33	UINT		
#		set_value9	%QW34	UINT		
#		set_value10	%QW35	UINT		
#		set_value11	%QW36	UINT		
#		CANopen resp	%IW2	UINT		
#		CANopen read function	%IW3	UINT		
#		error resp	%IW4	UINT		
#		Operation Statusword	%IW5	UINT		

Buttons: Reset Mapping, Always update variables, **Enabled 2 (always in bus cycle task)**

12. Double click **Device (INVT AX7X)** in the **Devices** pane, choose **Scan Network...**, and choose the PLC.

Communication Settings: **Scan Network...** Gateway - Device -

IP-Address: localhost  
Ports: 1217

Select the network path to the controller:

- Gateway-1 (scanning...)
  - AX71-C-1608P [0301.B00A]**

Device Name: AX71-C-1608P  
Device Address: 0301.B00A  
Block driver: UDP  
Number of channels: 4  
Serial number: 807E11300B60  
Target ID: 1631.0003

Buttons: **OK**, Cancel

13. Click the **Compile** icon in the toolbar.




Make sure that there is no error.



14. Click the **Login** icon.




Click **Yes**.



15. Click the **Run** icon.



The normal operation of the device is shown as follows.



16. Open **CANopen I/O Mapping** in the EC\_TX505 page, modify the parameters of the VFD, and view the status of the VFD.

The screenshot shows the 'EC\_TX505' configuration window with the 'CANopen I/O Mapping' tab selected. The table below lists the configured variables and their properties. A red box highlights the 'Current Value' and 'Prepared Value' columns.

Variable	Mapping	Channel	Address	Type	Current Value	Prepared Value	Unit	Description
+		Operation Command	%QW25	LINT	0			
+		set_value1	%QW26	LINT	0			
+		set_value2	%QW27	LINT	0			
+		set_value3	%QW28	LINT	0			
+		set_value4	%QW29	LINT	0			
+		set_value5	%QW30	LINT	0			
+		set_value6	%QW31	LINT	0			
+		set_value7	%QW32	LINT	0			
+		set_value8	%QW33	LINT	0			
+		set_value9	%QW34	LINT	0			
+		set_value10	%QW35	LINT	0			
+		set_value11	%QW36	LINT	0			
+		CANopen resp	%DI2	LINT	0			
+		CANopen read fuction	%DI3	LINT	0			
+		error resp	%DI4	LINT	0			
+		Operation Statusword	%DI5	LINT	16643			
+		return_value1	%DI6	LINT	0			
+		return_value2	%DI7	LINT	0			
+		return_value3	%DI8	LINT	0			
+		return_value4	%DI9	LINT	0			

Buttons at the bottom: **Reset Mapping** | **Always update variables** | Enabled 1 (use bus cycle task if not used in any task)

## Chapter 4 BACnet MSTP communication card

### 4.1 Overview

As a BACnet slave, it can realize operations such as the reading and writing of VFD process data and function codes, reading of VFD status words, and writing of VFD control words. The application layer supports setting 32 analog value objects and supports host controllers such as Yet Another BACnet Explorer (YABE) and PLC controller.

### 4.2 Features

In market demand, BACnet MS/TP is a data communication protocol used primarily in the building automation and HVAC (heating, ventilation and air conditioning) industries. The protocol supports devices such as fans, pumps and ventilation units to establish communication with PLCs. This facilitates a high level of automation in buildings.

The physical transmission medium for the bus is twisted pair (RS485 compliant), two-wire cable or fiber optic cable. The baud rate ranges from 9.6 kbit/s to 115.2 kbit/s. The maximum length of the bus cable is in the range of 100 m to 1200 m, depending on the selected transmission rate. A maximum of 31 nodes can be connected to the same network segment when repeaters are not used, while the number of nodes connected to the network (including repeaters and master nodes) can be increased to 127 when repeaters are used.

Table 4-1 BACnet MSTP card technical specifications

Category		Specifications
Main functions	Feature	<ul style="list-style-type: none"> <li>● Supports the BACnet protocol and BACnet MSTP devices.</li> <li>● Provides one BACnet MSTP port and supports half-duplex operations of 115.2kbps.</li> <li>● Supports the line, star, and daisy chain connection network topologies, with the number of slave nodes up to 31.</li> <li>● Supports timeout detection.</li> </ul>
	Service	<ul style="list-style-type: none"> <li>● Single-property reading service</li> <li>● Multi-property reading service</li> <li>● Single-property writing service</li> <li>● Multi-property writing service</li> <li>● I-Am service</li> <li>● I-Have service</li> <li>● Device communication control service</li> <li>● Device re-initialization service</li> </ul>
	Function	<ul style="list-style-type: none"> <li>● Supports the setting of 32 analog objects.</li> <li>● Supports the reading and writing of VFD process data and function codes, reading of VFD status words, and writing of VFD control words.</li> </ul>

Category		Specifications
		<ul style="list-style-type: none"> <li>Supports host controllers such as YABE and PLC.</li> </ul>
Others	Input power	Power voltage of 24V, current of 200mA, and maximum power of 4.8W
	Installation method	GD350 option, inserted to the slot
	Running environment temperature	-10 – +50 °C
	Storage temperature	-20 – +60 °C
	Relative humidity	5%–95% (No condensation)
	Distance	Up to 100 m (cable of shielded twisted pair or with magnetic ring) from the controller

### 4.3 Electrical wiring

#### 1. Node selection

A node address is the unique address of a device on the bus, and the address number of a node is set by the function code P15.01.

#### 2. Bus terminator

Each segment has a bus terminator at the head and at the tail to ensure error-free operation. The switches on the PCB are used to switch on the bus terminators, which prevent signal reflection at the bus cable end. If the communication card is the last or first module in the network, the bus terminator must be set to ON. When a D-sub connector with a built-in terminator is used, the communication card terminator must be disconnected.

Table 4-2 RS485 hardware specifications

Item	Description
Number of ports	1
Isolation	1.5kV electrical isolation
Standard	TIA/EIA-485
Communication speed and duplex	0.96k–115.2k baud (protocol depended), half-duplex
Connector type	Swappable, 3-bits, screw-type wiring board
Cable type	Cable of shielded twisted pair or with magnetic ring
Cable length	100 m
Topology	Line, star, and daisy chain connection
Unit load	1/8

## 4.4 Terminal wiring

### 4.4.1 control terminal layout

Table 4-3 BACnet MSTP card terminal layout

485+	485-	PGND	PE
------	------	------	----

### 4.4.2 control terminal functions

Table 4-4 BACnet MSTP card terminal functions

Signal	Port	Terminal function description
485+	RS-485	Positive differential signal
485-		Negative differential signal
PGND	/	Signal ground
PE	/	Earth

Table 4-5 Indicator functions

Indicator	Definition	Function		
LED1	Status indicator	<p>On: The expansion card is establishing a connection with the control board.</p> <p>Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s).</p> <p>Off: The expansion card is disconnected from the control board.</p>		
LED2	Run indicator (Green)	Off	Not powered or in fault state	Not powered or in fault state
		Blinking periodically (on-off at a 0.5s interval)	Online. Waiting to receive BACnet data frames	Waiting to receive data
		On	BACnet communication state	Received BACnet data frames
LED3	Fault indicator (Red)	Off	No fault	No fault
		Blinking periodically (on-off at a 0.5s interval for twice and 2s off)	Faulty	Duplicate address. The VFD keypad reports E-BAC.
		Blinking periodically (on-off at a 0.5s interval for three times and 2s off)	Faulty	No BACnet data frames received in specified time. (Timeout detection must be enabled, that


Indicator	Definition	Function		
				is, the timeout time cannot be 0). The VFD keypad reports E-BAC.
LED4	Power indicator	It is on once the control board feeds power to the communication card.		
LED5	485TX indicator (Green)	Off	No transmission	The device does not transmit data on the RS485 network.
		Blinking	Transmitting	The device is transmitting data on the RS485 network.
		On	Transmitting	The device is transmitting data fast on the RS485 network.
LED6	485RX indicator (Green)	Off	No receiving	The device does not receive data on the RS485 network.
		Blinking	Receiving	The device is receiving data on the RS485 network.
		On	Receiving	The device is receiving data fast on the RS485 network.

## 4.5 Connecting the BACnet MSTP card to the PLC

### 4.5.1 Bus communication networking


#### 4.5.1.1 Communication packet structure

The communication data frame structure (PKW+PZD) of BACnet MSTP is similar to that of PROFINET. See the following figure.




### 4.5.1.2 Networking topology


The BACnet MSTP communication card adopts standard 4-pin terminal interface, which can be used in line network topology, star network topology and daisy chain topology, and its electrical wiring diagram is shown in the following. BACnet MSTP cards form a communication network with the PLC by inserting a BACnet MSTP communication card into each unit.



Due to the constraints, the connection method currently used is to add the BACnet MSTP protocol conversion gateway between the PLC and the communication card. See the following figure.




The BACnet MSTP networking commissioning flowchart is as follows.




#### 4.5.2 Configuring the BACnet MSTP protocol conversion gateway on the Sunfull PLC

1. Open X2BACnet, select the **New Driver** option in the menu bar of the host controller configuration interface, as shown below.




In the displayed window, select **BACnetMSTP1**. (For every COM port that is enabled to collect MSTP, an MSTP drive needs to be created. If two buses are used and there are COM1 and COM2, you can create BACnetMSTP1 and BACnetMSTP2 to correspond to COM1 and COM2. Create BACnetMSTP1, BACnetMSTP2, BACnetMSTP3 and BACnetMSTP4 in total to correspond to 4 COM ports, as shown in the following figure.




- After drives are added, choose to create channels. As serial communication, the default BACnet MSTP channel serial port is COM1, and the other default communication parameters are as follows: 38400bps baud rate, 8 data bits, 1 stop bit,


no parity bit, 50ms timeout time (the timeout time does not need to be modified in most cases), and master node MAC address of 127, which is not recommended to modify. See the following figure.




After the channel is created, choose **New Device**, set the device properties in the pop-up dialog box, including the device ID. You can query which devices are online on the bus through BACnetScan automatic scanning. The request frame interval (**Delay Between Polls**) is 50 milliseconds. See following figure.




3. Choose **Scan Tags** to scan the device for all tags. See the following figure.




X2BACnet connects to the BACnet MSTP card through RS485. Add all scanned records, and save the project. See the following figure.



4. The PC port connects to port 2 of the protocol gateway 192.168.1.88. COM2 connects to the RS485 port of the BACnet MSTP card. Set the PC port properties. See the following figure.  
Open the X2BACnet host controller and import the saved project.



1. Port 1
2. Port 2
3. AC/DC power 24V
4. Fully electrical isolated 4-channel RS485 port
5. LED communication indicators



Click  to upload the project to the gateway. Enter the user name and password in the pop-up dialog box. The user name is fixed to **admin**, and the password is fixed to **admin123456**. Then you can set the system parameters related to the gateway. See the following figure.



### 4.5.3.1 Configuring the PLC (750-830) IP address through the WAGO Ethernet Settings


1. Open the WAGO Ethernet Settings software, click on **Settings** in the upper right corner, and then choose **Communication**, as shown in the following figure.




2. Select **Serial Ports** from the **Connection** drop-down list box, select the corresponding port number from the **Port** drop-down list box, and select the corresponding serial port number (which can be viewed in by choosing **Device Manager > Ports** on your PC), as shown in the following figure.



3. Click **Identify**, and wait for a while. If the PC and PLC are connected properly, the area in the red box as shown in the following figure will appear, showing information such as the PLC hardware and software versions, MAC address, and IP address. If the content in the red box area indicates that the connection has failed, check whether the connection between the PC and PLC is normal, as shown in the following figure.



4. Click **TCP/IP** and set the PLC IP address in red box ②, and ensure the PC IP address and the PLC IP address are in the same network segment. Then click **Write** to write the set IP address to the PLC. See the following figure.




5. After the writing is successful, open CoDeSys V2.3.


A. Use CoDeSys V2.3 to configure the PLC.

CoDeSys V2.3 has the same functions with WAGO-IO-PRO V2.3.


a) Open the CoDeSys software, click **File-New** to create a new document. The following window is displayed. Select the PLC model **WAGO\_750-830** from the drop-down list box, and click **OK**. See the following figure.




b) Click the **General** tab, choose **Load boot project automatically**, and click **OK**. See the following figure.





c) Create a POU program. Since the PLC must contain a PLC\_PRG program, and keep the default settings and click **OK**. See the following figure.



- d) Configure the PLC hardware. Select **PLC Configuration** from the **Resource** drop-down list box. At the right, choose **Hardware configuration**, right-click **K-Bus**, and choose **Edit**. See the following figure.



- e) Click the **Input/Output** tab in the **Configuration** dialog box. Click the  icon in the toolbar to scan the devices on the PLC hardware bus. When the scan is completed, the devices in red box ③ will appear. Click on any device. The corresponding device address, data type and function description will appear in the right window. Select **PLC**, **PLC from PI Assignment** in the **PI allocation** tab, indicating the PLC controlled IO devices. If other types are selected, the IO devices are communication controlled. See the following figure.




If no device is scanned, check the following:


- Whether the PLC is properly powered.
- Whether the PLC and PC are connected properly and are in the same network segment.

f) Configure tasks.


Create a task.



Set the circular interval to 30ms and append a program. See the following figure.



Select and add the program PLC\_PRG. See the following figure.




- g) Import the BACnet library file.

Copy all files from **00\_Libraries\_BA** to the **Building** folder in the CoDeSys installation directory, for example, **C:\Program Files\WAGO Software\CoDeSys V2.3\Targets\WAGO\Libraries\Building**.

After the copy is complete, choose **Library Manager** in the **Resource** tab in the CoDeSys main interface. Right-click on the blank area marked as (3), and choose **Additional Library**, choose **Building > BACnet\_01\_easy.lib**, and click **Open**. See


the following figure.



## B. Create PLC programs.

This section describes how to write a simple application program, using the ST structured language for programming. The program achieves the following functions: If the VFD frequency is set to 5Hz, when the IO.0 terminal input of the digital input module 750–400 is high, the VFD runs forward; when the terminal input is low, the VFD decelerates to stop. (The VFD frequency is given by BACnet communication, the control mode is communication, and VFD received PZD2 is the set frequency.)

Variable declaration is in red box ①, and the main program is in red box ②. The format of data variable declaration is in the format of *Variable name: Data type of variable*.



Description of the content in red box ①:

**CONTROL\_WORD** is VFD control word; **PZD\_SEND2** is the given PZD of VFD, **DI\_1** is the channel 0 of digital input module, and **%IX0.0** is the address of channel 0 of digital output module.

**BACNET\_ANALOG\_VALUE** is a data type of BACnet communication, which is defined in the library file **BACnet\_01\_easy.lib**.

```
PROGRAM PLC_PRG
```

```
VAR
```


```
CONTROL_WORD                                :BACNET_ANALOG_VALUE;
PZD_SEND2                                    :BACNET_ANALOG_VALUE;
DI_1 AT%IX0.0                                :BOOL;
```

```
END_VAR
```

Description of the content in red box ②:

**PZD\_SEND2**: Several properties of this object can follow at the right of the decimal point.

**Present\_Value** indicates the current value.



The syntax "=" is the assignment symbol.

```
PZD_SEND2.Present_Value := 500;
IF DI_1 = 1 THEN
CONTROL_WORD.Present_Value := 1;
ELSIF DI_1 = 0 THEN
CONTROL_WORD.Present_Value := 8;
```


END\_IF


After the program is completed, press F11 to compile the project and proceed to the next step if there are no errors.

**Note:** After the program is completed, the PLC does not control the VFD directly, and you need to map the defined variables to the VFD variable table through **WAGO BACnet configurator**. Next, you need to generate the **SYM\_XML variable** table and import it into the **WAGO BACnet configurator**.

C. Configure the symbol file.

In the main interface, choose **Project > Options** from the menu bar. In the pop-up **Options** dialog box, select **Dump XML Symbol table**, and click **Configure symbol file**. In the pop-up **Set object attributes** dialog box, select all, as shown in red box ④, and select the two items shown in red box ⑤. See the following figures.





After the setup, when the POU program is completed and the PLC is in login state, the file **xxx.sys\_xml** (xxx is the project name) will be generated automatically and saved in the created project folder.


The **SYS\_XML** file contains all variables in the project and can be imported directly into the **WAGO BACnet configurator** to configure the properties of each variable or object. This file is essential for the subsequent use of the PLC.

#### Note:


- If the system prompts that there is no relevant file locally during the generation process, you need to check whether the project built in CoDySys has been saved.
- If there are no variables declared in the POU program in the generated variable table, you need to check whether you have followed the steps in e) strictly.
- The XML file is generated only during the first PLC login. If the POU program has not changed, the XML file will not be regenerated subsequently, even if you log in again.

D. Download the program to the PLC to generate the **SYM\_XML** file.


a) Choose **Online > Communication Parameters**. See the following figure.




- b) In the **Communication Parameters** window, click the **NEW** button. Select **Tcp/Ip (3S Tcp/Ip driver)** in the new pop-up window, and then click **OK**. See the following figure.



- c) Select the newly created channel in the **Communication Parameters** window, and then fill in the PLC IP address in the **Value** column next to **Address**, and click **OK**. See the following figure.




- d) Choose **Online > Login** on the menu bar. The software will compile the project and generate the **SYM\_XML** file, which is located in the root directory of the project. After that, choose **Create boot project** to import the program file into the PLC, so that the PLC can run independently even if the PLC is disconnected from the PC. See the following figure.



- E. Configure the PLC through the WAGO BACnet configurator.
- Set the IP addresses of the PLC, PC, VFD and other slave stations, which are required to be in the same network segment, and connect each node through the network cable.
  - Open the WAGO BACnet configurator and it will automatically scan the devices on the bus. Alternatively, scan manually by right-clicking on **Device Pools-Scan**


and choosing **Scan**. See the following figure.




In the preceding figure, **Controller [2721366]** is the VFD node in the bus and **Device\_0 [549311]** is the PLC node. The numeric part in [] is the decimal number converted from this node MAC address.

- c) Import the **SYM\_XML** file.

Right click on **Device\_0** (PLC device), and choose **Configure**. See the following figure.



Import the previously generated **SYM\_XML** file. After successful import, the objects (CONTROL\_WORD, PZD\_SEND2) declared in the previous project will appear in area ③. See the following figure.

**Note:**


- After the import is completed, check the I/O indicator of the PLC. If the import is correct, the indicator is steady on in green. If it is blinking in red periodically, you need to follow the instructions to perform troubleshooting.
- You can check the PLC status through the **Status** window of WAGO Ethernet Settings.
- For details about PLC panel indicators, see WAGO 750-830 description document.

## d) Map PLC variables to VFD variables.


Since the WAGO 750-830 PLC can only be used as a slave, not as a master, when used in a BACnet network. In actual use, it is necessary to map the relevant variables of the VFD or other devices to the PLC so that the VFD can be controlled by only operating the mapped address in the PLC through the PLC program.

The following example associates the **CONTROL\_WORD** control word in the PLC program with the **CONTROL\_WORD** in the VFD to control VFD startup, stop, and reset. The associated operations of other variables are similar.


- Select all devices that are scanned through the Scan menu. Right-click **Add to Database**. Choose **Device Pools > Database** to view the added devices. See the following figure.




- b) Access the **Configuration** interface of Device\_0 (PLC device). Chose **Values** > **AV0: PLC\_PRG.CONRTOL\_WORD**. In the right area, choose **Present Value** > **Client Mappings**. See the following figure.



- c) In the **Client Mapping Editor** window, select the VFD variable to be mapped with the PLC variable **AV0: PLC\_PRG.CONRTOL\_WORD**. Select **Controller – AV0: CONTROL\_WORD-Present Value**, and click **Add Write**. See the following figure.




- d) You can view the added variable in the **Client Mappings** column in the property window of the PLC variable **AV0: PLC\_PRG.CONRTOL\_WORD**. Map other variables with the same method. After mapping all variables, click **Store and Download** to download the property to the PLC. See the following figure.



- F. Run the program.

Disconnect the PLC from the PC. Slide the PLC run switch to the top. The mode selection switch is in the red rectangular in the following figure. When the switch is


slid to the top, it is in the running state. See the following figure.



#### 4.5.4 Controlling the VFD through WAGO BACnet configurator

If you only need to read and write VFD parameters and achieve basic control VFD functions, you can control the VFD directly through the WAGO BACnet configurator, without writing a PLC program.

1. Set the PZD related function codes of the VFD, and set the VFD control mode to communicate.
2. In the scanned devices, select the device (VFD) that needs to be controlled, and take **Controller [2721366]** as an example. Select the PZD functions or control words to be operated, taking **PZD\_SEND2** as an example. Enter the required value in the **Present Value** field. Then click **Commit**.



Set other parameters in the same way.

## Chapter 5 CAN master/slave expansion card

### 5.1 CAN master/slave expansion card operation

#### 5.1.1 Electrical connection

Use shielding wires as the bus cable, if possible. It is recommended that you connect the shielding wire to the PE terminal of the communication card. When there are only two devices for CAN master-slave communication, both devices shall be connected to the terminal resistor. When there are more than two devices, the starting device and terminal device shall be connected to the terminal resistor. The terminal resistor of the communication card can be connected through its terminal resistor switch. Figure 5-1 shows the electrical wiring.




Figure 5-1 Electrical wiring diagram

#### 5.1.2 Electrical wiring

Connection operation	Description
1. Determine the master count and slave count, and prepare the shielded twisted pairs.	Pay attention to the cable specifications.
2. Connect the cable according to Figure 5-1, and install the terminal resistor at the head and tail properly.	Pay attention to the terminal resistors.
3. Check the card hardware version according to the order finished-product card model.	Pay attention to the board silk model number.
4. Power on in a unified way. Check card type related function codes P19.00/P19.01/P19.02, card version related function codes P19.03/P19.04/P19.05, and control board software version function code P07.13 for consistency.	Check whether the latest version is used.
5. Use the following function code setting examples for reference.	Pay attention to the actual configuration.
6. Power on in a unified way, and check whether the running is normal.	If both the salve and slave work properly, the networking is successful.

Connection operation	Description
7. Set torque and frequency related function codes according to the actual application.	Pay attention to the actual application.

### 5.1.3 Function code setting

Master setting example		
Function code viewing and setting	Value	Description
P19.00/P19.01/19.02	15	CAN master/slave communication card type is successfully identified according to the card slot.
P19.03/P19.04/19.05	*.**	CAN master/slave communication card is successfully identified according to the card type and version number.
<b>P28.00</b>	<b>1</b>	<b>The local device is a master.</b>
<b>P28.06</b>	<b>N</b>	<b>Slave count</b>
P15.28	/	The communication address is invalid when it is a master.
P15.29	2	The communication baud rate is 125kbps.
P15.30	5.0s	The CAN communication timeout time is 5s.

Example of slave 1		
Function code viewing and setting	Value	Description
P19.00/P19.01/19.02	15	CAN master/slave communication card type is successfully identified according to the card slot.
P19.03/P19.04/19.05	*.**	CAN master/slave communication card is successfully identified according to the card type and version number.
<b>P28.00</b>	<b>2</b>	<b>The local device is a slave.</b>
P28.06	/	The count is invalid when it is a slave.
<b>P15.28</b>	<b>1</b>	<b>The slave CAN communication address starts from 1.</b>

Example of slave 1		
Function code viewing and setting	Value	Description
P15.29	2	The communication baud rate is 125kbps.
P15.30	5.0s	The CAN communication timeout time is 5s.

Example of slave N		
Function code viewing and setting	Value	Description
P19.00/P19.01/19.02	15	CAN master/slave communication card type is successfully identified according to the card slot.
P19.03/P19.04/19.05	* **	CAN master/slave communication card is successfully identified according to the card type and version number.
<b>P28.00</b>	<b>2</b>	<b>The local device is a slave.</b>
P28.06	/	The count is invalid when it is a slave.
<b>P15.28</b>	<b>N</b>	<b>The slave CAN communication address ends at N.</b>
P15.29	2	The communication baud rate is 125kbps.
P15.30	5.0s	The CAN communication timeout time is 5s.

#### 5.1.4 Fault handling

Fault	Description
Neither the master nor the slave has a fault.	The master/slave networking is successful.
The slave reports fault code 58: CAN communication fault (ESCAN)	The cause is that the slave timeout time is reached. Check the slave electrical wiring and function code settings. Check whether the fault is removed after reset.
The master reports fault code 69: CAN slave fault in master/slave synchronization (S-Err).	The cause is that a slave encounters a fault. Check the slave electrical wiring and function code settings. Check whether the fault is removed after reset.

Fault	Description
The slave reports fault code 58: CAN communication fault (ESCAN).	The cause is that the master timeout time is reached. Check the master electrical wiring and function code settings. Check whether the fault is removed after reset.

## 5.2 Related function parameters

Function code	Name	Parameter description	Default	Modify
P15.28	CAN communication address	0–127	1	⊙
P15.29	CAN communication baud rate	0–5 0: 50kbps 1: 100kbps 2: 125kbps 3: 250kbps 4: 500kbps 5: 1Mbps	2	⊙
P15.30	CAN communication timeout period	0.0–60.0s <b>Note:</b> It is invalid when the value is 0.0.	5.0s	○
P19.00	Type of expansion card at slot 1	0–65535 0: No card	0	●
P19.01	Type of expansion card at slot 2	1: PLC card 2: I/O card	0	●
P19.02	Type of expansion card at slot 3	3: Incremental PG card 4: Incremental PG card with UVW 5: Ethernet 6: DP 7: Bluetooth card 8: Resolver PG card 9: CANopen Communication card 10: WIFI card 11: PROFINET communication card 12: Sine-cosine PG card without CD signals 13: Sine-cosine PG card with CD signals 14: Absolute encoder PG card	0	●

Function code	Name	Parameter description	Default	Modify
		(reserved) 15: CAN master/slave communication card 16: Modbus TCP communication card 17: EtherCAT communication card (reserved) 18: BACnet communication card (reserved) 19: DeviceNET communication card (reserved) 20: PT100/PT1000 temperature detection card 21: EtherNet IP card 22: MECHATROLINK card (reserved) 23–65535: Reserved		
P28.00	Master/slave mode	0–2 0: Master/slave control is invalid. 1: The local device is a master. 2: The local device is a slave.	0	⊙
P28.01	Master/slave communication data selection	0–1 0: CAN 1: Reserved	0	⊙
P28.02	Master/slave control mode	0x000–0x112 Ones place: Master/slave running mode selection 0: Master/slave mode 0 1: Master/slave mode 1 2: Master/slave mode 2 Tens place: Slave start command source 0: Master 1: Determined by P00.01 Hundreds place: Whether to enable master/slave to send/receive data 0: Enable 1: Disable	0x001	⊙

Function code	Name	Parameter description	Default	Modify
P28.03	Slave speed gain	0.0–500.0%	100.0%	<input type="radio"/>
P28.04	Slave torque gain	0.0–500.0%	100.0%	<input type="radio"/>
P28.05	Speed/torque mode switching frequency point in master/slave mode 2	0.00–10.00Hz	5.00Hz	<input type="radio"/>
P28.06	Slave count	1–15	1	<input checked="" type="radio"/>
P28.07	Hidden	0–0	0	<input checked="" type="radio"/>
P28.08	Hidden	0–0	0	<input checked="" type="radio"/>
P28.09	CAN slave torque offset	-100.0–100.0%	0.0%	<input type="radio"/>

## Appendix A CANopen object dictionary

Index (hexadecimal)	Subindex	Description	Access permission	Data type	Default value
1000	0	Device type	RO	Unsigned32	0x0000 0000
1001	0	Error register	RO	Unsigned8	/
1003	<b>Error code register</b>				
	0	Number of subindexes	RW	/	/
	1	Error code	RO	Unsigned32	/
1005	0	COB-ID SYNC	RW	Unsigned32	/
1006	0	Communication cycle period	RW	Unsigned32	/
1007	0	Length of synchronous window	RW	Unsigned32	/
1008	0	Manufacturer-defined device name	CONST	String	INVT CANopen
1009	0	Manufacturer-defined hardware version	CONST	String	V1.00
100A	0	Manufacturer-defined software version	CONST	String	V1.00
100C	0	Protection time	RW	Unsigned16	0
100D	0	Life cycle factor	RW	Unsigned16	0
1016	<b>Consumer heartbeat time</b>				
	0	Number of subindexes	RO	Unsigned8	/
	1	Consumer heartbeat time	RW	Unsigned32	/
1017	0	Producer heartbeat time	RW	Unsigned16	0
1018	<b>Identifier objects</b>				
	0	Number of subindexes	RO	Unsigned8	4
	1	Supplier ID	RO	Unsigned32	0x0000 0000
	2	Product code	RO	Unsigned32	0x0000 0000

Index (hexadecimal)	Subindex	Description	Access permission	Data type	Default value
	3	Revision No.	RO	Unsigned32	0x0000 0000
	4	Sequence No.	RO	Unsigned32	0x0000 0000
1200	<b>Servo SDO</b>				
	0	Number of subindexes	RO	Unsigned8	/
	1	COB-ID Client -> server (Rx)	RO	Unsigned32	600H+Node ID
	2	COB-ID Server -> client (Tx)	RO	Unsigned32	580H+Node ID
1280	<b>SDO</b>				
	0	Number of subindexes	RO	Unsigned8	/
	1	COB-ID Client -> server (Rx)	RO	Unsigned32	/
	2	COB-ID Server -> client (Tx)	RO	Unsigned32	/
	3	Node ID of server SDO	RO	Unsigned8	/
1400	<b>PDO1 Rx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	/
	3	/	/	Unsigned16	/
	4	/	/	Unsigned8	/
	5	Event timer	RW	Unsigned16	/
1401	<b>PDO2 Rx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	/
	3	/	/	Unsigned16	/
	4	/	/	Unsigned8	/

Index (hexadecimal)	Subindex	Description	Access permission	Data type	Default value
	5	Event timer	RW	Unsigned16	/
1402	<b>PDO3 Rx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	/
	3	/	/	Unsigned16	/
	4	/	/	Unsigned8	/
	5	Event timer	RW	Unsigned16	/
1403	<b>PDO4 Rx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	/
	3	/	/	Unsigned16	/
	4	/	/	Unsigned8	/
	5	Event timer	RW	Unsigned16	/
1600	<b>PDO1 Rx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	3
	1	First mapped object	RW	Unsigned32	0x21000010
	2	Second mapped object	RW	Unsigned32	0x21000110
	3	Third mapped object	RW	Unsigned32	0x21000210
1601	<b>PDO2 Rx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	4

Index (hexadecimal)	Subindex	Description	Access permission	Data type	Default value
	1	First mapped object	RW	Unsigned32	0x21010010
	2	Second mapped object	RW	Unsigned32	0x21000310
	3	Third mapped object	RW	Unsigned32	0x21000410
	4	Fourth mapped object	RW	Unsigned32	0x21000510
1602	<b>PDO3 Rx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	4
	1	First mapped object	RW	Unsigned32	0x21000610
	2	Second mapped object	RW	Unsigned32	0x21000710
	3	Third mapped object	RW	Unsigned32	0x21000810
	4	Fourth mapped object	RW	Unsigned32	0x21000910
1603	<b>PDO4 Rx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	4
	1	First mapped object	RW	Unsigned32	0x21000a10
	2	Second mapped object	RW	Unsigned32	0x21000b10
	3	Third mapped object	RW	Unsigned32	0x21000c10
	4	Fourth mapped object	RW	Unsigned32	0x21000d10
1800	<b>PDO1 Tx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/

Index (hexadecimal)	Subindex	Description	Access permission	Data type	Default value
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	255
	3	Disabled time	RW	Unsigned16	500
	4	Reserved	RW	Unsigned8	/
	5	Event timer	RW	Unsigned16	0
1801	<b>PDO2 Tx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	254
	3	Disabled time	RW	Unsigned16	500
	4	Reserved	RW	Unsigned8	/
	5	Event timer	RW	Unsigned16	0
1802	<b>PDO3 Tx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	254
	3	Disabled time	RW	Unsigned16	500
	5	Event timer	RW	Unsigned16	0
1803	<b>PDO4 Tx communication parameters</b>				
	0	Supported Max. number of subindexes	RO	Unsigned8	/
	1	COB-ID used by PDO	RW	Unsigned32	/
	2	Transmission type	RW	Unsigned8	254
	3	Disabled time	RW	Unsigned16	500
	5	Event timer	RW	Unsigned16	0

Index (hexadecimal)	Subindex	Description	Access permission	Data type	Default value
1A00	<b>PDO1 Tx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	3
	1	First mapped object	RW	Unsigned32	0x20000010
	2	Second mapped object	RW	Unsigned32	0x20000110
	3	Third mapped object	RW	Unsigned32	0x20000210
1A01	<b>PDO2 Tx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	4
	1	First mapped object	RW	Unsigned32	0x20010010
	2	Second mapped object	RW	Unsigned32	0x20000310
	3	Third mapped object	RW	Unsigned32	0x20000410
	4	Fourth mapped object	RW	Unsigned32	0x20000510
1A02	<b>PDO3 Tx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	4
	1	First mapped object	RW	Unsigned32	0x20000610
	2	Second mapped object	RW	Unsigned32	0x20000710
	3	Third mapped object	RW	Unsigned32	0x20000810
	4	Fourth mapped object	RW	Unsigned32	0x20000910

Index (hexadecimal)	Subindex	Description	Access permission	Data type	Default value
1A03	<b>PDO4 Tx mapping parameters</b>				
	0	Number of application program objects mapped in PDO	RW	Unsigned8	4
	1	First mapped object	RW	Unsigned32	0x20000a10
	2	Second mapped object	RW	Unsigned32	0x20000b10
	3	Third mapped object	RW	Unsigned32	0x20000c10
	4	Fourth mapped object	RW	Unsigned32	0x20000d10

## Appendix B Related function codes

Function code	Name	Parameter description	Setting range	Default value
P00.01	Channel of running commands	0: Keypad 1: Terminal 2: Communication	0–2	0
P00.02	Communication mode of running commands	0: Modbus/Modbus TCP communication 1: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 2: Ethernet communication 3: EtherCAT/PROFINET/EtherNet IP communication 4: Programmable card 5: Wireless communication card 6: USB communication (reserved) <b>Note:</b> The values 1–5 correspond to extended functions that are available only with respective cards.	0–6	0
P00.06	A frequency command selection	0: Set via keypad 1: Set via AI1 2: Set via AI2 3: Set via AI3 4: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via Modbus/Modbus TCP communication 9: Set via PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 10: Set via Ethernet communication 11: Set via high speed pulse HDIB 12: Set via pulse train AB 13: Set via EtherCAT/PROFINET communication 14: Set via programmable card 15: Reserved	0–15	0
P00.07	B frequency command selection		0–15	15

Function code	Name	Parameter description	Setting range	Default value
P00.11	ACC time 1	0.0–3600.0s	0.0–3600.0s	Model depended
P03.11	Torque setting mode selection	0–1: Keypad (P03.12) 2: AI1 3: AI2 4: AI3 5: Pulse frequency HDIA 6: Multi-step torque 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 9: Ethernet communication 10: Pulse frequency HDIB 11: EtherCAT/PROFINET/EtherNet IP 12: Programmable card <b>Note:</b> For these settings, 100% corresponds to the motor rated current.	0–12	0
P03.14	Setting source of FWD rotation frequency upper limit in torque control	0: Keypad (P03.16) 1: AI1 2: AI2 3: AI3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 8: Ethernet communication 9: Pulse frequency HDIB 10: EtherCAT/PROFINET/EtherNet IP communication 11: Programmable card 12: Reserved <b>Note:</b> For these settings, 100% corresponds to the max. frequency.	0–12	0

Function code	Name	Parameter description	Setting range	Default value
P03.15	Setting source of REV rotation frequency upper limit in torque control	0: Keypad (P03.17) 1: AI1 2: AI2 3: AI3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 8: Ethernet communication 9: Pulse frequency HDIB 10: EtherCAT/PROFINET/EtherNet IP communication 11: Programmable card 12: Reserved <b>Note:</b> For these settings, 100% corresponds to the max. frequency.	0–12	0
P03.18	Setting source of electromotive torque upper limit	0: Keypad (P03.20) 1: AI1 2: AI2 3: AI3 4: Pulse frequency HDIA 5: Modbus/Modbus TCP communication 6: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 7: Ethernet communication 8: Pulse frequency HDIB 9: EtherCAT/PROFINET/EtherNet IP communication 10: Programmable card 11: Reserved <b>Note:</b> For these settings, 100% corresponds to the motor rated current.	0–11	0

Function code	Name	Parameter description	Setting range	Default value
P03.19	Setting source of braking torque upper limit	0: Keypad (P03.21) 1: AI1 2: AI2 3: AI3 4: Pulse frequency HDIA 5: Modbus/Modbus TCP communication 6: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 7: Ethernet communication 8: Pulse frequency HDIB 9: EtherCAT/PROFINET/EtherNet IP communication 10: Programmable card 11: Reserved <b>Note:</b> For these settings, 100% corresponds to the motor rated current.	0–11	0
P04.27	Voltage setting channel	0: Keypad; output voltage is determined by P04.28 1: AI1 2: AI2 3: AI3 4: HDIA 5: Multi-step (the set value is determined by P10 group) 6: PID 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 9: Ethernet communication 10: HDIB 11: EtherCAT/PROFINET/EtherNet IP 12: Programmable card 13: Reserved	0–13	0
P06.01	Y1 output	0: Invalid	0–63	0

Function code	Name	Parameter description	Setting range	Default value
P06.02	HDO output	1: In running	0-63	0
P06.03	Relay output RO1	2: In forward running 3: In reverse running	0-63	1
P06.04	Relay output RO2	4: In jogging 5: VFD fault 6: Frequency level detection FDT1 7: Frequency level detection FDT2 8: Frequency reached 9: Running in zero speed 10: Reach upper limit frequency 11: Reach lower limit frequency 12: Ready to run 13: In pre-exciting 14: Overload pre-alarm 15: Underload pre-alarm 16: Simple PLC stage completed 17: Simple PLC cycle completed 18: Reach set counting value 19: Reach designated counting value 20: External fault is valid 21: Reserved 22: Reach running time 23: Virtual terminal output of Modbus communication 24: Virtual terminal output of POROFIBUS/CANopen/DeviceNet/BA Cnet MSTP communication 25: Virtual terminal output of Ethernet communication 26: DC bus voltage established 27: z pulse output 28: During pulse superposition 29: STO act 30: Positioning completed 31: Spindle zeroing completed 32: Spindle scale-division completed 33: In speed limit 34: EtherCAT/PROFINET/EtherNet IP	0-63	5

Function code	Name	Parameter description	Setting range	Default value
		35: Reserved 36: Speed/position control switchover completed 37: Any frequency reached 38–40: Reserved 41: Y1 from the programmable card 42: Y2 from the programmable card 43: HDO from the programmable card 44: RO1 from the programmable card 45: RO2 from the programmable card 46: RO3 from the programmable card 47: RO4 from the programmable card 48: EC PT100 detected OH pre-alarm 49: EC PT1000 detected OH pre-alarm 50: AI/AO detected OH pre-alarm 51: Stopped or running at zero speed 52: Disconnection detected in tension control 53: Roll diameter setting reached 54: Max. roll diameter reached 55: Min. roll diameter reached 56: Fire control mode enabled 57–63: Reserved		
P06.14	Analog output AO1	0: Running frequency (0–Max. output frequency)	0–63	0
P06.16	HDO high-speed pulse output	1: Set frequency (0–Max. output frequency) 2: Ramp reference frequency (0–Max. output frequency) 3: Rotational speed (100% corresponds to the speed at max. output frequency.) 4: Output current (100% corresponds to twice the VFD rated current.) 5: Output current (100% corresponds to twice the motor rated current.) 6: Output voltage (100% corresponds to 1.5 times the VFD rated voltage.) 7: Output power (100% corresponds to	0–63	0

Function code	Name	Parameter description	Setting range	Default value
		<p>twice the motor rated power.)</p> <p>8: Set torque (100% corresponds to twice the motor rated current.)</p> <p>9: Output torque (Absolute value; 100% corresponds to twice the motor rated torque.)</p> <p>10: AI1 input (0–10V/0–20mA)</p> <p>11: AI2 input (0–10V)</p> <p>12: AI3 input (0–10V/0–20mA)</p> <p>13: HDIA input (0.00–50.00kHz)</p> <p>14: Value 1 set through Modbus (0–1000)</p> <p>15: Value 2 set through Modbus (0–1000)</p> <p>16: Value 1 set through PROFIBUS/CANopen/DeviceNet/BACnet MSTP (0–1000)</p> <p>17: Value 2 set through PROFIBUS/CANopen/DeviceNet/BACnet MSTP (0–1000)</p> <p>18: Value 1 set through Ethernet 1 (0–1000)</p> <p>19: Value 2 set through Ethernet 2 (0–1000)</p> <p>20: HDIB input (0.00–50.00kHz)</p> <p>21: Value 1 set through EtherCAT/PROFINET/EtherNet IP (0–1000)</p> <p>22: Torque current (bipolar; 100% corresponds to triple the motor rated current.)</p> <p>23: Exciting current (bipolar; 100% corresponds to triple the motor rated current.)</p> <p>24: Set frequency (bipolar; 0–Max. output frequency)</p> <p>25: Ramp reference frequency (bipolar; 0–Max. output frequency)</p>		

Function code	Name	Parameter description	Setting range	Default value
		26: Rotational speed (bipolar; 0–Speed corresponding to max. output frequency) 27: Value 2 set through EtherCAT/PROFINET/EtherNet IP communication (0–1000) 28: AO1 from the programmable card (0–1000) 29: AO2 from the programmable card (0–1000) 30: Rotational speed (100% corresponds to twice the motor rated synchronous speed) 31: Output torque (Actual value, 100% corresponds to twice the motor rated torque) 32: AI/AO temperature detection output 33–63: Reserved <b>Note:</b> When the output comes from the programmable card (28–29), if the card is a Codesys programmable card, P27.00 must be set to 1. When AO1 is of the current output type, 100% corresponds to 20mA; when AO1 is of the voltage output type, 100% corresponds to 10V; 100% of HDO corresponds to the output of P06.30.		
P07.27	Type of current fault	0: No fault	0–79	0
P07.28	Type of last fault	1: Inverter unit U phase protection (OUt1)		
P07.29	Type of 2nd-last fault	2: Inverter unit V phase protection (OUt2)		
P07.30	Type of 3rd-last fault	3: Inverter unit W phase protection (OUt3)		
P07.31	Type of 4th-last fault	4: Overcurrent during acceleration (OC1)		

Function code	Name	Parameter description	Setting range	Default value
P07.32	Type of 5th-last fault		0-79	0
P08.31	Motor 1 and motor 2 switching channel	LED ones place: Switching channel 0: Terminal 1: Modbus/Modbus TCP communication 2: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 3: Ethernet communication 4: EtherCAT/PROFINET/EtherNet IP communication LED tens place: Switching in running 0: Disabled 1: Enabled	0x00-0x14	0x00
P09.00	PID reference source	0: Set by P09.01 1: AI1 2: AI2 3: AI3 4: High-speed pulse HDIA 5: Multi-step 6: Modbus communication 7: PROFIBUS/CANopen/DeviceNet/BACnet MSTP communication 8: Ethernet communication 9: High-speed pulse HDIB 10: EtherCAT/PROFINET communication 11: Programmable card 12: Reserved	0-12	0
P09.02	PID feedback source	0: AI1 1: AI2 2: AI3 3: High-speed pulse HDIA 4: Modbus communication 5: PROFIBUS/CANopen/DeviceNet/BACn	0-10	0

Function code	Name	Parameter description	Setting range	Default value
		et MSTP communication 6: Ethernet communication 7: High-speed pulse HDIB 8: EtherCAT/PROFINET communication 9: Programmable expansion card 10: Reserved		
P15.01	Module address	0–127	0–127	2
P15.02	Received PZD2	0–31	0–31	0
P15.03	Received PZD3	0: Invalid	0–31	0
P15.04	Received PZD4	1: Set frequency (0–Fmax, unit: 0.01 Hz)	0–31	0
P15.05	Received PZD5	2: PID reference (-1000–1000, in which 1000 corresponds to 100.0%)	0–31	0
P15.06	Received PZD6	3: PID feedback (-1000–1000, in which 1000 corresponds to 100.0%)	0–31	0
P15.07	Received PZD7	4: Torque setting (-3000–+3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0–31	0
P15.08	Received PZD8	5: Setting of the upper limit of forward running frequency (0–Fmax, unit: 0.01 Hz)	0–31	0
P15.09	Received PZD9	6: Setting of the upper limit of reverse running frequency (0–Fmax, unit: 0.01 Hz)	0–31	0
P15.10	Received PZD10	7: Upper limit of the electromotive torque (0–3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0–31	0
P15.11	Received PZD11	8: Upper limit of the brake torque (0–3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0–31	0
P15.12	Received PZD12	9: Virtual input terminal command, 0x000–0x3FF (corresponding to S8, S7, S6, S5, HDIB, HDIA, S4, S3, S2, and S1 in sequence)	0–31	0

Function code	Name	Parameter description	Setting range	Default value
		10: Virtual output terminal command, 0x00–0x0F (corresponding to RO2, RO1, HDO, and Y1 in sequence) 11: Voltage setting (for V/F separation) (0–1000, in which 1000 corresponds to 100.0% of the rated voltage of the motor) 12: AO1 output setting 1 (-1000→1000, in which 1000 corresponds to 100.0%) 13: AO2 output setting 2 (-1000→1000, in which 1000 corresponds to 100.0%) 14: MSB of position reference (signed number) 15: LSB of position reference (unsigned number) 16: MSB of position feedback (signed number) 17: LSB of position feedback (unsigned number) 18: Position feedback setting flag (position feedback can be set only after this flag is set to 1 and then to 0) 19: Function code mapping (PZD2–PZD12 correspond to P14.49–P14.59 respectively.) 20–31: Reserved		
P15.13	Transmitted PZD2	0–47 0: Invalid	0–47	0
P15.14	Transmitted PZD3	1: Running frequency (×100, Hz) 2: Set frequency (×100, Hz)	0–47	0
P15.15	Transmitted PZD4	3: Bus voltage (×10, V) 4: Output voltage (×1, V)	0–47	0
P15.16	Transmitted PZD5	5: Output current (×10, A) 6: Actual output torque (×10, %)	0–47	0
P15.17	Transmitted PZD6	7: Actual output power (×10, %) 8: Rotating speed of the running (×1,	0–47	0

Function code	Name	Parameter description	Setting range	Default value
P15.18	Transmitted PZD7		0–47	0
P15.19	Transmitted PZD8		0–47	0
P15.20	Transmitted PZD9		0–47	0
P15.21	Transmitted PZD10		0–47	0
P15.22	Transmitted PZD11		0–47	0
P15.23	Transmitted PZD12		0–31	0
P15.25	DP communication timeout time	0.0 (invalid)–60.0s	0.0–60.0	5.0s
P15.26	CANopen communication timeout time	0.0 (invalid)–60.0s	0.0–60.0	5.0s
P15.27	CANopen communication baud rate	0: 1Mbps 1: 800k bps 2: 500k bps 3: 250k bps 4: 125k bps 5: 100k bps 6: 50k bps 7: 20k bps	0–7	3
P15.28	CAN communication address	0–127	0–127	1
P15.29	CAN baud rate setting	0: 50k bps 1: 100k bps 2: 125k bps 3: 250k bps 4: 500k bps 5: 1M bps	0–5	2

Function code	Name	Parameter description	Setting range	Default value
P15.30	CAN communication timeout time	0.0 (invalid)–60.0s	0.0–60.0	5.0s
P15.31	DeviceNet communication timeout time	0.0 (invalid)–60.0s	0.0–60.0	5.0s
P15.41	BACnet communication mode selection	0: P15.46 is valid. 1: P15.42 is valid.	0–1	0
P15.42	BACnet_MSTP baud rate	0–5 0: 9600bps 1: 19200bps 2: 38400bps 3: 57600bps 4: 76800bps 5: 115200bps	0–5	0
P15.43	Communication control word expression format	0: Decimal format 1: Binary format	0–1	0
P15.44	Communication control word/status word display selection	0: Display currently identified card (only one) 1: DP card 2: CANopen card 3: PROFINET card 4: Ethernet IP card 5: Modbus TCP card 6: EtherCAT card	0–6	0
P15.45– P15.69	Reserved			
P16.01	Reserved			
P16.02	Ethernet monitoring card IP address 1	0–255	0–255	192
P16.03	Ethernet monitoring card IP address 2	0–255	0–255	168

Function code	Name	Parameter description	Setting range	Default value
P16.04	Ethernet monitoring card IP address 3	0-255	0-255	0
P16.05	Ethernet monitoring card IP address 4	0-255	0-255	1
P16.06	Ethernet monitoring card subnet mask 1	0-255	0-255	255
P16.07	Ethernet monitoring card subnet mask 2	0-255	0-255	255
P16.08	Ethernet monitoring card subnet mask 3	0-255	0-255	255
P16.09	Ethernet monitoring card subnet mask 4	0-255	0-255	0
P16.10	Ethernet monitoring card subnet gateway 1	0-255	0-255	192
P16.11	Ethernet monitoring card subnet gateway 2	0-255	0-255	168
P16.12	G Ethernet monitoring card subnet gateway 3	0-255	0-255	1
P16.13	Ethernet monitoring card subnet gateway 4	0-255	0-255	1
P16.14	Ethernet card monitoring variable address 1	0x0000-0xFFFF	0000-FFFF	0x0000

Function code	Name	Parameter description	Setting range	Default value
P16.15	Ethernet card monitoring variable address 2	0x0000–0xFFFF	0000–FFFF	0x0000
P16.16	Ethernet card monitoring variable address 3	0x0000–0xFFFF	0000–FFFF	0x0000
P16.17	Ethernet card monitoring variable address 4	0x0000–0xFFFF	0000–FFFF	0x0000
P16.18–P16.23	Reserved			
P16.24	Expansion card identification time of slot 1	0.0–600.0s When this parameter is set to 0.0, disconnection fault detection is not performed.	0.0–600.0	0.0s
P16.25	Expansion card identification time of slot 2	0.0–600.0s When this parameter is set to 0.0, disconnection fault detection is not performed.	0.0–600.0	0.0s
P16.26	Expansion card identification time of slot 3	0.0–600.0s When this parameter is set to 0.0, disconnection fault detection is not performed.	0.0–600.0	0.0s
P16.27	Expansion card communication timeout time of slot 1	0.0–600.0s When this parameter is set to 0.0, disconnection fault detection is not performed.	0.0–600.0	0.0s
P16.28	Expansion card communication timeout time of slot 2	0.0–600.0s When this parameter is set to 0.0, disconnection fault detection is not performed.	0.0–600.0	0.0s
P16.29	Expansion card communication timeout time of slot 3	0.0–600.0s When this parameter is set to 0.0, disconnection fault detection is not performed.	0.0–600.0	0.0s

Function code	Name	Parameter description	Setting range	Default value
P16.30	Reserved			
P16.31	PROFINET communication timeout time	0.0 (invalid)–60.0s	0.0–60.0	5.0s
P16.32	Received PZD2	0: Invalid	0–31	0
P16.33	Received PZD3	1: Set frequency (0–Fmax, unit: 0.01 Hz)	0–31	0
P16.34	Received PZD4		0–31	0
P16.35	Received PZD5	2: PID reference (-1000–1000, in which 1000 corresponds to 100.0%)	0–31	0
P16.36	Received PZD6		0–31	0
P16.37	Received PZD7	3: PID feedback (-1000–1000, in which 1000 corresponds to 100.0%)	0–31	0
P16.38	Received PZD8		0–31	0
P16.39	Received PZD9	4: Torque setting (-3000–+3000, in which 1000 corresponds to 100.0% of the rated current of the motor)	0–31	0
P16.40	Received PZD10		0–31	0
P16.41	Received PZD11		0–31	0
P16.42	Received PZD12	5: Setting of the upper limit of forward running frequency (0–Fmax, unit: 0.01 Hz) 6: Setting of the upper limit of reverse running frequency (0–Fmax, unit: 0.01 Hz) 7: Upper limit of the electromotive torque (0–3000, in which 1000 corresponds to 100.0% of the rated current of the motor) 8: Upper limit of the brake torque (0–3000, in which 1000 corresponds to 100.0% of the rated current of the motor) 9: Virtual input terminal command, 0x000–0x3FF (bit9–bit0 correspond to S8/S7/S6/S5/HDIB/HDIA/S4/S3/S2/S1 in sequence) 10: Virtual output terminal command, 0x00–0x0F (bit3–bit0 correspond to RO2/RO1/HDO/Y1 in sequence) 11: Voltage setting (for V/F separation) (0–1000, in which 1000 corresponds to 100.0% of the rated voltage of the	0–31	0

Function code	Name	Parameter description	Setting range	Default value
		motor) 12: AO1 output setting 1 (-1000→+1000, in which 1000 corresponds to 100.0%) 13: AO2 output setting 2 (-1000→+1000, in which 1000 corresponds to 100.0%) 14: MSB of position reference (signed number) 15: LSB of position reference (unsigned number) 16: MSB of position feedback (signed number) 17: LSB of position feedback (unsigned number) 18: Position feedback setting flag (position feedback can be set only after this flag is set to 1 and then to 0) 19: Function code mapping (PZD2–PZD12 correspond to P14.49–P14.59 respectively.) 20–31: Reserved		
P16.43	Transmitted PZD2	0: Invalid	0–47	0
P16.44	Transmitted PZD3	1: Running frequency (×100, Hz) 2: Set frequency (×100, Hz) 3: Bus voltage (×10, V)	0–47	0
P16.45	Transmitted PZD4	4: Output voltage (×1, V) 5: Output current (×10, A)	0–47	0
P16.46	Transmitted PZD5	6: Actual output torque (×10, %) 7: Actual output power (×10, %)	0–47	0
P16.47	Transmitted PZD6	8: Rotating speed of the running (×1, RPM)	0–47	0
P16.48	Transmitted PZD7	9: Linear speed of the running (×1, m/s) 10: Ramp frequency reference	0–47	0
P16.49	Transmitted PZD8	11: Fault code 12: AI1 value (×100, V)	0–47	0
P16.50	Transmitted PZD9	13: AI2 value (×100, V) 14: AI3 value (×100, V)	0–47	0
P16.51	Transmitted PZD10	15: HDIA frequency (×1000, kHz) 16: Terminal input state	0–47	0

Function code	Name	Parameter description	Setting range	Default value
P16.52	Transmitted PZD11	17: Terminal output state 18: PID reference (×10, %) 19: PID feedback (×10, %)	0–47	0
P16.53	Transmitted PZD12	20: Rated torque of the motor 21: MSB of position reference (signed number) 22: LSB of position reference (unsigned number) 23: MSB of position feedback (signed number) 24: LSB of position feedback (unsigned number) 25: Status word 26: HDIB frequency value (×1000, kHz) 27: MSB of PG card pulse feedback count 28: LSB of PG card pulse feedback count 29: MSB of PG card pulse reference count 30: LSB of PG card pulse reference count 31: Function code mapping (PZD2–PZD12 correspond to P14.60–P14.70 respectively.) 32: Status word 3 33–47: Reserved	0–47	0
P16.54	EtherNet IP communication timeout time	0.0–60.0s	0.0–60.0s	5.0s
P16.55	EtherNet IP communication rate setting	0: Self-adaption 1: 100M full duplex 2: 100M half duplex 3: 10M full duplex 4: 10M half duplex	0–4	0
P16.56	Bluetooth pairing code	0–65535	0–65535	0

Function code	Name	Parameter description	Setting range	Default value
P16.57	Bluetooth host type	0: No host connection 1: Mobile APP 2: Bluetooth box 3-8: Reserved	0-8	0
P16.58	Industrial Ethernet communication card IP address 1	0-255	0-255	192
P16.59	Industrial Ethernet communication card IP address 2	0-255	0-255	168
P16.60	Industrial Ethernet communication card IP address 3	0-255	0-255	0
P16.61	Industrial Ethernet communication card IP address 4	0-255	0-255	20
P16.62	Industrial Ethernet communication card subnet mask 1	0-255	0-255	255
P16.63	Industrial Ethernet communication card subnet mask 2	0-255	0-255	255

Function code	Name	Parameter description	Setting range	Default value
P16.64	Industrial Ethernet communication card subnet mask 3	0-255	0-255	255
P16.65	Industrial Ethernet communication card subnet mask 4	0-255	0-255	0
P16.66	Industrial Ethernet communication card gateway 1	0-255	0-255	192
P16.67	Industrial Ethernet communication card gateway 2	0-255	0-255	168
P16.68	Industrial Ethernet communication card gateway 3	0-255	0-255	0
P16.69	Industrial Ethernet communication card gateway 4	0-255	0-255	1
P19.00	Type of card at slot 1	0: No card 1: Programmable card	0-50	0
P19.01	Type of card at slot 2	2: I/O card 3: Incremental PG card	0-50	0
P19.02	Type of card at slot 3	4: Incremental PG card with UVW 5: Ethernet communication card 6: DP communication card 7: Bluetooth card 8: Resolver PG card 9: CANopen communication card 10: WIFI card 11: PROFINET communication card	0-50	0

Function code	Name	Parameter description	Setting range	Default value
		12: Sine-cosine PG card without CD signals 13: Sine-cosine PG card with CD signals 14: Absolute encoder PG card (reserved) 15: CAN master/slave communication card 16: Modbus TCP communication card 17: EtherCAT communication card (reserved) 18: BACnet communication card (reserved) 19: DeviceNet communication card (reserved) 20: PT100/PT1000 temperature detection card 21: EtherNet IP communication card 22: MECHATROLINK communication card (reserved) 23: Bluetooth card 2 24–31: Reserved 32: SSI-PG card 33–50: Reserved		



E-mail: [overseas@invt.com.cn](mailto:overseas@invt.com.cn) Website: [www.invt.com](http://www.invt.com)

The products are owned by **Shenzhen INVT Electric Co.,Ltd.**

Two companies are commissioned to manufacture: (For product code, refer to the 2nd/3rd place of S/N on the name plate.)

**Shenzhen INVT Electric Co.,Ltd.** (origin code: 01)

Address: INVT Guangming Technology Building, Songbai Road,  
Matian, Guangming District, Shenzhen, China

**INVT Power Electronics (Suzhou) Co.,Ltd.** (origin code: 06)

Address: No. 1 Kunlun Mountain Road, Science & Technology  
Town, Gaoxin District, Suzhou, Jiangsu, China

Industrial Automation:  HMI

PLC

VFD

Servo System

Elevator Intelligent Control System

Rail Transit Traction System

Energy & Power:

UPS


DCIM

Solar Inverter

SVG

New Energy Vehicle Powertrain System  New Energy Vehicle Charging System

New Energy Vehicle Motor



66001-00600

Copyright© INVT.

Manual information may be subject to change without prior notice.

202408 (V1.7)