

# Goodrive5000 Series Medium Voltage Variable-frequency Speed Regulation System

**User Manual** 



SHENZHEN INVT ELECTRIC CO., LTD.

Change history

No.	Change description	Version	Release date
1	First release.	V1.0	April 2023
2	<ul> <li>Moved the original section 2.4.4 Product outline to section 2.4.3, and updated the data in Table 2-3.</li> <li>Updated the direction description of user power supply in Table 3-3.</li> <li>Updated the UI images in section 3.3.</li> <li>Added function code group P25 and updated some function codes.</li> <li>Updated the description in section 10.4.2.</li> </ul>	V1.1	April 2024
3	<ul> <li>Modified section 3.1.3 Control system.</li> <li>Modified the caption of Table 3-4.</li> <li>Modified the fastening torque requirements in section 4.3.2.3.</li> <li>Modified section 4.3.3 Secondary wiring.</li> <li>Modified the function codes for P06 group.</li> <li>Modified Appendix B Communication expansion card.</li> </ul>	V1.2	February 2025

## Preface

Thank you for purchasing INVT Goodrive5000 medium voltage variable-frequency speed regulation system.

For ease of use, read the manual carefully before using Goodrive5000 product.

As an upgrade product of GD5000 series medium voltage VFD, Goodrive5000 medium voltage variable-frequency speed regulation system inherits the high reliability feature of Goodrive5000 platform but optimizes the software, structure, and components, achieving more compact structure, easier installation and maintenance, and optimum protection.

- With mature power unit series technology, high power factor and high fault tolerance rate.
- With the DSP+FPGA+ARM tripe-core technology, advanced control algorithm, high control accuracy, fast dynamic response and large low frequency output torque.
- With optimized structure layout + distributed cables, smaller size and better heat dissipation.
- With Upgrade touch screen program, configuration programming and more convenient maintenance.

Goodrive5000 medium voltage variable-frequency speed regulation system can be widely applied in the following industries.

Thermal power generation: Induced-draft fan, FD (forced draught) fans, primary air fans, secondary air fans, feed pumps, circulating pumps, condensate pumps, mortar pumps, etc.

Cement: High temperature fans, kiln head exhaust fans, kiln end exhaust fans, coal mill circulating fans, raw material mill circulating fans, cement mill circulating fans, ball mills, etc.

Metallurgy: Blast furnace blowers, main sintering fans, coke-oven blowers, dust removal fans, ring cooling fans, combustion fans, circulating water pumps, slag pumps, rolling mills, etc.

Chemical industry: Desulfurization fans, nitrogen compressors, CO<sub>2</sub> compressors, ammonia compressors, other medium compressors, gas fans, circulating water pumps, etc.

Mining: Main ventilators, gas pumps, pressure fans, exhaust fans, air compressors, drainage pumps, medium pumps, belt conveyors, etc.

Petrochemical industry: Main pipeline pumps, oil-well pumps, medium pumps, circulation pumps, booster pumps, compressors, etc.

Water industry: Submersible pumps, clear water pumps, sewage pumps, oxygen delivery blowers, etc.

Others: Fans, pumps of pharmaceutical, paper making and other industries, and other loads such as wind turbines and dynamometers.

This manual is Goodrive5000 medium voltage variable-frequency speed regulation system manual, presenting safety precautions, product information, mechanical and electrical installation, device commissioning, and precautions related to daily maintenance. Read through this manual carefully before installation to ensure the product is installed and operated in a proper manner to give full play to its excellent performance and powerful functions. If you have any question about the function and performance of the product, please consult our technical support.

If the product is ultimately used for military affairs or weapon manufacture, comply with the export control regulations in the Foreign Trade Law of the People's Republic of China and complete related formalities.

To continuously improve the performance of the product to meet higher application requirements, we reserve the right to continuously improve the product and accordingly the product manual, which may be made without prior notice. We have the final interpretation of the manual content.

## Contents

1 Precautions	1
2 Product overview	1
2.1 Product overview	1
2.2 Product features	1
2.3 Technical parameters	2
2.4 Product model and model selection description	3
2.4.1 Product model instruction	
2 4 2 Nameplate model instruction	5
2 4 3 Product outline	5
2.4.4 Product specifications and dimensions	6
2.5 Product application	10
2.6 Product reference standards	10
2.0 Principle and composition	10
2.1 Draduet principle	12
3.1 Product principle	12 12
3.1.1 Main Circuit	13
3.1.2 Power unit.	14
3.1.3 Control system	14
3.1.4 Board jumper and selector switch	18
3.2 Product composition	20
3.2.1 Transformer cabinet	21
3.2.2 Power unit cabinet	21
3.2.3 Control cabinet	22
3.2.4 Bypass cabinet	24
3.2.5 Power unit	26
3.3 HMI	27
3.3.1 Interface introduction	27
3.3.2 Login interface	27
3.3.3 Main interface	28
3.3.4 Level-2 interface	29
3.3.5 Level-3 interface	36
3.3.6 Other interfaces	37
4 Installation and wiring	40
4.1 Installation conditions	40
4.1.1 Environment requirement	40
4.1.2 Installation dimension requirements	
4 1 3 Dissipation guidance	43
4.1.4 Foundation and channel design	44
4 1 5 Cabinet installation	45
4.2 Mechanical wiring	46
4.2 1 Transportation and moving	 16
4.2.2 Unpacking inspection	0+ ۸۵
4.2.2 Orpacking inspection	<del>4</del> 0 ۱۷
4.2.3 Fositioning and fixing	40
4.2.4 What to uo alter scrapping	49
4.5 Electrical Installation	49
4.3.1 FIELdULIUIIS	49
4.3.2 Fillidly Willig	50
4.3.3 Secondary Wiring	52
4.3.4 User-provided accessories and wiring	52
4.3.5 General introduction to user terminals	52
5 System commissioning and running	56
5.1 Commissioning flowchart	56
5.2 Commissioning precautions	56
5.3 Check before commissioning running	57

5.4 Power-on commissioning of the control cabinet	
5.5 Medium voltage power-on commissioning	
5.5.1 Commissioning without motor	
5.5.2 Motor no-load commissioning	
5.5.3 Motor load-carrying commissioning	
6 Function description	61
P00 group Basic functions	
P01 group Start and stop control	
P02 group Motor parameter 1	
P03 group Vector control	
P04 group V/F control	
P05 group Input terminal functions	
P06 group Output terminal functions	
P07 group Human-machine interface	
P08 group Enhanced functions	
P09 group Fault record parameters	
P10 group PID control	
P11 group Multi-step speed control	
P12 group Master/slave control	
P13 group Protection parameters	
P14 group SM control parameters	
P15 group Switching cabinet control functions	
P16 group Serial communication	
P17 group Ethernet communication	
P18 group Communication card functions	
P19 group Motor parameter 2	
P20 group Motor parameter 3	
P21 Encoder state viewing	
P22 group Encoders	
P23 group Temperature controller communication	
P24 group Reserved functions	
P25 group Transformer protefction	
P28 group SD card functions	
7 Function introduction and application	
7.1 Frequency setting	
7.2 Parameter autotuning	
7.3 Start/stop control	
7.4 V/F control	
7.5 Vector control	
7.6 PID control	
7.7 Analog/Digital input/output	
7.8 Bypass switching function	
7.8.1 Switching cabinet function setting	
7.8.2 Manual bypass	
7.8.3 Automatic bypass	
7.8.4 One-driving-more application	
7.9 Master-slave control	
7.9.1 Flexible connection	
7.9.2 Rigid connection	
7.10 Synchronous switching	
7.10.1 Synchronous switching with reactors	
7.10.2 Synchronous switching without reactors	
7.11 Unit bypass function	
8 Alarm and fault solution	
8.1 System fault	
8.1.1 DSP fault	
8.1.2 ARM fault	
8.2 Unit fault	

8.3 Action after fault	219
8.4 Action after alarm	220
8.4.1 Introduction of system alarm	220
8.4.2 Introduction of unit alarm	221
8.5 Common faults and solutions	221
9 Routine maintenance	223
9.1 Routine inspection	223
9.2 Routine maintenance procedure	223
10 Modbus communication protocol	228
10.1 Modbus protocol introduction	228
10.2 Application of Modbus	228
10.2.1 RS485	228
10.2.2 RTU mode	
10.3 RTU command code and communication data	
10.3.1 Command code 03H, reading N words (continuously up to 16 words)	
10.3.2 Command code 06H, writing a word	
10.3.3 Command code 08H, diagnosis	
10.4 Data address definition	
10.4.1 Function code address format rules	
10.4.2 Addresses of other Modbus functions	
10.4.3 Fieldbus scale	252
10.4.4 Error message response	253
10.4.5 Read/Write operation examples	255
10.5 Common communication faults	
Appendix A EMC	257
A.1 EMC features of the system	
A.2 General EMC guidelines on the wiring of the system	
Appendix B Communication expansion card	259
B.1 Model definition and function description	
B.1.1 Function description	
B.2 Communication card	
B.2.1 PROFIBUS-DP communication card (EC-TX503D)	
B.2.2 PROFINET communication card (EC-TX509C)	
B.2.3 PROFIBUS-DP/PROFINET communication protocol	
B.3 PG expansion card	
B.3.1 Incremental encoder PG card (EC-PG101-05, EC-PG101-12, EC-PG101-24)	
B.3.2 Resolver PG card (EC-PG104-00)	
B.3.3 Sin/Cos encoder PG card (EC-PG102-05) and UVW encoder PG card (EC-PG103-05)	
Appendix C Function parameter list	279
C.1 Introduction to function code setting	
C.2 Function parameter list	

## **1** Precautions

This chapter describes safety precautions that are very important for safety and must be compliant.

#### Marking conventions

Safety precautions and warning labels are posted on the outside of each cabinet, on the inner side of power unit cabinet door, and on the front of the power unit.

A	Danger	Personal injury or even death will be caused by incorrect operations or mishandling.
	Note	Ignoring dangerous situations may lead to personal injury or serious equipment damage.
	Electrostatic sensitive	The PCBA may be damaged if related requirements are not followed.
	Medium voltage danger!	Do not open the door in power-on state. You can open the cabinet door for maintenance and other actions only after all power has been disconnected at least 15 minutes.
A	Electric shock danger!	Non-professionals cannot perform the work.
$\wedge$	Warning	This equipment has more than two power supplies. To avoid electric shock, disconnect all power supplies before maintenance.

Before maintenance, the main circuit breaker must be disconnected and the main circuit must be in discharge state. Grounding and other related measures must be taken.

#### About application



- Before installation, wiring, running or maintenance, please read this manual carefully to ensure proper use. You must also be familiar with the driven load and all relevant safety precautions when using it.
- Disconnect the equipment before performing the insulation test. The product has been tested for voltage resistance at the factory, so there is no need to perform the voltage resistance test again, and it should be noted that ambient temperature and humidity can affect the insulation resistance.
- When the product runs under the grid where phase lines are grounded or runs under the IT grid and a grounding fault occurs, excessive voltage to ground may cause damage to the insulation of the motor.



- The medium voltage variable-frequency speed regulation system is only applicable to three-phase medium voltage asynchronous and synchronous motors, disallowing other purposes of use; otherwise, danger may result.
- In applications where the failure of this product could cause accidents or losses, appropriate safety measures must be in place.

- Do not touch the machine after power-on, otherwise, electric shock may occur.
- Anyone wearing or implanted with electronic medical devices should stay away from the variable-frequency speed regulation system, motors, and power cables during system operation, because the presence of electromagnetic field may interfere with the proper operation of medical devices.

## 📩 Electrostatic sensitive

- Strong electric fields or electrostatic discharges may damage individual components, integrated circuits, modules or devices, resulting in functional failure.
- Electronic components, modules or equipment shall be placed on conductive matting (workbenches with anti-static matting, conductive anti-static foam materials, anti-static packing bags, etc.).

#### About delivery



- When moving, transporting and placing equipment, the equipment placement position should be kept level and flat.
- When lifting equipment, ensure that the power of lifting equipment is sufficient and that the lifting and lowering process is smooth.
- Do not drop (or leave) foreign objects such as wires, paper, metal shavings, and tools in the variable-frequency speed regulation system.

#### **About installation**



- The grounding wire must be configured in strict accordance with the technical requirements of the manual and national standards.
- Only trained and qualified professionals can perform the wiring.
- Ensure there is no voltage input to the control circuit and the main circuit before you can operate.
- Input and output cables must be wired according to the instructions and cannot be connected incorrectly; otherwise, equipment may be damaged.
- Ensure that the input power supply meets the requirements of the product specifications.
- The variable-frequency speed regulation system shall be installed on fire-retardant materials, such as metal bracket.
- Do not place flammable objects including drawings and manual in or near the cabinet of the variable frequency speed regulation system.
- Do not install or run a variable-frequency speed regulation system whose components are damaged.

#### **About wiring**



- A medium voltage circuit breaker for circuit protection must be configured on the power side of the medium voltage variable-frequency speed regulation system.
- The grounding wire must be reliably connected.
- Wiring operations must be carried out under the guidance of our professional staff and in accordance with the relevant electrical safety operation standards.
- Wiring operations can be performed only after the equipment has been installed properly.
- The input power phases and rated input voltage of the power supply must be consistent with the rated values of the variable-frequency speed regulation system.
- The output terminals (U, V, and W) cannot be connected to an AC power supply.
- The input and output cables must meet the insulation and capacity requirements in the relevant national or industry standards.

#### About operating and running



- The medium voltage variable-frequency speed regulation system can be connected to the power only after each electrical cabinet door is closed, and the cabinet doors cannot be opened any more upon the power-on.
- Operate in accordance with medium voltage operation specifications. Do not touch a switch with wet hands.
- In the event of a trip restart, the designed peripheral system must be able to protect the safety
  of people and equipment.
- Do not touch the terminals of the medium voltage variable-frequency speed regulation system that is connected to the power because the terminals may be live even if they are in the stop state.
- Do not start or stop the medium voltage variable-frequency speed regulation system by connecting or disconnecting the main circuit.
- Do not disconnect the fan power while it is running; otherwise, overheating may result, which causes equipment damage.
- Ensure that the room for hosting the system is well ventilated so that the ambient temperature is within the range of -5°C-+40°C.
- The operations on transformer cabinets, power unit cabinets or bypass cabinets must comply with medium voltage operating procedures.
- The transformer cabinet, power unit cabinet, and bypass cabinet of the product are medium voltage danger areas, and the cabinet doors cannot be opened upon power-on (the system has been configured with locking devices).
- Guardrails (marked with medium voltage danger signs) must be installed at the necessary locations and they cannot be removed while the equipment is running.

#### About maintenance and component replacement



- Only qualified personnel can perform maintenance and component replacement in accordance with the relevant operating procedures.
- Do not touch any cabinet part if you are not sure whether there is voltage in the cabinet or whether the temperature is high.
- The grounding resistance should be checked frequently to check whether it meets the requirements of equipment operation and national standards. Non-compliance may cause danger.

#### About disposal



• Dispose of scrap components or parts as industrial waste.

## 2 Product overview

#### 2.1 Product overview

As the medium voltage variable-frequency speed regulation system that INVT develops, designs and produces, Goodrive5000 product adopts advanced high performance vector control mode and simultaneously it is compatible with V/F control vectorization. The product features high-quality input, high power factor and excellent power output, and it also has the advantages of high control precision, quick dynamic torque response and large low-frequency output torque. The product can meet the application requirements of modern industry for energy saving and process speed regulation of large and medium-sized fans and general machinery such as pumps, and is widely used in electric power, metallurgy, mining, building materials, petrochemical, municipal engineering and other industries.

### 2.2 Product features

Goodrive5000 medium voltage variable-frequency speed regulation system is a medium voltage driving device that INVT develops, designs and produces to control three-phase AC (synchronous/asynchronous) motor speed, featuring:

- Independently-developed high-performance vector control technology (for asynchronous/synchronous motors), high-precision, and fast dynamic response.
- Embedded PID regulator, implementing closed-loop run.
- Compatible with V/F control vectorization. Optimized V/F control technology, making V/F control dynamic response performance close to that of vector control. Automatic torque boost at low frequency helps to obtain good low-frequency torque characteristics.
- Excellent low-frequency compensation performance. Outstanding output performance obtained in vector control or V/F control by using advanced dead-zone compensation and low-frequency oscillation suppression algorithm.
- Retention at transient voltage drop. The system does not stop if the main circuit encounters a power failure. This eliminates the device stop due to a sudden power failure.
- Optimized overvoltage stall protection. It is a control technique that uses closed-loop bus voltage to decelerate quickly without reporting an overvoltage fault.
- Master-slave control. It implements power balancing of multiple motors.
- Statistics on variable-frequency electricity consumption.
- V/F separation (suitable for power industry)
- One-driving-more bypass cabinet control.
- Braking energy equalization balances the braking energy absorbed by each power unit to lower the overvoltage point.
- Automatic voltage regulation (AVR) on output voltage. It accurately controls the output voltage and improves the motor control characteristics.
- Strong voltage adaptability. The system adapts to a wide range of input voltage, applicable to domestic and international grid voltage conditions.
- Speed-tracking restart for all frequency bands. This allows a running motor to restart, meeting production continuity requirements.
- Synchronous switchover. This implements the no-disturbance switchover between the power

frequency and variable frequency, reducing the impact on mechanical equipment and grid.

- Multiple communication modes. Modbus-RTU, PROFIBUS-DP (optional), PROFINET (optional), and Ethernet UDP (optional).
- Modular structure design, facilitating maintenance.
- The detachable ventilating window mounted externally is convenient for dedusting and maintenance.
- Touch screen display in Chinese, graded menu is easy to operate.
- Dual redundancy of control power, interlock protection against faults.

In addition to the preceding advantages, Goodrive5000 medium voltage variable-frequency speed regulation system has the following protection functions and features:

- Real-time monitoring on run parameters, real-time recording of run data, alarm and fault protection, and fault querying.
- Overload and overcurrent protection.
- Protection against input phase loss.
- Protection against overvoltage, undervoltage, overtemperature, and overspeed.
- High reliability for using optic-fiber isolation communication.

### 2.3 Technical parameters

See technical parameters of Goodrive5000 medium voltage variable-frequency speed regulation system in the following table.

	Item	6kV	10kV	
	Rated input voltage	AC 3PH 6kV	AC 3PH 10kV	
	Voltage fluctuation range	-10%-+10%		
Input	Input frequency	50/60Hz; ±5%		
	Input power factor	≥ 0.96 (load of 20%–100%)		
	Input current harmonic	Meets IEEE519-2014 and GB/ <sup>-</sup>	۲14549-93 standards	
	Output voltage range	0-6kV	0-10kV	
	Output current range	See section 2.4.4 Product spe	cifications and dimensions.	
	Output capacity range	0-5600kVA	0-10000kVA	
Output	Output power range	0–4500kW 0–8000kW		
Output	Output frequency	0–120Hz (The product needs to be customized when the		
	range	frequency exceeds 120Hz)		
	Output current harmonic	≤2%		
	Control mode	V/F control, open-loop vector control, and closed-loop vector control.		
	Control system	DSP, FPGA, ARM		
	НМІ	Touch screen		
Control	Adjustable speed ratio	1:50 (V/F); 1:100 (open-loop vector control); 1:200		
performance	Aujustable-speed fatio	(closed-loop vector control)		
periormance	Speed control	$\pm$ 1% of max. speed (V/F); $\pm$ 0.4% of max. speed (open-loop		
	accuracy	vector control); $\pm$ 0.2% of max. speed (closed-loop vector		
		control)		
	Torque response time	< 200ms (open-loop vector control); < 100ms (closed-loop		
	i si que response time	vector control)		

Item		6kV	10kV			
	Overload protection	120%: 60s (every 10 minutes)				
		180%: immediate protection is carried out.				
	ACC/DEC time	0–3600s, customized				
	Digital input	12 digital inputs				
	Digital output	10 relay outputs (5 NO, 5 NO/	NC). It can be extended to 12			
Signal I/O	Digitatoutput	outputs.	outputs.			
olgilari, o	Analog input	Four inputs: AI1, AI2, AI3 (0-10V/4-20mA); AI4 (-10V-10V)				
	Analog output	Three outputs: AO1, AO2, AO3	3 (0–10V/4–20mA); three			
	, indiog output	outputs: AO4, AO5, AO6* (0–2	0mA)			
Comm	unication mode	Supports the Modbus protoco	ol, provides the standard RS485			
		interface, PROFIBUS, PROFIN	ET and Ethernet.			
		Including protection against	overcurrent, overvoltage,			
		undervoltage, motor overload	d, variable-frequency speed			
	System protection	regulation system overload, an	d phase loss.			
Protection		Including protection against overheat, temperature				
function		controller fault, communication fault, and access fault.				
	Unit protection	Including protection against communication fault,				
		undervoltage, overvoltage, overtemperature, input phase				
		loss, VCE fault, and bypass fai	ult.			
	Mounting method	Installed in cabinet				
	Ingress protection (IP)	IP30 (The product needs to be customizable for other IP				
	rating	rating)				
	Noise level	≪80dB				
	Incoming/outgoing	Bottom in and bottom out (The product needs to be				
	method	customizable for other wiring	g methods)			
	Cooling method	Forced air cooling				
	Control power	AC 380V±10%				
Others	MTBF	50000h				
		-10°C–+40°C. Derating is need	led when the temperature			
	Temperature of	exceeds 40°C. The max. runni	ng temperature is 50°C.			
	running environment	Note: Preheating is needed b	efore starting when the			
		temperature is below 0°C.				
	Altitude	Below 1000m. Derating is needed when the altitude exceeds				
		True of dust discussed	y increase of 100m.			
	Environment	Free of dust, direct sunshine, flammable or corrosive gas, oil				
	<u>, , , , , , , , , , , , , , , , , , , </u>	pollution, steam and vibration.				
	Vibration amplitude	≪0.59g				

**Note:** \* indicates that AO6 is a dedicated channel for excitation.

### 2.4 Product model and model selection description

When selecting the models, refer to the rated voltage, current and power of the motors.

**Note:** Make sure the system capacity is not smaller than the motor capacity.

#### 2.4.1 Product model instruction

.

The product model definitions of Goodrive5000 series products are shown in Figure 2-1.



The product model definitions are shown in Table 2-1.

Table 2-1 Model definition	description
----------------------------	-------------

Symbol	Field description	Definition				
1	Product series	GD5000: GD5000 series vector medium voltage VFD				
	Product	A: Asynchronous vector product (AM)				
(2)	category	B: Synchronous vector product (SM)				
3	Rated capacity	050: 500kVA 10000: 10000kVA				
	Input	03: voltage degree 3kV	66: voltage degree 6.6kV			
4	voltage	33: voltage degree 3.3kV	10: voltage degree 10kV			
		04: voltage degree 4.16kV	11: voltage degree 11kV			
		06: voltage degree 6 kV				
Ē	Output	When the input voltage is the	same as the output voltage, reserve a			
3	voltage	single voltage value.				
		When the input voltage is different from the output voltage, reserve both				
	Maintonanco	S: Front maintenance				
6	Maintenance	D: Dual-side maintenance				
	type	L: Integrated machine				
		R: Energy feedback system				
		Default: No energy feedback				
		C: Bypass system with unit contactor.				
	Later and the second	Default: Bypass system without unit contactor.				
Ū	Lot number	G: Plateau type				
		Default: Plain type				
		F: Film capacitor type				
		Default: Electrolytic capacitor				
		Switching cabinet type	Version			
		0: No switching cabinet	6: 06			
		A: Automatic switching cabinet	7: 07			
	Product	M: Manual switching cabinet				
8	version	<b>Note:</b> When the product needs	to select the switching cabinet, use one			
		digit to indicate the version, suc	ch as GD5000-A0500-10-L-M7. When the			
		product does not select the swit	ching cabinet, use two digits to indicate			
		the version, such as GD5000-A050	60-10-I -07.			

#### 2.4.2 Nameplate model instruction

$\left  \right\rangle$	GD5000 Medium Vo	ltage Variable	Frequency Speed Regulation	on System
	Product M	odel		]
	Rated Capacity	kVA	Rated Motor Power	kW
	Rated Input Voltage	kV	Rated Output Current	A
	Rated Input Frq	47-60Hz	Rated Output Voltage	kV
	Rated Input Power Factor	≥0.96	Output Frq Range	0-120Hz
	IP Grade	IP	Manufacture Date	
	•		M	ADE IN CHINA
2	<u> </u>		「英威腾电气股份有限公司 IEN INVT ELECTRIC CO., LTD.	

Figure 2-2 Nameplate of the system

#### 2.4.3 Product outline



Figure 2-3 Outline structure of the system

**Note:** The outline structure diagram is for reference only.

#### 2.4.4 Product specifications and dimensions

Product model	Rated Rated output		Outline dimensions	Standard	
	power (kW)	current (A)	W×D×H (mm)	weight (kg)	
GD5000-A0250-06-L-07	200	24	1900×1600×2422	1513	
GD5000-A0315-06-L-07	250	30	1900×1600×2422	1563	
GD5000-A0355-06-L-07	280	34	1900×1600×2422	1563	
GD5000-A0400-06-L-07	315	38	$1900 \times 1600 \times 2422$	1578	
GD5000-A0500-06-L-07	400	48	$1900 \times 1600 \times 2422$	1718	
GD5000-A0560-06-L-07	450	54	1900×1600×2422	1768	
GD5000-A0630-06-L-07	500	61	1900×1600×2445	1845	
GD5000-A0710-06-L-07	560	68	1900×1600×2445	1895	
GD5000-A0800-06-L-07	630	77	1900×1600×2445	1975	
GD5000-A0900-06-L-07	710	87	1900×1600×2445	2055	
GD5000-A0300-00-L-07	800	96	$1900 \times 1600 \times 2445$	2000	
GD5000-A1000-00-L-07	900	108	$1900 \times 1000 \times 2443$	3527	
GD5000-A1250-06-L-07	1000	108	$2600 \times 1600 \times 2744$	3687	
GD5000-A1400-06-L-07	1120	135	$2600 \times 1600 \times 2744$	3987	
GD5000-A1600-06-L-07	1250	154	3200×1600×2744	4407	
GD5000-A1800-06-L-07	1400	173	3200×1600×2744	4557	
GD5000-A2000-06-L-07	1600	192	3200×1600×2744	4797	
GD5000-A2240-06-L-07	1800	216	3200×1600×2744	5232	
GD5000-A2500-06-L-07	2000	241	3500X1600X2861	4779	
GD5000-A0250-06-L-A7	200	24	2600x1600x2422	2063	
GD5000-A0315-06-L-A7	250	30	2600x1600x2422	2113	
GD5000-A0355-06-L-A7	280	34	2600x1600x2422	2113	
GD5000-A0400-06-L-A7	315	38	2600×1600×2422	2128	
GD5000-A0500-06-L-A7	400	48	2600×1600×2422	2268	
GD5000-A0560-06-L-A7	450	54	2600×1600×2422	2318	
GD5000-A0630-06-L-A7	500	61	2600×1600×2445	2395	
GD5000-A0710-06-L-A7	560	68	2600×1600×2445	2445	
GD5000-A0800-06-L-A7	630	77	2600×1600×2445	2525	
GD5000-A0900-06-L-A7	710	87	2600×1600×2445	2605	
GD5000-A1000-06-L-A7	800	96	2600×1600×2445	2676	
GD5000-A1120-06-L-A7	900	108	3300×1600×2744	4077	
GD5000-A1250-06-L-A7	1000	120	3300×1600×2744	4237	
GD5000-A1400-06-L-A7	1120	135	3300×1600×2744	4537	
GD5000-A1600-06-L-A7	1250	154	3900×1600×2744	4957	
GD5000-A1800-06-L-A7	1400	173	3900×1600×2744	5107	
GD5000-A2000-06-L-A7	1600	192	3900×1600×2744	5347	
GD5000-A2240-06-L-A7	1800	216	3900×1600×2744	5782	
GD5000-A2500-06-L-A7	2000	241	4200X1600X2861	5329	
GD5000-A0250-06-L-M7	200	24	2600x1600x2422	1893	
GD5000-A0315-06-L-M7	250	30	2600x1600x2422	1943	
GD5000-A0355-06-L-M7	280	34	2600x1600x2422	1943	
GD5000-A0400-06-L-M7	315	38	2600×1600×2422	1958	
GD5000-A0500-06-L-M7	400	48	2600×1600×2422	2098	

Table 2-2 Specifications of Goodrive5000 integrated machine products (6kV)

Product overview

Product model	Rated power (kW)	Rated output current (A)	Outline dimensions W×D×H (mm)	Standard weight (kg)
GD5000-A0560-06-L-M7	450	54	2600×1600×2422	2148
GD5000-A0630-06-L-M7	500	61	2600×1600×2445	2225
GD5000-A0710-06-L-M7	560	68	2600×1600×2445	2275
GD5000-A0800-06-L-M7	630	77	2600×1600×2445	2355
GD5000-A0900-06-L-M7	710	87	2600×1600×2445	2435
GD5000-A1000-06-L-M7	800	96	2600×1600×2445	2506
GD5000-A1120-06-L-M7	900	108	3300×1600×2744	3907
GD5000-A1250-06-L-M7	1000	120	3300×1600×2744	4067
GD5000-A1400-06-L-M7	1120	135	3300×1600×2744	4367
GD5000-A1600-06-L-M7	1250	154	3900×1600×2744	4787
GD5000-A1800-06-L-M7	1400	173	3900×1600×2744	4937
GD5000-A2000-06-L-M7	1600	192	3900×1600×2744	5177
GD5000-A2240-06-L-M7	1800	216	3900×1600×2744	5612
GD5000-A2500-06-L-M7	2000	241	4200X1600X2861	5159

Table 2-3 Specifications of Goodrive5000 separate machine products (6kV)

Droduct model	Rated power	Rated output	<b>Outline dimensions</b>	Standard
Floduct model	(kW)	current (A)	W×D×H (mm)	weight (kg)
GD5000-A2800-06-D-07	2240	270	3800×1600×2862	6328
GD5000-A3150-06-D-07	2500	303	3800×1600×2862	6893
GD5000-A3550-06-D-07	2800	342	4500×1600×2882	7992
GD5000-A4000-06-D-07	3150	385	4500×1600×2882	8817
GD5000-A4500-06-D-07	3550	433	4900×1600×2882	9710
GD5000-A5000-06-D-07	4000	481	4900×1600×2882	10095
GD5000-A5600-06-D-07	4500	539	4900×1600×2882	10400
GD5000-A2800-06-D-A7	2240	270	4500×1600×2862	6878
GD5000-A3150-06-D-A7	2500	303	4500×1600×2862	7443
GD5000-A3550-06-D-A7	2800	342	5300×1600×2882	8732
GD5000-A4000-06-D-A7	3150	385	5300×1600×2882	9557
GD5000-A4500-06-D-A7	3550	433	5700×1600×2882	10450
GD5000-A5000-06-D-A7	4000	481	5700×1600×2882	10835
GD5000-A5600-06-D-A7	4500	539	5700×1600×2882	11140
GD5000-A2800-06-D-M7	2240	270	4500×1600×2862	6708
GD5000-A3150-06-D-M7	2500	303	4500×1600×2862	7273
GD5000-A3550-06-D-M7	2800	342	5300×1600×2882	8622
GD5000-A4000-06-D-M7	3150	385	5300×1600×2882	9447
GD5000-A4500-06-D-M7	3550	433	5700×1600×2882	10340
GD5000-A5000-06-D-M7	4000	481	5700×1600×2882	10725
GD5000-A5600-06-D-M7	4500	539	5700×1600×2882	11030

Product model	Rated power (kW)	Rated output current (A)	urrent (A) Outline dimensions W×D×H (mm)	
GD5000-A0250-10-L-07	200	14	$1900 \times 1600 \times 2422$	1780
GD5000-A0315-10-L-07	250	18	$1900 \times 1600 \times 2422$	1830
GD5000-A0355-10-L-07	280	20	1900×1600×2422	1830
GD5000-A0400-10-L-07	315	23	1900×1600×2422	1830
GD5000-A0450-10-L-07	355	26	1900×1600×2422	1880
GD5000-A0500-10-L-07	400	29	1900×1600×2422	1915
GD5000-A0560-10-L-07	450	32	1900×1600×2422	1985
GD5000-A0710-10-L-07	560	41	1900×1600×2422	2105
GD5000-A0800-10-L-07	630	46	1900×1600×2422	2135
GD5000-A0900-10-L-07	710	52	1900×1600×2422	2215
GD5000-A1000-10-L-07	800	58	1900×1600×2445	2272
GD5000-A1120-10-L-07	900	65	1900×1600×2445	2312
GD5000-A1250-10-L-07	1000	72	1900×1600×2445	2562
GD5000-A1400-10-L-07	1120	81	1900×1600×2445	2612
GD5000-A1600-10-L-07	1250	92	1900×1600×2445	2743
GD5000-A1700-10-L-07	1400	98	1900×1600×2445	2823
GD5000-A2000-10-L-07	1600	115	2600×1600×2744	4759
GD5000-A2240-10-L-07	1800	129	2600×1600×2744	4964
GD5000-A2500-10-L-07	2000	144	2600×1600×2744	5219
GD5000-A2800-10-L-07	2240	162	3500×1600×2861	5136
GD5000-A3150-10-L-07	2500	182	3500×1600×2861	5586
GD5000-A3550-10-L-07	2800	205	3500×1600×2861	5986
GD5000-A4000-10-L-07	3150	231	3500X1600X2861	6186
GD5000-A0250-10-L-A7	200	14	2600x1600x2422	2330
GD5000-A0315-10-L-A7	250	18	2600x1600x2422	2380
GD5000-A0355-10-L-A7	280	20	2600x1600x2422	2380
GD5000-A0400-10-L-A7	315	23	2600x1600x2422	2380
GD5000-A0450-10-L-A7	355	26	2600x1600x2422	2430
GD5000-A0500-10-L-A7	400	29	2600×1600×2422	2465
GD5000-A0560-10-L-A7	450	32	2600×1600×2422	2535
GD5000-A0710-10-L-A7	560	41	2600×1600×2422	2655
GD5000-A0800-10-L-A7	630	46	2600×1600×2422	2685
GD5000-A0900-10-L-A7	710	52	2600×1600×2422	2765
GD5000-A1000-10-L-A7	800	58	2600×1600×2445	2822
GD5000-A1120-10-L-A7	900	65	2600×1600×2445	2862
GD5000-A1250-10-L-A7	1000	72	2600×1600×2445	3112
GD5000-A1400-10-L-A7	1120	81	2600×1600×2445	3162
GD5000-A1600-10-L-A7	1250	92	2600×1600×2445	3293
GD5000-A1700-10-L-A7	1400	98	2600×1600×2445	3373
GD5000-A2000-10-L-A7	1600	115	3300×1600×2744	5309
GD5000-A2240-10-L-A7	1800	129	3300×1600×2744	5514
GD5000-A2500-10-L-A7	2000	144	3300×1600×2744	5769
GD5000-A2800-10-L-A7	2240	162	4200×1600×2861	5686
GD5000-A3150-10-L-A7	2500	182	4200×1600×2861	6136
GD5000-A3550-10-L-A7	2800	205	4200×1600×2861	6536
GD5000-A4000-10-L-A7	3150	231	4200X1600X2861	6736

Table 2-4 Parameters of Goodrive5000 integrated machine products (10kV)
---

Product overview

Product model	Rated power (kW)	Rated output current (A)	Outline dimensions W×D×H (mm)	Standard weight (kg)
GD5000-A0250-10-L-M7	200	14	2600×1600×2422	2160
GD5000-A0315-10-L-M7	250	18	2600×1600×2422	2210
GD5000-A0355-10-L-M7	280	20	2600×1600×2422	2210
GD5000-A0400-10-L-M7	315	23	2600×1600×2422	2210
GD5000-A0450-10-L-M7	355	26	2600×1600×2422	2260
GD5000-A0500-10-L-M7	400	29	2600×1600×2422	2295
GD5000-A0560-10-L-M7	450	32	2600×1600×2422	2365
GD5000-A0710-10-L-M7	560	41	2600×1600×2422	2485
GD5000-A0800-10-L-M7	630	46	2600×1600×2422	2515
GD5000-A0900-10-L-M7	710	52	2600×1600×2422	2595
GD5000-A1000-10-L-M7	800	58	2600×1600×2445	2652
GD5000-A1120-10-L-M7	900	65	2600×1600×2445	2692
GD5000-A1250-10-L-M7	1000	72	2600×1600×2445	2942
GD5000-A1400-10-L-M7	1120	81	2600×1600×2445	2992
GD5000-A1600-10-L-M7	1250	92	2600×1600×2445	3123
GD5000-A1700-10-L-M7	1400	98	2600×1600×2445	3203
GD5000-A2000-10-L-M7	1600	115	3300×1600×2744	5139
GD5000-A2240-10-L-M7	1800	129	3300×1600×2744	5344
GD5000-A2500-10-L-M7	2000	144	3300×1600×2744	5599
GD5000-A2800-10-L-M7	2240	162	4200×1600×2861	5516
GD5000-A3150-10-L-M7	2500	182	4200×1600×2861	5966
GD5000-A3550-10-L-M7	2800	205	4200×1600×2861	6366
GD5000-A4000-10-L-M7	3150	231	4200X1600X2861	6566

Table 2-5 Specifications of Goodrive5000 separate machine products (10kV)

Product model	Rated power (kW)	Rated output current (A)	Outline dimensions W×D×H (mm)	Standard weight (kg)
GD5000-A4500-10-D-07	3550	260	4700×1600×2745	9376
GD5000-A5000-10-D-07	4000	289	4700×1600×2745	10241
GD5000-A5600-10-D-07	4500	323	4700×1600×2745	10536
GD5000-A6300-10-D-07	5000	364	5600×1600×2882	11112
GD5000-A7100-10-D-07	5600	410	5600×1600×2882	11467
GD5000-A7500-10-D-07	6000	433	6600×1600×2882	14200
GD5000-A8000-10-D-07	6300	462	6600×1600×2882	14430
GD5000-A9000-10-D-07	7100	520	6600×1600×2882	16235
GD5000-A10000-10-D-07	8000	577	6600×1600×2882	16350
GD5000-A4500-10-D-A7	3550	260	5400×1600×2745	9926
GD5000-A5000-10-D-A7	4000	289	5400×1600×2745	10791
GD5000-A5600-10-D-A7	4500	323	5400×1600×2745	11086
GD5000-A6300-10-D-A7	5000	364	6400×1600×2882	11852
GD5000-A7100-10-D-A7	5600	410	6400×1600×2882	12207
GD5000-A7500-10-D-A7	6000	433	7400×1600×2882	14940
GD5000-A8000-10-D-A7	6300	462	7400×1600×2882	15170
GD5000-A9000-10-D-A7	7100	520	7400×1600×2882	16975
GD5000-A10000-10-D-A7	8000	577	7400×1600×2882	17090

Product overview

Product model	Rated power	Rated output	Outline dimensions	Standard
	(KVV)	Current (A)	WXDXH (MM)	weight (kg)
GD5000-A4500-10-D-M7	3550	260	5400×1600×2745	9756
GD5000-A5000-10-D-M7	4000	289	5400×1600×2745	10621
GD5000-A5600-10-D-M7	4500	323	5400×1600×2745	10916
GD5000-A6300-10-D-M7	5000	364	6400×1600×2882	11742
GD5000-A7100-10-D-M7	5600	410	6400×1600×2882	12097
GD5000-A7500-10-D-M7	6000	433	7400×1600×2882	14830
GD5000-A8000-10-D-M7	6300	462	7400×1600×2882	15060
GD5000-A9000-10-D-M7	7100	520	7400×1600×2882	16865
GD5000-A10000-10-D-M7	8000	577	7400×1600×2882	16980

#### ∠Note:

- The outline dimensions of medium voltage variable-frequency speed regulation system listed in the tables above are standard.
- The outline dimensions of the system can be customized based on user requirements. Dimensions may vary among customized products listed in the catalog.
- If the value exceeds the rated data, please contact us.
- The dimensions may be subject to the technical agreement without notice during improving.

### 2.5 Product application

Widely used in various industries, Goodrive5000 series products provide perfect medium voltage AC motor (AM/SM) soft-start, speed regulation, energy saving and smart control solutions. The detailed applications are as follows:

Steel/Metallurgy	Air blowers, dusting blowers, ID (induced draft) fans, compression fans, descaling pumps, mud pumps, feed pumps, slag washing pumps, phosphorus removal pumps, rolling mills, etc.				
Cement/Building material	High temperature fans, furnace head fans, furnace end fans, dusting blowers, raw meal rolling machine, clinker rolling machine, ore rolling machine, roller press, ball mill, etc.				
Thermal power/Hydropower/Garbage power	Boiler induced-draft fans, FD (forced draught) fans, primary air fans, secondary air fans, desulphurization fans, air compressors, boiler feed pumps, condensate pumps, circulating pumps, ash pumps, ozone generator, etc.				
Oil/Chemical industry/Natural gas	Water flooding pumps, circulating pumps, oil pipe pumps, submersible pumps, electric submersible pumps, brine pumps, descaling pumps, mud pumps, compressors, etc.				
Paper making/Pharmacy	Beating pumps, cleaning pumps, etc.				
Coal/mining	Belt conveyors, air exhausters, dusting blower, gas pumps, medium pumps, etc.				
Municipal engineering	Domestic water pumps, industrial water pumps, sewage pumps, clean water pumps, purifying pumps, etc.				
Others	Power station pumps, wind tunnel test fans, etc.				

### 2.6 Product reference standards

Goodrive5000 integrated machine medium voltage variable-frequency speed regulation system is designed and manufactured with reference to the latest version of national standards (GB or GB/T), International Electrotechnical Commission (IEC) standards, and International System of Units (SI) as the minimum design specifications, and some of its relevant technical parameters can meet the requirements of GB or GB/T and IEC standards.

Some technical standards for design reference:

IEC 61800-5-1:2007	Adjustable speed electrical power drive systems - Part 5-1: Safety requirements - Electrical, thermal and energy
IEC 61800-3-2017	Adjustable speed electrical power drive systems - Part 3: EMC requirements and specific test methods
IEC 61800-4-2012	Adjustable speed electrical power drive systems. Part 4. General requirements. Rating specifications for a.c power drive systems above 1000 V a.c. and exceeding 35 kV
IEC 60204-1-2016	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
IEC 60204-11:2018	Safety of machinery - Electrical equipment of machines - Part 11: Requirements for HV equipment for voltages above 1000 V a.c. or 1500 V d.c. and not exceeding 36 kV
IEC 60721-3-1-2018	Classification of environmental conditions - Part 3-1: Classification of groups of environmental parameters and their severities - Storage
IEC 60721-3-2-2018	Classification of environmental conditions - Part 3-2: Classification of groups of environmental parameters and their severities - Transportation and Handling
IEC 60721-3-3-2019	Classification of environmental conditions - Part 3-3: Classification of groups of environmental parameters and their severities - Stationary use at weatherprotected locations
IEEE 519-2014	Recommended Practices and Requirements for Harmonic Control in Electrical Power Systems
IEC 61800-5-1:2007	Adjustable speed electrical power drive systems - Part 5-1: Safety requirements - Electrical, thermal and energy
IEC 61800-3-2017	Adjustable speed electrical power drive systems - Part 3: EMC requirements and specific test methods
IEC 61800-4-2012	Adjustable speed electrical power drive systems. Part 4. General requirements. Rating specifications for a.c power drive systems above 1000 V a.c. and exceeding 35 kV
IEC 60204-1-2016	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
IEC 60204-11:2018	Safety of machinery - Electrical equipment of machines - Part 11: Requirements for HV equipment for voltages above 1000 V a.c. or 1500 V d.c. and not exceeding 36 kV
IEC 60721-3-1-2018	Classification of environmental conditions - Part 3-1: Classification of groups of environmental parameters and their severities - Storage
IEC 60721-3-2-2018	Classification of environmental conditions - Part 3-2: Classification of groups of environmental parameters and their severities - Transportation and Handling
IEC 60721-3-3-2019	Classification of environmental conditions - Part 3-3: Classification of groups of environmental parameters and their severities - Stationary use at weatherprotected locations

IEEE 519-2014	Recommended Practices and Requirements for Harmonic Control in Electrical Power Systems		
GB/T 12668.501-2013	Adjustable speed electrical power drive systems Part 5-1: Safety requirements—Electrical, thermal and energy		
GB/T 12668.3-2012	Adjustable speed electrical power drive systems Part 3: EMC requirements and specific test methods		
GB/T 1094.1-2013	Power transformers-Part 1: General		
GB/T 1094.3-2017	Power transformers-Part 3: Insulation levels, dielectric tests and		
GB/T 1094.11-2007	Power transformers-Part 11: Dry-type transformers		
GB/T 14549-1993	Quality of electric energy supply harmonics in public supply network		
GB/T 3956-2008	Conductors of insulated cables		
GB/T 10233-2016	Basic testing method for low-voltage switchgear and controlgear		
GB/T 11022-2020	Common specifications for medium voltage switchgear and controlgear standards		
GB/T 4208-2017	Degree of protection provided by enclosure (IP code)		
GB/T 2423	Environmental testing Part 2: Test methods (series standard)		
GB/T 30843.1-2014	Variable-frequency drive above 1 kV and not exceeding 35 kV Part 1: Technical conditions		
GB/T 30843.2-2014	Variable-frequency drive above 1 kV and not exceeding 35 kV Part 2: Test methods		
GB/T 30843.3-2017	Variable-frequency drive above 1 kV and not exceeding 35 kV Part 3: Safety requirements		
GB/T 12668.902-2021	Adjustable speed electrical power drive systems Part 9-2: Ecodesign for power drive systems, motor starters, power electronics and their driven applications—Energy efficiency indicators for power drive systems and motor starters		

## **3 Principle and composition**

### 3.1 Product principle

Goodrive5000 integrated machine medium voltage variable-frequency speed regulation system adopts the technology of multi-unit series PWM wave superposition. By power units in series, the input voltage of the grid runs through phase-shifting transformer, becomes 3\*N channels 3-phase 690V voltage (N: the number of power units in each phase), and then supplies power to each power unit. The system consists of the main circuit, power units and control system. Each unit uses H-bridge whose PWM output is controlled by the main control system. Connect the unit outputs of the same phase in series, connect the first unit of each phase in "Y", and combine the last units of three phases into medium voltage output. The schematic diagram is shown in Figure 3-1.

#### 3.1.1 Main circuit



Figure 3-1 Topological diagram of the system

The isolation transformer is dry-type phase shifting transformer using forced air cooling, the original side is in "Y" connection directly connected to medium voltage incoming line, and the secondary side winding is in prolonged delta connection with a certain phase difference.

60°

Phase – shifting angle =  $\frac{1}{1}$  the number of power units in each phase

The secondary side winding supplies power to the power units and the phase difference is determined by the number of power units and the voltage degree of the variable-frequency speed regulation system.

#### 3.1.2 Power unit

The power units mainly consist of main circuit and control circuit. The main circuit includes protection, rectification, filtering, converting and bypass (optional). Its schematic diagram is shown in Figure 3-2.



Figure 3-2 Schematic diagram of power units

The input terminals R/S/T are connected to 3-phase low voltage output of the secondary coil of the transformer, electrify DC bus after 3-phase full-bridge rectification, and then convert into AC output by H-bridge converting. The output terminal of power units in single phase is ACI/ACO.

The unit control circuit controls the power units by receiving the signals from the main control system, and simultaneously it monitors the power units by sending its own information including voltage, faults and states back to the main control system via optical fiber.

The power units have the function of unit bypasses, one is IGBT bypass and the other is contactor bypass (optional). When a unit has a fault, the unit will achieve automatic bypass to ensure the system continues working normally.

#### 3.1.3 Control system

The main control system of Goodrive5000 medium voltage variable-frequency speed regulation system consists of modules such as the main control board, power supply module, temperature controller, system I/O, user I/O, terminal control board, and expansion I/O board (optional). The modular design is adopted, and single boards are connected via connectors. In this way, each single board has clear functions for the convenience of signal identification and maintenance. The control system and the power unit are isolated by optical fiber for signal transmission, ensuring stability and reliability. The internal resistance of the current analog input is  $500\Omega$ , and the max. load resistance of the current analog output is  $500\Omega$ .

The terminal control board provides interfaces of multi-functional user IO terminals, supporting 12 digital inputs, five relay NO outputs (220VAC, 6A), five relay NO/NC outputs (NO contact : 220VAC, 5A; NC contact: 220VAC, 3A), four analog inputs, and six analog outputs. The interface profile is shown in Figure 3-3.



Figure 3-3 Terminal control board interface outline diagram

The user interface definitions of the terminal control be	oard are as follows.
---	----------------------

No.	Name		Direction	Туре	Remarks
1	Digital input	S1	User→Terminal	Digital	
2	Digital input	S2	User→Terminal	Digital	
3	Digital input	S3	User→Terminal	Digital	CNI20
4	Digital input	S4	User→Terminal	Digital	CN38
5	Digital input	S5	User→Terminal	Digital	
6	Digital input	S6	User→Terminal	Digital	
7	Digital input	S7	User→Terminal	Digital	
8	Digital input	S8	User→Terminal	Digital	
9	Digital input	S9	User→Terminal	Digital	CNOO
10	Digital input	S10	User→Terminal	Digital	CN39
11	Digital input	S11	User→Terminal	Digital	
12	Digital input	S12	User→Terminal	Digital	
13	Digital input		User→Terminal	Digital	
14	Digital input	COM-1	User→Terminal	Digital	CN6
15	Digital input		User→Terminal	Digital	

Tahlo 3-1 Digital in	nut nort descrir	ntions of the term	ninal control board
Table J-1 Digitatin	քաւ քնու ազելոր		

Table 3-2 Relay output port descriptions of the terminal control board

No.	Name	1	Direction	Туре	Remarks
1	Delevieuteut	RO1A	Terminal→User	Digital	
2	Relay output	RO1C	Terminal→User	Digital	CNE
3	Delau autaut	RO2A	Terminal→User	Digital	CND
4	Relay output	RO2C	Terminal→User	Digital	
5	Relay output	RO3A	Terminal→User	Digital	
6		RO3C	Terminal→User	Digital	CN22
7		RO4A	Terminal→User	Digital	CN32
8	Relay output	RO4C	Terminal→User	Digital	
9	Relay output	RO5A	Terminal→User	Digital	
10		RO5C	Terminal→User	Digital	
11		RO6A	Terminal→User	Digital	CN33
12	Relay output	RO6B	Terminal→User	Digital	
13	3	RO6C	Terminal→User	Digital	
14		RO7A	Terminal→User	Digital	
15	Relay output	RO7B	Terminal→User	Digital	CN34
16		RO7C	Terminal→User	Digital	
17		RO8A	Terminal→User	Digital	
18	Relay output	RO8B	Terminal→User	Digital	CN35
19		RO8C	Terminal→User	Digital	
20		RO9A	Terminal→User	Digital	
21	Relay output	RO9B	Terminal→User	Digital	CN36
22	2	RO9C	Terminal→User	Digital	
23		RO10A	Terminal→User	Digital	
24	Relay output	RO10B	Terminal→User	Digital	CN37
25		RO10C	Terminal→User	Digital	

No.	Name		Direction	Туре	Remarks
1	User power	+10.5V-1	Terminal→User		
2	supply	GND_AI	Terminal→User		
3	Analogianut	AI1+	User→Terminal	Analog	CN140
4	4	Al1-	User→Terminal	Analog	CN40
5	Anglesingut	AI2+	User→Terminal	Analog	
6	Analog input	AI2-	User→Terminal	Analog	
7	Analogianut	AI3+	User→Terminal	Analog	
8	Analog Input	AI3-	User→Terminal	Analog	
9	Analog input	AI4+	User→Terminal	Analog	CN141
10	Analog Input	Al4-	User→Terminal	Analog	CN41
11	Analog output	AO1_0	Terminal→User	Analog	
12	12 Analog output	AO2_0	Terminal→User	Analog	
13	Analog output	AO3_0	Terminal→User	Analog	
14	14 Analog output	AO4_I	Terminal→User	Analog	
15	Analog output	AO5_I	Terminal→User	Analog	
16	Analog output	AO6_I	Terminal→User	Analog	CN42
17	AO reference ground		Terminal→User	Analog	CN42
18	AO reference ground		Terminal→User	Analog	
19	AO reference ground	GND_AO	Terminal→User	Analog	
20	AO reference ground		Terminal→User	Analog	
21	Lloor 495	485+	User→Terminal	Digital	CN43
22	USEI 485	485-	User→Terminal	Digital	
23	User 485 reference ground	485G_I	Terminal→User		
24	Ground	PE	User→Terminal		

Table 3-3 Analog input & output terminal and 485 terminal descriptions of the terminal control board

The expansion I/O board (optional) includes 6 NO relay outputs (multiplexed with DC relay terminal board, 220VAC, 5A). 6 sets of NO and NC relay outputs (NO contact: 220VAC, 5A; NC contact: 220VAC, 3A). The interface outline diagram is shown in Figure 3-4.



Figure 3-4 Expansion I/O board interface outline diagram

Tahlo 3	A Interface	signal de	scription	of the AC	rolav	torminal	hoard
Table 3	5-4 internace	z signal ue	scription	UT THE AC	relay	terminat	Duaru

No.	Name	1	Direction	Туре	Remarks
1		RO11A	Terminal→User	Digital	
2	Relay output	RO11C	Terminal→User	Digital	CN6
3	Delay autaut	RO12A	Terminal→User	Digital	
4	Relay output	RO12C	Terminal→User	Digital	
5	Delay output	RO13A	Terminal→User	Digital	CN7
6	Relay output	RO13C	Terminal→User	Digital	
7	Delay autaut	RO14A	Terminal→User	Digital	
8	Relay output	RO14C	Terminal→User	Digital	CN8
9	A Relay output	RO15A	Terminal→User	Digital	
10	Relay output	RO15C	Terminal→User	Digital	
11	Dolov output	RO16A	Terminal→User	Digital	CN9
12	Relay output	RO16C	Terminal→User	Digital	
13		RO17A	Terminal→User	Digital	
14	Relay output	RO17B	Terminal→User	Digital	CN10
15	15	RO17C	Terminal→User	Digital	
16		RO18A	Terminal→User	Digital	
17	Relay output	RO18B	Terminal→User	Digital	CN11
18		RO18C	Terminal→User	Digital	
19		RO19A	Terminal→User	Digital	
20	Relay output	RO19B	Terminal→User	Digital	CN12
21		RO19C	Terminal→User	Digital	
22		RO20A	Terminal→User	Digital	
23	Relay output	RO20B	Terminal→User	Digital	CN13
24		RO20C	Terminal→User	Digital	
25		RO21A	Terminal→User	Digital	
26	Relay output	RO21B	Terminal→User	Digital	CN14
27		RO21C	Terminal→User	Digital	
28		RO22A	Terminal→User	Digital	
29	Relay output	RO22B	Terminal→User	Digital	CN15
30		RO22C	Terminal→User	Digital	

The DC relay terminal control board (optional) includes 6 relay NO and NC outputs (220VDC, 5A). The interface outline diagram is shown in Figure 3-5.



Figure 3-5 DC relay	hoard interface	o outling diagram
riguit J-J De rela		c outline ulagram

No.	Name		Direction	Туре	Remarks
1		RO11A	Terminal→User	Digital	
2	<b>Relay output</b>	RO11B	Terminal→User	Digital	CN2
3	3	RO11C	Terminal→User	Digital	
4		RO12A	Terminal→User	Digital	
5	Relay output	RO12B	Terminal→User	Digital	CN3
6		RO12C	Terminal→User	Digital	
7		RO13A	Terminal→User	Digital	
8	Relay output	RO13B	Terminal→User	Digital	CN4
9		RO13C	Terminal→User	Digital	
10		RO14A	Terminal→User	Digital	
11	Relay output	RO14B	Terminal→User	Digital	CN5
12	12	RO14C	Terminal→User	Digital	
13		RO15A	Terminal→User	Digital	
14	Relay output	RO15B	Terminal→User	Digital	CN6
15		RO15C	Terminal→User	Digital	
16		RO16A	Terminal→User	Digital	
17	Relay output	RO16B	User→Terminal	Digital	CN7
18		RO16C	User→Terminal	Digital	

The user interface definitions of the DC relay board are as follows.

#### 3.1.4 Board jumper and selector switch

Voltage and current switching on terminal control board: The analog output signals can be voltage or current signals which are switched by the DIP switch. SW1 corresponds to AO1, SW2 corresponds to AO2, and SW3 corresponds to AO3 on the terminal control board. According to instructions on I/O board, connect the mini jumper to select the corresponding voltage or current signal. If the DIP switch is set to ON, it is output voltage analog. If the switch is set to OFF, it is output current analog.

User 485 setting: The RS485 interface supports Modbus communication protocol, and you can choose whether to connect the terminal resistor through the SW4 switch of the user I/O board. The system connects the  $120\Omega$  terminal resistor when SW4 is set to OFF.







The system I/O board includes input and output current detection, input and output voltage detection, and dial-up selection of different voltage and current levels as shown in Figure 3-8 and Figure 3-9.

SW2	SW3	SW4	Output voltage
ON         I         I         I         I         I           OFF         I	ON         I         I         I         I         I           OFF         I	ON         Image: second s	3kV/3.3kV
ON         I         I         I         I         I           OFF         I	ON         I         I         I         I         I           OFF         I	ON         I         I         I         I         I           OFF         I         2         3         4         5         6	4.16kV
ON         I         I         I         I         I           OFF         I	ON         I         I         I         I         I           OFF         I	ON         I	6kV/6.6kV
ON	ON	ON OFF 2 3 4 5 6	10kV/11kV

#### Figure 3-8 Dial-up configuration of the system I/O board (output voltage)

SW5	SW6	Output current
ON 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	ON 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0A-53A
ON <b>A A A A A A A A A A</b>	ON <b>I I I I I I I I I I</b>	54A-106A
ON         I         I         I         I         I           OFF         I	ON         I         I         I         I         I           OFF         I	107A-176A
ON	ON         I	177A-282A
ON	ON	283A-424A
ON 0FF 2 3 4 5 6	ON 0FF 2 3 4 5 6	425A-777A

#### Figure 3-9 Dial-up configuration of the system I/O board (output current)

**Note:** The grey color in the above figure represents the strikers of the switch.

DIP switch functions of the main control board

Table 3-5 SW1, SW2 function and position

Switch	ON	OFF
SW1	ARM flash loading mode	ARM serial programming mode enable
SW2	DSP flash loading mode	DSP serial programming mode enable

### 3.2 Product composition

Goodrive5000 medium voltage variable-frequency speed regulation system is mainly composed of the transformer cabinet, power unit cabinet, control cabinet, power units and HMI; in actual use, bypass cabinet can be fitted as optional according to requirements of users. The outline diagram of Goodrive5000 medium voltage variable-frequency speed regulation system is shown in Figure 3-10.





#### 3.2.1 Transformer cabinet

The transformer cabinet is used to install phase shifting transformer and accessories. The internal layout of the transformer cabinet is shown in Figure 3-11.



Figure 3-11 Layout in the transformer cabinet

The phase shifting isolation transformer installed in the transformer cabinet provides 3-phase power supply for power units to achieve high/low voltage shifting and isolation. The phase shifting transformer adopts dry-type structure, isolation degree at H and secondary side in prolonged delta connection, effectively reducing harmonics at the grid side.

The temperature control system inside the transformer monitors the temperature of each phase in real-time, and provides over-temperature protection and alarms. The default setting is: when the temperature of the phase shifting transformer exceeds 90°C, the system will alarm but not stop automatically; when the temperature exceeds 110°C, the system will conduct temperature protection and stop automatically.

A special grounding copper bar at the bottom of the transformer cabinet is used for reliable medium voltage grounding. The system shall be grounded together with the medium voltage grounding system during construction.

#### 3.2.2 Power unit cabinet

The power unit cabinet is the converter of the system and the actuator for AC-DC-AC conversion. It is used to

install power units and accessories. The internal layout of the power unit cabinet is shown in Figure 3-12.





The power unit cabinet is used for installing power units; by the connection of medium voltage cable and secondary side winding of phase-shifting isolation transformer, the transformer can supply power to power units. The power units are placed in three lines in the cabinet, with the units of the same line in series connection forming A/B/C 3-phase. A1/B1/C1 power units are connected in "Y" shape, and the power unit at the end of the cascade connection is the medium voltage point of A, B and C phases. At this medium voltage point, connect to the output terminal copper bar of the transformer cabinet through the medium voltage cables for external medium voltage output.

By the connection of the optical fiber and main control system, the main control system realizes control and protection on power units.

#### 3.2.3 Control cabinet

As the brain of the system, the control cabinet has the functions of command, control and self-protection. It is used to install the main control system, secondary control circuit system, and so on. The internal layout of the control cabinet is shown in Figure 3-13.

#### Figure 3-13 Layout in the control cabinet

See.	-
*C-17 1111	
3 × #	
IN VOIL	
Tarter (Maria)	
10 THE (STON & W)	
FINE IN 1 (FIFE	
[]	
A STORE	
L	
	-

Goodrive5000 variable-frequency speed regulation system use independent control cabinets which are isolated from the medium voltage section of transformer cabinet, power unit cabinet by optical fiber, isolation transformer and special grounding.

There are 3 power supplies for the control system: main power supply, backup power supply and UPS power supply (optional). When the main supply fails, the system will switch into backup power supply automatically; when both the main and backup power supplies fail, the system will switch to the UPS power supply. When a power supply encounters a fault, the system will report an alarm to ensure stable operation in bad power conditions.

Goodrive5000 variable-frequency speed regulation system provides with indicators, buttons, alarm and HMI installed on the door of the control cabinet for convenient operation and monitoring. Its layout is shown in Figure 3-14.



#### Figure 3-14 Layout of control cabinet door

Fault indicator: It indicates whether the system is in fault or alarm state. If a fault occurred, the fault indicator is on.

Running indicator: It indicates whether the system is in running state. If the system is in running state, the indicator is on.

Ready indicator: It indicates whether the system is in standby or ready state. If the system does not run and no fault is in detection after power-on, the indicator is on.

Emergency stop button: If the main control board is damaged or cannot be controlled normally, users can push the emergency stop button; by the physical circuit disconnection, damage will be minimized.



- Power on only after disconnecting medium voltage by loosening the emergency stop button with rotation.
- When the switching cabinet is under power frequency, the emergency stop button is invalid. Disconnect medium voltage by directly powering off the higher level or sending the command of disconnecting medium voltage to the system.
- When under manual switching, the emergency stop button can only control higher level medium voltage breaker or contactor. Connect the knife switch in series in the switching cabinet to higher level control circuit.

#### 3.2.4 Bypass cabinet

In industrial applications, it is necessary to configure the switching cabinet with the medium voltage variable-frequency speed regulation system. Goodrive5000 medium voltage variable-frequency speed regulation system provides standard manual bypass cabinets and automatic bypass cabinets with isolation for choice. The system provides different combinations of bypass cabinets to meet different application requirements.

The bypass cabinets are used to make the equipment run at power frequency if the system has a fault, thereby ensuring the continuity of the production and improving the reliability of the system. According to production process requirements of users, the manual bypass cabinet or automatic bypass cabinet can be selected. When the system stops for a short time according to production process requirements, operators can switch between the variable frequency and the power frequency under power failure by using the manual bypass cabinet. The main circuit diagram of the manual bypass cabinet is shown in Figure 3-15.



Figure 3-15 Main circuit diagram of the manual bypass cabinet

When the system is not allowed to stop, the automatic bypass cabinet will switch automatically. The cabinet has three medium voltage vacuum contactors KM1, KM2 and KM3, among which KM2 and KM3 realize electric interlock to ensure the power frequency supply will not be directly connected to the output terminal of the variable-frequency speed regulation system.

The automatic bypass cabinet with isolation also has two isolation knife switches QS1 and QS2 to isolate the variable-frequency speed regulation system from medium voltage power supply when the motor runs at power frequency, convenient for maintenance and inspection. The main circuit diagram of automatic

bypass cabinet with isolation is shown in Figure 3-16.

Figure 3-16 Main circuit diagram of the automatic bypass cabinet



With bypass cabinets, users' power cables (power incoming cable and motor outgoing cable) usually feed in at the bottom of the cabinets; while the power cable, between the bypass cabinet and the variable-frequency speed regulation system, adopts special medium voltage cable and lays out in the cabinet.




## 3.2.5 Power unit

The power units, the converting part of the medium voltage variable-frequency speed regulation system, achieve medium-low-medium voltage shifting of the system by connection in series.

When installing the power units, put them on the brackets, next push the units inside till close to the air duct baffle, then fix them with screws. Connect corresponding input cables and series copper bars, and finally plug corresponding optical fiber cables in.

When removing the power units, follow the requirements and procedures of relevant medium voltage maintenance. First, unplug the optical fiber cables, then remove input cables and series copper bars. Next, twist off the screws on the power units, and finally remove the power units from the brackets. The appearance of the power unit is shown in Figure 3-17.

Figure 3-17Figure 3-17.







# 3.3 HMI

# 3.3.1 Interface introduction

The product is equipped with a 7-inch touch screen, which can be used to set the system functions, monitor the working status information, and view the running logs.

The specific functional block diagram is shown as Figure 3-18.





The touch screen operation interface is designed with corresponding operation windows, and the corresponding sub-interface pops up after clicking the operation window. The sub-interface is also designed with operation buttons (level-2 interface) that allow users to set or read parameters in the corresponding interface according to their usage needs.

# 3.3.2 Login interface

After the control system powers on or users exit the main interface, the login interface will be displayed on the touch screen as shown in Figure 3-19. Users can choose to log in based on permissions.

Figure 3-19 Login interface of the touch screen				
INVT GD5000 HV-VF Speed Regulation System				
UserName: Operator × Password: Login				
el:400-700-9997 http://www.invt.com.en Version:3.05 Config:3.05				

We have three categories of login permissions based on application requirements.

Operator: for who will not configure the system and only start or stop the variable-frequency speed regulation system.

Administrator: for technical leaders who can configure and operate the system.

Manufacturer: for personnel who manufacture the system.

Table 3-6 Limited rights in different regions for different operators

Area Operator		Administrator	Manufacturer
Data display	Allow view	Allow view	Allow view
State display	Allow view	Allow view	Allow view
Start/stop control	Allow operation	Allow operation	Allow operation
Expansion command	Allow operation	Allow operation	Allow operation
Parameter setting	Prohibit viewing	Allow operation	Allow operation
Instant information	Allow view	Allow view	Allow view
Running log	Allow view	Allow view	Allow view
Data monitoring	Allow view	Allow view	Allow view

# 3.3.3 Main interface

#### Figure 3-20 Touch screen main interface diagram



No.	Area	Keys an	d contents	Definition	
	State			The system is in the working state.	
1	dicplay	System state		Control command channel	
	uispiay			The unit is in the bypass state.	
		Fragua	novcotting	Set frequency of the variable-frequency speed regulation	
		Freque	ncy setting	system.	
		Dunnin	fraguancy	Actual running frequency of the variable-frequency speed	
		Runnin	girequency	regulation system.	
2	Data	Innu	tvoltago	Input voltage of the variable-frequency speed regulation	
2	display	inpu	tvollage	system.	
		Outou	ut voltago	Output voltage of the variable-frequency speed regulation	
		Output volt		system.	
		Pupping current	Output current of the variable-frequency speed regulation		
		Kunning cu		system.	
		Startup		Under the local command channel, push the button to	
				send forward running command to the system.	
	Start/stop		Coast to	Under any command channel, push the button to coast to	
3	control	Stop	stop	stop.	
	Control	Stop	Decelerate	Under any command channel, push the button to	
			to stop	decelerate to stop.	
		Reset		Fault reset by manual	
			Command		Level-2 interface—Switching cabinet operation page of the
	Command expar			system	
		Parame	eter setting	Level-2 interface—Function code interface of the system	
				Level-2 interface—It displays running parameters, unit	
	Eunction	Instant	nformation	information, user terminals, and system terminal status of	
4	buttons			the system.	
	Duttons	Dup	ninglog	Level-2 interface—It displays running records, operation	
		Kuli	ning log	records, alarm records, and fault record data of the system.	
		Data n	onitoring	Level-2 interface—Data monitoring interface, displayed in	
		Datali	onitoring	the form of waveform curves.	
			Exit	Return to the login page.	

The above diagram shows the main interface of the touch screen, whose main interface is divided into the following areas.

# 3.3.4 Level-2 interface

## 3.3.4.1 Command expansion level-2 interface

The interface mainly shows the switching cabinet operations of the system. The diagram is shown as Figure 3-21.



No.	Area	Keys and contents	Definition	
		Forward	Under the local command channel, push the button to send	
		jogging	forward jogging command to the system.	
	Running	Reverse	Under the local command channel, push the button to send	
1	control	jogging	reverse jogging command to the system.	
	(Expansion)	Reverse running	Under the local command channel, push the button to send reverse running command to the system.	
	Switching cabinet 1	Variable frequency	The motor is in variable-frequency run mode.	
2		Power frequency	The motor is in power-frequency run mode.	
		Cut off	Cuts off the input medium voltage power of the specified	
		medium	motor, and the running mode of other motors is not	
		voltage	affected.	
	State	Switch state	Displays the status of isolation knife switches and vacuum	
3	display of	Switch state	contactors in the switching cabinet.	
5	switching cabinet	Present state	Used to display working state of present switching cabinet.	

#### **3.3.4.2** Parameter setting level-2 interface

The function groups in the following figure need to be set. You can press the corresponding buttons to pop up the function code group setting interfaces for the corresponding functions, and you can press the back button to return to the previous interface.

GD5000 Series HV VF Speed Regulation System 2023-08-23 09:33:08					
P0:	P1:	P2:	P3:		
Basic Fune	Start/stop Ctrl	MotorParam 1	Vector Ctrl		
P4:	P5:	P6:	P7:		
V/F control	Input terminals	Output terminals	HMI		
P8:	P9:	P10:	P11:		
Enhanced Func	FltRec	PID Ctrl	Mul-stepSpCtrl		
P12:	P13:	P14:	P15:		
Master/slave ctrl	Protection Param	SM ctrl	SwtCabinet Ctrl		
P16:	P17:	P18:	P19:		
SeriesComm	Ethernet Comm	Fieldbus Comm	MotorParam 2		
1/2 NextPage Back					

#### Figure 3-22 Parameter setting level-2 interface diagram

You can press the instant information button to pop up the level-2 interface. The level-2 interface mainly displays the running parameters, unit information, user terminals, and system terminals of the system.

nParam	Name	NumerVal	Name	NumerVal
	RefFreq	0.00Hz	UserOutpTrml1	000000000000000000000000000000000000000
	RunFreq	0.00Hz	UserOutpTrml2	0000000
Info	Torq	0.0%	SysInpTrml	00000000000
	OutpVolt	0V	SysOutpTrml	0000000
	InpVolt	0V	OutpPwrFactor	0.0%
	OutpCur	0.0A	InpPwrFactor	0.0%
	InpCur	0.0A	InpCurActiveComp	0.0A
	OutpPwr	0.0%	InpCurReactiveComp	0.0A
	InpPwr	0.0%	OutpCurActiveComp	0.0A
	UserInpTrml	00000000000	OutpCurReactiveComp	0.0A

#### Figure 3-23 Running parameters

#### Figure 3-24 Unit information

GD5000 Series HV VF Speed Regulation System 2023-08-23 09:34:19							
RunParam	No.	Ver. MCU	Ver. FPGA	BusVolt	Temp	Fault	Bypass
UnitInfo							
UserTrml							
SysTrml							
1/3	Un	it State	<b>3yPFault</b>		NextP	age	Back

invt gd50	00 Sei	ries HV VF Speed Reg	gulation	ı Syst	em 2023-08-	-23 09:34:34
RunDaram	No.	Name	State	No.	Name	State
	S01	0:Invalid	0	S11	0:Invalid	0
	S02	0:Invalid	0	S12	0:Invalid	0
TUNT	S03	0:Invalid	0			
Unitinio	S04	0:Invalid	0			
	<b>S</b> 05	0:Invalid	0			
	S06	0:Invalid	0			
UserTrml	S07	0:Invalid	0			
	S08	0:Invalid	0			
	S09	0:Invalid	0			
SysTrml	S10	0:Invalid	0			
1/3					NextPage	Back

#### Figure 3-25 User terminals

Figure 3-26 System terminals

RunParam	No.	Name	State	No.	Name	Stat
	SI01	Cust 380VPwrState	0			
	SI02	VFD 380VPwrState	0			
<b>T</b> UT 0	SI03	DoorAccessState	0			
UnitInfo	SI04	CabTopFan RunState	0			
	SI05	Buffer Contactor Status	0			
	SI06	0:Remote;1:LocalTrml	0			
UserTrml	SI07	CabTopFan FaultStatus	0			
	S108	Emergency stop signal status	0			
	SI09	Temp.controller alarm status	0			
SysTrml	SI10	Temp.controller fault status	0			

No.	Area	Keys and contents	Definition					
		Reference frequency	Set frequency of the system.					
		Running frequency	Actual running frequency of the system.					
		Torquo	Displays the ratio of the system output torque to the					
		Torque	rated torque.					
		Output voltage	Output voltage of the system.					
	Running parameters	Running	Running				Input voltage	Input voltage of the system.
1				Output current	Output current of the system.			
T		Input current	Input current of the system.					
			Output power	Displays the ratio of the output motor power to the				
		Output power	rated motor power.					
		Input power	Displays the ratio of the input motor power to the					
		input power	rated motor power.					
		User input terminal	0/1 corresponds to the user input terminal in the					
		User input terminal	open/closed state					

No.	Area	Keys and contents	Definition
			0/1 corresponds to user output terminal 1 in the
		User output terminal 1	open/closed state.
			0/1 corresponds to user output terminal 2 in the
		User output terminal 2	open/closed state.
			0/1 corresponds to system input terminal in the
		System input terminal	open/closed state.
			0/1 corresponds to system output terminal in the
		System output terminal	open/closed state
		Output power factor	Size of output power factor
			Size of input power factor
		component	Magnitude of input current active current
			Magnitude of input current reactive current
		Output current active	Magnitude of output current active current
		component	
		Output current reactive	Magnitude of output current reactive current
		component	
		U-phase bus voltage	Magnitude of U-phase DC bus voltage
		V-phase bus voltage	Magnitude of V-phase DC bus voltage
		W-phase bus voltage	Magnitude of w-phase DC bus voltage
			Primary side A phase temperature value of the
		tomporaturo	transformer
			Primany-side B-phase temperature value of the
		temperature	transformer
		Transformer C-phase	Primary-side C-phase temperature value of the
		temperature	transformer
		Transformer a-phase	Secondary-side a-phase temperature value of the
		temperature	transformer
		Transformer b-phase	Secondary-side b-phase temperature value of the
		temperature	transformer
		Transformer c-phase	Secondary-side c-phase temperature value of the
		temperature	transformer
		Corresponding value of Al1	Corresponding input voltage or current percentage of Al1
		Corresponding value of Al2	Corresponding input voltage or current percentage of AI2
		Corresponding value of AI3	Corresponding input voltage or current percentage of AI3
		Corresponding value of AI4	Corresponding input voltage percentage of AI4
		Corresponding value of AO1	Corresponding output function percentage of AO1
		Corresponding value of AO2	Corresponding output function percentage of AO2
		Corresponding value of AO3	Corresponding output function percentage of AO3
		Corresponding value of AO4	Corresponding output function percentage of AO4
		Corresponding value of AO5	Corresponding output function percentage of AO5
		PID reference	Percentage of PID reference
		PID feedback	Percentage of PID feedback
		Motor temperature 1	Displays the temperature of motor channel 1

No.	Area	Area Keys and contents Definition		
		Motor temperature 2	Displays the temperature of motor channel 2	
		Motor temperature 3	Displays the temperature of motor channel 3	
		Motor temperature 4	Displays the temperature of motor channel 4	
		Motor temperature 5	Displays the temperature of motor channel 5	
		Motor vibration 1	Displays the vibration amplitude of motor channel 1	
		Motor vibration 2	Displays the vibration amplitude of motor channel 2	
		Motor vibration 3	Displays the vibration amplitude of motor channel 3	
		Motor vibration 4	Displays the vibration amplitude of motor channel 4	
		Motor vibration 5	Displays the vibration amplitude of motor channel 5	
		Power consumption per second	Power consumption per second	
		Total power consumption	Total power consumption	
2	Unit parameters	This interface mainly displays the information of each unit of the syste		
		No.	Displays the number of the user terminal	
3	User terminals	Terminal function	Displays the terminal functions set by function codes, which can be changed.	
		Status	Displays corresponding state of user terminal: 0 or 1	
		No.	Displays the number of input and output terminals	
			Displays corresponding function setting of each	
4	System	Terminal function	terminal, which cannot be changed.	
	terminal	Status	Displays corresponding state of system terminal: 0 or 1	

## 3.3.4.3 Running log level-2 interface

You can press the Run button to pop up the interface. It mainly displays running records, operation records, alarm records, and fault records of the system.



Figure 3-27 Running records

**INVE** GD5000 Series HV VF Speed Regulation System 2023-08-23 09:35:30 QueryMonth 2023-08 RunRec OpsChanl Storage time OpsItems 🔨 OpsRec AlmRec V FltRec < > PrevPage ExpRecord NextPage

#### Figure 3-28 Running records

Figure 3-29 Alarm records



#### Figure 3-30 Fault records



#### 3.3.4.4 Data monitoring level-2 interface

The data monitoring interface mainly records the data status when the system is running, and plotting it as a graph to to be displayed on the oscilloscope. The default monitoring parameters are input voltage, output voltage, input current, output current, reference frequency and running frequency. You can click the parameter name at the left column to change the parameters to be monitored, and click the curve column to hide the parameter curve. You can choose whether to use this function or not by using the "Disable" button. Ymax and Ymin in the bottom left corner can be used to set the curve coordinates, and the "ExpRecord" buttoncan be used to export parameters records for 5 days.



Figure 3-31 Data monitoring interface

## 3.3.5 Level-3 interface

The level-2 interface function code group popped up by pressing the parameter setting button can generate level-3 interfaces, and the following briefly introduces the content of the level-3 interface.

#### 3.3.5.1 Function code group level-3 interface

The main interface displays the value and state of each function code which can be modified or set by users. The white edit box indicates the item is modifiable while the grey box indicates the item is read-only.

V VF Speed Regulation Syste	em 2023-08-23 09:33:27
01 Run Cmd Channel	02 PresCommCmd Channel
unknown	unknown
04 UP/DOWN adjustment	05 Speed Ref Mode
unknown	unknown
07 B FreqCmd	08 B FreqCmdRefObject
unknown	unknown
10 Max Output Freq unknown	11 RunFreq Up limit unknown
13 FuncCode SetFreq	14 TorqSet
unknown	unknown
NextGroup	NextPage Back
	V VF Speed Regulation Syste 01 Run Cmd Channel Unknown 04 UP/DOWN adjustment Unknown 07 B FreqCmd Unknown 10 Max Output Freq Unknown 13 FuncCode SetFreq Unknown NextGroup

Figure 3-32 Level 3 interface for setting parameters

#### 3.3.5.2 Editing bar level-3 interface

Figure 3-33 Editing bar setting interface diagram

Func Code:	×
Group:	P0.00 CtrlMode
Unit:	DeviceVal:0
Range:	0~0 Pres: 0
Modify:	Changeable at any time
OK	Cancel

# 3.3.6 Other interfaces

#### 3.3.6.1 Soft keypad

The input of the touch screen software depends on the soft keypad. After clicking the keypad, the following interface will pop up. Users can click the corresponding value to complete the setting.



Figure 3-34 Soft keypad

#### 3.3.6.2 Unit bypass state display

The bypass state interface can be accessed from the unit information interface of **Instant information**, which allows you to view the states of all units. Determine whether the units are in bypass state, and configure the bypass state of the units in this interface.



#### 3.3.6.3 Extras menu on main interface

**Note:** On login interface, clicking on the hidden buttons in the top left and top right corners in sequence three times will pop up extras menu options.

Figure 3-36 Extr	as menu on login interiace	
	Language	
Cha	nge and Check IP	
C	hange Password	
1	Delete Record	
		Back

## Figure 3-36 Extras menu on login interface

#### 1. Language and logo

Click the button to pop up a options menu, you can choose language type and logo of the touch screen according to the application needs. Restart the touch screen after the selection is complete, and the system automatically changes the language environment to the set language type.

Please confirm!	<b>X</b>
Chinese	English

#### 2. IP view and change

You can view and modify the IP of the touch screen, IP of the system, subnet mask, gateway, MAC. The communication between the touch screen and the system is completed through the configuration mode. When the system is connected to multiple touch screens, it is necessary to modify the IP data of the touch screen, and ensure that the IP value of the touch screen and the IP value of the system are in the same network segment. Generally, the IP value of the touch screen and the system is set to be in 192.168.1.\* network segment.

**Note:** Turn the DIP switch of the control board to the configuration mode state before viewing the configuration mode, and view the valid information after setting the DIP switch information correctly.

0	
HMI IP	0.0.0.0
GD5000 IP	192.168.1.2
GD5000 Mask	0.0.0.0
GD5000 Gateway	0.0.0.0
GD5000 MAC	0.0.0.0.0
IP configuration: 1. Change the GD5000 IP to 192.168.105.2, and also modify the HMI IP to the same network segment 192.168.105.222,Click on the 'Save' button. 2. Power off, dials SW3 and SW4 to ON. When powered on again, the touch screen and the main control system enter configuration mode for communication. 3. Modify the GD5000 Para to the user's required address (HMI IP remains) and click the 'Save'' button 4. Power off, dials SW3 and SW4 to OFF.Power on again, modify GD5000 IP and HMI IP to meet user requirements. Click 'Save' to complete the IP modification.	
Si	ave Back

Figure 3-37 Interface of configuration mode

#### 3. Modify password

Click the button to pop up a options menu, you can change login password of the operator or administrator according to the application needs.

User	v
Old Password	
New Password	
Confirm Password	
	Reset Password
ОК	Back

#### 4. Delete records

Click the button to enter the interface to delete the relevant content recorded in the touch screen system. This function will clear the recorded data and information. Exercise caution when using this function.

rigure 5 50 Detete records interface and	Brunn
Delete Running Record Alarm Record	
Delete Operation Record Fault Record	
Delete waveform records	
Delete All Record	
	Back

Figure 3-38 Delete records interface diagram

# **4 Installation and wiring**

GD5000 series medium voltage variable-frequency speed regulation system needs to be installed in a suitable location and space for different working conditions. You must conduct plant layout and construction according to the foundation drawings and installation requirements provided by the manufacturer.

# 4.1 Installation conditions

## **4.1.1 Environment requirement**

1. Regarding the installation environment of the equipment, you shall observe the requirements in the following table.

Item	Content		
Ambient	Within the range of -10°C–40°C. Preheating is needed when the temperature is		
temperature	below 0°C. Derating is needed when the temperature is above 40°C. The average		
	Value of 24 hours shall be in the range of 3	5°C-35°C.	
Relative	The relative humidity shall be less than 5	0% when the max. temperature is 40°C.	
humidity	The relative humidity cannot exceed 80%	at low temperature.	
nannarty	No condensation occurs.		
	Below 1000m. Derating is needed when t	he altitude is higher than 1000m. (When	
Altitude	the altitude exceeds 1000m, please inform the manufacturer in advance before		
	ordering.)		
Air pressure	Within the range of 860–1060kpa.		
Air quality	The dusts in the electrical room shall be roughly equal to atmospheric dusts,		
All quality	especially not containing iron powder, silicone particles, etc.		
	Corrosive gas	Concentration	
	Hydrogen sulfide (H <sub>2</sub> S)	≪0.001ppm	
	Sulfur dioxide (SO <sub>2</sub> )	≪0.05ppm	
Corrosion	Chlorine (Cl <sub>2</sub> )	≤0.1ppm	
factors	Ammonia (NH₃)	≤0.1ppm	
	Nitrogen oxide (NO <sub>x</sub> )	≪0.02ppm	
	Ozone (O <sub>3</sub> )	≤0.002ppm	
	hydrogen chloride (HCl)	$\leq 0.1 \text{mg/m}^3$	

Table 4-1	Installation	environmen	t of the e	auipment
T C C T I	motattation	cite in orinine in		quipinent

2. Regarding the storage environment of the equipment, you shall observe the requirements in the following table.

ltem	Con	tent
Relative	-40–+70°C, with the air temperature	Do not put it in the place with
temperature	change rate less than 1°C/min.	Do not put it in the place with
Relative	Loss than 05%	condensation of freeze caused by rapid
humidity	Less than 95%	changes of temperature.
Storage	Without direct sunlight, dust, corrosive g	as, combustible gas, oil mist, steam, and
environment	dripping water.	

**Note:** Improper storage of power electronic equipment can affect the service life of the equipment or even cause the equipment to be inoperable. Reference standards for storage environment conditions: IEC61800-4 (GB12668.4-2006), UDC 621.3:658.78, GB4798.1-88.

General requirements:

- A. Do not place it directly on the ground; place it on appropriate supporting objects.
- B. If there is any impact of humidity, appropriate desiccating agent shall be provided: each unit of desiccating agent (30g) absorbs 6g water content. According to the packaging materials in use, you will need the desiccating agent of the following amounts: Polyethylene metal film: 10 units per square meter; aluminum metal film: 8 units per square meter.
- C. Taking polyethylene materials or aluminum metal film as the protective packaging can prevent the water content from infiltrating.
- D. Regular inspection: During the whole storage period, inspect the storage state and packaging state of the equipment every month. If the equipment has been damaged, you need to check the damage immediately and find out the reason. After repairing the damaged equipment, store the system according to the requirements mentioned above.
- 3. To ensure the spare parts are not damaged, you shall observe the following matters during the storage of spare parts.

After receiving Goodrive5000 series medium voltage variable-frequency speed regulation system, check immediately whether there is any damage to the spare parts, and if any damage to the spare parts is found, please report it to us. We will not undertake any product quality guarantee responsibility for the damage caused by external shock or external environment within the product quality guarantee period. Within the quality guarantee period, to prevent the equipment spare parts from damage, please pay attention to following items.



- There must be no vibration or impact at the storage place, and it is necessary to avoid damage caused by moisture, frost, temperature, dust and gravels.
- The environment conditions shall meet the requirements of temperature and humidity: The spare parts must be stored in a dry original packaging box without flying insects, and kept away from corrosive gas.
- The relative humidity shall be less than 95%, and the storage temperature for the spare parts shall be -5°C -+55°C.
- The circuit boards must be stored in anti-static packing bags without leakage of desiccant agent, and kept away from corrosive gas that may cause damage to the circuit boards or gases containing alkali-saline or other impurities, and they must not be frozen.
- The power unit is equipped with electrolytic capacitors inside, long-term power off of
  electrolytic capacitors will lead to the deterioration of their electrical characteristics; therefore,
  store them in the method of electrifying once every year.
- If you find that the humidity has surpassed the maximum allowable extent in the air, environmental protection measures such as cooling, heating, dehumidifying and other methods shall be taken to guarantee the environment conditions for storing the spare parts.

# 4.1.2 Installation dimension requirements

Please refer to the relevant drawings in the engineering technical data for the cabinet size, outline

dimensions and base plate installation diagrams of the variable-frequency speed regulation system. All cabinets need to be installed according to the drawings. Sufficient clearances need to be reserved to ensure the space for air flow, max. door swing, and maintenance. Please provide access to the installation base (such as aisle spacing) and ensure that space is reserved for auxiliary equipment for transporting the variable-frequency speed regulation system.





Figure 4-2 Schematic diagram 2 of installation requirements (side view, unit: mm)



Figure 4-3 Schematic diagram 3 of double-row installation requirements (side view, unit: mm)



#### Table 4-2 Installation space dimensions

Min. width of surrounding passage of the medium voltage variable-frequency speed		
regulation system		
Layout manner	Maintenance channel	Operation channel
Dual-line layout	0.6m	2.0m/1.5m
Single-line layout	0.6m	1.5m

# 4.1.3 Dissipation guidance

The cooling air duct of the variable-frequency speed regulation system is shown in Figure 4-4. To guarantee sufficient cooling, the distance between the top of the system and the roof must comply with the requirements of relevant national regulations. To reduce ambient temperature further, you can install centralized ventilation air ducts for transmitting the hot air through centrifugal blower and directly to the outside by the air ducts.







# 4.1.4 Foundation and channel design

The cabinets of Goodrive5000 medium voltage variable-frequency speed regulation system must be vertically installed onto the concrete casting foundation framework made of flat steel channels, with the overall roughness of the surface below 5mm. The foundation must be made of non-combustible materials and have smooth and abrasion-free surface, and shall be moisture-proof and able to bear the weight of the system. The cable ducts must be made of non-combustible materials and have smooth and abrasion-free surface, with measures preventing animals from entering.



Figure 4-5 Schematic diagram of foundation installation



# 4.1.5 Cabinet installation

The system is directly welded onto foundation steel channels, and the wiring inside the cabinets shall be performed under the guidance of our professionals.



The following installation guidelines are applicable to the general installation in industrial environment. In special environment, please make inquiry to us for detailed installation procedures.

- 1. Before mechanical installation, please be sure to meet all environment conditions described above.
- Examine the basic level with level instruments. The allowable maximum overall roughness is less than 5mm. If the ground surface is not flat, it may cause cabinet distortion and cabinet doors cannot be opened or closed smoothly.
- 3. Move to the installation position. Please refer to the requirements of moving.
- 4. Open all cabinet doors, and carefully inspect possible transportation damage to the system and the attached devices. If any part is damaged or missing, please immediately contact the technical service department of our company and the logistics company. Please note the opening methods of cabinet doors.
- 5. Check whether the cabinet doors can be fully opened or closed; if not, the cabinet need to be adjusted. Examine the position-restraint locks on the doors: after power on, aside from the doors of the main control cabinets, no other front doors and back doors can be opened. The illegal opening of cabinet doors will trigger the alarm.
- 6. Perform the wiring inside the cabinet under the guidance of our professionals.

**Note:** Please pay attention to the opening methods of cabinet doors. Forced opening of cabinet doors is forbidden; otherwise, the equipment will be damaged.

# 4.2 Mechanical wiring

## 4.2.1 Transportation and moving

The outer packaging of Goodrive5000 medium voltage variable-frequency speed regulation system can endure the external impact from the sea, land or air transportation, but appropriate protection measures must be taken to avoid the pollution of water immersion and dust. Besides, during the process of transportation, it is necessary to avoid the impact caused by mechanical shocks, damage and rough handling.

To move, disassemble and store properly, please pay attention to all relevant precautions and indication and instruction tags on the packaging boxes. We recommend entrusting logistic companies with a good reputation and credit to lift and transport the medium voltage variable-frequency speed regulation system.

#### 4.2.1.1 Transportation

Goodrive5000 medium voltage variable-frequency speed regulation system can be transported by any vehicles such as trucks, trains, airplanes and ships. During transportation, the products must be handled with care. Exposure to rain and sunlight are both strictly forbidden. No severe vibration, impact, inclination or upend is allowed.

#### 4.2.1.2 Moving

The variable-frequency speed regulation equipment can be transported in two ways after packing, namely forklifts and cranes.

Method 1: Forklifts

When using a forklift, you need to confirm that the bearing weight of the forklift must be more than 10 tons, the relieved tooth shall be at least 2.0m long and its thickness shall not be larger than 90mm. The relieved tooth must be adjustable from 600mm to 1200mm.



## ∠Note:

7777

- Do not pick up the cargo with the forklift at high speed.
- When picking up the cargo with the forklift, it is necessary to adjust the fork tine spacing (the center of gravity is between fork tines) as needed to make the load of two fork tines balanced.
- The entry depth of the fork tines shall touch all the sleepers at the bottom of the box, first tilt the gantry back to make the cargo close to the fork arms, then lift it up.
- During the process of cargo lifting or landing, the forklift shall keep the horizontal direction and unmoved.
- The bottom end of fork tines shall be kept at a distance of 15-40cm from the ground or car surface before moving horizontally.
- When the forklift is operating, people are forbidden to stand here to avoid accidental injury.

• When there are people around, it is necessary to whistle to notify them before leaving the ground or the car surface slowly.

#### Method 2: Cranes

During hoisting, use lifting slings instead of wire ropes. The hooks of the lifting slings must be hooked to the lifting position on the steel channels, and the distance between the top hook position and the cabinet must meet the minimum distance specified, as shown in Figure 4-7.

Figure 4-7 Hoisting of system components with packages (unit: mm)



The system can also be transported in two ways after removal from the wooden box, cranes or chain hoisting and rolling bars.

Method 1: Cranes or chain hoisting



#### Method 2: Rolling bars

It is the simplest method. Put parallel rolling bars on the floor to move the cabinet and move the rolling bars

in cycle. (The length of the rolling bar shall exceed the thickness of the cabinet, the diameter shall not be smaller than 50mm and the space between the rolling bars shall not be larger than 500mm.)



Figure 4-9 Moving with rolling bars

# 4.2.2 Unpacking inspection

After receiving the medium voltage variable-frequency speed regulation system that you ordered, please conduct unpacking check according to the following requirement. if there is anything wrong with the products you ordered or they do not comply with the specifications that you ordered, please contact the agent from whom you order the equipment or contact the nearest office of our company.

- 1. Check the nameplate of the medium voltage variable-frequency speed regulation system and confirm the models and specifications of the equipment you ordered.
- 2. Check whether any damage has occurred on the appearance during handling and transportation, such as damage to the cabinet appearance, any distortion to the door and sideboards and inner devices falling off, etc.
- 3. Open the cabinet door and check whether the control cables are loose and there is water immersion, missing or damaged parts.
- 4. By contrast of the supply list, check whether the equipment that you ordered is complete.

# 4.2.3 Positioning and fixing



- Ensure that various kinds of fibers, paper scraps, sawdust, metal fragments and other foreign materials do not enter into the cabinets or adhere to the radiators; otherwise, it may cause accidents or fire.
- Install onto the non-combustible structure made of basic steel channels; otherwise, it may cause fire.

The medium voltage variable-frequency speed regulation system is composed of one or more than three cabinets (depending on power size, layout mode and optional parts). According to the requirements, a single cabinet or multiple cabinets can be placed upon the foundation steel channels vertically using traveling cranes or forklifts. The cabinet bodies shall be assembled, connected, positioned and aligned, then shall be directly welded onto foundation steel channels, the wiring inside the cabinets and between the cabinets shall be installed under the guidance of the professionals from our company. In some cases, the power units shall be separately packaged for transportation, and they are installed into the power unit cabinets under the guidance of the professionals from our company after arriving.

The following installation guidelines are applicable to the general installation in industrial environment. In

special environment, please make inquiry to us for detailed installation procedures.

- 1. Before mechanical installation, please be sure to meet all environment conditions described above.
- 2. Examine the basic level with level instruments. The allowable maximum overall roughness is less than 5mm. If the ground surface is not flat, it may cause cabinet distortion and cabinet doors cannot be opened or closed normally.
- 3. Move to the installation position. Please refer to the requirements of moving.
- 4. Open all cabinet doors, and carefully inspect possible transportation damage to the system and the attached devices. If any part is damaged or missing, please immediately contact our technical service department and the logistics company. Please note the opening methods of cabinet doors.
- 5. Check whether the cabinet doors can be fully opened or closed; if not, the cabinet bodies need to be adjusted. Examine the position-restraint locks on the doors: after power on, aside from the doors of the main control cabinets, no other front doors and back doors can be opened. The illegal opening of cabinet doors will trigger the alarm.
- 6. Perform the fine adjustment of the cabinets, and fix the adjacent cabinets tightly with binding bolts.
- 7. Connect the wiring inside the cabinets, install and fix the power units under the guidance of the professionals of our company.

**Note:** The phase-shifting transformer cabinet must be installed separately. Please pay attention to the opening methods of cabinet doors. Forced opening of cabinet doors is forbidden; otherwise, the equipment will be damaged.

## 4.2.4 What to do after scrapping



• When the package or product is scrapped, deal with it as industrial effluent; otherwise, injuries or environment pollution may occur.

The package of Goodrive5000 integrated machine medium voltage variable-frequency speed regulation system shall be designed with the minimum usage of the packing materials that have adverse effects on the environment; some of the packing materials can be recycled and reused. The handling of the packing materials shall comply with the nation

nal standards related to environment protection.

While scrapping the devices inside the medium voltage variable-frequency speed regulation system, the electrolytic capacitors, PCBs, electronic components and other parts need to be dealt with correct methods so that any part may not cause harm to the surroundings. These handling methods can refer to the national laws and regulations on environment protection.

# 4.3 Electrical installation

## 4.3.1 Precautions



- All connectors must receive insulation treatment to ensure good insulation. The connecting
  positions must be kept clean and meet the requirement of corresponding cleanliness.
- Medium voltage electrical insulation distance must meet the requirements of electrical safety distance in order to avoid short circuit.

- 1. Ensure that the medium voltage incoming and outgoing cables match the control cable insulation and the voltage class of the variable-frequency equipment. Ensure that the medium voltage incoming and outgoing cables and the diameter of the control cables meet the load power requirements.
- 2. Ensure that the medium voltage incoming circuit breaker is in the switch-off state, and hang the work sign.
- 3. Ensure that the medium voltage incoming and outgoing cables must be wired separately to prevent mixed lines.
- 4. Ensure that the protective steel armor of medium voltage incoming and outgoing cables shall be reliably grounded, and the cables and the cabinets are reliably fixed.
- 5. Route the control signal cables separately from the electrical cables, and the analog signal cables must use shielded twisted pairs and one end of the shielded wires shall be reliably grounded.
- 6. Ensure that the system cabinets are reliably grounded.

# 4.3.2 Primary wiring

## 4.3.2.1 Incoming/outgoing and grounding method



• Do not exchange the wiring of I/O terminals; otherwise, the system and other devices may be damaged.

The primary wiring feeds in R, S, T terminals and feeds out U, V, W terminals in transformer cabinet. The copper bar at the bottom of the transformer cabinet will be connected to the grounding of transformer, unit cabinet and control cabinet, and user grounding grid after the system is installed.

**Note:** The terminals of control circuit in control cabinet shall be grounded seperately.

## 4.3.2.2 Standard requirements of medium voltage power distribution

	🛕 Danger
•	Connect I/O terminals properly; otherwise, the system may be damaged.

- Before the power is connected to Goodrive5000 integrated machine medium voltage variable-frequency speed regulation system, it needs to pass through the main circuit breaker which is allowed to close only after receiving the medium voltage closing allowing signal from the system.
- The power of main circuit breaker is directly connected to the input terminals of the variable-frequency speed regulation system in no need of passing through the input reactor.
- The variable-frequency output of the system is connected to the motor by the output terminals of switching cabinets.

## 4.3.2.3 The wiring of the system and switching cabinets

Terminal		Name	Description	Fastening torque requirements
laput	R	Main circuit power input, the 1 <sup>st</sup> phase sequence	Connect to 3PH medium voltage AC power, the <sup>1st</sup> phase sequence	M10: 25N.m
mput	S	Main circuit power input, the 2 <sup>nd</sup> phase sequence	Connect to 3PH medium voltage AC power, the 2 <sup>nd</sup> phase sequence	M12: 45N.III M16: 100N.m

#### Goodrive5000 series medium voltage variable-frequency speed regulation system

Terminal		Name	Description	Fastening torque requirements
	т	Main circuit power input, the 3 <sup>rd</sup> phase sequence	Connect to 3PH medium voltage AC power, the 3 <sup>rd</sup> phase sequence	
	U	Output of the medium voltage variable-frequency speed regulation system, the 1 <sup>st</sup> phase sequence	Connect to 3PH AC medium voltage motor, the 1 <sup>st</sup> phase sequence	
Output	V	Output of the medium voltage variable-frequency speed regulation system, the 2 <sup>nd</sup> phase sequence	Connect to 3PH AC medium voltage motor, the 2 <sup>nd</sup> phase sequence	
	w	Output of the medium voltage variable-frequency speed regulation system, the 3 <sup>rd</sup> phase sequence	Connect to 3PH AC medium voltage motor, the 3 <sup>rd</sup> phase sequence	

**Note:** The output phase sequence of U, V and W terminals may be different from that of R, S and T. When power frequency power bypass is a necessity, make sure input phase sequence is consistent with output phase sequence; otherwise, the system cannot work properly.

## 4.3.2.4 Layout of medium voltage cables

The layout of main power supply and motor cables must comply with national standards. Please refer to the instructions and suggestions of the manufacturer.

- 1. It is recommended to use 3PH armoring steel cables shielded individually. If 1PH cable is used, 3PH cables shall be combined with each other to ensure EMC.
- 2. According to requirements of the manufacturer, install collectors at the cable terminations.
- 3. Corresponding ground wire shall be grounded in compliance with national electrical standards.

## 4.3.2.5 Grounding

Ensure the ground wire with less than  $4\Omega$  ground resistance, use wires between the cabinet and door of the system, channel in base among cabinets, copper conductor cable with no less than  $50 \text{ mm}^2$  sectional area for the ground connection between the whole-set equipment and the grid. To guarantee equipment and personal safety, check the grounding before using.



- Before wiring, please confirm that the input power supply has been cut off. There is the risk of electric shock and fire.
- Electric engineering professionals are allowed to perform the wiring. There is the risk of electric shock and fire.
- Be sure to make reliable grounding of the cabinet. There is the risk of electric shock and fire.
- Please check whether the AC main circuit power supply is consistent with the rated voltage of the variable-frequency speed regulation system; otherwise, there will be risk of injury and fire hazard.
- Please use the screwdriver of designated torque to tighten the terminals; otherwise, there will be the risk of fire.

 Do not connect the input power supply to the output terminals U, V and W; otherwise, internal damage may occur to the variable-frequency speed regulation system.

## 4.3.3 Secondary wiring

Recommended cross section and specification of control power supply, signal and communication cables:

- 1. Control power input cable: Use multi-core flexible copper wires with a cross-sectional area of 0.5–4 mm<sup>2</sup> (depending on load, up to two wires per phase can be connected).
- 2. Analog input/output cables: Whole shielded twisted pair, cross section 0.5–1.5 mm<sup>2</sup>;
- 3. Digital input/output cables: Whole shielded twisted pair, cross section 0.5–1.5 mm<sup>2</sup>;
- 4. Communication cables: Select specialized communication according to relevant requirements, or whole shielded twisted pair, cross section 0.5–1.5 mm<sup>2</sup>;

## 4.3.4 User-provided accessories and wiring

#### 1. Main circuit breaker

The main circuit breaker can be vacuum breaker or air isolation circuit breaker which will meet not only the requirements of voltage and current of power supply, but also the requirements of primary side voltage and current of phase shifting transformer. Furthermore, it shall be capable of bearing current surge caused by switching on the transformer, and it will not trip after fault current caused by secondary side short circuit in 100ms.

#### 2. Input cable

There are no special requirements for the cables from the circuit breaker to the primary side of transformer. The rated voltage of the cables shall keep consistent with the voltage of the primary side circuit. The rated current shall satisfy the transformer and the set requirements for protection. On basis of the maximum ambient temperature, set the decreased capacity of the cables according to the cooling factors and local electrical regulations, and install it in accordance with the standards for medium voltage equipment.

#### 3. Output cable

There are no special requirements for the cables from Goodrive5000 series medium voltage variable frequency speed regulation system to the motor. It is recommended that the cable length to be no longer than 1000m, the case that the field cable length is longer than 1000m shall be indicated in the order.

The rated voltage of the cables shall keep consistent with the motor model, and the rated current shall comply with the motor model as well as allowable overload current requirements for motor protection. The decreased capacity of the cables shall refer to the maximum ambient temperature, cooling factors, and national electrical standards. The installation shall be in accordance with the standards for medium voltage equipment.

#### 4. Control power cables

The external redundant power supply of the system is AC 380V, it is recommended to use a multi-core soft copper wire higher than this voltage, according to the corresponding load current, transmitting the wires to the corresponding terminals of the control panel, and tighten the wires up.

## 4.3.5 General introduction to user terminals

Goodrive5000 medium voltage variable-frequency speed regulation system provides standard 12-channel digital inputs, 10-channel relay outputs, 4-channel analog inputs, and 6-channel analog outputs. All user terminals are programmable and they can be set by function codes. Simultaneously, the control terminals can be extended as required.

All user terminals are connected to the terminal blocks, so pay attention to connecting from the terminal blocks before using. The secondary wiring for users shall be conducted in the control cabinet. The wiring diagram of user terminals is shown as Figure 4-10.



Figure 4-10 Wiring diagram of user terminals

The descriptions of user terminals are as follows.

Category	Terminal	Function	Technical specifications		
	S1	Multi-function input 1	1.	Forming the optical coupler isolation input	
	S2	Multi-function input 2		with COM-1.	
Distal	S3	Multi-function input 3	2.	The input voltage can only be 24V provided	
Digital	S4	Multi-function input 4		by the system.	
Input	S5	Multi-function input 5	3.	The suspension of terminals will be regarded	
	S6	Multi-function input 6		as disconnected.	
	S7	Multi-function input 7	4.	Input impedance: 1kΩ	

Category Terminal Eulection Technical specifications					
Category	co	Multi function input 9			
	50	Multi-function input 8			
	59	Multi-function input 9			
	S10	Multi-function input 10			
	S11	Multi-function input 11			
	S12	Multi-function input 12			
		24V power supply			
		provided by the system,			
24V	+24V	which is only used for			
power		internal circuits and not			
supply		connected to the			
		outside.			
	COM-1	24V power GND			
101/	+10.51/	+10.5V power supply			
nowor	10.51	provided by the system.			
cupply		+10.5V power supply			
supply	GND-AI	ground	y al 1 1. Differential input al 2 2. For voltage input, voltage range 0-+10V; for current input, current range 4-20mA, 20r		
	AI1+/AI1-	Analog input terminal 1	1. Differential input		
	AI2+/AI2-	Analog input terminal 2	2. For voltage input, voltage range 0-+10V; for		
Analog input	AI3+/AI3-	Analog input terminal 3	<ul> <li>current input, current range 4–20mA, 20mA</li> <li>current corresponding to +10V.</li> <li>3. Input impedance: 20kΩ (voltage)/500Ω (current)</li> </ul>		
	AI4+/AI4-	Analog input terminal 4	<ol> <li>Differential input</li> <li>Voltage input range: -10V-+10V</li> <li>Voltage input resistance: 20kΩ</li> </ol>		
	A01	Analog output terminal	1. Outputting the voltage and current		
	AO2	Analog output terminal	<ol> <li>Output voltage range: 4-+10V, output</li> </ol>		
		2 Analog output terminal	3. For voltage output, allowable output		
Analog	AO3	3	impedance is ≥5kΩ. For current output, allowable output impedance is 100–500Ω.		
output	۵04	Analog output terminal	· · · · ·		
	704	4	1. Outputting the current corresponding to		
	AO5	Analog output terminal 5	GND-AO terminals. 2. Output current range: 4–20mA, allowable		
	AO6	Analog output terminal 6	output impedance: 100–500Ω		
	RO1	Relay output terminal 1			
	RO2	Relay output terminal 2			
	RO3	Relay output terminal 3	1. R01–R05: NO: R06–R010: NO/NC		
Relav	RO4	Relay output terminal 4	2. The current withstand capacity of RO1–RO5		
output	RO5	Relay output terminal 5	relays is 6A (resistive load) and that of RO6-		
	R06	Relay output terminal 6	RO10 relays is 3A (resistive load).		
	R07	Relay output terminal 7			
	RO8	Relay output terminal 8			

Category	Terminal	Function	Technical specifications
	RO9	Relay output terminal 9	
	RO10	Relay output terminal 10	

#### ∠Note:

- 1. Do not route the analog cables and input power cables in parallel.
- 2. Do not use the same line for the signal cables and input power cables.



- Installation of large current positions: to enable the variable-frequency speed regulation system to meet the technical properties, pay close attention to large current installation (All I/O terminals with more than 10A current flow shall be considered large current terminals). The key points are:
- Terminals shall use the materials with excellent conductive property, such as oxygen-free copper terminals, silver-plating or tin-plating fasteners and other connecting materials.
- All terminals shall be carefully cleaned with ethanol before connecting.
- Connections of all connectors shall be very reliable, the fasteners shall be tightened with wrenches, the important connectors shall be wrenched tight reliably with torque wrenches to ensure the contact resistance is less than 2mΩ.
- The fasteners of all large current connecting positions shall include spring washers which will be pressed flat after fastening.
- The current density of large current wires shall be appropriate to avoid heating and thus influence the device.

# **5** System commissioning and running

# **5.1 Commissioning flowchart**

This chapter mainly introduces the steps and contents required for commissioning the GD5000 series medium voltage variable-frequency speed regulation system, including the initial power-on inspection to the operation of the medium voltage motor, each step of which needs to be operated under the guidance of our professionals or after users have received relevant professional training. The function performance commissioning and parameter setting must be carried out in strict accordance with the relevant regulations and our operation manual. The commissioning process shall be carried out in accordance with Figure 5-1.



Figure 5-1 Schematic diagram of system commissioning procedures

# 5.2 Commissioning precautions



- Do not touch the terminals of the variable-frequency speed regulation system that is connected to the power because the terminals may be live even if they are in the stop state.
- Only trained and authorized personnel can operate the control cabinet although it has no medium voltage.
- The transformer cabinet, power unit cabinet, and bypass cabinet of the product are medium voltage danger areas, and the cabinet doors cannot be opened upon power-on.

Users must provide at least two professional electrical technicians as our on-site cooperation personnel during commissioning, who must meet the following conditions.

- 1. They are familiar with medium voltage electrical equipment and the corresponding safety norms.
- 2. They are familiar with the user's load transmission process and the control logic involved with our equipment.
- 3. They are authorized to operate the medium voltage equipment and transmission equipment involved in the user's side.

# **5.3 Check before commissioning running**

No.	Check item	Check	
1	Ensure that there are no foreign objects inside the bypass cabinet, transformer		
Ţ	cabinet, unit cabinet, or control cabinet.		
	Ensure that all electrical connections are tight and that there is no cabinet		
2	damage; if so, the integrity of components, cables, or other materials around the		
	damage must be checked to ensure that there are no safety hazards.		
2	Check all parallel cabinet lines, overcoils, and other cables in easy-to-cut places		
3	to ensure that no conductors are exposed.		
	The grounding bar of the system cabinet must be reliably connected to the earth,		
4	and the ground wire at the door panel inside the cabinet is reliably connected to		
	ensure personnel safety.		
Б	Check the grounding wire connected to the grounding bar in each cabinet of the		
5	system is firmly connected without breakage.		
6	Ensure that the power cable of the cooling fan is reliably connected, the fan is		
0	firmly installed and rotates without abnormal friction sound.		
7	Ensure that the cable wiring between phase shifting transformer and unit, unit		
I	and unit is normal.		
0	Ensure that the optical fiber of each power unit is properly connected to the main		
0	control board.		
9	Ensure that each single board and its external wiring is proper and solid.		
10	The power cables and signal cables connected by users are correctly connected;		
10	and wired separately.		
11	Ensure that each cabinet door is free of abnormalities and locked before		
11	powering on.		

# 5.4 Power-on commissioning of the control cabinet



The following steps must be performed in order, make sure each step is performed and confirmed correctly before proceeding to the next step.

Step	Commissioning contents	Check
1	The control power supply is three-phase four-wire power supply, to ensure that the voltage in the required range.	
2	Close the power switch in the control cabinet, observe whether the single boards in the control cabinet are normal and whether there are abnormal phenomena such as abnormal noise and odor in the cabinet. Close the fan switch in the control cabinet and check whether the fan is turning and	
3	rotating smoothly without abnormalities.	
4	<ul> <li>Log in the touch screen to enter the main interface, and enter the parameter setting interface.</li> <li>Setting P00.21 to 1 to restore default values (required for the first power-on commissioning, no operation required later).</li> <li>Ensure that parameters such as system power, voltage and current levels, and number of units are correct according to the model.</li> <li>Set function codes relating to the buffer, UPS, switching cabinet, fan start/stop and unit bypass according to the actual configuration of the model.</li> <li>Set motor parameters according to the actual load type.</li> <li>Select the appropriate control mode and start-up method, and set the relevant control parameters.</li> <li>Set the parameters of the user port according to the actual user application function.</li> </ul>	
5	Perform the switching cabinet logic control test for the device in commissioning mode (can be ignored without switching cabinet)	
6	Start and stop, simulate faults and other operation s are conducted to ensure that the system is equipped with the self-protection function.	
7	Ensure that the opening and closing signals of the system are correct, valid and reliable to verify the interlock function of the medium voltage switchgears.	
8	Cancel the commissioning mode and related parameters, and put the system in POFF state.	
9	Prepare for medium voltage power-on commissioning.	

# 5.5 Medium voltage power-on commissioning



The medium voltage power-on commissioning shall be conducted after the operations of sections 5.1 Commissioning flowchart-5.4 Power-on commissioning of the control cabinet are done.

# 5.5.1 Commissioning without motor

Г

Attention					
The fo	llowing steps must be performed in order, making sure that each step is perform	med and			
confir	confirmed correctly before proceeding to the next step.				
Step	Commissioning contents	Check			
1	Ensure that the system is in the power-off state, system input terminals R, S and T are connected reliably to the medium voltage incoming cables. Ensure that the output terminals U, V and W are disconnected from the motor, close all cabinets and lock them.				
2	After the control power supply is connected, when the system is in POFF state, a switch-on permission signal is issued, notifying that the medium voltage power supply shall be connected.				
3	Connect the medium voltage power supply according to the medium voltage safety operation procedures, if any equipment abnormality occurs in the middle of the process, you can disconnect the medium voltage input power supply immediately by pressing the emergency stop button or notifying the superiorofficer.				
4	Ensure there is no abnormality during the power-on of the medium voltage power supply, and verify again whether the medium voltage switch-off logic is normal.				
5	Connect the medium voltage power supply again, and observe whether the input voltage, unit bus voltage, and U, V and W phase bus voltage are normal.				
6	Observe whether there are alarms or faults in the system and whether the information displayed on each interface of the touch screen is normal.				
7	Locally verify the correctness of basic functions such as start/stop operation and ACC/DEC operation, and ensure the data states of each module detection and feedback are correct.				
8	Verify whether some of the alarms and faults can be reported normally and the protection actions are normal.				
9	Manually disconnect the user power supply and verify the dual power switching function. You shall observe the rotation direction of the fans.				
10	After confirming that there is no abnormality in different working states of the no-load equipment, stop the machine and cut off the medium voltage power supply.				
11	Prepare to perform commissioning with the motor.				

# 5.5.2 Motor no-load commissioning

Attention           The following steps must be performed in order, making sure that each step is performed confirmed correctly before proceeding to the next step.				
Step	Commissioning contents	Check		
1	Ensure that the motor is disconnected from the load.			
2	Disconnect the medium voltage power and control power supplies, and reliably connect the motor cables to output terminals U, V and W of the system in phase sequence.			
3	Connect the medium voltage power supply according to the steps, put the system in the standby or stopped state, and confirm that there is no abnormality in the system.			
4	Ensure that the function parameters are set correctly, and perform jogging in the expansion command interface to see whether the motor rotation direction is correct (change the rotation direction by changing the wiring or modifying the parameters if the direction is opposite), and confirm that there is no abnormality.			

5	Set the target frequency, conduct several speed boost and droop tests on the system in steps of 5Hz, and observe whether there is any abnormality in the motor and system during the process.	
6	If there is no abnormality in the commissioning, stop and disconnect the medium voltage power supply.	
7	Prepare the motor load-carrying commissioning.	

# 5.5.3 Motor load-carrying commissioning

	<u>Attention</u>				
The fo	The following steps must be performed in order, making sure that each step is performed and				
confir	med correctly before proceeding to the next step.				
Step	Commissioning contents	Check			
1	Connect the motor to the load, switch on the control power supply after all checks are completed, and connect the medium voltage power supply according to the steps.				
2	When the system is in the standby or stopped state and the motor load is light, start the system, observe the change of the output voltage and current of the system as the frequency increases, and add loads to meet the user's production process requirements.				
3	If any alarm or fault occurs during the start-up or running process, stop immediately and handle the situation according to chapter 8 Alarm and fault solution.				
4	After trial running, conduct 24-hour on-site inspection, and record data such as the running frequency, input and output voltage, and input and output current.				
5	Ensure that the equipment operates normally and meets user requirements until the end of trial running.				
6	Conduct the training and work handover to operators.				

# **6 Function description**

# P00 group Basic functions

Function code	Name	Description	Setting range	Default
P00.00	Control mode selection	<ul> <li>0: Space voltage vector control mode</li> <li>1: Asynchronous sensorless vector</li> <li>control</li> <li>2: Synchronous sensorless vector</li> <li>control</li> <li>3: Vector control</li> </ul>	0-3	0

Select speed control mode of the variable-frequency speed regulation system.

0: Space voltage vector control

Space voltage vector control mode supports both AMs and SMs and is applicable to cases where speed control precision is not required high for general load, such as fans and pumps, and where a variable-frequency speed regulation system drives multiple motors.

1: Asynchronous sensorless vector control

Asynchronous sensorless vector control also called open loop vector supports asynchronous motors and applies to the cases requiring high performance without pulse encoders, low-frequency large-torque and high speed control precision. One variable-frequency speed regulation system drives only one motor such as conveyors and large-power drive equipment.

2: Synchronous sensorless vector control

Synchronous sensorless vector control only supports synchronous motors and the system shall carry out high precision adjustment on output current by close loop control algorithm to make torque and speed output more stable and accurate.

3: Vector control

Vector control supports synchronous and asynchronous motors, uses encoders as speed detection sensor for higher precision and wider range, and applies to the cases requiring high rotating speed control precision and low-frequency large-torque.

**Note:** Precise motor parameters are the necessity for vector control with high performance. Therefore, input the nameplate parameters of the motor correctly before running and finish motor parameters autotuning. Adjusting P3 group vector control can optimize vector control performance.

Function code	Name	Description	Setting range	Default
P00.01	Channel of running commands	0: Local 1: Terminal 2: Communication 3: Master	0–3	0

The function code can be used to select the command channel of the system control commands (such as start, stop, forward, reverse, jog, fault reset, etc.) in the remote-local state (remote-local terminal points to remote). In the local state (remote-local terminal points to local), the operation is only controlled by the touch screen. When the terminal R\_N of the control cabinet is valid, that is, in the local state, it has nothing
to do with P00.01, and the operation is only controlled by the touch screen.

0: Local

Some functions are available by setting the function codes. (The touch screen supports our Ethernet protocol and IP protocol).

1: Terminal

The control commands including forward running, reverse running, forward jogging, reverse jogging, stop, and fault reset are controlled by input signals of multifunctional input terminals. Please refer to detailed settings in P05.

2: Communication

For details about communication modes, refer to chapter 10 Modbus communication protocol.

3: Master

The channel is mainly used to set the running command of the slave under master-slave control. If the function code is set to 3, the slave is controlled by the start/stop command of the master.

Function code	Name	Description	Setting range	Default
P00.02	Current communication command channel	0: Modbus 1: Fieldbus 2: Ethernet	0–2	0

**Note:** The touch screen of the system applies Ethernet channel.

When P00.01=2, P00.01 is used to select the communication method of frequency setting command channel.

Function code	Name	Description	Setting range	Default
P00.03	UP/DOWN setting	<ol> <li>0: Valid, save the setting at power-off.</li> <li>1: Valid, do not save the setting at power-off.</li> <li>2: Invalid</li> <li>3: Valid during running, clear at stop</li> </ol>	0-3	0
P00.04	UP/DOWN adjustment	-120.00-120.00Hz	-120.00-120.00	0.00Hz

The function code of UP/DOWN setting (frequency setting increasing/decreasing) can modify the set frequency of the system, adjust any frequency setting except multi-step speed setting and achieve fine adjustment on the set frequency of the system. Actual set frequency of the system=set frequency of channels + adjusted frequency, as shown in Figure 6-1.

0: Valid, save the setting at power-off. You can set a fine-tuning value, save the value after the system control power is powered off, and the value is automatically combined with the current set frequency after next power on.

1: Valid, do not save the setting at power-off. You can set a fine-tuning value, but the value is not saved after the system control power is powered off.

2: Invalid. The terminal UP/DOWN function is invalid, and the set fine-tuning value is automatically cleared.

3: Valid during running, clear at stop. The terminal UP/DOWN function is valid during running, and the set fine-tuning value is automatically cleared at stop.

**Note:** When the parameters of the system restore to default values, the value of UP/DOWN will be cleared automatically.

After the UP/DOWN setting is valid, P00.03 will display the UP/DOWN adjusted value with the range of -120.00–120.00Hz.

Function code	Name	Description	Setting range	Default
P00.05	Speed reference mode	0: Speed mode 1: Torque mode 2: Slave speed mode 3: Slave torque mode	0-3	0

0: Speed mode. The system will output frequency at the set speed command and the motor will automatically adjust the output torque to keep the speed. But the output torque is limited by P03.12. If the load torque is greater than the upper limit, the output torque of the system is limited and the motor speed will change.

1: Torque mode. The system will output torque at the set torque command and the output frequency is limited by the upper and lower limits. When the set torque is greater than the load torque, the output frequency will increase to the upper limit and when the set torque is lower than the load torque, the output frequency will decrease to the lower limit. If the output frequency of the system is limited, the output torque is different from the set torque.

2–3: Slave speed and torque mode. The two modes have no difference and they are mainly used in the master-slave mode.

## ∠Note:

- During decelerating to stop, the system will switch from torque control mode to speed control mode.
- When P12.29=3 (slave) and P00.01=3, the local is the slave. The torque control mode and speed control mode can also be switched via multifunction input terminals. The torque control mode is only for vector control.

Function code	Name	Description	Setting range	Default
P00.06	Setting channel of frequency A command	0: Function code 1: Al1 2: Al2 3: Al3 4: Al4 5: Multi-step speed running 6: PID control 7: Modbus 8: Fieldbus	0–8	0

Goodrive5000 medium voltage variable-frequency speed regulation system supports two command sources A and B, A command source is the general channel, B command source is the auxiliary channel. The combination of P00.06 and P00.07 determines the value of frequency setting. Refer to P00.09 for the way of combination.

0: Function code, frequency A setting is the value of P00.13.

1–4: AI, AI1, AI2, AI3, and AI4 are programmable analog input terminals. Refer to P5 group for the functions. Whether AI1, AI2, and AI3 are current or voltage inputs can be selected by the function code.

5: Multi-step speed running, the system runs at multi-step speed and P11.00 will select multi-step speed. P11.00=0, the multi-step speed terminal in P5 will select current step; P11.00=1, P11.18–P11.33 is the current step and P11.01–P11.16 is current frequency (multi-step n frequency=maximum frequency P00.10 \* speed n percentage)

6: PID control, the result of built-in PID module adjustment is the set frequency of the system. See PID source, setting, feedback and parameters in P10 group.

7: Modbus, set the frequency of frequency A source.

8: Profibus, set the frequency of frequency A source.

**Note:** The fieldbus card of the system is optional.

Function code	Name	Description	Setting range	Default
P00.07	Setting channel of frequency B command	0: Al1 1: Al2 2: Al3 3: Al4	0-3	0
P00.08	Reference object of frequency B command	0: Max. output frequency 1: Frequency A command	0-1	0

P00.07 and P00.08 determine the value of frequency B setting. Frequency B =Reference of frequency B (P00.08)\* Frequency B command source (P00.07).

If P00.07=0, P00.08=0, Al1 input percentage is 50%, max frequency setting is 50Hz, then frequency B =  $50Hz \times 50\% = 25Hz$ ; P00.07=0, P00.08=1, Al1 input percentage is 50%, frequency A command source is 40Hz, then frequency B =  $40Hz \times 50\% = 20Hz$ .

Function code	Name	Description	Setting range	Default
P00.09	Combination mode of setting source	0: A 1: B 2: A+B 3: Max(A, B)	0-3	0

P00.09 is used to set the combination of frequency sources, and it can be also switched by P5 group, as shown in Figure 6-1.

P00.09=0: Current frequency is frequency A command.

P00.09=1: Current frequency is frequency B command.

P00.09=2: Current frequency is frequency A command + B command.

P00.09=3: Current frequency is the greater value between frequency A and B command.

Figure 6-1 Combination of frequency sources



Function code	Name	Description	Setting range	Default
P00.10	Max. output frequency	P00.11-200.00Hz	P00.11-200.00	50.00Hz

Set the max. frequency of the variable-frequency speed regulation system.

Function code	Name	Description	Setting range	Default
P00.11	Upper limit of running frequency	P00.12–P00.10 (Max. frequency)	P00.12-P00.10	50.00Hz
P00.12	Lower limit of running frequency	0.00Hz–P00.11 (Upper limit of running frequency)	0.00-P00.11	0.00Hz

P00.11 and P00.12 are used to set output frequency upper and lower limits of the system. Pay attention to distinguish upper limit of running frequency from maximum output frequency, the former for actual maximum frequency and the latter for set maximum frequency.

Restrictions on the relationship between frequencies: Max. output frequency  $\geq$  upper limit frequency  $\geq$  set frequency  $\geq$  lower limit frequency.

Function code	Name	Description		Setting range	Default	
P00.13	Function code	0.00Hz-P00.10	(Max.	output	0.00_P00.10	50 0047
	setting frequency	frequency)			0.00-P00.10	30.00HZ

When frequency A command select "P00.06=0", the value of the function code is the original setting one of the variable-frequency speed regulation system.

Function code	Name	Description	Setting range	Default
P00.14	Torque setting	0: Function code 1: Al1 2: Al2 3: Al3 4: Al4 5: Reserved 6: Multi-step speed running 7: Modbus 8: Fieldbus	0–8	0

In the vector control mode, P00.05=1, torque reference channel can be selected by P00.14. If the torque is set as negative, the torque output direction is reverse to the set running direction.

**Note:** The set running direction is determined by the reference direction and P00.18.

Function code	Name	Description	Setting range	Default
P00.15	Function code setting torque	-200.0%-200.0%	-200.0%-200.0%	30.0%

When P00.14=0, P00.15 is used to set the set torque of the system, among which 100.0% corresponds to the rated output current of the system.

Function code	Name	Description	Setting range	Default
P00.16	ACC time 1	0.1-3600.0s	0.1-3600.0	Model depended

Function code	Name	Description	Setting range	Default
P00.17	DEC time 1	0.1-3600.0s	0.1-3600.0	Model depended

ACC time means the time needed if the variable-frequency speed regulation system speeds up from 0Hz to the max. output frequency (P00.10).

DEC time means the time needed if the variable-frequency speed regulation system speeds down from the max. output frequency (P00.10) to 0Hz.



When the set frequency ( $f_{SET}$ ) equals to the maximum frequency ( $f_{MAX}$ ), the actual acceleration and deceleration time will be in accordance with the set time.

When the set frequency is less than the maximum frequency, the actual acceleration and deceleration time will be less than the set time.

Actual acceleration and deceleration time = set time \* (set frequency ÷ maximum frequency)

The system has 4 groups of ACC and DEC time.

Group 1: P00.16, P00.17;

Group 2: P08.00, P08.01;

Group 3: P08.02, P08.03;

Group 4: P08.04, P08.05.

Select different ACC/DEC time groups via state combinations of these two multi-function digital input terminals which must be set to the function 14 and function 15. For details, refer to terminal functions of P05 group. The first group of ACC and DEC time is by default.

Function code	Name	Description	Setting range	Default
P00.18	Running direction	0: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running	0–2	0

0: Run at the default direction. The motor runs in accordance with the actual direction.

1: Run at the opposite direction. The motor runs at the opposite direction, which is equivalent to changing the direction of motor by changing any two-phase sequence.

**Note:** After initialization of parameters, the direction of the motor will restore to the original state. Be cautious to use when the motor direction is forbidden to change after commissioning.

2: Disable reverse running. Disable reverse running. It can be used in some special scenarios where reverse running is disabled, such as in situations which need to switch between power frequency and variable frequency. When reverse running is disabled, the system will enter into the standby state after receiving the reverse running command.

Function code	Name	Description	Setting range	Default
P00.19	Carrier frequency	0.5–2.0kHz	0.5-2.0	0.7kHz

The carrier frequency has been properly set in the factory before the variable-frequency speed regulation system is delivered, you do not need to modify it. When the frequency used exceeds the default carrier frequency, the variable-frequency speed regulation system needs to derate.

Function code	Name	Description	Setting range	Default
P00.20	Motor parameter autotuning	0: No operation 1: Rotary autotuning 2: Encoder autotuning 3: Motor frequency drop rate autotuning 4: Power frequency and variable frequency switching time autotuning 5: Static autotuning (Reserved)	0–5	0

In vector control, more accurate motor parameters are needed, and users can select whether to perform parameter autotuning based on application scenarios.

0: No operation. Motor parameter autotuning is not performed.

1: Rotary autotuning. Comprehensive motor parameter autotuning is performed. It is recommended to use rotating autotuning when high control accuracy is required.

2: Encoder autotuning, set a proper value of P00.23, and ensure that the motor runs stably in V/F before performing the autotuning.

3: Motor frequency drop rate autotuning, select synchronous switching without reactors. It is recommended to perform autotuning with the load. After setting P00.20=3, click the Run button, the system automatically runs to the rated frequency of the motor, and coasts to stop. After the end of the autotuning, you can view the autotuning results through P15.09–P15.12.

4: Power frequency and variable frequency switching time autotuning, select the synchronous switching without reactors. It is necessary to perform action time autotuning for contactors. In the low-voltage commissioning mode, after setting P00.20=4, click the variable frequency button, then click the power frequency button to complete the autotuning process. After the end of the autotuning, you can view the autotuning results through P15.17–P15.20.

Function code	Name	Description	Setting range	Default
P00.21	Function parameter restore	0: No operation 1: Restore to default values 2: Clear fault files 3: Clear ammeter records	0–3	0

5: Static autotuning. Partial motor parameter autotuning is performed.

The function code can restore the parameters to default values, and clear all fault records and ammeter records of the system.

**Note:** After the selected operation of P00.21 is performed, the function code is automatically restored to 0. Restoring to default values will not restore parameters of P02 group.

Function code	Name	Description	Setting range	Default
P00.22	AVR function selection	0: Disable 1: Enable all the time 2: Disable during DEC	0–2	1

**Note:** When AVR (Auto Voltage Regulation) function is disabled, the output voltage of the system will change along with the input voltage (or DC bus voltage). When the function is enabled, the output voltage will keep stable in a certain range. When DEC time is too long to meet field requirements, cancel the AVR function to shorten the DEC time.

Function code	Name	Description	Setting range	Default
	Encoder			
P00.23	autotuning	0.00Hz-P00.10	0.00-P00.10	10.00Hz
	frequency			
P00.24	Forward rotation			
	upper-limit	0.0047 000.10		
	frequency in	0.00Hz-P00.10	0.00-+00.10	50.00112
	torque control			
	<b>Reverse rotation</b>	0.00Hz-P00.10	0.00-P00.10	50.00Hz
D00 25	upper-limit			
F00.23	frequency in			
	torque control			
DUU 26	Electromotive	0.0. 200.0%	0 0 200 0	100.0%
P00.26	torque upper limit	0.0-200.0%	0.0-200.0	100.0%
DUU 32	Power generation	0.0. 200.0%	0 0 200 0	100.0%
F00.21	torque upper limit	0.0-200.0%	0.0-200.0	100.0%

# P01 group Start and stop control

Function code	Name	Description	Setting range	Default
P01.00	Braking mode	0: DC braking 1: Dual-frequency braking	0-1	0

P01.00 is used to set braking modes.

0: DC braking. When the output frequency of the system reaches the starting frequency of DC braking, DC current will run through the stator winding, and the braking torque will generate because the rotor cuts the static magnetic field.

1: Dual-frequency braking. It can produce a strong braking torque and significantly reduce the stopping time, applicable to scenarios with high requirements for braking time.

Function code	Name	Description	Setting range	Default
P01.01	Start mode	0: Direct start 1: Start after DC braking 2: Start after rotating speed tracking	0–2	0

0: Direct start. Start from the starting frequency.

1: Start after DC braking. Start the motor from the starting frequency after DC braking (Set the parameters P01.05 and P01.05). It is suitable in cases where reverse rotation may occur to the small inertia load during

## starting (such as pump load).

2: Start after rotating speed tracking. The system calculates the speed and direction of the motor, and starts running from the current speed, which can implement impact-free smooth startup for rotating motors.

Function code	Name	Description	Setting range	Default
	Starting			
P01.02	frequency of	0.00–10.00Hz	0.00-10.00	0.10Hz
	direct start			
	Starting			
P01.03	frequency hold	0.0–50.0s	0.0-50.0	0.0s
	time			

The system starts from the starting frequency (P01.02), then accelerates to the target frequency on basis of the set ACC time after hold time of starting frequency (P01.03). The starting frequency could not be limited by the frequency lower limit.

Setting a proper starting frequency and starting frequency hold time can increase the torque during starting, which can avoid the situation that the motor cannot start at 0 frequency in some occasions.

## **/**Note:

- If the target frequency is lower than starting frequency, the system will be in the running state with no output.
- The starting frequency shall not be greater than the frequency upper limit; otherwise, the system will be in the running state with no output and cannot respond to the running commands. When the starting frequency is greater than starting frequency of DC braking at stop, the system stops and DC braking is invalid. When the running frequency is lower than the starting frequency, the system coasts to stop.
- Running state with no output: When the PID is dormant, negative frequency or negative torque is given when reverse running is disabled, the target frequency is less than the starting frequency, and the set frequency is less than the frequency lower limit, the system will be in the running state, but there is no output frequency and output voltage. When the conditions for restoring the state without output are met, the system outputs, and the speed tracking starts.



Function code	Name	Description	Setting range	Default
P01.04	DC braking current before start	0.0–120.0% (of the system rated current)	0.0-120.0	0.0%
P01.05	Braking time before start	0.0–50.0s	0.0–50.0	0.0s

## Figure 6-3 Direct start

P01.04: It indicates the applied DC current value during DC braking before start. It is the percentage of rated current of the system.

P01.05: It is duration of DC braking before start. If P01.05 is set to be 0, DC braking is invalid.

**Note:** 

- DC braking before start is valid only when P01.04 and P01.05 are non-zero.
- The higher the DC braking current, the greater the braking torque, but the more serious the motor heating. Please set the function code properly according to actual conditions on site.

Function code	Name	Description	Setting range	Default
P01.06	ACC/DEC mode	0: Linear type 1: S curve	0-1	0

0: Linear type

The output speed increases or decreases as a straight line, and the acceleration = maximum frequency  $\div$  ACC (DEC) time.

### 1: S curve

Output speed changes as S curve. The S curve is generally applied to hoists, conveyor belts, and other application scenarios where smoother start or stop is required.

Function code	Name	Description	Setting range	Default
P01.07	S curve starting segment proportion	1.0–40.0% (ACC/DEC time)	1.0-40.0	30.0%
P01.08	S curve ending segment proportion	1.0–40.0% (ACC/DEC time)	1.0-40.0	30.0%

S curve can directly influence whether the system starts and stops at load smoothly. The parameters of S curve are divided into ACC segment and DEC segment parameters, and the correspondence between these parameters and S-curve is shown as Figure 6-4. In the following figure, t1 (t1=t\*P01.07) is the DEC/ACC time defined by P01.07, and the slope of output frequency change gradually increases during the period. t2 (t2=t\*P01.08) is the DEC/ACC time defined by P01.08, during which the slope of the output frequency change gradually decreases. The slope of the output frequency change is constant during the time between t1 and t2. The shape of S curve is determined by ACC/DEC frequency range, ACC/DEC time, starting-segment time, and ending-segment time.

### Figure 6-4 ACC/DEC of S curve



Function code	Name	Description	Setting range	Default
P01.09	Stop mode	0: Decelerate to stop 1: Coast to stop	0-1	0

### 0: Decelerate to stop

When the stop command is valid, the system decreases the output frequency according to the defined DEC curve. If there is no DC braking at stop, the system will coast to stop when the frequency decelerates to the starting frequency; otherwise, it will coast to stop after DC braking.

### 1: Coast to stop

When the stop command is valid, the system immediately blocks the output and the motor coasts to stop according to the mechanical inertia.

Function code	Name	Description	Setting range	Default
P01.10	Starting frequency of DC braking at stop	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz
P01.11	Wait time before DC braking at stop	0.0–50.0s	0.0–50.0	0.0s
P01.12	DC braking current at stop	0.0–120.0% (of the system rated current)	0.0-120.0	0.0%
P01.13	DC braking time at stop	0.0–50.0s	0.0–50.0	0.0s

Starting frequency of DC braking at stop: During the deceleration to stop, the VFD starts DC braking at stop when running frequency reaches the starting frequency determined by P01.10. When the starting frequency of DC braking at stop is 0 or lower than the start frequency (P01.02), DC braking is invalid, and the system coasts to stop when the frequency decelerates to the starting frequency.

Wait time before DC braking at stop: The system blocks output when the starting frequency of DC braking at stop is reached during DEC. After this wait time, DC braking is started so as to prevent overcurrent caused by DC braking at high speed.

DC braking current at stop: It indicates the applied DC current value during DC braking at stop. Stronger braking current indicates larger braking torque.

DC braking time at stop: It indicates the hold time of DC braking.

✓ Note: DC braking at stop is valid only when P01.12 and P01.13 are non-zero.



## Figure 6-5 DC braking at stop

Function description

Function code	Name	Description	Setting range	Default
P01.14	Torque of frequency superposition braking	0.0%–50.0%	0.0-50.0	30.0%
P01.15	Enabling voltage of frequency superposition braking	1000-1500V	1000-1500	1130V
P01.16	Dual-frequency frequency of frequency superposition braking	200.0-500.0Hz	200.0-500.0	300.0Hz
P01.17	Dual-frequency current-limit point of frequency superposition braking	0.0%–100.0%	0.0–100.0	0.0%
P01.18	Dual-frequency voltage-limit point of frequency superposition braking	50.0%-80.0%	50.0-80.0	80.0%
P01.19	Proportional coefficient of frequency superposition braking	0–65535	0–65535	5
P01.20	Integral coefficient of frequency superposition braking	0–65535	0-65535	2
P01.21	Adjusting multiple of frequency superposition braking	0–65535	0–65535	2
P01.22	Reserved	0-65535	0-65535	0
P01.23	Reserved	0–65535	0–65535	0

When the frequency superposition braking is valid and the bus voltage exceeds P01.15, the system starts outputting frequency superposition frequency to reduce bus voltage. At the time, frequency superposition voltage amplitude output shall not exceed P01.18 (relative to motor rated voltage) and frequency superposition frequency output is P01.16. In vector mode, a greater value of P01.14 indicates a faster frequency superposition braking deceleration. In V/F mode, the function code is invalid.

Function code	Name	Description	Setting range	Default
P01.24	FWD/REV running deadzone time	0.0–3600.0s	0.0-3600.0	1.0s

Set the hold time at zero frequency in the transition between forward and reverse running. It is shown as Figure 6-6.

Figure 6-6 FWD/REV running deadzone time



Function code	Name	Description	Setting range	Default
P01.25	Action selected when running frequency less than frequency lower limit (valid when frequency lower limit greater than 0)	0: Run at the frequency lower limit 1: Stop 2: Sleep	0–2	0

The function code determines the running state of the variable-frequency speed regulation system when absolute value of the set frequency is lower than the lower-limit one.

0: Run at the frequency lower limit. The target frequency is equal to the frequency lower limit.

1: Stop. The system will coast to stop when it decelerates to the lower frequency limit.

2: Sleep. The system decelerates to the frequency lower limit and enters into the running state with no output when the set frequency is lower than the frequency lower limit (refer to Note 3 in P01.03). When the set frequency is higher than or equal to the frequency lower limit again, the system will start to run automatically.

Function code	Name	Description	Setting range	Default
D01.26	Power-off restart	0: Disable	0 1	0
P01.26	selection	1: Enable	1–0	0
P01.27	Sudden power-off	0.00-50.00s	0.00-50.00	1.00s
	time			
	Wait time for			
P01.28	restart after	0.0–3600.0s (valid when P01.26=1)	0.0-3600.0	1.0s
	power-off			

**Note:** If the main circuit of the system powers off during running, the steps for processing are as follows:



#### Figure 6-7 Processing after power off

P01.26 is the action when the system powers off and on again during running.

0: Disable. The system will not automatically restart when the main circuit is powered on again.

1: Enable. The system will be automatically restored to the previous running state after re-power on. That is, if the system is in the running state before power off, it will automatically restart after the delay of (P01.28) upon re-power on (when the system is controlled by terminals, ensure that the running command of the terminal is not withdrawn). If the system is in the stopped state before power-off, the system will not restart automatically after re-power on.

**Note:** This function may cause serious consequences, please use it with cautions.

P01.27 indicates the sudden power-off time, namely the maximum electric dazzling time that the system can bear during the normal running. When the power-off interval of the grid does not exceed the set time, the system can work normally without reporting a fault of power off in running.

Function code	Name	Description	Setting range	Default
P01.29	Medium voltage switch action at	0: Cut off medium voltage during stop 1: Not cut off medium voltage during	0-1	1
	stop	stop		

P01.29 decides whether to cut off medium voltage at sto	tage at stop.
---	---------------

Function code	Name	Description	Setting range	Default
P01.30	Waiting time of switching-on	0.0–3600.0s	0.0–3600.0	10.0s

P01.30 refers to the waiting time from responding to power frequency into variable frequency properly to sending the switching-on allowing signal. It is used to protect the units from impact caused by a short time in switching on twice continuously.

Function code	Name	Description	Setting range	Default
P01.31	Running ready waiting time	0.0-3600.0s	0.0-3600.0	10.0s

P01.31 refers to the waiting time from finishing bus charging to sending the running ready signal to the higher level control system after the higher level medium voltage switch is connected to the medium voltage power supply.

Function code	Name	Description	Setting range	Default
	Pull-in current at			
P01.32	zero frequency	0.0–100.0%	0.0-100.0	20.0%
	start			
	Cut-off frequency			
P01.33	at zero frequency	P01.02-P14.17	P01.02-P14.17	0.00Hz
	start			
	Exit time of			
D01 24	pull-in current at	0.00, 40.00c	0.00 40.00	1.00c
PU1.54	zero frequency	0.00-40.005	0.00-40.00	1.005
	start			
		0: None		
		1: UDP		
P01.35	Command source	2: Internally command	0-5	0
101.00	of coast to stop	3: Terminal		v
		4: Modbus		
		5: PROFIBUS		
		0: None		
	Command source	1: UDP		
P01.36	of decelerate to	2: Terminal	0-4	0
	stop	3: Modbus		
		4: PROFIBUS		

The time is used to make sure DC bus charging completely so as to reduce voltage surge of the grid.

P01.35 and P01.36 are used to check the current command sources of coast to stop and decelerate to stop and cleared in next start.

## P02 group Motor parameter 1

Function code	Name	Description	Setting range	Default
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3	0

**Note:** The motor parameters are particularly important in motor protection and the voltage output, so be sure to set the parameters in accordance with the motor nameplate. When P02.00 is AM, the parameters of SM cannot be modified. When P02.00 is SM, the parameters of AM cannot be modified.

Function code	Name	Description	Setting range	Default
P02.01	Rated power of AM 1	4–50000kW	4–50000kW	Model depended
P02.02	Rated frequency of AM 1	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P02.03	Rated speed of AM 1	1–36000rpm	1-36000	Model depended
P02.04	Rated voltage of AM 1	0–20000V	0-20000	Model depended
P02.05	Rated current of AM 1	0.1-1000.0A	0.1-1000.0	Model depended

In order to achieve control performance, the system needs to match with the motor power. If the bias is too great, the control and protection performance of the system will degrade significantly.

Function code	Name	Description	Setting range	Default
P02.06	Stator resistance of AM 1	0.001-65.535Ω	0.001-65.535	Model depended
P02.07	Rotor resistance of AM 1	0.001-65.535Ω	0.001-65.535	Model depended
P02.08	Stator and rotor inductance of AM 1	0.1–6553.5mH	0.1-6553.5	Model depended
P02.09	Stator and rotor mutual inductance of AM 1	0.1–6553.5mH	0.1-6553.5	Model depended
P02.10	No-load current of AM 1	0.01-655.35A	0.01-655.35A	Model depended

**Note:** Resetting the rated power of the motor (P02.01) can initialize the parameters P02.06–P02.10.

The parameters from P02.06–P02.10 have a great impact on control performance in vector control. During the initialization, the system will determine a group of initial parameters according to the system power. After motor autotuning is performed, the parameters will be updated and saved automatically and users should not modify them at will. Be sure not to change P02.06–P02.10 in V/F control.

Function code	Name	Description	Setting range	Default
P02.11	Rated power of SM 1	4–50000kW	4–50000kW	Model depended
P02.12	Rated frequency of SM 1	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P02.13	Rated speed of SM 1	0–36000rpm	0-36000	1500rpm
P02.14	Number of pole pairs of SM 1	1–50	1–50	2

Function code	Name	Description	Setting range	Default
P02.15	Rated voltage of SM 1	0-20000V	0–20000	Model depended
P02.16	Rated current of SM 1	0.1-1000.0A	0.1-1000.0	Model depended

**Note:** 

- 1. The motor parameters are particularly important in motor protection and voltage output, so be sure to set the parameters in accordance with the information on the nameplate of SM.
- 2. In order to achieve control performance, the system needs to match with the motor power. If the bias is too great, the control and protection performance of the system will degrade significantly.
- 3. Resetting the rated power of the SM (P02.11) can initialize the parameters P02.17–P02.20.

Function code	Name	Description	Setting range	Default
P02.17	Stator resistance of SM 1	0.001-65.535Ω	0.001-65.535	Model depended
P02.18	Direct-axis inductance of SM 1	0.1-655.35mH	0.1-655.35	Model depended
P02.19	Quadrature-axis inductance of SM 1	0.1-655.35mH	0.1-655.35	Model depended
P02.20	Counter-emf constant of SM 1	0–20000	0–20000	9700

The parameters from P02.17–P02.20 are reserved in V/F control.

# P03 group Vector control

Function code	Name	Description	Setting range	Default
P03.00	Speed-loop proportional gain 1	0–100	0-100	5
P03.01	Speed-loop integral time 1	0.01–10.00s	0.01-10.00	0.10s
P03.02	Low-point frequency for switching	0.00Hz-P03.05	0.00-P03.05	5.00Hz
P03.03	Speed-loop proportional gain 2	0–100	0-100	5
P03.04	Speed-loop integral time 2	0.01–10.00s	0.01-10.00	0.10s
P03.05	High-point frequency for switching	P03.02–P00.10 (Max. ouput frequency)	P03.02-P00.10	10.00Hz

Parameters of P03 group are valid only in vector control (P00.00 = 1, 2, 3).

Below the switching frequency 1 (P03.02), the speed-loop PI parameters are: P03.00 and P03.01. Above the switching frequency 2 (P03.05), the speed-loop PI parameters are: P03.03 and P03.04. PI parameters are

obtained according to the linear change of two groups of parameters. See Figure 6-9.



The speed loop dynamic response characteristics of vector control can be adjusted by setting the proportional coefficient and integral time of speed regulator. Increasing proportional gain or reducing integral time can accelerate dynamic response of speed loop; however, if the proportional gain is too large or integral time is too small, system oscillation and overshoot may occur. If Integral time is too small, stable oscillation or speed offset may occur.

PI parameters have a close relationship with the inertia of the system. Adjust PI parameters depending on different loads to meet various demands.

Function code	Name	Description	Setting range	Default
	Current-loop			
P03.06	proportional	0–65535	0–65535	500
	coefficient P			
	Current-loop			
P03.07	integral	0–65535	0-65535	500
	coefficient I			

**Note:** The preceding two parameters adjust the PI adjustment parameters of the current loop, affecting the dynamic response speed and control accuracy directly. Generally, you do not need to change the default values.

Function code	Name	Description	Setting range	Default
P03.08	Speed loop filter time	0.000-1.000s	0.000-1.000	0.002s

This function code is the filter time for motor speed detection, which can be set appropriately in the cases where speed fluctuates violently in vector control.

Function code	Name	Description	Setting range	Default
P03.09	VC slip compensation	50.0%–200.0%	50.0–200.0	100.0%
	coefficient			

Slip compensation coefficient is used to adjust the slip frequency of the vector control and improve the speed control accuracy of the system. Adjusting the parameter properly can control the speed steady-state error.

Function code	Name	Description	Setting range	Default
P03.10	Reserved	0–65535	0-65535	0
P03.11	Reserved	0–65535	0-65535	0
P03.12	Torque upper limit setting	0.0–200.0% (of the system rated current)	0.0-200.0	150.0%

P03.12 is used to set the torque upper limit, and 100% corresponds to rated output current of the system.

**Note:** 

- A greater value of P03.12 indicates a better speed tracking performance. But too large torque upper limit will easily cause overcurrent.
- P03.12 is valid in the vector control speed mode. In the torque mode, the percentage of actual output torque=percentage of set torque (P00.15) × P03.12 = active component of output current/rated motor current.

# P04 group V/F control

Function code	Name	Description	Setting range	Default
P04.00	V/F curve setting	0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F (V/F separation)	0–5	0

Parameters of P04 group are valid only in V/F control (P00.00=0).

0: Straight-line V/F curve. It is applicable to constant torque loads.

1: Multi-point V/F curve. It can be defined by setting P04.05–P04.10.

2–4: Multi-power V/F curve. It is applicable to variable torque loads, such as fans, pumps and so on. The curves for each power are shown in the following figure.

5: Customized V/F (V/F separation)

**Note:** In the following figure, V<sub>b</sub> is the motor rated voltage and f<sub>b</sub> is the motor rated frequency.

Figure 6-10 V/F curves



Function code	Name	Description	Setting range	Default
P04.01	Torque boost	0.0%-10.0%	0.0-10.0	0.1%
P04.02	Torque boost cut-off	0.0%–50.0% (of the motor rated frequency)	0.0–50.0	20.0%

In order to compensate for low-frequency torque characteristics, you need to make some boost compensation for the output voltage.

When P04.01 is non-zero, the system is manual torque boost. The V/F curve after boost is shown as follows (less than P04.02, the value of torque boost is determined by P04.01 and current frequency.). Torque boost can improve the low-frequency torque V/F performance.





You need to select torque boost based on the load. For example, larger load requires larger torque boost, however, if the torque boost is too large, the motor will run at over-excitation, which may cause increased output current and motor overheating, thus decreasing the efficiency.

**Note:** When torque boost is set to 0.0%, the system is automatic torque boost and it is valid in the whole frequency range.

Function code	Name	Description	Setting range	Default
P04.03	V/F slip compensation	0.0-200.0%	0.0-200.0	0.0%

The parameter is set to compensate for the motor rotating speed change caused by load change in V/F control mode, and thus improve the rigidity of the mechanical characteristics of the motor. The value is set to motor rated slip, which can be calculated as below:

P04.03= (fb-n\*p/60)/fb\*100%

Of which,  $f_b$  is the rated frequency of the motor, corresponding to function code P02.02, n is the rated rotating speed of the motor, corresponding to function code P02.03, p is the number of pole pairs of the motor.

Function code	Name	Description	Setting range	Default
P04.04	Energy-saving operation	0: Energy-saving operation is invalid 1: Energy-saving operation is valid	0-1	0

Energy-saving operation: When the motor is running with light load or without load, output voltage will be reduced appropriately to save energy.

**Note:** The function is especially effective for fan and pump loads.

Function code	Name	Description	Setting range	Default
P04.05	V/F frequency point 1	0.00Hz-P04.07	0.00-P04.07	0.00Hz

### Goodrive5000 series medium voltage variable-frequency speed regulation system

Function code	Name	Description	Setting range	Default
P04.06	V/F voltage point 1	0.0%-P04.08	0.0-P04.08	0.0%
P04.07	V/F frequency point 2	P04.05-P04.09	P04.05-P04.09	0.00Hz
P04.08	V/F voltage point 2	P04.06-P04.10	P04.06-P04.10	0.0%
P04.09	V/F frequency point 3	P04.07–P00.10 (max. frequency)	P04.07-P00.10	0.00Hz
P04.10	V/F voltage point 3	P04.08–100.0% (of the motor rated voltage)	P04.08-100.0	0.0%

P04.05–P04.10 are used to set the user-defined multi-point V/F curve. The value of the V/F curve needs to be set according to the load characteristics of the motor.

## ∠Note:

- V1<V2<V3, f1<f2<f3. Setting high voltage for low frequency may cause motor overheat or damage, and cause system overcurrent stall or trigger overcurrent protection.
- Set (P04.09, P04.10) at first, then (P04.07, P04.08), and finally (P04.05, P04.06).



✓Note: V/F voltage is relative to the percentage of motor rated voltage (P02.04).

	Function code	Name	Description	Setting range	Default
P04.11	PWM method	0: PWM method 1	0-1	0	
		1: PWM method 2			

Select the modulating wave method of the variable-frequency speed regulation system.

0: SPWM 1, sine waves with triple-harmonics.

1: SPWM 2, standard sine waves.

Function code	Name	Description	Setting range	Default
P04.12	Voltage setting channel	0: Voltage 1: Al1 2: Al2 3: Al3 4: Al4 5: Multi-step running 6: PID 7: Modbus communication 8: PROFIBUS/PROFINET communication	0–8	0

Function code	Name	Description	Setting range	Default
P04.13	Set voltage	0.0%–100.0% (of the motor rated voltage)	0.0-100.0	20.0%
P04.14	Voltage increase time	0.0s-3600.0s	0.0-3600.0	100.0s
P04.15	Voltage decrease time	0.0s-3600.0s	0.0-3600.0	100.0s

The function code (P04.00= 5) is used to select the output voltage setting channel at V/F curve separation.

Voltage increase time means the time needed for the system to accelerate from 0V to the motor rated voltage.

Voltage decrease time means the time needed for the system to decelerate from the motor rated voltage to 0V.

Function code	Name	Description	Setting range	Default
P04.16	Min. output voltage	0.0%-P04.17	0.0-P04.17	5.0%
P04.17	Max. output voltage	P04.16-100.0%	P04.16-100.0	100.0%

The function codes are used to set the upper and lower limits of output voltage.

Figure 6-13 Upper and lower limits of output voltage



Function code	Name	Description	Setting range	Default
P04.18	Low-frequency oscillation control factor	0–100	0-100	10
P04.19	High-frequency oscillation control factor	0-100	0-100	0
P04.20	Oscillation control frequency threshold	0.00-120.00Hz	0.00-120.00	15.00Hz

In V/F control, motors, especially the large-power motors, may experience current oscillation at certain frequencies, which may cause unstable motor running, or even system overcurrent. Therefore, you need to adjust the size of the oscillation control factor in real time through P04.18 and P04.19 to adjust the intensity of oscillation control according to application situations on site.

The oscillation control frequency threshold specifies the action range of the low-frequency oscillation control factor and the high-frequency oscillation control factor. When the running frequency is lower than P04.20, the control intensity specified in P04.18 is used. When the running frequency is higher than P04.20, the control intensity specified in P04.19 is used.

**Note:** The higher the low frequency and high frequency oscillation control factors are not better. When there is a serious mismatch between the oscillation control factors and the motor characteristics, it will aggravate the current oscillation of the motor.

# P05 group Input terminal functions

Goodrive5000 medium voltage variable-frequency speed regulation system provides 12 multi-function digital input terminals (S1–S12) and 4 analog input terminals as standard configuration, and the functions of these terminals are configurable.

Function code	Name	Description	Setting range	Default
P05.00	Function of S1	0: No function	0-71	1
P05.01	Function of S2	1: Run forward	0-71	2
P05.02	Function of S3	2: Run reversely	0-71	3
P05.03	Function of S4	3: Enable three-wire running	0-71	6
P05.04	Function of S5	4: Forward jogging	0-71	7
P05.05	Function of S6	5: Reverse jogging	0-71	0
P05.06	Function of S7	6: Coast to stop (emergency stop)	0-71	0
P05.07	Function of S8	7: Fault reset	0-71	0
P05.08	Function of S9	8: External fault NO input	0-71	0
P05.09	Function of S10	9: External fault NC input	0-71	0
P05.10	Function of S11	10: Increase frequency setting (UP)	0-71	0
P05.11	Function of S12	<ul> <li>(DOWN)</li> <li>12: Clear the frequency</li> <li>increase/decrease setting</li> <li>13: Clear the frequency</li> <li>increase/decrease setting</li> <li>temporarily</li> <li>14: ACC/DEC time selection 1</li> <li>15: ACC/DEC time selection 2</li> <li>16: Multi-step speed terminal 1</li> <li>17: Multi-step speed terminal 2</li> <li>18: Multi-step speed terminal 3</li> <li>19: Multi-step speed terminal 4</li> <li>20: Pause multi-step speed running</li> <li>21: Switch between A setting and B</li> <li>setting</li> <li>22: Switch between (A+B) setting and</li> <li>A setting</li> <li>23: Switch between (A+B) setting and</li> <li>B setting</li> <li>24: Variable-frequency running (pulse signal ↑)</li> <li>25: Power-frequency running (pulse</li> </ul>	0-71	0

Function code	Name	Description	Setting range	Default	
		signal↑)			
		26: Switching from variable frequency			
		to power frequency (pulse signal $\uparrow$ )			
		27: Switching from power frequency			
		to variable frequency (pulse signal $\uparrow$ )			
		28: Medium voltage disconnection			
		input			
		29: Pause PID control			
		30: UPS feedback			
		31: Reserved			
		32: Switching cabinet address 0			
		33: Switching cabinet address 1			
		34: Switching cabinet address 2			
		35: Switch the running command to			
		local			
		36: Switch the running command to			
		terminal			
		37: Switch the running command to			
		communication			
		38: DCS start			
		39: DCS stop			
		40: Disable torque control			
		41: Enable master/slave control			
		42: Master-slave speed			
		synchronization counting reset			
		terminal			
		43: Disable ACC/DEC			
		44: Precharge cabinet vacuum			
		contactor KM2 feedback			
		45: Commissioning signal input			
		46: Start on-site operation box			
		47: Stop on-site operation box			
		48: Medium voltage switch QF1M1			
		feedback			
		49: Medium voltage switch QF1M2			
		feedback			
		50: Medium voltage switch QF1M3			
		feedback			
		51: Medium voltage switch QF1M4			
		feedback			
		52: Medium voltage switch QF1M5			l
		feedback			l
		53: Medium voltage switch QF1M6			
		feedback			l
		54: Medium voltage switch QF1M7			
		feedback			
		55: Medium voltage switch OF1M8			L

Function code	Name	Description	Setting range	Default
		feedback		
		56: Medium voltage switch QF2M1		
		feedback		
		57: Medium voltage switch QF2M2		
		feedback		
		58: Medium voltage switch QF2M3		
		feedback		
		59: Medium voltage switch QF2M4		
		feedback		
		60: Medium voltage switch QF2M5		
		feedback		
		61: Medium voltage switch QF2M6		
		feedback		
		62: Medium voltage switch QF2M7		
		feedback		
		63: Medium voltage switch QF2M8		
		feedback		
		64: Switching cabinet 1 remote		
		on-site state		
		65: Switching cabinet 2 remote		
		on-site state		
		66: Switching cabinet 3 remote		
		on-site state		
		67: Switching cabinet 4 remote		
		on-site state		
		68: Switching cabinet 5 remote		
		on-site state		
		69: Switching cabinet 6 remote		
		on-site state		
		70: Switching cabinet 7 remote		
		on-site state		
		71: Switching cabinet 8 remote		
		on-site state		

This parameter is used to set the corresponding function of digital multi-function input terminals.

- 0: No function
- 1: Run forward (FWD)
- 2: Run reversely (REV)
- 3: 3-wire control S<sub>In</sub>

Functions 1–3 are only valid when the running command channel is configured as terminal, in which function 3 is valid only when it is configured as 3-wire control. For details, see the description of terminal control running mode (P05.14).

- 4: Forward jogging
- 5: Reverse jogging

The terminals are used to select the states of jogging, which can control the motor for forward jogging and reverse jogging. For details about jogging frequency and ACC/DEC time, see the descriptions of P08.06–

P08.08.

6: Coast to stop

When the command takes effect, the system will block output immediately. For large inertia loads and without limit to stop time, it is advised to apply the method. It has the same meaning as P01.09. If the terminal command is not cancelled, the system cannot start.

7: Fault reset

It is used for long distance fault reset. If the terminal acts, the system will perform fault reset. The function is pulse triggering, a pulse rising edge for reset once.

- 8: External fault NO input
- 9: External fault NC input

The above two functions are mainly used to receive external faults. If the external faults are reported, the system will generate external fault signals and act according to P09.02. As for external fault NC input, the terminal switch-on indicates no fault while the terminal switch-off indicates external faults. External fault NO input is opposite.

- 10: Increase frequency setting (UP)
- 11: Decrease frequency setting (DOWN)
- 12: Clear the frequency increase/decrease setting
- 13: Clear the frequency increase/decrease setting temporarily

The above four functions are used to perform frequency fine-tuning by external terminals (Refer to the descriptions of P00.02 and P00.03). UP is frequency increase command while DOWN is frequency decrease command (Refer to the descriptions of P05.19 and P05.20). Terminal 12 is used to clear the frequency value set by UP/DOWN. Terminal 13 is used to clear the frequency value set by UP/DOWN temporarily. The frequency value goes back to normal when the terminal is invalid.

14, 15: ACC/DEC time selection terminal 1, 2

The status of the two terminals can be combined to select four groups of ACC/DEC time.

Terminal 2	Terminal 1	ACC/DEC time	Parameter
OFF	OFF	ACC/DEC time 1	P00.11, P00.12
OFF	ON	ACC/DEC time 2	P08.00, P08.01
ON	OFF	ACC/DEC time 3	P08.02, P08.03
ON	ON	ACC/DEC time 4	P08.04, P08.05

16–19: Multi-step speed terminal 1–4

16-step speeds can be set by combining states of these four terminals. See detailed instructions of multi-step speed control parameters in group P0 and P11.

**Note:** Multi-step speed terminal 1 is the low-order bit, and multi-step speed terminal 4 is the high-order bit.

Multi-step speed	Multi-step speed	Multi-step speed	Multi-step speed
terminal 4	terminal 3	terminal 2	terminal 1
Bit3	Bit2	Bit1	Bit0

20: Pause multi-step speed running

Once the terminal is enabled, whatever multi-step speed terminals or analog terminals change, the set frequency keeps in current step.

21: Switch between A setting and B setting

22: Switch between (A+B) setting and A setting

23: Switch between (A+B) setting and B setting

The above three functions are used to switch the frequency setting channels.

When the system frequency is set by A-channel and the terminal 21 acts, the channel of frequency setting will switch to B-channel. After the terminal 21 returns, the channel of frequency setting will switch to A-channel. The terminals 22 and 23 are invalid.

Similarly, when the system frequency is set by B-channel and the terminal 21 acts, the channel of frequency setting will switch to A-channel. After the terminal 21 returns, the channel of frequency setting will switch to B-channel.

The functions of terminals 22 and 23 are similar to the function of 21.

### 24: Variable-frequency running

When the terminal is valid, the system switches from the power-off state to the variable-frequency state by pulse signal of the terminal, that is to say, KM1, KM2, KM3 and KM4 are off at first, then KM1, KM2 and KM3 are on (KM4 is still off). If the system is in other states, the terminal input is invalid.

### 25: Power-frequency running

When the terminal is valid, the system switches from the power-off state to the power frequency bypass state by pulse signal of the terminal, that is to say, KM1, KM2, KM3 and KM4 are off at first, then KM4 is on. If the system is in other states, the terminal input is invalid.

26: Switch from variable frequency to power frequency

When the terminal is valid, the system switches from the variable-frequency state to the power frequency bypass state by pulse signal of the terminal, that is to say, KM1, KM2, and KM3 are on and KM4 is off at first, then KM4 is on and KM1, KM2 and KM3 are off. If the system is in other states, the terminal input is invalid.

27: Switch from power frequency to variable frequency

When the terminal is valid, the system changes from the power frequency bypass state to the variable-frequency state by pulse signal of the terminal, that is to say, KM4 is on and KM1, KM2, and KM3 are off at first, then KM1, KM2 and KM3 are on and KM4 is off. If the system is in other states, the terminal input is invalid.

**Note:** Functions 24–27 are valid only for the system with isolated automatic switching cabinet. If there is no isolated automatic switching cabinet, they are invalid.





**Note:** 150A and lower system models are not equipped with the pre-charge resistor as standard configuration.

28: Medium voltage disconnection input

If the terminal is valid, the system will automatically cut off the medium voltage.

29: Pause PID control

PID is ineffective temporarily, and the system maintains the present frequency output.

30: UPS feedback signal

31: Reserved

32: Switching cabinet address 0

33: Switching cabinet address 1

34: Switching cabinet address 2

Take the combinations of 0 and 1 of 3 switching cabinet addresses (000–111, 8 combinations in total) as the number of 1–8 switching cabinets, in which 000–111 corresponds to the switching cabinets 1–8 respectively.

35: Switch the running command to local

When the terminal is valid, the running command channel of the system will be forced to switch into UDP.

36: Switch the running command to terminal

When the terminal is valid, the running command channel of the system will be forced to switch into terminal.

37: Switch the running command to communication

When the terminal is valid, the running command channel of the system will be forced to switch into communication specified in P00.02.

**Note:** Above channel switching is valid only when the remote-local switch is at remote.

38: DCS start, forward running

39: DCS stop

40: Disable torque control

The control mode will switch from torque control to speed control if the terminal is valid. In actual application, the terminal can be used to switch between speed control and torque control.

41: Enable master/slave control

42: Master-slave speed synchronization counting reset terminal

Pulse encoder count reset signal input terminal for the speed synchronization method in master-slave control (this terminal is reserved).

43: Disable ACC/DEC

When this function is valid, ensure that the system is not affected by the fluctuation of the external frequency reference sources and the current output frequency remains. The function is invalid in the torque mode.

44: Precharge cabinet vacuum contactor KM2 feedback

45: Commissioning signal input

When this function is valid, the system can simulate the states of ready, power frequency, and variable frequency without connecting to the medium voltage power supply.

46: Start on-site operation box

47: Stop on-site operation box

- 48: Medium voltage switch QF1M1 feedback
- 49: Medium voltage switch QF1M2 feedback
- 50: Medium voltage switch QF1M3 feedback51: Medium voltage switch QF1M4 feedback
- 52: Medium voltage switch QF1M5 feedback
- 53: Medium voltage switch QF1M6 feedback
- 54: Medium voltage switch QF1M7 feedback
- 55: Medium voltage switch QF1M8 feedback
- 56: Medium voltage switch QF2M1 feedback
- 57: Medium voltage switch QF2M2 feedback
- 58: Medium voltage switch QF2M3 feedback
- 59: Medium voltage switch QF2M4 feedback
- 60: Medium voltage switch QF2M5 feedback
- 61: Medium voltage switch QF2M6 feedback
- 62: Medium voltage switch QF2M7 feedback
- 63: Medium voltage switch QF2M8 feedback

48 and 56 are vacuum breaker feedback of QF1M1 at the variable-frequency side and QF2M1 at the power frequency side of the switching cabinet 1 (main switching cabinet). When P15.01 is 1, variable frequency and power frequency share the power. As long as either QF1M1 or QF2M1 feedback switches on, the common vacuum breaker will switch off. As long as both QF1M1 and QF2M1 feedback switch off, the common vacuum breaker will switch off. When P15.01 is 0, variable frequency and power frequency do not share the power. QF1M1 and QF2M1 feedback indicates the states of vacuum breakers respectively, high electrical level standing for switching on and low electrical level for switching off.

49–55: Feedback of medium voltage switch QF1M2–QF1M8 indicates the state feedback of the higher level vacuum breaker at the variable frequency end of switching cabinet 2–8 respectively.

57–63: Feedback of medium voltage switch QF2M2–QF2M8 indicates the state feedback of the higher level vacuum breaker at the power frequency end of switching cabinet 2–8 respectively.

**Note:** If the system is configured with the higher level vacuum breaker, you must set the terminal used for vacuum contactor feedback to the corresponding vacuum breaker feedback function according to the on-site wiring.

- 64: Switching cabinet 1 remote on-site state
- 65: Switching cabinet 2 remote on-site state
- 66: Switching cabinet 3 remote on-site state
- 66: Switching cabinet 4 remote on-site state
- 66: Switching cabinet 5 remote on-site state
- 66: Switching cabinet 6 remote on-site state
- 66: Switching cabinet 7 remote on-site state
- 66: Switching cabinet 8 remote on-site state



Function code	Name	Description	Setting range	Default
P05.12	Input terminal polarity setup	0x0000-0xFFFF	0x0000-0xFFFF	0x0000

The function code is used to set the polarity of the digital input terminals, i.e. whether the terminal contact is NO or NC. Each input terminal corresponds to a bit, and 0 indicates NO contact, and 1 indicates NC contact.

•	-	-	-	S12	S11	S10	S9	<b>S</b> 8	S7	<b>S</b> 6	S5	S4	S3	S2	S1
Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0

Function code	Name	Description	Setting range	Default
P05.13	Digital filter times	1–500	1-500	20

P05.17 is used to set the filter time of sampling of S1–S12 terminals. In strong interference cases, increase the value to avoid maloperation.

Function code	Name	Description	Setting range	Default
P05.14	Terminal control running mode	0: Two-wire control mode 1 1: Two-wire control mode 2 2: Three-wire control mode 1 3: Three-wire control mode 2	0–3	0

This parameter defines four different control modes that control the system through external terminals.

0: Two-wire control 1, the enabling consistent with the direction. This mode is widely used. The defined FWD/REV terminal command determines the motor rotation direction.

Figure 6-16 Two-wire control (the enabling consistent with the direction)



1: Two-wire control 2, the enabling separated from the direction. In this mode, FWD is the enabling terminal. The direction depends on the defined REV state.

Figure 6-17 Two-wire control (the enabling separated from the direction)



2: Three-wire control mode 1. If  $S_{ln}$  (In=1-12) is 3 (three-wire control enabled), when  $S_{ln}$  switches on, the running command will be generated by FWD (terminal rising edge is valid) and the direction will be controlled by REV (REV off indicates forward running; REV on indicates reverse running.). When  $S_{ln}$  switches off, the system will stop.



Figure 6-18 Three-wire control 1

**Note:** K1: Enabling switch; SB1: Running button; K2: Running direction switch.

3: Three-wire control mode 2. If  $S_{in}$  (In=1-12) is 3 (three-wire control enabled), when  $S_{in}$  switches on, the running command will be generated by FWD or REV and the direction will be controlled by both of them. When  $S_{in}$  switches off, FWD and REV are invalid. FWD and REV (both rising edges are valid) refer to inputs of forward and reverse running commands respectively.



Figure 6-19 Three-wire control 2

Note: SB1: Forward running; K1: Enabling switch; SB2: Reverse running.

## ∠Note:

- The system will not respond to the running commands given before two-wire control is ready. Only after the ready of two-wire control will the system respond to re-given running commands.
- For two-wire control running mode, when the FWD/REV terminal is valid, if the system stops due to a stop command given by another source, the system does not run again after the stop command disappears even if the control terminal FWD/REV is still valid. To make the system run, you need to trigger FWD/REV again.

Function code	Name	Description	Setting range	Default
P05.15	Frequency			
	rate of the	0.01–50.00Hz/s	0.01-50.00	0.50Hz/s
	terminal UP			
	Frequency			
P05.16	increment change		0.01 50.00	0.50Hz/s
	rate of the	0.01-50.00HZ/S	0.01-50.00	
	terminal DOWN			

When UP/DOWN terminal functions are used to adjust the set frequency, P05.15 and P05.16 are used to set the UP/DOWN change rate.

Function code	Name	Description	Setting range	Default
P05.17	AI1 lower limit	0.00V-P05.19	0.00-P05.19	0.00V
P05.18	Corresponding setting of Al1 lower limit	-100.0%-P05.20	-100.0-P05.20	0.0%
P05.19	Al1 upper limit	P05.17-10.00V	P05.17-10.00	10.00V
P05.20	Corresponding setting of Al1 upper limit	P05.18-100.0%	P05.18-100.0	100.0%
P05.21	AI1 input filter time	0.00s-10.00s	0.00-10.00	2.00s

The preceding function codes define the relationship between the input voltage or input current of analog inputs AI1 and its corresponding setting. When the analog input voltage or current exceeds the range from the upper limit to the lower limit, the upper limit or lower limit is used.

When the analog input is current input, 0mA–20mA current corresponds to 0V–10V voltage.

In different applications, 100.0% of the analog setting corresponds to different nominal values. See the descriptions of each application section for details.

The following figure shows the relationship between AI1/AI2 and corresponding setting.

Figure 6-20 Relationship between AI1/AI2 and corresponding setting



All input filter time: to adjust the sensitivity of analog input. Increasing the value properly can enhance analog input anti-interference but may reduce the sensitivity of analog input.

Function code	Name	Description	Setting range	Default
P05.22	AI2 lower limit	0.00V-P05.24	0.00-P05.24	0.00V
P05.23	Corresponding setting of Al2 lower limit	-100.0%-P05.25	-100.0-P05.25	0.0%
P05.24	AI2 upper limit	P05.22-10.00V	P05.22-10.00	10.00V
P05.25	Corresponding setting of AI2 upper limit	P05.23-100.0%	P05.23-100.0	100.0%
P05.26	Al2 input filter time	0.00s-10.00s	0.00-10.00	2.00s
P05.27	AI3 lower limit	0.00V-P05.29	-1000-P05.29	0.00V
P05.28	Corresponding setting of AI3 lower limit	-100.0%-P05.30	-100.0-P05.30	0.0%
P05.29	AI3 upper limit	P05.27-10.00V	P05.27-10.00	10.00V
P05.30	Corresponding setting of AI3 upper limit	P05.28–100.0%	P05.28-100.0	100.0%
P05.31	AI3 input filter time	0.00s-10.00s	0.00-10.00	2.00s
P05.32	AI4 lower limit	-10.00V-P05.34	-10.00-P05.34	0.00V
P05.33	Corresponding setting of AI4 lower limit	-100.0%-P05.35	-100.0-P05.35	0.0%
P05.34	AI4 upper limit	P05.32-10.00V	P05.32-10.00	10V
P05.35	Corresponding setting of AI4 upper limit	P05.33-100.0%	P05.33-100.0	100.0%
P05.36	AI4 input filter time	0.00s-10.00s	0.00-10.00	2.00s

The setting of AI2, AI3 and AI4 is the same as that of AI1. AI4 is only -10V-+10V voltage type.

Function code	Name	Description	Setting range	Default
P05.37	Al1 mode switchover		0-1	0
P05.38	AI12 mode switchover	0: Current 1: Voltage	0-1	0
P05.39	AI3 mode switchover		0-1	0
P05.40	Al1 calibration configuration	0–2 0: Disable	0–2	0
P05.41	AI2 calibration configuration	1: Calibrate AI lower limit 2: Calibrate AI upper limit	0–2	0

Function code	Name	Description	Setting range	Default
P05 42	AI3 calibration		0-2	0
1 05.42	configuration		0 2	0
P05.43	Al4 zero			
	calibration	-10.00%-10.00%	-10.00-10.00	0.00
	coefficient			

The calibration method of P05.40–P05.42 is as follows: Take the calibration of AI1 as an example, when input 4mA–20mA corresponds to 0–10V, first calibrate AI lower limit, input 4mA, set P05.40=1, and wait for AI1 input value in the instant message to be 0%. Then calibrate AI upper limit, set P05.40=2, input 20mA, wait for AI1 input value in the instant message to be 100%, set P05.40=0, AI1 calibration is completed.

Function code	Name	Description	Setting range	Default
P05.44	Communication analog lower limit	0.000V-P05.46	0.000-P05.46	0.000V
P05.45	Corresponding setting of communication analog lower limit	-100.0%-P05.47	-100.0-P05.47	0.0%
P05.46	Communication analog upper limit	P05.44-10.000V	P05.44-10.000	10.000V
P05.47	Corresponding setting of communication analog upper limit	P05.45–100.0%	P05.45-100.0	100.0%
P05.48	Communication setting range	0.00–100.00mm	0.00-100.00	0.00mm
P05.49	S1 switch-on delay	0.00-50.00s	0.00-50.00s	1.50s
P05.50	S1 switch-off delay	0.00–50.00s	0.00-50.00	1.50s
P05.51	S2 switch-on delay	0.00-50.00s	0.00-50.00	1.50s
P05.52	S2 switch-off delay	0.00–50.00s	0.00-50.00	1.50s
P05.53	S3 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.54	S3 switch-off delay	0.00-50.00s	0.00-50.00	1.50s
P05.55	S4 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.56	S4 switch-off delay	0.00–50.00s	0.00-50.00	1.50s
P05.57	S5 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.58	S5 switch-off delay	0.00–50.00s	0.00-50.00	1.50s
P05.59	S6 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.60	S6 switch-off delay	0.00–50.00s	0.00-50.00	1.50s
P05.61	S7 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.62	S7 switch-off delay	0.00–50.00s	0.00-50.00	1.50s
P05.63	S8 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.64	S8 switch-off delay	0.00–50.00s	0.00-50.00	1.50s
P05.65	S9 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.66	S9 switch-off delay	0.00-50.00s	0.00-50.00	1.50s
P05.67	S10 switch-on delay	0.00–50.00s	0.00-50.00	1.50s
P05.68	S10 switch-off delay	0.00–50.00s	0.00-50.00	1.50s

Function code	Name	Description	Setting range	Default
P05.69	S11 switch-on delay	0.00-50.00s	0.00-50.00	1.50s
P05.70	S11 switch-off delay	0.00-50.00s	0.00-50.00	1.50s
P05.71	S12 switch-on delay	0.00-50.00s	0.00-50.00	1.50s
P05.72	S12 switch-off delay	0.00-50.00s	0.00-50.00	1.50s

# P06 group Output terminal functions

Goodrive5000 medium voltage variable-frequency speed regulation system provides 10 multi-function relay output terminals (RO1–RO10, a maximum of 22 multi-function relay outputs are supported) and 5 multi-function analog output terminals (AO1–AO5) as standard configuration.

Function code	Name	Description	Setting range	Default
P06.00	RO1 output	0: No output		1
P06.01	RO2 output	1: In system running		2
P06.02	RO3 output	2: Fault output		11
P06.03	RO4 output	3: Frequency level detection FDT		12
P06.04	RO5 output	output 4: Froquency reached		0
P06.05	RO6 output	5: Zero speed running		0
P06.06	RO7 output	6: Variable-frequency working		0
P06.07	RO8 output	state		0
P06.08	RO9 output	7: Power frequency bypass		0
P06.09	RO10 output	working state		0
P06.10	RO11 output	8: Running time reached		0
P06.11	RO12 output	9: Running forward		0
P06.12	RO13 output	10: Running reversely		0
P06.13	RO14 output	request)		0
P06.14	RO15 output	12: Alarm output		0
P06.15	RO16 output	Variable-frequency:		0
P06.16	RO17 output	13: Permission of medium voltage	0-91	0
P06.17	RO18 output	switch QF1M1 switching on		0
P06.18	RO19 output	14: Permission of medium voltage		0
P06.19	RO20 output	SWITCH QF1M2 SWITCHING ON		0
P06.20	RO21 output	switch OF1M3 switching on		0
P06.21	RO22 output	<ul> <li>16: Permission of medium voltage switch QF1M4 switching on</li> <li>17: Permission of medium voltage switch QF1M5 switching on</li> <li>18: Permission of medium voltage switch QF1M6 switching on</li> <li>19: Permission of medium voltage switch QF1M7 switching on</li> <li>20: Permission of medium voltage switch QF1M8 switching on power frequency</li> <li>Power frequency:</li> <li>21: Permission of medium voltage</li> </ul>		0

Function code	Name	Description	Setting range	Default
		switch QF2M1 switching on		
		22: Permission of medium voltage		
		switch QF2M2 switching on		
		23: Permission of medium voltage		
		switch QF2M3 switching on		
		24: Permission of medium voltage		
		switch QF2M4 switching on		
		25: Permission of medium voltage		
		switch QF2M5 switching on		
		26: Permission of medium voltage		
		switch QF2M6 switching on		
		27: Permission of medium voltage		
		switch QF2M7 switching on		
		28: Permission of medium voltage		
		switch QF2M8 switching on		
		29: Permission of medium voltage		
		switch QF1M1 switching off		
		30: Permission of medium voltage		
		switch QF1M2 switching off		
		31: Permission of medium voltage		
		switch QF1M3 switching off		
		32: Permission of medium voltage		
		switch OF1M4 switching off		
		33: Permission of medium voltage		
		switch QF1M5 switching off		
		34: Permission of medium voltage		
		switch OF1M6 switching off		
		35: Permission of medium voltage		
		switch OF1M7 switching off		
		36: Permission of medium voltage		
		switch OF1M8 switching off		
		37. Permission of medium voltage		
		switch OF2M1 switching off		
		38. Permission of medium voltage		
		switch OF2M2 switching off		
		39. Permission of medium voltage		
		switch OF2M3 switching off		
		40. Permission of medium voltage		
		switch OF2M4 switching off		
		41. Permission of medium voltage		
		switch OF2M5 switching off		
		42. Permission of medium voltage		
		switch OE2M6 switching off		
		43. Permission of medium voltage		
		switch OE2M7 switching off		
		At Dormission of modium voltage		
		switch OE2M <sup>9</sup> switching off		
		AE: Variable frequency working		
		45. Variable-frequency Working		
		state of switching cabinet 1		
		46: Power-Trequency Working		
		state of switching cabinet 1 46: Power-frequency working state of switching cabinet 1		

Function code	Name	Description	Setting range	Default
		47: Variable-frequency working		
		state of switching cabinet 2		
		48: Power-frequency working		
		state of switching cabinet 2		
		49: Variable-frequency working		
		state of switching cabinet 3		
		50: Power-frequency working		
		state of switching cabinet 3		
		51: Variable-frequency working		
		state of switching cabinet 4		
		52: Power-frequency working		
		state of switching cabinet 4		
		53: Variable-frequency working		
		state of switching cabinet 5		
		54: Power-trequency working		
		state of switching cabinet 5		
		55: Variable-frequency working		
		state of switching cabinet 6		
		56: Power-frequency working		
		state of switching cabinet 6		
		state of switching sphinet 7		
		State of Switching Cabinet 7		
		state of switching cabinet 7		
		50. Variable-frequency working		
		state of switching cabinet 8		
		60: Power-frequency working		
		state of switching cabinet 8		
		(45–60: Both power frequency		
		and variable frequency valid at		
		the same time indicates fault.)		
		61: Unit bypass state		
		62: Remote-local state		
		63–64: Reserved		
		65: Low-voltage commissioning		
		vacuum contactor KM1 control		
		66: Low-voltage commissioning		
		vacuum contactor KM2 control		
		67: Switching cabinet 1# KM1		
		feedback signal		
		68: Switching cabinet 1# KM2		
		feedback signal		
		69: Switching cabinet 1# KM3		
		feedback signal		
		70: Switching cabinet 2# KM1		
		feedback signal		
		71: Switching cabinet 2# KM2		
		teedback signal		
		72: Switching cabinet 2# KM3		
		teedback signal		
		73: Switching cabinet 3# KM1		
Function code	Name	Description	Setting range	Default
---------------	------	------------------------------	---------------	---------
		feedback signal		
		74: Switching cabinet 3# KM2		
		feedback signal		
		75: Switching cabinet 3# KM3		
		feedback signal		
		76: Switching cabinet 4# KM1		
		feedback signal		
		77: Switching cabinet 4# KM2		
		feedback signal		
		78: Switching cabinet 4# KM3		
		feedback signal		
		79: Switching cabinet KM4		
		feedback signal		
		80: Switching cabinet 1 QS1		
		feedback signal		
		81: Switching cabinet 1 QS2		
		feedback signal		
		82: Switching cabinet 1 QS3		
		feedback signal		
		83: Switching cabinet 2 QS1		
		feedback signal		
		84: Switching cabinet 2 QS2		
		feedback signal		
		85: Switching cabinet 2 QS3		
		feedback signal		
		86: Switching cabinet 3 QS1		
		feedback signal		
		87: Switching cabinet 3 QS2		
		feedback signal		
		88: Switching cabinet 3 QS3		
		teedback signal		
		89: Switching cabinet 4 QS1		
		feedback signal		
		90: Switching cabinet 4 QS2		
		feedback signal		
		91: Switching cabinet 4 QS3		
		feedback signal		

0: No output.

1: In running: When the system is running, ON signal will be output.

2: Fault output: When any fault occurs to the system, ON signal will be output.

3: Frequency level detection signal FDT. Refer to the descriptions for P08.15–P08.16.

4: The frequency reached. Refer to the description of P08.17.

5: In zero-speed running. When the system is running and the output frequency is zero, ON signal will be output.

6: Variable-frequency working state. When the system is in the variable-frequency state, ON signal will be output.

7: Power frequency bypass working state. When the system is in the power frequency bypass state, ON signal will be output.

8: Running time reached. When the local accumulative running time reaches the set time in P07.11, ON signal will be output.

9: Running forward

10: Running reversely

11: Ready for running. When main circuit and control circuit powers are established, the protection functions do not act. When the system is ready to run, ON signal will be output.

12: Alarm output: When the system alarms (not to cause fault abnormality), ON signal will be output.

13: Permission of medium voltage switch QF1M1 switching on

14: Permission of medium voltage switch QF1M2 switching on

15: Permission of medium voltage switch QF1M3 switching on

16: Permission of medium voltage switch QF1M4 switching on

17: Permission of medium voltage switch QF1M5 switching on

18: Permission of medium voltage switch QF1M6 switching on

19: Permission of medium voltage switch QF1M7 switching on

20: Permission of medium voltage switch QF1M8 switching on

21: Permission of medium voltage switch QF2M1 switching on

22: Permission of medium voltage switch QF2M2 switching on

23: Permission of medium voltage switch QF2M3 switching on

24: Permission of medium voltage switch QF2M4 switching on

25: Permission of medium voltage switch QF2M5 switching on

26: Permission of medium voltage switch QF2M6 switching on

27: Permission of medium voltage switch QF2M7 switching on

28: Permission of medium voltage switch QF2M8 switching on

13–28: Permissions of medium voltage switch switching on. After the system receives the variable-frequency running signals, it needs to pass self-testing and waiting time set in P01.30, and then send signals to the higher level (console or medium voltage switch). The higher level will switch on the higher level medium voltage switch after receiving the signal.

29: Permission of medium voltage switch QF1M1 switching off

30: Permission of medium voltage switch QF1M2 switching off

31: Permission of medium voltage switch QF1M3 switching off

32: Permission of medium voltage switch QF1M4 switching off

33: Permission of medium voltage switch QF1M5 switching off

34: Permission of medium voltage switch QF1M6 switching off

35: Permission of medium voltage switch QF1M7 switching off

36: Permission of medium voltage switch QF1M8 switching off

37: Permission of medium voltage switch QF2M1 switching off

38: Permission of medium voltage switch QF2M2 switching off

39: Permission of medium voltage switch QF2M3 switching off

40: Permission of medium voltage switch QF2M4 switching off

41: Permission of medium voltage switch QF2M5 switching off

42: Permission of medium voltage switch QF2M6 switching off

43: Permission of medium voltage switch QF2M7 switching off

44: Permission of medium voltage switch QF2M8 switching off

29–44: Permissions of medium voltage switch switching off. When the system needs to switch off the higher level medium voltage switch, it is necessary to send signals to the higher level (console or medium voltage vacuum breaker) which will have to switch off the higher level medium voltage switch to protect the system.

45: Variable-frequency working state of switching cabinet 1

46: Power-frequency working state of switching cabinet 1

47: Variable-frequency working state of switching cabinet 2

48: Power-frequency working state of switching cabinet 2

49: Variable-frequency working state of switching cabinet 3

50: Power-frequency working state of switching cabinet 3

51: Variable-frequency working state of switching cabinet 4

52: Power-frequency working state of switching cabinet 4

53: Variable-frequency working state of switching cabinet 5

54: Power-frequency working state of switching cabinet 5

55: Variable-frequency working state of switching cabinet 6

56: Power-frequency working state of switching cabinet 6

57: Variable-frequency working state of switching cabinet 7

58: Power-frequency working state of switching cabinet 7

59: Variable-frequency working state of switching cabinet 8

60: Power-frequency working state of switching cabinet 8 (45–60: Both power frequency and variable frequency valid at the same time indicates fault.)

45–60: The working states of switching cabinets 1–8.

When the corresponding motor of the switching cabinet is in the variable-frequency state, ON signal will be output in the variable-frequency working state. When the corresponding motor of the switching cabinet is in the power frequency state, ON signal will be output in the power frequency working state.

61: Unit bypass state

When the system has unit bypass, ON signal will be output.

62: Remote-local state

When the switch is at the local state, the system can only control through the local command channel and output OFF signal; and at the remote state, the system can control through terminals, Modbus and fieldbus, and output ON signal.

63-64: Reserved

65: Low-voltage commissioning vacuum contactor KM1 control

66: Low-voltage commissioning vacuum contactor KM2 control

65–66: Low-voltage commissioning vacuum contactor control (mainly used for low-voltage power-on commissioning of the factory)

67: Switching cabinet 1# KM1 feedback signal

68: Switching cabinet 1# KM2 feedback signal

69: Switching cabinet 1# KM3 feedback signal

70: Switching cabinet 2# KM1 feedback signal

71: Switching cabinet 2# KM2 feedback signal

72: Switching cabinet 2# KM3 feedback signal

- 73: Switching cabinet 3# KM1 feedback signal
- 74: Switching cabinet 3# KM2 feedback signal
- 75: Switching cabinet 3# KM3 feedback signal
- 76: Switching cabinet 4# KM1 feedback signal
- 77: Switching cabinet 4# KM2 feedback signal
- 78: Switching cabinet 4# KM3 feedback signal
- 79: Switching cabinet KM4 feedback signal

✓ Note: ON signals refer to the signals of the relay NO contact on and NC contact off.

- 80: Switching cabinet 1 QS1 feedback signal
- 81: Switching cabinet 1 QS2 feedback signal
- 82: Switching cabinet 1 QS3 feedback signal
- 83: Switching cabinet 2 QS1 feedback signal
- 84: Switching cabinet 2 QS2 feedback signal
- 85: Switching cabinet 2 QS3 feedback signal
- 86: Switching cabinet 3 QS1 feedback signal
- 87: Switching cabinet 3 QS2 feedback signal
- 88: Switching cabinet 3 QS3 feedback signal
- 89: Switching cabinet 4 QS1 feedback signal
- 90: Switching cabinet 4 QS2 feedback signal
- 91: Switching cabinet 4 QS3 feedback signal

Function code	Name	Description	Setting range	Default
P06.22	AO1 output	0: Running frequency (100%	0-10	0
P06.23	AO2 output	corresponds to the max. frequency)	0-10	0
P06.24	AO3 output	1: Set frequency (100% corresponds	0-10	0
P06.25	AO4 output	to the max. frequency)	0-10	0
P06.26	AO5 output	<ul> <li>2: Output current valid value (100% corresponds to twice the system rated current)</li> <li>3: Output current valid value (100% corresponds to twice the motor rated current)</li> <li>4: Output voltage (100% corresponds to 1.2 times the system rated voltage)</li> <li>5: Output power (100% corresponds to twice the motor rated power)</li> <li>6: Output torque (100% corresponds to twice the motor rated torque)</li> <li>7: Al1 input value (100% corresponds to 10V)</li> <li>8: Al2 input value (100% corresponds to 10V)</li> <li>9: Al3 input value (100% corresponds to 10V)</li> <li>10: Al4 input value (100% corresponds to 10V)</li> </ul>	0–10	0

AO1, AO2, and AO3 provide 0–10V voltage output or 4–20mA current output which can be selected by the jumpers SW1 (AO1), SW2 (AO2), and SW3 (AO3) on the I/O board. AO4 and AO5 only provide current output.

Set value	Function	Range
0	Running frequency	100% corresponds to the max. output frequency
1	Set frequency	100% corresponds to the max. output frequency
2	Output current valid value	100% corresponds to twice the rated current of variable-frequency speed regulation system
3	Output current valid value	100% corresponds to twice the motor rated current
4	Output voltage	100% corresponds to 1.2 times the rated voltage of variable-frequency speed regulation system
5	Output power	100% corresponds to twice the motor rated power
6	Output torque	100% corresponds to twice the motor rated torque
7	Al1 input	100% corresponds to 10V
8	Al2 input	100% corresponds to 10V
9	Al3 input	100% corresponds to 10V
10	Al4 input	100% corresponds to 10V

Function code	Name	Description	Setting range	Default
P06.27	AO1 output lower limit	0.00%-P06.29	0.00%-P06.29	0.00%
P06.28	AO1 output corresponding to lower limit	0.00V-P06.30	0.00V-P06.30	0.00V
P06.29	AO1 output upper limit	P06.27-100.0%	P06.27-100.0	100.0%
P06.30	AO1 output corresponding to upper limit	P06.28-10.00V	P06.28-10.00	10.00V
P06.31	AO2 output lower limit	0.00%-P06.33	0.00%-P06.33	0.00%
P06.32	AO2 output corresponding to lower limit	0.00V-P06.34	0.00V-P06.34	0.00V
P06.33	AO2 output upper limit	P06.31-100.0%	P06.31-100.0	100.0%
P06.34	AO2 output corresponding to upper limit	P06.32-10.00V	P06.32-10.00	10.00V
P06.35	AO3 output lower limit	0.00%-P06.37	0.00%-P06.37	0.00%
P06.36	AO3 output corresponding to lower limit	0.00V-P06.38	0.00V-P06.38	0.00V
P06.37	AO3 output upper limit	P06.35-100.0%	P06.35-100.0	100.0%
P06.38	AO3 output corresponding to	P06.36-10.00V	P06.36-10.00	10.00V

Function code	Name	Description	Setting range	Default
	upper limit			
P06.39	AO4 output lower limit	0.00%-P06.41	0.00%-P06.41	0.0%
P06.40	AO4 output corresponding to lower limit	0.00V-P06.42	0.00V-P06.42	0.00V
P06.41	AO4 output upper limit	P06.39-100.0%	P06.39-100.0	100.0%
P06.42	AO4 output corresponding to upper limit	P06.40-10.00V	P06.40-10.00	10.00V
P06.43	AO5 output lower limit	0.00%-P06.45	0.00%-P06.45	0.0%
P06.44	AO5 output corresponding to lower limit	0.00V-P06.46	0.00V-P06.46	0.00V
P06.45	AO5 output upper limit	P06.43-100.0%	P06.43-100.0	100.0%
P06.46	AO5 output corresponding to upper limit	P06.44-10.00V	P06.44-10.00	10.00V

Analog output is shown in the following figure.

#### Figure 6-21 Relationship between the reference value and analog output



**Note:** When current output is selected for AO1, AO2 and AO3, 1mA corresponds to 0.5V.

Function code	Name	Description	Setting range	Default
P06.47	RO1 switch-on delay	0.00-50.00s	0.00–50.00	0.00s
P06.48	RO1 switch-off delay	0.00-50.00s	0.00–50.00	0.00s
P06.49	RO2 switch-on delay	0.00–50.00s	0.00–50.00	0.00s
P06.50	RO2 switch-off delay	0.00-50.00s	0.00–50.00	0.00s
P06.51	RO3 switch-on delay	0.00-50.00s	0.00-50.00	0.00s

Function code	Name	Description	Setting range	Default
P06.52	RO3 switch-off delay	0.00-50.00s	0.00-50.00	0.00s
P06.53	RO4 switch-on delay	0.00-50.00s	0.00-50.00	0.00s
P06.54	RO4 switch-off delay	0.00-50.00s	0.00-50.00	0.00s
P06.55	RO5 switch-on delay	0.00-50.00s	0.00-50.00	0.00s
P06.56	RO5 switch-off delay	0.00-50.00s	0.00–50.00	0.00s
P06.57	RO6 switch-on delay	0.00-50.00s	0.00–50.00	0.00s
P06.58	RO6 switch-off delay	0.00-50.00s	0.00-50.00	0.00s
P06.59	RO7 switch-on delay	0.00-50.00s	0.00-50.00	0.00s
P06.60	RO7 switch-off delay	0.00-50.00s	0.00-50.00	0.00s
P06.61	RO8 switch-on delay	0.00-50.00s	0.00-50.00	0.00s
P06.62	RO8 switch-off delay	0.00–50.00s	0.00–50.00	0.00s

# P07 group Human-machine interface

Function code	Name	Description	Setting range	Default
P07.00	Touch screen version	0.00–655.35	0.00-655.35	Default setting
P07.01	Standard I/O board software version	0.00-655.35	0.00-655.35	Default setting
P07.02	Software version (FPGA)	0.00–655.35	0.00-655.35	Default setting
P07.03	Software version (DSP)	0.00–655.35	0.00-655.35	Default setting
P07.04	Software version (ARM)	0.00-655.35	0.00-655.35	Default setting
P07.05	Unit MCU version	0.00–655.35	0.00-655.35	Default setting

The touch screen version is read-only.

The standard I/O board software version is read-only.

The software version (FPGA) is read-only.

The software version (DSP) is read-only.

The software version (ARM) is read-only.

The unit MCU version is read-only.

Function code	Name	Description	Setting range	Default
P07.06	Max. number of available units	1-12	1–12	Default setting

The system supports up to 12 units per phase in series, and the max. number of units available to users is 12 at the factory according to the users' purchase needs.

Function code	Name	Description	Setting range	Default
P07.07	Supported motor type	0: Only AM 1: Only SM 2: SM and AM	0–2	Default setting

According to the users' purchase needs, set the supported motor types at the factory. 0 indicates that only AMs are supported, 1 indicates that only SMs are supported, and 2 indicates that both SMs and AMs are supported.

Function code	Name	Description	Setting range	Default
P07.08	Unit FPGA version	0-655.35	0-655.35	Default setting

The unit FPGA version is read-only.

Function code	Name	Description	Setting range	Default
P07.09	Two-quadrant and four-quadrant selection	0: Two-quadrant 1: Four-quadrant	0-1	Default setting

P07.09 is used to set whether a two-quadrant or four-quadrant VFD is supported.

0: The two-quadrant VFD is supported.

1: The four-quadrant VFD is supported.

Function code	Name	Description	Setting range	Default
P07.10	Max. number of switching	0-4	0-4	Default
	cabinets			setting

It is applied in the cases where one VFD drives multiple motors, supporting a maximum of 4 switching cabinets. Set the parameters at the factory according to the users' purchase needs.

Function code	Name	Description	Setting range	Default
P07.11	Local accumulative	0–65535h	0-65535	0h
	running time			

The function code is used to record the accumulative running time of the system by hours. It is read-only.

Function code	Name	Description	Setting range	Default
P07.12	Local running time	0–65535min	0-65535	0min

Function code	Name	Description	Setting range	Default
P07.13	Factory bar code 1	0–65535	0-65535	0
P07.14	Factory bar code 2	0-65535	0-65535	0
P07.15	Factory bar code 3	0-65535	0-65535	0
P07.16	Factory bar code 4	0-65535	0-65535	0
P07.17	Factory bar code 5	0-65535	0-65535	0
P07.18	Factory bar code 6	0-65535	0-65535	0

The function code is used to set the current running time of the system by minutes. If the running time is reached, users can operate after the system outputs the signal of running time reached.

### **P08 group Enhanced functions**

Function code	Name	Description	Setting range	Default
P08 00	ACC time 2	0.1-3600.0s	0 1-3600 0	Model
1 00.00	Ace time 2	0.1 3000.03	0.1 3000.0	depended
D09 01	DEC time 2	0.1.2600.0c	0 1 2600 0	Model
P00.01	DEC time 2	0.1-3000.05	0.1-3600.0	depended
		0.1. 2000.0	0.1. 2000.0	Model
P08.02	ACC time 3	0.1-3600.05	0.1-3600.0	depended
000 02		0.1. 2000.0	0.1.2000.0	Model
P08.03	DEC time 3	0.1-3600.05	0.1-3600.0	depended
	ACC time 1	0.1.2600.0c	0 1 2600 0	Model
P08.04	ACC time 4	0.1-3600.05	0.1-3600.0	depended
P08.05	DEC time 1	0.1. 2000.0	0.1.2000.0	Model
	DEC time 4	0.1-3000.05	0.1-3600.0	depended

The function codes P08.00–P08.05 can be switched by the combinations of multi-function input terminals (see the description of P05). The definitions of different ACC/DEC time are the same, as described in P00.16 and P00.17.

Function code	Name	Description	Setting range	Default
P08.06	Running frequency of jogging	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	5.00Hz
P08.07	ACC time of jogging	0.1-3600.0s	0.1-3600.0	Model depended
P08.08	DEC time of jogging	0.1-3600.0s	0.1-3600.0	Model depended

Jogging start/stop mode: Direct start and decelerate to stop.

ACC time for jogging means the time needed for the variable-frequency speed regulation system speeds up from 0Hz to the max. output frequency (P00.10) during jogging.

DEC time for jogging means the time needed for the variable-frequency speed regulation system speeds down from the max. output frequency (P00.10) to 0Hz during jogging.

#### **Note:**

- Jogging enjoys the top priority. Even in the torque mode, if the jogging command is valid, it is necessary to switch into speed mode to respond to the jogging command.
- When the jogging command is valid, run in linear ACC/DEC according to jogging ACC/DEC time. If there is no running command after jogging is cancelled, stop according to the jogging DEC curve, otherwise, switch into the ACC/DEC curve of normal running.

Function code	Name	Description	Setting range	Default
P08.09	Jump frequency 1	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz
P08.10	Jump frequency amplitude 1	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz
P08.11	Jump frequency 2	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz
P08.12	Jump frequency amplitude 2	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz
P08.13	Jump frequency 3	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz
P08.14	Jump frequency amplitude 3	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz

The variable-frequency speed regulation system can avoid mechanical resonance points by setting jump frequencies. Goodrive5000 integrated machine medium voltage variable-frequency speed regulation system supports the setting of three jump frequencies. If three jump frequency points are set to 0, this function is invalid.

**Note:** The qualified object of the jump frequency is the set frequency. For example,  $f_0$ =initial set frequency,  $f_j$ =jump frequency,  $\Delta_f$ =jump amplitude, f=actual running frequency. If (f<sub>j</sub>- $\Delta$ f/2)<f\_0 $\leq$ f\_j, thus f=f<sub>j</sub>- $\Delta$ f/2. If f<sub>j</sub><f\_0 $\leq$ (f<sub>j</sub>+ $\Delta$ f/2), thus f=f<sub>j</sub>+ $\Delta$ f/2.



Function code	Name	Description	Setting range	Default
P08.15	Auto fault reset count	0–3	0-3	0

#### Figure 6-22 Jump frequency diagram

Function code	Name	Description	Setting range	Default
P08.16	Auto fault reset interval	0.1–100.0s	0.1-100.0	1.0s

Auto fault reset count: When the system uses automatic fault reset, it is used to set the number of automatic fault reset times. The system will automatically reset and start speed tracking when light faults occurs. If the continuous reset times exceed the set value during the period set in P08.32, the system stops and manual intervention is needed.

Auto fault reset interval: Time interval from when a fault occurred to when automatic fault reset takes effect.

Function code	Name	Description	Setting range	Default
P08.17	FDT electrical level detection value	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	50.00Hz
P08.18	FDT lagging detection value	0.0–100.0% (FDT electrical level)	0.0-100.0	5.0%

When the output frequency exceeds the corresponding frequency FDT electrical level, output the signal until the output frequency decreases to a value lower than the corresponding frequency (FDT retention detection value). The specific waveform is shown in Figure 6-23.





**Note:** FDT electrical level retention value is the percentage corresponding to FDT electrical level.

Function code	Name	Description	Setting range	Default
P08.19	Detection amplitude for frequency being reached	0.0–100.0% (of the max. frequency)	0.0-100.0	0.0%

The output frequency of the system outputs pulse signals within the detection range of the set frequency, as shown in Figure 6-24.

#### Figure 6-24 Detection amplitude value for frequency being reached



**Note:** The detection amplitude value for frequency being reached is the percentage corresponding to the maximum frequency (P00.10).

Function code	Name	Description	Setting range	Default
P08.20	Overmodulation	0: Overmodulation is invalid 1: Overmodulation is valid	0-1	0

Under the conditions of low voltage (below 85% of rated voltage) or heavy loads for a long time, the system can improve utilization of bus voltage and thus raise output voltage by overmodulation.

Function code	Name	Description	Setting range	Default
P08.21	Running mode of cooling fan	0: Normal mode 1: The fan keeps running after power-on.	0-1	0

0: During normal running mode, the fan starts running under the following conditions.

- 1) The temperature of the transformer is higher than the value set in P23.20 or the temperature of the unit is higher than the value set in P23.22.
- 2) The system is running.
- 3) Conditions for the fan stops running: The system does not run, and the temperature of the transformer is lower than the value set in P23.21 and the temperature of the unit is lower than the value set in P23.23.
- 1: The fan keeps running after power-on. The fan keeps running after the system is powered on.

Function code	Name	Description	Setting range	Default
P08.22	Alarm reset interval	0.0s (The alarm function is invalid) 0.1–3600.0s	0.0-3600.0	1.0s

**Note:** Alarm means when the system works abnormally, if users do not pay attention to it, the abnormity will cause faults. Users can select whether it is necessary for the system to report alarms and the interval of automatic alarm reset.

Function code	Name	Description	Setting range	Default
P08.23	Reference frequency	0.0-100.0%	0.0-100.0	0.0%
	disconnection			

Function code	Name	Description	Setting range	Default
	threshold			
P08.24	Reference	0.0–360.0s		
	frequency		0.0-360.0	0.0s
	disconnection			
	time			

Set the frequency disconnection threshold: 100% of the threshold corresponds to the upper limit of running frequency (P00.11), when the system detects the set frequency less than or equal to the set frequency threshold, it will start timing. If the timing exceeds the disconnection time, the system will reports the frequency setting disconnection fault.

Function code	Name	Description	Setting range	Default
P08.25	Drop control	0.00-10.00Hz	0.00-10.00	0.00Hz
P08.26	Reserved	0–65535	0-65535	0
	Unit alarm			
P08.27	temperature	60.0-100.0°C	60.0-100.0	75°C
	setting			

When the unit temperature exceeds the temperature set in P08.27, too high unit temperature is reported.

Function code	Name	Description	Setting range	Default
P08.28	Droop control	0: Droop control mode 1	0-1	0
	mode	1: Droop control mode 2		-
	Droop control			
P08.29	mode 1 droop	-10.00–10.00Hz	-10.00-10.00	0.00Hz
	frequency			
	Droop control			
P08.30	mode 2 droop	-10.00–10.00Hz	-10.00-10.00	0.00Hz
	frequency			

When several variable-frequency speed regulation systems drive one load, due to different speeds, unbalanced load distribution will make the system at the highest speed bear heavy load. The droop control is featuring speed changing along with loads and balanced distribution. Adjust the parameter from the smallest one to the largest one. The relationship between the load and output frequency is shown as Figure 6-25.

#### Figure 6-25 Motor characteristics in droop control



The parameter is used to adjust the frequency change rate of droop control for the system.

Function code	Name	Description	Setting range	Default
P08.31	Ambient temperature alarm detection value	0–100°C	0-100	60°C
P08.32	Initialization time of fault reset count	0: The fault reset count will not be automatically reset. 1–65535min: The auto fault reset count is cleared after the time is set.	0–65535	60min
P08.33	Allowed time of undervoltage fault reset	0–100s	0-100	10s
P08.34- P08.39	Reserved	0–65535	0-65535	0

Ambient temperature alarm detection value: When the ambient temperature detection value exceeds the alarm value, the system will reports ambient temperature too high.

Initialization time of fault reset count: See the description of P08.15.

Allowed time of undervoltage fault reset: After the continuous undervoltage time exceeds the set value, the fault will not be automatically reset even if the input voltage is restored.

# P09 group Fault record parameters

Function code	Name	Description	Setting range	Default
P09.00	Action selection 1 of DSP fault	0xAAAA–0xFFFF Two bits stand for a fault. 00: No processing 01: Alarm 10: Light fault, stop but not cut off medium voltage power. 11: Serious fault, stop and cut off medium voltage power. Automatic reset is disabled.	0xAAAA-0xFFFF	0xEABA
P09.01	Action selection 2 of DSP fault	0x8AAA-0xFFFF	0x8AAA-0xFFFF	0x8EAA
P09.02	Action selection 3 of DSP fault	0xAA82-0xFFFF	0xAA82-0xFFFF	0xAA82
P09.03	Action selection 4 of DSP fault	0x0000-0xFFFF	0x0000-0xFFFF	0x07FC
P09.04	Action selection 1 of ARM fault	0x0000-0xFFFF	0x0000-0xFFFF	0x555D
P09.05	Action selection 2 of ARM fault	0x0000-0xFFFF	0x0000-0xFFFF	0x6555
P09.06	Action selection 3 of ARM fault	0x0000-0xFFFF	0x0000-0xFFFF	0x1555
P09.07	Action selection 4	0x0000-0xFFFF	0x0000-0xFFFF	0x1555

Function code	Name	Description	Setting range	Default
	of ARM fault			
P09.08	Action selection 1 of unit fault	0x2AEA-0xFFFF	0x2AEA-0xFFFF	0xAAEA
P09.09	Action selection 2 of unit fault	0x0AAA-0xFFFF	0x0AAA-0xFFFF	0xAAAA
P09.10	Action selection 3 of unit fault	0xAABF-0XFFFF	0xAABF-0xFFFF	0xAABF
P09.11	Action selection 4 of unit fault	0x000B-0xFFFF	0x000B-0xFFFF	0x000B

The fault action includes 4 types: no processing, alarm, light fault (stop but not cut off medium voltage power), and serious fault (stop and cut off medium voltage power). Each two bits in the fault action selection word are combined to set the action selection when a certain fault occurs.

00: No processing.

01: Alarm.

10: Light fault, stop but not cut off medium voltage power. Automatic fault reset is enabled.

Function code	Name	Description	Setting range	Default
P09.12	2th-last DSP fault 1	Each bit stands for 1 fault type. 0: No fault; 1: Fault Bit0: Software overcurrent Bit1: Hardware overcurrent Bit2: Grid overvoltage Bit3: Grid undervoltage Bit4: Motor overload Bit5: VFD overload Bit5: VFD overload Bit6: Phase loss on output side Bit7: Input phase loss detection fault Bit8: Current detection fault Bit9: Parameter autotuning fault Bit10: Encoder disconnection fault Bit11: Encoder reversal fault Bit12: Handshake fault Bit13: Input overcurrent Bit14: Voltage detection transmission board fault Bit15: Phase sequence inconsistency	0x0000-0xFFFF	0x0000
P09.13	2th-last DSP fault 2	Each bit stands for 1 fault type. 0: No fault; 1: Fault Bit16: Magnetic pole position detection Bit17: Speed out-of-tolerance-range fault Bit18: VFD overspeed fault Bit19: Resolver position reading error	0x0000-0xFFFF	0x0000

11: Serious fault, stop and cut off medium voltage power. Automatic fault reset is disabled.

Function code	Name	Description	Setting range	Default
		Bit20: The resolver can't track the		
		motor rotation		
		Bit21: Resolver signal distortion fault		
		Bit22: UVW encoder connection fault		
		Bit23: UVW encoder zero position		
		fault		
		Bit24: Encoder parameter		
		autotuning fault		
		Bit25: Transformer loss is too large		
		Bit26: Reactive current is too large		
		Bit27: Transformer overload		
		Bit28: Input voltage imbalance		
		Bit29: Input current imbalance		
		Bit3031: Reserved		

P09.12 and P09.13 includes 32 DSP fault types, each bit stands for 1 fault type, bitn=1 means some fault occur, bitn=0 means the fault does not occur.

Similarly, P09.14 and P09.15 includes 32 ARM fault types, and P09.16 and P09.17 includes 26 unit fault types.

The relationship between fault word and fault type as follows:

For example, if a DSP hardware overcurrent fault occurs in P09.12, bit1 of P09.12 (bit15–bit0) is 1. If P09.00 is set to 0XEABA, bit3–bit2 of P09.00 is 10, indicating that the hardware overcurrent fault is configured as a light fault, and the system stops but does not cut off the medium voltage power supply.

Function code	Name	Description	Setting range	Default
P09.14	2th-last ARM fault type 1	Each bit stands for 1 fault type. 0: No fault; 1: Fault Bit0: VFD overheating Bit1: VFD tripping Bit2: External fault Bit3: Modbus communication fault Bit4: Buffer cabinet fault Bit5: PID disconnection fault Bit5: PID disconnection fault Bit6: Door access fault Bit7: Synchronous switchover timeout Bit8: Synchronous switchover serious fault Bit9: Factory time reached Bit10: Ambient temperature too high Bit11: Switching cabinet communication fault Bit12: Insufficient SD card capacity Bit13: QF feedback fault Bit15: Power off in running	0x0000-0xFFFF	0x0000
P09.15	2th-last ARM fault type 2	Bit16: PROFIBUS communication fault Bit17: Reference frequency disconnection detection fault	0x0000-0xFFFF	0x0000

Function code	Name	Description	Setting range	Default
		Bit18: Switching cabinet 1 action		
		fault		
		Bit19: Switching cabinet 2 action		
		fault		
		Bit20: Switching cabinet 3 action		
		Tault Dital: Switching enhinet 4 action		
		fault		
		Bit22: Version not match		
		Bit23: Reserved		
		Bit24: Ambient temperature too high		
		Bit25: Unit optical-fiber		
		communication fault		
		Bit26: Fan overheating fault		
		Bit27: Master/slave optical-fiber		
		communication fault		
		Bit28-bit29: Reserved		
		communication fault		
		Bit31: Reserved		
P09.16	2th-last unit fault 1	Each bit stands for 1 fault type.	0x0000-0xFFFF	0x0000
		0: No fault; 1: Fault		
		Bit0: Unit optical-fiber uplink		
		communication fault		
		Bit1: Unit optical-fiber downlink		
		communication fault		
		Bit2: The unit is not ready		
		Bit4: Unit undervoltage		
		Bit5: Unit power fault		
		Bit6: Unit overheating		
		Bit7: Unit input phase loss		
		protection		
		Bit8: Unit input power loss		
P09.17	2th-last unit fault 2	protection	0x0000-0xFFFF	0x0000
		Bit9: ACI fault		
		Bit10: ACO fault		
		Bit11: Unit hardware overvoltage		
		Bit12. The unit does not match		
		Bit14: Reserved		
		Bit15: Reserved		
		Bit16: Rectifier unit R-phase VCE		
		Bit17: Rectifier unit S-phase VCE		
		Bit18: Rectifier unit T-phase VCE		
		Bit19: Grid-side current detection		
		fault		
1		Bit20: Phase lock failure		

Function code	Name	Description	Setting range	Default
		Bit21: Rectifier side overheating		
		Bit22: Reserved		
		Bit23: Reserved		
		Bit24: Zero calculation fault		
		Bit25: Hardware overcurrent		
		If the number is 0, there is no unit		
		fault.		
D00 19	2nd-last fault unit	If it is not 0, then	0.00	0
P09.18	number	A1-A12: 1-12	0-30	0
		B1-B12: 13-24		
		C1-C12: 25-36		

Displays the 2nd-last fault unit number. If the fault unit number is 0, it means no fault. If it is non-zero, 1–12 represent the faults of A1–A12 units in phase A, 13–24 represent the faults of B1–B12 units in phase B, and 25–36 represent the faults of C1–C12 units in phase C, respectively.

Function code	Name	Description	Setting range	Default
P09.19	ACC/DEC state at 2nd-last fault	0: Constant speed 1: ACC 2: DEC	0–2	0

Displays the ACC/DEC state at 2nd-last fault when the system runs. 0 indicates constant speed, 1 indicates ACC, and 2 indicates DEC.

Function code	Name	Description	Setting range	Default
P09.20	Running frequency at 2nd-last fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz
P09.21	Set frequency at 2nd-last fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz
P09.22	Output current at 2nd-last fault	0.0-6553.5A	0.0-6553.5	0.0A
P09.23	Output voltage at 2nd-last fault	0-65535V	0-65535	0V
P09.24	Input current at 2nd-last fault	0.0-6553.5A	0.0-6553.5	0.0A
P09.25	Input voltage at 2nd-last fault	0-65535V	0-65535	0V
P09.26	Unit bus voltage at 2nd-last fault	0-65535V	0-65535	0V
P09.27	Unit temperature at 2nd-last fault	0.0-6553.5°C	0.0-6553.5	0.0°C

P09.20–P09.27 displays the frequency, voltage, current, and unit temperature at 2nd-last fault for the users to check.

Function code	Name	Description	Setting range	Default
P09.28	System input terminal state at	0x0000-0xFFFF	0x0000-0xFFFF	0x0000

Function code	Name	Description	Setting range	Default
	2nd-last fault			
	User input terminal			
P09.29	state at 2nd-last	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
	fault			

P09.28 is system input terminal states at 2nd-last fault, which are hexadecimal digits to display the states of 10 system input terminals at 2nd-last fault. If the input terminal is ON, the corresponding bit is 1. If it is OFF, the corresponding bit is 0. You can know the state of the system digital input signals at the fault through this value. The sequence is as follows.

Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8
Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	S10	S9
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
S8	S7	S6	S5	S4	S3	S2	S1

P09.29 is user input terminal states at 2nd-last fault, which are hexadecimal digits to display the states of 12 user input terminals at 2nd-last fault. If the input terminal is ON, the corresponding bit is 1. If it is OFF, the corresponding bit is 0. You can know the state of the digital input signals at the fault through this value. The sequence is as follows.

Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8
Reserved	Reserved	Reserved	Reserved	S12	S11	S10	S9
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
S8	S7	S6	S5	S4	S3	S2	S1

Functio n code	Name	Description	Setting range	Default
	System output			
P09.30	terminal state at	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
	2nd-last fault			
	User output			
P09.31	terminal state 1 at	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
	2nd-last fault			
	User output			
P09.32	terminal state 2 at	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
	2nd-last fault			

P09.30 is system output terminal states at 2nd-last fault, which are hexadecimal digits to display the states of 8 system output terminals at 2nd-last fault. If the output terminal is ON, the corresponding bit is 1. If it is OFF, the corresponding bit is 0. You can know the state of the digital output signals at the fault through this value. The sequence is as follows.

Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8
Reserved							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
RO8	RO7	RO6	RO5	RO4	RO3	RO2	RO1

P09.31 and P09.32 are user output terminal states at 2nd-last fault, which are hexadecimal digits to display the states of 20 user output terminals at 2nd-last fault. If the output terminal is ON, the corresponding bit is 1. If it is OFF, the corresponding bit is 0. You can know the state of the digital output signals at the fault through this value. The sequence is as follows.

P09.31 indicates:

Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8
RO16	RO15	RO14	RO13	RO12	RO11	RO10	RO9
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
RO8	RO7	RO6	RO5	RO4	RO3	RO2	RO1

P09.32 indicates:

Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8
Reserved							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Reserved	Reserved	RO22	RO21	RO20	RO19	RO18	R017

Function code	Name	Description	Setting range	Default
P09.33	Last DSP fault 1	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.34	Last DSP fault 2	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.35	Last ARM fault type 1	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.36	Last ARM fault type 2	0x0000-0xFFF	0x0000-0xFFFF	0x0000
P09.37	Last unit fault 1	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.38	Last unit fault 2	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.39	Last fault unit number	If the number is 0, there is no unit fault. If it is not 0, then A1–A12: 1–12 B1–B12: 13–24 C1–C12: 25–36	0–36	0
P09.40	ACC/DEC state at last fault	0: Constant speed 1: ACC 2: DEC	0–2	0
P09.41	Running frequency at last fault	0.00Hz-P00.10	0.00Hz-P00.10	0.00Hz
P09.42	Set frequency at last fault	0.00Hz-P00.10	0.00Hz-P00.10	0.00Hz
P09.43	Output current at last fault	0.0-6553.5A	0.0-6553.5	0.0A
P09.44	Output voltage at last fault	0-65535V	0-65535	0V
P09.45	Input current at last fault	0.0-6553.5A	0.0-6553.5	0.0A
P09.46	Input voltage at last fault	0-65535V	0-65535	0V
P09.47	Unit bus voltage at last fault	0-65535V	0-65535	0V
P09.48	Unit temperature at last fault	0.0-6553.5°C	0.0-6553.5	0.0°C
P09.49	System input terminal state at	0x0000-0xFFF	0x0000-0xFFFF	0x0000

Function code	Name	Description	Setting range	Default
	last fault			
P09.50	User input terminal state at last fault	0x0000-0xFFF	0x0000-0xFFFF	0x0000
P09.51	System output terminal state at last fault	0x0000-0xFFF	0x0000-0xFFFF	0x0000
P09.52	User output terminal state 1 at last fault	0x0000-0xFFF	0x0000-0xFFFF	0x0000
P09.53	User output terminal state 2 at last fault	0x0000-0xFFF	0x0000-0xFFFF	0x0000

Same as the descriptions of 2nd-last fault.

Function code	Name	Description	Setting range	Default
P09.54	Present DSP fault 1	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.55	Present DSP fault 2	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.56	Present ARM fault type 1	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.57	Present ARM fault type 2	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.58	Present unit fault 1	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.59	Present unit fault 2	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.60	Unit number at present fault	If the number is 0, there is no unit fault. If it is not 0, then A1–A12: 1–12 B1–B12: 13–24 C1–C12: 25–36	0–36	0
P09.61	ACC/DEC state at present fault	0: Constant speed 1: ACC 2: DEC	0–2	0
P09.62	Running frequency at present fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz
P09.63	Set frequency at present fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz
P09.64	Output current at present fault	0.0-6553.5A	0.0-6553.5	0.0A
P09.65	Output current at present fault	0-65535V	0–65535	0V
P09.66	Input current at present fault	0.0-6553.5A	0.0-6553.5	0.0A
P09.67	Input voltage at present fault	0-65535V	0-65535	0V
P09.68	Unit bus voltage at present fault	0-65535V	0-65535	0V

Function code	Name	Description	Setting range	Default
P09.69	Unit temperature at present fault	0.0-6553.5°C	0.0-6553.5	0.0°C
P09.70	System input terminal state at present fault	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.71	User input terminal state at present fault	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.72	System output terminal state at present fault	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.73	User output terminal state 1 at present fault	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.74	User output terminal state 2 at present fault	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P09.75	Reserved	0–65535	0-65535	0

Same as the descriptions of 2nd-last fault.

### P10 group PID control

PID control, a common mode for process control, is mainly used to adjust output frequency of the system by performing scale-division, integral and differential operations on the deviation between feedback signal of controlled variables and signal of the target, thus forming a feedback system to keep the controlled variables above the target. It is applicable to flow control, pressure control, temperature control, and so on. The basic principle diagram of control is as follows.

Figure 6-26 Process PID principle diagram



Function code	Name	Description	Setting range	Default
P10.00	PID reference source	0: Function code (P10.01) 1: Al1 2: Al2 3: Al3 4: Al1+ Al1 5: Al2+ Al3 6: Al3+ Al1 7: Reserved	0–10	0

Function code	Name	Description	Setting range	Default
		8: Multi-step running		
		9: Modbus		
		10: PROFIBUS/PROFINET		

When the frequency source selects PID, that is, P00.06=6, the group function is enabled. The function code determines the target reference channel during the PID process. The reference target of process PID is a relative value, for which 100% equals 100% of the feedback signal of the controlled system. The system operates in relative value (0–100%), by default, 100% of PID reference and feedback values correspond to 10V.

**Note:** After setting the parameters of P11 group, multi-step speed reference can be realized by current step selection via terminals.

Function code	Name	Description	Setting range	Default
P10.01	Local preset PID reference	0.0%-100.0%	0.0-100.0	0.0%

Set P10.00 to 0, namely the target source is set by function code, and the parameter needs to be set. The base value of the function code is the feedback of the system.

Function code	Name	Description	Setting range	Default
P10.02	PID feedback source	0: Al1 1: Al2 2: Al3 3: Al1+ Al2 4: Al2+ Al3 5: Al3+ Al1 6: Reserved 7: Modbus 8: PROFIBUS/PROFINET	0-8	0

It is used to select the PID feedback channel.

**Note:** The reference channel and feedback channel cannot be duplicate. Otherwise, effective PID control cannot be achieved.

Function code	Name	Description	Setting range	Default
P10.03	PID output characteristics selection	0: PID output is positive. 1: PID output is negative.	0-1	0

0: PID output is positive. When the feedback signal is greater than the PID reference value, the output frequency of the system will decrease to balance the PID.

1: PID output is negative. When the feedback signal is greater than the PID reference value, the output frequency of the system will increase to balance the PID.

Function code	Name	Description	Setting range	Default
P10.04	Proportional gain (Kp)	0.00-100.00	0.00-100.00	1.00
P10.05	Integral time (Ti)	0.01–10.00s	0.01-10.00	0. 50s

Function code	Name	Description	Setting range	Default
P10.06	Differential time (Td)	0.00-10.00s	0.00-10.00	0.00s

PID is the most commonly used control method in process control, each part of which plays a different role. The following is a brief description of the working principle and regulation methods.

Proportional control (P): When the feedback is different from the reference, the output will be proportional to the difference. If such a difference is constant, the regulating variable will also be constant. Proportional control can respond to feedback changes rapidly, however, it cannot eliminate the difference by itself. A larger proportional gain indicates a faster regulating speed, but a too large gain will result in oscillation. To solve this problem, set the integral time to a large value and the differential time to 0, run the system only with proportional control, and then change the reference to observe the difference (that is, static difference) between the feedback signal and reference. If the static difference occurs in the direction of reference change (such as reference increase, where the feedback is always less than the reference after system stabilizes), continue increasing the proportional gain; otherwise, decrease the proportional gain. Repeat this process until the static difference becomes small.

Integral time (I): When feedback is different from reference, the output regulating variable accumulates continuously, if the difference persists, the regulating variable will increase continuously until difference disappears. The integral regulator can be used to effectively eliminate static difference. A smaller integral time indicates a stronger effect. However, too strong regulation may lead to repetitive overshoot, which will cause system instability and oscillation. The feature of oscillation caused by strong integral effect is that the feedback signal fluctuates up and down based on the reference variable, and fluctuation range increases gradually until oscillation occurs. The integral time parameter is generally regulated gradually from large to small until the stabilized system speed fulfills the requirement.

Differential time (D): When the difference between feedback and reference changes, there is output of the regulating variable that is proportional to the difference variation rate, and this regulating variable is only related to the direction and magnitude of the difference change rather than the direction and magnitude of the difference itself. Differential control is used to control the feedback signal variation based on the change trend. A larger differential time indicates a stronger effect. Exercise caution before using the differential regulator since it may enlarge the system interferences, especially those with high change frequency.

#### PID parameter setting:

There are multiple methods of PID parameter setting, among which the steps of the experience try and error method that is most widely used are as follows.

#### (1) Determine proportional gain P

When determining proportional gain P, remove the integral term and differential term first, i.e. Ti=0 and Td=0, thus turning the system into pure proportional control. Set input to 60%–70% of the maximum value allowed by the system, increase Kp from 0 gradually till system oscillation appears; decrease Kp till the oscillation disappears, record Kp at this time. The set proportional gain is 60%–70% of current proportional gain. Proportional gain setting finishes.

#### (2) Determine integral time Ti

After above setting, set Td to 0, proportional gain to the value in first step and integral time Ti to a larger value, then decrease Ti till system oscillation appears, increase Ti till the oscillation disappears, and finally record Ti at this time. The set integral coefficient is 150%–180% of current integral coefficient. Integral time setting finishes.

#### (3) Determine differential coefficient Td

Generally, Td=0, if differential effect is necessary, the setting is the same as Kp and Ti setting, 30% of critical

oscillation.

(4) System fine-tuning

After all settings, the system runs with load. Adjust the values under different conditions to achieve satisfying control effects. As for experienced engineers, they can skip over above three steps and adjust PID factors directly.

Function code	Name	Description	Setting range	Default
P10.07	Sampling cycle (T)	0.01-100.00s	0.01-100.00	0.10s
P10.08	PID control deviation limit	0.0–100.0% (Reference source)	0.0-100.0	0.0%

Sampling cycle (T): Used to indicate the sampling cycle of feedback. The regulator calculates once in each sampling cycle. A longer sampling cycle indicates slower response.

PID control deviation limit: The output of the PID system is relative to the max. deviation of the closed loop reference. As shown in the following figure, the PID regulator stops regulating in the range of deviation limit and restores working out of the deviation limit. Set the function parameter properly to adjust the accuracy and stability of the PID system.

Figure 6-27 Relationship between PID deviation limit and system output frequency



Function code	Name	Description	Setting range	Default
P10.09	Feedback offline detection value	0.0–100.0% (Reference source)	0.0-100.0	0.0%
P10.10	Feedback offline detection time	0.0–3600.0s (Reference source)	0.0-3600.0	1.0s

Feedback offline detection value: The set value is relative to full range (100%) of PID feedback value. The system will be detecting PID feedback when PID reference is valid. When the feedback value is less than or equal to feedback offline detection value, the system begins timing for detection. If the detection time exceeds feedback offline detection time, the system will report the PID feedback offline.

Function code	Name	Description	Setting range	Default
P10.11	PID wake-up-from-sleep value	0.0–100.0% (Reference source)	0.0-100.0	0.0
P10.12	PID sleep delay	0.0–360.0s	0.0-360.0	1.0s

PID wake-up-from-sleep value: If the system is in sleep, when PID feedback value is higher than PID sleep value (negative) or PID feedback value is lower than PID sleep value (positive), PID will be waked up. Then

system output frequency increases from 0 until PID feedback reaches PID reference again.

PID sleep delay: If the time is not 0, PID sleep will be valid. After PID feedback reaches PID reference and work steadily, the system will keep current output frequency for PID sleep delay, then reduce the output frequency to 0 and enter into the sleep state until PID is waked up again.

Reference value Output frequency Time t

Figure 6-28 Diagram for PID sleep and wake-up-from-sleep

As shown above, the positive characteristics of the PID feedback are analyzed as an example. After the system starts running, output frequency increases, so does PID feedback. When the feedback value reaches the reference value within the deviation limit, the system remains current output frequency for PID sleep delay set in P10.12, and the output frequency is reduced to 0. Because of system inertia, PID feedback reduces slowly. When the feedback value reaches the PID wake-up-from-sleep value set in P10.11, the system will be waked up from sleep, and the output frequency increases, so does PID feedback.

### P11 group Multi-step speed control

In non-jogging mode, multi-step speed control has the highest priority. If the speed step is not 0, that is to say, the frequency setting or PID setting source is other modes, the system will run at multi-step speed mode.

✓ Note: Only when the frequency setting or PID setting source is multi-step speed mode is step 0 valid.

When PID setting source is multi-step speed, the setting of multi-step speed is the percentage of PID reference rather than frequency.

Function code	Name	Description	Setting range	Default
P11.00	Multi-step speed	0: Terminal	0-1	0
	reference	1. Analog		

Select a multi-step speed setting method.

0: Terminal. Refer to the description of group P05.

1: Analog. Refer to the description of P11.17.

Function code	Name	Description	Setting range	Default
P11.01	Multi-step speed 0	-100.0-100.0%	-100.0-100.0	0.0%
P11.02	Multi-step speed 1	-100.0–100.0%	-100.0-100.0	0.0%
P11.03	Multi-step speed 2	-100.0–100.0%	-100.0-100.0	0.0%
P11.04	Multi-step speed 3	-100.0–100.0%	-100.0-100.0	0.0%
P11.05	Multi-step speed 4	-100.0-100.0%	-100.0-100.0	0.0%
P11.06	Multi-step speed 5	-100.0-100.0%	-100.0-100.0	0.0%
P11.07	Multi-step speed 6	-100.0-100.0%	-100.0-100.0	0.0%
P11.08	Multi-step speed 7	-100.0–100.0%	-100.0-100.0	0.0%

Function code	Name	Description	Setting range	Default
P11.09	Multi-step speed 8	-100.0-100.0%	-100.0-100.0	0.0%
P11.10	Multi-step speed 9	-100.0-100.0%	-100.0-100.0	0.0%
P11.11	Multi-step speed 10	-100.0-100.0%	-100.0-100.0	0.0%
P11.12	Multi-step speed 11	-100.0-100.0%	-100.0-100.0	0.0%
P11.13	Multi-step speed 12	-100.0-100.0%	-100.0-100.0	0.0%
P11.14	Multi-step speed 13	-100.0-100.0%	-100.0-100.0	0.0%
P11.15	Multi-step speed 14	-100.0-100.0%	-100.0-100.0	0.0%
P11.16	Multi-step speed 15	-100.0-100.0%	-100.0-100.0	0.0%

P11.01–P11.16 are used to set the value of each step speed.

If the frequency setting source is multi-step speed, 100.0% corresponds to the maximum frequency P00.10. The sign of multi-step speed determines the running direction. Negative value means reverse running. Multi-step speed can be set continuously in the range of -fmax-fmax. Goodrive5000 medium voltage variable-frequency speed regulation system supports the setting of 16-step speeds.





As for multi-step speed terminal setting mode, the step speed can be set by the combinations of input terminals.

Set S1–S4 to multi-step speed input terminals. The following table shows the relationship between the terminals and steps. The multi-step speed control process is shown in Figure 6-29.

S1	OFF	ON	OFF	ON												
S2	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON
S3	OFF	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF	OFF	OFF	ON	ON	ON	ON
S4	OFF	ON	ON													
Step	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

As for analog mode (P11.17), select analog input source at first, and set the step speed (P11.18–P11.33) according to the input analog values.

Function code	Name	Description	Setting range	Default
P11.17	Multi-step speed	0: AI1	0.2	0
	analog input	1: AI2	0-3	0

Function code	Name	Description	Setting range	Default
	source	2: AI3		
		3: AI4		

When P11.00=1, P11.17 is used to set the multi-step speed analog input source, namely AI1–AI4.

Function code	Name	Description	Setting range	Default
P11.18	Corresponding analog of step 0	-100.0–100.0%	-100.0-100.0	0.0%
P11.19	Corresponding analog of step 1	-100.0–100.0%	-100.0-100.0	0.0%
P11.20	Corresponding analog of step 2	-100.0–100.0%	-100.0-100.0	0.0%
P11.21	Corresponding analog of step 3	-100.0–100.0%	-100.0-100.0	0.0%
P11.22	Corresponding analog of step 4	-100.0–100.0%	-100.0-100.0	0.0%
P11.23	Corresponding analog of step 5	-100.0–100.0%	-100.0-100.0	0.0%
P11.24	Corresponding analog of step 6	-100.0–100.0%	-100.0-100.0	0.0%
P11.25	Corresponding analog of step 7	-100.0–100.0%	-100.0-100.0	0.0%
P11.26	Corresponding analog of step 8	-100.0–100.0%	-100.0-100.0	0.0%
P11.27	Corresponding analog of step 9	-100.0–100.0%	-100.0-100.0	0.0%
P11.28	Corresponding analog of step 10	-100.0–100.0%	-100.0-100.0	0.0%
P11.29	Corresponding analog of step 11	-100.0–100.0%	-100.0-100.0	0.0%
P11.30	Corresponding analog of step 12	-100.0–100.0%	-100.0-100.0	0.0%
P11.31	Corresponding analog of step 13	-100.0–100.0%	-100.0-100.0	0.0%
P11.32	Corresponding analog of step 14	-100.0–100.0%	-100.0-100.0	0.0%
P11.33	Corresponding analog of step 15	-100.0–100.0%	-100.0-100.0	0.0%

P11.18–P11.33 are used to set corresponding steps of analog. Take Aln for example, P11.29<Aln≤P11.30, corresponding multi-step speed 12, corresponding multi-step speed frequency setting is P11.13\*P00.10. During step setting by analog, the step will be 15 if not satisfying the conditions of step 0–14.

# P12 group Master/slave control

Function code	Name	Description	Setting range	Default
P12.00	Master-slave mode	0: Power-balancing mode	0 1	0
	selection	1: Reserved	1-0	0

The power-balancing mode is a load distribution application for applications where two motor axes runs in way of gearboxes, guide rails or shafts coupling. The power balancing application controls the load distribution between the drives. The master controls the operation of the slaves by sending command signals and setting values (speed and torque settings) to the slaves.

Speed synchronization mode is used for multiple drives in synchronous running, where multiple independent cranes are connected to one load. The speed synchronization function requires the system shall have pulse encoder feedback and communication connection.

Function code	Name	Description	Setting range	Default
P12.01	Reference signal sources sent by the master to the slave	<ul><li>0: The master outputs torque signal</li><li>1: The master outputs current signal</li><li>2: The master outputs PG signal</li><li>(reserved)</li></ul>	0-2	0

In master-slave control mode, the signals sent by the master to the slave include the command signals, the master running frequency signals (reference signal 1), and the signal source selected by P12.01 (reference signal 2).

0: The master outputs a torque signal, indicating that the master sends the current output torque to the slave.

1: The master outputs a current signal, indicating that the master sends the current output current to the slave.

2: The master outputs a PG signal (this function is reserved).

Function code	Name	Description	Setting range	Default
P12.02	Filter time of slave reference signal	0.00s-655.35s	0.00-655.35	0.00s

P12.02 is used to set the filter time of slave reference signal to eliminate influence caused by interferences.

Function code	Name	Description	Setting range	Default
P12.03	PID adjustment limit	0.0-100.0%	0.0-100.0	100.0%

The integral result limit range limits the PID adjustment result (-P12.03  $\leq$  PID output  $\leq$  P12.03). When the PID output is less than -P12.03, PID output = -P12.03; when the PID output is greater than P12.03, PID output = P12.03. The PID adjustment limit value cannot be 0.

Function code	Name	Description	Setting range	Default
P12.04	PID mode selection	<ul><li>0: Proportion plus integration as synchronous coefficient</li><li>1: Proportion plus integration as error correction</li></ul>	0-1	0

Function code	Name	Description	Setting range	Default	
P12.05	Slave reference frequency source gain	0.01-100.00	0.01-100.00	1.00	
P12.06	Slave reference signal source gain	0.01-100.00	0.01-100.00	1.00	

PID mode selection: Keep the default value and do not change it.

In master-slave control, the product of the reference frequency source (reference signal 1) received by the slave and the gain set in P12.05 is used as the internal operational frequency data of the slave. It is more convenient for users to adjust the speed relationship between the master and the slave flexibly.

Similarly, in master-slave control, the product of the reference signal source (reference signal 2) received by the slave and the gain set in P12.06 is used as the internal operational signal data of the slave. It is more convenient for users to adjust the speed relationship between the master and the slave flexibly.

Function code	Name	Description	Setting range	Default
P12.07	Master-slave proportional coefficient P1	0.0000-6.5535	0.0000-6.5535	0.1000
P12.08	Master-slave integral coefficient I1	0.00s-655.35s	0.00-655.35	1.00s
P12.09	Low-point frequency for switching master-slave PI	0.00Hz-P12.12	0.00-P12.12	5.00Hz
P12.10	Master-slave proportional coefficient P2	0.000–6.5535	0.000-6.5535	10.0000
P12.11	Master-slave integral coefficient I2	0.00s–655.35s	0.00s-655.35	6.00s
P12.12	High-point frequency for switching master-slave PI	P12.09-P00.10	P12.09-P00.10	10.00Hz

P12.07–P12.12 are used to set proportional coefficient and integral coefficient of slave PI adjustment. The control diagram of master-slave power-balancing mode is shown as Figure 6-30 and Figure 6-31.



Figure 6-30 Master-slave flexible connection, the slave adopts speed control mode

Figure 6-31 Master-slave rigid connection, the slave adopts torque control mode



High and low switching frequency of PI and corresponding PI coefficients are in the same switching way as speed loop PI parameters in P3 group. Refer to the description of speed loop parameters in P3 group. Because PID adjustment is only used as the fine-tuning on slave control signals, proportional and integral adjusting effect cannot be too strong. That is to say, set smaller proportional coefficient and larger integral coefficient.

Function code	Name	Description	Setting range	Default
P12.13	PI control deviation limit	0.0-80.0%	0.0-80.0	0.0%

Master-slave PI control deviation limit: The output of the PI system is relative to the max. deviation of the closed loop reference. As shown in Figure 6-32, the PI regulator stops regulating in the range of deviation limit. Set the function parameter properly to adjust the accuracy and stability of the PI system.

Figure 6-32 Relationship between the deviation limit and corresponding output frequency



Function code	Name	Description	Setting range	Default
P12.14	Lower limit of PI integral enabling deviation	0.0-100.0%	0.0-100.0	0.0%
P12.15	Master-slave control differential coefficient	0.00s-655.35s	0.00-655.35	0.00s

P12.14 is defined when slave PI calculation begins running under master-slave control. Only when the running speed of the master exceeds the lower limit of synchronous speed will the slave begin PI calculation. The function code can perform PI adjustment after the slave starts running.

Function code	Name	Description	Setting range	Default
P12.16- P12.23	Reserved	0–65535	0-65535	0
P12.24	Master-slave control ID code	0–15	0-15	0
P12.25	Master-slave character	0–1	0-1	0
P12.26	Master-slave node state 1	0x0000-0xFFFF	0x0000-0xFFFF	0x0000
P12.27	Master-slave node state 2	0x0000-0xFFFF	0x0000-0xFFFF	0x0000

P12.24–P12.27 are mainly used for inquiry under master-slave control.

P12.24 indicates the code of the local in the master-slave control system. There is a maximum of 16 machines in a master-slave control system, numbered 0–15, among which 0 represents the master and following codes represent the slaves in sequence.

P12.25 is the symbol of substituted master. If any fault occurs to the master during running, a substituted

master will be selected from the slaves to control other slaves. At this time, P12.25=1.

P12.26 and P12.27 indicate the states of the master and the slaves in the master-slave control system. Each two bits of the parameter indicates a state for 16 machines at most.

00: Power off

01: Ready

10: Running

11: Fault

Function code	Name	Description	Setting range	Default
P12.28	Bit27: Master/slave optical-fiber communication fault shield	0: Enable 1: Disable	0-1	0

P12.28 is used to select whether to shield master-slave optical fiber communication fault. For one machine, set P12.28 to 0 to shield master-slave optical fiber communication fault.

Function code	Name	Description	Setting range	Default
P12.29	Master-slave type setting	0: Single master 1: Spare machine 2: Master 3: Slave	0–3	0
P12.30	Enabling spare machine KM1 closing	0: Disable 1: Enable	0-1	0
P12.31- P12.32	Reserved	0–65535	0-65535	0

P12.29 is used to set the master-slave type. When P12.29=0, the VFD will run independently; when P12.29=1, multiple for operation and one for spare, the VFD will be the spare machine; when P12.29=2, the VFD will be the master; when P12.29=3 (P00.01=3), the VFD will be the slave.

P12.30 is used in the application of multiple for operation and one for spare. When P12.30=1, by clicking the variable frequency 1 on the touch screen, the contactor KM1 closes; when P12.30=0, cope it with normal mode.

## P13 group Protection parameters

Function code	Name	Description	Setting range	Default
P13.00	Protection against	0: Disable	0-1	1
	output phase loss	1: Enable		

The function code is used to select whether the system performs output phase loss protection.

Function code	Name	Description	Setting range	Default
P13.01	Motor overload protection selection	0: No protection 1: Common motor (with low-speed compensation) 2: Frequency-variable motor (without low-speed compensation)	0–2	2

0: No protection. The system has no motor overload protection. Exercise caution when using this function.

1: Common motor (with low-speed compensation). As the cooling effect of a common motor is degraded at low speed running, the corresponding current thermal protection value needs to be adjusted properly, the low compensation indicates lowering the overload protection threshold of the motor whose running frequency is lower than 30Hz.

2: Frequency-variable motor (without low-speed compensation). Because the heat dissipation function for a variable-frequency motor is not impacted by the rotation speed, it is not necessary to adjust the protection value at low speed running.

Function code	Name	Description	Setting range	Default
P13.02	Motor overload protection coefficient	20.0%–120.0% (of the motor rated current)	20.0-120.0	100.0%

Figure 6-33 Motor overload protection coefficient setting



Motor overload multiples M=Iout/(In\*K)

"In" is rated motor current, "lout" is VFD output current, and "K" is motor overload protection coefficient.

A smaller value of "K" indicates a bigger value of "M".

When M=116%, protection is performed after motor overload lasts for 1 hour; when M=200%, protection is performed after motor overload lasts for 60 seconds; and when M $\geq$ 400%, protection is performed immediately.

Function code	Name	Description	Setting range	Default
P13.03	Frequency decreasing point at sudden power failure	600–900V	600–900	650V
P13.04	Frequency drop rate at transient power-off	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	3.00Hz

When the frequency drop rate at transient power-off is set to 0, the frequency drop at transient power-off is invalid.

Frequency decreasing point at sudden power failure: If the bus voltage drops to the sudden frequency decreasing point due to the power loss of the grid, the variable-frequency speed regulation system begins to decrease the running frequency according to P13.04 to make the motor in the power generation state. The regenerative power can maintain the bus voltage to ensure normal running of the system until the recovery of power.

**Note:** Adjusting these two parameters properly to avoid the stopping caused by the grid voltage drop during heavy load start-up.

Function code	Name	Description	Setting range	Default
P13.05	Overvoltage	0: Disable	0-1	1
	stalling protection	1: Enable		
P13.06	Overvoltage			
	stalling protection	300–1280V	300-1280	1100V
	voltage			

During DEC running of the system, due to load inertia, the actual decreasing ratio of the motor speed is lower than the decreasing ratio of the output frequency. At this time, the motor will feedback the electric energy to the system, which will make the bus voltage increase. If no measures are taken, the system will be report an overvoltage fault caused by the rise in bus voltage.

During the running of the system, overvoltage stall protection will detect the unit bus voltage and compare it with overvoltage stalling point defined in P13.06. If the overvoltage stalling point is exceeded, the output frequency of the system will stop decreasing. If the unit bus voltage is lower than the overvoltage stalling point, the system will continue DEC running. It is shown as Figure 6-34.

#### Figure 6-34 Overvoltage stalling function diagram



Function code	Name	Description	Setting range	Default
P13.07	Automatic current limit threshold	50-180%	50-180	125%
P13.08	Frequency drop rate during current limit	0.00–10.00Hz (0.00 indicates overcurrent stalling is invalid.)	0.00-10.00	10.00Hz

During accelerated running, as the load is too large, the actual acceleration rate of motor is lower than that of output frequency, if no measures are taken, overcurrent during acceleration may occur.

During the running of the system, this function will detect the output current and compare it with the automatic current limit threshold defined in P13.07 (P13.07 \* rated current of the system). If it exceeds the threshold, the system will run at stable frequency during ACC running, while the system will run in decreased frequency during constant running according to the value set in P13.08. If it exceeds the threshold continuously, the output frequency of the system will continue to decrease until 0. When the output current is detected to be lower than the automatic current limit threshold again, it will continue accelerated running, as shown in Figure 6-35.

#### Figure 6-35 Automatic current limit threshold



Function code	Name	Description	Setting range	Default
P13.09	Input overvoltage prealarm threshold	105–120%	105–120	110%

P13.09 is used to set the prealarm threshold for input voltage detection. When the actual input voltage exceeds the prealarm threshold, the system will report an alarm. The value corresponds to the percentage of rated input voltage.

Function code	Name	Description	Setting range	Default
P13.10	Unit bypass function	0: Manual bypass 1: Common automatic bypass 2: Neutral point drifting automatic bypass	0–2	0
P13.11	Unit manual bypass setting	0x000-0x1FF	0x000-0x1FF	VFD voltage depended

P13.10 is used to set bypasses of the system.

0: Manual bypass. The unit is not automatically bypassed in the event of a unit failure. If users want to bypass a unit, it is necessary to set P13.11 to perform a manual bypass setting. When a unit in one phase is bypassed, the units in the corresponding position in the other two phases are also bypassed.

1: Common automatic bypass. The system does not report a fault in the event of a unit failure and automatically bypasses the faulty unit directly. At this time, P13.11 is invalid. When a unit in one phase is bypassed, the units in the corresponding position in the other two phases are also bypassed.

2: Neutral point drifting automatic bypass. The system does not report a fault in the event of a unit failure and automatically bypasses the faulty unit directly. The difference with function 1 lies in: It only bypasses the faulty unit.

Goodrive5000 medium voltage variable-frequency speed regulation system support 12 units in series at most. P13.11 adopts hex, with each bit corresponding to one unit. When corresponding bit is 1, do not bypass the unit; when corresponding bit is 0, bypass the unit.

Number of bypass units:

For 10kV asynchronous motors, a maximum of 2 units can be bypassed, and the minimum number of effective units must not be less than 6. For 6kV asynchronous motors, a maximum of 2 units can be bypassed, with a minimum number of 3 effective units. For 3kV asynchronous motors, a maximum of 2 units can be bypassed, with a minimum of 2 effective units.

For synchronous motors, a maximum of 2 units can be bypassed, and the voltage levels corresponding to the minimum number of effective units are as follows: 10kV: 7 units, 6kV: 4 units, 3kV: 3 units.
		y y y	0 1	
Function code	Name	Description	Setting range	Default
P13.12	Hardware overcurrent point	50–185% (of the VFD rated current)	50-185	180%
P13.13	Hardware current-limit point	50–185% (of the VFD rated current)	50–185	180%

**Note:** The output capacity of the system is reduced after bypassing and derating is required.

P13.12 is used to set the hardware overcurrent point of the system. When output current of the system exceeds the hardware overcurrent point, the system reports the hardware overcurrent fault.

P13.13 is used to set the hardware current limit point. When output current of the system exceeds the hardware current limit point, the system begins hardware current limit.

Function code	Name	Description	Setting range	Default
P13.14	Optical-fiber communication alarm triggering value	0–50	0–50	5

P13.14: 10s is one detection cycle.

The optical-fiber communication alarm will be reset if the number of fiber communication abnormalities detected in one cycle is less than (2xP13.14).;

If the number of communication abnormalities exceeds the triggering value (P13.14-2xP13.14) within one cycle, the alarm value will be cumulative plus one, and the optical-fiber communication alarm will be triggered when the cumulative value exceeds the value set in P13.14.

Function code	Name	Description	Setting range	Default
P13.15	Enable VFD overload integral	0–1 0: Disable 1: Enable	0-1	0
P13.16	Overload integral value	0–65535 Accumulated overload integral value	0-65535	0

Fault reset can clear accumulated values and optical-fiber communication alarms.

P13.15: When this parameter is set to 0, the overload timing value is reset after the VFD is stopped. In this case, the determination of VFD overload takes more time, and therefore the effective protection over the VFD is weakened. When this parameter is set to 1, the overload timing value is not reset, and the overload timing value is accumulative. In this case, the determination of VFD overload takes less time, and therefore the protection over the VFD can be performed more quickly.

P13.16: Overload integral value.	

Function code	Name	Description	Setting range	Default
	Underload			
P13.17	prealarm detection	0.0–200.0%	0.0-200.0	0.0%
	value			
	Underload			
P13.18	prealarm detection	0.0-3600.0s	0.0-3600.0	1.0s
	time			

Function code	Name	Description	Setting range	Default
P13.19	Speed deviation detection value	0.0-50.0%	0.0–50.0	10.0%
P13.20	Speed deviation detection time	0.0-10.0s	0.0-10.0s	1.0s
P13.21- P13.23	Reserved	0–65535	0-65535	0

P13.17: The underload prealarm detection value is the threshold to determine whether to enter the underload state.

P13.18: The underload fault is triggered after keeping the underload state for the detection time.

In the constant speed state, the output current  $\leq$  (underload percentage (function code adjustable (0.1%)) \* motor rated current), continuous state time  $\geq$  underload setting time (function code setting (0.1s)), report an alarm. No fault is reported in the non-running state, commissioning mode, or non-constant speed state.

P13.19: The speed deviation detection value is the threshold to determine whether to enter the speed deviation state.

P13.20: The speed deviation fault is triggered after keeping the speed deviation state for the detection time.

In the constant speed state, the difference between the reference frequency and the running frequency  $\geq$  or  $\leq$  [deviation percentage (function code adjustable) \* motor rated frequency], duration  $\geq$  deviation setting time (function code setting (0.1s)), report an alarm. No fault is reported in the non-running state or commissioning mode.

Function code	Name	Description	Setting range	Default
P14.00	SM reference sources	0: D-axis current reference (flux-weakening 0) 1: Max. torque current ratio (flux-weakening 0) 2: Unit power factor (flux-weakening 0) 3: D-axis current reference (flux-weakening 1) 4: Max. torque current ratio (flux-weakening 1) 5: Unit power factor control(flux-weakening 1)	0–5	0
P14.01	SM excitation mode	0: Manual 1: Automatic	0-1	1

#### P14 group SM control parameters

When the system controls synchronous motors, P14.00 is used to set the reference source of synchronous motors.

For the vector control of permanent magnet synchronous motors (electrically excited synchronous motor is invalid), GD5000 series medium voltage VFD provides three current control algorithms.

1. D-axis current reference: Control according to Id=0. For surface-mounted permanent magnet synchronous motors, the electromagnetic torque generated by the VFD output current is maximum at this time, and for inserted permanent magnet synchronous motors, the reluctance torque of the motor

is not fully utilized at this time.

- 2. Max. torque-current ratio: For inserted permanent magnet synchronous motors, the reluctance torque of the motor can be fully utilized at this time, and the torque generated by the output current is optimal.
- 3. Unit power factor: At this time, the output efficiency is high, the copper loss of the motor rotor is low, but the torque is not optimal. When the SMs work above the rated frequency, the flux-weakening control algorithm is required to prevent the current regulator from saturation due to the limitation of the max. voltage output capacity of the VFD, and GD5000 provides two flux-weakening control algorithms.
- Flux-weakening 0: Using voltage regulator control method, which does not depend on motor parameters, with easy parameter adjustment but poor dynamic response.
- Flux-weakening 1: Using motor model calculation method, this method depends on motor parameters. When the motor parameters are accurate, dynamic response is fast. The robustness of the system is poor because motors Ld and Lq are easily affected by motor current, temperature and other factors.

Users shall choose the appropriate control method according to the actual working conditions.

P14.01 is used to set the excitation mode of synchronous motors (permanent magnet synchronous motors are invalid)

0: Manual, the system does not adjust exciting current.

1: Automatic, the system automatically adjusts the exciting current according to power factors.

Function code	Name	Description	Setting range	Default
P14.02	Initial value percentage of SM automatic excitation	0.0%-100.0%	0.0-100.0	0.0%
P14.03	Starting frequency of automatic excitation	0.00Hz–50.00Hz	0.00-50.00	0.00Hz

When P14.01 is set to 1, P14.02 is used to set the initial value of SM automatic excitation, which is relative to the percentage of rated exciting current. When the output frequency of the system reaches the frequency set in P14.03, automatic excitation starts running.

Function code	Name	Description	Setting range	Default
P14.04	Output power factor setting of SM	0.0%-200.0%	0.0–200.0	0.0%

P14.03 is used to set the output power factor of the SM. 0.0%–100.0% indicates that the load characteristic of the motor is inductive. 0.0% corresponds to power factor 0 and 100.0% corresponds to power factor 1. 100.0%–200.0% indicates that the load characteristic of the motor is capacitive. 200.0% corresponds to power factor 1.

Function code	Name	Description	Setting range	Default
P14.05	Corresponding voltage of SM exciting analog 0%	0.00V-P14.06	0.00-P14.06	0.00V
P14.06	Corresponding voltage of SM	P14.05-10.00V	P14.05-10.00	10.00V

Function code	Name	Description	Setting range	Default
	excitation analog 100%			

P14.04 and P14.05 correspond to the max. and mini. values of the SM excitation analog voltage respectively. 100% corresponds to the max. value of the excitation analog adjustment and 0% corresponds to the mini. value of the excitation analog adjustment.

Function code	Name	Description	Setting range	Default
P14.07	Low-frequency oscillation control factor of SM	0–100	0-100	10
P14.08	High-frequency oscillation control factor of SM	0–100	0-100	0
P14.09	Oscillation control frequency threshold of SM	0.00-120.00Hz	0.00-120.00	15.00Hz
P14.10	Oscillation control frequency switch of SM	0.00-120.00Hz	0.00-120.00	0.00Hz

P14.06–P14.09 are mainly used for V/F control of SMs with alternating loads, such as air compressors. When the output frequency of the system reaches the set frequency of P14.09, the SM oscillation control function is valid. At this time, if the frequency is higher than P14.08, P14.07 is used, and if the frequency is lower than P14.08, P14.06 is used.

Function code	Name	Description	Setting range	Default
	Power-frequency			
P14.11	exciting current	0.0%-100.0%	0.0-100.0	0.0%
	reference			

P14.11 is used to set the control signal of the excitation current output by the VFD during manual excitation or power frequency bypass running.

Function code	Name	Description	Setting range	Default
P14.12	Flux-weakening protection coefficient of SM	0–3000	0–3000	1000
P14.13	Identification current of SM	0.0%-100.0%	0.0-100.0	20.0%
P14.14	SM autotuning command	0: Low-frequency autotuning 1: High-frequency autotuning	0-1	0
P14.15	D-axis pull-in current 1	0.0%-100.0%	0.0-100.0	20.0%
P14.16	D-axis pull-in current 2	0.0%-100.0%	0.0-100.0	10.0%
P14.17	Pull-in current switchover	0.00–P00.10 (two decimal places)	0.00-P00.10	10.00

Goodrive5000 series medium voltage variable-frequency speed regulation system

Function code	Name	Description	Setting range	Default
	frequency point			
P14.18	Reference frequency as zero action	0: Suspend disabled 1: Suspend enabled	0-1	0
P14.19	Pull-in current in hovering state	0.0%-100.0%	0.0-100.0	50.0%
P14.20	Starting time of hovering	0.00-10.00s	0.00-10.00	1.00
P14.21	Exit time of hovering	0.00-10.00s	0.00-10.00	1.00

For SMs with PG vector control (no PG vector is invalid), in applications such as up and down belt conveyors or hoists, the VFD is required to use the hover function to ensure that loads such as belt conveyors or hoists do not slide under zero frequency running. A greater value of P14.19 indicates a higher value of the max. hovering torque, but it will increase the copper loss of motor stator resistor. In practice, set a proper value according to the load conditions.

When the hover function is enabled:

When the set frequency < the starting frequency and the running frequency < the starting frequency, enter into the hovering state, at this time, inject pull-in current to SM D-axis. The current increases from 0 to the value set in P14.19 after the time set in P14.20 is reached.

When the set frequency > the starting frequency and the running frequency > the starting frequency, exit the hovering state, at this time, inject the current to SM D-axis. The current is decreased to 0 after the time set in P14.21 is reached.



#### Figure 6-36 Hover function enabling status description

Function code	Name	Description	Setting range	Default
P14.22	Reactive current closed-loop control enable	0-1	0-1	0
P14.23	Starting frequency of reactive current closed-loop	0.00Hz-P00.10	0.00-P00.10	0.00Hz

Function code	Name	Description	Setting range	Default
P14.24	Proportional coefficient of reactive current regulation	0–1000	0-1000	50
P14.25	Integral coefficient of reactive current regulation	0–1000	0-1000	50

The reactive current closed-loop synchronous motors are valid in V/F control. P14.15, P14.16, and P14.17 are used to set the reactive current reference values.

#### P15 group Switching cabinet control functions

Function code	Name	Description	Setting range	Default
P15.00	Delay for switching from variable frequency to power frequency	0.0-60.0s	0.0-60.0	2.0s

When the motor switches from variable frequency to power frequency, the switch will act after delay time set by P15.00.

Function code	Name	Description	Setting range	Default
P15.01	Switching cabinet QF configuration mode	0: Independent mode 1: Two-in-One mode	0-1	0

P15.01 is used to set QF configuration modes at power frequency and variable frequency.

0: Power frequency and variable frequency has independent QF.

1: Power frequency and variable frequency share one QF.

Function code	Name	Description	Setting range	Default
P15.02	Switching cabinet	0: Locally controlled	0-1	0
	command channel	1: Master controlled		

P15.02 is used to set the command channel of the slave.

0: The commands are given by the local. That is to say, the switching of power frequency and variable frequency is controlled by the local.

1: The commands are given by the master. That is to say, the switching of power frequency and variable frequency is controlled by the master.

Function code	Name	Description	Setting range	Default
P15.03	Synchronous switching enabling	<ul><li>0: Disable</li><li>1: Synchronous switching with</li><li>reactors</li><li>2: Synchronous switching without</li><li>reactors</li></ul>	0-2	0

The synchronous switching function can achieve bumpless synchronous switching between power frequency and variable frequency. P15.03=1 is used to set whether to perform synchronous switching during switching from the variable-frequency to the power frequency.

0: Disable. The inrush current is large during the switching process.

1: Synchronous switching with reactors

2: Synchronous switching without reactors

**Note:** When the system reports a synchronous switching fault, it indicates failure of KM4 switching off or incorrect switching off feedback. It is necessary to check whether the contact of KM4 is damaged or feedback is incorrect. After KM4 acts and feedbacks properly, restart the system to continue synchronous switching.

Function code	Name	Description	Setting range	Default
P15.04	QF1 configuration information 1	Set the configuration information of switching cabinets 1–4, QF1 configuration information is set independently by 4 bits, and 0000– 0100 are valid. 0000: No common use 0001: Group 1 QF1 in common use 0010: Group 2 QF1 in common use 0111: Group 3 QF1 in common use 0100: Group 4 QF1 in common use	0x0000-0xFFFF	0x0000
P15.05	QF1 configuration information 2	Set the configuration information of switching cabinets 5–8, QF1 configuration information is set independently by 4 bits, and 0000– 0100 are valid. 0000: No common use 0001: Group 1 QF1 in common use 0010: Group 2 QF1 in common use 0101: Group 3 QF1 in common use 0100: Group 4 QF1 in common use	0x0000-0xFFFF	0x0000

P15.04 and P15.05 are used for configuration information of the switching cabinets in common use when two or above inputs share one group of QF1. For example, when P15.04=0x0011, the switching cabinets 1 and 2 share the 1st group of QF1. When P15.05=0x3033, the switching cabinet 5, 6 and 8 share the 3rd group of QF1.

Function code	Name	Description	Setting range	Default
P15.06	Synchronous switching reactor	0–1000V	0-1000	50V
5100	voltage drop		- 2000	

The function is used to compensate voltage drop of the reactor and the parameter is set according to the reactance and current.

Function code	Name	Description	Setting range	Default
P15.07	KM1 configuration information 1	Set the configuration information of switching cabinets 1–4, QS1/KM1 configuration information is set	0x0000-0xFFFF	0x0000

Function code	Name	Description	Setting range	Default
		independently by 4 bits, and 0000– 0100 are valid. 0000: No common use 0001: Group 1 QS1/KM1 in common use 0010: Group 2 QS1/KM1 in common use 0011: Group 3 QS1/KM1 in common use 0100: Group 4 OS1/KM1 in common		
		use		
P15.08	KM1 configuration information 2	Set the configuration information of switching cabinets 5–8, QS1/KM1 configuration information is set independently by 4 bits, and 0000– 0100 are valid. 0000: No common use 0001: Group 1 QS1/KM1 in common use 0010: Group 2 QS1/KM1 in common use 0101: Group 3 QS1/KM1 in common use	0x0000-0xFFFF	0x0000

P15.07 and P15.08 are used for configuration information of the switching cabinets in common use when two or above inputs share one group of QS1/KM1. For example, when P15.07=0x0011, the switching cabinets 1 and 2 share the 1st group of QS1/KM1. When P15.08=0x3033, the switching cabinet 5, 6 and 8 share the 3rd group of QS1/KM1.

For each switch position of the switching cabinets in P15.04, P15.05, P15.07 and P15.08, refer to Figure 6-5 One-driving-more diagram in P5 group.

Function code	Name	Description	Setting range	Default
	Motor frequency			
P15.09	drop rate of	0.00-50.00Hz	0.00-50.00	0.00Hz
	switching cabinet 1			
	Motor frequency			
P15.10	drop rate of	0.00-50.00Hz	0.00-50.00	0.00Hz
	switching cabinet 2			
	Motor frequency			
P15.11	drop rate of	0.00–50.00Hz	0.00-50.00	0.00Hz
	switching cabinet 3			
	Motor frequency			
P15.12	drop rate of	0.00-50.00Hz	0.00-50.00	0.00Hz
	switching cabinet 4			
D15 12	Action time of	0.300ms	0 300	90mc
F 13.13	switching cabinet 1		0-300	301115
P15.14	Action time of	0–300ms	0-300	90ms

Function description

Function code	Name	Description	Setting range	Default
	switching cabinet 2			
P15.15	Action time of switching cabinet 3	0–300ms	0–300	90ms
P15.16	Action time of switching cabinet 4	0–300ms	0-300	90ms
P15.17	Torque current of switching cabinet 1	0.0-6553.5A	0.0-6553.5	0.0A
P15.18	Torque current of switching cabinet 2	0.0-6553.5A	0.0-6553.5	0.0A
P15.19	Torque current of switching cabinet 3	0.0-6553.5A	0.0-6553.5	0.0A
P15.20	Torque current of switching cabinet 4	0.0-6553.5A	0.0-6553.5	0.0A
P15.21	Synchronous switchover phase lock delay	0–120min	0–120	2min
P15.22	Synchronous switchover angle compensation of switching cabinet 1	-200.0–200.0°	-200.0–200.0	12.0°
P15.23	Synchronous switchover angle compensation of switching cabinet 2	-200.0–200.0°	-200.0–200.0	12.0°
P15.24	Synchronous switchover angle compensation of switching cabinet 3	-200.0–200.0°	-200.0–200.0	12.0°
P15.25	Synchronous switchover angle compensation of switching cabinet 4	-200.0–200.0°	-200.0–200.0	12.0°
P15.26	Synchronous switchover actual deviation angle of switching cabinet 1	0–65535°	0–65535	0°
P15.27	Synchronous switchover actual deviation angle of switching cabinet 2	0–65535°	0–65535	0°
P15.28	Synchronous switchover actual deviation angle of switching cabinet 3	0–65535°	0-65535	0°
P15.29	Synchronous switchover actual deviation angle of	0–65535°	0-65535	0°

Function code	Name	Description	Setting range	Default
	switching cabinet 4			
P15.30	Voltage detection board enabling	<ul><li>0: Disable (Power frequency and variable frequency share the voltage detection board)</li><li>1: Enable (The detection boards of power frequency and variable frequency are separate)</li></ul>	0-1	0
P15.31	Reserved	0–65535	0-65535	0
P15.32	Filter coefficient for synchronous switchover	1–20	1–20	4
P15.33	Phase locking stability accuracy for synchronous switchover	1–500	1–500	200
P15.34	Stability holding time for synchronous switchover	0.1–100.0s	0.1-100.0	4.0s
P15.35	Fault power-frequency bypass action selection	0: Manual power-frequency bypass 1: Automatic power-frequency bypass	0-1	0
P15.36	KM1 configuration	0: KM1 is configured 1: KM1 is not configured	0-1	1
P15.37	Switching cabinet type	0: Manual 1: Automatic	0-1	0

#### P16 group Serial communication

Function code	Name	Description	Setting range	Default
P16.00	Local Modbus address	1–247; 0 indicates a broadcast address	1-247	1

The function code is used to set Modbus communication node address. When slave communication address is set to 0 (broadcast address), the slaves only accept the communication frame without response. In the same Modbus network, the local communication addresses on the communication network are unique and slave address cannot be repeated. It is the basis of the point-to-point communication between the upper computer and the system.

Function code	Name	Description	Setting range	Default
P16.01 Modbus baud rate	0: 1200 bps			
		1: 2400 bps	Setting range     Default       0-5     4	
	Madhua haud rata	2: 4800 bps	0 5	4
	Moubus bauu rate	3: 9600 bps	Setting range     Default       0-5     4	
		4: 19200 bps		
		5: 38400 bps		

The function code is used to set the baud rate of the system. If the baud rate is different from the primary

node, communication will fail. (**Note:** BPS, abbreviation of bit per second, means how many bits in every second.)

Function code	Name	Description	Setting range	Default
P16.02	Modbus data bit check	0: No check (N, 8, 2) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 1) for RTU	0-3	1

The function code is used to set Modbus communication format.

0: Communication mode (RTU), byte length of 8 bits, no parity, stop bit of 2 bits

1: Communication mode (RTU), byte length of 8 bits, even check of 1bit, stop bit of 1 bit

2: Communication mode (RTU), byte length of 8 bits, odd check of 1bit, stop bit of 1 bit

3: Communication mode (RTU), byte length of 8 bits, no parity, stop bit of 1 bit

Function code	Name	Description	Setting range	Default
P16.03	Modbus communication	0–200ms	0–200	5ms
	response delay			

P16.03 is used to set the interval from when the VFD completes receiving data from upper computer to when it sends response data to the upper computer. If the response delay is shorter than the system processing time, the parameter may be subject to system processing time. If the delay is longer than the system processing time, the system needs to delay after data processing and sends data to upper computer after delay time is reached.

Function code	Name	Description	Setting range	Default
P16.04	Modbus communication timeout time	0.0 (invalid); 0.1–100.0s	0.0-100.0	0.0s
P16.05	Remote upgrade enabling	0–1 0: Disable 1: Enable When remote upgrade is enabled, the serial baud rate is automatically configured to 115200, and it can realize the remote upgrade of the main control ARM program with the 4G IoT module.	0-65535	0

When the function code is set to 0.0s, the communication timeout time is invalid.

When the function code is set to a valid value, the system reports the Modbus communication fault if the interval between current and next communication exceeds communication timeout time.

In general, the function code is set to 0.0. When continuous communication is required, you can set the function code to monitor communication status.

#### P17 group Ethernet communication

Function code	Name	Description	Setting range	Default
P17.00	High-order bit of local IP address	0x0000–0xFFFF (high-oder bit)	0x0000-0xFFFF	0xC0A8
P17.01	Low-order bit of Local IP address	0x0000–0xFFFF (low-order bit)	0x0000-0xFFFF	0x0102
P17.02	High-order bit of local subnet mask	0x0000–0xFFFF (high-oder bit)	0x0000-0xFFFF	0xFFFF
P17.03	Low-order bit of local subnet mask	0x0000–0xFFFF (low-order bit)	0x0000-0xFFFF	0xFF00
P17.04	High-order bit of local gateway	0x0000–0xFFFF (high-oder bit)	0x0000-0xFFFF	0xC0A8
P17.05	Low-order bit of local gateway	0x0000–0xFFFF (low-order bit)	0x0000-0xFFFF	0x0101
P17.06	High-order bit of local MAC	0x0000–0xFFFF (high-oder bit)	0x0000-0xFFFF	0x5254
P17.07	Middle-order bit of local MAC	0x0000–0xFFFF (middle-order bit)	0x0000-0xFFFF	0x4C19
P17.08	Low-order bit of local MAC	0x0000–0xFFFF (low-order bit)	0x0000-0xFFFF	0xF742

P17.00–P17.08 are used to set IP addresses, subnet masks, and MAC addresses for Ethernet communication. The parameters can be modified in setting mode; they will be read-only but unmodifiable in common mode.

IP address format: P17.00–P17.01

Example: IP address is C0.A8.01.02 (hexadecimal), namely 192.168.1.2 (decimal).

IP subnet mask format: P17.02–P17.03

Example: Subnet mask is FF.FF.FF.00 (hexadecimal), namely 255.255.255.0 (decimal).

Gateway format: P17.04.P17.05

Example: Subnet mask is C0.A8.01.01 (hexadecimal), namely 192.168.1.1 (decimal).

MAC address format: P17.06.P17.07. P17.08

Example: Subnet mask is 52.54.4C.19.F7.42 (hexadecimal).

Function code	Name	Description	Setting range	Default
P17.09	Log level of DSP command control module		0x0-0xF	0x0
P17.10	Log level of DSP speed control module	Bit0: No log Bit1: Fatal Bit2: Error Bit4: Key information Bit8: Prompt message Combination of above levels	0x0-0xF	0x0
P17.11	Log level of DSP torque calculation module		0x0-0xF	0x0
P17.12	Log level of DSP current loop		0x0-0xF	0x0

Function code	Name	Description	Setting range	Default
	Log level of DSP			
P17.13	oscillograph		0x0-0xF	0x0
	calculation module			
	Log level of DSP			
P17.14	fault management		0x0-0xF	0x0
	module			
	Log level of DSP			
P17.15	parameter inquiry		0x0-0xF	0x0
	module			

The system has the function of log recording. P17.09–P17.15 are used to set the log levels of each function module, which have 4 levels (bit3–bit0) marking the log level of current module. When the log level is 1, the log of current module is recorded.

Function code	Name	Description	Setting range	Default
P17.16	Log level of ARM			
	start/stop control		0x0-0xF	0x0
	module			
	Log level of ARM			
P17.17	frequency		0x0-0xF	0x0
	reference module			
	Log level of ARM			
P17.18	fault handling		0x0-0xF	0x0
	module			
	Log level of ARM			
P17.19	frequency		0x0-0xF	0x0
	calculation module			
P17.20	Log level of ARM	Bit0: No log		
	switching cabinet	Bit1: Fatal	0x0-0xF	0x0
	module	Bit2: Error		
	Log level of ARM	Bit4: Key information		
P17.21	function code	Bit8: Prompt message	0x0-0xF	0x0
	module	Combination of above levels		
	Log level of ARM			
P17.22	terminal function		0x0-0xF	0x0
	module			
P17.23	Log level of ARM		0x0-0xF	0x0
	UDP/IP module			
P17.24	Log level of ARM		0x0-0xF	0x0
	Modbus module			
	Log level of ARM		0x0-0xF	0x0
	PROFIBUS module			
	Log level of ARM			
P17.26	master-slave		0x0-0xF	0x0
	module			

Log levels of P17.16–P17.26 ARM are the same as those of P17.09–P17.15 DSP.

Function code	Name	Description	Setting range	Default
P17.27	High-order bit of log receiving IP	0x0000–0XFFFF (high-order bit)	0x0000-0XFFFF	0x0000
P17.28	Low-order bit of log receiving IP	0x0000–0XFFFF (low-order bit)	0x0000-0XFFFF	0x0000

The function codes are used to set the IP address of the host controller that receives logs.

#### P18 group Communication card functions

Function code	Name	Description	Setting range	Default
P18.00	Module type	0: The module is not connected 1: PROFIBUS	0–2	0
5.00		2: PROFINET		

P18.00 is used to set the type of fieldbus communication and users cannot adjust the parameter.

0: It indicates that the fieldbus communication card is not connected.

#### 1: PROFIBUS card

2: PROFINET card

Function code	Name	Description	Setting range	Default
P18.01	Module address	0–99	0–99	2

In PROFIBUS, each device corresponds to a unique node address. If the selection switch of the node address (on DP expansion card) is set to 0, the parameter can be used to define the node address.

If the selection switch of the node address (on DP expansion card) is used to define the node address when the switch is not at 0, the parameter will be only used to display the node address.

After resetting the node address, it is necessary to restart the system to initialize PROFIBUS communication module.

Function code	Name	Description	Setting range	Default
P18.02	Received PZD2		0–20	0
P18.03	Received PZD3	U: Invalid	0–20	0
P18.04	Received PZD4	2. Torque reference value	0–20	0
P18.05	Received PZD5	3: Reserved 4: PID control setting value reference 5: PID control feedback value reference 6: V/F separation voltage reference	0–20	0
P18.06	Received PZD6		0–20	0
P18.07	Received PZD7		0–20	0
P18.08	Received PZD8		0–20	0
P18.09	Received PZD9		0–20	0
P18.10	Received PZD10	7: Power frequency and variable	0–20	0
P18.11	Received PZD11	Requency control command	0-20	0
P18.12	Received PZD12		0-20	0

The master and the system exchange data quickly by PROFIBUS-DP protocol and the data frame is 16 bits, the structure is as shown in Figure 6-37.



Figure 6-37 Structure of PROFIBUS-DP data frame

P18.02–P18.12 are used to set PZD2–PZD12 receiving data of master communication in PROFIBUS-DP, as

described	below.
ucscribcu	DCIOW.

Set value	Function	Description	
0	Invalid	No meaning	
1	Frequency reference	The master sends speed reference to the inverter. Data type: integer -10000–+10000, with 2 decimal places, unit: Hz; for example, 5000 is 50.00Hz.	
2	Torque reference	The master sends torque reference to the inverter. Data type: percentage, integer, -1000–+1000, with 2 decimal places, unit: %; for example, 500 is 50.00%.	
3	Reserved	-	
4	PID control setting value reference	Under PID mode, the master can set PID reference. Data type: percentage, integer, -10000–+10000, with 2 decimal places, unit: %; for example, 5000 is 50.00%.	
5	PID feedback value reference	Under PID mode, the master can set PID feedback. Data type: percentage, integer, -10000–+10000, with 2 decimal places, unit: %; for example, 5000 is 50.00%.	
6	V/F separation voltage reference	When V/F separation function is valid, set voltage reference through the master with one decimal place. For example, 100 indicates 10.0%, with the range of 0%–100.0%.	
7	Power frequency and variable frequency control command	Switching cabinet control command	
8-20	Reserved	-	

P18.02–P18.12 can be modified in any state	
--	--

Function code	Name	Description	Setting range	Default
P18.13	Sent PZD2	0: Invalid	0-31	9
P18.14	Sent PZD3	1: Running frequency	0-31	2
P18.15	Sent PZD4	2: Reserved	0-31	11
P18.16	Sent PZD5	3: Input voltage	0-31	6
P18.17	Sent PZD6	4: Output voltage	0-31	1
P18.18	Sent PZD7	5: Input current	0-31	5
P18.19	Sent PZD8	6: Output current	0-31	4
P18.20	Sent PZD9	8: Output power percentage	0-31	0
P18.21	Sent PZD10	9: Set frequency absolute value	0-31	0
P18.22	Sent PZD11	10: Present DSP fault 1	0-31	0
P18.23	Sent PZD12	11: Present DSP fault 2	0-31	0

#### Goodrive5000 series medium voltage variable-frequency speed regulation system

Function code	Name	Description	Setting range	Default
		12: Present ARM fault type 1		
		13: Present ARM fault type 2		
		14: Present unit fault 1		
		15: Present unit fault 2		
		16: Unit number at present fault		
		17: User input terminal 1		
		18: User input terminal 2		
		19: User output terminal 1		
		20: User output terminal 2		
		21: System input terminal		
		22: System output terminal		
		23: Reserved		
		24: State of switching cabinet 1		
		25: State of switching cabinet 2		
		26: State of switching cabinet 3		
		27: State of switching cabinet 4		
		28–31: Reserved		

P18.13–P18.23 are used to set PZD2–PZD12 sending data of master communication in PROFIBUS-DP, as described below.

Set value	Function	Description	
0	Invalid	No meaning	
1	Running frequency	The VFD sends data (running frequency, actual value, integer, two decimal places, unit: Hz) to the upper master through PZD in DP communication.	
2	Reserved	-	
3	Input voltage	The VFD sends data (input voltage, actual value, integer, unit: V) to the upper master through PZD in DP communication.	
4	Output voltage	The VFD sends data (output voltage, actual value, integer, unit: V) to the upper master through PZD in DP communication.	
The VFD sends data (input current, actual value, integer, of5Input currentplace, unit: A) to the upper master through PZD in DPcommunication.		The VFD sends data (input current, actual value, integer, one decimal place, unit: A) to the upper master through PZD in DP communication.	
6	Output current	The VFD sends data (output current, actual value, integer, one decimal place, unit: A) to the upper master through PZD in DP communication.	
7	Actual output torque	The VFD sends data (output torque, percentage, integer, one decimal place, unit: %) to the upper master through PZD in DP communication.	
8	Output power percentage	The VFD sends data (output power, the percentage relative to motor rated power, integer, one decimal place, unit: %) to the upper master through PZD in DP communication.	
9	Set frequency absolute value	The VFD sends data (set frequency, actual value, integer, two decimal places, unit: Hz) to the upper master through PZD in DP communication.	
10	Present DSP fault 1	Same as the description of P09.12.	
11	Present DSP fault 2	Same as the description of P09.13.	

Set value	Function	Description
12	Present ARM fault type 1	Same as the description of P09.14.
13	Present ARM fault type 2	Same as the description of P09.15.
14	Present unit fault 1	Same as the description of P09.16.
15	Present unit fault 2	Same as the description of P09.17.
16	Unit number at present fault	Same as the description of P09.18.
17	User terminal input state 1	User input terminal state 1
18	User terminal input state 2	User input terminal state 2
19	User terminal output state 1	User output terminal state 1
20	User terminal output state 2	User output terminal state 2
21	System terminal input state 1	System terminal input state 1
22	System terminal output state 2	System terminal output state 2
23	Reserved	-
24	State of switching cabinet 1	State of switching cabinet 1
25	State of switching cabinet 2	State of switching cabinet 2
26	State of switching cabinet 3	State of switching cabinet 3
27	State of switching cabinet 4	State of switching cabinet 4
28-31	Reserved	-

P18.13–P18.23 can be modified in any state.

Function code	Name	Description	Setting range	Default
P18.24	Temporary variable for PZD sending	0–65535	0-65535	0

The function code is used as a temporary variable for PZD sending.

P18.24 can be modified in any state.

Function code	Name	Description	Setting range	Default
P18.25	DP communication timeout time	0.0 (invalid); 0.1–100.0s	0.0-100.0	0.0s

When P18.25 is set to 0.0s, PROFIBUS-DP communication timeout is invalid. When P18.25 is set to a non-zero value (actual value, unit: second) and the interval between the present and next communication exceeds the communication timeout time, the system will report DP communication fault (PCF).

P18.25 can be modified in any state.

Function description

Function code	Name	Description	Setting range	Default
P18.26	PROFINET input length	0–32	0-32	24
P18.27	PROFINET output length	0-32	0-32	24
P18.28	PROFINET communication speed	0–65535	0–65535	0
P18.29	PROFINET IP address 1	0–65535	0-65535	192
P18.30	PROFINET IP address 2	0–65535	0-65535	168
P18.31	PROFINET IP address 3	0–65535	0-65535	0
P18.32	PROFINET IP address 4	0–65535	0-65535	4
P18.33	PROFINET subnet mask 1	0–65535	0-65535	255
P18.34	PROFINET subnet mask 2	0–65535	0-65535	255
P18.35	PROFINET subnet mask 3	0–65535	0-65535	255
P18.36	PROFINET subnet mask 4	0–65535	0-65535	0
P18.37	PROFINET gateway 1	0–65535	0-65535	192
P18.38	PROFINET gateway 2	0–65535	0-65535	168
P18.39	PROFINET gateway 3	0–65535	0-65535	0
P18.40	PROFINET gateway 4	0–65535	0-65535	2
P18.41	Reserved	0–65535	0–65535	0
P18.42	Reserved	0–65535	0–65535	0

## P19 group Motor parameter 2

Function code	Name	Description	Setting range	Default
P19.00	Type of motor 2	<ul> <li>0: Asynchronous motor (AM)</li> <li>1: Electrically excited synchronous motor</li> <li>2: Synchronous motor with damping winding</li> <li>3: Permanent-magnet synchronous motor</li> </ul>	0–3	0

Function description

Function code	Name	Description	Setting range	Default
P19.01	Rated power of AM 2	4–50000kW	4–50000	Model depended
P19.02	Rated frequency of AM 2	0.01Hz-P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.03	Rated speed of AM 2	1–36000rpm	1-36000	Model depended
P19.04	Rated voltage of AM 2	0–20000V	0-20000	Model depended
P19.05	Rated current of AM 2	0.1-1000.0A	0.1-1000.0	Model depended
P19.06	Stator resistance of AM 2	0.001-65.535Ω	0.001-65.535	Model depended
P19.07	Rotor resistance of AM 2	0.001–65.535Ω	0.001-65.535	Model depended
P19.08	Stator and rotor inductance of AM 2	0.1–6553.5mH	0.1-6553.5	Model depended
P19.09	Stator and rotor mutual inductance of AM 2	0.1–6553.5mH	0.1-6553.5	Model depended
P19.10	No-load current of AM 2	0.01-655.35A	0.01-655.35	Model depended
P19.11	Rated power of SM 2	4–50000kW	4–50000	Model depended
P19.12	Rated frequency of SM 2	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.13	Rated speed of SM 2	0–36000rpm	0-36000	1500rpm
P19.14	Number of pole pairs of SM 2	1–50	1–50	2
P19.15	Rated voltage of SM 2	0–20000V	0-20000	Model depended
P19.16	Rated current of SM 2	0.1-1000.0A	0.1-1000.0	Model depended
P19.17	Stator resistance of SM 2	0.001-65.535Ω	0.001-65.535	Model depended
P19.18	Direct-axis inductance of SM 2	0.1-6553.5mH	0.1-6553.5	Model depended
P19.19	Quadrature-axis inductance of SM 2	0.1-6553.5mH	0.1-6553.5	Model depended
P19.20	Counter-emf constant of SM 2	0–20000	0-20000	9700

For the parameter setting of motor 2, see the parameter descriptions of P02 group for details.

Function code	Name	Description	Setting range	Default
P19.21	Type of motor 3	0: Asynchronous motor (AM) 1: Electrically excited synchronous	0-3	0

Function code	Name	Description	Setting range	Default
		motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor		
P19.22	Rated power of AM 3	4–50000kW	4–50000	Model depended
P19.23	Rated frequency of AM 3	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.24	Rated speed of AM 3	1–36000rpm	1-36000	Model depended
P19.25	Rated voltage of AM 3	0–20000V	0-20000	Model depended
P19.26	Rated current of AM 3	0.1-1000.0A	0.1-1000.0	Model depended
P19.27	Stator resistance of AM 3	0.001-65.535Ω	0.001-65.535	Model depended
P19.28	Rotor resistance of AM 3	0.001–65.535Ω	0.001-65.535	Model depended
P19.29	Stator and rotor inductance of AM 3	0.1–6553.5mH	0.1-6553.5	Model depended
P19.30	Stator and rotor mutual inductance of AM 3	0.1-6553.5mH	0.1-6553.5	Model depended
P19.31	No-load current of AM 3	0.01-655.35A	0.01-655.35	Model depended
P19.32	Rated power of SM 3	4–50000kW	4–50000	Model depended
P19.33	Rated frequency of SM 3	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.34	Rated speed of SM 3	0–36000rpm	0-36000	1500rpm
P19.35	Number of pole pairs of SM 3	1–50	1–50	2
P19.36	Rated voltage of SM 3	0-20000V	0-20000	Model depended
P19.37	Rated current of SM 3	0.1-1000.0A	0.1-1000.0	Model depended
P19.38	Stator resistance of SM 3	0.001–65.535Ω	0.001-65.535	Model depended
P19.39	Direct-axis inductance of SM 3	0.1-6553.5mH	0.1-6553.5	Model depended
P19.40	Quadrature-axis inductance of SM 3	0.1–6553.5mH	0.1-6553.5	Model depended
P19.41	Counter-emf constant of SM 3	0–20000	0-20000	9700

For the parameter setting of motor 3, see the parameter descriptions of P02 group for details.

Function code	Name	Description	Setting range	Default
P19.42	Type of motor 4	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0-3	0
P19.43	Rated power of AM 4	4–50000kW	4-50000	Model depended
P19.44	Rated frequency of AM 4	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.45	Rated speed of AM 4	1–36000rpm	1-36000	Model depended
P19.46	Rated voltage of AM 4	0–20000V	0–20000	Model depended
P18.47	Rated current of AM 4	0.1-1000.0A	0.1-1000.0	Model depended
P19.48	Stator resistance of AM 4	0.001–65.535Ω	0.001-65.535	Model depended
P19.49	Rotor resistance of AM 4	0.001–65.535Ω	0.001-65.535	Model depended
P19.50	Stator and rotor inductance of AM 4	0.1-6553.5mH	0.1-6553.5	Model depended
P19.51	Stator and rotor mutual inductance of AM 4	0.1–6553.5mH	0.1-6553.5	Model depended
P19.52	No-load current of AM 4	0.01-655.35A	0.01-655.35	Model depended
P19.53	Rated power of SM 4	4–50000kW	4–50000	Model depended
P19.54	Rated frequency of SM 4	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.55	Rated speed of SM 4	0–36000rpm	0-36000	1500rpm
P19.56	Number of pole pairs of SM 4	1–50	1–50	2
P19.57	Rated voltage of SM 4	0–20000V	0–20000	Model depended
P19.58	Rated current of SM 4	0.1-1000.0A	0.1-1000.0	Model depended
P19.59	Stator resistance of SM 4	0.001-65.535Ω	0.001-65.535	Model depended
P19.60	Direct-axis inductance of SM 4	0.1-6553.5mH	0.1-6553.5	Model depended
P19.61	Quadrature-axis inductance of SM 4	0.1-6553.5mH	0.1-6553.5	Model depended

Function description

Function code	Name	Description	Setting range	Default
P19.62	Counter-emf constant of SM 4	0–20000	0-20000	9700

For the parameter setting of motor 4, see the parameter descriptions of P02 group for details.

Function code	Name	Description	Setting range	Default
P19.63	Type of motor 5	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3	0
P19.64	Rated power of AM 5	4–50000kW	4–50000	Model depended
P19.65	Rated frequency of AM 5	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.66	Rated speed of AM 5	1–36000rpm	1-36000	Model depended
P19.67	Rated voltage of AM 5	0–20000V	0–20000	Model depended
P19.68	Rated current of AM 5	0.1-1000.0A	0.1-1000.0	Model depended
P19.69	Stator resistance of AM 5	0.001–65.535Ω	0.001-65.535	Model depended
P19.70	Rotor resistance of AM 5	0.001–65.535Ω	0.001-65.535	Model depended
P19.71	Stator and rotor inductance of AM 5	0.1–6553.5mH	0.1-6553.5	Model depended
P19.72	Stator and rotor mutual inductance of AM 5	0.1–6553.5mH	0.1-6553.5	Model depended
P19.73	No-load current of AM 5	0.01-655.35A	0.01-655.35	Model depended
P19.74	Rated power of SM 5	4–50000kW	4–50000	Model depended
P19.75	Rated frequency of SM 5	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P19.76	Rated speed of SM 5	0–36000rpm	0-36000	1500rpm
P19.77	Number of pole pairs of SM 5	1–50	1–50	2
P19.78	Rated voltage of SM 5	0–20000V	0-20000	Model depended
P19.79	Rated current of SM 5	0.1-1000.0A	0.1-1000.0	Model depended
P19.80	Stator resistance of SM 5	0.001-65.535Ω	0.001-65.535	Model depended

Function code	Name	Description	Setting range	Default
P19.81	Direct-axis	0 1 6552 EmH	0 1 6552 5	Model
	inductance of SM 5	0.1-0000.000	0.1-0555.5	depended
D10.02	Quadrature-axis	0.1–6553.5mH	0.1-6553.5	Model
F19.0Z	inductance of SM 5			depended
P19.83	Counter-emf	0. 20000	0 20000	0700
	constant of SM 5	0-20000	0-20000	9100

For the parameter setting of motor 5, see the parameter descriptions of P02 group for details.

#### P20 group Motor parameter 3

Function code	Name	Description	Setting range	Default
P20.00	Type of motor 6	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3	0
P20.01	Rated power of AM 6	4–50000kW	4–50000	Model depended
P20.02	Rated frequency of AM 6	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P20.03	Rated speed of AM 6	1–36000rpm	1-36000	Model depended
P20.04	Rated voltage of AM 6	0–20000V	0-20000	Model depended
P20.05	Rated current of AM 6	0.1-1000.0A	0.1-1000.0	Model depended
P20.06	Stator resistance of AM 6	0.001-65.535Ω	0.001-65.535	Model depended
P20.07	Rotor resistance of AM 6	0.001-65.535Ω	0.001-65.535	Model depended
P20.08	Stator and rotor inductance of AM 6	0.1-6553.5mH	0.1-6553.5	Model depended
P20.09	Stator and rotor mutual inductance of AM 6	0.1–6553.5mH	0.1-6553.5	Model depended
P20.10	No-load current of AM 6	0.01-655.35A	0.01-655.35	Model depended
P20.11	Rated power of SM 6	4–50000kW	4–50000	Model depended
P20.12	Rated frequency of SM 6	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P20.13	Rated speed of SM 6	0–36000rpm	0-36000	1500rpm

Function code	Name	Description	Setting range	Default
P20.14	Number of pole pairs of SM 6	1–50	1–50	2
P20.15	Rated voltage of SM 6	0-20000V	0–20000	Model depended
P20.16	Rated current of SM 6	0.1-1000.0A	0.1-1000.0	Model depended
P20.17	Stator resistance of SM 6	0.001-65.535Ω	0.001-65.535	Model depended
P20.18	Direct-axis inductance of SM 6	0.1-6553.5mH	0.1-6553.5	Model depended
P20.19	Quadrature-axis inductance of SM 6	0.1-6553.5mH	0.1-6553.5	Model depended
P20.20	Counter-emf constant of SM 6	0–20000	0-20000	9700

For the parameter setting of motor 6, see the parameter descriptions of P02 group for details.

Function code	Name	Description	Setting range	Default
P20.21	Type of motor 7	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3	0
P20.22	Rated power of AM 7	4–50000kW	4–50000	Model depended
P20.23	Rated frequency of AM 7	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P20.24	Rated speed of AM 7	1–36000rpm	1-36000	Model depended
P20.25	Rated voltage of AM 7	0-20000V	0-20000	Model depended
P20.26	Rated current of AM 7	0.1-1000.0A	0.1-1000.0	Model depended
P20.27	Stator resistance of AM 7	0.001-65.535Ω	0.001-65.535	Model depended
P20.28	Rotor resistance of AM 7	0.001-65.535Ω	0.001-65.535	Model depended
P20.29	Stator and rotor inductance of AM 7	0.1–6553.5mH	0.1-6553.5	Model depended
P2030	Stator and rotor mutual inductance of AM 7	0.1–6553.5mH	0.1-6553.5	Model depended
P20.31	No-load current of AM 7	0.01-655.35A	0.01-655.35	Model depended
P20.32	Rated power of SM 7	4–50000kW	4–50000	Model depended

Function description

Function code	Name	Description	Setting range	Default
P20.33	Rated frequency of SM 7	0.01Hz-P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P20.34	Rated speed of SM 7	0–36000rpm	0-36000	1500rpm
P20.35	Number of pole pairs of SM 7	1–50	1–50	2
P20.36	Rated voltage of SM 7	0-20000V	0–20000	Model depended
P20.37	Rated current of SM 7	0.1-1000.0A	0.1-1000.0	Model depended
P20.38	Stator resistance of SM 7	0.001-65.535Ω	0.001-65.535	Model depended
P20.39	Direct-axis inductance of SM 7	0.1-6553.5mH	0.1-6553.5	Model depended
P20.40	Quadrature-axis inductance of SM 7	0.1–6553.5mH	0.1-6553.5	Model depended
P20.41	Counter-emf constant of SM 7	0–20000	0-20000	9700

For the parameter setting of motor 7, see the parameter descriptions of P02 group for details.

Function code	Name	Description	Setting range	Default
P20.42	Type of motor 8	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3	0
P20.43	Rated power of AM 8	4–50000kW	4–50000	Model depended
P20.44	Rated frequency of AM 8	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P20.45	Rated speed of AM 8	1–36000rpm	1-36000	Model depended
P20.46	Rated voltage of AM 8	0-20000V	0-20000	Model depended
P20.47	Rated current of AM 8	0.1-1000.0A	0.1-1000.0	Model depended
P20.48	Stator resistance of AM 8	0.001-65.535Ω	0.001-65.535	Model depended
P20.49	Rotor resistance of AM 8	0.001-65.535Ω	0.001-65.535	Model depended
P20.50	Stator and rotor inductance of AM 8	0.1-6553.5mH	0.1-6553.5	Model depended
P20.51	Stator and rotor mutual inductance of AM 8	0.1-6553.5mH	0.1-6553.5	Model depended

Function code	Name	Description	Setting range	Default
P20.52	No-load current of AM 8	0.01-655.35A	0.01-655.35	Model depended
P20.53	Rated power of SM 8	4–50000kW	4–50000	Model depended
P20.54	Rated frequency of SM 8	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz
P20.55	Rated speed of SM 8	0–36000rpm	0-36000	1500rpm
P20.56	Number of pole pairs of SM 8	1–50	1–50	2
P20.57	Rated voltage of SM 8	0–20000V	0-20000	Model depended
P20.58	Rated current of SM 8	0.1-1000.0A	0.1-1000.0	Model depended
P20.59	Stator resistance of SM 8	0.001-65.535Ω	0.001-65.535	Model depended
P20.60	Direct-axis inductance of SM 8	0.1-6553.5mH	0.1-6553.5	Model depended
P20.61	Quadrature-axis inductance of SM 8	0.1-6553.5mH	0.1-6553.5	Model depended
P20.62	Counter-emf constant of SM 8	0–20000	0-20000	9700

For the parameter setting of motor 8, see the parameter descriptions of P02 group for details.

When configuring multiple bypass cabinets in one-driving-more control, set the motor parameters corresponding to the motor numbers in P02 and P19.

#### P21 Encoder state viewing

Function code	Name	Description	Setting range	Default
P21.00	Actual frequency of encoder	-327.68–327.67Hz	-327.68-327.67	0.00Hz
P21.01	High-order bit of PG1 pulse count	0–65535	0-65535	0
P21.02	Low-order bit of PG1 pulse count	0–65535	0-65535	0
P21.03	Resolver counting	0–65535	0-65535	0
P21.04	<b>Resolver</b> angle	0.00–359.99	0.00-359.99	0.00
P21.05	Magnetic pole angle	0.00–359.99	0.00-359.99	0.00
P21.06	High bit of PG2 pulse count	0–65535	0-65535	0
P21.07	Low-order bit of PG2 pulse count	0–65535	0-65535	0
P21.08	QEP pulse counting	0–65535	0-65535	0

Function code	Name	Description	Setting range	Default
P21.09	Magnetic pole position	0–65535	0-65535	0
P21.10	Reserved	0–65535	0-65535	0
P21.11	Reserved	0–65535	0-65535	0
P21.12	Reserved	0–65535	0-65535	0

## P22 group Encoders

Function code	Name	Description	Setting range	Default
P22.00	Encoder type	0: Incremental encoder 1: UVW encoder 2: Resolver-type encoder 3: Sin/Cos encoder with CD 4: Sin/Cos encoder without CD	0-4	0
P22.01	Encoder pulse count	0–65535	0-65535	1000
P22.02	Encoder direction	0: Forward input 1: Reverse input	0-1	0
P22.03	Detection time of encoder offline fault	0.0-10.0s	0.0-10.0	1.0s
P22.04	Detection time of encoder reversal fault	0.0-10.0s	0.0-10.0	1.0s
P22.05	Filter times of encoder detection	0-10	0-10	1
P22.06	Speed ratio between motor and encoder	0.000-65.535	0.000-65.535	1.000
P22.07	Control parameters of SM	0x0000–0xFFFF Bit0: Enable Z pulse calibration Bit1: Enable encoder angle calibration Bit2: Enable SVC speed measurement Bit3: Rotary transformer speed detection mode Bit4: Z-pulse capture mode	0x0000-0xFFFF	0x0003
P22.08	Enable Z pulse offline detection	0: Disable 1: Enable	0-1	0
P22.09	Initial angle of Z pulse	0.00-359.99°	0.00-359.99	0.00°
P22.10	Pole initial angle	0.00–359.99°	0.00-359.99	0.00°
P22.11	Vector control frequency deviation value	0.0%–100.0% (of the max. frequency)	0.0-100.0	5.0%

Function code	Name	Description	Setting range	Default
P22.12	Deviation count time	0.0-6553.5s	0.0-6553.5	1.0s
P22.13	Encoder filter time	0.00-10.00s	0.00-10.00s	0.10s
P22.14– P22.17	Reserved	0–65535	0-65535	0

# P23 group Temperature controller communication

Function code	Name	Description	Setting range	Default
	Modbus baud rate	0: 1200 bps 1: 2400 bps		
	setting of	2: 4800 bps		
P23.00	temperature	3: 9600 bps	0–5	4
	controller	4: 19200 bps		
		5: 38400 bps		
	Data bit check	0: No check (N, 8, 2) for RTU		
D23 01	setting of	1: Even check (E, 8, 1) for RTU	0_3	1
F23.01	temperature	2: Odd check (O, 8, 1) for RTU	0-3	T
	controller	3: No check (N, 8, 1) for RTU		
	Modbus			
D22.02	communication	0.0.100.0-	0.0.100.0	10.0-
P23.02	temperature	0.0-100.05	0.0-100.0	10.05
	controller			
	Overtemperature			
P23.03	alarm temperature	0–135°C	0-135	90°C
	of transformer			
	Overtemperature			
022.04	tripping	0.125°C	0 125	110°C
F23.04	temperature of	0-135 C	0-135	110 C
	transformer			
	Calibration			
P23.05	coefficient of	-100 00%-100 00%	-100 00-100 00	0.00
1 23.03	temperature	100.0070 100.0070	-100.00-100.00	0.00
	control detection 1			
	Calibration			
P23.06	coefficient of	-100.00%-100.00%	-100.00-100.00	0.00
0.00	temperature			
	control detection 2			
	Calibration			
P23.07	coefficient of	-100.00%-100.00%	-100.00-100.00	0.00
123.01	temperature			
	control detection 3			
	Calibration			
P23.08	coefficient of	-100.00%-100.00%	-100.00-100.00	0.00
	temperature			
	control detection 4			

Function description

Function code	Name	Description	Setting range	Default
P23.09	Calibration coefficient of temperature control detection 5	-100.00%-100.00%	-100.00-100.00	0.00
P23.10	Calibration coefficient of temperature control detection 6	-100.00%-100.00%	-100.00-100.00	0.00
P23.11	Number of configured temperature controllers	1-4	1-4	1
P23.12	Transmission fault code of temperature controller 1	0–65535	0-65535	0
P23.13	Transmission slave address of temperature controller 1	0–65535	0-65535	0
P23.14	Transmission fault code of temperature controller 2	0–65535	0–65535	0
P23.15	Transmission slave address of temperature controller 2	0–65535	0–65535	0
P23.16	Transmission fault code of temperature controller 3	0–65535	0–65535	0
P23.17	Transmission slave address of temperature controller 3	0–65535	0–65535	0
P23.18	Transmission fault code of temperature controller 4	0–65535	0-65535	0
P23.19	Transmission slave address of temperature controller 4	0–65535	0-65535	0
P23.20	Fan turn-on temperature 1 (transformer)	P23.21–70.0°C When the temperature of the transformer is higher than the value set in P23.20, the fan turns on.	P23.21-75.0	50.0°C

Goodrive5000 series medium voltage variable-frequency speed regulation system

Function description

Function code	Name	Description	Setting range	Default
P23.21	Fan turn-off temperature 1	0.0–P23.20 When the temperature of the transformer is lower than the value set in P23.21, the fan turns off.	0.0-P23.20	40.0°C
P23.22	Fan turn-on temperature 2 (unit)	P23.23–70.0°C When the temperature of the unit is higher than the value set in P23.22, the fan turns on.	P23.21-75.0	50.0°C
P23.23	Fan turn-off temperature 2	0.0–P23.22 When the temperature of the unit is lower than the value set in P23.23, the fan turns off.	0.0-P23.22	40.0°C

# P24 group Reserved functions

Function code	Name	Description	Setting range	Default
P24.00	Reserved	0–65535	0-65535	0
P24.01	Reserved	0–65535	0-65535	0
P24.02	Reserved	0–65535	0-65535	0
P24.03	Reserved	0–65535	0-65535	0
P24.04	Reserved	0–65535	0-65535	0
P24.05	Reserved	0–65535	0-65535	0
P24.06	Reserved	0–65535	0-65535	0
P24.07	Reserved	0–65535	0-65535	0
P24.08	Reserved	0–65535	0-65535	0
P24.09	Reserved	0–65535	0-65535	0
P24.10	Reserved	0–65535	0-65535	0
P24.11	Reserved	0–65535	0-65535	0
P24.12	Reserved	0–65535	0-65535	0
P24.13	Reserved	0–65535	0-65535	0
P24.14	Reserved	0–65535	0-65535	0
P24.15	Reserved	0–65535	0-65535	0
P24.16	Reserved	0–65535	0-65535	0
P24.17	Reserved	0–65535	0-65535	0
P24.18	Reserved	0–65535	0-65535	0
P24.19	Reserved	0–65535	0-65535	0
P24.20	Reserved	0–65535	0-65535	0
P24.21	Reserved	0–65535	0-65535	0
P24.22	Reserved	0–65535	0-65535	0
P24.23	Reserved	0–65535	0-65535	0
P24.24– P24.52	Reserved	0–65535	0-65535	0

# P25 group Transformer protefction

Function code	Name	Description	Setting range	Default
P25.00	Max. input voltage imbalance	0.0-6553.5%	0.0-6553.5	0.0
P25.01	Max. input current imbalance	0.0-6553.5%	0.0-6553.5	0.0
P25.02	Input voltage R	0-65535V	0-65535	0
P25.03	Input voltage S	0-65535V	0-65535	0
P25.04	Input voltage T	0-65535V	0-65535	0
P25.05	Input current R	0.0-6553.5A	0.0-6553.5	0.0
P25.06	Input current S	0.0-6553.5A	0.0-6553.5	0.0
P25.07	Input current T	0.0-6553.5A	0.0-6553.5	0.0
P25.08	Filter value of input voltage R imbalance	0-65535V	0-65535	0
P25.09	Filter value of input voltage S imbalance	0–65535V	0-65535	0
P25.10	Filter value of input voltage T imbalance	0-65535V	0-65535	0
P25.11	Filter value of input current R imbalance	0.0-6553.5A	0.0-6553.5	0.0
P25.12	Filter value of input current S imbalance	0.0-6553.5A	0.0-6553.5	0.0
P25.13	Filter value of input current T imbalance	0.0-6553.5A	0.0-6553.5	0.0
P25.14	Fault word of transformer protection	0–65535	0-65535	0
P25.15– P25.56	Reserved	0–65535	0-65535	0
P25.57	Transformer protection constant 1	0.0-6553.5%	0.0-6553.5	5.0
P25.58	Transformer protection constant 2	0.0–6553.5	0.0-6553.5	0.5
P25.59	Transformer protection constant 3	0.00–655.35	0.00-655.35	1.00
P25.60	Transformer protection constant 4	0.0-6553.5%	0.0-6553.5	25.0
P25.61	Transformer protection	0.0-100.0%	0.0-100.0	30.0

Goodrive5000 series medium voltage variable-frequency speed regulation system

Function description

Function code	Name	Description	Setting range	Default
	constant 5			
	Transformer			
P25.62	protection	0.0-100.0%	0.0-100.0	40.0
	constant 6			
	Transformer			
P25.63	protection	0.0-100.0%	0.0-100.0	40.0
	constant 7			
	Transformer			
P25.64	protection	0.0–50.0A	0.0-50.0	5.0
	constant 8			
	Transformer			
P25.65	protection	0–5000ms	0-5000	2000
	constant 9			
P25.66-	Posonuod	0 65535	0 65525	0
P25.71	Reserveu	0-0000	0-00000	U

# P28 group SD card functions

Function code	Name	Description	Setting range	Default
P28.00	Number of files to be reserved	3–10 (The maximum number of files that can be saved for each type of file, such as alarm records, operation records, waveform files saved after fault triggering, etc.)	3–10	5
P28.01	File size	0.1-10.0M	0.1-10.0	1.0M
P28.02	Retention cycle of running records	0.5–30.0min	0.0-30.0	0.5min
P28.03	Year setting	When P28.07 is 0, the real time of	0-9999	Year
P28.04	Month and day setting	ARM is displayed, and P28.03– P28.06 update the time in real time. The RTC time can be modified by modifying P28.07.	1.01-12.31	Mon Day
P28.05	Hour and minute setting		0.0-23.59	Hour Min
P28.06	Seconds setting	Operation steps for configuring	0–59	Sec
P28.07	Setting mode enabling	Step 1 Input 2 to P28.07, the time stops updating at this time. Step 2 Change the date and time. Step 3 Input 1 to P28.07, when P28.07 is 0, it indicates that the configuration is complete	0–2	0
P28.08	Reserved	0–65535	0-65535	0
P28.09	Reserved	0–65535	0-65535	0
P28.10	Fault storage mode	0: Disable 1: Trigger the storage mode 2: Reserved	0-2	1
P28.11	SD card state feedback	SD card state feedback (feedback whether the previous operation is	0–6	0

Function code	Name	Description	Setting range	Default
		successful): 0: System power-on, if no SD card is inserted or SD card is invalid, the value is 0. 1: The initialization of the SD card is successful, waiting for SD card operation. 2: SD card reading failure 3: SD card writing failure 4: File opening failure 5: File creation failure 6: The operation is successful		
P28.12	Save function code configuration files (Number of function code groups, number of function codes and VFD model information)	0: Initial value, no operation 1: Save the function codes, and copy the configuration files to the SD card 2: The execution succeeds 3: The execution fails.	0–3	0
P28.13	Save function codes	0: Save function codes to the file 0 1: Save function codes to the file 1 2: Save function codes to the file 2	0–2	0
P28.14	Restore function codes	<ul> <li>0: Restore function codes from the function code parameter file 0</li> <li>1: Restore function codes from the function code parameter file 1</li> <li>2: Restore function codes from the function code parameter file 2</li> </ul>	0–2	0
P28.15	Save function codes to the SD card	0: Disable 1: Generate parameter files (unreadable) 2: Generate reports (.csv) 3: The execution succeeds 4: The execution fails.	0-4	0
P28.16	Restore function code settings from the SD card	<ul> <li>0: Disable</li> <li>1: Full recovery (including motor parameter groups)</li> <li>2: Filter recovery (excluding motor parameter groups)</li> <li>3: The execution succeeds</li> <li>4: The execution fails.</li> </ul>	0-4	0
P28.17	Sampling channel	0: No function 1: Running frequency	0–20	1
P28.18	Sampling channel 2	2: Output voltage 3: Input voltage	0–20	2

Goodrive5000 series medium voltage variable-frequency speed regulation system

Function description

Function code	Name	Description	Setting range	Default
P28.19	Sampling channel 3	4: Output U-phase current 5: Output V-phase current	0–20	3
P28.20	Sampling channel 4	6: Output W-phase current 7: Q-axis angle	0–20	4
P28.21	Sampling channel 5	8: T-axis angle 9: Output current M-axis component	0–20	5
P28.22	Sampling channel 6	10: Output current T-axis component	0–20	6
P28.23	Sampling channel 7	11–20: Reserved	0–20	7
P28.24	Sampling channel 8		0–20	8
P28.25	Sampling channel 9		0–20	9
P28.26	Sampling channel 10		0–20	10

# 7 Function introduction and application

This chapter is a brief introduction to the functions of the Goodrive5000 medium voltage variable-frequency speed regulation system, with all the necessary operation steps numbered, which must be followed strictly and accurately.



- Strictly follow the instructions in chapter 1 Precautions and only trained personnel with the permission of the user unit are allowed to operate the system.
- The system is medium voltage danger equipment, any operator must be familiar with the following precautions before operation, otherwise physical injury or death, or property damage may be caused.

### 7.1 Frequency setting

The system has two frequency command channels followed by multiple choices for users to set the frequency. Channel A and channel B support simple arithmetical operation between each other and they can switch into each other by setting multi-function input terminals. The final set frequency is calculated by the set values of frequency A and B sources according to P00.09.

Function code	Name	Description	Setting range
P00.06	Setting channel of frequency A command	0: Function code 1: Al1 2: Al2 3: Al3 4: Al4 5: Multi-step speed running 6: PID control 7: Modbus 8: Fieldbus	0–8
P00.07	Setting channel of frequency B command	0: Al1 1: Al2 2: Al3 3: Al4	0-3
P00.08	Reference object of frequency B command	0: Max. output frequency 1: Frequency A command	0-1
P00.09	Combination mode of setting source	0: A 1: B 2: A+B 3: Max(A, B)	0–3
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3
P02.01	Rated power of AM 1	4–50000kW	4–50000kW

Goodrive5000 series medium voltage variable-frequency speed regulation system Function introduction and application

Function code	Name	Description	Setting range
P02.02	Rated frequency of AM 1	0.01Hz–P00.10 (Max. output frequency)	0.01 - P00.10
P02.03	Rated speed of AM 1	1–36000rpm	1-36000
P02.04	Rated voltage of AM 1	0-20000V	0-20000
P02.05	Rated current of AM 1	0.1–1000.0A	0.1-1000.0
P02.06	Stator resistance of AM 1	0.001-65.535Ω	0.001-65.535
P02.07	Rotor resistance of AM 1	0.001-65.535Ω	0.001-65.535
P02.08	Stator and rotor leakage inductance of AM 1	0.1–6553.5mH	0.1-6553.5
P02.09	Stator and rotor mutual inductance of AM 1	0.1–6553.5mH	0.1-6553.5
P02.10	No-load current of AM 1	0.01-655.35A	0.01-655.35
P02.11	Rated power of SM 1	4–50000kW	4–50000kW
P02.12	Rated frequency of SM 1	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10
P02.13	Rated speed of SM 1	0–36000rpm	0-36000
P02.14	Number of pole pairs of SM 1	1–50	1–50
P02.15	Rated voltage of SM 1	0-20000V	0-20000
P02.16	Rated current of SM 1	0.1-1000.0A	0.1-1000.0
P02.17	Stator resistance of SM 1	0.001-65.535Ω	0.001-65.535
P02.18	Direct-axis inductance of SM 1	0.01–655.35mH	0.01-655.35
P02.19	Quadrature-axis inductance of SM 1	0.01–655.35mH	0.01-655.35
P02.20	Counter-emf constant of SM 1	0–20000	0-20000

#### 7.2 Parameter autotuning

After installing the system on site, confirm the wiring, carry out commissioning in operation procedures after power-on according to the operation manual, and select the motor type (P02.00). On basis of motor type selection and nameplate parameters setting (P02.01–P02.05 or P02.11–P02.16), press and hold the jogging forward button on the touch screen, and check the rotating direction of the motor. If the motor rotates in the reverse direction, you can power off and change any two phase wires of the motor to achieve positive rotation. The running direction of the motor can also be changed through setting P00.18 if cables cannot be changed.

Perform motor parameter autotuning (P00.20=1), press the forward running button on the touch screen to start parameter autotuning. The motor will automatically stop after the autotuning is complete.


After the autotuning is complete, ensure the motor parameters (P02 group) are correct. Set the control methods and running command channels (P00.00 and P00.01), running frequency, and start/stop mode and ACC/DEC time in P01 group. After that, send the running and stop commands to the system, the system will run according to the set mode and frequency, and stop after receiving the stop command. As a result, the system works normally.

## 7.3 Start/stop control

The start commands of the system include power-on start, power-off restart and start after fault reset. The start modes include start at the starting frequency, start after DC braking, and start after speed tracking. Users can select a proper start mode based on actual conditions. The stop modes include decelerate to stop and coast to stop. During coasting to stop, it is to block the medium voltage output of the system and the load stops according to its mechanical inertia. During decelerating to stop, the system gradually reduces the output voltage until there is no output, then stop. The DEC time and the parameters related to DC braking during deceleration are settable. Start after speed tracking can be used in cases where the system is started frequently. Direct start is recommended for SMs.

1. Logic diagram for start after a running command is given at power-on



2. Logic diagram for start after power-off restart is effective



#### 3. Logic diagram for start after automatic fault reset



Function code	Name	Description	Setting range
P01.00	Braking mode	0: DC braking 1: Dual-frequency braking	0-1
P01.01	Start mode	0: Direct start	0–2

Function code	Name	Description	Setting range
		1: Start after DC braking 2: Start after rotating speed tracking	
P01.02	Starting frequency of direct start	0.00–10.00Hz	0.00-10.00
P01.03	Starting frequency hold time	0.0–50.0s	0.0-50.0
P01.04	Braking current before start	0.0–120.0% (of the VFD rated current)	0.0-120.0
P01.05	Braking time before start	0.0–50.0s	0.0–50.0
P01.06	ACC and DEC mode	0: Linear type 1: S curve	0-1
P01.07	S curve starting segment proportion	1.0–40.0% (ACC/DEC time)	1.0-40.0
P01.08	S curve ending segment proportion	1.0–40.0% (ACC/DEC time)	1.0-40.0
P01.09	Stop mode	0: Decelerate to stop 1: Coast to stop	0-1
P01.10	Starting frequency of DC braking at stop	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10
P01.11	Wait time before DC braking at stop	0.0–50.0s	0.0-50.0
P01.26	Power-off restart selection	0: Disable 1: Enable	0-1
P01.27	Sudden power-off time	0.00-50.00s	0.00-50.00
P01.28	Wait time for restart after power-off	0.0–3600.0s (valid when P01.17=1)	0.0-3600.0
P01.29	Medium voltage switch action at stop	0: Cut off medium voltage during stop 1: Not cut off medium voltage during stop	0-1
P08.15	Auto fault reset count	0–3	0–3
P08.16	Auto fault reset interval	0.1–100.0s	0.1-100.0

# 7.4 V/F control

The system has built-in V/F control, which can be applied in most cases of the non-closed loop applications, including one-driving-more applications. V/F control provides multiple V/F curves for users to select the corresponding V/F curve flexibly according to on-site conditions and set multi-point V/F curves by themselves.

For loads featuring constant torque, such as conveyor belts, as the running process requires constant torque, it is recommended to adopt the straight line V/F curve. For loads featuring decreasing torque, such as fans and pumps, as there is a power (square or cube) relation between its actual torque and speed, it is recommended to adopt the V/F curve corresponding to the power of 1.3, 1.7 or 2.0. The system also provides multi-point V/F curves. Users can form a curve with 5 reference points through three customized frequency and voltage points, zero point, and rated frequency and voltage points.

Low frequency torque boost (P04.01) can effectively compensate for the low-speed torque performance in

V/F control. When it is set to 0, the system will automatically adjust the boost value according to loads. However, the boost value shall not be too large; otherwise, the motor may encounter low-frequency oscillation or overcurrent. If such a situation occurs, reduce the torque boost value.



Motor oscillation often occurs in V/F control in large-power driving applications. To solve this problem, the system provides two oscillation control factor function codes (P04.18 and P04.19) to adjust. Generally, they are set to default values. Users can adjust the parameters based on oscillation occurrence frequency. Use the low-frequency oscillation control factor when the frequency is below P04.20 and high-frequency oscillation control factor when the frequency of Alarger factor value indicates better control effect. However, if the value is too large, output current may be too large. Users cannot set it too large during adjustment.

Customized V/F function, namely V/F separation, indicates there is no corresponding relationship between voltage and frequency, and the voltage and frequency change according to their set values and ACC/DEC time, respectively.

Function code	Name	Description	Setting range
P00.00	Control mode selection	0: Space voltage vector control 1: Asynchronous sensorless vector control 2: Synchronous sensorless vector control 3: Vector control	0-3
P00.16	ACC time 1	0.1-3600.0s	0.1-3600.0
P00.17	DEC time 1	0.1-3600.0s	0.1-3600.0
P00.18	Running direction	0: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running	0-2
P00.20	Motor parameter autotuning	0: No operation 1: Parameter autotuning	0-1
P01.01	Start mode	0: Direct start 1: Start after DC braking 2: Start after rotating speed tracking	0-2
P01.02	Starting frequency of direct start	0.00–10.00Hz	0.00-10.00
P01.03	Starting frequency hold time	0.0–50.0s	0.0–50.0
P01.09	Stop mode	0: Decelerate to stop 1: Coast to stop	0-1
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0-1
P02.01	Rated power of AM 1	4–50000kW	4–50000kW

Function code	Name	Description	Setting range
P02.02	Rated frequency of AM 1	0.01Hz–P00.10 (Max. output frequency)	0.01Hz – P00.10
P02.04	Rated voltage of AM 1	0–20000V	0–20000
P02.05	Rated current of AM 1	0.1–1000.0A	0.1-1000.0
P04.01	Torque boost	0.0%-10.0%	0.0-10.0
P08.23	Drop control	0.00–10.00Hz	0.00-10.00
P12.29	Master-slave type setting	0: Single master 1: Spare machine 2: Master 3: Slave	0–3
P04.18	Low-frequency oscillation control factor	0-100	0-100
P04.19	High-frequency oscillation control factor	0-100	0-100
P04.20	Vibration control frequency threshold	0.00–120.00Hz	0.00-120.00

## 7.5 Vector control

AMs feature high order, nonlinearity, strong coupling and multi-variables, which increase difficulty to precisely control AMs. Vector control is a method for precise control over the motor, by measuring the stator current of the motor, and then decomposes the stator current into exciting current and torque current based on field orientation principle, and therefore controls the amplitude values and phase positions of the two components to realize decoupled control on exciting current and torque current, thus achieving high-performance speed regulation of the motor.

The system uses the sensor-less vector control algorithm, which is based on accurate motor parameters, the accuracy of motor parameters affects vector control performance. It is recommended to enter motor nameplate parameters first and autotune motor parameters before executing vector control.



Function code	Name	Description	Setting range
P00.00	Control mode selection	0: Space voltage vector control 1: Asynchronous sensorless vector control 2: Synchronous sensorless vector control 3: Vector control	0–3
P00.20	Motor parameter autotuning	<ul> <li>0: No operation</li> <li>1: Rotary autotuning</li> <li>2: Encoder autotuning</li> <li>3: Motor frequency drop rate autotuning</li> <li>4: Power frequency and variable</li> <li>frequency switching time autotuning</li> <li>5: Static autotuning (reserved)</li> </ul>	0–5
P02.00	Type of motor 1	<ul> <li>0: Asynchronous motor (AM)</li> <li>1: Electrically excited synchronous motor</li> <li>2: Synchronous motor with damping</li> <li>winding</li> <li>3: Permanent-magnet synchronous motor</li> </ul>	0–3
P02.01	Rated power of AM 1	4–50000kW	4–50000
P02.02	Rated frequency of AM 1	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10
P02.03	Rated speed of AM 1	1–36000rpm	1-36000
P02.04	Rated voltage of AM 1	0-20000V	0-20000
P02.05	Rated current of AM 1	0.1-1000.0A	0.1-1000.0
P03.00	Speed-loop proportional gain 1	0–100	0-100
P03.01	Speed-loop integral time 1	0.01–10.00s	0.01-10.00
P03.02	Low-point frequency for switching	0.00Hz-P03.05	0.00-P03.05
P03.03	Speed-loop proportional gain 2	0–100	0-100
P03.04	Speed-loop integral time 2	0.01–10.00s	0.01-10.00
P03.05	High-point frequency for switching	P03.02–P00.10 (Max. ouput frequency)	P03.02-P00.10
P03.06	Current-loop proportional coefficient P	0–65535	0–65535
P03.07	Current-loop integral coefficient I	0–65535	0–65535
P03.08	Speed loop filter time	0.000-1.000s	0.000-1.000
P03.09	VC slip compensation coefficient	50.0%-200.0%	50.0%-200.0%
P03.10	Encoder pulse count setting	1-65535	1-65535
P03.12	Torque upper limit setting	0.0–200.0% (of the VFD rated current)	0.0-200.0%

Vector control includes speed mode and torque mode. Speed control aims to stabilize the speed. The output torque of the system automatically changes according to different loads, to ensure that the running speed is consistent with the set speed. If the output torque is greater than the torque upper limit, the motor will no longer run at a set speed and its speed will automatically change. The system outputs torque at the set torque command in torque mode, and the output frequency is limited by the frequency upper and lower limits. When the set torque is greater than the load torque, the output frequency will increase to the upper limit and when the set torque is lower than the load torque, the output frequency will decrease to the lower limit. If the output frequency of the system is limited, the output torque is different from the set torque.

During the adjustment of vector control parameters, users need to have a better understanding of vector control algorithm, so parameters of P3 group are generally set to default values. Exercise caution when modifying these parameters.

# 7.6 PID control

PID control can be used in the closed-loop application of constant pressure water supply, and its flexible PID parameters setting can meet the user requirements in different control scenarios.

Function code	Name	Description	Setting range
P10.00	PID reference source	0: Function code (P10.01) 1: Al1 2: Al2 3: Al3 4: Al1+ Al2 5: Al2+ Al3 6: Al3+ Al1 7: Reserved 8: Multi-step running 9: Modbus 10: PROFIBUS/PROFINET	0-10
P10.01	Local preset PID reference	0.0%-100.0%	0.0-100.0
P10.02	PID feedback source	0: Al1 1: Al2 2: Al3 3: Al1+ Al2 4: Al2+ Al3 5: Al3+ Al1 6: Reserved 7: Modbus 8: PROFIBUS/PROFINET	0–8
P10.03	PID output characteristics selection	0: PID output is positive. 1: PID output is negative.	0-1
P10.04	Proportional gain (Kp)	0.00-100.00	0.00-100.00
P10.05	Integral time (Ti)	0.01-10.00s	0.01-10.00
P10.06	Differential time (Td)	0.00–10.00s	0.00-10.00
P10.07	Sampling cycle (T)	0.01–100.00s	0.01-00.00
P10.08	PID control deviation limit	0.0–100.0% (Reference source)	0.0-100.0

Function code	Name	Description	Setting range
P10.09	Feedback offline detection value	0.0–100.0% (Reference source)	0.0-100.0
P10.10	Feedback offline detection time	0.0–3600.0s (Reference source)	0.0-3600.0
P10.11	PID wake-up-from-sleep value	0.0–100.0% (Reference source)	0.0-100.0
P10.12	PID sleep delay	0.0-360.0s	0.0-360.0

In PID closed-loop application, first set PID reference and PID feedback sources, adjust proportional, integral, differential initial parameters of PID control, and run the system. Adjust PID parameters again according to the commissioning method provided by group P10 to achieve satisfying control effects.

# 7.7 Analog/Digital input/output

The system features a wide range of terminal control options. In applications, P05.37, P05.38 and P05.39 can be used to set voltage type or current type. Each analog input or output has upper & lower limits and corresponding maximum and minimum parameters which can be modified by users to adjust corresponding curves.



Figure 7-2 AI1 setting relationship

When AI1–AI3 deviates, they can be calibrated by function codes. The calibration method is as follows.

Take the calibration of AI1 as an example, when input 4mA–20mA corresponds to 0–10V, first calibrate AI lower limit, input 4mA, set P05.40=1, and wait for AI1 input value in the instant message to be 0%. Then calibrate AI upper limit, set P05.40=2, input 20mA, wait for AI1 input value in the instant message to be 100%, set P05.40=0, AI1 calibration is completed.

Function code	Name	Description	Setting range
P05.17	AI1 lower limit	0.00V-P05.19	0.00V-P05.19
P05.18	Corresponding setting of Al1 lower limit	-100.0%-P05.20	-100.0%-P05.20
P05.19	AI1 upper limit	P05.17-10.00V	P05.17-10.00
P05.20	Corresponding setting of Al1 upper limit	P05.18-100.0%	P05.18-100.0
P05.21	AI1 input filter time	0.00s-10.00s	0.00-10.00
P05.22	AI2 lower limit	0.00V-P05.24	0.00-P05.24
P05.23	Corresponding setting of Al2 lower limit	-100.0%-P05.25	-100.0-P05.25
P05.24	AI2 upper limit	P05.22-10.00V	P05.22-10.00
P05.25	Corresponding setting of AI2 upper limit	P05.23-100.0%	P05.23-100.0
P05.26	AI2 input filter time	0.00s-10.00s	0.00-10.00
P05.27	AI3 lower limit	-10.00V-P05.29	-10.00-P05.29
P05.28	Corresponding setting of AI3 lower limit	-100.0%-P05.30	-100.0-P05.30
P05.29	AI3 upper limit	P05.27-10.00V	P05.27-10.00
P05.30	Corresponding setting of AI3 upper limit	P05.28-100.0%	P05.28-100.0
P05.31	AI3 input filter time	0.00s-10.00s	0.00-10.00
P05.32	AI4 lower limit	-10.00V-P05.34	-10.00-P05.34
P05.33	Corresponding setting of Al4 lower limit	-100.0%-P05.35	-100.0-P05.35
P05.34	AI4 upper limit	P05.32-10.00V	P05.32-10.00
P05.35	Corresponding setting of Al4 upper limit	P05.33-100.0%	-100.0–100.0
P05.36	AI4 input filter time	0.00s-10.00s	0.00-10.00
P05.37	Al1 mode switchover		0-1
P05.38	Al2 mode switchover	0: Current	0-1
P05.39	AI3 mode switchover	1: voltage	0-1
	AI1 calibration		0.2
P05.40	configuration	0–2	0-2
D05 /1	AI2 calibration	0: Disable	0.2
F03.41	configuration	1: Calibrate AI lower limit	0-2
P05.42	AI3 calibration configuration	2: Calibrate AI upper limit	0–2
P05.43	AI4 zero calibration coefficient	-10%-10%	-10%-10%

Al4 can only be calibrated to zero by P05.43.

The system provides multiple I/O terminals as standard configuration. All are programmable terminals, thus ensuring the flexibility and expansibility of the system. There are 12 digital input terminals and 10 relay output terminals (can be extended to 12) as standard configuration. There are multiple function selections for user input terminals. When the user configures the function of one input terminal, the corresponding signal can be connected to that terminal.



Function code	Name	Description	Setting range
P05.00	Function of S1	0: No function	0-71
P05.01	Function of S2	1: Run forward	0-71
P05.02	Function of S3	2: Run reversely	0-71
P05.03	Function of S4	3: Enable three-wire running	0-71
P05.04	Function of S5	4: Forward jogging	0-71
P05.05	Function of S6	5: Reverse jogging	0-71
P05.06	Function of S7	6: Coast to stop (emergency stop)	0-71
P05.07	Function of S8	7: Fault reset	0-71
P05.08	Function of S9	8: External fault NO input	0-71
P05.09	Function of S10	9: External fault NC input	0-71
P05.10	Function of S11	10: Increase frequency setting (UP)	0-71
P05.11	Function of S12	12: Clear the frequency increase/decrease setting 13: Clear the frequency increase/decrease setting temporarily 14: ACC/DEC time selection 1 15: ACC/DEC time selection 2 16: Multi-step speed terminal 1 17: Multi-step speed terminal 2 18: Multi-step speed terminal 3 19: Multi-step speed terminal 4 20: Pause multi-step speed running 21: Switch between A setting and B setting 22: Switch between (A+B) setting and A setting 23: Switch between (A+B) setting and B setting	0-71

Function code	Name	Description	Setting range
		24: Variable-frequency running (pulse	
		signal↑)	
		25: Power-frequency running (pulse	
		signal↑)	
		26: Switching from variable frequency to	
		power frequency (pulse signal ↑)	
		27: Switching from power frequency to	
		variable frequency (pulse signal ↑)	
		28: Medium voltage disconnection input	
		29: Pause PID control	
		30: UPS feedback	
		31: Reserved	
		32: Switching cabinet address 0	
		33: Switching cabinet address 1	
		34: Switching cabinet address 2	
		35: Switch the running command to local	
		36: Switch the running command to	
		terminal	
		37: Switch the running command to	
		communication	
		38: DCS start	
		39: DCS stop	
		40: Disable torque control	
		41. Enable master/slave control	
		42. Master-slave speed synchronization	
		43: Disable ACC/DEC	
		44: Precharge cabinet vacuum contactor	
		KM2 feedback	
		45: Commissioning signal input	
		46: Start on-site operation box	
		47: Stop on-site operation box	
		48: Medium voltage switch QF1M1	
		feedback	
		49: Medium voltage switch QF1M2	
		feedback	
		50: Medium voltage switch QF1M3	
		feedback	
		51: Medium voltage switch QF1M4	
		feedback	
		52: Medium voltage switch QF1M5	
		feedback	
		53: Medium voltage switch QF1M6	
		feedback	
		54: Medium voltage switch QF1M7	
		teedback	
		55: Medium voltage switch QF1M8	

Function code	Name	Description	Setting range
		feedback 56: Medium voltage switch QF2M1 feedback	
		57: Medium voltage switch QF2M2	
		feedback	
		feedback	
		59: Medium voltage switch QF2M4	
		feedback 60: Medium voltage switch OF2M5	
		feedback	
		61: Medium voltage switch QF2M6	
		62: Medium voltage switch OF2M7	
		feedback	
		63: Medium voltage switch QF2M8	
		64: Switching cabinet 1 remote on-site	
		state	
		65: Switching cabinet 2 remote on-site	
		state 66: Switching cabinet 3 remote on-site	
		state	
		67: Switching cabinet 4 remote on-site	
		68: Switching cabinet 5 remote on-site	
		state	
		69: Switching cabinet 6 remote on-site	
		70: Switching cabinet 7 remote on-site	
		state	
		71: Switching cabinet 8 remote on-site	
	Input terminal polarity		
P05.12	setup	0x0000-0xFFFF	0x0000-0xFFFF
P05.13	Digital filter times	1-500	1-500
P05.49	S1 switch-on delay	0.00-50.00s	0.00-50.00
P05.50	S1 switch-off delay	0.00-50.00s	0.00-50.00
P05.51	S2 switch-on delay	0.00-50.00s	0.00-50.00
P05.52	S2 switch-off delay	0.00-50.00s	0.00-50.00
P05.53	S3 switch-on delay	0.00-50.00s	0.00-50.00
P05.54	S3 switch-off delay	0.00-50.00s	0.00-50.00
P05.55	S4 switch-on delay	0.00-50.00s	0.00-50.00
P05.56	S4 switch-off delay	0.00-50.00s	0.00-50.00
P05.57	S5 switch-on delay	0.00-50.00s	0.00-50.00
P05.58	S5 switch-off delay	0.00-50.00s	0.00-50.00
PU3.59	So switch-on delay	0.00-50.005	0.00-50.00

Function code	Name	Description	Setting range
P05.60	S6 switch-off delay	0.00-50.00s	0.00-50.00
P05.61	S7 switch-on delay	0.00-50.00s	0.00-50.00
P05.62	S7 switch-off delay	0.00-50.00s	0.00-50.00
P05.63	S8 switch-on delay	0.00-50.00s	0.00-50.00
P05.64	S8 switch-off delay	0.00-50.00s	0.00-50.00
P05.65	S9 switch-on delay	0.00-50.00s	0.00-50.00
P05.66	S9 switch-off delay	0.00-50.00s	0.00-50.00
P05.67	S10 switch-on delay	0.00-50.00s	0.00-50.00
P05.68	S10 switch-off delay	0.00-50.00s	0.00-50.00
P05.69	S11 switch-on delay	0.00-50.00s	0.00-50.00
P05.70	S11 switch-off delay	0.00-50.00s	0.00-50.00
P05.71	S12 switch-on delay	0.00-50.00s	0.00-50.00
P05.72	S12 switch-off delay	0.00–50.00s	0.00-50.00

Similarly, after the user output terminal is configured with one output signal, a low level signal will be output when conditions are met. Only RO1–RO8 have the input and output delay function. You can select and set the corresponding delay for delayed applications.



Function code	Name	Description	Setting range
P06.00	RO1 output	0: No output 1: In VFD running 2: Fault output 3: Frequency level detection FDT output 4: Frequency reached 5: Zero speed running	0–91

Function code	Name	Description	Setting range
		6: Variable-frequency working state	
		7: Power frequency bypass working state	
		8: Running time reached	
		9: Running forward	
		10: Running reversely	
		11: Ready for running (running request)	
		12: Alarm output	
		Variable-frequency:	
		13: Permission of medium voltage switch	
		QF1M1 switching on	
		14: Permission of medium voltage switch	
		QF1M2 switching on	
		15: Permission of medium voltage switch	
		QF1M3 switching on	
		16: Permission of medium voltage switch	
		QF1M4 switching on	
		17: Permission of medium voltage switch	
		QF1M5 switching on	
		18: Permission of medium voltage switch	
		QF1M6 switching on	
		19: Permission of medium voltage switch	
		QF1M7 switching on	
		20: Permission of medium voltage switch	
		QF1M8 switching on power frequency	
		Power frequency:	
		21: Permission of medium voltage switch	
		QF2M1 switching on	
		22: Permission of medium voltage switch	
		QF2M2 switching on	
		23: Permission of medium voltage switch	
		QF2M3 switching on	
		24: Permission of medium voltage switch	
		QF2M4 switching on	
		25: Permission of medium voltage switch	
		QF2M5 switching on	
		26: Permission of medium voltage switch	
		QF2M6 switching on	
		27: Permission of medium voltage switch	
		QF2M7 switching on	
		28: Permission of medium voltage switch	
		QF2M8 switching on	
		29: Permission of medium voltage switch	
		QF1M1 switching off	
		30: Permission of medium voltage switch	
		QF1M2 switching off	
		31: Permission of medium voltage switch	
		QF1M3 switching off	

Function code	Name	Description	Setting range
		32: Permission of medium voltage switch	
		QF1M4 switching off	
		33: Permission of medium voltage switch	
		QF1M5 switching off	
		34: Permission of medium voltage switch	
		QF1M6 switching off	
		35: Permission of medium voltage switch	
		QF1M7 switching off	
		36: Permission of medium voltage switch	
		QF1M8 switching off	
		37: Permission of medium voltage switch	
		QF2M1 switching off	
		38: Permission of medium voltage switch	
		QF2M2 switching off	
		39: Permission of medium voltage switch	
		QF2M3 switching off	
		40: Permission of medium voltage switch	
		QF2M4 switching off	
		41: Permission of medium voltage switch	
		QF2M5 switching off	
		42: Permission of medium voltage switch	
		QF2M6 switching off	
		43: Permission of medium voltage switch	
		QF2M7 switching off	
		44: Permission of medium voltage switch	
		QF2M8 switching off	
		45: Variable-frequency working state of	
		switching cabinet 1	
		46: Power-frequency working state of	
		switching cabinet 1	
		47: Variable-frequency working state of	
		switching cabinet 2	
		48: Power-frequency working state of	
		switching cabinet 2	
		49: Variable-frequency working state of	
		switching cabinet 3	
		50: Power-frequency working state of	
		switching cabinet 3	
		51: variable-frequency working state of	
		Switching cabinet 4	
		switching cabinet 4	
		Switching cabinet 4	
		switching cabinet 5	
		54. Power-frequency working state of	
		switching cabinet 5	
		55: Variable-frequency working state of	

Function code	Name	Description	Setting range
		switching cabinet 6	
		56: Power-frequency working state of	
		switching cabinet 6	
		57: Variable-frequency working state of	
		switching cabinet 7	
		58: Power-frequency working state of	
		switching cabinet 7	
		59: Variable-frequency working state of	
		Switching cabinet 8	
		60: Power-frequency working state of	
		(45-60: Both power frequency and	
		variable frequency valid at the same	
		time indicates fault.)	
		61: Unit bypass state	
		62: Remote-local state	
		63–64: Reserved	
		65: Low-voltage commissioning vacuum	
		contactor KM1 control	
		66: Low-voltage commissioning vacuum	
		contactor KM2 control	
		67: Switching cabinet 1# KM1 feedback	
		signal	
		68: Switching cabinet 1# KM2 feedback	
		signal	
		69: Switching cabinet 1# KM3 feedback	
		signal	
		righal	
		71: Switching cabinet 2# KM2 feedback	
		signal	
		72: Switching cabinet 2# KM3 feedback	
		signal	
		73: Switching cabinet 3# KM1 feedback	
		signal	
		74: Switching cabinet 3# KM2 feedback	
		signal	
		75: Switching cabinet 3# KM3 feedback	
		signal	
		76: Switching cabinet 4# KM1 feedback	
		signal	
		r: Switching cabinet 4# KM2 feedback	
		Signal 78: Switching cabinet 1# KM2 foodback	
		signal	
		79: Switching cabinet KM4 feedback	
		signal	

Function code	Name	Description	Setting range
		80: Switching cabinet 1 QS1 feedback	
		signal	
		81: Switching cabinet 1 QS2 feedback	
		signal	
		82: Switching cabinet 1 QS3 feedback	
		signal	
		83: Switching cabinet 2 QS1 feedback	
		signal	
		84: Switching cabinet 2 QS2 feedback	
		signal	
		85: Switching cabinet 2 QS3 feedback	
		signal	
		signal	
		87: Switching cabinet 3 OS2 feedback	
		signal	
		88: Switching cabinet 3 OS3 feedback	
		signal	
		89: Switching cabinet 4 QS1 feedback	
		signal	
		90: Switching cabinet 4 QS2 feedback	
		signal	
		91: Switching cabinet 4 QS3 feedback	
		signal	
P06.47	RO1 switch-on delay	0.00-50.00s	0.00-50.00
P06.48	RO1 switch-off delay	0.00-50.00s	0.00-50.00
P06.49	RO2 switch-on delay	0.00-50.00s	0.00-50.00
P06.50	RO2 switch-off delay	0.00-50.00s	0.00-50.00
P06.51	RO3 switch-on delay	0.00–50.00s	0.00-50.00
P06.52	RO3 switch-off delay	0.00-50.00s	0.00-50.00
P06.53	RO4 switch-on delay	0.00-50.00s	0.00-50.00
P06.54	RO4 switch-off delay	0.00–50.00s	0.00-50.00
P06.55	RO5 switch-on delay	0.00–50.00s	0.00-50.00
P06.56	RO5 switch-off delay	0.00–50.00s	0.00-50.00
P06.57	RO6 switch-on delay	0.00–50.00s	0.00-50.00
P06.58	RO6 switch-off delay	0.00–50.00s	0.00-50.00
P06.59	RO7 switch-on delay	0.00–50.00s	0.00-50.00
P06.60	RO7 switch-off delay	0.00–50.00s	0.00-50.00
P06.61	RO8 switch-on delay	0.00–50.00s	0.00-50.00
P06.62	RO8 switch-off delay	0.00–50.00s	0.00-50.00

# 7.8 Bypass switching function

INVT bypass cabinets are divided into manual bypass cabinets, automatic bypass cabinets and one-driving-more bypass cabinet.

## 7.8.1 Switching cabinet function setting

The system supports one-drive-multiple switching cabinet control. A maximum of 8 control boards can be used to control 8 switching cabinets. The address codes are selected by the DIP switches on the boards. The control scheme configuration of the one-drive-multiple switching cabinet is as follows.



Figure 7-4 Configuration of the one-driving-more switching cabinet

The DIP switch 1, 2 and 3 on the control board can combine into 4 states corresponding to 4 switching cabinet addresses. As shown in the following table, the main control board will send a command to the switching cabinet along with corresponding switching cabinet address, only when the switching cabinet address is the same as the command address, the switching cabinet will act.

DIP switch 1	DIP switch 2	DIP switch 3	Switching cabinet address
OFF	OFF	OFF	Switching cabinet 1
ON	OFF	OFF	Switching cabinet 2
OFF	ON	OFF	Switching cabinet 3
ON	ON	OFF	Switching cabinet 4

DIP switch 4 is the voltage detection function enabling. When the DIP switch is tuned to ON, the voltage detection function of the switching cabinet control board is enabled. When the DIP switch is tuned to OFF, the voltage detection function of the switching cabinet control board is disabled.

The switches and jumpers in the control system shall be set well in factory. It is not recommended to modify; otherwise, damage may occur. If necessary, please read the instructions carefully before proper operating.

Related function codes:

Function code	Name	Description	Setting range
P07.10	Max. number of switching cabinets	0-4	0-4
P15.01	Switching cabinet QF configuration mode	0: Independent mode 1: Two-in-One mode	0-1
P15.35	Fault power-frequency bypass action selection	0: Manual power-frequency bypass 1: Automatic power-frequency bypass	0-1
P15.36	KM1 configuration	0: KM1 is configured 1: KM1 is not configured	0-1
P15.37	Switching cabinet type	0: Manual 1: Automatic	0-1

For different types of switching cabinets, function codes need to be set according to the actual situation, such as the number of bypass cabinets, manual or automatic, whether KM1 is configured or not, etc.

### 7.8.2 Manual bypass

The following describes the function of configuring only one manual bypass cabinet. When the system stops for a short time according to production process requirements, operators can switch variable frequency to power frequency by using the manual bypass cabinet. Figure 7-5 is main circuit diagram of the manual bypass cabinet. QF refers to the higher level customer breaker of the system, the higher level breaker QF and the system shall be interlocked, that is, QF can only be switched on when the system is in the switch-on allowing state. QF switch-on of the higher level switchgear is invalid in the system fault state, QF is automatically switched off when a fault occurs to the system after switch-on.





Parameter setting: P07.10=1; P15.36=1; P15.37=0

The procedure of switching between variable frequency and power frequency is as follows.

**Note**: The switching operations of the knife switches QS1, QS2 are conducted in the switch-off state of QF.

#### Variable-frequency running

- Step 1 Press the unlock key of the electromagnetic lock, and pull the electromagnetic lock rightwards to the unlock position.
- Step 2 Pull out the baffle pin, and move it from the position of baffle closing to the position of power frequency and variable frequency switching. At this time, the operation hole of the power frequency and variable frequency switching isolation switch is open, insert the operation handle to rotate clockwise, so that the isolation switch QS2 is the switch-on (variable frequency) position, and pull out the operation handle.
- Step 3 Pull out the baffle pin, and move it from the position of power frequency and variable frequency switching to the position of the upper isolation switch-on/switch-off. At this time, the operation hole of the upper isolation switch is open, insert the operation handle to rotate counterclockwise, so that the upper isolation switch QS1 is switched on, and pull out the operation handle.
- Step 4 After the conversion is complete, pull out the baffle pin, put it down to the position of baffle closing, pull the electromagnetic lock leftwards, make the electromagnetic lock reset to the locking position, and the system is in the running state.
- Step 5 Send a switch-on permission signal, the GD5000 VFD is connected to the medium voltage power supply, the motor is connected to the VFD, and the VFD can be used normally.

#### Switch from variable frequency to power frequency

- Step 1 Press the unlock key of the electromagnetic lock, and pull the electromagnetic lock rightwards to the unlock position.
- Step 2 Pull out the baffle pin, and move it from the position of baffle closing to the position of the upper isolation switch-on/switch-off. At this time, the operation hole of the upper isolation switch is open, insert the operation handle to rotate clockwise, so that the upper isolation switch QS1 is switched

on, and pull out the operation handle.

- Step 3 Pull out the baffle pin, and move it from the position of the upper isolation switch-on/switch-off to the position of power frequency and variable frequency switching. At this time, the operation hole of the power frequency and variable frequency switching isolation switch is open, insert the operation handle to rotate counterclockwise, so that the isolation switch QS2 is the switch-off (power frequency) position, and pull out the operation handle.
- Step 4 After the conversion is complete, pull out the baffle pin, put it down to the position of baffle closing, pull the electromagnetic lock leftwards, make the electromagnetic lock reset to the locking position, and the system is in the running state.
- Step 5 After a variable frequency permission signal is sent, QF is allowed to switch on, and the motor is connected to the power frequency power supply.

### 7.8.3 Automatic bypass

The following describes the function of configuring only one automatic bypass cabinet. When the system is not allowed to stop, the automatic bypass cabinet will switch automatically. The cabinet has three medium voltage vacuum contactors KM1, KM2 and KM3, among which KM2 and KM3 realize electric interlock to ensure the power frequency supply will not be directly sent to the output terminal of the variable-frequency speed regulation system. The automatic bypass cabinet with isolation also has two isolation knife switches QS1 and QS2 to isolate the variable-frequency speed regulation system from medium voltage power supply when the motor runs at power frequency, convenient for maintenance and inspection. The main circuit diagram of automatic bypass cabinet is shown in Figure 7-6.



Figure 7-6 Main circuit diagram of the automatic bypass cabinet

Relevant parameter setting: P07.10=1, P15.36=0, P15.37=1. P15.35 needs to be configured according to whether a power frequency bypass is required after a fault occurs.

**Note**: The switching operations of the knife switches QS1, QS2 are conducted in the switch-off state of QF.

#### **Power-on operations:**

- Step 1 Close the cabinet door, and observe whether QS1 and QS2 are in the switch-off state.
- Step 2 Press the unlock key of the electromagnetic lock, and pull the electromagnetic lock rightwards to the unlock position.
- Step 3 Pull out the baffle pin, and move it from the position of baffle closing to the position of power frequency and variable frequency switching. At this time, the operation hole of the power frequency and variable frequency switching isolation switch is open, insert the operation handle to rotate counterclockwise, so that the isolation switch QS2 is the switch-on position, and pull out the operation handle.
- Step 4 Pull out the baffle pin, and move it from the position of power frequency and variable frequency switching to the position of the upper isolation switch-on/switch-off. At this time, the operation hole of the upper isolation switch is open, insert the operation handle to rotate counterclockwise,

so that the upper isolation switch QS1 is switched on, and pull out the operation handle.

- Step 5 After the conversion is complete, pull out the baffle pin, put it down to the position of baffle closing, pull the electromagnetic lock leftwards, make the electromagnetic lock reset to the locking position.
- Step 6 The system sends a command, KM1 and KM2 are switched on (KM3 is switched off).
- Step 7 Check whether the feedback signal of the vacuum contactor is consistent with the working state, and the system is in the variable-frequency running state.
- Mode for switching from variable frequency to power frequency:
- Step 1 Close the cabinet door, and observe whether QS1 and QS2 are switched on.
- Step 2 The system sends a command, KM1 and KM2 are switched off, KM3 is switched on, and the system is in the power frequency running state.
- Step 3 Check whether the feedback signal of the vacuum contactor is consistent with the working state, and the system is in the power frequency running state.

#### Maintenance mode:

- Step 1 Close the cabinet door, and observe whether QS1 and QS2 are switched on.
- Step 2 The system sends a command, KM1, KM2 and KM3 are switched off.
- Step 3 Check whether the feedback signal of the vacuum contactor is consistent with the working state,
- Step 4 Ensure that the front-end circuit breaker QF is switched off, the vacuum circuit breaker is moved out of the state, and the maintenance sign is hung.
- Step 5 Press the unlock key of the electromagnetic lock, and pull the electromagnetic lock rightwards to the unlock position.
- Step 6 Pull out the baffle pin, and move it from the position of baffle closing to the position of the upper isolation switch-on/switch-off. At this time, the operation hole of the upper isolation switch is open, insert the operation handle to rotate clockwise, so that the upper isolation switch QS1 is switched on, and pull out the operation handle.
- Step 7 Pull out the baffle pin, and move it from the position of the upper isolation switch-on/switch-off to the position of power frequency and variable frequency switching. At this time, the operation hole of the power frequency and variable frequency switching isolation switch is open, insert the operation handle to rotate clockwise, so that the isolation switch QS2 is the switch-off position, and pull out the operation handle.
- Step 8 After the conversion is complete, pull out the baffle pin, put it down to the position of baffle closing, pull the electromagnetic lock leftwards, make the electromagnetic lock reset to the locking position, and the system is in the maintenance state.

### 7.8.4 One-driving-more application

The system supports one-drive-four switching cabinet control, that is to say, 4 switching cabinets are controlled by corresponding 4 control boards. The address codes are selected by the DIP switches on the control boards. The following only introduces the application of 2 switching cabinets, and other switching cabinets are similar to it.

Figure 7-7 One-driving-two diagram



Relevant parameter settings: take automatic bypass cabinets with one-driving-two for example, P07.10=2; P15.01=1; P15.36=0; P15.37=1.

After the parameters are set as above, it will be configured to the automatic bypass cabinet state in independent mode as shown in Figure 7-7. (P15.01 is configured to independent mode when the bus of frequency input and frequency input are independent).

In the application, QS1, QS2, QS3 and QS4 need to be switched on manually when the medium voltage power is not connected.

M1 variable-frequency mode: When the medium voltage switch QF1 is in the switch-off state, a switch-on permission signal is issued, and user QF1 is switched on. When a variable frequency command is issued, KM1 is switched on, and the GD5000 VFD is connected to the medium voltage power supply. After the VFD completes the self-check items without fault, KM2 is switched on, the motor M1 is connected to the VFD, and the VFD can be used normally.

M1 power frequency mode: When users need power frequency running, a switch-on permission signal is issued, and user QF1 is switched on. After a power frequency command is issued, KM3 is switched on, and the motor M1 will be directly connected to the power frequency power supply.

#### ∠Note:

- When M1 is in the variable-frequency mode, M2 can only be in static or power frequency mode, and vice versa.
- KM1 and KM4, KM2 and KM5 are locked and they cannot be switched on simultaneously.
- During maintenance, disconnect QS1, QS2, QS3 and QS4 to form an obvious breakpoint, which can extend the one-driving-four applications. It is not described in detail here.

## 7.9 Master-slave control

Master-slave control is that two or above motors work in cooperation to drive the load, including master-slave power-balancing mode and master-slave speed synchronous mode. The first mode is the control mode that the motors are connected to work together in way of gearboxes, guide rails, chains, belts or shafts coupling and the powers among the motors are distributed properly to reach corresponding control precision. External control signals are connected to the master and the slaves are controlled by the master via communication. Master-slave power-balancing mode is the main mode of master-slave control.

As for rigid connection via gearboxes or shafts coupling, the master runs under speed mode while the slaves run under torque mode; as for flexible connection via belts, both the master and the slaves are under speed mode.



As shown in the above figure, the master-slave control adopts a ring connection method, where TX is the optical fiber transmitting port and RX is the optical fiber receiving port, which can support the control of one master and four slaves.

As for a master-slave control system, carry out parameters autotuning respectively at first, then select the speed mode for the master, next set the command channel and reference of the master and finally set master output signal source (P12.01). As for the slaves, set P00.01 to master, then select the speed mode or torque mode for the slaves, next set master output signal source in consistent with the master and finally adjust PID control parameters of the slaves.

No matter speed mode or torque mode for the slaves, the effect of PID adjusting is fine adjustment, so the effect should not be too strong; otherwise, the slaves may run unstably. Set P15.02 to 1 in the cases where the master and slaves need to power on and off at the same time and the switching cabinets are installed.



Rigid connection: Rigid connection modes such as gears, chains, rollers or shaft coupling, with no deviation in linear speed between the master and the slaves.

Flexible connection: Connection mode such as conveyor belts, with slight deviations in linear speed between the master and the slaves.

Connection mode of loads in coal industry: Rigid connection indicates the master and slaves drive a roller (Figure 1). There is belt connection (Figure 2) between the master and the slaves , which shall be flexible connection in theory, but is considered rigid connection in actual application. When the belt between the master and the slaves is not tight, it can be considered as a flexible connection. The master-slave connection usually involved in the practical applications is flexible connection or rigid connection, and the control method will usually be matched, as shown in the following table.

Control mode	Master running mode	Slave running mode	Master/slave connection mode
V/F control	Master speed mode	Slave speed mode	Flexible/rigid connection
Vector control	Master speed mode	Slave speed mode	Flexible connection
vector control	Master speed mode	Slave torque mode	Rigid connection

Note:

- Select a proper control method according to the type of master-slave load connection, V/F control is used in priority.
- For unstable situations of V/F control, vector control can be considered.

### 7.9.1 Flexible connection

#### 7.9.1.1 V/F control

When the master and the slaves use V/F control, the commissioning step flowchart is shown in the following figure.



First, the master and the slaves need to be in single-node mode, each frequency band in V/F control runs steadily. Observe the running direction of the motor to ensure the consistency of the running direction. Set the slave reference frequency gain = R master/R slave according to the master-slave roller diameter. Set the master-slave droop frequency to 1Hz, when the master-slave current fluctuates, the value can be fine-tuned.

Function	Name	Description	Setting	Master	Slave
code		0. Cross valtage	range		
P00.00	Control mode selection	<ul> <li>vector control</li> <li>1: Asynchronous</li> <li>sensorless vector</li> <li>control</li> <li>2: Synchronous</li> <li>sensorless vector</li> <li>control</li> <li>3: Vector control</li> </ul>	0–3	0	Same as the master
P00.16	ACC time 1	0.1-3600.0s	0.1-3600.0	100.0s	Same as the master
P00.17	DEC time 1	0.1-3600.0s	0.1-3600.0	100.0s	Same as the master
P00.18	Running direction	0: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running	0–2	V/F control diagram in section 7.9.1.1	V/F control diagram in section 7.9.1.1
P01.01	Start mode	0: Direct start 1: Start after DC braking 2: Start after rotating speed tracking	0–2	0	Same as the master
P01.02	Starting frequency of direct start	0.00-10.00Hz	0.00-10.00	0.5Hz	Same as the master
P01.03	Starting frequency hold time	0.0–50.0s	0.0-50.0	1s	Same as the master
P01.09	Stop mode	0: Decelerate to stop 1: Coast to stop	0-1	1	Same as the master
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0-1	Set according to the nameplate	Set according to the nameplate
P02.01	Rated power of AM 1	4–50000kW	4–50000kW	Set according to the nameplate	Set according to the nameplate
P02.02	Rated frequency of AM 1	0.01Hz–P00.10 (Max. output frequency)	0.01Hz – P00.10	Set according to the nameplate	Set according to the nameplate
P02.04	Rated voltage of AM 1	0–20000V	0–20000	Set according to the nameplate	Set according to the nameplate
P02.05	Rated current	0.1-1000.0A	0.1-1000.0	Set according	Set according

Function code	Name	Description	Setting range	Master	Slave
	of AM 1			to the nameplate	to the nameplate
P02.03	Rated speed of AM 1	0.1–1000.0A	0.1-1000.0	Set according to the nameplate, if there is no rated speed on the nameplate, consult the motor manufacturer.	Set according to the nameplate, if there is no rated speed on the nameplate, consult the motor manufacturer.
P04.01	Torque boost	0.0%-10.0%	0.0-10.0	0.1%	Same as the master
P08.23	Drop control	0.00-10.00Hz	0.00-10.00	1Hz	Same as the master
P04.18	Low-frequency oscillation control factor	0-100	0-100	V/F control diagram in section 7.9.1.1	V/F control diagram in section 7.9.1.1
P04.19	High-frequenc y oscillation control factor	0-100	0-100	V/F control diagram in section 7.9.1.1	V/F control diagram in section 7.9.1.1
P04.20	Vibration control frequency threshold	0.00-120.00Hz	0.00-120.00	15.00Hz	Same as the master
P12.29	Master-slave type setting	0: Single master 1: Spare machine 2: Master 3: Slave	0–3	2	3
P12.05	Slave reference frequency source gain	0.01-100.00	0.001- 100.000	The function code of the master is invalid.	The formula is as follows.

P12.05 is used to ensure that the master and the slaves drive the rollers at the same linear speed, which depends on the reduction ratio of the reducer and the radius of the roller. The master does not need to be set, but the slaves need to be set.

Slave P12.05= Roller radius of the master Roller radius of the slaves \* Reducer reduction ratio of the master Reducer reduction ratio of the slaves

- 1. If overcurrent is reported during the start-up process, the starting frequency can be increased appropriately.
- 2. If the output current of the master and the slaves fluctuates greatly during running, you can fine-tune P08.23 and adjust the step length  $\pm$  0.1Hz.
- 3. If the output current of the master and the slaves deviates greatly during running, you can fine-tune P12.05 and adjust the step length  $\pm$  0.001. If the output current of the slaves is lower than the master, you can increase P12.05, and vice versa. Balance the output current through no-load adjustment, and try not to adjust the droop value.

4. Calculate the slip frequency, and obtain the starting frequency.

#### 7.9.1.2 Vector control

When the master and the slaves use vector control, the commissioning step flowchart is shown in the following figure.



First, the master and the slaves need to be in single-node mode, each frequency band in V/F control runs steadily. Observe the running direction of the motor to ensure the consistency of the running direction. The parameter autotuning is needed before running in vector mode. Set the slave reference frequency gain = R master/R slave according to the master-slave roller diameter. Set the master-slave droop frequency to 1Hz, when the master-slave current fluctuates, the value can be fine-tuned.

Functio n code	Name	Description	Setting range	Master	Slave
P00.00	Control mode selection	0: Space voltage vector control 1: Asynchronous sensorless vector control 2: Synchronous sensorless vector control 3: Vector control	0-3	2	Same as the master
P00.05	Speed reference mode	0: Speed mode 1: Torque mode	0-3	0	2

Functio n code	Name	Description	Setting range	Master	Slave
		2: Slave speed mode 3: Slave torque mode			
P00.16	ACC time 1	0.1-3600.0s	0.1– 3600.0	100.0s	Same as the master
P00.17	DEC time 1	0.1–3600.0s	0.1- 3600.0	100.0s	Same as the master
P00.18	Running direction	<ol> <li>0: Run at the default direction.</li> <li>1: Run at the opposite direction.</li> <li>2: Disable reverse running</li> </ol>	0-2	V/F control diagram in section 7.9.1.1	V/F control diagram in section 7.9.1.1
P01.01	Start mode	0: Direct start 1: Start after DC braking 2: Start after rotating speed tracking	0–2	0	Same as the master
P01.02	Starting frequency of direct start	0.00-10.00Hz	0.00- 10.00	0.5Hz	Same as the master
P01.03	Starting frequency hold time	0.0–50.0s	0.0–50.0	4.0s	Same as the master
P01.09	Stop mode	0: Decelerate to stop 1: Coast to stop	0-1	1	Same as the master
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0-1	Set according to the nameplate	Set according to the nameplate
P02.01	Rated power of AM 1	4–50000kW	4–50000	Set according to the nameplate	Set according to the nameplate
P02.02	Rated frequency of AM 1	0.01Hz–P00.10(Max. output frequency)	0.01- P00.10	Set according to the nameplate	Set according to the nameplate
P02.04	Rated voltage of AM 1	0-20000V	0–20000	Set according to the nameplate	Set according to the nameplate
P02.05	Rated current of AM 1	0.1–1000.0A	0.1- 1000.0	Set according to the nameplate	Set according to the nameplate
P02.03	Rated speed of AM 1	0.1-1000.0A	0.1- 1000.0	Set according to the nameplate, if there is no rated speed on the nameplate, consult the motor manufacturer.	Set according to the nameplate, if there is no rated speed on the nameplate, consult the motor manufacturer.
P04.01	Torque boost	0.0%-10.0%	0.0-10.0	0.1%	Same as the master
P08.23	Drop control	0.00–10.00Hz	0.00- 10.00	1Hz	Same as the master

Functio n code	Name	Description	Setting range	Master	Slave
P04.18	Low-frequency oscillation control factor	0-100	0-100	V/F control diagram in section 7.9.1.1	V/F control diagram in section 7.9.1.1
P04.19	High-frequency oscillation control factor	0–100	0-100	V/F control diagram in section 7.9.1.1	V/F control diagram in section 7.9.1.1
P04.20	Vibration control frequency threshold	0.00–120.00Hz	0.00- 120.00	15.00Hz	Same as the master
P12.29	Master-slave type setting	0: Single master 1: Spare machine 2: Master 3: Slave	0-3	2	3
P12.02	Filter time of slave reference signal	0.00s-655.35s	0.00- 655.35	The function code of the master is invalid.	0.2s
P12.05	Slave reference frequency source gain	0.01–100.00	0.001- 100.000	The function code of the master is invalid.	The formula is as follows.

P12.05 is used to ensure that the master and the slaves drive the rollers at the same linear speed, which depends on the reduction ratio of the reducer and the radius of the roller. The master does not need to be set, but the slaves need to be set.

Slave P12.05= Roller radius of the slaves \* Reducer reduction ratio of the master Roller radius of the slaves \* 1.00

If overcurrent is reported during the start-up process, the starting frequency can be increased appropriately. For rollers with greater inertia, you can decrease the speed loop proportional gain 1 and increase the speed loop integral time 1 appropriately. Both the master and the slaves need to be modified to keep consistent.

Function code	Name	Description	Setting range	Default
P03.00	Speed-loop proportional gain 1	0-100	0-100	5
P03.01	Speed-loop integral time 1	0.01–10.00s	0.01-10.00	0.10s

## 7.9.2 Rigid connection

When the master uses vector speed control and the slaves use the vector torque control, the commissioning step flowchart is shown in the following figure.



The master uses vector speed mode, the slaves use the vector torque mode, in single-node mode, each frequency band in V/F control runs steadily. Observe the running direction of the motor to ensure the consistency of the running direction. Disconnect from the load to perform parameter autotuning, set the slave reference torque gain = P slave/P master according to the master-slave VFD power. Adjust the master speed loop PI parameters when the master-slave current fluctuates.

Function code	Name	Description	Setting range	Master	Slave
P00.05	Speed reference mode	0: Speed mode 1: Torque mode 2: Slave speed mode 3: Slave torque mode	0–3	0	3
P08.23	Drop control	0.00-10.00Hz	0.00-10.00	0.0Hz	Same as the master

# 7.10 Synchronous switching

### 7.10.1 Synchronous switching with reactors

Goodrive5000 medium voltage variable-frequency speed regulation system can achieve bumpless synchronous switching between power frequency and variable frequency. When variable frequency switches into power frequency, the system will adjust the phase, frequency and range of output voltage, and then switch into power frequency when in consistent with power supply at power frequency, with small surge. When power frequency switches into variable frequency, the system will automatically track current motor speed, and then switch into variable frequency. Achieved by the switching cabinet, synchronous switching makes the system run reliably with small surge to the motor and it is applicable in one-drive-more control such as constant pressure water supply.

Since there is an inherent angle deviation between the detection loop and the actual grid waveform, it is

necessary to perform the compensation angle autotuning. The commissioning steps are as follows (taking switching cabinet 1 as an example).

- 1. Set P15.03=1: Synchronous switching with reactors.
- 2. Set P15.21=0min, after setting P15.21 to 0min, only phase locking will be performed during synchronous switching, and the power frequency switching-on will not be executed.
- 3. When the VFD is running, it will execute "switch from variable frequency to power frequency" to lock the phases, if the running frequency of the VFD is lower than 35Hz, it will not respond to the command of "switch from variable frequency to power frequency". Open INVT Workshop and monitor the waveforms of input voltage and output voltage.
- 4. After locking phases for a period of time, view P15.26 to obtain the actual deviation angle.
- 5. Coast to stop, then set P15.22 = current value + P15.26, the current value is 4° by default.
- 6. Restore the default value of P15.21, and the value can also be adjusted appropriately according to the site.

Function code	Name	Description	Setting range	Default
P15.03	Synchronous switching enabling	0: Disable 1: Synchronous switching with reactors 2: Synchronous switching without reactors	0–2	0
P15.21	Synchronous switchover phase lock delay	0–120min	0-120	2min
P15.22	Synchronous switchover angle compensation of switching cabinet 1	-200.0–200.0°	-200.0–200.0	12.0°
P15.23	Synchronous switchover angle compensation of switching cabinet 2	-200.0–200.0°	-200.0-200.0	12.0°
P15.24	Synchronous switchover angle compensation of switching cabinet 3	-200.0–200.0°	-200.0-200.0	12.0°
P15.25	Synchronous switchover angle compensation of switching cabinet 4	-200.0–200.0°	-200.0-200.0	12.0°
P15.26	Synchronous switchover actual deviation angle of switching cabinet 1	0–65535	0–65535	0
P15.27	Synchronous switchover actual deviation angle of switching cabinet 2	0–65535	0–65535	0

Function code	Name	Description	Setting range	Default
	Synchronous			
P15.28	switchover actual	0–65535	0-65535	0
	deviation angle of			-
	switching cabinet 3			
P15.29	Synchronous			
	switchover actual	0 65535	0 65525	0
	deviation angle of	0-0333	0-00000	0
	switching cabinet 4			

If overcurrent or unit overvoltage is reported during the process of switching from variable frequency to power frequency, you can try to adjust P15.22, according to the 0.2 ° step length (increasing the compensation angle is in priority), and ensure the current peak is below 1.5 times the VFD current peak. If the switching fails, you can adjust P15.21, P15.33 and P15.34 appropriately. The smaller the stability accuracy indicates the longer the stability holding time, and the higher the phase locking accuracy indicates the smaller the shock. However, if there are fluctuations in the grid, phase locking failure may be caused.



Figure 7-8 Synchronous switching wiring diagram



Figure 7-9 Flowchart of switching from variable frequency to power frequency

Function code	Name	Description	Setting range	Default
P15.03	Synchronous switching enabling	<ul><li>0: Disable</li><li>1: Synchronous switching with</li><li>reactors</li><li>2: Synchronous switching without</li><li>reactors</li></ul>	0-2	0

Function code	Name	Description	Setting range	Default
	Synchronous			
P15.21	switchover phase	0–120min	0-120	2min
	lock delay			
	Filter coefficient for			
P15.32	synchronous	1–20	1–20	4
	switchover			
	Phase locking			
D15 22	stability accuracy	1 500	1 500	200
P15.55	for synchronous	1-500	1-500	200
	switchover			
P15.34	Stability holding			
	time for	0.1.100.00	0 1 100 0	1.00
	synchronous	0.1-100.05	0.1-100.0	4.05
	switchover			

### 7.10.2 Synchronous switching without reactors

The electrical block diagram of the standard one-driving-one synchronous switching without reactor is shown in Figure 7-10.

During the whole switching process, the input voltage of medium voltage bus 2, the contactor switching control signal, the feedback signal of the contactors and knife switches are completed by the switching cabinet control board. This switching method is mainly applicable to large inertia loads such as fans.

Figure 7-10 Electrical diagram of one-driving-one without reactor for switching from variable frequency to power





-203-

It is necessary to perform the autotuning for the switching cabinet action time and the motor frequency drop rate first. Take the switching cabinet 1 as an example, the process is as follows.



The operation process of synchronous switching without reactors is as follows. If the inrush current is large during the switching process, you can increase P15.22 appropriately and increase the step length by about 1°.



Function code	Name	Description	Setting range	Default
P15.03	Synchronous switching enabling	<ul><li>0: Disable</li><li>1: Synchronous switching with</li><li>reactors</li><li>2: Synchronous switching without</li><li>reactors</li></ul>	0–2	0
P15.09	Motor frequency drop rate of switching cabinet 1	0.00-50.00Hz	0.00-50.00	0.00Hz
P15.10	Motor frequency drop rate of switching cabinet 2	0.00–50.00Hz	0.00-50.00	0.00Hz
P15.11	Motor frequency drop rate of switching cabinet 3	0.00–50.00Hz	0.00-50.00	0.00Hz
P15.12	Motor frequency drop rate of switching cabinet 4	0.00–50.00Hz	0.00-50.00	0.00Hz
P15.13	Action time of switching cabinet 1	0–300ms	0-300	90ms
P15.14	Action time of switching cabinet 2	0–300ms	0–300	90ms
P15.15	Action time of	0–300ms	0-300	90ms
P15.16	Action time of switching cabinet 4	0–300ms	0–300	90ms
P15.17	Torque current of	0.0-6553.5A	0.0-6553.5	0.0A
P15.18	Torque current of switching cabinet 2	0.0-6553.5A	0.0-6553.5	0.0A
P15.19	Torque current of switching cabinet 3	0.0-6553.5A	0.0-6553.5	0.0A
P15.20	Torque current of switching cabinet 4	0.0-6553.5A	0.0-6553.5	0.0A
P15.21	Synchronous switchover phase lock delay	0–120min	0-120	2min
P15.22	Synchronous switchover angle compensation of switching cabinet 1	-200.0-200.0°	-200.0-200.0	12.0°
P15.23	Synchronous switchover angle compensation of switching cabinet 2	-200.0–200.0°	-200.0-200.0	12.0°
P15.24	Synchronous switchover angle compensation of switching cabinet 3	-200.0–200.0°	-200.0-200.0	12.0°
Function code	Name	Description	Setting range	Default
------------------	---	---------------	---------------	---------
P15.25	Synchronous switchover angle compensation of switching cabinet 4	-200.0–200.0°	-200.0–200.0	12.0°

# 7.11 Unit bypass function

The power units of the medium voltage VFD have the function of unit bypasses, one is IGBT bypass and the other is contactor bypass (optional). When a unit has a fault, the unit will achieve automatic bypass to ensure the system continues working normally.

#### ∠Note:

- 1. Unit bypass can only be completed when the unit optical-fiber communication is normal.
- 2. The unit bypass can bypass up to two groups of units for 10kV system and up to one group of units for 6kV system.

Unit bypass includes three types: manual bypass, common automatic bypass, and neutral point drifting automatic bypass. For details, you can set the bypass mode through P13.10, and see whether each unit is in bypass state through P13.11.

Function code	Name	Description	Setting range	Default
P13.10	Unit bypass function	0: Manual bypass 1: Common automatic bypass 2: Neutral point drifting automatic bypass	0–2	0
P13.11	Unit manual bypass setting	0x000-0x1FF	0x000-0x1FF	VFD voltage depended

Manual bypass: The units can be bypassed during running or standby. In the application, select the units to be bypassed according to the actual situation, and bypasses three units in a group simultaneously. For example, manually bypass three units (A6-B6-C6), as shown in Figure 7-11.





Common automatic bypass: When one fault occurs to a unit, the system can automatically bypass the faulty unit, but it will bypass the non-faulty units in the same group simultaneously. If a unit fault occurs to A1 unit

during running, which is not caused by communication, the VFD will automatically bypass three units A1-B1-C1, and the system still runs normally, as shown in Figure 7-12.



Figure 7-12 Common automatic bypass

Neutral point drifting automatic bypass: When some faults occurs to a unit, the system can automatically bypass the faulty unit. If a unit fault occurs to C2 unit during running, which is not caused by communication, the VFD will automatically bypass C2 unit, and the system still runs normally, as shown in Figure 7-13.



Figure 7-13 Neutral point drifting automatic bypass

Bypass unit recovery: When a unit of the VFD system is in the unit bypass state described in the above three cases, the unit can be restored to its normal state after the unit is repaired and tested to be fault-free. The recovery method is to first modify the bypass mode to manual bypass (when the modification is finished, three units in a group will be bypassed, and the state is similar to Figure 7-11), and click the bypass and non-bypass button to switch. Three units in the corresponding group can be automatically restored to the normal state. The intermediate operations will not affect the running of the VFD.

# 8 Alarm and fault solution

Goodrive5000 medium voltage variable-frequency speed regulation system provides various functions of fault protection and alarm. If any fault occurs to the system, it can indicate fault state and implement stop protection, power unit bypass, alarm, cutting off medium voltage input automatically according to alarm levels. Due to fault instructions on the touch screen and general fault solutions, in the guidance of alarm interface, users can make a quick judgment and work out appropriate solutions.

Goodrive5000 medium voltage variable-frequency speed regulation system has two types of faults, unit fault and system fault. The system faults are ARM fault and DSP fault. Users can view fault type and fault location on fault history sub-interface of the main interface on the touch screen.

For fault unit Xn, X (A/B/C) indicates the phase of fault unit and n (1–12) indicates the location of fault unit.

Goodrive5000 medium voltage variable-frequency speed regulation system also provides alarm functions. If the fault is not serious enough to cause destructive damage, the system will alarm without stop. During alarm, the system will reset automatically or manually.

Two types of alarms: System alarm and unit alarm. Users can view the types on alarm information menu of the main interface on the touch screen.

Three types of faults:

Serious fault: The fault causes alarm, stop and medium voltage power supply disconnection. The system cannot reset automatically and manual intervention is necessary.

Light fault: The fault causes alarm and stop, but no medium voltage power supply disconnection occurs. Refer to other faults except serious fault.

Alarm: Only alarm without stop. Refer to system alarm and unit alarm.

# 8.1 System fault

## 8.1.1 DSP fault

Fault name	Possible cause	Detection method	Solution
	ACC is too fast.	If the fault disappears by increasing the ACC time, it indicates the ACC time is too short.	Increase ACC time.
	The voltage of the grid is too low.	Check whether input grid voltage is within the input voltage range.	Check the input power.
Software/Hardware overcurrent	The system power is too small.	Check whether the motor power is greater than the rated power of the VFD.	Select the system with larger power.
	Load transient or exception occurred.	Check the load running process data (whether the speed is smooth and the motor vibration exceeds the standard).	Check the load or reduce the sudden change of load.
	The hall sensor is damaged or the	Check whether the wiring of the hall sensor is loose.	Perform the wiring properly.

Fault name	Possible cause	Detection method	Solution
	wiring is abnormal.	The hall sensor is damaged.	Replace the hall.
		Check whether the grounding	Connect the ground wire as
		is normal.	required.
		Check whether the direction	Adjust the direction of the
		of the hall sensor is consistent	hall sensors to be
		with the current direction.	consistent.
		Check whether there are	
		obvious interference sources	
		around the VFD, and use the	Ensure that the VED is
		computer to view the fault	properly grounded and
		data If there is no	that the current detection
	Interference false	abnormality, it can be	cables are configured with
	alarm	considered as interference	magnetic rings.
		false alarm.	Eliminate other
		Check whether an	interference sources.
		overcurrent fault is reported	
		occasionally and runs	
		normally again after reset.	
			Set the torque boost and
			oscillation control factor in
	Parameter setting	Check whether current	V/F control.
	problem	oscillation occurs.	Ensure that parameter
			autotuning is performed in
		Increase the DEC time and	
	DEC is too fast	observe whether overvoltage	Increase the DEC time if
		occurs.	allowed.
	<b>T</b> I I I I I	Check whether the motor	
	I ne load inertia	stops for too long after	Select a VFD with larger
	torque is too large.	coasting to stop of the VFD.	power.
	The system power is	Check whether the motor	Select a VED with larger
	too low.	power is greater than the	power.
		rated power of the VFD.	
		Check whether other devices	
Grid overvoltage	Exception occurred	on the same line are normal	Troubleshoot grid
	to input voltage	transiont surges in the grid	problems.
		voltage	
	<b>-</b>	Check whether the motor is	
		not stopped steadily or	
	Reset the rotating	dragged by external forces to	
	motor after a	rotate when the VFD starts.	Set the speed tracking start
	momentary power	Stop the motor steadily or	method.
	failure.	disconnect from the load to	
		test whether overvoltage	
		occurs.	

Fault name	Possible cause	Detection method	Solution
Grid undervoltage	The voltage of the grid is too low.	Check the actual grid voltage. Check whether there is a display exception of the actually normal VFD. Check whether the power-on buffer of the configuration buffer resistor is closed.	Adjust transformer connectors to meet the input range of the VFD. Adjust voltage calibration coefficient or replace the voltage detection board. Troubleshoot and resolve buffering abnormalities.
	Grid voltage is too low.	Check whether input grid voltage is within the range of -10%–+15% (rated value).	Check the grid voltage.
	The motor rated current is set incorrectly.	Check whether the motor parameters are consistent with the nameplate parameters. Check whether the actual output current of motor is consistent with the displayed current.	Reset the rated current of the motor according to actual parameters of the motor. Adjust the current calibration coefficient or replace the current detection board.
Motor overload	Motor stall or load jumps violently.	Check whether the running direction of the motor is correct. Check whether the motor braking system is open.	Eliminate the stalling. Release the hand brake.
	The motor power is too large.	Check whether the motor power deviates sharply from the rated power of the VFD.	Select a proper motor.
	Torque boost is too large	Check whether the torque boost is set too large in V/F control.	Decrease the torque boost.
	SM demagnetization	If the current was normal before but suddenly becomes larger now, it may be caused by SM demagnetization, and the counter-emf constant needs to be estimated.	Repair the motor.
	ACC is too fast.	If the overload disappears by reducing the ACC time, it indicates that ACC is too fast.	Decrease the ACC time.
System overload	The motor in rotating is restarted.	Check whether the motor is not stopped steadily or dragged by external forces to rotate when the VFD starts. Stop the motor steadily or disconnect from the load to test whether overvoltage occurs.	Set the speed tracking start method.
	Grid voltage is too	Check whether input grid	Check the grid voltage.

Fault name	Possible cause	Detection method	Solution
	low.	voltage is within the range of	
		10%–+15% (rated value).	
		If current is too large in V/F or	Coloct o VED with larger
	Load is too large.	vector control, it indicates	Select a VFD with larger
		that the load is too heavy.	power.
	Phase loss occurred		
	to U, V, W output (or	Charle whether the wiring of	Check the output wiring.
	the three phases of	check whether the winng of	Check the motor and
	motor is	output terminals is tightened.	cables.
Phase loss on	asymmetrical).		
output side		Check the hall U/V/W phase	
		sequence and check whether	The hall cable phase
	Hall or current	the hall wiring is tightened.	sequence corresponds to
	detection exception	Check whether the current	the drive.
		detection board is abnormal.	
	Phase loss occurred	Check the wiring terminals	Check the input power and
	on R, S, and T inputs.	are tightened.	wiring.
Input phase loss		Detect whether unbalance or	
input phase loss	Input power	violent fluctuation occurred	Check the input power and
	fluctuates violently	to inputs R, S, and T through	wiring.
		the upper computer.	
		Check whether the wiring of	
	The signal collection	the signal detection board is	Chack the connector and
	board connector is in poor contact.	tightened.	check the connector and
		Check whether the grounding	re-plug.
		is normal.	
	Auxiliary power		
Current detection	supply is damaged.	Initially check the signal	Poplace the signal
fault	Exception occurred	detection board circuit	dotaction board
lautt	to amplification	detection board circuit.	
	circuit.		
		Check whether the direction	
	Hall components are	of the hall sensor is consistent	Adjust the hall direction.
	broken	with the current direction.	Replace the hall
	broken	Check whether the hall sensor	component.
		is damaged.	
		Check whether the motor	
		power matches the VFD	
	The motor capacity	power.	Select the VFD with proper
	does not match the	Check whether the motor	power.
	system capacity	parameters are consistent	P
Motor autotuning		with the nameplate	
fault		parameters.	
		Check whether the stator	Adjust the motor
	Motor parameter is	resistance, rated voltage and	parameter settings, and
	set improperly	current settings are	perform the autotuning
		equivalent to the actual ones.	again. If a fault is reported
			during autotuning, adjust

Alarm and fault solution

Fault name	Possible cause	Detection method	Solution
			the stator resistance appropriately.
	Autotuning timeout.	Check whether the current detection is normal.	Run the VFD at no load and monitor whether the running current is normal.
Handshake fault	ARM does not work for a short time	Check whether the fault occurs during the program writing, if so, try to reset. If the fault can be reset, it will be normal, otherwise, it is necessary to rewrite the program. If a fault is reported during running, you may need to replace the main board.	Replace the control board.
	The system capacity is too small.	Check whether the motor power is consistent the VFD power.	Replace with a system of a larger capacity.
Input overcurrent	The input current detection cable suffers from interferences	Check whether to re-run without fault, if the fault does not appear during running, it can be considered as the interference.	Update the input current detection cables, and conduct a proper grounding of the shield layer.
	Medium voltage winding short circuit in the system	Stop the machine, and check whether there is a short circuit in the transformer winding.	Repair the transformer.
	The power cables of the voltage detection transmission board are not connected properly.	Check the wiring of the transmission board.	Re-plug.
Voltage detection transmission fault	The uplink and downlink optical fibers of the voltage detection transmission board are not connected properly/The optical fiber bending angle of the voltage detection transmission board fiber is too large	Check whether the voltage detection optical fiber is intact.	Replace the optical fiber.

## 8.1.2 ARM fault

Fault name	Possible cause	Detection method	Solution
	The load of the		Check whether the external
	transformer is too		signal circuit and its cable
	high.		shield are properly
	Ambient temperature		grounded.
	is too high.	Detect the embient	Check the load of
The phase	Temperature	Detect the ambient	transformer and ambient
shifting	controller fault	Charle whather the	temperature, and compare
transformer	Transformer cooling	tomporature data in the instant	them with rated values
trips.	circuit fault	information interface is	(make records).
	The protection circuit	displayed correctly	Check whether installation
	suffers from	Check whether the fan	conditions meet
	interferences	operates normally	requirements (whether it is
		Check whether the shield of the	exposed to sunlight and
		control cable is grounded	whether air circulation is
	The shield of the	properly	good)
Phase-shifting	control cable is	property.	Check whether the shield of
transformer	grounded		the control cable is grounded
overheating	improperly.		properly.
0			Check the temperature
			controller and its circuits.
		View the fault records to	Check input signals of
	External fault input terminal action	compare the user input terminal configuration with the user fault input terminal state	external device.
External fault			Check P05 group Input
			terminal functions.
		at the fault moment.	
	Incorrect baud rate	Check the wiring and serial	Set a proper baud rate.
	Serial	communication settings, read	Reset.
	communication error	and write any function code to	
Modbus		see whether any data is	
communication	Long period of	returned.	
fault	communication	Check whether the data on the	Check the wiring of
	interruption	bus are correct through the	communication interfaces.
		serial port monitoring	
		assistant.	
		I ne feedback signal of the	
		buffer cabinet is "0" after the	
		medium voltage power off, and	
	The contactor	the feedback signal of the	Check the contactor
	feedback is incorrect.	buffer cabinet is "1" after the	feedback.
Buffer cabinet		medium voltage power on. A	
fault		fault is reported when the	
		reedback signal does not	
	<b>T</b> L.	match.	
	The vacuum	Check whether the contactor	
	contactor or contact	can be closed / disconnected	Repair the contactor.
I	is damaged.	properly.	

Fault name	Possible cause	Detection method	Solution
	PID feedback		Check PID feedback signal
PID feedback	disconnection	Check PID reference source and	wires.
offline fault	PID feedback source	feedback source.	Charly DID foodbook courses
	disappears.		Check PID leedback source.
		Check whether each cabinet	Check the cabinet door
	The cabinet door is	door (control cabinet door is	closing state - Check the
	not properly closed	not affected) is in the closed	cabinet door travel switch
		state.	and its contacts.
		In the door opening state, press	Check the cabinet door
Door access	Cabinet door travel	the travel switch to see	closing state - Check the
fault	switch fault	whether the fault is eliminated	cabinet door travel switch
		whether the ladit is ethillated.	and its contacts.
	The shield of the		Check the cabinet door
	control cable is	/	closing state - Check the
	grounded	/	cabinet door travel switch
	improperly.		and its contacts.
	During synchronous		
	switching, the system		
	and the grid is not		
	synchronous at	Monitor whether the input	Ensure that the system runs
Svnchronous	running frequency, or	voltage fluctuates, causing	to the synchronous
switchover	the system output	phase locking failure, and	frequency of the grid before
timeout	voltage deviates	monitor whether the phases of	synchronous switching.
	sharply from grid	input and output voltages are	Adjust the phase locking
	input voltage , or the	consistent.	parameter setting.
	phase locking		
	parameters are set		
	improperly.		
	During the		
	synchronous	User output terminals are	
	switching process,	configured with 79: Switching	
Synchronous	the contactor	cabinet KM4 feedback signal.	Check the contactor
switchover	corresponding to the	Monitor whether KM4 acts	feedback.
serious fault	reactor does not	correctly during the	
	execute the	synchronous switching	
	correctly	process.	
	Poach the running		
Factory time	time set by the	1	Ask for manufacturer
reached	manufacturer	/	support.
	Ambient temperature		I ower the ambient
Motor	is too high		temperature
temperature is		Check the motor state and	Check the load or replace
too high	Motor overload for a	ambient temperature.	with a motor with greater
	long time		power.
Switching	The optical fiber		
cabinet	connector is	Detect the optical path.	Re-connect the connector.
communication	loosened.		

Fault name	Possible cause	Detection method	Solution
fault	The optical fiber is damaged.		Replace the optical fiber.
	Switching cabinet control board fault	Check whether there is light emitted normally from both ends TX of the optical fiber, if not, the hardware needs to be replaced.	Replace the control board.
The capacity of the SD card is insufficient.	The SD card saves too much data.	Take out of the SD card to check the remaining capacity.	Format the SD card after backing up its data.
DSP and ARM handshake fault	DSP does not work in a short time, and the software version does not match	Check whether the DSP and ARM software versions are matched (The matching principle is V.X.YY.ZZ, where ARM and DSP software YY must be consistent).	Replace the control board.
Power off in	The transient electric dazzling time of the grid during running is too long	Check whether there is electric	Check the grid power distribution.
running	The transient power-off time of the system is set too small.	box.	Increase the transient power-off time properly.
PROFILIUS	The PROFIBUS communication card is connected improperly.	Check whether the communication card is connected properly.	Re-connect the PROFIBUS communication card.
communication fault (fieldbus	The PROFIBUS communication card is damaged	Check the VFD communication parameter setting. Check the working state of the	Replace the PROFIBUS communication card.
fault)	Communication address setting error	communication card, and ensure the PLC configuration is	Reset the parameters.
	The interference is too large.	correct.	Remove the interference.
Reference	The wiring of the reference frequency sources is loosened.	Check whether the reference	Check the wiring.
frequency disconnection	Reference frequency sources disappear	correctly.	Check the reference frequency sources.
detection fault	The vacuum contactor or contact is damaged.	frequency sources disappear.	Replace the contactor.
	The state feedback of	Observe whether the switching	Check whether the wiring of
Switching	the vacuum	cabinet action corresponds	the switch state feedback is
cabinet action	contactor or isolation	correctly to the feedback signal	correct and whether the
fault	Switch is incorrect.	in commissioning mode.	contacts are in poor contact. Change the wiring to a spare

Fault name	Possible cause	Detection method	Solution
	contactor or isolation		contact that is not damaged,
	switch is damaged.		or replace the contactor or
			isolation switch.
		Check the software version of	
		each chip in P07 group.	
The software	The program of the	Check whether the DSP and	
version does	three chips of the	ARM software versions are	Replace the main control
not match	main control board	matched (The matching	board.
	does not match	principle is V.X.YY.ZZ, where	
		ARM and DSP software X.YY	
		must be consistent).	
	Ambient temperature	Check the ambient	Lower the ambient
_	is too high.	temperature.	temperature.
Fan	The fan temperature	Check the fan temperature sensor.	Check whether the fan
overheating	sensor at the top of		temperature sensor is
	the cabinet is		damaged.
	damaged.		
Master/slave	The optical fiber	For one machine, screen out this fault through the function codes.	Re-connect the connector.
optical-fiber	connector is		
communication	loosened		
fault	The optical fiber is		Replace the optical fiber.
	damaged.		
	The load drops	Check the load conditions.	Check the load conditions.
Underload fault	during constant	Check the unit state.	Check the unit state.
	speed running		
Caral	The reference		Check whether current-limit
Speed	frequency is	Check the actual running	frequency drop or
deviation fault	inconsistent with the	frequency.	overvoltage stall occurs.
	running frequency.		
Temperature	The wiring of 485	Connect the serial tooling to	Courses the continue of
controller		the RS485 bus interface to	Correct the wiring of
communication	interface is wrong.	judge whether there is normal	communication interfaces.
1	Cuffor from	Judge miletiter there is normat	Domovo the interforence

# 8.2 Unit fault

Fault name	Possible cause	Detection method	Solution
	The optical fiber	Stop and power off to check	
	connector is	whether the optical fiber	Re-connect the connector.
Unit	loosened.	connector is loosened.	
optical-fiber		Check whether the optical fiber	
uplink	The optical fiber is	connector shows light and	Deplese the entired fiber
communication	damaged.	whether the brightness is	Replace the optical liber.
fault		abnormal.	
		Disassemble the unit and test	Chaolythaunit
	Unit fault	whether the power supply of	Check the unit.

Fault name	Possible cause	<b>Detection method</b>	Solution			
		the unit control board is				
		normal.				
11	The optical fiber	Stop and power off to check	De connect the connector			
Unit optical fibor	connector is	whether the optical fiber	Re-connect the connector.			
downlink	tooseneu.	Connector is toosened.				
communication	The optical fiber is	connector shows light and				
fault	damaged.	whether the brightness is	Replace the optical fiber.			
	0	abnormal.				
Unit not roady	Unit control board	The fault cannot be reset, and	Repair the unit, and replace			
onit not ready	fault	the fault is reported frequently.	the unit control board.			
		Check whether the DEC time is				
	The load inertia is	too short. If the fault				
	large, and DEC is fast	disappears by reducing the	Increase the DEC time.			
		DEC time, it indicates that the				
			Adjust the oscillation factor			
		<b>a</b> l 1.1 11.1	In V/F control.			
	Current oscillation	Observe whether oscillation	Check whether the motor			
		occurs to output UVW current	parameters are correct, and perform parameter			
		tillough workshop.				
			autotuning.			
Unit			Check whether the unit bus			
overvoltage		Observe whether the grid	voltage is too high through			
	The grid voltage is	voltage is too high through the	Check whether the ACC/DEC			
	too high	touch screen or workshop, and	time is too short. causing the			
	0	check whether there is a grid	rising of unit voltage.			
		overvoltage alarm.	Adjust the output of the			
			phase-shifting transformer.			
		The fault cannot be reset, and				
		the fault is reported				
	Unit fault	Trequently.	Repair the unit.			
		whether the circuit and the				
		IGBT module are abnormal.				
		Observe whether input voltage				
	The grid input voltage	is low through the touch				
	is too low	screen, or observe the	Check the grid voltage.			
Unit	13 100 100	real-time voltage value through				
undervoltage		the upper computer.				
		Check the input of the faulty	Data at the sure it is not			
	Unit input exception	unit, and check the rectifier Detect the unit input.				
		Measure the actual				
Unit	Ambient temperature	temperature through the	Lower the ambient			
overheating	is too high.	temperature tester.				
	The cooling duct of	Check whether there is dust	Optimize the air duct.			

Fault name	Possible cause	Detection method	Solution			
	the unit is blocked	accumulation in the air duct.				
	Poor cabinet tightness and cooling condition	Visually inspect the dust condition of the dust filter.	Clean the dust filter.			
	The wiring of unit input terminals is wrong	Check the wiring of input terminals according to the electrical diagram.	Perform the correct wiring.			
Unit input phase loss	The shifting-transformer is faulty.	Check whether there are obvious damage signs of the transformer through visual inspection, and check the transformer impedance with a megameter.	Check the phase-shifting transformer			
	Unit fuse burn-out	Stop and power off, and check whether the unit fuse is burned out through visual inspection or a multimeter.	Repair the unit.			
Unit input	The wiring of unit input terminals is wrong	Check the wiring of input terminals according to the electrical diagram.	Check the wiring and perform the input wiring properly.			
power off	Unit fault	The fault cannot be reset, and the fault is reported frequently.	Ask for technical support.			
	Unit output short circuit	Check whether there is short circuit in output cables.	Ask for technical support.			
ACI fault	H bridge direct	The fault cannot be reset, and the fault is reported frequently.	Ask for technical support.			
	Unit drive fault	The fault cannot be reset, and the fault is reported frequently.	Ask for technical support.			
	Unit output short circuit	Check whether there is short circuit on output end of the VFD.	Check whether there is short circuit on output end of the VFD.			
ACO fault	H bridge direct connection	The fault cannot be reset, and the fault is reported frequently.	Ask for technical support.			
	Unit drive fault	The fault cannot be reset, and the fault is reported frequently.	Ask for technical support.			
	The load inertia is large, and DEC is fast	Check whether the motor DEC time is too short.	Change the motor DEC time.			
Hardware overvoltage	Current oscillation	Observe whether output current fluctuates greatly.	Adjust the oscillation factor In V/F control. Check whether the motor parameters are correct, and perform parameter autotuning in vector control			
	The grid voltage is too high	Observe whether the grid voltage is too high through the touch screen or workshop.	Adjust the output of the secondary side of the transformer.			
	Unit fault	Check whether the fault cannot be reset, and the fault is	Repair the unit.			

Fault name	Possible cause	Detection method	Solution		
		reported frequently.			
The unit does not match	The valid units configured by the manufacturer are not consistent with the actual valid units	Check whether the factory parameter unit configuration corresponds to the actual unit fiber connection.	Check the unit configuration.		
	Bypass relay fault	Check the bypass relay.	Replace the bypass relay.		
Unit bypass	The wiring of the bypass relay is wrong	Check the wiring of the bypass relay.	Check the wiring of the bypass relay.		
failure	A VCE fault occurs to the unit	Check whether the unit fault code for the bypass failure unit is VCE.	Repair the unit.		
	The internal IGBT is damaged	Check whether the unit IGBT is damaged.	Replace the IGBT module.		
Rectifier unit R/S/ T-phase VCE	Strong interference	Check whether the fault can be reset and whether it is an accidental fault.	Check the surroundings to rule out interference source.		
	External short circuit	Check the external circuit and eliminate the load fault.			
	The unit IGBT is damaged	Check whether the unit IGBT is damaged.			
Hardware overcurrent	ACC time of the inverter is short	If the fault disappears by reducing the ACC time, it indicates that the ACC time is too short.	Increase the ACC/DEC time.		
	Short circuit occurs on the output side of the unit	Detect whether short circuit occurs on the output side of the unit	Check the external circuit of the unit, and eliminate the short circuit fault.		
Grid-side current	The unit current detection components are damaged	Check whether the unit current detection circuit is abnormal. Check whether the current detection wiring is abnormal.	Check the wiring and the circuit boards.		
detection fault	Interference	Check whether there is interference.	Check the surroundings to rule out interference source.		
Zero calculation fault	The unit input voltage detection components are damaged	Check whether the voltage detection is abnormal.	Replace the hardware.		
iautt	Interference	Check whether there is interference.	Check the surroundings to rule out interference source.		

# 8.3 Action after fault

After a fault occurs to the system, it will latch and display fault information. At the same time, alarm begins.

For system fault, the system will coast to stop immediately. For serious system fault, such as the temperature of phase-shifting transformer over 110°C, the system will cut off medium voltage along with coast to stop.

For unit fault, use bypass fault unit according to requirements for derating without processing unit fault. If you check fault unit, stop the system and cut off medium voltage. Bypass fault unit is only used to deal with one fault unit. If several units encounter a fault and fault units are not in bypass, the system reports the fault and cuts off medium voltage.

The system will latch fault all the time and it will not restore to the normal state until users removes the fault and push the fault reset button.



- Do not reset and re-run the system if the fault reason is uncertain. Deal with the fault after confirming its level and reason.
- The system is complicated electronics converter equipment. Inspection or repair must be carried out under the instruction of manufacture engineers.
- Make sure the power supply is disconnected and the filter capacitor of the main circuit discharges completely before conducting system maintenance.

# 8.4 Action after alarm

## 8.4.1 Introduction of system alarm

Alarm code	Name	Possible cause	Solution			
1	Grid overvoltage	The grid voltage is too high.	Make sure the grid voltage within -15%– +10% of rated voltage.			
2	Transformer overheating	The load of the transformer is too high. Ambient temperature is too high; Temperature controller fault. Transformer cooling circuit fault. The protection circuit line suffers from interferences. The shield of the control cable is grounded improperly.	Check whether the external signal circuit and its cable shield are properly grounded. Check the load of transformer and ambient temperature, and compare them with rated values (make records). Check whether installation conditions meet requirements (whether it is exposed to sunlight and whether air circulation is good) Check whether the shield of the control cable is grounded properly. Check the temperature controller and its circuits.			
3	Control power 1 off	The main control power supply is off or connected improperly. The main control power switch of the control cabinet is not turned on. A fault occurred to the feedback relay of the control cabinet main control power supply.	Check the main control power supply system to ensure that it is powered and the wiring is proper. Check and ensure that the main control power switch is turned on. Check whether the feedback relay works properly, if not, replace it. Ask for technical support.			

Alarm code	Name	Possible cause	Solution
4	Control power 2 off	The backup control power supply is off or connected improperly. The backup control power switch of the control cabinet is not turned on. A fault occurred to the feedback relay of the control cabinet backup control power supply.	Check the backup control power supply system to ensure that it is powered and the wiring is proper. Check and ensure that the backup control power switch is turned on. Check whether the feedback relay works properly, if not, replace it. Ask for technical support.
5	Fan power off	The power supply for fan is off. The fan power switch of the control cabinet is not turned on. A fault occurred to the feedback of the control cabinet fan power supply.	Check whether the 380V fan power is turned on. Check and ensure that the fan power switch is turned on. Check whether the fan feedback works properly, if not, replace the fan running contactor.
6	UPS off	The UPS is not connected or has been damaged.	Check whether UPS can work properly.

## 8.4.2 Introduction of unit alarm

Unit	Name	Possible cause	Solution
1–36	Unit overheating	Fan fault. Poor cabinet tightness and cooling condition. Heavy load and large current.	Ask for technical support. Clean the dust filter. Select the system with larger power.
1–36	Optical-fiber communication alarm	The optical-fiber communication alarm triggering value is set improperly.	Set P13.14 properly.

1–36 indicates the number of alarm units. 1–12 is the number of A-phase units, 13–24 is the number of B-phase units and 25–36 is the number of C-phase units. After the system alarms, it will prompt and not affect working. However, users should pay attention to the alarm; otherwise, long time alarm may change into fault and result in system stop.

# 8.5 Common faults and solutions

The system may encounter the following faults during running. Please refer to the following solutions:

Ready indicator is not on:

- 1. Check whether input voltage exists through the touch screen. The ready indicator is on only when there is medium voltage.
- 2. Check whether the corresponding unit has voltage through the unit interface on the touch screen, if not, check the wiring between the phase-shifting transformer and the unit after power-off.

3. If the unit has voltage, but the ready indicator is still not on, please check whether the effective unit of the system is consistent with the unit which has voltage.

The system reports the overvoltage fault during decelerating:

- 1. Check whether the input voltage is too high.
- 2. Increase DEC time.

# **9** Routine maintenance

To ensure the system operates continuously and reliably for a long period of time, the system should be inspected daily and periodically. This chapter introduces the precautions of inspecting or maintaining the system.

## 9.1 Routine inspection

- 1. Check the room temperature and ventilation, and note that the room temperature should not exceed 40 °C.
- 2. Keep the room for the system clean.
- 3. Check whether the cooling fan is running normally (use an A4 paper placed in the cabinet air inlet, and the A4 paper shall be firmly absorbed by the filter screen).
- 4. Check whether the variable-frequency speed regulation system has abnormal sound and odor, whether the cabinet is hot, and whether the dry-type transformer three-phase temperature display is normal.
- 5. Check whether the variable-frequency speed regulation system control power supply and fan power supply air switches are closed and whether the UPS power switch at the bottom is turned on.
- 6. Record the variable-frequency speed regulation system running status (such as run mode, voltage, current, speed, and power) regularly, and record fault information upon a tripping fault and then identify the fault cause before re-power on.
- 7. Check whether the unit status, displayed temperature, and bus voltage are normal.
- 8. Check whether the bypass cabinet knife switch is in place and whether there is any abnormal vibration and sound in the medium voltage contactor.

## 9.2 Routine maintenance procedure

- Step 1 After the shutdown of the system, cut off the main power supply of the medium voltage switching cabinet and close the grounding knife switch.
- Step 2 Cut off the control power and UPS of the system.
- Step 3 Wait at least 15 minutes before opening the cabinet door, and ensure the discharge status of the power unit before starting to work; otherwise, there is a risk of electric shock.
- Step 4 If there is a lot of dust, dust filters should be cleaned once a week and the cabinet inside should be vacuumed.
- Step 5 Within the first month of putting the variable-frequency speed regulation system into operation, fasten all incoming and outgoing cables, all connection cables and the terminal blocks of control part. In the future, fasten them (including the control cables) once every six months.
- Step 6 Check whether the optical fiber plug of each power unit is loose.
- Step 7 Ensure that no tools or foreign objects are left in the cabinets and every electrical cabinet door is closed.
- Step 8 Perform the power-on running on the spare units periodically (typically 6 months) to ensure that the optical fiber holder plugs of the spare units are inserted properly to prevent the pollution.
- Step 9 Re-power on and record the maintenance records of the variable-frequency speed regulation system.

#### Attachment:

ltem	Content	Method/Criterion
Ambient environment	Check the temperature, and humidity, and whether there is vibration, dust, gas, oil spray, and water droplets in the environment. Check whether there are foreign matters, such as tools, or dangerous substances placed nearby.	Visual inspection or instruments, or appearance observation Compliant with technical specifications No such placing
Touch screen	Check whether the touch screen display is clear.	Visual inspection: The display is clear.
Structure	Check for abnormal vibration or sound. Check for loose fasteners such as screws. Check for deformation damage or collision marks. Check for dust, stains, or rust.	Visual inspection. No exception occurs.
Cooling fan	Check for abnormal vibration or sound.	Visual and auditory inspection. No exception occurs.
Ventilation duct	Check whether there are blockages or foreign objects attached. Observe whether the temperature displayed by the unit varies greatly with the previous temperature.	Visual inspection. No exception occurs.
Phase shifting transformer	Check whether there is abnormal temperature rise. Check whether there is abnormal sound.	Visual and auditory inspection, or appearance observation
Medium-voltage contactor	Check for abnormal vibration or sound.	Visual and auditory inspection. No exception occurs.

Table 9-2 System maintenance list

					Cycle						
Che	Check	Check	Charle item		Periodically		Mathad		Used	Demerilee	
NO.	scope	category	Check item	Daily	1	2	3	Μετποά	Criterion	ment	Remarks
1		Ambient environm ent	Ambient temperature, humidity, and dust	√	year	years	years	Observation	Ambient temperature: -5– 40°C, no freezing. RH: Below 90%, no condensation	Thermo meter and hygrom eter	
2	All	Entire system	Check for abnormal vibration or sound.	√				Visual and auditory inspection	No exception		
3		Main power voltage	Check whether the voltage is normal.	~				Check the input voltage displayed on the interface.	-15%–+10% of the rated voltage		

## Goodrive5000 series medium voltage variable-frequency speed regulation system

Routine maintenance

		Cycle									
	Check	Check	Check item		Pe	eriodica	ally		Criterion	Used instru	
No.	scope	category		Daily	1	2	3	Method			Remarks
					year	years	years			ment	
4		Control power voltage	Check whether the voltage is normal.	✓				Check the input voltage of the control part.	AC380V ± 10%	Multim eter	
5		HMI	Check whether display is normal and operations are correct.	V				Observation	Displayed data is in the normal range and operations are performed properly.		
6		Dust filter	Check for blockages and check whether there is much dust.	✓				Observation	Check the airflow of each air inlet with a piece of A4 size paper. The paper should be able to be firmly absorbed by the filter screeen, and there should be no obvious dust from the appearance.		
7	Main circuit	All	<ol> <li>Insulation         resistance check         (phase shifting         transformer         insulation)         2. Check fastened         parts for any         loose         phenomenon.         3. Check         components or         parts for         overheating.         4. Clean         4. Clean         Output         Output         Check         Components         Compo</li></ol>		✓ ✓ ✓	✓ ✓ ✓	✓ ✓ ✓	1. The resistance of the phase shifting transformer coil insulation to ground should be within the normal range. 2. Check and fasten. 3. Observe	1. Greater than 20MΩ 2–3. No exception.	DC 2500V insulati on resistan ce meter	
8		Connecti on conducto rs and wires	<ol> <li>Check whether conductors are tilted.</li> <li>Check whether the lead wire insulation layers are broken or</li> </ol>		✓ ✓	√ √	√ √	ය. Observe.	No exception occurs.		

## Goodrive5000 series medium voltage variable-frequency speed regulation system

Routine maintenance

					C	ycle						
No	Check	Check	Chackitam		Pe	eriodica	ally	Method	Mothod	Critorion	Used	Bomarks
NO.	scope	category		Daily	1	2	3		Criterion	ment	Remarks	
9		Terminal block	Check whether terminal blocks		year √	years √	years √	Observation	No exception occurs.			
			1. Check the filter capacitors for liquid leakage.	~	~	✓	~	1–2. Observe. 3. Use a	1–2. No exception.	Capacit		
10		Filter capacitor	2. Check for swelling. 3. Check static	~	✓	√	✓	capacitance meter for measurement	3. More than 85% of the rated capacity.	ance meter		
			capacitance.				✓	•				
11		Relay	<ol> <li>Check whether abnormal sounds such as "Boing, boing".</li> </ol>		√	~	~	1. Listen.	No exception			
			2. Check whether contacts are rough or broken.		✓	√	~	z. Observe.				
	Control		1. Check whether the output voltage between each phase is balanced during running of the variable-frequenc y speed regulation system.		✓			1. Measure the phase-to-pha se voltages of the U, V and W output terminals of the variable-freq uency speed	<ol> <li>The phase-to-phase voltage error should be within 10V.</li> <li>The medium voltage switch can be closed only after the signal of allowing</li> </ol>			
12	Protect ion circuit	Action check	2. Check whether the interlock between the system and its higher level medium voltage switch is normal and whether the protection circuit is normal.		~			regulation system. 2. Turn the higher level medium voltage switch of the system to the simulated running position for the relevant	signal of allowing closing is given from the variable-frequenc y speed regulation system; after the emergency button is pressed, the medium voltage switch should be opened at once	Multim eter		
13	Cooling system	Cooling air fan	1. Check for abnormal vibration or sound.	V				1. Rotate by hand at power off. 2. Check and	1. Perform smooth rotation. 2. No exception			

Routine maintenance

					C	ycle				Lined	
No	Check	Check	Check item		Pe	eriodica	ally	Mothod	Critorion	Used	Bomarks
NO.	scope	category		Daily	1	2	3	Method	citterion	ment	Remarks
					year	years	years			ment	
			2. Check					fasten.			
			connection parts		5	5	1				
			for any loose		v	v	v				
			phenomenon.								
			1. Check whether					1. None			
			the HMI display is	$\checkmark$				2. Clean with			
			normal.					shredded			Ensure
14		Display						cotton yarn			normal
					,			but not			display.
			z. ciedii		v			organic			
								solvents.			
								Check			
	<b>D</b> <sup>1</sup>							whether			
	Display	/ Indicatio n	Check whether					indicator	Design		
15			indicators are	$\checkmark$				turning-on	requirements are		
			properly on.					meets	met.		
								requirements			
								•			
								Check the			
10		Instrume	Check whether	,				indication	<b>-</b>		
16		nt	the indication	indication 🗸				value of the	l he rating is met.		
			value is normal.					instrument.			
			1. Check for					1. Visual and			
			abnormal	,				auditory			
			vibration or	V				inspection,			
17			sound.					and feel.	No exception		
17		All						2. Odor	occurs.		
			2. Check for	,				caused due to			
			odors.	V				overheating			
	Motor							or damage.			
										DC	
			спеск (аш					Remove the		2500V	
			terminals and					U, V, and W	,	insula	
18		insulation	grounding		$\checkmark$			connection	Above 5MΩ	tion	
		resistance	terminals) with					cables and		resist	
			an insulation					motor cables.		ance	
			resistance meter.							meter	

# **10 Modbus communication protocol**

The VFD provides RS485 communication interfaces and adopts the master-slave communication based on the international standard Modbus communication protocol. You can implement centralized control (setting commands for controlling the VFD, modifying the running frequency and related function code parameters, and monitoring the working state and fault information of the VFD) through PC/PLC, upper control computer, or other devices to meet specific application requirements.

## **10.1 Modbus protocol introduction**

Modbus is a communication protocol for use with electronic controllers. By using this protocol, a controller can communicate with other devices through transmission lines. It is a general industrial standard. With this standard, control devices produced by different manufacturers can be connected to form an industrial network and be monitored in a centralized way.

The Modbus protocol provides two transmission modes, namely American Standard Code for Information Interchange (ASCII) and remote terminal units (RTU). On one Modbus network, all the device transmission modes, baud rates, data bits, check bits, end bits, and other basic parameters must be set consistently.

A Modbus network is a control network with one master and multiple slaves, that is, on one Modbus network, there is only one device serving as the master, and other devices are the slaves. The master can communicate with any single slave or with all slaves. For separate access commands, a slave needs to return a response. For broadcasted information, slaves do not need to return responses.

# **10.2 Application of Modbus**

The VFD uses the Modbus RTU mode and communicates through RS485 interfaces.

#### 10.2.1 RS485

RS485 interfaces work in half-duplex mode and transmit data signals in the differential transmission way, which is also referred to as balanced transmission. An RS485 interface uses a twisted pair, where one wire is defined as A (+), and the other B (-). Generally, if the positive electrical level between the transmission drives A and B ranges from +2V to +6V, the logic is "1"; and if it ranges from -2V to -6V, the logic is "0".

The 485+ terminal on the terminal block of the VFD corresponds to A, and 485- corresponds to B.

The communication baud rate (P16.01) indicates the number of bits sent in a second, and the unit is bit/s (bps). A higher baud rate indicates faster transmission and poorer anti-interference capability. When a twisted pair of 0.56mm (24 AWG) is used, the maximum transmission distance varies according to the baud rate, as described in the following table.

Baud rate	Max. transmission distance	Baud rate	Max. transmission distance	
2400bps	1800m	9600bps	800m	
4800bps	1200m	19200bps	600m	

In long-distance RS485 communication, it is recommended that you use shielded cables, and use the shielding layer as the ground wire.

When there are fewer devices and the transmission distance is short, the whole network works well without terminal load resistors. The performance, however, degrades as the distance increases. Therefore, it is recommended that you use a 120  $\Omega$  terminal resistor when the transmission distance is long.

#### 10.2.1.1 Application to one VFD

Figure 10-1 Modbus on-site wiring diagram for the network with one VFD and PC. Generally, PCs do not provide RS485 interfaces, so you need to convert an RS232 or USB interface of a PC to an RS485 interface through an adapter. Connect end A of the RS485 interface to the 485+ port on the terminal block of the VFD, and connect end B to the 485- port. It is recommended that you use shielded twisted pairs. When an RS232-RS485 converter is used, the cable used to connect the RS232 interface of the PC and the converter cannot be longer than 15 m. Use a short cable when possible. It is recommended that you insert the converter directly into the PC. Similarly, when a USB-RS485 converter is used, use a short cable when possible.

After wiring, select the correct port (such as COM1 to connect the RS232-RS485 converter) on the upper computer, and set the basic parameters such as baud rate and data bit check consistent with those of the VFD.



Figure 10-1 Wiring of one RS485 VFD application

#### 10.2.1.2 Application to multiple VFDs

In practical application to multiple VFDs, chrysanthemum connection and star connection are commonly used.

According to the requirements of the RS485 industrial bus standards, all the devices need to be connected in chrysanthemum mode with one 120  $\Omega$  terminal resistor on each end, as shown in Figure 10-2. Figure 10-3 is simplified connection diagram, and Figure 10-4 is the practical application diagram.

Figure 10-2 Onsite chrysanthemum connection diagram



Figure 10-3 Simplified chrysanthemum connection diagram





Figure 10-5 shows the star connection diagram. When this connection mode is adopted, the two devices that are farthest away from each other on the line must be connected with a terminal resistor (the two devices are devices #1 and #15).



Use shielded cables, if possible, in multi-device connection. The baud rates, data bit check settings, and other basic parameters of all the devices on the RS485 line must be set consistently, and addresses cannot be repeated.

#### 10.2.2 RTU mode

#### 10.2.2.1 RTU communication frame structure

When a controller is set to use the RTU communication mode on a Modbus network, every byte (8 bits) in the message includes 2 hexadecimal characters (each includes 4 bits). Compared with the ASCII mode, the RTU mode can transmit more data with the same baud rate.

#### Code system

- 1 start bit.
- 7 or 8 data bits; the minimum valid bit is transmitted first. Each frame domain of 8 bits includes 2 hexadecimal characters (0–9, A–F).
- 1 odd/even check bit; this bit is not provided if no check is needed.
- 1 stop bit (with check performed), 2 bits (without check).

#### **Error detection domain**

• Cyclic redundancy check (CRC)

The following table describes the data format.

11-bit character frame (Bits 1 to 8 are data bits)

Modbus communication protocol

Start bit	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6	Bit7	Bit8	Check bit	Stop bit
10-bit character frame (Bits 1 to 7 are data bits)										
Start bit	Bit1	Bit2	Bit3	Bi	t4	Bit5	Bit6	Bit7	Check bit	Stop bit

In a character frame, only the data bits carry information. The start bit, check bit, and stop bit are used to facilitate the transmission of the data bits to the destination device. In practical applications, you must set the data bits, parity check bits, and stop bits consistently.

In RTU mode, the transmission of a new frame always starts from an idle time (the transmission time of 3.5 bytes). On a network where the transmission rate is calculated based on the baud rate, the transmission time of 3.5 bytes can be easily obtained. After the idle time ends, the data domains are transmitted in the following sequence: slave address, operation command code, data, and CRC check character. Each byte transmitted in each domain includes 2 hexadecimal characters (0–9, A–F). The network devices always monitor the communication bus. After receiving the first domain (address information), each network device identifies the byte. After the last byte is transmitted, a similar transmission interval (the transmission time of 3.5 bytes) is used to indicate that the transmission of the frame ends. Then, the transmission of a new frame starts.



The information of a frame must be transmitted in a continuous data flow. If there is an interval greater than the transmission time of 1.5 bytes before the transmission of the entire frame is complete, the receiving device deletes the incomplete information, and mistakes the subsequent byte for the address domain of a new frame. Similarly, if the transmission interval between two frames is shorter than the transmission time of 3.5 bytes, the receiving device mistakes it for the data of the last frame. The CRC check value is incorrect due to the disorder of the frames, and thus a communication fault occurs.

T1-T2-T3-T4 (transmission time of 3.5 bytes)
Communication address: 0–247 (decimal system) (0 is the broadcast
address)
03H: read slave parameters
06H: write slave parameters
Data of $2 \times N$ bytes, main content of the communication as well as the core of data exchanging.
Detection values CDC (1C hite)
Detection value: CRC (10 Dits)
T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)

Standard structure of an RTU frame:

#### 10.2.2.2 RTU communication frame error check modes

During the transmission of data, errors may occur due to various factors. Without check, the data receiving device cannot identify data errors and may make an incorrect response. The incorrect response may cause severe problems. Therefore, the data must be checked.

The check is implemented as follows: The transmitter calculates the to-be-transmitted data based on a

specific algorithm to obtain a result, adds the result to the rear of the message, and transmits them together. After receiving the message, the receiver calculates the data based on the same algorithm to obtain a result, and compares the result with that transmitted by the transmitter. If the results are the same, the message is correct. Otherwise, the message is considered incorrect.

The error check of a frame includes two parts, namely, bit check on individual bytes (that is, odd/even check using the check bit in the character frame), and whole data check (CRC check).

#### Bit check on individual bytes (odd/even check)

You can select the bit check mode as required, or you can choose not to perform the check, which will affect the check bit setting of each byte.

Definition of even check: Before the data is transmitted, an even check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is even, the check bit is set to "0"; and if it is odd, the check bit is set to "1".

Definition of odd check: Before the data is transmitted, an odd check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is odd, the check bit is set to "0"; and if it is even, the check bit is set to "1".

For example, the data bits to be sent are "11001110", including five "1". If the even check is applied, the even check bit is set to "1"; and if the odd check is applied, the odd check bit is set to "0". During the transmission of the data, the odd/even check bit is calculated and placed in the check bit of the frame. The receiving device performs the odd/even check after receiving the data. If it finds that the odd/even parity of the data is inconsistent with the preset information, it determines that a communication error occurs.

#### CRC check mode

A frame in the RTU format includes an error detection domain based on the CRC calculation. The CRC domain checks all the content of the frame. The CRC domain consists of two bytes, including 16 binary bits. It is calculated by the transmitter and added to the frame. The receiver calculates the CRC of the received frame, and compares the result with the value in the received CRC domain. If the two CRC values are not equal to each other, errors occur in the transmission.

During CRC, 0xFFFF is stored first, and then a process is invoked to process a minimum of 6 contiguous bytes in the frame based on the content in the current register. CRC is valid only for the 8-bit data in each character. It is invalid for the start, end, and check bits.

During the generation of the CRC values, the "exclusive or" (XOR) operation is performed on the each 8-bit character and the content in the register. The result is placed in the bits from the least significant bit (LSB) to the most significant bit (MSB), and 0 is placed in the MSB. Then, LSB is detected. If LSB is 1, the XOR operation is performed on the current value in the register and the preset value. If LSB is 0, no operation is performed. This process is repeated for 8 times. After the last bit (8th bit) is detected and processed, the XOR operation is performed on the next 8-bit byte and the current content in the register. The final values in the register are the CRC values obtained after operations are performed on all the bytes in the frame.

The calculation adopts the international standard CRC check rule. You can refer to the related standard CRC algorithm to compile the CRC calculation program as required.

The following example is a simple CRC calculation function for your reference (using the C programming language):

```
unsigned int crc_cal_value(unsigned char*data_value,unsigned char data_length)
```

```
int i;
unsigned int crc_value=0xffff;
while(data_length--)
```

{

```
{
    crc_value^=*data_value++;
    for(i=0;i<8;i++)
    {
        if(crc_value&0x0001)
            crc_value=(crc_value>>1)^0xa001;
        else
            crc_value=crc_value>>1;
        }
    }
    return(crc_value);
}
```

In the ladder logic, CKSM uses the table look-up method to calculate the CRC value according to the content in the frame. The program of this method is simple, and the calculation is fast, but the ROM space occupied is large. Use this program with caution in scenarios where there are space occupation requirements on programs.

## 10.3 RTU command code and communication data

#### 10.3.1 Command code 03H, reading N words (continuously up to 16 words)

The command code 03H is used by the master to read data from the VFD. The count of data to be read depends on the "data count" in the command. A maximum of 16 pieces of data can be read. The addresses of the read parameters must be contiguous. Each piece of data occupies 2 bytes, that is, one word. The command format is presented using the hexadecimal system (a number followed by "H" indicates a hexadecimal value). One hexadecimal value occupies one byte.

The 03H command is used to read information including the parameters and running status of the VFD.

For example, to read two contiguous data content pieces from 0004H from the VFD with the address of 01H (that is, to read content from data addresses 0004H and 0005H), the frame structure is as follows:

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)	
ADDR (address)	01H	
CMD (command code)	03H	
Start address MSB	00H	
Start address LSB	04H	
Data count MSB	00H	
Data count LSB	02H	
CRC LSB	85H	
CRC MSB	САН	
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)	

RTU master command (from the master to the VFD)

The value in START and END is "T1-T2-T3-T4 (transmission time of 3.5 bytes)", indicating that the RS485 needs to stay idle for at least the transmission time of 3.5 bytes. An idle time is required to distinguish on message from another to ensure that the two messages are not regarded as one.

ADDR=01H means the command message is sent to the VFD with the address of 01H and ADDR occupies one byte.

CMD=03H means the command message is sent to read data from the VFD and CMD occupies one byte.

"Start address" means reading data from the address and it occupies two bytes with the MSB on the left and LSB on the right.

"Data count" indicates the count of data to be read (unit: word). "Start address" is "0004H" and "Data count" is 0002H, indicating that data is to be read from the data addresses of 0004H and 0005H.

CRC check occupies two bytes, with the LSB on the left, and MSB on the right.

RTU slave response (from the VFD to the master)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)		
ADDR	01H		
CMD	03H		
Number of bytes	04H		
MSB of data in 0004H	13H		
LSB of data in 0004H	88H		
MSB of data in 0005H	00H		
LSB of data in 0005H	00H		
CRC LSB	7EH		
CRC MSB	9DH		
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)		

The definition of the response information is described as follows:

"ADDR" is "01H", indicating that the message is sent by the VFD whose address is 01H. The ADDR information occupies one byte.

"CMD" is "03H", indicating that the message is a response of the VFD to the 03H command of the master for reading data. The CMD information occupies one byte.

"Number of bytes" indicates the number of bytes between a byte (not included) and the CRC byte (not included). The value "04" indicates that there are four bytes of data between "Number of bytes" and "CRC LSB", that is, "MSB of data in 0004H", "LSB of data in 0004H", "MSB of data in 0005H", and "LSB of data in 0005H".

A piece of data contains two bytes, with the MSB on the left and LSB on the right. From the response, the data in 0004H is 1388H, and that in 0005H is 0000H.

CRC check occupies two bytes, with the LSB on the left, and MSB on the right.

#### 10.3.2 Command code 06H, writing a word

This command is used by the master to write data to the VFD. One command can be used to write only one piece of data. It is used to modify the parameters and running mode of the VFD.

For example, if the master writes 5000 (1388H) to 0004H of the VFD whose address is 02H, the frame structure is as follows.

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)		
ADDR	02H		
CMD	06H		
MSB of data writing address	00H		
LSB of data writing address	04H		
MSB of to-be-written data	13H		
LSB of to-be-written data	88H		
CRC LSB	С5Н		

RTU master command (from the master to the VFD)

Modbus communication protocol

CRC MSB	6EH		
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)		

RTU slave response (from the VFD to the master)

-	
START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR	02H
CMD	06H
MSB of data writing address	00H
LSB of data writing address	04H
MSB of to-be-written data	13H
LSB of to-be-written data	88H
CRC LSB	C5H
CRC MSB	6EH
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)

**Note:** The sections 10.3.1 and 10.3.2 mainly describe the command formats. For the detailed application, see the examples in section 10.4.5.

## 10.3.3 Command code 08H, diagnosis

Sub-function code description:

Sub-function code	Description
0000	Returned data based on query information

For example, to query about the circuit detection information about the VFD whose address is 01H, the query and return strings are the same, and the format is described as follows.

RTU master command:

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)		
ADDR	01H		
CMD	08H		
Sub-function code MSB	00H		
Sub-function code LSB	00H		
MSB of to-be-written data	12H		
LSB of to-be-written data	ABH		
CRC CHK LSB	ADH		
CRC CHK MSB	14H		
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)		

RTU slave response:

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)		
ADDR	01H		
СМD	08H		
Sub-function code MSB	00H		
Sub-function code LSB	00H		
MSB of to-be-written data	12H		
LSB of to-be-written data	ABH		
CRC CHK LSB	ADH		
CRC CHK MSB	14H		
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)		

## 10.4 Data address definition

This section describes the address definition of communication data. The addresses are used for controlling the running, obtaining the state information, and setting related function parameters of the VFD.

## 10.4.1 Function code address format rules

The address of a function code consists of two bytes, with the high-order byte on the left and low-order byte on the right. The function code serial number is used as the register address corresponding to the parameter, which needs to be converted into a hexadecimal number. Take P05.06 as an example: The group number is 05, and the number behind the dot mark is 06, that is, the parameter address is 506. Therefore, the function code address is 01FAH in the hexadecimal form. For P10.01, the parameter address is 03E9H.

Function code	Name	Description	Setting range	Default	Modify
P10.01	Local preset PID reference	0: Function code (P10.01) 1: Al1 2: Al2 3: Al3 4: Al1+ Al2 5: Al2+ Al3 6: Al3+ Al1 7: Reserved 8: Multi-step running 9: Modbus 10: PROFIBUS/PROFINET	0.0–10.0	0.0	0

∠Note:

- The parameters in the P29 group are set by the manufacturer and cannot be read or modified. Some parameters cannot be modified when the VFD is running; some cannot be modified regardless of the VFD status. Pay attention to the setting range, unit, and description of a parameter when modifying it.
- The service life of the Electrically Erasable Programmable Read-Only Memory (EEPROM) may be reduced if it is frequently used for storage. Some function codes do not need to be stored during communication. The application requirements can be met by modifying the value of the on-chip RAM, that is, modifying the MSB of the corresponding function code address from 0 to 1. For example, if P00.07 is not to be stored in the EEPROM, you need only to modify the value in the RAM, that is, set the address to 8007H. The address can be used only for writing data to the on-chip RAM, and it is invalid when used for reading data.

## 10.4.2 Addresses of other Modbus functions

In addition to modifying the parameters of the VFD, the master can also control the VFD, such as starting and stopping the VFD, and monitoring the running status of the VFD. The following table lists other function parameters.

Address	Function	Data description	R/W
1000H	VFD status	0001H: Forward running	R
		0002H: Reverse running	
		0003H: Stopped	
		0004H: Faulty	
		0005H: POFF state	
		For UDP/IP protocols, these information are	

Address	Function	Data description	R/W
		given in the handshake information. For the	
		UDP/IP protocols of the non-master node, or	
		other protocols, it is necessary to query the	
		address.	
		Bit0–bit1, logic state of the motor	
		0: Power-off state	
		1: Variable-frequency state	
		2: Power-frequency state	
		Bit2–bit8, results related to the VFD switching	
		cabinet 1	
		Bit2: QS1 state	
		Bit3: QS2 state	
1001H	Motor 1 state	Bit4: QS3 state	R
		Bit5: KM1 state	
		Bit6: KM3 state	
		Bit7: KM4 state	
		Bit8: KM5 state	
		Bit9-bit14: Reserved	
		Bit15: Control state of the switching cabinet 1	
		0: Remote	
		1: Local	
		Bit0–bit1, logic state of the motor	R
		0: Power-off state	
		1: Variable-frequency state	
		2: Power-frequency state	
		Bit2-bit8, results related to the VFD switching	
		cabinet 2	
		Bit2: QS1 state	
	Motor 2 state	Bit3: QS2 state	
1002H		Bit4: QS3 state	
		Bit5: KM1 state	
		Bit6: KM3 state	
		Bit7: KM4 state	
		Bit8: KM5 state	
		Bit9-bit14: Reserved	
		Bit15: Control state of the switching cabinet 2	
		0: Remote	
		1: Local	
		Bit0–bit1, logic state of the motor	
		0: Power-off state	
	Motor 3 state	1: Variable-frequency state	
		2: Power-frequency state	
10034		Bit2–bit8, results related to the VFD switching	R
1003H		cabinet 3	IX.
		Bit2: QS1 state	
		Bit3: QS2 state	
		Bit4: QS3 state	
		Bit5: KM1 state	

Address	Function	Data description	R/W
		Bit6: KM3 state	
		Bit7: KM4 state	
		Bit8: KM5 state	
		Bit9-bit14: Reserved	
		Bit15: Control state of the switching cabinet 3	
		0: Remote	
		1: Local	
		Bit0–bit1, logic state of the motor	
		0: Power-off state	
		1: Variable-frequency state	
		2: Power-frequency state	
		Bit2-bit8, results related to the VFD switching	
		cabinet 4	
		Bit2: QS1 state	
		Bit3: QS2 state	
1004H	Motor 4 state	Bit4: QS3 state	R
		Bit5: KM1 state	
		Bit6: KM3 state	
		Bit7: KM4 state	
		Bit8: KM5 state	
		Bit9-bit14: Reserved	
		Bit15: Control state of the switching cabinet 4	
		0: Remote	
		1: Local	
		Bit0-bit1, logic state of the motor	
		0: Power-off state	R
		1: Variable-frequency state	
		2: Power-frequency state	
		Bit2–bit8, results related to the VFD switching	
		cabinet 5	
	Motor 5 state	Bit2: QS1 state	
		Bit3: QS2 state	
1005H		Bit4: QS3 state	
		Bit5: KM1 state	
		Bit6: KM3 state	
		Bit7: KM4 state	
		Bit8: KM5 state	
		Bit9-bit14: Reserved	
		Bit15: Control state of the switching cabinet 5	
		0: Remote	
		1: Local	
1006H	Device code	200	R
100711	VED control state	0: Local state	
1007H	VFD control state	1: Remote state	К
		0: Invalid	
1000日	VED roady state	1: Ready to run	R
TUDAH	VFD ready state	2: Power-on fault state	
		3: Power off	

Address	Function	Data description	R/W
		4: Power-off fault state	
1000	Unit hypacs state	0: Without bypass unit	D
100511	Unit bypass state	1: With bypass unit	N
100AH	U-phase bypass unit	Each bit indicates the unit number of the	R
100BH	V-phase bypass unit	bypass. There are two types of bypasses:	R
100CH	W-phase bypass unit	symmetrical bypass and asymmetrical bypass.	R
100DH	U-phase bypass fault	Indicates the fault of the current bypass unit,	R
100EH	V-phase bypass fault	similar to the unit fault format, with each bit	R
100FH	W-phase bypass fault	indicating a fault.	R
1010H	A1 unit version	See the formats of unit versions.	R
1011H	A2 unit version	See the formats of unit versions.	R
1012H	A3 unit version	See the formats of unit versions.	R
1013H	A4 unit version	See the formats of unit versions.	R
1014H	A5 unit version	See the formats of unit versions.	R
1015H	A6 unit version	See the formats of unit versions.	R
1016H	A7 unit version	See the formats of unit versions.	R
1017H	A8 unit version	See the formats of unit versions.	R
1018H	A9 unit version	See the formats of unit versions.	R
1019H	A10 unit version	See the formats of unit versions.	R
101AH	A11 unit version	See the formats of unit versions.	R
101BH	A12 unit version	See the formats of unit versions.	R
101CH	B1 unit version	See the formats of unit versions.	R
101DH	B2 unit version	See the formats of unit versions.	R
101EH	B3 unit version	See the formats of unit versions.	R
101FH	B4 unit version	See the formats of unit versions.	R
1020H	B5 unit version	See the formats of unit versions.	R
1021H	B6 unit version	See the formats of unit versions.	R
1022H	B7 unit version	See the formats of unit versions.	R
1023H	B8 unit version	See the formats of unit versions.	R
1024H	B9 unit version	See the formats of unit versions.	R
1025H	B10 unit version	See the formats of unit versions.	R
1026H	B11 unit version	See the formats of unit versions.	R
1027H	B12 unit version	See the formats of unit versions.	R
1028H	C1 unit version	See the formats of unit versions.	R
1029H	C2 unit version	See the formats of unit versions.	R
102AH	C3 unit version	See the formats of unit versions.	R
102BH	C4 unit version	See the formats of unit versions.	R
102CH	C5 unit version	See the formats of unit versions.	R
102DH	C6 unit version	See the formats of unit versions.	R
1102EH	C7 unit version	See the formats of unit versions.	R
102FH	C8 unit version	See the formats of unit versions.	R
1030H	C9 unit version	See the formats of unit versions.	R
1031H	C10 unit version	See the formats of unit versions.	R
1032H	C11 unit version	See the formats of unit versions.	R
1033H	C12 unit version	See the formats of unit versions.	R
1034H-	High-order bit of A1–	0000H-FFFFH	R

Address	Function	Data description	R/W
103FH	A12 unit faults		
1040H	A1 unit temperature	0.0-100.0°c	R
1041H	A2 unit temperature	0.0-100.0°c	R
1042H	A3 unit temperature	0.0-100.0°c	R
1043H	A4 unit temperature	0.0-100.0°c	R
1044H	A5 unit temperature	0.0-100.0°c	R
1045H	A6 unit temperature	0.0–100.0°c	R
1046H	A7 unit temperature	0.0-100.0°c	R
1047H	A8 unit temperature	0.0-100.0°c	R
1048H	A9 unit temperature	0.0-100.0°c	R
1049H	A10 unit temperature	0.0–100.0°c	R
104AH	A11 unit temperature	0.0-100.0°c	R
104BH	A12 unit temperature	0.0–100.0°c	R
104CH	B1 unit temperature	0.0–100.0°c	R
104DH	B2 unit temperature	0.0-100.0°c	R
104EH	B3 unit temperature	0.0–100.0°c	R
104FH	B4 unit temperature	0.0–100.0°c	R
1050H	B5 unit temperature	0.0–100.0°c	R
1051H	B6 unit temperature	0.0–100.0°c	R
1052H	B7 unit temperature	0.0–100.0°c	R
1053H	B8 unit temperature	0.0–100.0°c	R
1054H	B9 unit temperature	0.0–100.0°c	R
1055H	B10 unit temperature	0.0–100.0°c	R
1056H	B11 unit temperature	0.0–100.0°c	R
1057H	B12 unit temperature	0.0–100.0°c	R
1058H	C1 unit temperature	0.0–100.0°c	R
1059H	C2 unit temperature	0.0–100.0°c	R
105AH	C3 unit temperature	0.0–100.0°c	R
105BH	C4 unit temperature	0.0–100.0°c	R
105CH	C5 unit temperature	0.0–100.0°c	R
105DH	C6 unit temperature	0.0–100.0°c	R
105EH	C7 unit temperature	0.0–100.0°c	R
105FH	C8 unit temperature	0.0–100.0°c	R
1060H	C9 unit temperature	0.0–100.0°c	R
1061H	C10 unit temperature	0.0–100.0°c	R
1062H	C11 unit temperature	0.0–100.0°c	R
1063H	C12 unit temperature	0.0–100.0°c	R
1064H-	High-order bit of B1–		_
106FH	B12 unit faults	0000H-FFFFH	R
1070H	A1 unit bus	0-1400V	R
1071H	A2 unit bus	0-1400V	R
1072H	A3 unit bus	0-1400V	R
1073H	A4 unit bus	0-1400V	R
1074H	A5 unit bus	0-1400V	R
1075H	A6 unit bus	0-1400V	R
1076H	A7 unit bus	0-1400V	R
1077H	A8 unit bus	0-1400V	R

## Goodrive5000 series medium voltage variable-frequency speed regulation system

Modbus communication protocol

Address	Function	Data description	R/W
1078H	A9 unit bus	0-1400V	R
1079H	A10 unit bus	0-1400V	R
107AH	A11 unit bus	0-1400V	R
107BH	A12 unit bus	0-1400V	R
107CH	B1 unit bus	0-1400V	R
107DH	B2 unit bus	0-1400V	R
107EH	B3 unit bus	0-1400V	R
107FH	B4 unit bus	0-1400V	R
1080H	B5 unit bus	0-1400V	R
1081H	B6 unit bus	0-1400V	R
1082H	B7 unit bus	0-1400V	R
1083H	B8 unit bus	0-1400V	R
1084H	B9 unit bus	0-1400V	R
1085H	B10 unit bus	0-1400V	R
1086H	B11 unit bus	0-1400V	R
1087H	B12 unit bus	0-1400V	R
1088H	C1 unit bus	0-1400V	R
1089H	C2 unit bus	0-1400V	R
108AH	C3 unit bus	0-1400V	R
108BH	C4 unit bus	0-1400V	R
108CH	C5 unit bus	0-1400V	R
108DH	C6 unit bus	0-1400V	R
108EH	C7 unit bus	0-1400V	R
108FH	C8 unit bus	0-1400V	R
1090H	C9 unit bus	0-1400V	R
1091H	C10 unit bus	0-1400V	R
1092H	C11 unit bus	0-1400V	R
1093H	C12 unit bus	0-1400V	R
1094H-	High-order bit of C1–		
109FH	C12 unit faults	0000H-FFFFH	R
	Low-order bit of A1		_
10A0H	unit fault	0000H-FFFFH	R
104111	Low-order bit of A2		_
IUAIH	unit fault	0000H-FFFFH	R
104211	Low-order bit of A3		
10A2H	unit fault	0000H-FFFFH	R
104211	Low-order bit of A4		D
10A3H	unit fault	0000H-FFFFH	ĸ
104411	Low-order bit of A5		P
10A4H	unit fault	00000-FFFFA	ĸ
10450	Low-order bit of A6	000004 55554	р
TUADE	unit fault		
10460	Low-order bit of A7	0000H-FFFFH	R
TOMOLI	unit fault		
10A7H	Low-order bit of A8	0000H-FFFFH	R
TOULL	unit fault		
10A8H	Low-order bit of A9	0000H-FFFFH	R
Address	Function	Data description	R/W
---------	----------------------	------------------	-----
	unit fault		
1040	Low-order bit of A10		D
104911	unit fault		п
10AAH	Low-order bit of A11	0000H-FFFFH	R
	unit fault		
10ABH	Low-order bit of A12	0000H-FFFFH	R
	unit fault		
10ACH	Low-order bit of B1	0000H-FFFFH	R
	Low-order bit of B2		
10ADH	unit fault	0000H-FFFFH	R
	Low-order bit of B3		_
10AEH	unit fault	0000H-FFFFH	R
10454	Low-order bit of B4		D
IUAFH	unit fault		ĸ
10B0H	Low-order bit of B5	0000H-FFFFH	R
100011	unit fault		
10B1H	Low-order bit of B6	0000H-FFFFH	R
	unit fault		
10B2H	Low-order bit of B7	0000H-FFFFH	R
	Low-order bit of B8	0000H-FFFFH	
10B3H	unit fault		R
	Low-order bit of B9	0000H-FFFFH	
10B4H	unit fault		R
100511	Low-order bit of B10		5
10B2H	unit fault		К
10B6H	Low-order bit of B11		R
100011	unit fault		
10B7H	Low-order bit of B12	0000H-FFFFH	R
	unit fault		
10B8H	Low-order bit of C1	0000H-FFFFH	R
	Low-order bit of C2		
10B9H	unit fault	0000H-FFFFH	R
	Low-order bit of C3		
10BAH	unit fault	0000H-FFFFH	R
100011	Low-order bit of C4		
TORRH	unit fault	0000H-FFFFH	R
10BCH	Low-order bit of C5		P
TOPCII	unit fault		
10BDH	Low-order bit of C6	0000H-FFFFH	R
	unit fault		
10BEH	Low-order bit of C7	0000H-FFFFH	R
	unit tault		
10BFH	Low-order bit of C8	٥000H-FFFFH	R
	unitiault		

Modbus communication protocol

Address	Function	Data description	R/W
10C0H	Low-order bit of C9 unit fault	0000H-FFFFH	R
10C1H	Low-order bit of C10	0000H-FFFFH	R
10C2H	Low-order bit of C11	0000H-FFFFH	R
10C3H	Low-order bit of C12	0000H-FFFFH	R
10C4H	A-phase unit fault	_	R
10C5H	B-phase unit fault	_	R
10C6H	C-phase unit fault	-	R
10C7H- 10CFH	Reserved	Reserved	R
10D0H	Actual step of multi-step speed	0–15	R
10D1H	Present ACC/DEC time	1-5	R
10D2H	Valid unit count	0–12. same as P07.06	R
10D3H	Present DSP1 fault	See group P09: Fault record parameters	R
10D4H	Present DSP2 fault	See group P09: Fault record parameters	R
10D5H	Present ARM fault type	See group P09: Fault record parameters	R
10D6H	Present ARM fault type	See group P09: Fault record parameters	R
10D7H	Present unit fault 1	See group P09: Fault record parameters	R
10D8H	Present unit fault 2	See group P09: Fault record parameters	R
10D9H	Unit number at present fault	-	R
10DAH	ACC/DEC state at	-	R
10DBH	Running frequency at	-	R
10DCH	Set frequency at	-	R
10DDH	Output current at	-	R
10DEH	Output current at	-	R
10DFH	Input current at	-	R
10E0H	Input voltage at	-	R
10E1H	Unit bus voltage at	-	R
10E2H	Unit temperature at	-	R
10E3H	System input terminal	-	R

Address	Function	Data description	R/W
	state at present fault		
10544	User input terminal		D
10040	state at present fault	-	ĸ
	System output		
10E5H	terminal state at	-	R
	present fault		
10F6H	User output terminal		D
102011	state 1 at present fault	-	K
10574	User output terminal		D
101711	state 2 at present fault	-	ĸ
10E8H	Present fault time	-	R
10504	Present control	D00.01	-
1059H	command channel	P00.01	
10EAH	Alarm output flag	-	-
		0: System alarm	-
	System/DSP/ARM	1–36: Unit alarm	
IVEDH	alarm code	98: DSP alarm	
		99: ARM alarm	
10504	High-order bit of alarm		р
IUECH	code	-	К
	Low-order bit of alarm		р
IUEDH	code	-	К
10554	Parameter autotuning	Used as the parameter autotuning auxiliary	р
IULLII	auxiliary bit	state of the upper computer display.	K
10FFH	Commissioning	Commissioning state flag	R
102111	auxiliary bit		
		8 low-order bits correspond to switch action	
		faults of the switching cabinet 1	
		8 high-order bits correspond to switch action	
		faults of the switching cabinet 2	
		Bit0: KM1	
		Bit1: KM2	
		Bit2: KM3	
		Bit3: KM4	
		Bit4: QS1	
	Switch action faults of	Bit5: QS2	_
10F0H	the switching cabinets	Bit6: OS3	R
	1-2	Bit7: Reserved	
		Bit8: KM1	
		Bito: KM2	
		BIL12: QS1 Bit12: QS2	
		BI(13: QS2	
		Bit14: QS3	
		Bit15: Reserved	
10F1H	Switch action faults of	Same as the above	R
	I the switching cabinets		

Address	Function	Data description	R/W
	2-3		
10F2H– 10FFH	Reserved	-	R
1100H- 11FFH	Property of each display value (bits by bits)	Bit0-bit2: Multiplication rate It indicates the number behind the dot mark. 0=6: Two decimal places. Bit3: Reserved It indicates restoring factory values is allowed to override the characteristics. Bit4: Sign characteristics 1= signed 0= unsigned Bit5-bit6: Write level 0 = Can be changed at any time 1 = Cannot be changed in running 2 = Cannot be changed Bit7: Read level 0 = readable 1= unreadable Bit8-bit10: Max. and Min value type 0 = The whole byte is used as a criterion (common) 1 = 8bit a group, as a criterion 3 = 2bit a group, as a criterion 3 = 2bit a group, as a criterion 5 = Cannot be repeated Bit11-bit15: Enumeration of the units 0= no unit 1 = hexadecimal (XXXXH) 2 = Enumeration type 3 = Pulse frequency (Hz) 4 = High-speed frequency (kHz) 5 = Frequency change rate (Hz/s) 6 = rpm 7 = Millisecond (ms) 8 = Second (s) 9 = Minute (m) 10 = Hour (h) 11 = Baud rate (bps) 12 = Percentage (%) 13 = Voltage (V) 14 = Current (A) 15 = Resistance (\Omega) 16 = Inductance (mH) 17 = Power (kW) 18 = PU (this is a per-unit value, and the unit is the associated data) 19 = °C	R

Address	Function	Data description	R/W
		20 = * (asterisk)	
		21 =µs	
		22 = KVA	
		23 = kWh	
		24 = MPa	
		25 =µm	
		26 = angle	
		27 = mm	
		0001H: Run forward	
		0002H: Run reversely	
		0003H: Jog forward	
2000H		0004H: Jog reversely	W
200011		0005H: Stop	
		0006H: Coast to stop (in emergency)	
		0007H: Fault reset	
	-	0008H: Stop jogging	
		8 high-order bits indicate the switching	
		cabinets that require power frequency and	
		variable frequency switching	
		00H: Main switching cabinet 1	
		01H: Switching cabinet 2	
		02H: Switching cabinet 3	
		03H: Switching cabinet 4	
		04H: Main switching cabinet 5	
		05H: Switching cabinet 6	
		06H: Switching cabinet 7	
		07H: Switching cabinet 8	
	Communication-based	8 low-order bits indicate the commands.	
	control command	00H: No action	
		01H: Variable frequency 1	
		02H: Power frequency	
2001H		03H: Switch from variable frequency to power	W
		frequency	
		04H: Switch from power frequency to variable	
		frequency 1	
		05H: Cut of medium voltage	
		06H: Variable frequency 2	
		07H: Switch from power frequency to variable	
		frequency 2	
		Variable frequency 1: If there are other	
		variable-frequency motors before, the original	
		variable-frequency motor runs at power	
		irequency after the switching cabinet is	
		Switched to variable frequency.	
		variable frequency 2: If there are other	
		variable frequency motor store, the original	
		witching cohinet is switched to wartching	
		variable-frequency motors before, the original variable-frequency motor stops after the switching cabinet is switched to variable	

Address	Function	Data description	R/W
		frequency.	
		Switch from power frequency to variable	
		frequency 1: If there are other	
		variable-frequency motors before, the original	
		variable-frequency motor runs at power	
		frequency after the switching cabinet is	
		switched to variable frequency.	
		Variable frequency 2: If there are other	
		variable-frequency motors before, the original	
		variable-frequency motor stops after the	
		switching cabinet is switched to variable	
	-	frequency.	
2004H		Read the fault records saved in the fault black	
200 111	-	box.	
2200H		-Fmax–Fmax, Hz, 2 decimal places after the	W
220011		decimal point	• •
		8 high-order bits indicate the switching	
		cabinets that require power frequency and	
		variable frequency switching	
		00H: Main switching cabinet 1	
2005H		01H: Switching cabinet 2	
		02H: Switching cabinet 3	
		03H: Switching cabinet 4	
		04H: Main switching cabinet 5	2005H
		05H: Switching cabinet 6	
		06H: Switching cabinet 7	
		07H: Switching cabinet 8	
		8 low-order bits indicate the commands.	
		00H: Allow variable frequency	
		01H: Allow power frequency	
		02H: Allow power frequency and variable	
		trequency	
220111		It can be PID reference or PID feedback	14/
2201H		according to the configuration.	vv
	-	Configure the compliant frequency of the	
		configure the sampling frequency of the	
		0:2K 0.5ms once	
		1.1K 1ms once	
2202H		2.0.5K 2ms once	W
220211		3: 0.25K. 4ms once	
		4: 0.125K. 8ms once	
		After the sampling times of ARM reaches 64.	
		all channels are uploaded uniformly	
2203H	1	-100.0%-100.0%	W
2204H	1	0.0%-100.0%	W
4000H	Reference frequency	0.00–120.00Hz (Actual value)	R
4001H	Running frequency	0.00–120.00Hz (Actual value)	R

Address	Function	Data description	R/W
4002H	Torque	0-100.0%	R
4003H	Output voltage	0–20000V (No decimal place)	R
4004H	Input voltage	0–20000V (No decimal place)	R
4005H	Output current	0.0-1000.0	R
4006H	Input current	0.0-1000.0	R
4007H	Output power	Percentage, one decimal place, signed	R
4008H	Input power	Percentage, one decimal place, unsigned	R
4009H	Output power factor	Percentage, one decimal place, unsigned	R
400AH	Input power factor	Percentage, one decimal place, unsigned	R
400BH	Input current active component	Percentage, (4096 per unit, P02.05)	R
400CH	Input current reactive components	Percentage, (4096 per unit, P02.05)	R
400DH	Output current active component	Percentage, (4096 per unit, P02.05)	R
400EH	Output current reactive component	Percentage, (4096 per unit, P02.05)	R
400FH	Input voltage L1L2 waveform	Actual value, (1.875 times the rated peak voltage corresponds to 2048, P02.04)	R
4010H	Input voltage L2L3 waveform	Actual value, (1.875 times the rated peak voltage corresponds to 2048, P02.04)	R
4011H	Input voltage L3L1	Actual value, (1.875 times the rated peak	R
4012H	Input current L1	Actual*10 value, (twice the rated peak current	R
		Actual*10 value (twice the rated peak current	
4013H	mput current L2	corresponds to 2018 PO2 05)	R
		Actual*10 value (twice the rated peak current	
4014H	waveform	corresponds to 2048, PO2 05)	R
4015H	Output voltage UV	Actual value, (1.875 times the rated peak	R
4016	Output voltage VW	Actual value, (1.875 times the rated peak	D
40100	waveform	voltage corresponds to 2048, P02.04)	ĸ
4017H	Output voltage WU waveform	Actual value, (1.875 times the rated peak voltage corresponds to 2048, P02.04)	R
4018H	Output U-phase	Actual*10 value, (twice the rated peak current corresponds to 32767, P02 05)	R
4019H	Output V-phase	Actual*10 value, (twice the rated peak current	R
		Actual*10 value (twice the rated pack current	
401AH	current waveform	corresponds to 32767 PO2 05	R
401BH	U-phase modulating	Waveform, no unit	R
401CH	V-phase modulating waveform	Waveform, no unit	R
401DH	W-phase modulating waveform	Waveform, no unit	R

Modbus communication protocol

Address	Function	Data description	R/W
401EH	Q-axis angle	0–65536	R
401FH	T-axis angle	0–65536	R
402011	Output current M-axis	227C0_227C7 (400C m on unit)	D
4020H	component	-32768–32767 (4096 per unit)	ĸ
402111	Output current T-axis	227C0_227C7 (400C more unit)	Р
4021H	component	-32768–32767 (4096 per unit)	ĸ
4022H	Output voltage phase	0–65536	R
4023H	Output current phase	0–65536	R
4024H	U-phase bus voltage	No decimal place (unit: V)	R
4025H	V-phase bus voltage	No decimal place (unit: V)	R
4026H	W-phase bus voltage	No decimal place (unit: V)	R
400711	Temperature in VFD		P
4027H	cabinet		ĸ
	Phase shifting		
4028H	transformer A1	°C	R
	temperature		
	Phase shifting		
4029H	transformer B1	°C	R
	temperature		
	Phase shifting		
402AH	transformer C1	°C	R
	temperature		
	Phase shifting		
402BH	transformer A2	°C	R
	temperature		
	Phase shifting		
402CH	transformer B2	°C	R
	temperature		
	Phase shifting		
402DH	transformer C2	°C	R
	temperature		
402EH	Bumpless switching	0_1	P
	flag bit		K
402FH	Motor temperature 1	°C	R
4030H	Motor temperature 2	°C	R
4031H	Motor temperature 3	°C	R
4032H	Motor temperature 4	°C	R
4033H	Motor temperature 5	°C	R
4034H	Motor vibration 1	0–65536	R
4035H	Motor vibration 2	0–65536	R
4036H	Motor vibration 3	0–65536	R
4037H	Motor vibration 4	0–65536	R
4038H-	Posoniad	Pesenved	
403FH	Reserveu		
4040H	User input terminal	Each bit indicates the corresponding terminal state.	R
4041H	User output terminal 1	Each bit on the user I/O board indicates the	R

Address	Function	Data description	R/W
		corresponding terminal state.	
40.4011		Each bit on the I/O expansion board indicates	
4042H	User output terminal 2	the corresponding terminal state.	R
404211		Each bit indicates the corresponding terminal	<b>_</b>
4043H	System input terminal	state.	R
404411	System output	Each bit indicates the corresponding terminal	D
4044H	terminal	state.	R
4045H	AI1 display	0-100.0%	R
4046H	AI2 display	0-100.0%	R
4047H	AI3 display	0-100.0%	R
4048H	AI4 display	0-100.0%	R
4049H	A01	0-100.0%	R
404AH	AO2	0-100.0%	R
404BH	AO3	0-100.0%	R
404CH	AO4	0-100.0%	R
404DH	AO5	0–65536	R
404EH	Reserved	0–50.000kHz	R
404FH	PID reference	0-100.0%	R
404FH	PID feedback	0-100.0%	R
405011	Power consumption		Р
4050H	per second	-	ĸ
	16 low-order bits of		
4051H	total power		R
	consumption	The final result needs to be calculated by the	
	16 high-order bits of	upper computer before display.	
4052H	total power		R
	consumption		
4053H	Reserved	Reserved used for nower saving display	R
4054H	Reserved	Reserved, used for power saving display	
		00H: No action	
		01H: Switch from power frequency to variable	
		frequency 2	
		02H: Switch from power frequency to variable	
	Operation commands	frequency 1	
4055H	of the touch screen	03H: Variable frequency 1	R
	display	04H: Variable frequency 2	
		05H: Switch from variable frequency to power	
		frequency	
		06H: Power frequency	
		UTH: Cut of medium voltage	
4056H	Uperation command:	Counting overflow	R
	count value	-	
4057H	Operation command:	Motor number	R
	Motor number		
405011	operation command:	1: LOCAL	<b>D</b>
4038H	power frequency and		
	variable frequency	J. FRUFIDUJ	

commands4: Terminal 5: Master 6: Terminal 1 7: Terminal 24059HFeedback state of switching cabinet 0KM5: 1 KM4: 1 KM3: 1 QS1: 1 QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the above Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 1OOH: Allow variable frequency O2H: Allow power frequency/variable frequency/variable frequencyR	Address	Function
4059HFeedback state of switching cabinet 15: Master 6: Terminal 1 7: Terminal 2R4059HFeedback state of switching cabinet 0KM5: 1 KM4: 1 KM3: 1 QS1: 1 QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the above Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 100H: Allow variable frequency 02H: Allow power frequency 02H: Allow power frequencyR405DHFeedback variable frequency allowing state of the switching cabinet 100H: Allow power frequency frequencyR		commands
4059HFeedback state of switching cabinet 0KM5: 1 KM4: 1 KM3: 1R4059HFeedback state of switching cabinet 0KM1: 1 QS1: 1 QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 1OH: Allow variable frequency O1H: Allow power frequencyR405DHFeedback variable frequency allowing cabinet 1OH: Allow power frequency o2H: Allow power frequencyR		
Image: state of the switching cabinet 27: Terminal 24059HFeedback state of switching cabinet 0KM5: 1 KM3: 1 CS1: 1 QS1: 1 QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the above Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 1OH: Allow variable frequency O1H: Allow power frequency/variable frequency/variable frequencyR		
4059HFeedback state of switching cabinet 0KM5: 1 KM4: 1 KM3: 1KM4: 1 KM3: 1R4059HFeedback state of switching cabinet 0QS1: 1 QS3: 1 Reserved: 9QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback variable frequency allowing state of the switching 01H: Allow power frequency 02H: Allow power frequency/variable frequencyR405DHFeedback variable frequency allowing state of the switching cabinet 100H: Allow power frequency/variable frequencyR		
4059HFeedback state of switching cabinet 0KM4: 1 KM3: 1 QS1: 1 QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the above Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 1OOH: Allow variable frequency 02H: Allow power frequency/variable frequency/variableR		
4059HFeedback state of switching cabinet 0KM3: 1 KM1: 1 QS1: 1 QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 100H: Allow variable frequency 02H: Allow power frequency/variable frequency/variableR		
4059HFeedback state of switching cabinet 0KM1: 1 QS1: 1 QS2: 1 QS3: 1 Reserved: 9R405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 100H: Allow variable frequency 01H: Allow power frequency/variable frequency/variableR		
4039H     switching cabinet 0     QS1: 1     QS2: 1       QS3: 1     QS3: 1       QS52H     QS3: 1       Reserved: 9     Reserved: 9       405AH     Feedback state of switching cabinet 1       Feedback state of switching cabinet 2     Same as the above       405BH     Feedback state of switching cabinet 2       A05CH     Feedback state of switching cabinet 3       Feedback state of switching cabinet 3     Same as the above       A05CH     Feedback state of switching cabinet 3       Feedback variable     00H: Allow variable frequency       405DH     Feedback variable       02H: Allow power frequency     R       405DH     Feedback variable       frequency allowing cabinet 1     02H: Allow power frequency       Feedback variable     02H: Allow power frequency/variable       Feedback variable     frequency       Feedback variable     frequency	40504	Feedback state of
QS2: 1 QS3: 1 Reserved: 9QS3: 1 Reserved: 9405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback variable frequency allowing state of the switching o1H: Allow power frequency 02H: Allow power frequency/variable frequencyR	40390	switching cabinet 0
QS3:1 Reserved:9405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable frequency allowing state of the switching cabinet 100H: Allow variable frequency 01H: Allow power frequency/variable frequency/variable frequencyR		
Image: series of the switching cabinet 1Reserved: 9Reserved: 9405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback variable of switching cabinet 3Same as the aboveR405CHFeedback variable of the switching cabinet 3Same as the aboveR405DHFeedback variable of the switching cabinet 300H: Allow variable frequencyR405DHFeedback variable of the switching cabinet 102H: Allow power frequencyR405DHFeedback variable of the switching cabinet 102H: Allow power frequencyR		
405AHFeedback state of switching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback variable frequency allowing state of the switching cabinet 100H: Allow variable frequency 01H: Allow power frequency/variable frequency/variable frequencyR		
405AHswitching cabinet 1Same as the aboveR405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback variable frequency allowing state of the switching cabinet 100H: Allow variable frequency 01H: Allow power frequency yower frequency/variableR405DHFeedback variable frequency allowing tate of the switching cabinet 100H: Allow power frequency frequencyR	405AH	Feedback state of
405BHFeedback state of switching cabinet 2Same as the aboveR405CHFeedback state of switching cabinet 3Same as the aboveR405CHFeedback variable frequency allowing state of the switching cabinet 100H: Allow variable frequency 01H: Allow power frequency/variable frequency/variable frequencyR	403A11	switching cabinet 1
403BH     switching cabinet 2     Same as the above     R       405CH     Feedback state of switching cabinet 3     Same as the above     R       405DH     Feedback variable     00H: Allow variable frequency     R       405DH     Frequency allowing state of the switching cabinet 1     00H: Allow power frequency/variable frequency/variable     R       Feedback variable     02H: Allow power frequency/variable frequency     R		Feedback state of
405CHFeedback state of switching cabinet 3Same as the aboveR405DHFeedback variable00H: Allow variable frequency 01H: Allow power frequency 02H: Allow power frequency/variable frequency/variable frequencyR405DHFeedback variable frequency allowing state of the switching cabinet 100H: Allow power frequency frequency/variable frequencyR	40360	switching cabinet 2
405CH     switching cabinet 3     Same as the above     R       405DH     Feedback variable     00H: Allow variable frequency     R       405DH     frequency allowing     01H: Allow power frequency     R       cabinet 1     frequency     02H: Allow power frequency/variable     R       Feedback variable     frequency     1     1	405CH	Feedback state of
405DH     Feedback variable     00H: Allow variable frequency       405DH     frequency allowing     01H: Allow power frequency       state of the switching     02H: Allow power frequency/variable       cabinet 1     frequency       Feedback variable     frequency	403CH	switching cabinet 3
405DH     frequency allowing state of the switching cabinet 1     01H: Allow power frequency 02H: Allow power frequency/variable frequency     R       Feedback variable     frequency		Feedback variable
405D11     state of the switching     02H: Allow power frequency/variable       cabinet 1     frequency       Feedback variable		frequency allowing
cabinet 1 frequency Feedback variable	405011	state of the switching
Feedback variable		cabinet 1
		Feedback variable
405EH Frequency allowing Same as the above	405EH	frequency allowing
state of the switching	HUSEIT	state of the switching
cabinet 2		cabinet 2
Feedback variable		Feedback variable
405FH frequency allowing Same as the above R	405FH	frequency allowing
state of the switching		state of the switching
cabinet 3		cabinet 3
Feedback variable		Feedback variable
4060H frequency allowing Same as the above R	4060H	frequency allowing
state of the switching		state of the switching
cabinet 4		cabinet 4
4061H– Reserved – R	4061H-	Reserved
4064H	4064H	
4065H Modify function code R	4065H	Modify function code
address		address
4066H R	4066H	Modify function code
backup value		backup value
4067H Modify function code - R	4067H	Modify function code
modified value		modified value
4068H Modify function code R	4068H	Modify function code
counting		counting
4069H Modify function code R	4069H	Modify function code
channel		channel
400AH- Reserved - R	406AH-	Reserved

Address	Function	Data description	R/W
		0: Decelerate to stop	
		1: Forward	
4075H	Running command	2: Reverse	R
		3: Coast to stop	
		4: Speed tracking	
		0: Forward jogging	
40764	log rupping command	1: Reverse jogging	р
40700	Jog running command	2: Cancel jogging	ĸ
		3: Jogging and coast to stop	
4077H	Modify the count value	Start/stop delay counting	R
4078H	Command channel	-	R
4079H	Run/jog flag	1: Run	ſ
		2: Jogging	К
407AH-	Pecanyod		
407FH	Reserved	-	
10000	Property of each		
4080H- 40EEH	oscilloscope unit (bits	Same as 3100H–31FFH	R
401111	by bits)		
		An address corresponds to an oscilloscope	
4100	Waveform start/stop	channel. Write the specific channel number to	
410011-	of each oscilloscope	the corresponding address.	R
41760	channel	If 0 is written, it indicates that the variable	
		cannot perform oscillography.	
		An address corresponds to an oscilloscope	
4180H-	Setting range of each	channel. The setting range of a signed value is	D
41FFH	oscilloscope channel	-Max-+Max, and the setting range of an	ĸ
		unsigned value is 0–Max.	

The Read/Write (R/W) characteristics indicate whether a function parameter can be read and written. For example, "Communication-based control command" can be written, and therefore the command code 06H is used to control the VFD. The R characteristic indicates that a function parameter can only be read, and W indicates that a function parameter can only be written.

**Note:** Some parameters in the preceding table are valid only after they are enabled. Take the running and stop operations as examples, you need to set "Running command channel" (P00.01) to "Communication", and set "Communication mode of running commands" (P00.02) to Modbus. For another example, when modifying "PID reference", you need to set "PID reference source" (P10.00) to Modbus communication.

## 10.4.3 Fieldbus scale

In practical applications, communication data is represented in the hexadecimal form, but hexadecimal values cannot represent decimals. For example, 50.12 Hz cannot be represented in the hexadecimal form. In such cases, multiply 50.12 by 100 to obtain an integer 5012, and then 50.12 can be represented as 1394H in the hexadecimal form (5012 in the decimal form).

In the process of multiplying a non-integer by a multiple to obtain an integer, the multiple is referred to as a fieldbus scale.

The fieldbus scale depends on the number of decimal places in the value specified in "Setting range" or "Default". If there are n (for example, 1) decimal places in the value, the fieldbus scale m (then m=10) is the result of 10 to the power of n. Take the following table as an example.

Modbus communication protocol

Function code	Name	Description	Setting range	Default	Modify
P01.28	Wait time for restart after power-off	0.0–3600.0s (valid when P01.17=1)	0.0-3600.0	1.0s	0

If "Setting range" or "Default value" contains one decimal, the fieldbus scale is 10. If the value received by the upper computer is 50, "Wait time for restart after power-off" of the VFD is 5.0 (5.0=50/10).

To set "Wait time for restart after power-off" to 5.0s through Modbus communication, you need first to multiply 5.0 by 10 according to the scale to obtain an integer 50, that is, 32H in the hexadecimal form, and then send the following write command:



After receiving the command, the VFD converts 50 into 5.0 based on the fieldbus scale, and then sets "Wake-up-from-sleep delay" to 5.0s.

For another example, after the upper computer sends the "Wait time for restart after power-off" parameter read command, the master receives the following response from the VFD:



The parameter data is 0032H, that is, 50, so 5.0 is obtained based on the fieldbus scale (50/10=5.0). In this case, the master identifies that "Wait time for restart after power-off" is 5.0s.

#### 10.4.4 Error message response

Operation errors may occur in communication-based control. For example, some parameters can only be read, but a write command is sent. In this case, the VFD returns an error message response.

Error message responses are sent from the VFD to the master. The following table lists the codes and definitions of the error message responses.

Modbus exception code					
Code	Name	Definition			
01H	Invalid function	<ul> <li>The function code received by the upper computer is not allowed to be executed. The possible causes are as follows:</li> <li>The function code is applicable only on new devices and is not implemented on this device.</li> <li>The slave is in faulty state when processing this request.</li> </ul>			
02H	Invalid data address	For the system, the data address in the request of the upper computer is not allowed. In particular, the combination of the register address and the number of the to-be-sent bytes is invalid.			
03H	Invalid data value	The received data domain contains a value that is not allowed. The value indicates the error of the remaining structure in the combined request. <b>Note:</b> It does not mean that the data item submitted for storage in the register includes a value unexpected by the program.			
06H	The slave device is	The system is busy (EPPROM is saving).			

Modbus exception code					
Code	Name	Definition			
	busy				
10H	Password error	The password entered in the password verification address is different from that set in P07.00.			
11H	Check error	The data frame sent from the upper computer is incorrect in the length, or in the ASCII format, the value of the LRC check bit is inconsistent with the CRC value calculated by the lower computer.			
12H	Parameter modification is invalid	In the parameter write command sent by the upper computer, the data sent is outside the range of the parameter, or the write address is currently in a non-rewritable state, or the written input terminal selection function has been already occupied by other terminals.			
13H	The system is locked	If the upper computer does not provide the correct password to unlock the system to perform a read or write operation, the error of "system being locked" is reported.			

When returning a response, the slave uses a function code domain and fault address to indicate whether it is a normal response (no error) or exception response (an error occurs). In a normal response, the slave returns the corresponding function code and data address or sub-function code. In an exception response, the slave returns a code that is equal to a normal code, but the first bit is logic 1.

For example, if the master sends a request message to a slave for reading a group of function code address data, the following code is generated:

```
0000011 (03H in the hexadecimal form)
```

In a normal response, the slave returns the same function code. In an exception response, the slave returns the following code.

#### 1000011 (83H in the hexadecimal form)

In addition to the modification of the code, the slave returns a byte of exception code that describes the cause of the exception. After receiving the exception response, the typical processing of the master is to send the request message again or modify the command based on the fault information.

For example, to set the "Channel of running commands" (P00.01, the parameter address is 0000H) to 04 for the VFD whose address is 01H, the command is as follows:



However, "Running command channel" ranges from 0 to 3. The value 4 is out of the setting range. In this case, the VFD returns an error message response as shown in the following:

01	86	03	<u>02 61</u>
VFD	Exception		

VFD Exception address response code Error code CRC

The exception response code 86H (generated based on the MSB "1" of the write command 06H) indicates that it is an exception response to the write command (06H). The error code is 03H that indicates the error "Invalid data value", which means "The received data domain contains a value that is not allowed". The value indicates the error of the remaining structure in the combined request.

#### 10.4.5 Read/Write operation examples

For the formats of the read and write commands, see sections 10.3.1 and 10.3.2.

#### 10.4.5.1 Read command 03H examples

Example 1: Read state word of the VFD whose address is 01H. According to the table of other Modbus function addresses in section 10.4.2 Addresses of other Modbus functions, the parameter address of state word of the VFD is 1000H.

The read command transmitted to the VFD is as follows:



Assume that the following response is returned:

<u>01</u>	<u>03</u>	<u>02</u>	<u>00 03</u>	<u>F8 45</u>
VFD	Read	Number of	Data	CRC
address	command	bvtes	content	URU

The data content returned by the VFD is 0003H, which indicates that the VFD is in the stopped state.

#### 10.4.5.2 Write command 06H examples

Example 1: Set the VFD whose address is 03H to be forward running. Refer to the table of other function parameters, the address of "Communication-based control command" is 2000H, and 0001H indicates forward running. See the following figure.

Function Address		Data description	R/W				
		0001H: Run forward					
	2000H	0002H: Run reversely					
		0003H: Jog forward					
Communication-based		0004H: Jog reversely	14/				
control command		0005H: Stop	VV				
					l	0006H: Coast to stop	
		0007H: Fault reset					
		0008H: Stop jogging					

The command transmitted from the master is as follows:



If the operation is successful, the following response is returned (same as the command sent from the master):



**Note:** In the preceding command description, spaces are added to a command just for explanatory purposes. In practical applications, no space is required in the commands.

#### 10.4.5.3 Example of Modbus communication commissioning

A PC is used as the host, an RS232-RS485 converter is used for signal conversion, and the PC serial port used by the converter is COM1 (an RS232 port). The upper computer commissioning software is the serial port

commissioning assistant Commix, which can be downloaded from the Internet. Download a version that can automatically execute the CRC check function. The following figure shows the interface of Commix.



First, set the serial port to **COM1**. Then, set the baud rate consistently with P16.01. The data bits, check bits, and end bits must be set consistently with P16.02. If the RTU mode is selected, you need to select the hexadecimal form **Input HEX**. To set the software to automatically execute the CRC function, you need to select **ModbusRTU** relevance **ModbusRTU**, select **CRC16 (MODBU SRTU**), and set the start byte to **1**. After the auto CRC check function is enabled, do not enter CRC information in commands. Otherwise, command errors may occur due to repeated CRC check.

The commissioning command to set the VFD whose address is 03H to be forward running is as follows:



#### ∠Note:

- Set the address (P16.00) of the VFD to 03.
- Set "Channel of running commands" (P00.01) to "Communication", and set "Communication channel of running commands" (P00.02) to the Modbus communication channel.
- Click Send. If the line configuration and settings are correct, a response transmitted by the VFD is received.

## **10.5 Common communication faults**

Common communication faults include the following:

- No response is returned.
- The VFD returns an exception response.

Possible causes of no response include the following:

- The serial port is set incorrectly. For example, the adapter uses the serial port COM1, but COM2 is selected for the communication.
- The settings of the baud rates, data bits, end bits, and check bits are inconsistent with those set on the VFD.
- The positive pole (+) and negative pole (-) of the RS485 bus are connected reversely.
- The resistor connected to 485 terminals on the terminal block of the VFD is set incorrectly.

# Appendix A EMC

EMC is short for electromagnetic compatibility, which refers to the ability of a device or system to function properly in its electromagnetic environment and not constitute an unbearable electromagnetic disturbance to anything in that environment. EMC includes two aspects: electromagnetic interference and electromagnetic immunity.

Electromagnetic interference can be divided into two categories according to the transmission paths: conducted interference and radiation interference.

Conducted interference propagates along any conductor. Therefore, any conductor, such as wire, transmission line, inductor, and capacitor, is a transmission channel for conducted interference.

Radiated interference is in the form of electromagnetic waves that propagate with energy that is inversely proportional to the square of the distance.

Electromagnetic interference must have three conditions or three elements at the same time: interference source, transmission channel, and sensitive receiver, each of which is indispensable. The solution of EMC problem mainly focuses the three elements. For users, the solution of EMC problem is mainly in transmission channels because the equipment as interference source or receiver cannot be changed.

Different electric and electronic devices have different EMC capacities because of adopting different EMC standards or classes.

## A.1 EMC features of the system

Like other electric or electronic devices, the system is not only an electromagnetic interference source but also an electromagnetic receiver. The operating principle of the system determines that it can produce certain electromagnetic interference noise. At the same time the system needs to be designed with certain anti-jamming ability to ensure the smooth working in certain electromagnetic environment. Its EMC features are shown in the following aspects:

- 1. The input current waveform is close to perfect sine waves, but the current still contains high-order harmonics that can form electromagnetic interferences, causing some impacts on the surrounding electronic equipment.
- 2. The output voltage is high-frequency PWM wave, which can form the common-mode voltage and differential mode voltage in phase-to-phase or phase-to-ground. And the leakage current will increase, which generates strong electromagnetic interferences, affecting the reliability of other electric equipment in the system.
- 3. As the electromagnetic radiation receiver, too strong external interference will lead to system malfunction or even damage, affecting the normal use of users.
- 4. In the system wiring, external interferences and system anti-interference capacity complement each other. During the process of reducing external interferences, the system anti-interference capacity is also improved.

## A.2 General EMC guidelines on the wiring of the system

The following introduces general EMC guidelines on medium voltage VFDs in several aspects including noise control, site wiring and grounding for reference in site installation, with consideration of ECM characteristics of the system where the input current and output voltage harmonics are relatively small but the voltage is high and the current is large.

#### Noise control:

All the connections to the system control terminals must use shielded wires. The shield layer of wire must be grounded near the system entrance. The ground mode is 360° loop connection formed by cable clips. It is

not allowed to connect the twisted shield layer to the ground of the VFD, which greatly decreases or loses the shield effect.

#### Site wiring

Power supply wiring: The shield layer of medium voltage power supply incoming cables of the system shall be grounded reliably. It is not allowed to route the power cables and control cables in parallel.

Device categorization: There are different electric devices in the same distribution system, which have different ability of emitting and withstanding electromagnetic noise. Therefore, it needs to categorize these devices into strong noise device and noise sensitive device. The same kind of devices needs to be placed in the same area, and the distance between devices in different categories needs to be more than 20cm.

Wiring in the control cabinet: During wiring, signal cables and power cables need to be arranged in different areas. It is not allowed to arrange them in parallel or in interlaced state at a close distance (less than 20cm) or tie them together. If the signal cables have to cross the power cables, they need to be arranged in 90 degree angle.

#### Grounding

The VFD must be grounded safely and reliably in operation. Grounding has the priority in all EMC methods because it does not only ensure the safety of equipment and persons, but also it is the simplest, most effective and lowest-cost solution for EMC problems.

Three categories of grounding: special pole grounding, common pole grounding and series-wound grounding. Different control system needs to use special pole grounding, different devices in the same control system needs to use common pole grounding, and different devices connected by the same power cables needs to use series-wound grounding.

## **Appendix B Communication expansion card**

## **B.1 Model definition and function description**

## **B.1.1 Function description**

This VFD features independent slots for installing closed-loop encoder cards and communication cards. The VFD can be equipped with various expansion cards to extend its application functions. The PG card supports applications of incremental, resolver, Sin/Cos, and UVW encoders. The communication card supports two communication modes: PROFIBUS-DP and PROFINET.





Expansion card type	Model	Description	Ordering information
PROFIBUS-DP communication card	EC-TX503D	Supports PROFIBUS-DP protocol	11023-00151
PROFINET communication card	EC-TX509C	Supports PROFINET protocol	11023-00149
5V incremental PG card	EC-PG101-05	<ul><li>5V incremental ABZ encoder</li><li>Supports differential input, up to 200kHz</li></ul>	11023-00014
12V incremental PG card	EC-PG101-12	<ul> <li>12V incremental ABZ encoder</li> <li>Supports differential, OC, and push-pull inputs, up to 100kHz</li> </ul>	11023-00003
24V incremental PG card	EC-PG101-24	<ul> <li>24V incremental ABZ encoder</li> <li>Supports differential, OC, and push-pull inputs, up to 100kHz</li> </ul>	11023-00004
Resolver PG card	EC-PG104-00	<ul> <li>Resolver encoder</li> <li>Supports pulse/direction differential input, up to 500kHz</li> <li>Supports 5V differential frequency-divided output</li> </ul>	-
Sin/Cos PG card	EC-PG102-05	<ul> <li>5V Sin/Cos encoder</li> <li>Supports pulse train reference input</li> <li>Supports the frequency-divided output of A, B, and Z</li> </ul>	11023-00005
UVW incremental PG card	EC-PG103-05	<ul> <li>5V UVW incremental encoder</li> <li>Supports the orthogonal input of A, B, and Z</li> <li>Supports the pulse input of phases U, V, and W</li> </ul>	11023-00006

#### Table B-1 Expansion card function description

## **B.2 Communication card**

## **B.2.1 PROFIBUS-DP communication card (EC-TX503D)**

## **B.2.1.1 Terminal description**





CN1	Con	nector pin	Description
	1	-	Unused
	2	-	Unused
	3	B-Line	Data+ (twisted pair 1)
	4	RTS	Request transmission
	5	GND_BUS	Isolation ground
09 08 07 08	6	+5V BUS	Isolated power supply of 5 V DC
9-pin D-type connector	7	-	Unused
	8	A-Line	Data- (twisted pair 2)
	9	-	Unused
	Housing	SHLD	PROFIBUS cable shielding line

#### Table B-2 CN1 description

#### **ZNote:**

- +5V BUS and GND\_BUS are bus terminators. Some devices, such as the optical transceiver (RS485), may need to obtain power through these pins.
- On some devices, the transmission and receiving directions are determined by RTS. In normal applications, only A-Line, B-Line, and the shield layer need to be used.

#### **B.2.1.2 Indicator description**

Table B-3 LED function description
------------------------------------

Symbol	Name	Description
		On: The expansion card is connecting with the control board.
	State indicator	Blinking (On: 500ms; Off: 500ms): The expansion card is connected to
LEDI	State mulcator	the control board properly.
		Off: The expansion card is disconnected from the control board.
	Communication	On: The expansion card is connected with the master device and data
LED2	indicator	exchange can be performed.
	indicator	Off: The expansion card is disconnected from the master device.
		On: The expansion card is offline and data exchange cannot be
		performed.
	Fault indicator	Blinking (On: 500ms; Off: 500ms): A configuration error occurs. The
		length of the user parameter data set during the initialization of the
		communication card is different from that during the network
		configuration.
LED3		Blinking (On: 250ms; Off: 250ms): User parameter data is incorrect.
		The length or content of the user parameter data set during the
		initialization of the communication card is different from that during
		the network configuration.
		Blinking (On: 125ms; Off: 125ms): An error occurs in the ASIC
		initialization of PROFIBUS-DP communication.
		Off: No fault
	Doworindicator	On: The expansion card is powered on.
LED4	Power indicator	Off: The expansion card is not powered on.

**Note:** For details about the operation, see the *Communication Card Operation Manual*.

#### **B.2.1.3 Wiring description**



Figure B-4 PROFIBUS bus connection

#### Note:

- 1. Figure B-4 shows the terminal wiring diagram. The cables are standard PROFIBUS cables, each consisting of a twisted pair and shielding layer. The shielding layers of PROFIBUS cables are directly grounded on all nodes. You can select a proper grounding mode based on the actual situation on site.
- 2. When connecting the stations, ensure that the data cables are not twisted. For systems to be used in environments with strong electromagnetic radiation, you need to use cables with shielding layers. The shielding layers can improve electromagnetic compatibility (EMC).
- 3. If shielding braid or shielding foil is used, connect the two ends of it to the protective ground and cover an area as large as possible to ensure high conductivity. In addition, data cables need to be separated from high-voltage cables.
- 4. When the data transmission rate is higher than 500kbit/s, do not use short stub. Use the plugs available in the market. You can directly connect the data input and output cables to those plugs, and the plug of the bus can be connected or disconnected at any time without interrupting data communication of other stations.

## **B.2.2 PROFINET communication card (EC-TX509C)**

#### **B.2.2.1 Terminal description**





#### **B.2.2.2 Indicator description**

Symbol	Name	Description			
	Power	On: The expansion card is powered on.			
LEDI	indicator	Off: The expansion card is not powered on.			
		Bus state indicator			
		On: No network connection			
	Stata	Blinking (On: 500ms; Off: 500ms): Network connection with the			
LED2	indicator	PROFINET controller is normal, but the communication is not			
	mulcator	established.			
		Off: The communication with the PROFINET controller has been			
		established.			
	Faultindicator	On: PROFINET diagnosis exists.			
LEDS	Fault Indicator	Off: No PROFINET diagnosis.			
		Slave ready indicator			
	State	On: TPS-1 protocol stack has started.			
LED4	indicator	Blinking (On: 500ms; Off: 500ms): TPS-1 waits for MCU initialization.			
		Off: TPS-1 protocol stack does not start.			
	Maintenance				
LED5	status	Reserved			
	indicator				
		Network port status indicator			
	State	On: The expansion card has been connected with the PC/PLC by using a			
LED6/7	indicator	network cable.			
		Off: The expansion card has not been connected with the PC/PLC.			
	Communicati	Network port communication indicator			
LED8/9	on indicator	On: The expansion card and the PC/PLC are communicating.			
		Off: The expansion card and the PC/PLC have no communication yet.			

Table B-4 LED function description

#### **B.2.2.3 Wiring description**

The PROFINET communication card can be used in a linear network topology and a star network topology.

Figure B-6 Linear network topology electrical connection



Figure B-7 Star network topology electrical connection



**Note:** For the star network topology, you need to prepare PROFINET switches.

#### **B.2.3 PROFIBUS-DP/PROFINET communication protocol**

PROFIBUS-DP/PROFINET information frame data structure

The PROFIBUS-DP/PROFINET system allows fast data exchange between the master and system devices. For system devices, data is always read and written in the master/slave mode. The system always functions as slave stations, and one address is clearly defined for each slave station. PROFIBUS transmits 16-bit packets periodically. Figure 3.1 shows the structure of the packet.

Figure B-8 Structure of PROFIBUS-DP packets

Parameter identification (PKW)			Fixed	P	rocess d (PZD) Distributa	ata ble zone		
PKW1	PKW2	PKW3	PKW4	CW SW	PZD2 PZD2	PZD3 PZD3		PZD12 PZD12

#### Parameter zone:

PKW1--Parameter identification

PKW2––Array index number

PKW3--Parameter value 1

PKW4--Parameter value 2

#### Process data:

CW--Control word (transmitted from the master to a slave. For description, see Table B-5)

SW--State word (transmitted from a slave to the master. For description, see Table B-7)

PZD--Process data (defined by users)

(When the process data is output by the master to a slave, it is a reference value; and when the process data is input by a slave to the master, it is an actual value.)

PZD zone (process data zone)

The PZD zone in a communication packet is designed for controlling and monitoring the system. The master and slave stations always process the received PZD with the highest priority. The processing of PZD takes priority over that of PKW, and the master and slave stations always transmit the latest valid data on the interfaces.

#### CWs and SWs

Using CWs is the basic method of the fieldbus system to control the variable-frequency speed regulation system devices. A CW is transmitted by the fieldbus master station to a system device. In this case, the adapter module functions as a gateway. The system device responds to the bit code information of the CW

and feeds state information back to the master through an SW.

CWs and SWs are shown in Table B-5 and Table B-7, respectively. For the bit code information related to the system equipment, refer to the operation manual.

#### **Reference value**

A system device may receive control information in multiple channels, including analog and digital input terminals, system control panel, and communication modules (such as RS485 and EC-TX503 adapter modules). To enable the control over system devices through PROFIBUS, you need to set the communication module as the controller of the system device.

The set values are shown in Table B-6.

#### Actual value

An actual value is a 16-bit word that includes information about system device operation. The monitoring function is defined through system parameters. The conversion scale of an integer transmitted as an actual value from the system device to the master depends on the set function. For more description, see the related system operation manual.

The set values are shown in Table B-8.

**Note:** A system device always checks the bytes of a CW and reference value.

## Task packet (master station $\rightarrow$ variable-frequency speed regulation system)

#### CW:

The first word in a PZD task packet is a system CW. Table B-5 describes all bits of CWs.

Bit	Name	Value	State to be entered/description
00	Lloorthoot	1	Enable heartbeat
00	Heartbeat	0	No function
01	Forward running	1	Enable forward running
01	Forward running	0	No function
02		1	Enable reverse running
02	Reverse running	0	No function
0.2	Forwardiagaing	1	Enable forward jogging
03	Forward Jogging	0	No function
0.4		1	Enable reverse jogging
04	Reverse jogging	0	No function
0.E	Coost to stop	1	Enable coast to stop
05	Coast to stop	0	No function
00	Chan	1	Enable stop
06	Stop	0	No function
07		1	Enable fault reset
07	Fault reset	0	No function
0.0	logstop	1	Enable jog stop
08	Jog stop	0	No function
00	Frabla to roug	1	Reserved
09	Enable torque	0	Reserved
10 14	Decented	1	Reserved
10-14	Reserveu	0	Reserved
15	Enable write	1	Reserved
13	chable while	0	Reserved

Table B-5 CWs

#### Reference value (REF):

The second to twelfth words in a PZD task packet are the main settings. The main frequency settings are provided by the main setting signal source.

Word	Name	Value
	Invalid	00
	Frequency reference	01
PZD2–	Torque reference	02
PZD12	Reserved	03
	PID reference	04
	PID feedback	05

#### Table B-6 Set value

Response packet (variable-frequency speed regulation system→master station)

#### SW:

The first word in a PZD response packet is a system SW. Table B-3 describes all bits of SWs.

Bit	Name	Value	State to be entered/description
00	laura li al	1	Heartbeat feedback
00	Invalid	0	No heartbeat feedback
01	Fault	1	Fault
01	Fault	0	No fault
02	Deeduterum	1	Ready to run
02	Ready to run	0	Not ready
0.2		1	Remote control state
03	Local/remote state	0	Local control state
0.4			Torque control mode
04	Control mode	0	Speed control mode
05	Forward running	1	In forward running
05		0	Not in forward running
00	Devenue	1	In reverse running
06	Reverse running	0	Not in reverse running
07	Maatau/alawa waada	1	Reserved
07	master/slave mode	0	Reserved
00	Frequency level	1	FDT output
08	detection FDT output	0	No FDT output
00	Frequency reached	1	Set frequency is reached
09		0	Set frequency is not reached
10-15	Reserved	-	-

#### Table B-7 SWs

#### Actual value (ACT):

The second to twelfth words in a PZD task packet are the main actual values. The main actual frequency values are provided by the main actual value signal source.

Word	Name	Value
PZD2- PZD12	Invalid	00
	Running frequency	01
	Output rotating speed (rpm)	02

Goodrive5000 series medium voltage variable-frequency speed regulation system

Word	Name	Value
	Input voltage	03
	Output voltage	04
	Output current	05
	Actual output torque	06
	Output power percentage	07
	Set frequency absolute value	08
	Present DSP fault	09
	Present ARM fault type 1	10
	Present ARM fault type 2	11
	Present unit fault	12
	Unit number at present fault	13
	User input terminal 1	14
	User input terminal 2	15
	User output terminal 1	16
	User output terminal 2	17
	Reserved	

#### PKW zone (parameter identification flag PKW1--numerical zone)

The PKW zone describes the processing mode of the parameter identification interface. A PKW interface is not a physical interface but a mechanism that defines the transmission mode (such reading and writing a parameter value) of a parameter between two communication ends.

Structure of the PKW zone

#### Figure B-9 Parameter identification zone

Parameter identification (PKW)				Proce	ess data	
PKW1	PKW2	PKW3	PKW4	CW SW	PZD2 PZD2	
Request No. Response No.	Parameter address	Parameter value error No.	Parameter value			

In the periodic PROFIBUS-DP communication, the PKW zone consists of four 16-bit words. The following table describes each word in the PKW zone.

First word

First word PKW 1 (16 bits)				
Bits 15-00	Task or response identification flag	0–7		

Second word

Second word PKW2 (16 bits)			
Bits 15–00	Basic parameter address	0-247	

Third word

Third word PKW3 (16 bits)			
Bits 15–00	Value (most significant word) of a parameter	00	

#### Fourth word

Fourth word PKW4 (16 bits)				
Bits 15-00	Value (least significant word) of a parameter	0–65535		

**Note:** If the master station requests the value of a parameter, the values in PKW3 and PKW4 of the packet that the master station transmits to the system are no longer valid.

#### Task request and response

When transmitting data to a slave, the master uses a request number, and the slave uses a response number to accept or reject the request. Table B-5 and Table B-6 describes the request and response functions.

Definitions of the task identification flag PKW1 are shown in Table B-9.

Red	quest No. (from the master to a slave)	Response signal	
Request No.	Function	Acceptance	Rejection
0	No task.	0	—
1	Read	1, 2	3
2	Write	1	3 or 4
3	Reserved	2	3 or 4
4	Write RAM and FLASH	1	3 or 4

Table B-9 Definitions of the task identification flag PKV	√1
---	----

Definitions of the response identification flag PKW1 are shown in Table B-10.

	Response No. (from a slave to the master)
Response No.	Function
0	Invalid parameter number
1	The parameter value cannot be modified
2	Exceeds the setting range.
3	<ul> <li>The task cannot be executed and one of the following error number is returned:</li> <li>0: Invalid parameter number</li> <li>1: The parameter value cannot be modified (read-only parameter)</li> <li>2: Exceeds the setting range</li> <li>3: Incorrect sub-index number</li> <li>4: The setting is disallowed (only reset).</li> <li>5: Invalid data type</li> <li>6: The task cannot be executed due to operation state</li> <li>7: Non-supported request</li> <li>8: The request cannot be completed due to a communication error</li> <li>9: A fault occurred to the writing operation in permanent storage area</li> </ul>
	<ul> <li>10: The request failed due to timeout</li> <li>11: The parameter cannot be assigned to PZD</li> <li>12: Cannot allocate the bits of the control word</li> <li>13: Other errors</li> </ul>
4	No permission to modify parameters

Table B-10 Definitions of the response identification flag PKW1

#### **PKW examples:**

Example 1: Reading the value of a parameter

You can set PKW1 to 1 and PKW2 to 0x0200 to read a value of motor type (the address of the motor type is 0x0200), and the value is returned in PKW4.

#### Request (master station $\rightarrow$ variable-frequency speed regulation system):



0001: Request for reading parameter values

Response (variable-frequency speed regulation system  $\rightarrow$  master station):



Example 2: Modifying a parameter value (modifying the value only on RAM)

You can set PKW1 to 0x0002 and PKW2 to 0x0200 to modify a value of motor type (the address of the motor type is 0x0200), and the value of motor type to be modified (SM: 1, AM: 0) is in PKW4.

Request (master station  $\rightarrow$  variable-frequency speed regulation system):



Response (variable-frequency speed regulation system→master station):

	PK	W1	PK	W2	PK	W3	PK	W4	C	W	ΡZ	D2	ΡZ	D3	 PZI	D12
Response	00	02	02	00	00	00	00	01	хх	хх	хх	xx	xx	xx	 хх	хх
$\sim$																

0001: Response (parameter value updated)

Example 3: Modifying a parameter value (modifying the value only on both RAM and EEPROM)

You can set PKW1 to 0x0004 and PKW2 to 0x0200 to modify a value of motor type (the address of the motor type is 0x0200), and the value of motor type to be modified (SM: 1, AM: 0) is in PKW4.

Request (master station  $\rightarrow$  variable-frequency speed regulation system):



Response (variable-frequency speed regulation system  $\rightarrow$  master station):

	PK	W1	PK	W2	PK	W3	PK	W4	C	W	PZ	D2	PZ	D3	 PZI	D12
Response	00	04	02	00	00	00	00	01	хх	xx	xx	хх	xx	хх	 хх	хх
							$\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	لے				_		_		

0001: Response (parameter value updated)

#### PZD examples:

The transmission of the PZD zone is implemented through system function code settings. For the function codes, see the related operation manual of INVT variable-frequency speed regulation system.

Example 1: Reading the process data of the system

In the example, select "01: Running frequency" in the actual value array as PZD3 to transmit, which can be achieved by setting P18.14 to 1. This operation is mandatory until the parameter is replaced by another option.

Request (master station  $\rightarrow$  variable-frequency speed regulation system):

	PKV	V1	PK	W2	PKV	V3	PKV	V4	C	W	ΡZ	D2	ΡZ	D3	•••	PZI	D12
Request	хх	Хх	хх	хх	хх	хх	хх	хх	хх	хх	хх	хх	00	01		хх	хх

Example 2: Writing process data to a system device

In the example, the value of "01: Frequency reference" in the reference array is taken out from PZD3, which can be achieved by setting P18.03 to 1. The parameters are updated with the contents of PZD3 in each request frame until another parameter is selected.

Request (master station  $\rightarrow$  variable-frequency speed regulation system):

	PK	W1	PK	W2	PK	W3	PK	W4	C	W	PZ	D2	ΡZ	D3	•••	PZI	)12
Request	хх	хх	хх	xx	хх	xx	хх	хх	хх	хх	xx	xx	00	01		хх	хх

Subsequently, the information contained in PZD3 is used as frequency reference in each request frame until another parameter is specified.

## **B.3 PG expansion card**

## B.3.1 Incremental encoder PG card (EC-PG101-05, EC-PG101-12, EC-PG101-24)

#### **B.3.1.1 Product specifications**

Cussification	Incremental encoder									
specification	EC-PG101-05	EC-PG101-12	EC-PG101-24							
Output power supply	Voltage output: 4.75V–7V; default: 5V±5%; Max. output current: 300mA	Voltage output: 11.75V–16V; default: 12V±5%; Max. output current: 350mA	Voltage output: 24 V ± 5% Max. output current: 300mA							
Input signal	Supports the A, B, and Z signal inputs of differential, open collector, and push-pull encoders. Response speed: 0–100kHz									
Output signal	Output frequency: 0–80kHz Output type: Differential output, push-pull output, open collector output, and frequency-divided output. Range: 1–256 Output impedance: 70Ω									

#### **B.3.1.2 Terminal description**



**Note:** You must choose a PG card when using PG vector control product. The function of the PG card includes processing two channels of quadrature encoder signals and supporting the Z signal input for spindle positioning. It can receive encoder signals with differential, open collector, and push-pull outputs. Additionally, the PG card is capable of frequency division output for the input encoder signals, providing two channels of differential signals as output. You can choose to output push-pull signals or open collector signals through jumper J1 or J2 according to your actual use.

The incremental encoder PG card has two 2\*4P user wiring terminals. The terminals are arranged as follows:

IA	<b>\</b> +	IA	۱-	IB+		IB-		_	0/	4+	0	4-	0	B+	OB
	P٧	VR	C	OM1	IZ+	L	Z-			С	A	0	В	C	OM1

Symbol	Name	Description							
PWR		EC-PG101-05: Voltage output: 4.75V–7V; default: 5V/±5%;							
		Max. output current: 300mA							
	Encoder working power	EC-PG101-12: Voltage output: 11.75V-16V; default							
COM1	output	12V±5%; Max. output current: 350mA							
		EC-PG101-24: Voltage output: 24V±5%; Max. output							
		current: 300mA							
IA+									
IA-		Comments the A.D. and Z signal is not a st differential second							
IB+	Encoder signal input	Supports the A, B, and Z signal inputs of differential, open							
IB-	terminal	100kHz							
IZ+		TOOKHZ							
IZ-									
OA+		Output frequency: 0–80kHz							
OA-	Differential	Output type: Differential output, push-pull output, open							
OB+	frequency-divided signal	collector output, and frequency-divided output.							
OB	output terminal	Range: 1–256							
OB-		Output impedance: 70Ω							
OA	Frequency-divided								
OB	push-pull signal and	The output signal type is selected by the jumper 11 or 12							
COM1	open collector signal	l							
COMI	output terminal								

Table B-11 Terminal function description

**∠Note:** The PG card does not connect PE to the earth internally, you can ground it during use.

The frequency division coefficient of the incremental encoder PG card is determined by the DIP switch on the card. The DIP switch consists of 8 bits. The frequency division coefficient is determined by adding 1 to the binary number represented by the switch settings. The switch marked "1" represents the least significant bit (LSB), while the switch marked "8" represents the most significant bit (MSB). When the switch is toggled to the ON position, the corresponding bit is valid and represents "1"; otherwise, it represents "0."

Decimal	Binary	Frequency division coefficient
0	0000000	1
1	0000001	2
2	0000010	3
m		m+1
255	11111111	256

Table B-12 Frequency division coefficients

#### **B.3.1.3 Wiring description**

#### Figure B-12 Wiring of incremental encoder PG card



#### **∕**Note:

- A PG card signal cable and a power cable must be routed separately and disallow parallel routing.
- To avoid interference from encoder signals, use a shielded cable for the PG card signal.
- The shield layer of the encoder shield cable should be connected to the earth (such as the PE of VFD), and it must be connected to earth only at one end to avoid signal interference.
- If the PG card uses frequency-divided output when externally connecting to a user power supply, the voltage should be less than 24V; otherwise the PG card will be damaged.
- You can set the output voltage by adjusting the 12–15V incremental encoder PG card potentiometer (clockwise for voltage increases) according to actual needs, and the force should not be too great when rotating the potentiometer.

#### **B.3.1.4 Input application connection**

The wiring for the differential output encoder is as follows:



The wiring for the open collector output encoder is as follows:





The wiring for the push-pull output encoder is as follows:

Figure B-15 Wiring for push-pull output encoder



**Note:** When used with the spindle positioning VFD, the Z signal must be connected, and the wiring method is the same as that for the A and B signals.

#### **B.3.1.5 Output application connection**

The wiring for PG card frequency-divided differential output is as follows:

B-16 Wiring for PG card frequency-divided differential output



The wiring for PG card frequency-divided open collector output is as follows:



Figure B-17 Wiring for PG card frequency-divided open collector output

Note: During open collector output, PWR at J1 and that at J2 are short connected to COA and COB.

The wiring for PG card frequency-divided push-pull output is as follows:





#### **Note**:

- Note: During push-pull output, PWR at J1 and that at J2 are short connected to HOA and HOB.
- Incremental encoder PG cards are mainly used to closed-loop vector control on asynchronous motors.

## B.3.2 Resolver PG card (EC-PG104-00)

#### **B.3.2.1 Terminal description**

EC-PG104-00 appearance



The resolver encoder card has one signal cable interface and three user wiring terminals, as shown in the following figure.





#### Table B-13 Input signal terminal function description

PIN	Symbol	Name	Description
1	SIN+		
2	SIN-	Encoder signal	Decommended resolver transformation ratio: 0.5
3	COS+	input	
8	COS-		
4	GND	-	-
5	Empty	-	-
6	EXC+	Encoder	Supports resolvers with a frequency range of 10–20 kHz
7	EXC-	excitation signal	and an excitation voltage of 7Vrms.
9	Empty	-	-

#### Table B-14 Output signal terminal function description

Symbol	Name	Description
OUT_A	Encoder signal	
	frequency-divided	
001_8	output	

#### **B.3.2.1** Wiring description



#### **/**Note:

- The encoder cable must use shielded twisted-pair cables, with shielding effectiveness of over 90%, or a braid density of the shielding layer not less than 80%.
- Encoder signals are weak electrical signals and must be routed separately from power cables, without any overlap.
- It is recommended to connect the encoder cable on the VFD side directly to the PG card terminal, with the shielding layer connected nearby to the housing, and wrapped with a ferrite core to enhance anti-interference capability.
- The shielding layer of the encoder cable on the motor side should be left floating and must not come into contact with the metal housing of the motor.
- If the encoder cable needs to be connected through a terminal block, a separate terminal box should be provided for the encoder cable only, and it should not be shared with other signal cables.

# B.3.3 Sin/Cos encoder PG card (EC-PG102-05) and UVW encoder PG card (EC-PG103-05)

#### **B.3.3.1 Product features**

Creation	Sin/Cos encoder PG card	UVW encoder PG card						
Specification	EC-PG102-05	EC-PG103-05						
Frequency division coefficient	1 (Without a frequency-division switch)	1–256 (With a frequency-division switch)						
Output power supply	<ul> <li>Adjustable voltage range: 4.75V–7V</li> <li>Default setting: 5V/±5%</li> <li>Max. output current: 300mA</li> </ul>	<ul> <li>Adjustable voltage range: 4.75V-7V</li> <li>Default setting: 5V/±5%</li> <li>Max. output current: 300mA</li> </ul>						
Output signal	<ul> <li>Output form: Two quadrature frequency division differential outputs, and open collector output</li> <li>Open collector output resistance: 70Ω</li> </ul>	<ul> <li>Output form: Two quadrature differential outputs, and open collector output</li> <li>Open collector output resistance: 70Ω</li> </ul>						

**Note:** You can choose the output voltage according to your actual use. When transmitting encoder signals over long distances, the output supply voltage can be adjusted using a potentiometer (the voltage adjustment method is the same as that for the incremental encoder card) to extend the wiring distance.

#### B.3.3.2 Terminal and dial switch description

EC-PG102-05 appearance	EC-PG103-05 appearance

The UVW encoder PG card, like the Sin/Cos encoder PG card, has one signal cable interface and seven user terminals, as shown in the following figure.



OA +	OA-	OB +	OB-
OA	OB	COM1	

## DB15

Frequency-divided output interface

**/**Note:

- OA+, OA-, OB+, and OB- are differential output signal terminals, while OA, OB, and COM1 are open collector signal output terminals.
- The PG card does not connect PE to the earth internally, you can ground it during use.
- The Sin/Cos encoder and UVW encoder PG cards have the similar output signal wiring method as the incremental encoder PG card, but they do not support push-pull output.

The DB15 three-row female interface is the encoder signal input interface. The following table shows the PG card interface signal arrangement sequence.

VFD interface	SIN/COS	UVW
5	A+	A+
6	A-	A-
8	B+	B+
1	В-	В-
3	R+	Z+
4	R-	Z-
11	C+	U+
10	C-	U-
12	D+	V+
13	D-	V-
Goodrive5000 series medium voltage variable-frequency speed regulation system

Communication expansion card

VFD interface	SIN/COS	UVW
9	PWR	PWR
7	GND	GND
14	Empty	W
15	Empty	W-
2	Empty	Empty

**Note**:

- When using the above two PG cards, the signal arrangement of the Sin/Cos or UVW encoder must correspond to the respective signal arrangement of the PG card before inserting the DB15 male connector into the DB15 female connector on the PG card.
- The frequency division coefficient setting for the UVW encoder PG card is the same as that for the incremental encoder.
- The Sin/Cos encoder PG card and the UVW encoder PG card are primarily used for closed-loop vector control of synchronous motors.
- The UVW encoder PG card supports 5V incremental encoder signal processing, and the input wiring method is the same as that for the incremental encoder PG card. It is mainly used for the A, B, Z, PWR, and GND ports on the DB15 connector.

## **Appendix C Function parameter list**

## C.1 Introduction to function code setting

The function parameters are divided into 21 groups (P00–P20) by function, and each group includes several function codes. A three-level menu style is applied to the function codes. For example, "P08.08" indicates the 8th function code in the P00.08 group. P29 group consists of factory function parameters, which are user inaccessible.

The function group numbers correspond to the level-1 menus, the function codes correspond to the level-2 menus, and the function parameters correspond to the level-3 menus.

1. The content of the function code table is as follows:

Column 1 "Function code ": Code of the function group and parameter.

Column 2 "Name": Full name of the function parameter.

Column 3 "Description": Detailed description of the function parameter.

Column 4 "Setting range": The valid setting value range of the function parameters, displayed on the touch screen.

Column 5 "Default": Initial value set in factory.

Column 6 "Modify": Whether the parameter can be modified, and conditions for the modification.

"O" indicates that the value of the parameter can be modified when the VFD is in stopped or running state.

"O" indicates that the value of the parameter cannot be modified when the VFD is in running state.

"•" indicates that the value of the parameter is detected and recorded, and cannot be modified.

(The VFD automatically checks and constrains the modification of parameters, which helps prevent incorrect modifications.)

2. The parameters adopt the decimal system (DEC). If the hexadecimal system is adopted, all bits are mutually independent on data during parameter editing, and the setting ranges at some bits can be hexadecimal (0–F).

3. "Default" indicates the factory setting of the function parameter. If the value of the parameter is detected or recorded, the value cannot be restored to the factory setting.

4. To better protect parameters, the VFD provides the password protection function. After setting the user password, the system will enter into the user password authentication state before the touch screen enters into the user interface. You need to enter the correct user password to enter the interface. For the factory parameters, you need to enter the correct factory password to enter the interface. (You are not advised to modify the factory parameters. Incorrect parameter setting may cause operation exceptions or even damage to the VFD.) If password protection is not in locked state, you can change the password any time.

5. When you modify function parameters through serial communication, the user password protection function is also applicable and compliant with the same rule.

Function code	Name	Description	Setting range	Default	Modify
P00 group	Basic functions				
P00.00	Control mode selection	0: Space voltage vector control 1: Asynchronous sensorless vector control 2: Synchronous sensorless vector control 3: Vector control	0-3	0	0
P00.01	Channel of running commands	0: Local 1: Terminal 2: Communication 3: Master	0-3	0	0
P00.02	Current communication command channel	0: Modbus 1: Fieldbus 2: Ethernet	0-2	0	0
P00.03	UP/DOWN setting	0: Valid, save the setting at power-off. 1: Valid, do not save the setting at power-off. 2: Invalid 3: Valid during running, clear at stop	0–3	0	0
P00.04	UP/DOWN adjustment	-120.00-120.00Hz	-120.00- 120.0	0.00Hz	•
P00.05	Speed reference mode	0: Speed mode 1: Torque mode 2: Slave speed mode 3: Slave torque mode	0-3	0	O
P00.06	Setting channel of frequency A command	0: Function code 1: Al1 2: Al2 3: Al3 4: Al4 5: Multi-step speed running 6: PID control 7: Modbus 8: Fieldbus	0-8	0	0
P00.07	Setting channel of frequency B command	0: Al1 1: Al2 2: Al3 3: Al4	0-3	0	0
P00.08	Reference object of frequency B command	0: Max. output frequency 1: Frequency A command	0-1	0	0

P00.09         Combination mode of setting source         0: A 1: B 2: A+B 3: Max(A, B)         0-3         0           P00.10         Max. output frequency         P00.11-200.00Hz         P00.11- 200.00         50.00Hz           P00.11         Upper limit of running frequency         P00.12- frequency         P00.12- frequency         P00.12- p00.10         0.00Hz         50.00Hz           P00.12         Lower limit of running frequency         0.012-P00.10 (Max. output frequency)         0.00-P00.10         0.00Hz           P00.13         Function code setting frequency         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         0.00Hz           P00.14         Function code setting frequency         0.0Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         Torque setting         0.Function code 1: Al1 2: Al2 3: Al3         0-8         0           P00.15         Function code setting torque         2:00.0%-200.0%         -200.0-200.0         30.0%           P00.15         Function code setting torque         -200.0%-200.0%         -200.0-200.0         30.0%           P00.16         ACC time 1         0.1-3600.0s         0.1-3600.0         Model depended           P00.17         DEC time 1         0.1-3600.0s         0.1-3600.0         0-2         0	code	Name	Description	Setting range	Default	Modify
P00.09Combination mode of setting source1: B 2: A+B 3: Max(A, B)0-30P00.10Max. output frequencyP00.11-200.00HzP00.11- 200.0050.00HzP00.11Upper limit of running frequencyP00.12-P00.10 (Max. ouput frequency)P00.12- P00.1050.00HzP00.12Lower limit of running frequency0.00Hz-P00.11 (Upper limit of running frequency)0.00-P00.100.00HzP00.13Function code setting frequency0.00Hz-P00.10 (Max. output frequency)0.00-P00.1050.00HzP00.13Function code setting frequency0.0Hz-P00.10 (Max. output frequency)0.00-P00.1050.00HzP00.14Function code setting 5: Reserved 6: Multi-step speed running 7: Modbus 8: Fieldbus0-80P00.15Function code setting torque-200.0%-200.0%-200.0-200.030.0%P00.16ACC time 10.1-3600.0s0.1-3600.0Model dependedP00.17DEC time 10.1-3600.0s0.1-3600.0Model dependedP00.18Running direction 1: Run at the default direction. 2: Disable reverse running0-20P00.19Carrier frequency0.5-2.00.7kHzP00.19Carrier frequency0.5-2.00.7kHz			0: A			
P00.09         setting source         2: A+B         0-3         0           3: Max(A, B)		Combination mode of	1: B			
Image: set of the set	P00.09	setting source	2: A+B	0-3	0	$\bigcirc$
P00.10         Max. output frequency         P00.11-200.00Hz         P00.11- 200.00         F00.11- 200.00         F00.12- F00.12         P00.12- F00.12         P00.12- F00.12         P00.12- F00.12         P00.12- F00.12         P00.12- F00.13         P00.12- F00.13         P00.12- F00.13         P00.12- F00.13         P00.12- F00.10         COOPOL2- F00.10         COOPOL2- F00.11         COOPOL2- F00.12         COOPOL2- F00.12         COOPOL2- F00.12         COOPOL2- F00.12         COOPOL2- F00.12         COOPOL2- F00.12         COOPOL2- F00.12         COOPOL2- F00.13         COOPOL2- F00.13 <thcoopol2- F00.13</thcoopol2- 		_	3: Max(A, B)			
P00.10         frequency         P00.11-200.00H2         200.00         50.00H2           P00.11         Upper limit of running frequency         P00.12-P00.10 (Max. ouput frequency)         P00.12- P00.10         P00.12- P00.10         F00.12- P00.10         F00.12- P00.10         F00.12- P00.10         F00.12- P00.10         F00.12- P00.10         F00.12- P00.10         F00.10         F00.12- P00.10         F00.10         F00.12- P00.10         F00.10         F00.12- P00.10         F00.10         F00.12- P00.10         F00.10         F00.10         F00.12         F00.10         F00.10         F00.12         F00.10         F00.10         F00.10         F00.10         F00.10         F00.10         F00.10         F00.10         F00.11         F00.10         F00.10         F00.11         F00.10         F00.10         F00.11         F00.10         F00.10         F00.11         F00.12         F00.11         F00.13         F00.13         F00.13         F00.13         F00.13         F00.13         F00.13         F00.13         F00.13         F00.14         F00.13	D00 10	Max. output		P00.11-		
P00.11         Upper limit of running frequency         P00.12-P00.10 (Max. ouput frequency)         P00.12- P00.10         P00.12- P00.10         P00.10         P00.12- P00.10           P00.12         Lower limit of running frequency         0.00Hz-P00.11 (Upper limit of frequency)         0.00-P00.10         0.00Hz           P00.13         Function code setting frequency         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         Function code setting frequency         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         Function code setting 1: Al1         0.00Hz         0.00-P00.10         50.00Hz           P00.14         Torque setting 4: Al4         3: Al3         0-8         0         0           P00.15         Function code setting torque         2:00.0%-200.0%         -200.0-200.0         30.0%           P00.16         ACC time 1         0.1-3600.0s         0.1-3600.0         Model depended           P00.17         DEC time 1         0.1-3600.0s         0.1-3600.0         Model depended           P00.18         Running direction 1: Run at the opposite direction. 2: Disable reverse running         0-2         0           P00.19         Carrier frequency         0.5-2.0KHz         0.5-2.0         0.7kHz	P00.10	frequency	P00.11-200.00Hz	200.00	50.00HZ	0
P00.11         frequency         frequency         P00.10         0.00112           P00.12         Lower limit of running frequency         0.00Hz-P00.11 (Upper limit of running frequency)         0.00-P00.10         0.00Hz           P00.13         Function code setting frequency)         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         Function code setting frequency)         0: Function code         1: Al1         2: Al2         3: Al3           P00.14         Torque setting         4: Al4         0-8         0         0           Function code setting reduction code setting         5: Reserved         0: Multi-step speed running         0.00-200.0         30.0%           P00.15         Function code setting torque         -200.0%-200.0%         -200.0-200.0         30.0%         0.1-3600.0           P00.16         ACC time 1         0.1-3600.0s         0.1-3600.0         0.1-3600.0         Model depended           P00.17         DEC time 1         0.1-3600.0s         0.1-3600.0         0.1-3600.0         Model depended           P00.18         Running direction         1: Run at the default direction.         0-2         0         0           P00.19         Carrier frequency         0.5-2.0kHz         0.5-2.0         0.7kHz <td< td=""><td>P00 11</td><td>Upper limit of running</td><td>P00.12–P00.10 (Max. ouput</td><td>P00.12-</td><td>50 0047</td><td></td></td<>	P00 11	Upper limit of running	P00.12–P00.10 (Max. ouput	P00.12-	50 0047	
P00.12         Lower limit of running frequency         0.00Hz-P00.11 (Upper limit of running frequency)         0.00-P00.10         0.00Hz           P00.13         Function code setting frequency         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         Frequency         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         Frequency         0.00Hz         0.00-P00.10         50.00Hz           P00.14         Frequency         0.00Hz         50.00Hz         50.00Hz           P00.14         Frequency         0.00Hz         50.00Hz         50.00Hz           P00.14         Frequency         0.00Hz         50.00Hz         50.00Hz           P00.14         Torque setting         5.11         5.12         5.12           P00.15         Function code setting torque         -200.0%-200.0%         -200.0-200.0         30.0%           P00.16         ACC time 1         0.1-3600.0s         0.1-3600.0         Model depended           P00.17         DEC time 1         0.1-3600.0s         0.1-3600.0         Model depended           P00.18         Running direction         1: Run at the default direction. 2: Disable reverse running         0-2         0           P00.19         <	P00.11	frequency	frequency)	P00.10	50.00HZ	0
100.12         frequency         running frequency)         0.00 + 00.10         0.001/2           P00.13         Function code setting frequency         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         Frequency         0: Function code 1: Al1 2: Al2 3: Al3         0.00-P00.10         50.00Hz           P00.14         Torque setting         4: Al4 5: Reserved 6: Multi-step speed running 7: Modbus 8: Fieldbus         0-8         0           P00.15         Function code setting torque         -200.0%-200.0%         -200.0-200.0         30.0%           P00.16         ACC time 1         0.1-3600.0s         0.1-3600.0         Model depended           P00.17         DEC time 1         0.1-3600.0s         0.1-3600.0         Model depended           P00.18         Running direction         1: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running         0-2         0           P00.19         Carrier frequency         0.5-2.0kHz         0.5-2.0         0.7kHz	P00 12	Lower limit of running	0.00Hz–P00.11 (Upper limit of	0 00_P00 10	0.00Hz	$\bigcirc$
P00.13         Function code setting frequency         0.00Hz-P00.10 (Max. output frequency)         0.00-P00.10         50.00Hz           P00.14         frequency         frequency)         0: Function code	1 00.12	frequency	running frequency)	0.00-1 00.10	0.00112	
Pointfrequencyfrequency)one for for and both and b	P00 13	Function code setting	0.00Hz–P00.10 (Max. output	0 00-P00 10	50 00Hz	$\bigcirc$
P00.14       O: Function code       1: Al1       2: Al2       3: Al3       4: Al4       0-8       0	1 00.15	frequency	frequency)	0.00 1 00.10	50.00112	
P00.14       I: Al1       I: Al2       I: Al3         P00.14       Torque setting       4: Al4       0-8       0         5: Reserved       6: Multi-step speed running       0-8       0         6: Multi-step speed running       7: Modbus       0       0         8: Fieldbus       1: Al4       0       0       0         P00.15       Function code setting torque       -200.0%-200.0%       -200.0-200.0       30.0%       0         P00.16       ACC time 1       0.1-3600.0s       0.1-3600.0       0.1-3600.0       Model depended         P00.17       DEC time 1       0.1-3600.0s       0.1-3600.0       Model depended       0         P00.18       Running direction       1: Run at the default direction.       0-2       0       0         P00.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz       0         P00.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz       0			0: Function code			
P00.14       Torque setting       2: Al2       3: Al3       0-8       0         900.14       Torque setting       4: Al4       0-8       0         5: Reserved       6: Multi-step speed running       0       0         6: Multi-step speed running       7: Modbus       0       0         900.15       Function code setting torque       -200.0%-200.0%       -200.0-200.0       30.0%         900.16       ACC time 1       0.1-3600.0s       -200.0-200.0       30.0%         900.17       DEC time 1       0.1-3600.0s       0.1-3600.0       Model depended         900.18       Running direction       1: Run at the default direction.       0.1-3600.0       Model depended         900.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz         900.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz			1: AI1			
P00.14Torque setting3: Al3 4: Al4 5: Reserved 6: Multi-step speed running 7: Modbus 8: Fieldbus0-80P00.15Function code setting torque-200.0%-200.0% 0.1-3600.0-200.0-200.030.0%-P00.16ACC time 1 0.1-3600.0s0.1-3600.0s0.1-3600.0Model depended-P00.17DEC time 1 0.1-3600.0s0.1-3600.0s0.1-3600.0-Model depended-P00.18Running direction 1: Run at the opposite direction. 2: Disable reverse running0-20-P00.19Carrier frequency0.5-2.0kHz0.5-2.00.7kHz-P00.19Carrier frequency0.5-2.0kHz0.5-2.00.7kHz-			2: AI2			
P00.14       Torque setting       4: Al4       0-8       0         5: Reserved       5: Reserved       1       1         6: Multi-step speed running       7: Modbus       1       1         7: Modbus       8: Fieldbus       1       1         P00.15       Function code setting torque       -200.0%-200.0%       -200.0-200.0       30.0%         P00.16       ACC time 1       0.1-3600.0s       -1-3600.0       Model depended         P00.17       DEC time 1       0.1-3600.0s       0.1-3600.0       Model depended         P00.18       Running direction       1: Run at the default direction.       0.1-3600.0       Model depended         P00.18       Running direction       1: Run at the opposite direction.       0-2       0       1         P00.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz       1         P00.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz       1			3: AI3			
5: Reserved       5: Reserved       5: Reserved       5: Multi-step speed running       6: Multi-step speed running <td< td=""><td>P00.14</td><td>Torque setting</td><td>4: AI4</td><td>0-8</td><td>0</td><td><math>\bigcirc</math></td></td<>	P00.14	Torque setting	4: AI4	0-8	0	$\bigcirc$
6: Multi-step speed running 7: Modbus 8: Fieldbus			5: Reserved			
P00.15Function code setting torque-200.0%-200.0%-200.0-200.030.0%P00.16Function code setting torque-200.0%-200.0%-200.0-200.030.0%1P00.16ACC time 1-1-3600.0s $0.1-3600.0$ Model depended1P00.17DEC time 1 $0.1-3600.0$ s $0.1-3600.0$ Model dependedModel dependedP00.17DEC time 1 $0.1-3600.0$ s $0.1-3600.0$ Model dependedModel dependedP00.18Running direction $1.3600.0$ s $0.1-3600.0$ Model dependedModel dependedP00.19Carrier frequency0.5-2.0kHz $0.5-2.0$ $0.7$ kHz $0.5-2.0$ $0.7$ kHzP00.19Carrier frequency $0.5-2.0$ kHz $0.5-2.0$ $0.7$ kHz $0.7$ kHzP00.19Carrier frequency $0.5-2.0$ kHz $0.5-2.0$ $0.7$ kHz $0.5-2.0$			6: Multi-step speed running			
P00.15Function code setting torque $-200.0\%-200.0\%$ $-200.0-200.0$ $30.0\%$ P00.16ACC time 1 $-200.0\%-200.0\%$ $-200.0-200.0$ $30.0\%$ P00.17ACC time 1 $0.1-3600.0s$ $0.1-3600.0s$ $0.1-3600.0s$ P00.17DEC time 1 $0.1-3600.0s$ $0.1-3600.0s$ $Model$ dependedP00.18Running direction $1:Run at the default direction.1:Run at the opposite direction.2: Disable reverse running0-20P00.19Carrier frequency0.5-2.0kHz0.5-2.00.7kHzP00.19Carrier frequency0.5-2.0kHz0.5-2.00.7kHz$			7: Modbus			
P00.15Function code setting torque-200.0%-200.0%-200.0-200.030.0%P00.16ACC time 10.1-3600.0s0.1-3600.0Model dependedP00.17DEC time 10.1-3600.0s0.1-3600.0Model dependedP00.18Running direction0: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running0-20P00.19Carrier frequency0.5-2.0kHz0.5-2.00.7kHzP00.19Image: set of the			8: Fieldbus			
FoundtorqueDescriptionDescriptionModel dependedP00.16ACC time 10.1–3600.0s0.1–3600.0Model dependedP00.17DEC time 10.1–3600.0s0.1–3600.0Model dependedP00.18Running direction1: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running0–20P00.19Carrier frequency0.5–2.0kHz0.5–2.00.7kHzI: Rotary autotuning1: Rotary autotuning0.5–2.00.7kHz	P00.15	Function code setting	-200.0%-200.0%	-200.0-200.0	30.0%	$\bigcirc$
P00.16ACC time 10.1-3600.0sModel dependedP00.17DEC time 10.1-3600.0s0.1-3600.0Model dependedP00.18Running direction1: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running0-20P00.19Carrier frequency0.5-2.0kHz0.5-2.00.7kHzI: Rotary autotuning1: Rotary autotuning0: No operation0.1-3600.0		torque		20010 20010		0
P00.17     DEC time 1     0.1–3600.0s     Model depended       P00.18     Running direction     1: Run at the default direction. 1: Run at the opposite direction. 2: Disable reverse running     0-2     0       P00.19     Carrier frequency     0.5–2.0kHz     0.5–2.0     0.7kHz       I: Rotary autotuning     1: Rotary autotuning     0: No operation     0.1–3600.0	P00.16	ACC time 1	0.1–3600.0s	0.1-3600.0	Model	$\bigcirc$
P00.17       DEC time 1       0.1–3600.0s       Model depended         P00.18       Running direction       0: Run at the default direction.       0–2       0         P00.19       Carrier frequency       0.5–2.0kHz       0.5–2.0       0.7kHz         I: Rotary autotuning       0: No operation       1: Rotary autotuning       0.5–2.0       0.7kHz					depended	
P00.18       Running direction       0: Run at the default direction.       0-2       0         P00.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz         0: No operation       1: Rotary autotuning       1: Rotary autotuning       0: No	P00.17	DEC time 1	0.1–3600.0s	0.1-3600.0	Model	$\bigcirc$
P00.18       Running direction       1: Run at the opposite direction.       0-2       0         2: Disable reverse running       2: Disable reverse running       0.5-2.0       0.7kHz         P00.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz         1: Rotary autotuning       1: Rotary autotuning       0.5-2.0       0.7kHz					depended	
P00.18       Running direction       1: Run at the opposite direction.       0-2       0         2: Disable reverse running       2: Disable reverse running       0.5-2.0       0.7kHz         P00.19       Carrier frequency       0.5-2.0kHz       0.5-2.0       0.7kHz         0: No operation       1: Rotary autotuning       0.5-2.0       0.7kHz	D00 10	Describe discribed	0: Run at the default direction.	0.0	0	
P00.19     Carrier frequency     0.5–2.0kHz     0.5–2.0     0.7kHz       0: No operation     1: Rotary autotuning	P00.18	Running direction	1: Run at the opposite direction.	0-2	0	0
P00.19     Carrier frequency     0.5–2.0 kHz     0.5–2.0     0.7kHz       0: No operation     1: Rotary autotuning			2: Disable reverse running		0.71.11	
0: No operation	P00.19	Carrier frequency	0.5–2.0kHz	0.5-2.0	0.7kHz	O
			0: No operation			
			1: Rotary autotuning			
2: Encoder autotuning			2: Encoder autotuning			
S: Motor frequency drop rate	D00 20	Motor parameter	3: Motor frequency drop rate		0	
autotuning autotuning 0-5 0	P00.20	autotuning	autotuning	0-5	0	O
4: Power frequency and variable			4: Power frequency and variable			
rrequency switching time			frequency switching time			
autotuning			autotuning			
p: Static autotuning (reserved)			D: No operation			
U: NO Operation		Eunction parameter	U. NO OPERATION			
P00.21 restore 2: Clear fault files 0–3 0	P00.21	rectors	2: Cloar fault filos	0–3	0	$\bigcirc$
2: Clear amostor records		restore	2. Clear ammeter records			
			o. levalid			
V: IIIVallu AV/P function 1: Valid during the whole		AV/D function	U. IIIVallu			
P00.22 Avertain 1: valid during the whole 0–2 1	P00.22	AVRIUNCTION	1. valid during the whole	0–2	1	$\bigcirc$
2: Disable during DEC		selection	2. Disable during DEC			

Function code	Name	Description	Setting range	Default	Modify
P00.23	Encoder autotuning frequency	0.00Hz-P00.10	0.00-P00.10	10.00Hz	•
P00.24	Forward rotation upper-limit frequency in torque control	0.00Hz-P00.10	0.00-P00.10	50.00Hz	0
P00.25	Reverse rotation upper-limit frequency in torque control	0.00Hz–P00.10	0.00-P00.10	50.00Hz	0
P00.26	Electromotive torque upper limit	0.0–200.0%	0.0-200.0	100.0%	0
P00.27	Power generation torque upper limit	0.0–200.0%	0.0-200.0	100.0%	0
P01 group	Start and stop control				
P01.00	Braking mode	0: DC braking 1: Dual-frequency braking	0-1	0	O
P01.01	Start mode	0: Direct start 1: Start after DC braking 2: Start after rotating speed tracking	0-2	0	O
P01.02	Starting frequency of direct start	0.00–10.00Hz	0.00-10.00	0.10Hz	O
P01.03	Starting frequency hold time	0.0–50.0s	0.0-50.0	0.0s	O
P01.04	Braking current before start	0.0–120.0% (of the VFD rated current)	0.0-120.0	0.0%	O
P01.05	Braking time before start	0.0–50.0s	0.0-50.0	0.0s	O
P01.06	ACC and DEC mode	0: Linear type 1: S curve	0-1	0	O
P01.07	S curve starting segment proportion	1.0–40.0% (ACC/DEC time)	1.0-40.0	30.0%	O
P01.08	S curve ending segment proportion	1.0–40.0% (ACC/DEC time)	1.0-40.0	30.0%	O
P01.09	Stop mode	0: Decelerate to stop 1: Coast to stop	0-1	0	0
P01.10	Starting frequency of DC braking at stop	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz	0
P01.11	Wait time before DC braking at stop	0.0–50.0s	0.0-50.0	0.0s	0
P01.12	DC braking current at stop	0.0–120.0% (of the VFD rated current)	0.0-120.0	0.0%	0
P01.13	DC braking time at stop	0.0–50.0s	0.0-50.0	0.0s	0
P01.14	Torque of frequency superposition braking	0.0%–50.0%	0.0-50.0	30.0%	0

Function code	Name	Description	Setting range	Default	Modify
P01.15	Enabling voltage of frequency	1000-1500V	1000-1500	1130V	0
P01.16	Dual-frequency frequency of frequency superposition braking	200.0–500.0Hz	200.0-500.0	300.0Hz	0
P01.17	Dual-frequency current-limit point of frequency superposition braking	0.0–100.0%	0.0-100.0	0.0%	0
P01.18	Dual-frequency voltage-limit point of frequency superposition braking	50.0%-80.0%	50.0-80.0	80.0%	0
P01.19	Proportional coefficient of frequency superposition braking	0–65535	0-65535	5	0
P01.20	Integral coefficient of frequency superposition braking	0–65535	0-65535	2	0
P01.21	Adjusting multiple of frequency superposition braking	0–65535	0-65535	2	O
P01.22	Reserved	0–65535	0-65535	0	
P01.23	Reserved	0–65535	0-65535	0	
P01.24	FWD/REV running deadzone time	0.0-3600.0s	0.0-3600.0	1.0s	0
P01.25	Action selected when running frequency less than frequency lower limit (valid when frequency lower limit greater than 0)	0: Run at the frequency lower limit 1: Stop 2: Sleep	0-2	0	0
P01.26	Power-off restart selection	0: Disable 1: Enable	0-1	0	0
P01.27	Sudden power-off time	0.00–50.00s	0.00-50.00	1.00s	O
P01.28	Wait time for restart after power-off	0.0–3600.0s (valid when P01.17=1)	0.0-3600.0	1.0s	0
P01.29	Medium voltage switch action at stop	0: Cut off medium voltage during stop 1: Not cut off medium voltage during stop	0-1	1	0
P01.30	Waiting time of switching-on allowing	0.0-3600.0s	0.0-3600.0	10.0s	0

Function code	Name	Description	Setting range	Default	Modify
P01.31	Running ready waiting time	0.0–3600.0s	0.0-3600.0	10.0s	0
P01.32	Pull-in current at zero frequency start	0.0–100.0%	0.0-100.0	20.0%	0
P01.33	Cut-off frequency at zero frequency start	P01.02-P14.17	P01.02- P14.17	0.00Hz	0
P01.34	Exit time of pull-in current at zero frequency start	0.00–40.00s	0.00-40.00	1.00s	0
P01.35	Command source of coast to stop	0: None 1: UDP 2: Internally command 3: Terminal 4: Modbus 5: PROFIBUS	0–5	0	•
P01.36	Command source of decelerate to stop	0: None 1: UDP 2: Terminal 3: Modbus 4: PROFIBUS	0-4	0	•
P02 group	Motor parameter 1				
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0-3	0	0
P02.01	Rated power of AM 1	4–50000kW	4–50000	Model depended	O
P02.02	Rated frequency of AM 1	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P02.03	Rated speed of AM 1	1–36000rpm	1-36000	Model depended	O
P02.04	Rated voltage of AM 1	0-20000V	0-20000	Model depended	O
P02.05	Rated current of AM 1	0.1–1000.0A	0.1-1000.0	Model depended	O
P02.06	Stator resistance of AM 1	0.001–65.535Ω	0.001– 65.535	Model depended	0
P02.07	Rotor resistance of AM 1	0.001–65.535Ω	0.001– 65.535	Model depended	0
P02.08	Stator and rotor leakage inductance of AM 1	0.1–6553.5mH	0.1-6553.5	Model depended	0
P02.09	Stator and rotor mutual inductance of AM 1	0.1–6553.5mH	0.1-6553.5	Model depended	0

Function code	Name	Description	Setting range	Default	Modify
P02.10	No-load current of AM 1	0.01–655.35A	0.01-655.35	Model depended	0
P02.11	Rated power of SM 1	4–50000kW	4–50000	Model depended	O
P02.12	Rated frequency of SM 1	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P02.13	Rated speed of SM 1	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P02.14	Number of pole pairs of SM 1	1-50	1–50	2	O
P02.15	Rated voltage of SM 1	0-20000V	0–20000	Model depended	O
P02.16	Rated current of SM 1	0.1–1000.0A	0.1-1000.0	Model depended	$\bigcirc$
P02.17	Stator resistance of SM 1	0.001–65.535Ω	0.001– 65.535	Model depended	0
P02.18	Direct-axis inductance of SM 1	0.01–655.35mH	0.01-655.35	Model depended	0
P02.19	Quadrature-axis inductance of SM 1	0.01–655.35mH	0.01-655.35	Model depended	0
P02.20	Counter-emf constant of SM 1	0-20000	0–20000	9700	0
P03 group	Vector control				
P03.00	Speed-loop proportional gain 1	0-100	0-100	5	0
P03.01	Speed-loop integral time 1	0.01–10.00s	0.01-10.00	0.10s	0
P03.02	Low-point frequency for switching	0.00Hz-P03.05	0.00-P03.05	5.00Hz	0
P03.03	Speed-loop proportional gain 2	0-100	0-100	5	0
P03.04	Speed-loop integral time 2	0.01–10.00s	0.01-10.00	0.10s	0
P03.05	High-point frequency for switching	P03.02–P00.10 (Max. ouput frequency)	P03.02- P00.10	10.00Hz	0
P03.06	Current-loop proportional coefficient P	0-65535	0–65535	500	0
P03.07	Current-loop integral coefficient I	0–65535	0-65535	500	0
P03.08	Speed loop filter time	0.000–1.000s	0.000-1.000	0.002s	$\bigcirc$
P03.09	VC slip compensation coefficient	50.0%–200.0%	50.0-200.0	100.0%	0
P03.10	Reserved	0–65535	0-65535	0	$\bigcirc$
P03.11	Reserved	0–65535	0-65535	0	0
P03.12	Torque upper limit setting	0.0–200.0% (of the VFD rated current)	0.0–200.0	150.0%	0

Function code	Name	Description	Setting range	Default	Modify
P04 group	Space voltage vector c	ontrol			•
P04.00	V/F curve setting	0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F (V/F separation)	0–5	0	O
P04.01	Torque boost	0.0%-10.0%	0.0-10.0	0.1%	$\bigcirc$
P04.02	Torque boost cut-off	0.0%–50.0% (of the motor rated frequency)	0.0–50.0	20.0%	O
P04.03	V/F slip compensation	0.0%–200.0%	0.0-200.0	0.0%	0
P04.04	Energy-saving operation	0: Energy-saving operation is invalid 1: Energy-saving operation is valid	0-1	0	O
P04.05	V/F frequency point 1	0.00Hz-P04.07	0.00-P04.07	0.00Hz	$\bigcirc$
P04.06	V/F voltage point 1	0.0%-P04.08	0.0-P04.08	0.0%	$\bigcirc$
P04.07	V/F frequency point 2	P04.05-P04.09	P04.05– P04.09	0.00Hz	0
P04.08	V/F voltage point 2	P04.06-P04.10	P04.06– P04.10	0.0%	0
P04.09	V/F frequency point 3	P04.07–P00.10 (max. frequency)	P04.07- P00.10	0.00Hz	0
P04.10	V/F voltage point 3	P04.08–100.0% (of the motor rated voltage)	P04.08- 100.0	0.0%	0
P04.11	PWM method	0: PWM method 1 1: PWM method 2	0-1	0	O
P04.12	Voltage setting channel	The function code is used to select the output voltage setting channel at V/F curve separation. 0: Voltage 1: Al1 2: Al2 3: Al3 4: Al4 5: Multi-step running 6: PID 7: Modbus communication 8: PROFIBUS/PROFINET communication	0–8	0	0
P04.13	Voltage set through keypad	0.0%–100.0% (of the motor rated voltage)	0.0-100.0	20.0%	0
P04.14	Voltage increase time	0.0s-3600.0s	0.0-3600.0	100.0s	0
P04.15	Voltage decrease time	0.0s-3600.0s	0.0-3600.0	100.0s	$\cup$

Function code	Name	Description	Setting range	Default	Modify
P04.16	Min. output voltage	0.0%-P04.17	0.0-P04.17	5.0%	0
P04.17	Max. output voltage	P04.16-100.0%	P04.16- 100.0	100.0%	0
P04.18	Low-frequency oscillation control factor	0-100	0–100	10	0
P04.19	High-frequency oscillation control factor	0-100	0-100	0	0
P04.20	Vibration control frequency threshold	0.00–120.00Hz	0.00-120.00	15.00Hz	0
P05 group	Input terminal functio	ns			-
P05.00	Function of S1	0: No function	0-71	1	$\bigcirc$
P05.01	Function of S2	1: Run forward	0-71	2	$\bigcirc$
P05.02	Function of S3	2: Run reversely	0-71	3	$\bigcirc$
P05.03	Function of S4	3: Enable three-wire running	0-71	6	$\bigcirc$
P05.04	Function of S5	4: Forward jogging	0-71	7	O
P05.05	Function of S6	5: Reverse jogging	0-71	0	$\bigcirc$
P05.06	Function of S7	6: Coast to stop (emergency stop)	0-71	0	$\bigcirc$
P05.07	Function of S8	P: Fault reset	0-71	0	$\bigcirc$
P05.08	Function of S9	9: External fault NC input	0-71	0	$\bigcirc$
P05.09	Function of S10	10: Increase frequency setting (UP)	0-71	0	$\bigcirc$
P05.10	Function of S11	11: Decrease frequency setting	0-71	0	$\bigcirc$
P05.11	Function of S12	<ul> <li>(DOWN)</li> <li>12: Clear the frequency</li> <li>increase/decrease setting</li> <li>13: Clear the frequency</li> <li>increase/decrease setting</li> <li>13: Clear the frequency</li> <li>increase/decrease setting</li> <li>temporarily</li> <li>14: ACC/DEC time selection 1</li> <li>15: ACC/DEC time selection 2</li> <li>16: Multi-step speed terminal 1</li> <li>17: Multi-step speed terminal 3</li> <li>19: Multi-step speed terminal 4</li> <li>20: Pause multi-step speed</li> <li>running</li> <li>21: Switch between A setting and B setting</li> <li>22: Switch between (A+B) setting</li> <li>and A setting</li> <li>23: Switch between (A+B) setting</li> <li>and B setting</li> <li>24: Variable-frequency running</li> <li>(pulse signal ↑)</li> <li>25: Power-frequency running</li> </ul>	0-71	0	

Function	Name	Description	Setting	Default	Modify
code			range		-
		(pulse signal 1)			
		26: Switching from variable			
		(requency to power frequency			
		(puise signal   )			
		27: Switching from power			
		(autor signal 1)			
		(puise signal  )			
		28: Medium Voltage disconnection			
		Input			
		29: Pause PID control			
		30: UPS feedback			
		31: Reserved			
		32: Switching cabinet address 0			
		33: Switching cabinet address 1			
		54: Switching cabinet address 2			
		35: Switch the running command			
		to local			
		36: Switch the running command			
		to terminat			
		37: Switch the running command			
		20: DCS start			
		39: DCS stop			
		40. Disable torque control			
		41: Enable master/stave control			
		42. Master-slave speed			
		torminal			
		43. Disable ACC/DEC			
		contactor KM2 foodback			
		45: Commissioning signal input			
		46: Start on-site operation box			
		47: Stop on-site operation box			
		48: Medium voltage switch OF1M1			
		feedback			
		49: Medium voltage switch OF1M2			
		feedback			
		50: Medium voltage switch OF1M3			
		feedback			
		51: Medium voltage switch OF1M4			
		feedback			
		52: Medium voltage switch OF1M5			
		feedback			
		53: Medium voltage switch OF1M6			
		feedback			
		54: Medium voltage switch OF1M7			

Function code	Name	Description	Setting range	Default	Modify
Function code	Name	Description feedback 55: Medium voltage switch QF1M8 feedback 56: Medium voltage switch QF2M1 feedback 57: Medium voltage switch QF2M2 feedback 58: Medium voltage switch QF2M3 feedback 59: Medium voltage switch QF2M4 feedback 60: Medium voltage switch QF2M5 feedback 61: Medium voltage switch QF2M6 feedback 62: Medium voltage switch QF2M6 feedback 63: Medium voltage switch QF2M7 feedback 63: Medium voltage switch QF2M8 feedback 64: Switching cabinet 1 remote on-site state 65: Switching cabinet 2 remote	Setting range	Default	Modify
		on-site state 65: Switching cabinet 2 remote on-site state 66: Switching cabinet 3 remote on-site state 67: Switching cabinet 4 remote on-site state 68: Switching cabinet 5 remote on-site state 69: Switching cabinet 6 remote on-site state 70: Switching cabinet 7 remote on-site state 71: Switching cabinet 8 remote			
P05.12	Input terminal	0x0000–0xFFFF	0x0000- 0xFFFF	0x0000	0
P05.13	Digital filter times	1–500	1–500	20	0
P05.14	Terminal control running mode	0: Two-wire control mode 1 1: Two-wire control mode 2 2: Three-wire control mode 1 3: Three-wire control mode 2	0-3	0	O
P05.15	Frequency increment change rate of the terminal UP	0.01–50.00Hz/s	0.01-50.00	0.50Hz/s	0
P05.16	Frequency increment change rate of the terminal DOWN	0.01–50.00Hz/s	0.01–50.00	0.50Hz/s	0

Function code	Name	Description	Setting range	Default	Modify
P05.17	AI1 lower limit	0.00V-P05.19	0.00-P05.19	0.00V	0
P05.18	Corresponding setting of Al1 lower limit	-100.0%-P05.20	-100.0- P05.20	0.0%	0
P05.19	AI1 upper limit	P05.17-10.00V	P05.17- 10.00	10.00V	0
P05.20	Corresponding setting of AI1 upper limit	P05.18-100.0%	P05.18- 100.0	100.0%	0
P05.21	AI1 input filter time	0.00-10.00s	0.00-10.00	2.00s	$\bigcirc$
P05.22	AI2 lower limit	0.00-P05.24	0.00-P05.24	0.00V	$\bigcirc$
P05.23	Corresponding setting of AI2 lower limit	-100.0%-P05.25	-100.0– P05.25	0.0%	0
P05.24	AI2 upper limit	P05.22-10.00V	P05.22- 10.00	10.00V	0
P05.25	Corresponding setting of AI2 upper limit	P05.23-100.0%	P05.23- 100.0	100.0%	0
P05.26	AI2 input filter time	0.00-10.00s	0.00-10.00	2.00s	$\bigcirc$
P05.27	AI3 lower limit	-10.00V-P05.29	-10.00- P05.29	0.00V	0
P05.28	Corresponding setting of AI3 lower limit	-100.0%-P05.30	-100.0- P05.30	0.0%	0
P05.29	AI3 upper limit	P05.27-10.00V	P05.27- 10.00	10.00V	0
P05.30	Corresponding setting of AI3 upper limit	P05.28-100.0%	P05.28- 100.0	100.0%	0
P05.31	AI3 input filter time	0.00-10.00s	0.00-10.00	2.00s	0
P05.32	AI4 lower limit	-10.00V-P05.34	-10.00- P05.34	0.00V	0
P05.33	Corresponding setting of AI4 lower limit	-100.0%-P05.35	-100.0- P05.35	0.0%	0
P05.34	AI4 upper limit	P05.32-10.00V	P05.32- 10.00	10.00V	0
P05.35	Corresponding setting of AI4 upper limit	P05.33-100.0%	P05.33- 100.0	100.0%	0
P05.36	Al4 input filter time	0.00–10.00s	0.00-10.00	2.00s	0
P05.37	Al1 mode switchover		0-1	0	0
P05.38	Al2 mode switchover	10: Current	0-1	0	0
P05.39	AI3 mode switchover	11: voltage	0-1	0	0
P05.40	AI1 calibration configuration	0–2 0: Disable	0-2	0	0

Function code	Name	Description	Setting range	Default	Modify
P05.41	AI2 calibration configuration	1: Calibrate AI lower limit 2: Calibrate AI upper limit	0-2	0	0
P05.42	AI3 calibration configuration	✓ Note: When input 4mA–20mA corresponds to 0–10V, first calibrate AI lower limit, input 4mA, and wait for 20s to complete the calibration. Calibrate AI upper limit, input 20mA, and wait for 20s to complete the calibration. Then set the function code to 0.	0-2	0	0
P05.43	AI4 zero calibration coefficient	-10.00%-10.00%	-10.00-10.00	0.00%	0
P05.44	Communication analog lower limit	0.000V-P05.46	0.000- P05.46	0.000V	0
P05.45	Corresponding setting of communication analog lower limit	-100.0%-P05.47	-100.0- P05.47	0.0%	0
P05.46	Communication analog upper limit	P05.44-10.000V	P05.44- 10.000	10.000V	0
P05.47	Corresponding setting of communication analog upper limit	P05.45-100.0%	P05.45- 100.0	100.0%	0
P05.48	Communication setting range	0.00–100.00mm	0.00-100.00	0.00mm	0
P05.49	S1 switch-on delay	0.00–50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.50	S1 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.51	S2 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.52	S2 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.53	S3 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.54	S3 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.55	S4 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.56	S4 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.57	S5 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.58	S5 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.59	S6 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	$\bigcirc$
P05.60	S6 switch-off delay	0.00–50.00s	0.00-50.00	1.50s	0
P05.61	S7 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	0
P05.62	S7 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	0
P05.63	S8 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	0
P05.64	S8 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	0
P05.65	S9 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	0
P05.66	S9 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	0
P05.67	S10 switch-on delay	0.00-50.00s	0.00-50.00	1.50s	0
P05.68	S10 switch-off delay	0.00-50.00s	0.00-50.00	1.50s	0

Function	Name	Description	Setting	Default	Modify
	C11 awitch on dolou	0.00 50.000	range	1.500	
P05.69	S11 switch-off delay	0.00-50.005	0.00-50.00	1.505	0
P05.70	S11 switch-off delay	0.00-50.005	0.00-50.00	1.505	0
P05.71	S12 switch-on delay	0.00-50.005	0.00-50.00	1.50s	0
P05.72	S12 switch-off delay	0.00–50.00s	0.00-50.00	1.50S	0
P06 group	P06 group Output terminal functions		[		
P06.00	RO1 output	0: No output	0-91	1	0
P06.01	RO2 output	1: In VFD running	0-91	2	0
P06.02	RO3 output	2: Fault output	0-91	11	0
P06.03	RO4 output	3: Frequency level detection FDT	0-91	12	0
P06.04	RO5 output	output	0-91	0	$\bigcirc$
P06.05	RO6 output	4: Frequency reached	0-91	0	$\bigcirc$
P06.06	RO7 output	5: Zero speed running	0-91	0	$\bigcirc$
P06.07	RO8 output	6: Variable-frequency working	0-91	0	$\bigcirc$
P06.08	RO9 output	state	0-91	0	$\bigcirc$
P06.09	RO10 output	7: Power frequency working state	0-91	0	$\bigcirc$
P06.10	RO11 output	8: Running time reached	0-91	0	$\bigcirc$
P06.11	RO12 output	9: Running forward	0-91	0	0
P06.12	RO13 output	10: Running reversely	0-91	0	0
P06.13	RO14 output	request)	0-91	0	0
P06.14	RO15 output	12: Alarm output	0-91	0	0
P06.15	RO16 output	Variable frequency:	0-91	0	0
P06.16	RO17 output	12: Dermission of modium voltage	0-91	0	$\bigcirc$
P06.17	RO18 output	switch OE1M1 switching on	0-91	0	$\bigcirc$
P06.18	RO19 output	14. Permission of medium voltage	0-91	0	$\bigcirc$
P06.19	RO20 output	switch OF1M2 switching on	0-91	0	$\bigcirc$
P06.20	RO21 output	15. Permission of medium voltage	0_91	0	$\bigcirc$
1 00.20	Nozi output	switch OF1M3 switching on	0.01	0	
		16. Permission of medium voltage			
		switch OF1M4 switching on			
		17. Permission of medium voltage			
		switch OF1M5 switching on			
		18. Permission of medium voltage			
		switch OF1M6 switching on			
		19. Permission of medium voltage			
		switch OF1M7 switching on			
		20: Permission of medium voltage			
P06.21	RO22 output	switch OF1M8 switching on power	0-91	0	$\bigcirc$
		frequency			
		Power frequency:			
		21: Permission of medium voltage			
		switch OF2M1 switching on			
		22: Permission of medium voltage			
		switch OF2M2 switching on			
		23: Permission of medium voltage			
		switch OF2M3 switching on			
		24: Permission of medium voltage			

Function	Name	Description	Setting	Default	Modify
coue		switch OE2M4 switching on	Talige		
		25: Permission of medium voltage			
		switch OF2M5 switching on			
		26. Permission of medium voltage			
		switch OF2M6 switching on			
		27. Permission of medium voltage			
		switch OF2M7 switching on			
		28. Permission of medium voltage			
		switch OF2M8 switching on			
		29: Permission of medium voltage			
		switch OF1M1 switching off			
		30: Permission of medium voltage			
		switch OF1M2 switching off			
		31: Permission of medium voltage			
		switch QF1M3 switching off			
		32: Permission of medium voltage			
		switch QF1M4 switching off			
		33: Permission of medium voltage			
		switch QF1M5 switching off			
		34: Permission of medium voltage			
		switch QF1M6 switching off			
		35: Permission of medium voltage			
		switch QF1M7 switching off			
		36: Permission of medium voltage			
		switch QF1M8 switching off			
		37: Permission of medium voltage			
		switch QF2M1 switching off			
		38: Permission of medium voltage			
		switch QF2M2 switching off			
		39: Permission of medium voltage			
		switch QF2M3 switching off			
		40: Permission of medium voltage			
		switch QF2M4 switching off			
		41: Permission of medium voltage			
		switch QF2M5 switching off			
		42: Permission of medium voltage			
		switch QF2M6 switching off			
		43: Permission of medium voltage			
		switch QF2M7 switching off			
		44: Permission of medium voltage			
		switch QF2M8 switching off			
		45: Variable-frequency working			
		state of switching cabinet 1			
		46: Power-frequency working			
		state of switching cabinet 1			
		47: Variable-frequency working			
		state of switching cabinet 2			I I

Function code	Name	Description	Setting range	Default	Modify
		48 <sup>.</sup> Power-frequency working			
		state of switching cabinet 2			
		49. Variable-frequency working			
		state of switching cabinet 3			
		50: Power-frequency working			
		state of switching cabinet 3			
		51: Variable-frequency working			
		state of switching cabinet 4			
		52: Power-frequency working			
		state of switching cabinet 4			
		53: Variable-frequency working			
		state of switching cabinet 5			
		54: Power-frequency working			
		state of switching cabinet 5			
		55: Variable-frequency working			
		state of switching cabinet 6			
		56: Power-frequency working			
		state of switching cabinet 6			
		57: Variable-frequency working			
		state of switching cabinet 7			
		58: Power-frequency working			
		state of switching cabinet 7			
		59: Variable-frequency working			
		state of switching cabinet 8			
		60: Power-frequency working			
		state of switching cabinet 8 (45–			
		60: Both power frequency and			
		variable frequency valid at the			
		same time indicates fault.)			
		61: Unit bypass state			
		62: Remote-local state			
		63–64: Reserved			
		65: Low-voltage commissioning			
		vacuum contactor KM1 control			
		66: Low-voltage commissioning			
		vacuum contactor KM2 control			
		67: Switching cabinet 1# KM1			
		feedback signal			
		68: Switching cabinet 1# KM2			
		feedback signal			
		69: Switching cabinet 1# KM3			
		feedback signal			
		70: Switching cabinet 2# KM1			
		feedback signal			
		71: Switching cabinet 2# KM2			
		feedback signal			
		72: Switching cabinet 2# KM3			

Function code	Name	Description	Setting range	Default	Modify
		feedback signal			
		73: Switching cabinet 3# KM1			
		feedback signal			
		74: Switching cabinet 3# KM2			
		feedback signal			
		75: Switching cabinet 3# KM3			
		feedback signal			
		76: Switching cabinet 4# KM1			
		feedback signal			
		77: Switching cabinet 4# KM2			
		feedback signal			
		78: Switching cabinet 4# KM3			
		feedback signal			
		79: Switching cabinet KM4			
		feedback signal			
		80: Switching cabinet 1 QS1			
		feedback signal			
		81: Switching cabinet 1 QS2			
		feedback signal			
		82: Switching cabinet 1 QS3			
		feedback signal			
		83: Switching cabinet 2 QS1			
		feedback signal			
		84: Switching cabinet 2 QS2			
		feedback signal			
		85: Switching cabinet 2 QS3			
		feedback signal			
		86: Switching cabinet 3 QS1			
		feedback signal			
		87: Switching cabinet 3 QS2			
		feedback signal			
		88: Switching cabinet 3 QS3			
		feedback signal			
		89: Switching cabinet 4 QS1			
		feedback signal			
		90: Switching cabinet 4 QS2			
		feedback signal			
		91: Switching cabinet 4 QS3			
D0C 00	A01	leedback signal	0.10		
PU6.22	AO1 output	o: Running frequency (100%	0-10	0	$\bigcirc$
P06.23	AO2 output	frequency	0-10	0	$\bigcirc$
P06.24	AO3 output	Irequency)	0-10	0	$\bigcirc$
P06.25	AO4 output	1. Set frequency (100%	0-10	0	$\bigcirc$
		frequency			
P06.26	AO5 output	2: Output current valid value	0-10	0	$\bigcirc$
	-	2. Output current valid value			
		(100%) corresponds to twice the			

Function	Name	Description	Setting	Default	Modify
Function code	Name	DescriptionVFD rated current)3: Output current valid value(100% corresponds to twice themotor rated current)4: Output voltage (100%corresponds to 1.2 times the VFDrated voltage)5: Output power (100%corresponds to twice the motorrated power)6: Output torque (100%corresponds to twice the motorrated torque)7: Al1 input value (100%corresponds to 10V)8: Al2 input value (100%corresponds to 10V)0: Al2 input value (100%)	Setting range	Default	Modify
		9: Al3 input value (100% corresponds to 10V) 10: Al4 input value (100% corresponds to 10V)			
P06.27	AO1 output lower limit	0.00%-P06.29	0.00-P06.29	0.00%	0
P06.28	AO1 output corresponding to lower limit	0.00V-P06.30	0.00-P06.30	0.00V	0
P06.29	AO1 output upper limit	P06.27-100.0%	P06.27- 100.0	100.0%	0
P06.30	AO1 output corresponding to upper limit	P06.28-10.00V	P06.28- 10.00	10.00V	0
P06.31	AO2 output lower limit	0.00%-P06.33	0.00-P06.33	0.0%	0
P06.32	AO2 output corresponding to lower limit	0.00V-P06.34	0.00-P06.34	0.00V	0
P06.33	AO2 output upper limit	P06.31-100.0%	P06.31- 100.0	100.0%	0
P06.34	AO2 output corresponding to upper limit	P06.32-10.00V	P06.32- 10.00	10.00V	0
P06.35	AO3 output lower limit	0.00%-P06.37	0.00-P06.37	0.0%	0
P06.36	AO3 output corresponding to lower limit	0.00V-P06.38	0.00-P06.38	0.00V	0
P06.37	AO3 output upper	P06.35-100.0%	P06.35-	100.0%	$\bigcirc$

Function code	Name	Description	Setting range	Default	Modify
	limit		100.0		
P06.38	AO3 output corresponding to upper limit	P06.36-10.00V	P06.36- 10.00	10.00V	0
P06.39	AO4 output lower limit	0.00%-P06.41	0.00-P06.41	0.0%	0
P06.40	AO4 output corresponding to lower limit	0.00V-P06.42	0.00-P06.42	0.00V	0
P06.41	AO4 output upper limit	P06.39-100.0%	P06.39- 100.0	100.0%	0
P06.42	AO4 output corresponding to upper limit	P06.40-10.00V	P06.40- 10.00	10.00V	0
P06.43	AO5 output lower limit	0.00%-P06.45	0.00-P06.45	0.0%	0
P06.44	AO5 output corresponding to lower limit	0.00V-P06.46	0.00-P06.46	0.00V	0
P06.45	AO5 output upper limit	P06.43-100.0%	P06.43- 100.0	100.0%	0
P06.46	AO5 output corresponding to upper limit	P06.44-10.00V	P06.44- 10.00	10.00V	0
P06.47	RO1 switch-on delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.48	RO1 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.49	RO2 switch-on delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.50	RO2 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.51	RO3 switch-on delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.52	RO3 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.53	RO4 switch-on delay	0.000–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.54	RO4 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.55	RO5 switch-on delay	0.00-50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.56	RO5 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P06.57	RO6 switch-on delay	0.00–50.00s	0.00-50.00	0.00s	0
P06.58	RO6 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	0
P06.59	RO7 switch-on delay	0.00–50.00s	0.00-50.00	0.00s	0
P06.60	RO7 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	0
P06.61	RO8 switch-on delay	0.00–50.00s	0.00-50.00	0.00s	0
P06.62	RO8 switch-off delay	0.00–50.00s	0.00-50.00	0.00s	$\bigcirc$
P07 group	Human-machine inter	face			
P07.00	Touch screen version	0.00-655.35	0.00-655.35	Default setting	•
P07.01	Standard I/O board software version	0.00–655.35	0.00-655.35	Default setting	

Function code	Name	Description	Setting range	Default	Modify
P07.02	Software version (FPGA)	0.00-655.35	0.00-655.35	Default setting	•
P07.03	Software version	0.00–655.35	0.00-655.35	Default	•
P07.04	Software version	0.00–655.35	0.00-655.35	Default	•
P07.05	Unit MCU version	0.00–655.35	0.00-655.35	Default	•
P07.06	Max. number of available units	1–12	1–12	Default setting	•
P07.07	Supported motor type	0: Only AM 1: Only SM 2: SM and AM	0-2	Default setting	•
P07.08	Unit FPGA version	0.00–655.35	0.00-655.35	Default setting	•
P07.09	Two-quadrant and four-quadrant selection	0: Two-quadrant 1: Four-quadrant	0-1	Default setting	•
P07.10	Max. number of switching cabinets	0-4	0-4	Default setting	•
P07.11	Local accumulative running time	0–65535h	0-65535	0h	•
P07.12	Local running time	0–65535min	0-65535	0min	0
P07.13	Factory bar code 1	0–65535	0-65535	0	
P07.14	Factory bar code 2	0-65535	0-65535	0	
P07.15	Factory bar code 3	0–65535	0-65535	0	
P07.16	Factory bar code 4	0–65535	0-65535	0	
P07.17	Factory bar code 5	0-65535	0-65535	0	
P07.18	Factory bar code 6	0–65535	0-65535	0	
P08 group	Enhanced functions			•	
P08.00	ACC time 2	0.1–3600.0s	0.1-3600.0	Model depended	0
P08.01	DEC time 2	0.1–3600.0s	0.1-3600.0	Model depended	0
P08.02	ACC time 3	0.1–3600.0s	0.1-3600.0	Model depended	0
P08.03	DEC time 3	0.1–3600.0s	0.1-3600.0	Model depended	0
P08.04	ACC time 4	0.1–3600.0s	0.1-3600.0	Model depended	0
P08.05	DEC time 4	0.1–3600.0s	0.1-3600.0	Model depended	0
P08.06	Running frequency of jogging	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	5.00Hz	0
P08.07	ACC time of jogging	0.1–3600.0s	0.1-3600.0	Model depended	0

Function code	Name	Description	Setting range	Default	Modify
P08.08	DEC time of jogging	0.1–3600.0s	0.1-3600.0	Model depended	0
P08.09	Jump frequency 1	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz	0
P08.10	Jump frequency amplitude 1	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz	0
P08.11	Jump frequency 2	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz	0
P08.12	Jump frequency amplitude 2	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz	0
P08.13	Jump frequency 3	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz	0
P08.14	Jump frequency amplitude 3	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	0.00Hz	0
P08.15	Auto fault reset count	0-3	0-3	0	0
P08.16	Auto fault reset interval	0.1–100.0s	0.1-100.0	1.0s	0
P08.17	FDT electrical level detection value	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	50.00Hz	0
P08.18	FDT lagging detection value	0.0–100.0% (FDT electrical level)	0.0-100.0	5.0%	0
P08.19	Detection amplitude for frequency being reached	0.0–100.0% (of the max. frequency)	0.0-100.0	0.0%	0
P08.20	Overmodulation	0: Overmodulation is invalid 1: Overmodulation is valid	0-1	0	O
P08.21	Cooling-fan running mode	0: Normal mode 1: The fan keeps running after power up.	0-1	1	0
P08.22	Alarm reset interval	0.0s (The alarm function is invalid) 0.1–3600.0s	0.0-3600.0	1.0s	0
P08.23	Reference frequency disconnection threshold	0.0-100.0%	0.0-100.0	0.0%	O
P08.24	Reference frequency disconnection time	0.0–360.0s	0.0-360.0	0.0s	O
P08.25	Drop control	0.00–10.00Hz	0.00-10.00	0.00Hz	0
P08.26	Reserved	0–65535	0-65535	0	0
P08.27	Unit alarm temperature setting	60.0–100.0°C	60.0-100.0	75.0°C	0
P08.28	Droop control mode	0: Droop control mode 1 1: Droop control mode 2	0-1	0	O
P08.29	Droop control mode 1 droop frequency	-10.00–10.00Hz	-10.00-10.00	0.00Hz	•
P08.30	Droop control mode 2 droop frequency	-10.00–10.00Hz	-10.00-10.00	0.00Hz	•

Function code	Name	Description	Setting range	Default	Modify
P08.31	Ambient temperature alarm detection value	0-100°C	0-100	60°C	0
P08.32	Initialization time of fault reset count	0–65535min	0–65535	60min	0
P08.33	Allowed time of undervoltage fault reset	0–100s	0-100	10s	0
P08.34- P08.39	Reserved	0–65535	0–65535	0	0
P09 group	Fault record paramete	rs			
P09.00	Action selection 1 of DSP fault	Two bits stand for a fault. 0: No processing 1: Alarm 2: Light fault, stop but not cut off medium voltage power. 3: Serious fault, stop and cut off medium voltage power. Automatic reset is disabled.	0xAAAA– 0xFFFF	0xEABA	0
P09.01	Action selection 2 of DSP fault	0x8AAA-0xFFFF	0x8AAA– 0xFFFF	0x8EAA	0
P09.02	Action selection 3 of DSP fault	0xAA82-0xFFFF	0xAA82– 0xFFFF	0xAA82	0
P09.03	Action selection 4 of DSP fault	0xAAAA-0xFFFF	0xAAAA– 0xFFFF	0x0x07FC	0
P09.04	Action selection 1 of ARM fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x555D	0
P09.05	Action selection 2 of ARM fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x6555	0
P09.06	Action selection 3 of ARM fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x1555	0
P09.07	Action selection 4 of ARM fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x1555	0
P09.08	Action selection 1 of unit fault	0x2AEA-0xFFFF	0x2AEA– 0xFFFF	0xAAEA	0
P09.09	Action selection 2 of unit fault	0x0AAA-0xFFFF	0x0AAA– 0xFFFF	0xAAAA	0
P09.10	Action selection 3 of unit fault	0xAABF-0xFFF	0xAABF– 0xFFFF	0xAABF	0
P09.11	Action selection 4 of unit fault	0x000B-0xFFFF	0x000B– 0xFFFF	0x000B	0
P09.12	2th-last DSP fault 1	bitN=0: No fault bitN=1: Fault Bit0: Software overcurrent Bit1: Hardware overcurrent Bit2: Grid overvoltage Bit3: Grid undervoltage	0x0000– 0xFFFF	0x0000	•

Function	Name	Description	Setting	Default	Modify
code	Hume	Description	range	Denual	Moully
		bit4: Motor overload Bit5: VFD overload Bit6: Phase loss on output side Bit7: Input phase loss detection fault Bit8: Current detection fault Bit9: Parameter autotuning fault Bit10: Encoder disconnection fault Bit11: Encoder reversal fault Bit12: Handshake fault Bit13: Input overcurrent Bit14: Voltage detection transmission board fault Bit15: Phase sequence			
P09.13	2th-last DSP fault 2	BitN=0: No fault BitN=1: Fault Bit16: Magnetic pole position detection Bit17: Speed out-of-tolerance-range fault Bit18: VFD overspeed fault Bit19: Resolver position reading error Bit20: The resolver can't track the motor rotation bit21: Resolver signal distortion fault Bit22: UVW encoder connection fault Bit23: UVW encoder zero position fault Bit24: Encoder parameter autotuning fault Bit25: Transformer loss is too large Bit26: Reactive current is too large Bit27: Transformer overload Bit28: Input voltage imbalance Bit29: Input current imbalance Bit29: Input current imbalance	0x0000- 0xFFFF	0x0000	
P09.14	2th-last ARM fault type 1	bitN=0: No fault bitN=1: Fault Bit0: Transformer overheating Bit1: Transformer tripping Bit2: External fault Bit3: Modbus communication fault Bit4: Buffer cabinet fault	0x0000– 0xFFFF	0x0000	•

Function	Name	Description	Setting	Default	Modify
coue		Bit5: PID disconnection fault	range		
		Bit6: Door access alarm			
		Bit7: Synchronous switchover			
		timeout			
		Bit8: Synchronous switchover			
		serious fault			
		Bit9: Factory time reached			
		Bit10: Motor temperature too high			
		Bit11: Switching cabinet			
		communication fault			
		Bit12: Insufficient SD card capacity			
		Bit13: QF feedback fault			
		Bit14: DSP and ARM handshake			
		fault			
		bit15: Power off during running			
		bitN=0: No fault			
		bitN=1: Fault			
		Bit16: PROFIBUS communication			
		fault			
		Bit17: Reference frequency			
		disconnection detection fault			
		Bit18: Switching cabinet 1 action			
		fault			
		Bit19: Switching cabinet 2 action			
		Tault			
		Sitzo: Switching cabinet 3 action			
		Bit21: Switching cabinot 4 action			
P09 15	2th-last ARM fault	fault	0x0000-	0v0000	
1 05.15	type 2	Bit22: Version not match	0xFFFF	0,0000	
		bit23: Reserved			
		bit24: Ambient temperature too			
		high			
		Bit25: Unit optical-fiber			
		communication fault			
		Bit26: Fan overheating fault			
		Bit27: Master/slave optical-fiber			
		communication fault			
		Bit28-bit29: Reserved			
		Bit30: Temperature controller			
		communication fault			
		bit31: Reserved			
		bitN=0: No fault			
		bitN=1: Fault	0x0000-		_
P09.16	2th-last unit fault 1	Bit0: Unit optical-fiber uplink	0xFFFF	0x0000	
		communication fault			
		Bit1: Unit optical-fiber downlink			

Function code	Name	Description	Setting range	Default	Modify
		communication fault Bit2: The unit is not ready Bit3: Unit overvoltage Bit4: Unit undervoltage Bit5: Unit power fault Bit6: Unit overheating Bit7: Unit input phase loss protection Bit8: Unit input power loss protection Bit9: Upper bridge VCE fault Bit10: Lower bridge VCE fault Bit11: Hardware overvoltage Bit12: The unit does not match Bit13: Unit bypass failure bit14: Reserved	Tange		
P09.17	2th-last unit fault 2	bit13: Reserved bitN=0: No fault bitN=1: Fault Bit16: Rectifier unit R-phase VCE Bit17: Rectifier unit S-phase VCE Bit18: Rectifier unit T-phase VCE Bit19: Grid current detection fault Bit20: Phase lock failure Bit21: Rectifier side overheating bit22: Reserved bit23: Reserved Bit24: Zero calculation fault Bit25: Hardware overcurrent Bit26-31: Reserved	0x0000- 0xFFFF	0x0000	•
P09.18	2nd-last fault unit number	If the number is 0, there is no unit fault. If it is not 0, then A1–A12: 1–12 B1–B12: 13–24 C1–C12: 25–36	0–65535	0	•
P09.19	ACC/DEC state at 2nd-last fault	0: Constant speed 1: ACC 2: DEC	0-2	0	•
P09.20	Running frequency at 2nd-last fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz	
P09.21	Set frequency at 2nd-last fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz	
P09.22	Output current at 2nd-last fault	0.0-6553.5A	0.0-6553.5	0.0A	
P09.23	Output voltage at 2nd-last fault	0-65535V	0-65535	0V	•

Function code	Name	Description	Setting range	Default	Modify
P09.24	Input current at 2nd-last fault	0.0-6553.5A	0.0-6553.5	0.0A	•
P09.25	Input voltage at 2nd-last fault	0-65535V	0-65535	0V	•
P09.26	Unit bus voltage at 2nd-last fault	0-65535V	0-65535	0V	•
P09.27	Unit temperature at 2nd-last fault	0.0–6553.5°C	0.0–6553.5	0.0°C	•
P09.28	System input terminal state at 2nd-last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.29	User input terminal state at 2nd-last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.30	System output terminal state at 2nd-last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.31	User output terminal state 1 at 2nd-last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.32	User output terminal state 2 at 2nd-last fault	0x0000-0xFFFF	0x0000- 0xFFFF	0x0000	•
P09.33	Last DSP fault 1	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.34	Last DSP fault 2	0x0000-0xFFFF	0x0000- 0xFFFF	0x0000	•
P09.35	Last ARM fault type 1	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.36	Last ARM fault type 2	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.37	Last unit fault 1	0x0000-0xFFFF	0x0000- 0xFFFF	0x0000	•
P09.38	Last unit fault 2	0x0000-0xFFFF	0x0000- 0xFFFF	0x0000	•
P09.39	Last fault unit number	Same as the description of P09.18.	0–36	0	•
P09.40	ACC/DEC state at last fault	0: Constant speed 1: ACC 2: DEC	0-2	0	•
P09.41	Running frequency at last fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz	•
P09.42	Set frequency at last fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz	•
P09.43	Output current at last fault	0.0–6553.5A	0.0-6553.5	0.0A	•
P09.44	Output voltage at last fault	0-65535V	0-65535	0V	

Function code	Name	Description	Setting range	Default	Modify
P09.45	Input current at last fault	0.0-6553.5A	0.0-6553.5	0.0A	•
P09.46	Input voltage at last fault	0-65535V	0–65535	0V	•
P09.47	Unit bus voltage at last fault	0-65535V	0-65535	0V	•
P09.48	Unit temperature at last fault	0.0–6553.5°C	0.0–6553.5	0.0°C	•
P09.49	System input terminal state at last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.50	User input terminal state at last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.51	System output terminal state at last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.52	User output terminal state 1 at last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.53	User output terminal state 2 at last fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.54	Present DSP fault 1	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.55	Present DSP fault 2	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.56	Present ARM fault type 1	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.57	Present ARM fault type 2	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.58	Present unit fault 1	0x0000-0xFFFF	0x0000- 0xFFFF	0x0000	•
P09.59	Present unit fault 2	0x0000-0xFFFF	0x0000- 0xFFFF	0x0000	•
P09.60	Unit number at present fault	If the number is 0, there is no unit fault. If it is not 0, then A1–A12: 1–12 B1–B12: 13–24 C1–C12: 25–36	0–36	0x0000	•
P09.61	ACC/DEC state at present fault	0: Constant speed 1: ACC 2: DEC	0-2	0	•
P09.62	Running frequency at present fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz	•
P09.63	Set frequency at present fault	0.00Hz-P00.10	0.00-P00.10	0.00Hz	•
P09.64	Output current at	0.0-6553.5A	0.0-6553.5	0.0A	•

Function code	Name	Description	Setting range	Default	Modify
P09.65	Output current at present fault	0-65535V	0-65535	0V	•
P09.66	Input current at present fault	0.0-6553.5A	0.0-6553.5	0.0A	•
P09.67	Input voltage at present fault	0-65535V	0–65535	0V	•
P09.68	Unit bus voltage at present fault	0-65535V	0–65535	0V	•
P09.69	Unit temperature at present fault	0.0–6553.5°C	0.0-6553.5	0.0°C	•
P09.70	System input terminal state at present fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.71	User input terminal state at present fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.72	System output terminal state at present fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.73	User output terminal state 1 at present fault	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P09.74	User output terminal state 2 at present fault	0x0000-0xFFFF	0x0000- 0xFFFF	0x0000	•
P09.75	Present fault time	0–65535	0-65535	0	
P10 group	PID control				
P10.00	PID reference source	0: Function code (P10.01) 1: Al1 2: Al2 3: Al3 4: Al1+ Al2 5: Al2+ Al3 6: Al3+ Al1 7: Reserved 8: Multi-step running 9: Modbus 10: PROFIBUS/PROFINET	0-10	0	0
P10.01	Local preset PID reference	0.0%-100.0%	0.0-100.0	0.0%	$\bigcirc$
P10.02	PID feedback source	0: Al1 1: Al2 2: Al3 3: Al1+ Al2 4: Al2+ Al3 5: Al3+ Al1 6: Reserved 7: Modbus	0-8	0	0

Function code	Name	Description	Setting range	Default	Modify
		8: PROFIBUS/PROFINET feedback	U		
P10.03	PID output characteristics selection	0: PID output is positive. 1: PID output is negative.	0-1	0	0
P10.04	Proportional gain (Kp)	0.00–100.00	0.00-100.00	1.00	0
P10.05	Integral time (Ti)	0.01-10.00s	0.01-10.00	0. 50s	0
P10.06	Differential time (Td)	0.00-10.00s	0.00-10.00	0.00s	0
P10.07	Sampling cycle (T)	0.01–100.00s	0.01-00.00	0.10s	$\bigcirc$
P10.08	PID control deviation limit	0.0–100.0% (Reference source)	0.0-100.0	0.0%	0
P10.09	Feedback offline detection value	0.0–100.0% (Reference source)	0.0-100.0	0.0%	0
P10.10	Feedback offline detection time	0.0–3600.0s (Reference source)	0.0-3600.0	1.0s	0
P10.11	PID wake-up-from-sleep value	0.0–100.0% (Reference source)	0.0-100.0	0.0%	0
P10.12	PID sleep delay	0.0–360.0s	0.0-360.0	1.0s	$\bigcirc$
P11 group	Multi-step speed contr	ol			
P11.00	Multi-step speed reference	0: Terminal 1: Analog	0-1	0	0
P11.01	Multi-step speed 0	-100.0-100.0%	-100.0-100.0	0.0%	0
P11.02	Multi-step speed 1	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.03	Multi-step speed 2	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.04	Multi-step speed 3	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.05	Multi-step speed 4	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.06	Multi-step speed 5	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.07	Multi-step speed 6	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.08	Multi-step speed 7	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.09	Multi-step speed 8	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.10	Multi-step speed 9	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.11	Multi-step speed 10	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.12	Multi-step speed 11	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.13	Multi-step speed 12	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.14	Multi-step speed 13	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.15	Multi-step speed 14	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.16	Multi-step speed 15	-100.0–100.0%	-100.0-100.0	0.0%	$\bigcirc$
P11.17	Multi-step speed analog input source	0: AI1 1: AI2 2: AI3 3: AI4	0-3	0	0
P11.18	Corresponding analog of step 0	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.19	Corresponding analog of step 1	-100.0–100.0%	-100.0-100.0	0.0%	0

Function code	Name	Description	Setting range	Default	Modify
P11.20	Corresponding analog of step 2	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.21	Corresponding analog of step 3	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.22	Corresponding analog of step 4	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.23	Corresponding analog of step 5	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.24	Corresponding analog of step 6	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.25	Corresponding analog of step 7	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.26	Corresponding analog of step 8	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.27	Corresponding analog of step 9	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.28	Corresponding analog of step 10	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.29	Corresponding analog of step 11	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.30	Corresponding analog of step 12	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.31	Corresponding analog of step 13	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.32	Corresponding analog of step 14	-100.0–100.0%	-100.0-100.0	0.0%	0
P11.33	Corresponding analog of step 15	-100.0–100.0%	-100.0-100.0	0.0%	0
P12 group	Master/slave control				•
P12.00	Master-slave mode selection	0: Power-balancing mode 1: Reserved	0-1	0	O
P12.01	Reference signal sources sent by the master to the slave	0: The master outputs torque signal 1: The master outputs current signal 2: The master outputs PG signal	0-2	0	O
P12.02	Filter time of slave reference signal	0.00s-655.35s	0.00-655.35	0.00s	0
P12.03	PID adjustment limit	0.0–100.0%	0.0-100.0	100.0%	0
P12.04	PID mode selection	0: Proportion plus integration as synchronous coefficient 1: Proportion plus integration as error correction	0-1	0	0
P12.05	Slave reference frequency source gain	0.01–100.00	0.01-100.00	1.00	0

Function code	Name	Description	Setting range	Default	Modify
P12.06	Slave reference signal source gain	0.01-100.00	0.01-100.00	1.00	0
P12.07	Master-slave proportional coefficient P1	0.0000–6.5535	0.0000- 6.5535	0.1000	0
P12.08	Master-slave integral coefficient I1	0.00s-655.35	0.00-655.35	5.00	0
P12.09	Low-point frequency for switching master-slave PI	0.00Hz-P12.12	0.00-P12.12	5.00Hz	0
P12.10	Master-slave proportional coefficient P2	0.0000–6.5535	0.0000- 6.5535	0.1000	0
P12.11	Master-slave integral coefficient I2	0.00s-655.35	0.00-655.35	5.00	$\bigcirc$
P12.12	High-point frequency for switching master-slave PI	P12.09-P00.10	P12.09- P00.10	10.00Hz	0
P12.13	PI control deviation limit	0.0-80.0%	0.0-80.0	0.0%	0
P12.14	Lower limit of PI integral enabling deviation	0.0-100.0%	0.0-100.0	0.0%	0
P12.15	Master-slave control differential coefficient	0.00s-655.35s	0.00-655.35	0.00	0
P12.16- P12.23	Reserved	0–65535	0-65535	0	•
P12.24	Master-slave control ID code	0-15	0-15	0	•
P12.25	Master-slave character	0-1	0-1	0	•
P12.26	Master-slave node state 1	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P12.27	Master-slave node state 2	0x0000-0xFFFF	0x0000– 0xFFFF	0x0000	•
P12.28	Bit27: Master/slave optical-fiber communication fault shield	0: Enable 1: Disable	0-1	0	0
P12.29	Master-slave type setting	0: Single master 1: Spare machine 2: Master 3: Slave	0-3	0	•
P12.30	Enabling spare machine KM1 closing	0: Disable 1: Enable	0-1	0	•
P12.31	Reserved	0–65535	0-65535	0	
P12.32	Reserved	0–65535	0–65535	0	

Function code	Name	Description	Setting range	Default	Modify
P13 group	Protection parameters		-		
P13.00	Protection against output phrase loss	0: Disable 1: Enable	0-1	1	0
P13.01	Motor overload protection selection	0: No protection 1: Common motor (with low-speed compensation) 2: Variable-frequency motor (without low-speed compensation)	0–2	2	0
P13.02	Motor overload protection coefficient	20.0%–120.0% (of the motor rated current)	20.0-120.0	100.0%	0
P13.03	Frequency decreasing point at sudden power failure	600–900V	600–900	650V	0
P13.04	Frequency drop rate at transient power-off	0.00Hz–P00.10 (Max. output frequency)	0.00-P00.10	3.00Hz	0
P13.05	Overvoltage stalling protection	0: Disable 1: Enable	0-1	1	0
P13.06	Overvoltage stalling protection voltage	300-1280V	300-1280	1100V	0
P13.07	Automatic current limit threshold	5-180%	5–180	120%	0
P13.08	Frequency drop rate during current limit	0.00–10.00Hz (0.00 indicates overcurrent stalling is invalid.)	0.00-10.00	10.00Hz	0
P13.09	Input overvoltage prealarm threshold	105-120%	105–120	110%	0
P13.10	Unit bypass function	0: Manual bypass 1: Common automatic bypass 2: Neutral point drifting automatic bypass	0-2	0	0
P13.11	Unit manual bypass setting	0x000-0x1FF	0x000-0x1FF	VFD voltage depended	0
P13.12	Hardware overcurrent point	50–200% (of the VFD rated current)	50-200	180%	O
P13.13	Hardware current-limit point	50–200% (of the VFD rated current)	50-200	180%	O
P13.14	Optical-fiber communication alarm triggering value	0-20	0–20	5	0
P13.15	Enable VFD overload integral	0: Disable 1: Enable	0-1	0	0
P13.16	Overload integral value	Accumulated overload integral value	0-65535	0	0
P13.17	Underload prealarm detection value	0.0–200.0%	0.0-200.0	0.0%	0

Function code	Name	Description	Setting range	Default	Modify
P13.18	Underload prealarm detection time	0.0–3600.0s	0.0-3600.0	1.0s	0
P13.19	Speed deviation detection value	0.0–50.0%	0.0-50.0	10.0%	0
P13.20	Speed deviation detection time	0.0-10.0s	0.0-10.0	1.0s	0
P13.21- P13.23	Reserved	0–65535	0-65535	0	0
P14 group	SM control				
P14.00	SM reference sources	0: D-axis current reference (flux-weakening 0) 1: Max. torque current ratio (flux-weakening 0) 2: Unit power factor (flux-weakening 0) 3: D-axis current reference (flux-weakening 1) 4: Max. torque current ratio (flux-weakening 1) 5: Unit power factor control(flux-weakening 1)	0–5	0	O
P14.01	SM excitation mode	0: Manual 1: Automatic	0-1	1	
P14.02	Initial value percentage of SM automatic excitation	0.0%–100.0%	0.0-100.0	0.0%	0
P14.03	Starting frequency of automatic excitation	0.00Hz-50.00Hz	0.00-50.00	0.00Hz	O
P14.04	Output power factor setting of SM	0.0%–200.0%	0.0-200.0	0.0%	0
P14.05	Corresponding voltage of SM excitation analog 0%	0.00V-P14.06	0.00-P14.06	0.00V	O
P14.06	Corresponding voltage of SM excitation analog 100%	P14.05–10.00V	P14.05- 10.00	10.00V	O
P14.07	Low-frequency oscillation control factor of SM	0-100	0-100	10	0
P14.08	High-frequency oscillation control factor of SM	0-100	0–100	0	0
P14.09	Oscillation control frequency threshold of SM	0.00–120.00Hz	0.00-120.00	15.00Hz	0
P14.10	Oscillation control	0.00-120.00Hz	0.00-120.00	0.00Hz	$\bigcirc$

Function code	Name	Description	Setting range	Default	Modify
	frequency switch of SM				
P14.11	Power-frequency exciting current reference	0.0%–100.0%	0.0-100.0	0%	0
P14.12	Weakening protection coefficient of SM	0–3000	0–3000	1000	0
P14.13	Identification current of SM	0.0–100.0%	0.0-100.0	20.0%	O
P14.14	SM autotuning command	0: Low-frequency autotuning 1: High-frequency autotuning	0-1	0	0
P14.15	D-axis pull-in current 1	0.00-100.0%	0.00-100.0	20.0%	O
P14.16	D-axis pull-in current 2	0.00-100.0%	0.00-100.0	10.0%	•
P14.17	Pull-in current switchover frequency point	0.00Hz–P00.10 (two decimal places)	0.00-P00.10	10.00Hz	0
P14.18	Reference frequency as zero action	0: Suspend disabled 1: Suspend enabled	0-1	0	0
P14.19	Pull-in current in hovering state	0.0-100.0%	0.0-100.0	50.0%	0
P14.20	Starting time of hovering	0.00–10.00s	0.00-10.00	1.00s	0
P14.21	Exit time of hovering	0.00-10.00s	0.00-10.00	1.00s	$\bigcirc$
P14.22	Reactive current closed-loop control enable	0-1	0-1	0	0
P14.23	Reactive current closed-loop starting frequency	0.00Hz-P00.10	0.00-P00.10	0.00Hz	0
P14.24	Proportional coefficient of reactive current regulation	0-1000	0-1000	50	
P14.25	Integral coefficient of reactive current regulation	0-1000	0-1000	50	
P15 group	Switching cabinet cont	trol function			
P15.00	Delay for switching from variable frequency to power frequency	0.0–60.0s	0.0-60.0	2.0s	0
P15.01	Switching cabinet QF configuration mode	0: Independent mode 1: Two-in-One mode	0-1	0	O
P15.02	Switching cabinet command channel	0: Locally controlled 1: Master controlled	0-1	0	O

Function code	Name	Description	Setting range	Default	Modify
P15.03	Synchronous switching enabling	0: Disable 1: Synchronous switching with reactors 2: Synchronous switching without reactors	0-2	0	O
P15.04	Switching cabinet QF1 configuration information 1	0: No common use 1: Group 1 in common use 2: Group 2 in common use 3: Group 3 in common use 4: Group 4 in common use	0x0000– 0xFFFF	0x0000	O
P15.05	Switching cabinet QF1 configuration information 2	0: No common use 1: Group 1 in common use 2: Group 2 in common use 3: Group 3 in common use 4: Group 4 in common use	0x0000- 0xFFFF	0x0000	O
P15.06	Synchronous switching reactor voltage drop	0–1000V (line voltage)	0-1000	50V	O
P15.07	Switching cabinet KM1 configuration information 1	Set the common information of a switching cabinet every 4 bits. 0: No common use 1: Group 1 in common use 2: Group 2 in common use 3: Group 3 in common use 4: Group 4 in common use	0x0000– 0xFFFF	0x0000	O
P15.08	Switching cabinet KM1 configuration information 2	0: No common use 1: Group 1 in common use 2: Group 2 in common use 3: Group 3 in common use 4: Group 4 in common use	0x0000– 0xFFFF	0x0000	O
P15.09	Motor frequency drop rate of switching cabinet 1	0.00–50.00Hz	0.00-50.00	0.00Hz	O
P15.10	Motor frequency drop rate of switching cabinet2	0.00–50.00Hz	0.00-50.00	0.00Hz	O
P15.11	Motor frequency drop rate of switching cabinet 3	0.00–50.00Hz	0.00-50.00	0.00Hz	O
P15.12	Motor frequency drop rate of switching cabinet 4	0.00–50.00Hz	0.00-50.00	0.00Hz	O
P15.13	Action time of switching cabinet 1	0–300ms	0-300	90ms	O
P15.14	Action time of switching cabinet 2	0–300ms	0-300	90ms	O
Function code	Name	Description	Setting range	Default	Modify
------------------	---	---------------	------------------	---------	--------
P15.15	Action time of switching cabinet 3	0–300ms	0-300	90ms	O
P15.16	Action time of switching cabinet 4	0–300ms	0-300	90ms	O
P15.17	Torque current of switching cabinet 1	0.0-6553.5A	0.0-6553.5	0.0	O
P15.18	Torque current of switching cabinet 2	0.0-6553.5A	0.0-6553.5	0.0	O
P15.19	Torque current of switching cabinet 3	0.0-6553.5A	0.0-6553.5	0.0	O
P15.20	Torque current of switching cabinet 4	0.0-6553.5A	0.0-6553.5	0.0	O
P15.21	Synchronous switchover phase lock delav	0–120min	0-120	2min	O
P15.22	Synchronous switchover angle compensation of switching cabinet 1	-200.0–200.0°	-200.0-200.0	12.0°	O
P15.23	Synchronous switchover angle compensation of switching cabinet 2	-200.0–200.0°	-200.0–200.0	12.0°	O
P15.24	Synchronous switchover angle compensation of switching cabinet 3	-200.0–200.0°	-200.0-200.0	12.0°	O
P15.25	Synchronous switchover angle compensation of switching cabinet 4	-200.0–200.0°	-200.0–200.0	12.0°	O
P15.26	Synchronous switchover actual deviation angle of switching cabinet 1	0.0–6553.5°	0.0-6553.5	0.0°	•
P15.27	Synchronous switchover actual deviation angle of switching cabinet 2	0.0–6553.5°	0.0-6553.5	0.0°	•
P15.28	Synchronous switchover actual deviation angle of switching cabinet 3	0.0–6553.5°	0.0-6553.5	0.0°	•
P15.29	Synchronous switchover actual deviation angle of switching cabinet 4	0.0–6553.5°	0.0-6553.5	0.0°	•

Function code	Name	Description	Setting range	Default	Modify
P15.30	Voltage detection board enabling	0: Disable (Power frequency and variable frequency share the voltage detection board) 1: Enable (The detection boards of power frequency and variable frequency are separate)	0-1	0	0
P15.31	Reserved	0–65535	0-65535	0	$\bigcirc$
P15.32	Filter coefficient for synchronous switchover	1–20	1–20	4	O
P15.33	Phase locking stability accuracy for synchronous switchover	1–500	1-500	200	0
P15.34	Stability holding time for synchronous switchover	0.1–100.0s	0.1–100.0	4.0s	O
P15.35	Fault power-frequency bypass action selection	0: Manual power-frequency bypass 1: Automatic power-frequency bypass	0-1	0	O
P15.36	KM1 configuration	0: KM1 is configured 1: KM1 is not configured	0-1	1	O
P15.37	Switching cabinet type	0: Manual 1: Automatic	0-1	0	O
P16 group	Serial communication				
P16.00	Local Modbus address	1–247; 0 indicates a broadcast address	1–247	1	0
P16.01	Modbus baud rate	0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS 4: 19200BPS 5: 38400BPS	0–5	4	0
P16.02	Modbus data bit check	0: No check (N, 8, 2) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 1) for RTU	0-3	1	0
P16.03	Modbus communication response delay	0–200ms	0–200	5ms	0
P16.04	Modbus communication timeout time	0.0 (invalid); 0.1–100.0s	0.0-100.0	0.0s	0
P16.05	Remote upgrade enabling	0: Disable 1: Enable When remote upgrade is enabled,	0-1	0	O

Function code	Name	Description	Setting range	Default	Modify
		the serial baud rate is automatically configured to 115200, and it can realize the			
		remote upgrade of the main control ARM program with the 4G IoT module.			
P17 group	Ethernet communicati	on			
P17.00	MSB of Local IP address	0x0000–0xFFFF (high-order bit)	0x0000– 0xFFFF	0xC0A8	•
P17.01	LSB of Local IP address	0x0000–0xFFFF (low-order bit)	0x0000– 0xFFFF	0x0102	•
P17.02	MSB of local subnet mask	0x0000–0xFFFF (high-order bit)	0x0000– 0xFFFF	0xFFFF	•
P17.03	LSB of local subnet mask	0x0000-0xFFFF (low-order bit)	0x0000– 0xFFFF	0xFF00	•
P17.04	MSB of local gateway	0x0000–0xFFFF (high-order bit)	0x0000– 0xFFFF	0xC0A8	•
P17.05	LSB of local gateway	0x0000–0xFFFF (low-order bit)	0x0000– 0xFFFF	0x0101	•
P17.06	MSB of local MAC	0x0000–0xFFFF (high-order bit)	0x0000– 0xFFFF	0x5254	•
P17.07	Middle-order bit of local MAC	0x0000–0xFFFF (middle-order bit)	0x0000– 0xFFFF	0x4C19	•
P17.08	LSB of local MAC	0x0000–0xFFFF (low-order bit)	0x0000– 0xFFFF	0xF742	•
P17.09	Log level of DSP command control module		0-0xF	0	0
P17.10	Log level of DSP speed control module		0x0-0xF	0x0	0
P17.11	Log level of DSP torque calculation module	Bit0: No log Bit1: Fatal	0x0-0xF	0x0	0
P17.12	Log level of DSP current loop	Bit2: Error Bit4: Key information	0x0-0xF	0x0	0
P17.13	Log level of DSP oscillograph calculation module	Bit8: Prompt message Combination of above levels	0x0-0xF	0x0	0
P17.14	Log level of DSP fault management module		0x0-0xF	0x0	0
P17.15	Log level of DSP parameter inquiry module		0x0-0xF	0x0	0
P17.16	Log level of ARM start/stop control module	Bit0: No log Bit1: Fatal Bit2: Error	0x0-0xF	0x0	0

Function code	Name	Description	Setting range	Default	Modify
	Log level of ARM	Bit4: Key information			
P17.17	frequency reference	Bit8: Prompt message	0x0-0xF	0x0	$\bigcirc$
	module	Combination of above levels			
D17 10	Log level of ARM fault		00	00	
P17.18	handling module		UXU-UXF	UXU	0
	Log level of ARM				
P17.19	frequency calculation		0x0-0xF	0x0	$\bigcirc$
	module				
	Log level of ARM				
P17.20	switching cabinet		0x0-0xF	0x0	$\bigcirc$
	module				
D17 21	Log level of ARM			0v0	$\bigcirc$
1 17.21	function code module		0.00-0.01	0.00	$\bigcirc$
	Log level of ARM				
P17.22	terminal function		0x0-0xF	0x0	$\bigcirc$
	module				
P17 23	Log level of ARM		0x0_0xF	0x0	$\bigcirc$
1 11120	UDP/IP module			0/10	0
P17 24	Log level of ARM		0x0-0xF	0x0	$\bigcirc$
	Modbus module			0/10	
P17.25	Log level of ARM		0x0-0xF	0x0	$\bigcirc$
	PROFIBUS module			••	
P17.26	Log level of ARM		0x0-0xF	0x0	$\bigcirc$
	master-slave module			••	Ŭ
P17.27	High-order bit of log	0x0000-0XFFFF (high-order bit)	0x0000-	0x0000	$\bigcirc$
	receiving IP		0XFFFF		Ŭ
P17.28	Low-order bit of log	0x0000–0XFFFF (low-oder bit)	0x0000-	0x0000	$\bigcirc$
	receiving IP		0XFFFF		
P18 group	PROFIBUS communica	tion			
		0: The module is not connected			
P18.00	Module type	1: PROFIBUS	0–2	0	•
		2: PROFINET			
P18.01	Module address	0–99	0–99	2	$\bigcirc$
P18.02	Received PZD2	0: Disable	0–20	0	$\bigcirc$
P18.03	Received PZD3	1: Frequency reference value	0–20	0	$\bigcirc$
P18.04	Received PZD4	(actual value: -MaxFrq–MaxFrq,	0–20	0	$\bigcirc$
P18.05	Received PZD5	two decimal places)	0–20	0	$\bigcirc$
P18.06	Received PZD6	2: Torque reference value	0–20	0	$\bigcirc$
P18.07	Received PZD7	(percentage, two decimal places)	0–20	0	$\bigcirc$
P18.08	Received PZD8	3: Reserved	0–20	0	0
P18.09	Received PZD9	4: PID control setting value	0–20	0	$\bigcirc$
P18.10	Received PZD10	reterence	0–20	0	$\bigcirc$
P18.11	Received PZD11	5: PID control feedback value	0-20	0	0
		reference			
P18.12	Received PZD12	o. v/r separation reference	0–20	0	$\cap$
		7. Power frequency and variable			~
P18.12	Received PZD12	(percentage, two decimal places) 7: Power frequency and variable	0–20	0	0

Function code	Name	Description	Setting range	Default	Modify
		frequency control command	5		
<b>D1010</b>	0 1 0 7 0 0	8–20: Reserved			
P18.13	Sent PZD2	0: Invalid	0-31	0	0
P18.14	Sent PZD3	1: Running frequency	0-31	0	0
P18.15	Sent PZD4	2: Reserved	0-31	0	0
P18.16	Sent PZD5	3: Input voltage	0-31	0	0
P18.17	Sent PZD6	4: Output voltage	0-31	0	$\bigcirc$
P18.18	Sent PZD7	5: Input current	0-31	0	$\bigcirc$
P18.19	Sent PZD8	6: Output current	0-31	0	$\bigcirc$
P18.20	Sent PZD9	7: Actual output torque	0-31	0	$\bigcirc$
P18.21	Sent PZD10	8: Output power percentage	0-31	0	$\bigcirc$
P18.22	Sent PZD11	9: Set frequency absolute value	0-31	0	$\bigcirc$
P18.23	Sent PZD12	<ul> <li>11: Present DSP fault 2</li> <li>12: Present ARM fault 1</li> <li>13: Present ARM fault 2</li> <li>14: Present unit fault 1</li> <li>15: Present unit fault 2</li> <li>16: Unit number at present fault</li> <li>17: User input terminal 1</li> <li>18: User input terminal 2</li> <li>19: User output terminal 2</li> <li>21: System input terminal 2</li> <li>22: System output terminal 2</li> <li>23: Reserved</li> <li>24: State of switching cabinet 1</li> <li>25: State of switching cabinet 3</li> <li>27: State of switching cabinet 4</li> <li>28-31: Reserved</li> </ul>	0-31	0	0
P18.24	Temporary variable for PZD sending	0–65535	0-65535	0	0
P18.25	DP communication timeout time	0.0 (invalid); 0.1–100.0s	0.0-100.0	0.0s	0
P18.26	PROFINET input length	0-32	0-32	24	•
P18.27	PROFINET output length	0-32	0-32	24	•
P18.28	PROFINET communication speed	0-65535	0-65535	0	•
P18.29	PROFINET IP address 1	0–65535	0-65535	192	•
P18.30	PROFINET IP address 2	0–65535	0-65535	168	•

Function code	Name	Description	Setting range	Default	Modify
P18.31	PROFINET IP address 3	0–65535	0-65535	1	•
P18.32	PROFINET IP address 4	0-65535	0–65535	4	•
P18.33	PROFINET subnet mask 1	0–65535	0-65535	255	●
P18.34	PROFINET subnet mask 2	0–65535	0–65535	255	•
P18.35	PROFINET subnet mask 3	0–65535	0-65535	255	●
P18.36	PROFINET subnet mask 4	0–65535	0-65535	0	●
P18.37	PROFINET gateway 1	0–65535	0-65535	192	$\bullet$
P18.38	PROFINET gateway 2	0–65535	0-65535	168	
P18.39	PROFINET gateway 3	0–65535	0-65535	1	
P18.40	PROFINET gateway 4	0–65535	0-65535	2	$\bullet$
P18.41	Reserved	0–65535	0-65535	0	0
P18.42	Reserved	0–65535	0-65535	0	$\bigcirc$
P19 group	Motor parameter 2				
P19.00	Type of motor 2	1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3	0	0
P19.01	Rated power of AM 2	4–50000kW	4–50000	Model depended	O
P19.02	Rated frequency of AM 2	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	0
P19.03	Rated speed of AM 2	1–36000rpm	1-36000	Model depended	0
P19.04	Rated voltage of AM 2	0-20000V	0-20000	Model depended	O
P19.05	Rated current of AM 2	0.1–1000.0A	0.1-1000.0	Model depended	O
P19.06	Stator resistance of AM 2	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.07	Rotor resistance of AM 2	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.08	Stator and rotor leakage inductance of AM 2	0.1–6553.5mH	0.1-6553.5	Model depended	0
P19.09	Stator and rotor mutual inductance of AM 2	0.1–6553.5mH	0.1-6553.5	Model depended	0

Function code	Name	Description	Setting range	Default	Modify
P19.10	No-load current of AM 2	0.01-655.35A	0.01–655.35	Model depended	0
P19.11	Rated power of SM 2	4–50000kW	4–50000	Model depended	O
P19.12	Rated frequency of SM 2	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P19.13	Rated speed of SM 2	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P19.14	Number of pole pairs of SM 2	1-50	1–50	2	0
P19.15	Rated voltage of SM 2	0-20000V	0–20000	Model depended	O
P19.16	Rated current of SM 2	0.1–1000.0A	0.1-1000.0	Model depended	O
P19.17	Stator resistance of SM 2	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.18	Direct-axis inductance of SM 2	0.01–655.35mH	0.01-655.35	Model depended	0
P19.19	Quadrature-axis inductance of SM 2	0.01–655.35mH	0.01-655.35	Model depended	0
P19.20	Counter-emf constant of SM 2	0–20000	0-20000	9700	0
P19.21	Type of motor 3	<ul> <li>0: Asynchronous motor (AM)</li> <li>1: Electrically excited synchronous motor</li> <li>2: Synchronous motor with damping winding</li> <li>3: Permanent-magnet synchronous motor</li> </ul>	0–3	0	0
P19.22	Rated power of AM 3	4–50000kW	4–50000	Model depended	O
P19.23	Rated frequency of AM 3	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P19.24	Rated speed of AM 3	1–36000rpm	1-36000	Model depended	0
P19.25	Rated voltage of AM 3	0-20000V	0–20000	Model depended	O
P19.26	Rated current of AM 3	0.1–1000.0A	0.1-1000.0	Model depended	O
P19.27	Stator resistance of AM 3	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.28	Rotor resistance of AM 3	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.29	Stator and rotor leakage inductance of AM 3	0.1–6553.5mH	0.1-6553.5	Model depended	0
P19.30	Stator and rotor mutual inductance of	0.1–6553.5mH	0.1-6553.5	Model depended	0

Function code	Name	Description	Setting range	Default	Modify
	AM 3				
P19.31	No-load current of AM 3	0.01-655.35A	0.01-655.35	Model depended	0
P19.32	Rated power of SM 3	4–50000kW	4–50000	Model depended	O
P19.33	Rated frequency of SM 3	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P19.34	Rated speed of SM 3	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P19.35	Number of pole pairs of SM 3	1-50	1–50	2	0
P19.36	Rated voltage of SM 3	0-20000V	0–20000	Model depended	0
P19.37	Rated current of SM 3	0.1–1000.0A	0.1-1000.0	Model depended	0
P19.38	Stator resistance of SM 3	0.001-65.535Ω	0.001- 65.535	Model depended	0
P19.39	Direct-axis inductance of SM 3	0.01–655.35mH	0.01-655.35	Model depended	0
P19.40	Quadrature-axis inductance of SM 3	0.01–655.35mH	0.01-655.35	Model depended	0
P19.41	Counter-emf constant of SM 3	0–20000	0-20000	9700	0
P19.42	Type of motor 4	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0-3	0	0
P19.43	Rated power of AM 4	4–50000kW	4–50000	Model depended	O
P19.44	Rated frequency of AM 4	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	0
P19.45	Rated speed of AM 4	1–36000rpm	1-36000	Model depended	O
P19.46	Rated voltage of AM 4	0-20000V	0–20000	Model depended	O
P18.47	Rated current of AM 4	0.1–1000.0A	0.1-1000.0	Model depended	O
P19.48	Stator resistance of AM 4	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.49	Rotor resistance of AM 4	0.001-65.535Ω	0.001- 65.535	Model depended	0
P19.50	Stator and rotor leakage inductance of AM 4	0.1–6553.5mH	0.1-6553.5	Model depended	0

Function code	Name	Description	Setting range	Default	Modify
P19.51	Stator and rotor mutual inductance of AM 4	0.1–6553.5mH	0.1-6553.5	Model depended	0
P19.52	No-load current of AM 4	0.01–655.35A	0.01–655.35	Model depended	0
P19.53	Rated power of SM 4	4–50000kW	4–50000	Model depended	$\bigcirc$
P19.54	Rated frequency of SM 4	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	$\bigcirc$
P19.55	Rated speed of SM 4	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P19.56	Number of pole pairs of SM 4	1-50	1–50	2	O
P19.57	Rated voltage of SM 4	0-20000V	0–20000	Model depended	O
P19.58	Rated current of SM 4	0.1–1000.0A	0.1-1000.0	Model depended	O
P19.59	Stator resistance of SM 4	0.001-65.535Ω	0.001– 65.535	Model depended	0
P19.60	Direct-axis inductance of SM 4	0.01–655.35mH	0.01–655.35	Model depended	$\bigcirc$
P19.61	Quadrature-axis inductance of SM 4	0.01–655.35mH	0.01–655.35	Model depended	0
P19.62	Counter-emf constant of SM 4	0–20000	0-20000	9700	0
P19.63	Type of motor 5	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0–3	0	0
P19.64	Rated power of AM 5	4–50000kW	4–50000	Model depended	$\bigcirc$
P19.65	Rated frequency of AM 5	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	$\bigcirc$
P19.66	Rated speed of AM 5	1–36000rpm	1-36000	Model depended	$\bigcirc$
P19.67	Rated voltage of AM 5	0-20000V	0-20000	Model depended	$\bigcirc$
P19.68	Rated current of AM 5	0.1–1000.0A	0.1-1000.0	Model depended	O
P19.69	Stator resistance of AM 5	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.70	Rotor resistance of AM 5	0.001–65.535Ω	0.001– 65.535	Model depended	0
P19.71	Stator and rotor leakage inductance of	0.1–6553.5mH	0.1-6553.5	Model depended	0

Function code	Name	Description	Setting range	Default	Modify
	AM 5				
P19.72	Stator and rotor mutual inductance of AM 5	0.1–6553.5mH	0.1-6553.5	Model depended	0
P19.73	No-load current of AM 5	0.01-655.35A	0.01-655.35	Model depended	0
P19.74	Rated power of SM 5	4–50000kW	4–50000	Model depended	O
P19.75	Rated frequency of SM 5	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P19.76	Rated speed of SM 5	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P19.77	Number of pole pairs of SM 5	1-50	1–50	2	O
P19.78	Rated voltage of SM 5	0-20000V	0–20000	Model depended	O
P19.79	Rated current of SM 5	0.1-1000.0A	0.1-1000.0	Model depended	0
P19.80	Stator resistance of SM 5	0.001-65.535Ω	0.001- 65.535	Model depended	0
P19.81	Direct-axis inductance of SM 5	0.01–655.35mH	0.01-655.35	Model depended	0
P19.82	Quadrature-axis inductance of SM 5	0.01–655.35mH	0.01-655.35	Model depended	0
P19.83	Counter-emf constant of SM 5	0-20000	0–20000	9700	0
P20 group	Motor parameter 3				
P20.00	Type of motor 6	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0-3	0	0
P20.01	Rated power of AM 6	4–50000kW	4–50000	Model depended	O
P20.02	Rated frequency of AM 6	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P20.03	Rated speed of AM 6	1–36000rpm	1-36000	Model depended	O
P20.04	Rated voltage of AM 6	0-20000V	0–20000	Model depended	O
P20.05	Rated current of AM 6	0.1–1000.0A	0.1-1000.0	Model depended	O
P20.06	Stator resistance of AM 6	0.001-65.535Ω	0.001– 65.535	Model depended	0

Function code	Name	Description	Setting range	Default	Modify
P20.07	Rotor resistance of AM 6	0.001–65.535Ω	0.001– 65.535	Model depended	0
P20.08	Stator and rotor leakage inductance of AM 6	0.1–6553.5mH	0.1-6553.5	Model depended	0
P20.09	Stator and rotor mutual inductance of AM 6	0.1–6553.5mH	0.1-6553.5	Model depended	0
P20.10	No-load current of AM 6	0.01–655.35A	0.01-655.35	Model depended	0
P20.11	Rated power of SM 6	4–50000kW	4-50000	Model depended	0
P20.12	Rated frequency of SM 6	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	0
P20.13	Rated speed of SM 6	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P20.14	Number of pole pairs of SM 6	1-50	1–50	2	0
P20.15	Rated voltage of SM 6	0-20000V	0-20000	Model depended	O
P20.16	Rated current of SM 6	0.1–1000.0A	0.1-1000.0	Model depended	0
P20.17	Stator resistance of SM 6	0.001–65.535Ω	0.001– 65.535	Model depended	0
P20.18	Direct-axis inductance of SM 6	0.01–655.35mH	0.01-655.35	Model depended	0
P20.19	Quadrature-axis inductance of SM 6	0.01–655.35mH	0.01-655.35	Model depended	0
P20.20	Counter-emf constant of SM 6	0–20000	0-20000	9700	0
P20.21	Type of motor 7	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0-3	0	0
P20.22	Rated power of AM 7	4–50000kW	4–50000	Model depended	O
P20.23	Rated frequency of AM 7	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	0
P20.24	Rated speed of AM 7	1–36000rpm	1-36000	Model depended	O
P20.25	Rated voltage of AM 7	0-20000V	0-20000	Model depended	O
P20.26	Rated current of AM 7	0.1–1000.0A	0.1-1000.0	Model depended	O
P20.27	Stator resistance of	0.001–65.535Ω	0.001-	Model	$\bigcirc$

Function code	Name	Description	Setting range	Default	Modify
	AM 7		65.535	depended	
P20.28	Rotor resistance of AM 7	0.001–65.535Ω	0.001– 65.535	Model depended	0
P20.29	Stator and rotor leakage inductance of AM 7	0.1–6553.5mH	0.1-6553.5	Model depended	0
P20.30	Stator and rotor mutual inductance of AM 7	0.1–6553.5mH	0.1-6553.5	Model depended	0
P20.31	No-load current of AM 7	0.01-655.35A	0.01-655.35	Model depended	0
P20.32	Rated power of SM 7	4–50000kW	4-50000	Model depended	O
P20.33	Rated frequency of SM 7	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P20.34	Rated speed of SM 7	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P20.35	Number of pole pairs of SM 7	1-50	1–50	2	O
P20.36	Rated voltage of SM 7	0-20000V	0-20000	Model depended	0
P20.37	Rated current of SM 7	0.1–1000.0A	0.1-1000.0	Model depended	O
P20.38	Stator resistance of SM 7	0.001–65.535Ω	0.001– 65.535Ω	Model depended	0
P20.39	Direct-axis inductance of SM 7	0.01–655.35mH	0.01-655.35	Model depended	0
P20.40	Quadrature-axis inductance of SM 7	0.01–655.35mH	0.01–655.35	Model depended	0
P20.41	Counter-emf constant of SM 7	0-20000	0–20000	9700	0
P20.42	Type of motor 8	0: Asynchronous motor (AM) 1: Electrically excited synchronous motor 2: Synchronous motor with damping winding 3: Permanent-magnet synchronous motor	0-3	0	0
P20.43	Rated power of AM 8	4–50000kW	4–50000	Model depended	O
P20.44	Rated frequency of AM 8	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P20.45	Rated speed of AM 8	1–36000rpm	1-36000	Model depended	O
P20.46	Rated voltage of AM 8	0-20000V	0–20000	Model depended	O
P20.47	Rated current of AM 8	0.1–1000.0A	0.1-1000.0	Model depended	O

## Goodrive5000 series medium voltage variable-frequency speed regulation system

Function code	Name	Description	Setting range	Default	Modify
P20.48	Stator resistance of AM 8	0.001–65.535Ω	0.001- 65.535	Model depended	0
P20.49	Rotor resistance of AM 8	0.001–65.535Ω	0.001- 65.535	Model depended	0
P20.50	Stator and rotor leakage inductance of AM 8	0.1–6553.5mH	0.1-6553.5	Model depended	0
P20.51	Stator and rotor mutual inductance of AM 8	0.1–6553.5mH	0.1-6553.5	Model depended	0
P20.52	No-load current of AM 8	0.01-655.35A	0.01-655.35	Model depended	0
P20.53	Rated power of SM 8	4–50000kW	4–50000	Model depended	O
P20.54	Rated frequency of SM 8	0.01Hz–P00.10 (Max. output frequency)	0.01-P00.10	50.00Hz	O
P20.55	Rated speed of SM 8	0–36000rpm	0-36000	1500rpm	$\bigcirc$
P20.56	Number of pole pairs of SM 8	1–50	1–50	2	O
P20.57	Rated voltage of SM 8	0-20000V	0-20000	Model depended	O
P20.58	Rated current of SM 8	0.1–1000.0A	0.1-1000.0	Model depended	O
P20 59	Stator resistance of	0 001-65 5350	0.001-	Model	$\bigcirc$
1 20.00	SM 8		65.535	depended	0
P20.60	Direct-axis inductance of SM 8	0.01–655.35mH	0.01–655.35	Model depended	0
P20.61	Quadrature-axis inductance of SM 8	0.01–655.35mH	0.01–655.35	Model depended	0
P20.62	Counter-emf constant of SM 8	0-20000	0–20000	9700	0
P21 Enco	der state viewing				
P21.00	Actual frequency of encoder	-327.68–327.67Hz	-327.68– 327.67	0.00Hz	•
P21.01	High-order bit of PG1 pulse count	0-65535	0-65535	0	●
P21.02	Low-order bit of PG1 pulse count	0-65535	0-65535	0	•
P21.03	Resolver counting	0–65535	0-65535	0	
P21.04	Resolver angle	0.00–359.99	0.00-359.99	0.00	
P21.05	Magnetic pole angle	0.00-359.99	0.00-359.99	0.00	
P21.06	High-order bit of PG2 pulse count	0–65535	0-65535	0	•
P21.07	Low-order bit of PG2 pulse count	0–65535	0-65535	0	•
P21.08	QEP pulse counting	0–65535	0-65535	0	$\bullet$

Function code	Name	Description	Setting range	Default	Modify
P21.09	Magnetic pole position	0–65535	0-65535	0	•
P21.10- P21.12	Reserved	0–65535	0-65535	0	•
P22 group	Encoders				
P22.00	Encoder type	0: Incremental encoder 1: UVW encoder 2: Resolver-type encoder 3: Sin/Cos encoder with CD 4: Sin/Cos encoder without CD	0-4	0	O
P22.01	Encoder pulse count	0–65535	0-65535	1000	$\bigcirc$
P22.02	Encoder direction	0: Forward input 1: Reverse input	0-1	0	O
P22.03	Detection time of encoder offline fault	0.0–10.0s	0.0-10.0	1.0s	O
P22.04	Detection time of encoder reversal fault	0.0–10.0s	0.0-10.0	1.0s	O
P22.05	Filter times of encoder detection	0-10	0-10	1	O
P22.06	Speed ratio between motor and encoder	0.000–65.535	0.000– 65.535	1.000	O
P22.07	Control parameters of SM	0x0000–0xFFFF Bit0: Enable Z pulse calibration Bit1: Enable encoder angle calibration Bit2: Enable SVC speed measurement Bit3: Rotary transformer speed detection mode Bit4: Z-pulse capture mode	0x0000- 0xFFFF	0x0003	0
P22.08	Enable Z pulse offline detection	0: Disable 1: Enable	0-1	0	O
P22.09	Initial angle of Z pulse	0.00–359.99°	0.00-359.99	0.00°	$\bigcirc$
P22.10	Pole initial angle	0.00–359.99°	0.00-359.99	0.00°	0
P22.11	Vector control frequency deviation value	0.0%–100.0% (of the max. frequency)	0.0-100.0	5.0%	0
P22.12	Deviation count time	0.0-6553.5s	0.0-6553.5	1.0s	0
P22.13	Encoder filter time	0.00-10.00s	0.00-10.00	0.10s	0
P22.14- P22.17	Reserved	0–65535	0-65535	0	•
Group 23	Temperature controller	communication			
P23.00	Modbus baud rate setting of temperature	0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS	0–5	4	•

Function code	Name	Description	Setting range	Default	Modify
		4: 19200BPS 5: 38400BPS	-		
P23.01	Data bit check setting of temperature controller	0: No check (N, 8, 2) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 1) for RTU	0–3	1	•
P23.02	Modbus communication timeout time of temperature controller	0.0–100.0s	0.0-100.0	10.0s	O
P23.03	Overtemperature alarm temperature of transformer	0–135°C	0-135	90°C	O
P23.04	Overtemperature tripping temperature of transformer	0–135°C	0-135	110°C	O
P23.05	Calibration coefficient of temperature control detection 1	-100.00%–100.00%	-100.00- 100.00	0.00%	O
P23.06	Calibration coefficient of temperature control detection 2	-100.00%–100.00%	-100.00- 100.00	0.00%	O
P23.07	Calibration coefficient of temperature control detection 3	-100.00%–100.00%	-100.00- 100.00	0.00%	O
P23.08	Calibration coefficient of temperature control detection 4	-100.00%–100.00%	-100.00- 100.00	0.00%	O
P23.09	Calibration coefficient of temperature control detection 5	-100.00%–100.00%	-100.00- 100.00	0.00%	O
P23.10	Calibration coefficient of temperature control detection 6	-100.00%–100.00%	-100.00- 100.00	0.00%	O
P23.11	Number of configured temperature controllers	1-4	1-4	1	O
P23.12	Transmission fault code of temperature controller 1	0–65535	0-65535	0	•
P23.13	Transmission slave address of temperature controller 1	0-65535	0-65535	0	•
P23.14	Transmission fault code of temperature	0–65535	0-65535	0	

Function code	Name	Description	Setting range	Default	Modify
	controller 2		_		
P23.15	Transmission slave address of temperature controller 2	0–65535	0-65535	0	•
P23.16	Transmission fault code of temperature controller 3	0–65535	0-65535	0	•
P23.17	Transmission slave address of temperature controller 3	0–65535	0-65535	0	•
P23.18	Transmission fault code of temperature controller 4	0–65535	0–65535	0	•
P23.19	Transmission slave address of temperature controller 4	0–65535	0–65535	0	•
P23.20	Fan turn-on temperature 1 (transformer)	P23.21–70.0°C When the temperature of the transformer is higher than the value set in P23.20, the fan turns on.	P23.21-75.0	50.0°C	0
P23.21	Fan turn-off temperature 1	0.0–P23.20 When the temperature of the transformer is lower than the value set in P23.21, the fan turns off.	0.0-P23.20	40.0°C	0
P23.22	Fan turn-on temperature 2 (unit)	P23.23–70.0°C When the temperature of the unit is higher than the value set in P23.22, the fan turns on.	P23.22-75.0	50.0°C	0
P23.23	Fan turn-off temperature 2	0.0–P23.22 When the temperature of the unit is lower than the value set in P23.23, the fan turns off.	0.0-P23.22	40.0°C	0
P24 group	Reserved functions	1	1		
P24.00	Reserved	0–65535	0-65535	0	
P24.01	Reserved	0-65535	0-65535	0	•
P24.02	Reserved	0-65535	0-65535	0	
P24.03	Reserved	0 65525	0 65535	0	
P24.04	Reserved	0_65535	0-65535	0	
P24.06	Reserved	0-65535	0-65535	0	
P24.07	Reserved	0-65535	0-65535	0	•

Function	Name	Description	Setting	Default	Modify
P24.08	Reserved	0-65535	0-65535	0	
P24.09	Reserved	0-65535	0-65535	0	
P24.10	Reserved	0-65535	0-65535	0	•
P24.11	Reserved	0-65535	0-65535	0	•
P24.12	Reserved	0–65535	0-65535	0	•
P24.13	Reserved	0-65535	0-65535	0	
P24.14	Reserved	0-65535	0-65535	0	•
P24.15	Reserved	0-65535	0-65535	0	
P24.16	Reserved	0-65535	0-65535	0	
P24.17	Reserved	0-65535	0-65535	0	
P24.18	Reserved	0-65535	0-65535	0	
P24.19	Reserved	0-65535	0-65535	0	
P24.20	Reserved	0-65535	0-65535	0	
P24.20	Reserved	0–65535	0-65535	0	
P24.22	Reserved	0–65535	0-65535	0	
P24.23	Reserved	0–65535	0-65535	0	•
P24.24-	Decented	0 65525	0 65525	0	
P24.52	Reserved	0-65535	0-00030	0	•
P25 group	Transformer protectio	n			1
P25.00	Max. input voltage imbalance	0.0-6553.5%	0.0–6553.5	0.0	0
P25.01	Max. input current imbalance	0.0-6553.5%	0.0-6553.5	0.0	0
P25.02	Input voltage R	0-65535V	0-65535	0	0
P25.03	Input voltage S	0-65535V	0-65535	0	0
P25.04	Input voltage T	0-65535V	0-65535	0	$\bigcirc$
P25.05	Input current R	0.0-6553.5A	0.0-6553.5	0.0	$\bigcirc$
P25.06	Input current S	0.0-6553.5A	0.0-6553.5	0.0	$\bigcirc$
P25.07	Input current T	0.0-6553.5A	0.0-6553.5	0.0	0
P25.08	Filter value of input voltage R imbalance	0-65535V	0-65535	0	0
P25.09	Filter value of input voltage S imbalance	0-65535V	0-65535	0	0
P25.10	Filter value of input voltage T imbalance	0-65535V	0-65535	0	0
P25.11	Filter value of input current R imbalance	0.0-6553.5A	0.0-6553.5	0.0	0
P25.12	Filter value of input current S imbalance	0.0-6553.5A	0.0-6553.5	0.0	0
P25.13	Filter value of input current T imbalance	0.0-6553.5A	0.0-6553.5	0.0	0
P25.14	Fault word of transformer protection	0–65535	0-65535	0	0
P25.15- P25.56	Reserved	0-65535	0-65535	0	0

Function code	Name	Description	Setting range	Default	Modify
P25.57	Transformer protection constant 1	0.0-6553.5%	0.0-6553.5	5.0	0
P25.58	Transformer protection constant 2	0.0–6553.5	0.0-6553.5	0.5	0
P25.59	Transformer protection constant 3	0.00–655.35	0.00-655.35	1.00	$\bigcirc$
P25.60	Transformer protection constant 4	0.0-6553.5%	0.0–6553.5	25.0	0
P25.61	Transformer protection constant 5	0.0-100.0%	0.0-100.0	30.0	0
P25.62	Transformer protection constant 6	0.0-100.0%	0.0-100.0	40.0	0
P25.63	Transformer protection constant 7	0.0-100.0%	0.0-100.0	40.0	0
P25.64	Transformer protection constant 8	0.0–50.0A	0.0-50.0	5.0	0
P25.65	Transformer protection constant 9	0–5000ms	0–5000	2000	0
P25.66- P25.71	Reserved	0–65535	0-65535	0	0
P28 group	SD card functions				
P28.00	Number of files to be reserved	3–10 (The maximum number of files that can be saved for each type of file, such as alarm records, operation records, waveform files saved after fault triggering, etc.)	3-10	5	O
P28.01	File size	0.1-10.0M	0.1-10.0	1.0M	O
P28.02	Retention cycle of running records	0.5–30.0Min	0.0-30.0	0.5Min	O
P28.03	Year setting	When P28.07 is 0, the real time of	0–9999	Year	$\bigcirc$
P28.04	Month and day setting	ARM is displayed, and P28.03– P28.06 update the time in real	1.01-12.31	Mon Day	0
P28.05	Hour and minute setting	time. The RTC time can be modified by	0.0-23.59	Hour Min	0
P28.06	Seconds setting	modifying P28.07.	0–59	Sec	$\bigcirc$
P28.07	Setting mode enabling	Operation steps for configuring time: 1. Input 2 to P28.07, the time stops updating at this time. 2. Change the date and time. 3. Input 1 to P28.07, when P28.07 is 0, it indicates that the configuration is complete.	0-2	0	0
P28.08	Reserved	0-65535	0-65535	0	0
P28.09	Reserved	0–65535	0-65535	0	$\bigcirc$

Function code	Name	Description	Setting range	Default	Modify
P28.10	Fault storage mode	0–2 0: Disable 1: Trigger the storage mode 2: Reserved	0-2	1	O
P28.11	SD card state feedback	SD card state feedback (feedback whether the previous operation is successful): 0: System power-on, if no SD card is inserted or SD card is invalid, the value is 0. 1: The initialization of the SD card is successful, waiting for SD card operation. 2: SD card reading failure 3: SD card writing failure 4: File opening failure 5: File creation failure 6: The operation is successful	0–6	0	O
P28.12	Save function code configuration files (Number of function code groups, number of function codes and VFD model information)	0: Initial value, no operation 1: Save the function codes, and copy the configuration files to the SD card 2: The execution succeeds 3: The execution fails.	0–3	0	0
P28.13	Save function codes	0: Save function codes to the file 0 1: Save function codes to the file 1 2: Save function codes to the file 2	0–2	0	O
P28.14	Restore function codes	0: Restore function codes from the function code parameter file 0 1: Restore function codes from the function code parameter file 1 2: Restore function codes from the function code parameter file 2	0-2	0	O
P28.15	Save function codes to the SD card	0: Disable 1: Generate parameter files (unreadable) 2: Generate reports (.csv) 3: The execution succeeds 4: The execution fails.	0-4	0	O
P28.16	Restore function code settings from the SD card	0: Disable 1: Full recovery (including motor parameter groups) 2: Filter recovery (excluding motor parameter groups) 3: The execution succeeds 4: The execution fails.	0-4	0	O

Function code	Name	Description	Setting range	Default	Modify
P28.17	Sampling channel 1	0: No function	0-20	1	
P28.18	Sampling channel 2	1: Running frequency	0–20	2	
P28.19	Sampling channel 3	2: Output voltage	0–20	3	
P28.20	Sampling channel 4	3: Input voltage	0–20	4	
P28.21	Sampling channel 5	4: Output U-phase current	0–20	5	
P28.22	Sampling channel 6	5: Output V-phase current	0–20	6	
P28.23	Sampling channel 7	6: Output W-phase current	0–20	7	
P28.24	Sampling channel 8	7: Q-axis angle	0–20	8	
P28.25	Sampling channel 9	8: T-axis angle	0–20	9	
		9: Output current M-axis			
P28.26	Sampling channel 10	component 10: Output current T-axis component 11–20: Reserved	0–20	10	•
P29 group	Factory parameters				
P29.00	Factory password	0–65535	0-65535	***	
P29.01	VFD model	0–20	0–20	Model depended	0
P29.02	VFD rated power	4–50000kW	4–50000	Model depended	0
P29.03	VFD rated voltage	10-20000V	10-20000	Model depended	O
P29.04	Actual grid voltage	10-20000V	10-20000	Model depended	O
P29.05	VFD rated current	0.0-1000.0A	0.0-1000.0	Model depended	0
P29.06	Unit output selection	0x000-0xFFF	0x000-0xFFF	Voltage depended	O
P29.07	Deadzone time	0.0μs–10.0μs	0.0-10.0	Model depended	O
P29.08	A-phase unit fault shield	0x000-0xFFF	0x000-0xFFF	Voltage depended	O
P29.09	B-phase unit fault shield	0x000-0xFFF	0x000-0xFFF	Voltage depended	O
P29.10	C-phase unit fault shield	0x000-0xFFF	0x000-0xFFF	Voltage depended	O
P29.11	Unit software overvoltage point	0-1500V	0–1500	Model depended	O
P29.12	Unit ready voltage	0-1000V	0-1000	Model depended	O
P29.13	Software overcurrent point	50.0%–200.0%	50.0-200.0	190.0%	0
P29.14	U-phase bus voltage calibration coefficient	50.0%–150.0%	50.0-150.0	100.0%	O
P29.15	V-phase bus voltage calibration coefficient	50.0%–150.0%	50.0-150.0	100.0%	O
P29.16	W-phase bus voltage	50.0%-150.0%	50.0-150.0	100.0%	$\bigcirc$

## Goodrive5000 series medium voltage variable-frequency speed regulation system

Function code	Name	Description	Setting range	Default	Modify
	calibration coefficient				
P29.17	Input voltage calibration coefficient	30.0%–200.0%	30.0-200.0	100.0%	0
P29.18	Input current calibration coefficient	50.0%-150.0%	50.0-150.0	100.0%	0
P29.19	Output voltage calibration coefficient	30.0%–200.0%	30.0-200.0	100.0%	0
P29.20	Output current calibration coefficient	50.0%-150.0%	50.0-150.0	100.0%	0
P29.21	Bypass mode	0: IGBT bypass 1: Contactor bypass	0-1	0	O
P29.22	Reserved	0–65535	0-65535	0	O
P29.23	Factory time setting	0–65535	0-65535	0h	$\bigcirc$
P29.24	Reserved	0–65535	0-65535	0	$\bigcirc$
P29.25	Factory bar code 1	500–2000	500-2000	1500	$\bigcirc$
P29.26	Factory bar code 2	500–2000	500-2000	1500	$\bigcirc$
P29.27	Running mode	0: User mode 1: Low voltage commissioning mode	0-1	0	•
P29.28	Precharge configuration	0: Not configured 1: The precharge resistor is configured.	0-1	0	•
P29.29	UPS configuration	0: UPS is not configured 1: UPS is configured	0-1	0	•

Your Trusted Industry Automation Solution Provider



Shenzhen INVT Electric Co., Ltd. Address: INVT Guangming Technology Building, Songbai Road, Matian, Guangming District, Shenzhen, China

INVT Power Electronics (Suzhou) Co., Ltd. Address: No. 1 Kunlun Mountain Road, Science & Technology Town, Gaoxin District, Suzhou, Jiangsu, China





Copyright© INVT. Manual information may be subject to change without prior notice.



INVT mobile website

INVT e-manual