

TS600 Series Programmable Logic Controller

Programming and Application Manual



SHENZHEN INVT ELECTRIC CO., LTD.

TS600 Series Programmable Logic Controller Programming and Application Manual

No.	Change description	Version	Change date
	• Updated section 9.2.2 Scanning Device.		
	• Updated section 9.2.3 Master Setting.		
	• Updated section 16.1 TS600 Series Host Local Expansion		
	Module.		
	• Updated section 19.3 Fault Code List.		
	• Updated section 20 Firmware Burning and Upgrade.		

Preface

TS600 is a new-generation compact PLC series product independently developed by INVT. With powerful motion control and distributed I/O control functions, it supports EtherCAT fieldbus communication, can conveniently realize user process movement through custom variables, axis control configuration and graphic block instructions, and can realize multi-level network communication via RS485, CAN, EtherCAT interfaces.

TS600 series full-scene compact controllers are available in multiple models to meet various needs of users for compact automation equipment, and are suitable for compact design, multi-axis motion control, temperature control, communication networking and other scenarios.

This manual mainly introduces the basic knowledge of PLC programming, quick start, communication, motion control, the usage of high-speed counter of TS600 series, etc. The software interface in the manual may vary due to different versions.

This manual applies to the following readers: Personnel with electrical professional knowledge (such as qualified electrical engineers or personnel with equivalent knowledge).

The users using this product for the first time should read this manual carefully first. If you have any technical problems, please contact our customer service.

This manual is not delivered along with the product. To obtain an electronic version of the PDF file, you can:

Log in to INVT's official website (www.invt.com) \rightarrow Service and Support \rightarrow Data Download \rightarrow Search for keywords and download.

List of related manuals

Name	Ordering Code
TS600 Series Programmable Logic Controller User Manual	66001-01167
TS600 Series Programmable Logic Controller Command Manual	66001-01290

Contents

Preface	
Contents	iii
1 Overview	
1.1 Product Overview	1
1.2 One-stop Solutions	
2 Quick Start	
2.1 Programming Software	
2.1.1 Software Introduction	
2.1.2 Computer Configuration Requirements	
2.1.3 How to Get Our Software	
2.1.4 Auto Station Pro Programming Software Installation Process	
2.1.5 Auto Station Pro Running Interface	2
2.1.6 Programming Language	
2.2 Communication Settings	
2.2.1 Communication Connection Method	3
2.2.2 Ethernet Connection	
2.3 Typical Steps of Programming for Users	
2.4 Programming and Debugging	
2.4.1 Sample Project Requirements	5
2.4.2 Start the Programming Environment	
2.4.3 Establish a Project	5
2.4.4 Write a Control Program	
2.4.5 Establish a Communication Connection	6
2.4.6 Compile and Download the Program	7
2.4.7 Start the Programmable Controller	
2.5 Switch PLC Working Mode	
2.6 Trace	9
2.6.1 Function Introduction	9
2.6.2 Operating Steps	9
2.7 Scan Period Setting	11
2.7.1 Time Setting	
3 Basic Knowledge of Programming	
3.1 Summary	
3.2 Soft Element	
3.2.1 Bit Soft Element	
3.2.2 Word Soft Element	
3.2.3 Bit Operation of Word Elements	
3.3 Variables	
3.3.1 Custom Variables	
3.3.2 Define Variables	
3.3.3 Define Arrays	15
3.3.4 Define Struct	
3.3.5 Bit Operation of Variables	
3.3.6 How to Use Variables	
3.4 Variable Binding Address	
3.4.1 Overview	
3.4.2 Variable Attribute	
3.4.3 Bind Array Variables to Soft Elements	
3.5 Use a Variable as Array Subscript	
3.5.1 Rules of Usage	
3.5.2 Basic Combination Types	
3.5.3 Complex combination Type	
3.5.4 Programming Instance	19

TS600 Series Programmable Logic Controller Programming and Application Manual	Contents
3.6 Graphic Block Instruction	21
3.6.1 Composition of Graphic Blocks	
3.6.2 Graphic Block Instruction Programming	21
3.7 Library Functions	
3.7.1 Example of Exporting an Addition Library	
3.7.2 Example of Importing An Addition Library	24
3.7.3 Call Library Functions	25
3.8 System Variables	27
3.8.1 Overview	
3.8.2 List of System Variables	
3.8.3 SYS_CAN CAN Interface Running Information	
3.8.4 _SYS_COM Serial Port Running Information	
3.8.5 _SYS_ECAT EtherCAT Running Status Information	
3.8.6 _SYS_ETHERNET Ethernet Information	
3.8.7 _SYS_INFO PLC Running Information	
3.9 Timer	
3.9.1 TON	
3.9.2 TONR	
3.9.3 TOF	
3.9.4 TMON	
3.10 Function Block and Function (FB/FC)	
3.10.1 Function Block (FB)	
3.10.2 Function (FC)	
4 User C language	
4.1 Overview	
4.2 Instruction Format	
4.3 Operating Steps	
4.4 Use Case	
5 Programming Language	
5.1 Ladder Diagram (LAD)	
5.1.1 Concept of Ladder Diagram	
5.1.2 Basic Programming Elements of Ladder Diagram	
5.1.3 Energy Flow	
5.2 Instruction List (IL)	
5.3 Sequential Function Chart (SFC)	
6 Serial Communication	
6.1 Serial Communication Resources 6.1.1 Supported Serial Communication Protocols	
6.1.2 Applicable Baud Rate 6.2 Link characteristics	
6.3 RS485 Power Terminal Wiring	
6.4 Serial Networking Connection	
6.5 RS232 Interface	
6.6 Freeport Communication Protocol	
6.6.1 Brief Introduction	
6.6.2 Setting of Freeport Parameters	
6.7 Modbus-RTU/ASCII Master	
6.7.1 Brief Introduction	
6.7.2 Serial Port Setting	
6.7.3 Master Setting	
6.7.4 Master Configuration Table	
6.8 Modbus-RTU/ASCII Slave	
6.8.1 Brief Introduction	
6.8.2 Slave Settings	
6.8.3 Slave Related Information	
6.9 Modbus-RTU Communication Application Example	
6.9.1 Brief Introduction	
6.9.2 Enable Master	
6.9.3 Enable Master	

TS600 Series Programmable Logic Controller Programming and Application Manual	Contents
6.9.4 Example Phenomenon	
7 Ethernet Communication	
7.1 Ethernet Communication Resources	
7.2 Ethernet Wiring Example	
7.3 Ethernet IP Address	
7.3.1 Factory Default IP Address	
7.3.2 Modify IP Address in Upper Computer Interface	
7.3.3 Modify IP address with System Variables	
7.4 TCP Free protocol	
7.5 UDP Free Protocol	
7.6 Modbus TCP Master	
7.6.1 Brief Introduction	
7.6.2 Modbus TCP Master Settings	
7.6.3 Modbus TCP Master Configuration Table	
7.7 Modbus TCP Slave	
7.7.1 Brief Introduction	
7.7.2 Modbus TCP Slave Settings	
7.7.3 Slave Related Information	
7.8 Modbus TCP Communication Application Example	
7.8.1 Brief Introduction	
7.8.2 Modbus TCP Master Settings	
7.8.3 Modbus-TCP Slave Settings	
7.8.4 Example Phenomenon	
8 CAN Communication	
8.1 Overview	
8.2 Hardware Interface	
8.3 CAN Network	
8.3.1 CAN Communication Networking	
8.3.2 Communication Distance Corresponding to CAN Baud Rate	
8.3.3 CAN Interface System Variable	
8.4 CANopen Communication Instruction	
8.4.1 CANopen Communication Protocol	
8.4.2 CANopen Axis Control Instruction List	
8.4.3 Explanation of CANopen-related Terms	
8.4.4 CANopen Indicators	
8.5 CANopen Configuration	
8.5.1 Master Configuration	
8.5.2 Slave Configuration	
8.5.3 PDO Enabling	
8.5.4 PDO Mapping Editing	
8.5.5 PDO Attribute Settings	
8.5.6 Service Data Object	
8.5.7 Online Debugging Function	
8.5.8 I/O Mapping	
8.5.9 Device Information	
8.5.10 CANopen Slave Description	
8.6 Troubleshooting of CANopen Communication	
8.6.1 Common Troubleshooting Steps	
8.6.2 Fault Code List	
8.7 CAN Free Protocol	
8.7.1 Function Introduction of CAN Free Format	
8.7.2 Communication Specifications of CAN Free Format	
8.7.3 CAN Free Port Configuration	
8.7.4 CAN Free Format Data Sending and Receiving	
9 EtherCAT Communication	
9.1 Overview	
9.2 Master Configuration	
9.2.1 Import Device XML	
9.2.2 Scanning Device	

TS600 Series Programmable Logic Controller Programming and Application Manual	Contents
9.2.3 Master Setting	
9.2.4 Start-stop & Disable & Enable	
9.2.5 Summary of System Variables	
9.3 Slave Configuration	
9.3.1 General Settings	
9.3.2 Process Data	
9.3.3 Startup Parameters	
9.3.4 I/O Function Mapping	
9.3.5 Start-stop/Disable/Enable	
9.3.6 Disable Slave by Instruction	
9.3.7 System Variables	
9.4 Fault and Diagnosis	
9.4.1 Fault Acquisition	
9.4.2 Fault Code	
10 EtherNet/IP Communication	
10.1 Overview	
10.2 Class1 Communication	
10.2.1 Slave Configuration	
10.2.2 Use Example of Slave	
11 Motion Control 11.1 Brief Introduction of Motion Control Axis	
11.1 Bher Introduction of Motion Control Axis	
11.1.2 PLCopen State Machine	
11.1.2 PLCOPEN State Machine	
11.1.4 Axis Configuration Parameters	
11.1.5 Axis System Variable	
11.1.6 Axis Instruction List	
11.2 Motion Control Axis Setting Steps	
11.2.1 Create a New Project Document	
11.2.2 Create Project Configuration	
11.2.3 Set Axis Parameters	
11.2.4 Write a Program	
11.2.5 Download Project	
11.2.6 Basic Motion	
11.3 Motion Control Axis Configuration	
11.3.1 Comparison of Fieldbus Servo Axis and Local Pulse Axis	
11.3.2 Basic Settings	
11.3.3 Mode Setting	
11.3.4 Axis Speed Setting	
11.3.5 Probe Setting	
11.3.6 Output Settings	
11.3.7 Home Setting	
11.4 Online Monitoring	
11.5 Axis Control Function	
11.5.1 Overview	
11.5.2 Online Debugging	
11.5.3 Instruction Control Rule	
11.5.4 Limit Processing	
11.5.5 Positioning Acceleration and Deceleration Curve	
11.6 Fault Type	
12 High-speed Counter	
12.1 Brief Introduction of High-speed Counter Axis	
12.2 Create a Counter Axis	
12.3 Counter Axis Unit and Conversion	
12.4 Set the Working Mode 12.4.1 Linear Mode	
12.4.1 Lifear Mode	
12.4.2 Rotation mode	
12.5.1 Overview	

TS600 Series Programmable Logic Controller Programming and Application Manual	Contents
12.5.2 Counting Mode	
12.5.3 Hardware Reset Settings	
12.5.4 Probe Setting	
12.5.5 Preset Settings	
12.5.6 Comparison Output Settings	
12.6 Application of Encoder Axis Instruction	
12.6.1 Overview	
12.6.2 Axis Position Ranging/Speed Measurement Instruction	
12.6.3 Axis Position Preset Instruction	
12.6.4 Probe Instruction	
12.6.5 Single-step Comparison Instruction	
12.6.6 Continuous Comparison Instruction	
12.6.7 Array Comparison Instruction	
12.6.8 Hardware Comparison Output of Encoder Axis	
12.6.9 Encoder Axis Comparison Interrupt	
12.6.10 Modify the Gear Ratio of Encoder Axis	
12.6.11 Modify Mode/Limit Value of Encoder Axis	
13 Interpolation Function	
13.1 Brief Introduction of Interpolation Function	
13.1.1 Basic Introduction	
13.1.2 Instruction List	
13.1.3 Upper Computer Axis Group Configuration Interface Configuration	
13.1.4 Online Monitoring	
13.2 Interpolation Operation	
13.2.1 Basic Introduction	
13.2.2 State Machine of Axis Group	
13.2.3 Axle Group Enable and Reset	
13.2.4 Linear Interpolation	
13.2.5 Plane Arc Interpolation	
13.2.6 Axis Group Halt	
13.2.7 Axis Group Stop	
13.2.8 Axis Group Immediate Stop	
13.2.9 Axle Set Speed regulation	
13.2.10 Axis Group Interrupt Mechanism	
14 Electronic Cam Function	
14.1 Brief Introduction of Electronic Cam	
14.2 Software Configuration	
14.2.1 Overview	
14.2.2 Cam Node Setting	
14.2.3 Cam Curve Setting	
14.2.4 Import and Export	
14.2.5 Call Instruction	
14.3 State Machine	
14.4 Electronic Cam Operation	
14.4.1 Gear Action	
14.4.2 Cam Action	
14.4.3 Cam Table	
14.4.4 Master Axis Phase Compensation	
14.4.5 Motion Superposition	
14.4.6 How to Handle Axis Configuration Parameters in Cam or Gear	
15 Memory Formula Management	
15.1 Overview	
15.2 Power-down Variable Keeping	
15.2.1 Range of Power-down Variable Keeping	
15.2.2 Data Retention File Upload and Download	
15.3 Memory Management of Custom Variable Table	
15.3.1 Expand and Fold Complex Type Variables	
15.3.2 Monitor Variables	
15.3.3 Edit Variable Initializations and Comments	

TS600 Series Programmable Logic Controller Programming and Application Manual	Contents
15.3.4 Switch and Display Binary System	
15.4 Memory Management of Soft Elements	
15.4.1 Operation Interface	
15.4.2 Editing Rules for Data Types	
16 Expansion Module	
16.1 TS600 Series Host Local Expansion Module	
16.1.1 Summary of Expansion Module	
16.1.2 Expansion Module System Variables	
16.1.3 Expansion Module Configuration	
16.1.4 Expansion Module Configuration	
16.2 Basic Operation of Local Expansion Module	
16.2.1 Module Enable	
16.2.2 Module Disable	
16.2.3 Get Physical Configuration	
17 Subroutine, Library	
17.1 Subroutine	
17.2 General Subroutine Application	
17.2.1 Matters Needing Attention in the Use of General Subroutines	
17.2.2 Definition of General Subroutine Variable Table	
17.2.3 General Subroutine Parameter Passing	
17.2.4 Examples of Using General Subroutines	
17.3 Interrupt Subroutine Application	
17.3.1 External Interrupt Subroutine	
17.3.2 Timer Interrupt Subroutine	
18 Application of Custom Variable Communication	
18.1 Overview	
18.2 Example Project	
18.2.1 Accessing Custom Variables via Binding to Elements	
18.2.2 Accessing Custom Variables via Tag Communication	
19 Fault Diagnosis	
19.1 Panel Diagnosis	
19.1.1 Indicator	
19.2 Software Diagnosis	
19.2.1 Get the Basic Information of PLC	
19.2.2 View Error Log	
19.3 Fault Code List	
19.3.1 Fault Code Classification	
19.3.2 Fault Code List	
20 Firmware Burning and Upgrade	
20.1 Upper Computer Firmware Upgrade	
20.2 SD Card Firmware Upgrade	
20.2.1 Step of Generating PLC Application Upgrade Package	
20.2.2 SD Card Upgrading Steps	
20.3 Upgrade of Upper Computer Applications or Open the Project	
20.3.1 Upgrade Applications with Upgrade Pack	
20.3.2 Open a Project with Upgrade Pack	
21 4G IoT Expansion Card	
21.1 Overview	
21.2 User Login of IoT Monitoring Platform	
21.3 Add a Device Type	
21.4 Add Devices to IoT Platform	
21.5 Device Installation & Wiring	
21.6 Establish VPN Transparent Transmission Channel	
21.6.1 Connect PLC Remotely through VPN	
21.6.2 FAQ	
21.7 Web Page Monitoring	
21.7 Web Page Monitoring 21.8 Module Interface Description	
	299

TS600 Series Programmable Logic Controller Programming and Application Manual	Contents
22.1.1 Modbus RTU	
22.1.2 Modbus ASCII	
22.1.3 Modbus TCP	
22.1.4 Modbus Function Code	
22.1.5 Example of Modbus Message Parsing	
22.1.6 Modbus Abnormal Response	

1 Overview

1.1 Product Overview

TS600 is a series of new-generation small PLC products independently developed by INVT. With powerful motion control and distributed I/O control functions, it supports EtherCAT fieldbus communication, can conveniently realize user process movement through custom variables, axis control configuration and graphic block instructions, and can realize multi-level network communication via RS485, CAN, EtherCAT interfaces.

TS600 series full-scene compact controllers are available in multiple models to meet various needs of users for compact automation equipment, and are suitable for compact design, multi-axis motion control, temperature control, communication networking and other scenarios.

1.2 One-stop Solutions

The typical application topology of TS600 series solution is illustrated by TS600 series TS635, as shown in the following figure.




Figure 1-1 Typical Application Topology of TS635

2 Quick Start

2.1 Programming Software

2.1.1 Software Introduction

Auto Station Pro is the upper computer software of INVT's TS600 Series Small PLC. The user interface of Auto Station Pro programming software is user-friendly, which is convenient for users to configure, program, debug, download and monitor PLC as required.

2.1.2 Computer Configuration Requirements

ltem	Minimum configuration	Recommended configuration	
CDU	Equivalent to Intel's Pentium D805 or	Equivalent to Intel's Pentium Dual G4620 or	
CPU	above	above	
Memory	4GB	Above 4GB	
Craphics cord	Functional in 1280 \times 640 resolution	Functional in 1280 $ imes$ 640 resolution and	
Graphics card	and 256 color mode	65535 color mode	
OS	Windows 7 and later	Windows 7 and later	
Communication	USD type Cinterface D145		
ports	USB type-C interface, RJ45		
Other devices	Power supply		

Table 2-1 Basic Configuration of Auto Station Pro Programming Environment

2.1.3 How to Get Our Software

Auto Station Pro is free, and users can download the software installation package in the application software options of "Services and Support" > "Data Download" on INVT official website (www.invt.com).

Our Company is constantly improving products and materials, so the users should update the software version in time when they need it, and consult the latest released reference materials, which is beneficial to the program design of users.

2.1.4 Auto Station Pro Programming Software Installation Process

The Auto Station Pro installation package released by Shenzhen INVT Electric Co., Ltd. is a separate executable program whose installation process can be started by double-clicking.

- 1. Follow the installation wizard step by step. Users can choose different installation paths as required.
- 2. After installation, the INVT program group will appear in the Start menu; At the same time, the installer will also install the Auto Station Pro shortcut icon on the desktop.
- 3. Double-click the shortcut icon to run the program.

Uninstall: The software can be uninstalled through Windows Control Panel.

Note: To upgrade and install the new version of Auto Station Pro, please uninstall the old version of Auto Station Pro first.

2.1.5 Auto Station Pro Running Interface

The main interface of this program basically includes 5 parts: menu bar and toolbar, "Project manger" window, "Instruction tree" window, "Messages output" window and workspace.

Auto Station Pro V1.2.9 - [D:\Users\Administrator\Documents\002.tsp2] - [MAIN]	X
File(F) Edit(E) View(V) Ladder(L) PLC(P) Debugging(D) Tool(T) W	findow(W) Help(H)	∠ & & & ⊕
		✓ ps × ps × ps Find Last Nee
Image: System variable table Image: System variable tabl	[1004 30 130] [1004 99 132760 130]	
Compile @ Communication @ Conversion Q Find	\$	Wood Contacte Instanction
For help, press F1	Disconnect	Rewri Row: 10, Column: 8

Figure 2-1 Auto Station Pro Main Interface

No.	Name	Description		
1	Main menu bar and shortcut toolbar	Programming software operation menu, including programming, debugging, communication and other related settings, file management and programming debugging shortcuts		
2	Project manager	It includes program management, variable management, parameter management and configuration management of PLC projects.		
3	Workspace	Used to write user programs		
4	"Instruction tree" window	Used to load the instruction set supported by PLC in the project, and load the expansion module supported by PLC		
5	"Messages output" window	It includes compilation information, communication information, transformation information, and search information		

2.1.6 Programming Language

The programming languages supported by Auto Station Pro include:

- Ladder diagram (LAD)
- Instruction List (IL)
- Sequential Function Chart (SFC)
- User C language

2.2 Communication Settings

2.2.1 Communication Connection Method

The communication connection with Auto Station Pro can be established via USB interface or Ethernet to realize the download, monitoring and debugging of programs.

2.2.2 Ethernet Connection

When users connect PLC via Ethernet, the operations involved may include selecting network port, reading IP address of device, modifying IP address of device and PING function. This section will focus on these operations.

Double-click Ethernet 1 in the "Project manager" bar, as shown on the left side of the figure below, and the menu of Ethernet 1 in the system block will pop up as shown on the right side of the figure below.

PLC network port setting

IP address, subnet mask and gateway address can be clicked to read the current configuration value. If you need to change it, you can modify it and click to write. The default IP of Ethernet 1 is 192.168.1.10. If you need to factory reset the settings, you can click to reset IP.

The high-end model of TS600 has two Ethernet ports, and you should reference Ethernet 1 for the reading and writing of IP of Ethernet 2.

File(F) Edit(E) View(V) Ladder(L) PLC(P) Debugging ^S)	/stem Block Ethernet1 - Dialog		×
Image: Image:	Master configuration ModeuxaTCP master Enable control element X0	Slave configuration Slave configuration Slave por number: 502	IDEL Instruc I C I C I C
 Y = nos group setting ♥ EtherCAT ♥ COM1 ♥ COM2 ♥ Ethernet1 ♥ Ethernet2 ♥ Ethernet2 	PLC Elhenet seting IP address: 192 168 1 10 Subnet Maik: 255 255 0 0 Gatemay Address: 132 168 1 1	Read Reset IP Wite Identification device	
Cross-reference table Cross-reference table Cross-reference table Trace resegres output window	-SOCKET	ierver Udg-Peer	
		OK Cancel Hel	p

PING function

Auto station Pro comes with PING function, which can test whether the network connection between computer and target PLC device is normal, and the destination IP address should be filled in correctly during the test.

ogramming	port setting)
PLC - VSB setti VSB por	-	Ethernet	Connect Disconnect	
Ethernet Peer-to Port nu	-peer IP address:	192 .168 . 1 9016	. 10 PING Delay time(m:	s):]
PLC netwo	ork port setting		Fin	d
Number	IP	Device type	Mac address	

2.3 Typical Steps of Programming for Users

The user who uses INVT's PLC products for the first time needs to note that 5 steps are required to write and debug a complete user program. Take TS600 series PLC as an example.

Step 1 Establish a project

Step 2 Start hardware system configuration based on hardware connection architecture of PLC application

system of TS600 series

- A. If only TS600 main module is used, you can go directly to the next step.
- B. If the local expansion module is used, the module needs to be configured. According to the actual selected and mounted module type and model and installation sequence, add and configure the module on the "Expansion module configuration" page of Auto Station Pro.
- Step 3 Complete communication configuration and set corresponding function parameters according to the application requirements

According to the application requirements, set the corresponding functional parameters in "Setting" in the "Project manager".

- Step 4 According to the application requirements, write user programs and establish related variables
- Step 5 Connect PLC in Auto Station Pro programming environment, compile, download, debug and troubleshoot the user program until it runs correctly.

2.4 Programming and Debugging

2.4.1 Sample Project Requirements

Complete a marquee programming and debugging process: Suppose the output Y0, Y1, Y2 respectively control three lights, a red one, a yellow one and a green one, and use input X0 as a start switch, the program will do the following control:

- When the switch is turned on, the red, yellow and green lights are lit alternately for 2 seconds each (using timers T0, T1 and T2 with an accuracy of 100ms)
- When the switch is turned off, the three lights go out

2.4.2 Start the Programming Environment

After the programming software is installed correctly, click the programming software icon from the Start menu bar to start the software. The main interface is as shown in Figure 2-2.




Figure 2-2 Auto Station Pro Startup Main Interface

2.4.3 Establish a Project

Create a new TS635 project by choosing "Default editor" (ladder diagram, instruction list, sequential function chart), as shown in Figure 2-3.

Figure 2-3 Auto Station Pro: New Project Interface


TS600	Project setting Name:		
	Location: D:\Users\Administrato	r\Documents\	
	Default editor: Ladder		
TS633		~	
	Project description:		
TS635	Device description		
		Network bus type operation control PLC	Hore
	Local digital I/0:	32(16 inputs/16 outputs)	Hore
	Operational control capability:	Maximum 36 axis	Nore
	Electronic cam/gear:	Support	Nore
	High-speed input:	8 x 200K high-speed input	Hore
	High-speed output:	4-axis 200K pulse output	Hore
	Right module expansion:	Support, up to 16	Mox e
	Left expansion card:	Support	More
	Ethernet:	2 independent network ports	More
	Serial port communication:	2 x 485	More
	EtherCAT:	1 channel, max 72 slaves	More
	axis synchronization cycleperiod:	16 axis/1ms	More
	CAN:	CANOpen, Maximum 32 axis	More
	Other interfaces:	1 x USB (Type-C)	Nore
	Program capacity:	200K steps	Nore
	Data capacity:	Customized variables 2MB	Hore
	Command speed:	Simple command 20K steps 0.2ms	Hore
	C subroutines:	Support	Hore

2.4.4 Write a Control Program

Figure 2-4 Creating related variables

🖥 MAIN	📑 Global variable table	1				4 ⊳	×
	Variable Name	Data Type	Initial Value	Power Down	Comments	Element A	J b.
1	Interval	INT	20	No Hold			
2							

Figure 2-5 Programming user programs



2.4.5 Establish a Communication Connection

Choose "Menu bar" > "Tool" > "PLC communication". The interface is as shown in Figure 2-6.

PLC OUSB OE Ethernet Connect USB setting USB port: COMI Disconnect Ethernet setting Peer-to-peer IP address: 192.168.1.10 FING Delay time(ms): Port number: 9016 5000 FING Delay time(ms): FLC network port setting Find	0			
USB setting USB port: COMI Ethernet setting Peer-to-peer IP address: 192 .168 . 1 . 10 FING Port number: 9016 PLC network port setting Find	ramming	port setting		
thernet setting Peer-to-peer IP address: 192 .168 . 1 . 10 PING Delay time(ms): Fort number: 9016 C network port setting Find	JSB setti	ng	Ethernet	
Peer-to-peer IP address: 192 .168 . 1 . 10 PING Delay time(ms): Fort number: 9016 5000 LC network port setting Find	thernet	setting		DISCOMECT
Find	Peer-to	-peer IP address:		
	LC netwo	rk port setting	-	
	- 1			
Number IP Device type Mac address	Number	IP	Device type	Mac address

Figure 2-6 Establishing Communication Connection

For "PLC", you can choose USB communication or Ethernet communication.

- To select USB, you need to choose "USB". After selecting the port, click "Connect", as shown in Figure 2-7.
- When choosing Ethernet connection, you need to set the "IP address" of the lower computer, then click "Connect", as shown in Figure 2-8.







Figure 2-8 Establishing Ethernet Connection



2.4.6 Compile and Download the Program

Step 1 Open the edited PLC program and click the compile button store to compile. The difference between these two compile buttons is that the left one is used to compile only the program on the currently open page, and the right one is used to compile the entire project.
After compiling, the compilation information is output below the software.

Figure 2-9 Successfully Compiled



Step 2 After successful compilation, you can click the Download button in to download. When downloading the program, PLC must stop. If PLC is running, the system will prompt with a dialog box, as shown in Figure 2-10.

Figure 2-10) Stop Runnii	ng ×
Note: The PLC is in the ru want to stop the PLC an	nning state, do you co d continue the operat	

Step 3 Click the "OK" button to stop PLC, and the system will prompt with a compiling dialog box, as shown in Figure 2-11.

	ion Pro		
0		ed to recompile before downloading the last compiled files will be downloa	

Step 4 If you don't want to recompile and download the last compilation result, you can select "No", otherwise, you can select "Yes" to recompile the program. After compilation, a download window will appear, as shown in Figure 2-12.



Do	wnload	×
	Download option Download Download Download Download Download User block User data block	
	Whether uploading is allowed	
	• Yes ONo	
	Clear power-down retained data after download O Yes	

According to your needs, select the content to be downloaded in the "Download option". In this example, only the written application program needs to be downloaded. Select the required application program, and click the "Download" button to start downloading. A progress bar will be displayed during the downloading process, and the user will be prompted of the successful download after completion.

2.4.7 Start the Programmable Controller

After the application program is downloaded, you must start the programmable controller to run. Select "PLC" > "Start", or toggle the switch of the programmable controller to RUN. After the programmable controller runs normally, close the switch connected to the input point X0, and you can see that the three lights connected to the output points Y0, Y1 and Y2 are lit in turn.

2.5 Switch PLC Working Mode

- PLC has two working modes, namely RUN and STOP:
 - RUN mode: In this mode, PLC mainly performs X-point input testing, scanning operation of user program, element refresh, Y-point output and communication.
 - STOP mode: In this mode, PLC stops the scanning of user application program and the output of Y point, and the communication also stops.

Note: In STOP mode, if the upper computer is monitoring, PLC will still communicate with the upper computer

- If customers need to switch the working mode of PLC, there are two methods to choose:
 - ♦ Use the physical toggle switch RUN/STOP on the PLC panel to switch.
 - In Auto Station Pro, click the RUN or STOP button
 in the toolbar to switch between Run and Stop state.

2.6 Trace

2.6.1 Function Introduction

In Auto Station Pro, users can use element oscilloscope function, which is similar to digital sampling oscilloscope and can record the historical values of lower computer elements. When Trace function is enabled, Auto Station Pro will start to store the time-stamped value data records. Users can continuously monitor the changes of element values on the element oscilloscope page, which is convenient for program debugging.

2.6.2 Operating Steps

This section demonstrates how to use Trace to capture changes in D0, R0, and VAR_01, and introduces how to operate the element oscilloscope function.

Step 1 Right-click "Trace" in Project Management and click to insert a new Trace Monitoring Table.

Figure 2-13 Open Element Oscilloscope Function

Ethernet1

Ethernet2

EtherNet/IP

Cross-reference table


Element monitor table

Insert(M)


essages output window

Step 2 Double-click the newly created Trace Monitoring Table to enter the Trace interface.

Figure 2-14 Main Interface of Trace




Step 3 Click "Add Variables" in Figure 2-14, and choose the main task from the associated tasks in the "Variable setting" pop-up window. Set variables D0, R0 and VAR_01 to be captured, and then click "OK" to save the variable settings.



Related tasks: Main V		
Trigger mode: == 🗸	Trig	ger value:
Variable type: BOOL 🗸	Number of post-trigger	adoptions:
Trigger variable:		
Variable name: D0 Variable type: REAL 🗸	Add->	D0
Curve color:	<-Delete	

Step 4 After configuring the variables, right-click on the Trace view and choose "Start Track".

Figure 2-16 Element Oscilloscope



 \angle Note: The abscissa and ordinate in the trace state will automatically adjust with the value of variables, and users can also operate with the mouse wheel.

Step 5 Right-click on the Trace view to choose single channel display or multi-channel display.




Figure 2-17 Select Single Channel

2.7 Scan Period Setting

Users can choose two working modes: constant scanning period and inconstant scanning period.

- When choosing constant scanning period, the program runs according to the specified scanning period.
 - When the program running time for testing is less than the set scanning period, PLC scans the ♦ program according to the set period value.

01:40.768

01:40.832


01:40.896

01:40.960


- When the actual program running time is longer than the set scanning period, PLC scans ∻ according to the actual running time.
- When choosing non-constant period (usually the constant scanning time is set to 0), PLC will automatically adjust the scanning period according to the program running time.

2.7.1 Time Setting

Step 1 Double-click or right-click to open "Setting time" in the system block in Project Manager.



Step 2 In the pop-up dialog box, you can set the "Scan period" of the program which is default to 0, that is, the non-constant scanning period mode. In addition, users can also set the "Watchdog time setting" and "Power failure detection time setting ".



Default val	ue	
Watchdog time setting	200	ms
Constant scan time setting	0	ms
Power failure detection time setting	10	ms

Note: The constant scan time setting cannot be greater than the watchdog timer time

3 Basic Knowledge of Programming

3.1 Summary

The variable memory structure used in programming includes soft elements, custom variables and system variables.

- Soft elements: X, Y, M, LM, S, T, C, D, R, V, Z can be directly used in user programs.
- Custom variables: VTD should be defined in the variable table before use.
- System variables: _SYS_CAN, _SYS_COM, _SYS_ECAT, _SYS_ETHERNET, _SYS_INFO, _SYS_AXSI_ENC_INFO, _SYS_AXIS_MC_INFO, _SYS_GROUP_MC_INFO, _SYS_CAM_TABLE, etc. are used to obtain system internal information.

3.2 Soft Element

3.2.1 Bit Soft Element

This PLC programming supports bit soft elements. The specific type, range, points and related description of bit soft elements are shown in the following table.

Туре	Range	Points	Data Type	Description
x	X0-X1777	1,024 points Octal code	BOOL	Input
Y	Y0-Y1777	1,024 points Octal code	BOOL	Output
М	M0-M32767	32768 points	BOOL	 M0–M999: not saved in case of power-down From M1000: saved in case of power-down
LM	LM0-LM63	64 points	BOOL	Local auxiliary relay
S	S0-S4095	4096 points	BOOL	 S0-S999: not saved in case of power-down From S1000: saved in case of power-down
т	T0-T399	400 points	BOOL	 Accuracy 100ms: T0-T199, 200 points Accuracy 10ms: T200-T299, 100 points Accuracy 1ms: T300-T399, 100 points
с	C0-C255	256 points	BOOL	 16-bit ordinary CTUD: C0 - C199, 200 points 32-bit ordinary CTUD: C200 - C255, 56 points

3.2.2 Word Soft Element

This PLC programming supports word soft elements. The specific type, range, points and related description of word soft elements are shown in the following table.

Туре	Range	Points	Data Type	Description
D	D0-D32767	32768 points	BOOL/INT/DINT/WORD/ DWORD/REAL	 D0–D999: not saved in case of power-down From D1000: saved in case of power-down
R	R0-R32767	32768 points	BOOL/INT/DINT/WORD/ DWORD/REAL	 R0–R999: not saved in case of power-down From R1000: saved in case of power-down
V	V0-V63	64	INT	Temporary variable, which can only be used in subroutines
Z	Z0-Z15	16	INT	Not saved in case of power-down
т	T0-T399	400 points	INT	T0–T199: 100ms accuracy T200–T299: 10ms accuracy T300–T399: 1ms accuracy
с	C0-C235	256 points	INT/DINT	C0 – C199: 16-bit CTUD or 16-bit cyclic counter C200 – C255: 32-bit CTUD

Note: The power-down keeping range cannot be changed.

Word soft elements can be used as integers or floating-point numbers. The soft elements themselves do not have data type attribute, and the elements are interpreted as integers or floating-point numbers according to the parameter attributes of instructions.

- When used as a 16-bit integer, it occupies 1 soft element
- When used as a 32-bit integer, it occupies 2 soft element
- When used as a floating point number, it occupies 2 soft elements

Example

• Word soft elements used as 16-bit integers

Use a 16-bit assignment instruction to assign a value of 100 to the word soft element D100, occupying D100.



• Word soft elements used as 32-bit integers

Use a 32-bit assignment instruction to assign a value of 100 to the word soft element D100, occupying D100 (lower order) and D101 (higher order).




• Word soft elements used as floating-point numbers

Use a floating point number to assign a value of 100 to the word soft element D100, occupying D100 and D101.

MO _____ [RMOV 100.0000 D100]

3.2.3 Bit Operation of Word Elements

Bit operation of word elements can be done by (.). For example, D100.8 means operation shall be done to the 8th bit on D100 word element, and the lowest bit is the 0th bit.



Note: The bits of a word element start from bit 0: D100.8 can be regarded as a BOOL element, to which some bit operation instructions can be applied.

3.3 Variables

3.3.1 Custom Variables


In PLC programming system, in addition to using direct addresses, such as X, Y, M, D, R and other elements for programming, it is also possible to program with "variables" without specific addresses stored to realize the required control logic or the complete control process of application objects, thus improving the convenience and readability of code writing.

3.3.2 Define Variables

Custom variables are supported, and users can define global variables and directly use variable name for programming in the program. You need to follow the following rules when defining a global variable name:

- 1. It can only contain "_, letters, numbers, Chinese characters" and cannot start with "_, numbers".
- 2. It cannot have the same name as "soft element form, constant, standard data type, instruction".
- 3. It cannot be a keyword such as "ARRAY, TRUE, FALSE, ON, OFF, NULL, Struct".

Figure 3-1 Defining in Global Variable Table



3.3.3 Define Arrays

Users can define arrays if ARRAY is chosen as the data type when programming.

1. Choose the type and length of array variables in the pop-up dialog box, and click "OK" to define the array, as shown in the following figure.

🚡 MAIN	🛛 👪 Global variable table	1*						
	Variable Name	Data Type	Initial Value	Power Down	Comments	Element Ad	Current Value	Value 1
1	📮 aa	DINT[2]	OFF	No Hold				
2	aa[0]	DINT	0	No Hold				
3	aa[1]	DINT	0	No Hold				

2. Use it directly in the user interface, as shown in the following figure.

				8 8		
MAIN *	👪 Global var	iable table	1			
1						
	MCO I	DMOV	aa[0]	aa[1]]	

3.3.4 Define Struct

Right-click in the global variable table to create a new data structure, and then right-click it to change the name of the struct variable, so as to name the struct member and select the data type of the member. When using the struct variable, the program uses "struct variable name. member variable" to represent the struct member.

Project manager	▼ ₽ ×	MAIN *	🚱 Global variable table 1	Struct1 *		
	^		Variable Name	Data Type		Comments
Program block		1	member0	BOOL	~	
 Frögram bickt M MAIN S SBR_1 User C language Library System variable table Global variable table Struct 	,	2	member1	ARRAY BOOL WORD INT DWORD DINT REAL _strv_MC_DIGTIAL_SWITCH _strv_CAMLNDDE _strv_AXIS_CFG	£	

3.3.5 Bit Operation of Variables

3.3.6 How to Use Variables

After the variables are defined, the variable names can be directly used for programming, and no soft elements need to be assigned.

- Direct programming operation with variables
- When using array variables, the array elements are represented by "[number]" in the program, and the number starts from 0.

3.4 Variable Binding Address

3.4.1 Overview

The custom variables support binding the address of soft element. After binding, the address of custom variables is associated with the address of soft element.

To realize the function of custom variable binding software, you only need to fill the address to be associated in the address field of the variable table. Then, compile the project, and the software will automatically generate the assigned address, as shown in the following figure.

		Project ma	nager	₹ ₽ ×		
		- 🖵 A	ABC(TS635)	^		
		▼ {	} Program block			
			{M} MAIN			
			<pre>{S} SBR_1</pre>			
			📘 User C langu	age		
		E	Library			
		▶ .	System variable ta	able		
		▼ [Global variable ta	ble		
			▼ 🖬 Struct			
			Struct1			
			Software eler	ment list		
			C language g	lobal varia		
			🔚 Global variab	le table 1		
MAIN	🗳 👪 Global variable tabl	e 1 *	<u> </u>			
	Variable Name	Data Type	Initial Value	Power Down	Comments	El
1	test1	BOOL	OFF	No Hold		M1
2	test2	INT	0	No Hold		D1
· ·			1			

3.4.2 Variable Attribute

After a custom variable is bound to a soft element, the power-down retention attribute changes with the bound soft element.

As shown in the following figure, M1000 is in the power-down retention area, so after Test_1 is bound to it, the power-down retention attribute correspondingly changes to retention type; While D100 is in the non-power-down retention area, after Test_2 is bound to it, the power-down retention attribute will change to non-retention type. After the element is bound, the power-down retention attribute changes automatically as the case may be, and users do not need to set it, as shown in the following figure.

	Variable Name	Data Type	Initial Value	Power Down	Comments	Element Ad	Current Value
1	Test_1	BOOL	OFF	Hold		M1000	
2	Test_2	INT	0	No Hold		D100	
3	Test_3	BOOL	OFF	No Hold		YO	
4							
7							

3.4.3 Bind Array Variables to Soft Elements

To bind an array variable to a soft element, you only need to fill the address to be mapped in the address field of the variable table.

- Word variables occupy the number of word elements according to variable type, one INT variable occupies a 16-bit element, and REAL and DINT variables occupy two 16-bit elements each.
- BOOL variables occupy the corresponding number of bit elements.
- Array variables can only bind soft elements of corresponding types, that is, word variables can only bind word elements, and bit variables can only bind bit elements.

For example:

Define the array variable Array_0 of BOOL type, whose length is 10, and specify binding M0 element, then M0 – M9 element will be occupied;

Define the array variable Array_1 of INT type, whose length is 10, and specify binding D0 element, then D0–D9 element will be occupied;

3.5 Use a Variable as Array Subscript

3.5.1 Rules of Usage

General rule of using a variable as array subscript: There is at most one variable which can be used as the subscript in the whole variable set.

The format is defined as array[index] or stru[index]. var, where array represents an array or struct array, index and var represent variables, stru represents a struct, and so on.

3.5.2 Basic Combination Types


- array variables, as variables of array, only support bit variable arrays, word variable arrays, double-word variable arrays and floating-point variable arrays.
- index variable, a variable as an array subscript:
 - ♦ Only single word variable INT (16 bits) and double word variable DINT (32 bits) are supported; A certain element of an array or a certain member of a struct is supported to be an index variable, such as array [index[5]], array[stru.index].
 - Soft elements are not supported, and other variables such as bit variables, floating-point variables, pointer variables, etc. are not supported; array elements with variable subscripts or struct array members are not supported to be index variables, such as array[index[i]], array[stru[i].Index];

3.5.3 Complex combination Type

- The following variable types are supported:
 - ♦ You can use the element of an array as the operand of an instruction, i.e. putting an index variable at the end, such as array[index], stru.array[index], stru1[3]. stru2. array[index], stru1.stru2.stru3. array[index], and so on.
 - You can use the member of a struct array as the operand of the instruction, i.e. putting an index variable in the middle, such as stru[index].var, stru1[index].stru2.var, stru1.stru2[5].stru3[index].array[3], and so on.
- The following variable types are not supported:
 - It is not supported to use a single struct element in a struct array as the operand of an instruction, that is, to put an index variable at the end, such as stru[index], stru1.stru2.stru3[index], stru1.stru2[2].stru3.stru4[index], and so on.
 - ♦ Struct arrays with double or multiple variables, such as stru[index1]. array[index2].
 - ♦ Two-dimensional or multidimensional arrays, such as array[index1][index2].
- Instructions for use:
 - ♦ The operands of the ZSET/ZRST instruction do not support arrays with a subscript variable.
 - ♦ The operands of the PTxxx instruction do not support arrays with a subscript variable.
 - ♦ The operands of SFC instruction do not support arrays with an subscript variable.
 - For operands of instructions that use contiguous variables (array-type operands) (such as BMOV batch assignment instructions), variables in the form of arr[index] can be used in instead of a struct array element in the form of stru[index].var (because it is un-continuous); For jump assignment, you need to use loop instructions to achieve the purpose of batch jump assignment.
 - It is mainly used in the operands of single-cycle instructions, but not recommended in the operands of multi-cycle instructions. If it is used, please strictly control the logic and timing. If the timing control is not good, it may lead to abnormal execution or conflict when the value is switched (such as the axis of pulse output instruction).

3.5.4 Programming Instance

- Example 1
- 1. When assigning a value to an array element, and the program is as follows:



2. Start assigning 123 to i16arr[1], after which each trigger of M300 will assign 321 to each of the following array elements; After startup, the result is as shown in the following figure:

	Element Name	Data Type	Display Fo:	Current Value	New Value
1	 🗏 i16arr	INT[16]	Decimal		
2	i16arr[0]	INT	Decimal	0	
3	i16arr[1]	INT	Decimal	123	
4	i16arr[2]	INT	Decimal	0	
5	i16arr[3]	INT	Decimal	0	
6	i16arr[4]	INT	Decimal	0	
7	i16arr[5]	INT	Decimal	0	
8	i16arr[6]	INT	Decimal	0	
9	i16arr[7]	INT	Decimal	0	
10	i16arr[8]	INT	Decimal	0	
11	i16arr[9]	INT	Decimal	0	
12	i16arr[10]	INT	Decimal	0	
13	i16arr[11]	INT	Decimal	0	
14	i16arr[12]	INT	Decimal	0	
15	i16arr[13]	INT	Decimal	0	
16	i16arr[14]	INT	Decimal	0	

3. After M300 is triggered once, the result is as follows:

	Element Name	Data Type	Display Fo:	Current Value	New Value
1	 🗏 i16arr	INT[16]	Decimal		
2	i16arr[0]	INT	Decimal	0	
3	i16arr[1]	INT	Decimal	123	
4	i16arr[2]	INT	Decimal	321	
5	i16arr[3]	INT	Decimal	0	
6	i16arr[4]	INT	Decimal	0	
7	i16arr[5]	INT	Decimal	0	
8	i16arr[6]	INT	Decimal	0	
9	i16arr[7]	INT	Decimal	0	
10	i16arr[8]	INT	Decimal	0	
11	i16arr[9]	INT	Decimal	0	

4. After M300 is triggered several times, the result is as follows:

	Element Name	Data Type	Display Fo:	Current Value	New Value
1	 🗏 i16arr	INT[16]	Decimal		
2	i16arr[0]	INT	Decimal	0	
3	i16arr[1]	INT	Decimal	123	
4	i16arr[2]	INT	Decimal	321	
5	i16arr[3]	INT	Decimal	321	
6	i16arr[4]	INT	Decimal	321	
7	i16arr[5]	INT	Decimal	321	
8	i16arr[6]	INT	Decimal	0	
9	i16arr[7]	INT	Decimal	0	
10	i16arr[8]	INT	Decimal	0	
11	i16arr[9]	INT	Decimal	0	

- Example 2
- 1. When operating a member variable of struct array, the program is as follows:



2. After M400 is triggered, set stru_arr[2].b_enable, and control stru_arr[4].b_enable, as shown below:



+ × [] ± ∓ ∠ ⊞ ⊞ /∏_2	•				
	Element Nam	ne Data Type	Display For	Current Value	New Value	
1	🖂 stru_arr	Struct1[5]	Decimal			
2	-= stru_arr[0]	Struct1	Decimal			
3	stru_arr[0]]. b_e BOOL	Decimal	OFF	-	
4	stru_arr[0]	. iie INT	Decimal	0		
5	stru_arr[0]	. i32 DINT	Decimal	0		
6	🕞 stru_arr[1]	Struct1	Decimal			
7].b_€ BOOL	Decimal	OFF	20	
8	stru_arr[1]]. i16 INT	Decimal	0		
9	stru_arr[1]]. i32 DINT	Decimal	0		
10	🕞 stru_arr[2]	Struct1	Decimal			
11	stru_arr[2]].b_e BOOL	Decimal	ON		
12	stru_arr[2]]. i16 INT	Decimal	0		
13	stru_arr[2]]. i32 DINT	Decimal	0		
14	🕞 stru_arr[3]	Struct1	Decimal			
15	stru_arr[3]].b_e BOOL	Decimal	OFF		
16	stru_arr[3]]. i16 INT	Decimal	0		
17	stru_arr[3]]. i32 DINT	Decimal	0		
18	🔚 stru_arr[4]	Struct1	Decimal			
19	stru_arr[4]]. b_e BOOL	Decimal	ON		
20	stru_arr[4]]. i16 INT	Decimal	0		
21	stru_arr[4]	. i32 DINT	Decimal	0		
22		WORD	Decimal			


Where, the struct is defined as follows:

	Variable Name	Data Type	
1	b_enable	BOOL	
2	i16_a	INT	
3	i32_b	DINT	
4			

3.6 Graphic Block Instruction

3.6.1 Composition of Graphic Blocks

Some instructions support graphic block programming, and graphic block instructions are composed of instruction name, energy flow signal, input side and output side. Take the motion control axis graphic block instruction as an example, and its specific composition is shown in the following figure.




The floating-point numbers such as target position and target speed in the instruction are of single-precision floating-point format, so the value of the instruction should conform to the range and precision of single-precision floating-point format when processing in PLC program, that is, its numerical range is -3.4E38–3.4E38, and the precision is 7 significant digits. If the significant digits of a certain number exceed 7 digits, the extra digits will be automatically rounded.

3.6.2 Graphic Block Instruction Programming


1. When programming, users need to drag the graphic block instruction from the instruction tree on the right side of the upper computer to the left, and then add the graphic block instruction to the program network. The graphic block supports direct editing of instruction parameters. As shown in the following figure:

↓ ★ Instruction tree
Find Last Next
Control Calculation Instruction
► 🤣 Verification Instruction
► 🤣 Axis control (pulse input)
🔲 MC_SetAxisConfigPara (Axis configurai
MC_Power (Enable)
MC_Reset (Reset)



Input parameters in the graphic block instruction to complete the editing of the graphic block instruction.

- 1) "???" means parameters are required.
- ② You can choose whether to use parameters. If no parameters are used, the instruction input is default to the parameter values automatically, and the instruction state cannot be obtained when the instruction output is in the program or monitored and debugged.
- 2. All instructions under the toolbox instruction set node are in graphic block mode. When programming, you can directly double-click the instructions under the toolbox instruction set node and add the instructions to the current focus position of the ladder diagram, as shown in the following figure:





- ① Double-click the instruction to add it to the ladder diagram
- ② The instruction is added successfully

3.7 Library Functions

Library functions encapsulate reusable program blocks of a program into a universal library, and the program blocks in the encapsulated library can be repeatedly called in the program of different projects.

Using encapsulated libraries in programming enhances program development efficiency, reduces programming errors, and improves program quality.

The basic step to use library functions is as follows: Choose "Create a library project to be encapsulated" \rightarrow "Write the program" -> "Export a library file" \rightarrow "Create current project" \rightarrow "Import the library file".

3.7.1 Example of Exporting an Addition Library

1. Create a new addition library project and then a new subroutine Add_lib.

MAIN 📑 SBR_1							
Variable Address	Variabl	e Name	Variable Type	e Data Type	e Comments	Comments	
VO	add1		IN	WORD			
V1	add2		IN	WORD			
LMO	add_sum	1	OUT	BOOL			
		SBR_1				×	ł
		Progra	m name:	add_1ib	Author:		
<		Progra	m description:				P
1							
					OF	Consel	
					OK	Cancel	
	l						1

2. Write the input variables "add1" and "add2", then the output variable "add_Sum", and finally the core code.

File(F) Edit(E) View(V) Ladder(L) PLC(P) Debugging(D)	Tool(T) Window(W) Help(H)			
🕒 🖻 🗐 🗶 🗇 🖞	$c \in C$) Q E			· · · ·
	\$ * *	$\rightarrow \downarrow$	⊸ ♪ ┼	╢╴╢	
Project manager 🛛 🗢 👎 🕇	≚ 📴 MAIN 🔚 add_lib *				
🗕 🖵 thtnh(TS635)	Variable Address	Variable Name	Variable Type	Data Type	Comments
{ } Program block	VO	add1	IN	INT	
MAIN	V1	add2	IN	INT	
{ <mark>s</mark> } add lib	V2	add_sum	OUT	INT	
{I} INT 1			TEMP	BOOL	
Ser Clanguage			TEMP	BOOL	
{ } FB					
{ } FC					
	<				
System variable table					
🖌 🔠 Global variable table	1				
🕶 🚱 System blocks settings	SNO	- ADD #	add1 #add:	2 #ac	ld_sun]
Basic settings		-			
EXP-CARD					

Right click on "Program block" in the "Project manager"interface, and select "Export library". 3.



Export library(E) {I} INT_1 Create a new subroutine folder

{s} add I

User C language

{ } FB { } FC 📑 Library ▶ 🖭 System variable table

V2

add_su

Select the save path, fill in the "Library name", "Version", and "Library description" fields, select the 4. subroutine to save, and click"Export library".

S	Library export X
	Export path: C:\Program Files (x86)\INVT\Auto Station Pro\lib\
	Library name: add_lib
	Version: V1.0
	Library description: add_sum = add1 + add2
	Select Program Name Library Function Library Function add_lib add_lib add_lib add_lib
	Export library Cancel

The interface of export success is shown as follows. 5.

Library export	×
Export path: C:\Program Files (x86)\INVT\Auto Station Pro\lib\ Auto Station Pro Version: Library c SelectPre	×
▲ 确定 Export library Cancel	

3.7.2 Example of Importing An Addition Library

1. Open the project that requires the use of library functions, right click on "Library" at the bottom of the "Instruction tree" interface, and select "Import library".

Find Last Next Data Sheet Instruction Form Manipulation Instruction String Processing Instruction Data Processing Instruction Data Processing Instruction Real-Time Clock Instruction Control Calculation Instruct Verification Instruction Axis control (pulse input) Axis control (CANopen) Communication Instruction Communication Instruction Communication Other Instructions 	Instruction tree 🔷 🔫 🗙
 Form Manipulation Instruct String Processing Instructio Data Processing Instruction Real-Time Clock Instruction Control Calculation Instruct Control Calculation Instruct Verification Instruction Axis control (pulse input) Axis control (EtherCAT& pu Axis control(CANopen) Communication (CANopen) Communication Instruction ECAT communication FB FC 	Find Last Next
 String Processing Instructio Data Processing Instruction Real-Time Clock Instruction Control Calculation Instruct Verification Instruction Axis control (pulse input) Axis control (EtherCAT& pu Axis control(CANopen) Communication Instruction Communication Instruction ECAT communication Other Instructions FB FC 	► 🥏 Data Sheet Instruction 🔨
 Data Processing Instruction Real-Time Clock Instruction Control Calculation Instruct Verification Instruction Axis control (pulse input) Axis control (EtherCAT& pu Axis control(CANopen) Communication(CANopen) Communication Instruction ECAT communication Other Instructions FB FC 	Form Manipulation Instruct
 Real-Time Clock Instruction Control Calculation Instruct Verification Instruction Axis control (pulse input) Axis control (EtherCAT& pu Axis control(CANopen) Communication(CANopen) Communication Instruction ECAT communication Other Instructions FB FC 	String Processing Instructio
 Control Calculation Instruct Verification Instruction Axis control (pulse input) Axis control (EtherCAT& pulse) Axis control(CANopen) Communication(CANopen) Communication Instruction ECAT communication Other Instructions FB FC 	Data Processing Instruction
 Verification Instruction Axis control (pulse input) Axis control (EtherCAT& pu Axis control(CANopen) Communication(CANopen) Communication Instruction ECAT communication Other Instructions FB FC 	Real-Time Clock Instruction
 Axis control (pulse input) Axis control (EtherCAT& pu Axis control(CANopen) Communication(CANopen) Communication Instruction Communication Instruction ECAT communication Other Instructions FB FC 	► Sontrol Calculation Instruct
 Axis control (EtherCAT& pu Axis control(CANopen) Communication(CANopen) Communication Instruction ECAT communication Other Instructions FB FC 	► Serification Instruction
 Axis control(CANopen) Communication(CANopen) Communication Instruction ECAT communication Cother Instructions FB FC 	► S Axis control (pulse input)
 Communication(CANopen) Communication Instruction ECAT communication Other Instructions FB FC 	🕨 🤣 Axis control (EtherCAT& pu
 Communication Instruction ECAT communication Other Instructions FB FC 	► 🤣 Axis control(CANopen)
 ECAT communication Other Instructions FB FC 	► Communication(CANopen)
 Other Instructions FB FC 	► Communication Instruction
FC	• SECAT communication
FC	► Other Instructions
	▶ 🤣 FB
	6 FC
Remove Library (function)	

2. Select the library save path (which is the lib file under the installation path of the upper computer software by default), then select the corresponding library, load library function, and finally click "Import library".

TS600 Series Programmable Logic Controller Programming and Application Manual

Library import					\times
Library name:	add_lib			Select	
Version:	V1.0				
Library description:					
SelectLibrary Functi	on Name	Library H	Runcti	on Description	
Imp	ort libra	ry		Cancel	

3. The interface of import success is shown as follows.

Library import						
Library name:	ADD_LIB			Select		
Version:	V1. 0	Auto Stat	ion F	Pro	\times	
Library description:						
SelectLibrary Functi	on Name		Imp	ort successful		
				确定		
Imp	ort libra	ry		Cancel		

3.7.3 Call Library Functions

There are two ways to call library programs:

Method 1: In the "Instruction tree" interface, select the newly imported library program, double click on the functional program or drag it into the project, fill in the value passed in, and click "OK".

╮╠╬╬╎→↓⊸ッ╢╫╫╟ ╖╫╷╸╆╷╸╺ ╠╵╸╵ ≁ ┉
X Image: Maximum and the second
L Calling subroutines/libraries × • ● Batch Data Processin
► 🖉 Data Sheet Instruction
Subroutine/Libr. All subroutines/libraries ~
String Processing Ins
Subprogram/Libr add_lib 🗸 🕨 Data Processing Instr
Variable Na Variable Ad Variable TyData Type Passed-In VComments . 🔷 Real-Time Clock Inst
add1 V0 IN INT Control Calculation In
add2 V1 IN INT add_sum V2 OUT INT
Axis control (pulse in
► Ø Axis control (EtherCA
Axis control(CANope
►
Communication Instr
► Decar Communication
0K Cancel → Ø Other Instructions
● FB
Kersage output window V 4 X
Messages catput window
✓ 🖶 add lib
× <

Method 2: In the "Project manager" interface, right click on "Library", select "Call library function", select "Subroutine/Libr" and "Subprogram/Libr", fill in the "Passed-In Value" field, and click "OK".

	Project manager			▼ # ×			
	🗕 🖵 add_lib	(TS635)		~			
	• { } Prog		k				
			-				
{ M} MAIN {5 } add lib							
		-					
	11 { 1 }	NT_1					
	🔽 U	lser C lang	juage				
	{ } FB						
	{ } FC						
		arv					
		Call library f	unction				
🧮 Library	► 🔤 Syst						
	111 .				~		
Calling subroutin	ies/libraries				×		
Subroutine/Lib	ADD_LIB (V1.0)						
Subprogram/Lib	add_lib		\sim				
babprogram, pro							
	iable Ad Variable T	y Data Type	Passed-In V	Comments			
add1 V0 add2 V1	IN IN	INT INT					
add_sum V2	OUT	INT					
,				OK	Cancel		
				un	Cancer		

Using either of the above two methods generates the following ladder diagram code, which indicates a successful library import.

-[CALL add_lib D0 D1 D2]

If D0=1 and D1=3 are assigned, D2=4 can be obtained, as shown in the figure below.

1								
SM1		[MOV	1	1 D0]		
	Ļ	[MOV	3	3 D1]		
M1		[CALL	add_lib	DO		D1	D2]
🔳 Elemer	Element monitoring table							
+ × R ±	∓ <u>⊿</u>	2 🗄 🔓 🛱						
		Element Nam	e	Data Type	Display Fo	Current V	alue	New Value
1		D2		WORD	Decimal	4		
2				WORD	Decimal			
3				WORD	Decimal			
4				WORD	Decimal			
5				WORD	Decimal			

Note: To update the library, you need to delete original library functions, including those under "Library" in "Project manager" and "Instruction tree", and then re-import the library file.

3.8 System Variables

3.8.1 Overview

System variables are registers used to express and change PLC running status information, such as device model, version number, serial port, Ethernet and CAN communication, etc.

3.8.2 List of System Variables

Category of system variables	Description					
SVS CAN	Information related to CAN communication, such as node					
_SYS_CAN	number, baud rate, slave on-line status, etc					
SVS COM	Serial communication related information, such as node					
_SYS_COM	number, baud rate, slave node online status, etc.					
_SYS_ECAT	EtherCAT master and slave node status information					
	Ethernet communication information, such as IP, MAC,					
_SYS_ETHERNET	online status, error diagnosis, etc.					
	PLC system information, such as SN number, firmware					
_SYS_INFO	version, RTC clock, module diagnosis, system log, etc.					
_SYS_AXSI_ENC_INFO	Encoder axis information					
_SYS_AXIS_MC_INFO	Motion control axis struct					
_SYS_GROUP_MC_INFO	Axis group					
_SYS_CAM_TABLE	Cam table					

Table 3-1 System Variable Information

3.8.3 _SYS_CAN CAN Interface Running Information

Table 3-2 _stru_SYS_CAN Interface Information

Name	Data Type	Description	R/W type
_sCAN.BaudRate	INT	Baud rate (kbps)	R
_sCAN.LoadRate	INT	Load rate (%)	R
_sCAN.RxPerSec	INT	Frames received per second (FPS)	R
_sCAN.TxPerSec	INT	Frames transmitted per second (FPS)	R
_sCAN.RxErrCnt	INT	Receive error counter	R
_sCAN.TxErrCnt	INT	Transmit error counter	R
_sCAN.Protocol	INT	Communication protocol	R

Table 3-3	sCANOpen	Interface	Information

Name	Data Type	Description	R/W type
_sCANOpen.NodeID	INT	Node ID	R
_sCANOpen.NodeState	INT	Node status, 1 for online and 0 for offline	R
_sCANOpen.sEmcy	_stru_CANOpe n_EMCY	Emergency	R

TS600 Series Programmable Logic Controller Programming and Application Manual

Name	Data Type	Description	R/W type
_sCANOpen.sDebug	_stru_CANOpe n_DEBUG	Commissioning interface	R
_sCANOpen.sCfgErr	_stru_CANOpe n_CFG_ERR	Configuration error message	R
_sCANOpen.sEmcy.NodeID	INT	Emergency Node ID	R
_sCANOpen.sEmcy.ErrorCode	INT	Emergency error code	R
_sCANOpen.sEmcy.RegAndMsErrField	INT	Error register pre-manufacturer custom error message area	R
_sCANOpen.sDebug.NodeID	INT	Debug node ID	R
_sCANOpen.sDebug.State	INT	Debug status	R
_sCANOpen.sDebug.Index	INT	Debug primary index	R
_sCANOpen.sDebug.SubIndexAndSize	INT	Debug sub-index and data size	R
_sCANOpen.sDebug.Data	INT	Debug data or error code	R
_sCANOpen.sCfgErr.NodeID	INT	Configuration error message node ID	R
_sCANOpen.sCfgErr.ConfigIndex	INT	Configuration number	R
_sCANOpen.sCfgErr.ErrorCode	DINT	Error code	R

3.8.4 _SYS_COM Serial Port Running Information

Table 3-4 sCOMx_485 Serial Port Information

Name	Data Type	Description	R/W type
_sCOMx_485.BaudRate	DINT	Baud rate	R
_sCOMx_485.DataBits	INT	Data bit	R
_sCOMx_485.Parity	INT	Check bit	R
_sCOMx_485.StopBits	INT	Stop bit	R
_sCOMx_485.Interface	INT	Physical interface	R
_sCOMx_485.Protocol	INT	Communication protocol	R
_sCOMx_485.Reserved	INT	Reserved	R

Table 3-5 _stru_COMFreePortx Serial Freeport Protocol Information

Name	Data Type	Description	R/W type
_sFreex.Sent	DINT	Number of bytes transmitted	R
_sFreex.Received	DINT	Maximum timeout (ms)	R
_sFreex.Timeout	DINT	Number of bytes transmitted	R
_sFreex.Sendlen	INT	Transmit data buffer	R
_sFreex.Sendbuf	INT	Receive data buffer	R
_sFreex.Recvbuf	INT	Number of bytes received	R
_sFreex.Recvlen	INT	Enabled state	R
_sFreex.Enable	BOOL	Activated status	R
_sFreex.Activate	BOOL	Busy state	R
_sFreex.Busy	BOOL	Completion sign	R
_sFreex.Done	BOOL	Error sign	R
_sFreex.Error	BOOL	Reserved	R

Name	Data Type	Description	R/W type
_sMbMstx.AddrNum	INT	Number of nodes	R
_sMbMstx.TimeOut	INT	Maximum timeout (ms)	R
_sMbMstx.ResponseTime	INT	Response time (ms)	R
_sMbMstx.Connected	BOOL	Number of connections	R
_sMbMstx.Enable	BOOL	Enabled state	R
_sMbMstx.Activate	BOOL	Activated status	R
_sMbMstx.Busy	BOOL	Busy state	R
_sMbMstx.Done	BOOL	Port Modbus communication completion flag bit	R
_sMbMstx.Error	BOOL	Port Modbus communication error flag bit	R
_sMbMstx.ErrSlID	BOOL	Slave node ID number	R

Table 3-6 _sMbMstx Serial Port Modbus RTU/ASCII Master Node Information

 ${\tt Table 3-7_sMbMST_MSGx\ Serial\ Port\ Modbus\ RTU/ASCII\ Master\ Connection\ -Slave\ Information}$

Name	Data Type	Description	R/W type
_sMbMstMsgx.DisableSlv	BOOL	Slave node disabled or not	R
_sMbMstMsgx.IsSlvDisable	BOOL	Slave disability flag	R

Table 3-8 $_$ sMbSlvx Serial Port Modbus RTU/ASCII Master Information

Name	Data Type	Description	R/W type
_sMbSlvx.SlvID	INT	Number of nodes	R
_sMbSlvx. Enable	BOOL	Enabled state	R
_sMbSlvx. Activate	BOOL	Activated status	R
_sMbSlvx. Busy	BOOL	Busy state	R
_sMbSlvx. Done	BOOL	Port Modbus communication completion flag bit	R
_sMbSlvx. Error	BOOL	Port Modbus communication error flag bit	R

Table 3-9_stru_COMNnbusx Serial Port Modbus RTU/ASCII Slave Information

Name	Data Type	Description	R/W type
_sNNBusx.SlvId	INT	Node number	R
_sNNBusx.Delay	INT	N:N additional delay	R
_sNNBusx.RetryTimes	INT	Retry times	R
_sNNBusx.Mode	INT	N:N network refresh mode	R
_sNNBusx.Period	DINT	N:N Polling period of communication	R
_sNNBusx.Error	DINT	Communication error flag bit0-bit31 represent error flag bits for nodes numbered 0-31, respectively 1: Error, 0: No Error	R

3.8.5 _SYS_ECAT EtherCAT Running Status Information

Name	Data Type	Description	R/W
		Master running status flag bit	type
_sECATMst.MasterRunState	BOOL	ON: Run, OFF: Stop	R
		Physical connection status of	
	500	master	-
_sECATMst.LinkState	BOOL	ON: normal, OFF: network cable	R
		disconnected	
_sECATMst.HeartBeat	BOOL	EtherCAT real-time task heartbeat	R
_sECATMst.BlockHeartBeat	BOOL	EtherCAT non-real-time task	R
	DINT	heartbeat	
_sECATMst.MaxCycleTime	DINT	Maximum cycle time, μs	R
_sECATMst.MinCycleTime	DINT	Minimum cycle time, μs	R
_sECATMst.CycleTime	DINT	Cycle time, µs	R
sECATMst.MaxExeTime	DINT	Maximum execution time, μs	R
SECATMst.MinExeTime	DINT	Minimum execution time, μs	R
sECATMst.ExeTime	DINT	Execution time, µs	R
_sECATMst.Tx_frames	DINT	Total frames sent	R
sECATMst.Rx_frames	DINT	Total frames received	R
_sECATMst.Tx_frame_rates	DINT	Frame rate at which the data is	R
		transmitted, frames/second	
_sECATMst.Rx_frame_rates	DINT	Frame rate at which the data is	R
		received, frames/second The speed at which the byte is	
_sECATMst.Tx_bytes_rate	DINT	transmitted, bytes/second	R
		The speed at which the byte is	
_sECATMst.Rx_bytes_rate	DINT	received, bytes/second	R
		Lost EtherCAT data frame, in	
_sECATMst.Loss_rate	DINT	frames	R
	DOOL	Reset execution time and cycle	
_sECATMst.ResetTime	BOOL	time	R/W
_sECATMst.StartMaster	BOOL	Start the master	R/W
sECATMst.StopMaster	BOOL	Stop the master	R/W
	D.O.O.	Reset transmit and receive data	5/11/
_sECATMst.ClearFrameCounter	BOOL	frame counter	R/W
_sECATMst.DisableMaster	BOOL	Disable Master Enable	R/W
		Status of all slaves,	
_sECATMst.SlaveState	INT	1: All slaves are online	R
		0: Some slaves are not online	
_sECATMst.FirstErrorSlave	INT	First faulty slave	R
_sECATMst.LibVersion	DINT	EtherCAT library version	R
sECATMst.MstVersion	DINT	EtherCAT master version	R
_sECATMst.DriveVersion	DINT	EtherCAT NIC driver version	R
sECATMst.Tx_error_cnt	DINT	EtherCAT transmit error count	R
_sECATMst.Rx_timeout_cnt	DINT	EtherCAT receive frame timeout count	R

Name	Data Type	Description	R/W type
_sECATMst.Tx_corrupt_cnt	DINT	EtherCAT receive invalid frame count	R
_sECATMst.Tx_unmach_cnt	DINT	EtherCAT receive unmatched frame count	R
_sECATMst.RxPDOLength	DINT	EtherCAT total receive PDOs	R
_sECATMst.TxPDOLength	DINT	EtherCAT total transmit PDOs	R
_sECATMst.ConfigureState	DINT	EtherCAT configuration status	R
_sECATMst.Delay	DINT	EtherCAT synchronizer	R
_sECATMst.SlvLinkState	INT	Connection status of all slave	R
_sECATMst.DisableState	INT	Master disability state	R

Table 3-11 EtherCAT Slave Status Information

Name	Data Type	Description	R/W type
_sECATSlv.Unused	BOOL	System retention	R
_sECATSlv.SlaveRunState	BOOL	Slave running status ON: Run, OFF: Stop	R
_sECATSlv.SetAliasState	BOOL	Alias written to slave: ON means busy	R
_sECATSlv.SetAliasError	BOOL	Failed to write alias to slave	R
_sECATSlv.MatchState	BOOL	Slave type mismatch	R
_sECATSlv.ConfigError	BOOL	Slave configuration error	R
_sECATSlv.SetAlias	BOOL	Set slave alias, rising edge is valid	R/W
_sECATSlv.DisableEnable	BOOL	Disable slave enable	R/W
_sECATSlv.ALState	INT	EtherCAT state machine status	R
_sECATSlv.ALCode	INT	Fault code	R
_sECATSlv.ActAlias	INT	Actual node alias	R
_sECATSlv.TarAlias	INT	Target alias to write	R/W
_sECATSlv.StationAddress	INT	Actual node name	R
_sECATSlv.SlaveRingPos	INT	Configuration address	R
_sECATSlv.SDOErrorCode	INT	Startup parameter configuration error count	R
_sECATSlv.CfgErrorCode	DINT	Configuration error code	R
_sECATSlv.DisableState	INT	Configuration state	R

3.8.6 _SYS_ETHERNET Ethernet Information

Name	Data Type	Description	R/W type
_sENETx.MAC	INT	Physical address	R
_sENETx.IP	DINT	Native IP address	R/W
_sENETx.NetMask	DINT	Subnet mask	R/W
_sENETx.GateWay	DINT	Gateway	R/W
		CW	
_sENETx.CmdCtrl	INT	0: Read	R/W
		1: Edit	

Name	Data Type	Description	R/W type
		2: Write	
		3: Error.	

Note: You can monitor the network information of this machine in the variable table, and you can also modify IP, Subnet mask, gateway and other information in the running state.

Name	Data Type	Description	R/W type
_sMbTcpMstx.SlvIP	DINT	IP address (of slave)	R
_sMbTcpMstx. SlvPort	DINT	Port number (of slave)	R
_sMbTcpMstx.Timeout	INT	Connection timeout (ms)	R
_sMbTcpMstx.ResponseTime	INT	Response time	R
_sMbTcpMstx.Connected	BOOL	Connection flag	R
_sMbTcpMstx.Enable	BOOL	Enabled state	R
_sMbTcpMstx.Activate	BOOL	Activated status	R
_sMbTcpMstx.Busy	BOOL	Busy state	R
_sMbTcpMstx.Done	BOOL	Port Modbus communication completion flag bit	R
_sMbTcpMstx.Error	BOOL	Port Modbus communication error flag bit	R

Table 3-13 _stru_MBTCP_MSTx ModbusTCP Master Information

Table 3-14 _stru_MBTCP_MST_MSGx ModbusTCP Slave Information

Name	Data Type	Description	R/W type
_sMbTcpMstMsgx.MstIP	DINT	Native IP address	R
_sMbTcpMstMsgx.MstPort	DINT	Port number	R
_sMbTcpMstMsgx.DisableSlv	BOOL	Slave node disabled or not	R
_sMbTcpMstMsgx.IsSlvDisable	BOOL	Slave disability flag	R

Table 3-15 _stru_MBTCP_SLVx ModbusTCP Master Connection — Slave Information

Name	Data Type	Description	R/W type
_sMbTcpSlvx.Connections	INT	Number of connections	R
_sMbTcpSlvx.MstIP	DINT	Master IP address table	R
_sMbTcpSlvx.MstPort	DINT	Master port number table	R
_sMbTcpSlvx.SlvIP	DINT	Slave node IP address	R
_sMbTcpSlvx.SlvPort	DINT	Slave node port number	R
_sMbTcpSlvx. SlvID	INT	Slave node ID	R
_sMbTcpSlvx.Connected	BOOL	Connection flag of corresponding node	R
_sMbTcpSlvx.Enable	BOOL	Enabled state	R
_sMbTcpSlvx.Error	BOOL	Communication error flag bit	R
_sMbTcpSlvx.ErrIP	DINT	IP address of master node with error	R
_sMbTcpSlvx.ErrPort	DINT	Port number of master node with error	R

Name	Data Type	Description	R/W type
		Dialing status of 4G module	
		0: Initialization	
		1: No port, port read-write error.	
		2: No SIM card inserted.	
_slotCard.ModemState	INT	3: SIM card has no data flow, APN	R
		error, etc.	
		4: Abnormal signal strength	
		5: Dialing activation failed	
		6: Dialed successfully	
		MQTT server connection status	
_slotCard.MqttState	INT	0: Not connected	R
		1: Connected	
_slotCard.CSQ	DINT	Signal strength	R
_slotCard.Reserved	DWORD	Reserved	R

Table 3-16 _stru_IOT_CARD 4G IoT Card Information

Table 3-17 _stru_LABEL_COM Tag Communication Information

Name	Data Type	Description	R/W type
_sLabelCom.IP	DINT	Tag communication IP address	R
_sLabelCom.PORT	DINT	Tag communication port number	R
_sLabelCom. Reserved	DWORD	Reserved	R

3.8.7 _SYS_INFO PLC Running Information

• Get PLC production device information

Table 3-18 DevInfo Device Information

Name	Data Type	Description	R/W type
_sDevInfo.Device	INT	Device Model ID	R
_sDevInfo.Vender	INT	Manufacturer ID	R
_sDevInfo.HWVersion	DINT	Hardware version	R
_sDevInfo.SWVersion	DINT	Software version	R
_sDevInfo.FPGAVersion	DINT	FPGA version	R
_sDevInfo.BattVolt	DINT	Battery voltage	R

• Get CPU and memory utilization and diagnose CPU performance.

Table 3-19 OSM System Monitor

Name	Data Type	Description	R/W type
_sOSM.CPU	INT	cpu utilization	R
_sOSM.Memory	INT	Memory usage	R

• Obtain the execution cycle time of programs and tasks, so as to judge the complexity of program execution logic.

Name	Data Type	Description	R/W type
_sProgram.TotalSize	DINT	Total program capacity	R
_sProgram.UsedSize	DINT	Used program capacity	R
_sProgram.CurRunTime	DINT	Current program runtime (μs)	R
_sProgram.MinRunTime	DINT	Minimum program runtime (μs)	R
_sProgram.MaxRunTime	DINT	Maximum program runtime (μs)	R
_sProgram.AveRunTime	DINT	Average program runtime (μs)	R
_sProgram.ConstScanTime	DINT	Constant scan time (µS)	R
_sProgram.WDT	DINT	Watchdog reset time (s)	R
_sProgram.Reset	BOOL	Reset cycle time	R/W

Table 3-20 Program User Program Information

• The error log information of PLC is recorded.

Table 3-21 CurErrLst Error Message List

Name	Data Type	Description	R/W type
_sCurErrLst.Quantity	DINT	Current error quantity	R
_sCurErrLst.ErrInfo	_stru_ERR_INF O	Current error message list	R
_sCurErrLst.sErrInfo.SubErrorCode	INT	Sub-error code	R
_sCurErrLst.sErrInfo.MainErrorCode	INT	Main error code	R
_sCurErrLst.sErrInfo.TimStamp	DINT	Time stamp	R

Get RTC clock

Table 3-22 RTC Clock

Name	Data Type	Description	R/W type
_sDataTime.Second	INT	Second	R
_sDataTime.Minute	INT	Minute	R
_sDataTime.Hour	INT	Hour	R
_sDataTime.Day	INT	Day	R
_sDataTime.Month	INT	Month	R
_sDataTime.Year	INT	Year	R
_sDataTime.WeekDay	INT	Week	R
_sDataTime.YearDay	INT	Days	R
_sDataTime.Timestamp	DINT	Total seconds	R

Table 3-23 UsrIntCtl Interrupt Enable Control

Name	Data Type	Description	R/W type
_sUsrIntCtl[0]	_UsrIntCtl[67]	-	-
_sUsrIntCtl[0].Enable	BOOL	Enable control bit	R
_sUsrIntCtl[0].IntID	INT	Interrupt program ID	R
_sUsrIntCtl[···]	_UsrIntCtl[67]	-	-

Name	Data Type	Description	R/W type
_sExtModule.CfgNum	INT	User-configured module number	R
_sExtModule.ActNum	INT	Actually mounted module number	R
_sExtModule.Res_Align	DINT	Reserved for byte alignment	R
_sExtModule.ExtSlot	mExtSlot	-	R
_sExtModule.sExtSlot[n].CfgType	INT	nth expansion module User-configured type	R
_sExtModule.sExtSlot[n].ActType	INT	nth expansion module Type of actual mount	R
_sExtModule.sExtSlot[n].Error	BOOL	nth expansion module Error Status	R
_sExtModule.sExtSlot[n].Disable	BOOL	nth expansion module Module disabled	R
_sExtModule.sExtSlot[n].Res_Align	INT	Reserved for byte alignment	R
_sExtModule.sExtSlot[n].SWVersion	DINT	nth expansion module Software version	R
_sExtModule.sExtSlot[n].LGVersion	DINT	nth expansion module Logic device version	R

Table 3-24 ExtModule Expansion Module System Variable Related Information

Table 3-25 ExtCard Extension Card Related Information

Name	Data Type	Description	R/W type
_sExtCard.mCfgType	INT	User-configured module type	R
_sExtCard.mActType	INT	Type of actually mounted module	R
_sExtCard.SWVersion	DINT	Software version	R
_sExtCard.LGVersion	DINT	Logic device version	R
_sExtCard.Error	BOOL	Error state	R
_sExtCard.Disable	BOOL	Module disabled	R

Table 3-26 AlarmInfo Alarm Information and Control Bits

Name	Data Type	Description	R/W type
_sAlarmInfo.Alarm_Enable	BOOL	Alarm enabled	R/W
_sAlarmInfo.Alarm_Act_Flg	BOOL	S900 – S999 alarm action flag	R
_sAlarmInfo.Alarm_Min_Num	INT	S900–S999 minimum alarm action element number	R

Table 3-27 SM System Variables

Name	Data Type	Description	R/W type
SM0	BOOL	Running monitoring bit	R
SM1	BOOL	Initial running pulse bit	R
SM2	BOOL	Power-on flag bit	R
SM3	BOOL	Error flag bit	R
SM10	BOOL	Clock oscillation with a cycle of 10ms	R

Name	Data Type	Description	R/W type
SM11	BOOL	Clock oscillation with a cycle of 100ms	R
SM12	BOOL	Clock oscillation with a cycle of 1ms	R
SM13	BOOL	Clock oscillation with a cycle of 1min	R
SM14	BOOL	Clock oscillation with a cycle of 1hour	R
SM15	BOOL	Scanning cycle oscillation bit	R
SM18	BOOL	Operation zero flag	R
SM19	BOOL	Operation borrow flag	R
SM20	BOOL	Operation carry flag	R
SM22	BOOL	Set when instruction executes incorrectly	R
SM23	BOOL	Set when instruction element number subscript overflows	R
SM24	BOOL	Set when instruction parameter is illegal	R
SM30	BOOL	Multi-cycle instruction completion flag bit	R
SM31	BOOL	BINDA instruction output character flag bit	R/W
SM32	BOOL	ATI/ITA/ASC/CCITT/CRC16/LRC/C CD instruction bit processing mode flag bit	R/W
SM33	BOOL	SORTR/SORTC instruction descending sort enabled	R/W
SM34	BOOL	SMOV instruction data format setting bit	R/W
SM35	BOOL	The comparison results of BKCMP instruction matrix are all flagged with 1	R

3.9 Timer

3.9.1 TON


3.9.1.1 Function Description

- 1. When the energy flow is valid and the timing value is less than 32767, the specified T element (D) times (the timing value accumulates with the travel time). When the timing value reaches 32767, the timing value will remain unchanged at 32767.
- 2. When the timing value is greater than or equal to the preset value (S), the timing coil output of the specified T element is ON.
- 3. When the energy flow is OFF, timing stops, the timing value is reset to zero, and the timing coil output is OFF.
- 4. When the system executes this instruction for the first time, the timing coil value of the specified T element will be reset to OFF and the timing value will be reset to zero.

3.9.1.2 Application Example



3.9.1.3 Sample Sequence Chart



3.9.2 TONR


3.9.2.1 Function Description

- 1. When the energy flow is valid and the timing value is less than 32767, the specified T element (D) times, and the timing value increases with the travel time. When the timing value reaches 32767, the timing value will remain unchanged at 32767.
- 2. When the timing value is greater than or equal to the preset value (S), the timing coil output of the specified T element is ON.
- 3. When the energy flow is OFF, timing stops, and the timing coil and the timing value remain the current timing value.

3.9.2.2 Application Example



3.9.2.3 Sample Sequence Chart




3.9.3 TOF


3.9.3.1 Function Description

- 1. When the energy flow changes from $ON \rightarrow OFF$ (falling edge), the designated timer T (D) starts timing.
- 2. When the energy flow is OFF, and the specified timer T has started timing, the timing is continued. Until the timing value is equal to the preset value (S), the timing coil output of the specified T element is OFF, then the timing value will remain at the preset value and will not change.
- 3. If the timing is not started, it will not be started even if the energy flow input is OFF.
- 4. When the energy flow is ON, timing stops, the timing value is reset to zero, and the timing coil output is ON.

3.9.3.2 Application Example



3.9.3.3 Sample Sequence Chart



3.9.4 TMON


3.9.4.1 Function Description

- 1. When the input energy flow changes from OFF \rightarrow ON (rising edge) and is in an untimed state, the specified timer T (D) starts timing (starting from the current value), the timing coil output is kept ON under the timing state (the length of the timing state is determined by S).
- 2. In the timing state (the timing length is determined by S), no matter how the energy flow changes, the timing is kept, and the timing coil output is kept ON.
- 3. When the timing value is reached, timing stops, the timing value is reset to zero, and the coil output is reset to OFF.

3.9.4.2 Application Example



3.9.4.3 Sample Sequence Chart



3.10 Function Block and Function (FB/FC)

Function block programs use ladder diagrams for programming. Within function block programs, functions (FCs) or function blocks (FBs) can be called, supporting up to six levels of nested calls.

3.10.1 Function Block (FB)

FB function blocks encapsulate reusable program blocks of a program into a universal function block, and the FB function blocks can be repeatedly called in the program of the same project.

Using encapsulated FB function blocks in programming enhances program development efficiency and improves program readability.

The FB function block can generate one or more values when executed, retains its own special internal variables, and the system allocates memory for the state variables within the FB function blocks. These internal variables constitute its own state characteristics. For input variable values with identical parameter values, different internal state variables may exist, leading to different computational results.


Before using the FB function blocks, it needs to be instantiated (by adding an independent FB instantiation table in the global variable table).

The basic steps for using the FB function block are: Create a function block > Function block programming> Function block instantiation> Run the function block.

3.10.1.1 Create a Function Block

You can create a new function block through the Auto Station Pro software.

- Step 1 Right-click "{ }FB" under the corresponding project name node, select "Insert", and a new function block named FB1 is created.
- Step 2 Right-click "FB1" to access relevant settings such as "Name", "Encryption", etc.



3.10.1.2 Function Block Programming

Double-click on the newly created function block under the "{ }FB" node to enter the function block program editing interface. The function block program editing interface has an additional window for input/output and local variable definitions compared to regular program editing. The parameters of an FB function block can be classified into Input (IN), Output (OUT), Input/Output (IN_OUT), and Local Variables (TEMP).

Note: In addition to using variables, the FB function block program can also use supported soft elements as global variables, such as D0.

The input/output and local variable definition window is shown below.

TS600 Series Programmable Logic Controller Programming and Application Manual


Variable Name	Variable Type	Data Type	Comments
add1	IN	INT	
add2	IN	INT	
add_sum	OUT	INT	
	TEMP	BOOL	
	TEMP	BOOL	

- Variable name: Customize the name of the variable.
- Variable type

Variable type	Category	Description
IN	Input variable	The parameters are provided by the logic block that calls input variables, and the input is the commands passed to the logic block, where IN type parameters will be generated on the left side of the graphic block as input parameters.
OUT	Output variable	Provide parameters to the logic block that calls output variables, indicating it outputs structured data from the logic block. OUT type parameters will be generated on the right side of the graphic block as output parameters.
INOUT	Input/Output variables	Input and output variables can not only be passed into the called logic block, but also can be modified within the called logic block. IN_OUT type parameters serve as input and output parameters, which can be generated on the left side, right side or the top of the graphic block.
TEMP	Local variables	Valid only within this logic block and cannot be accessed externally.

- Data types: Variable data types supported include BOOL, INT, DINT, WORD, DWORD, and REAL (other types will be developed iteratively with each version).
- Note: Used to annotate the meaning of variables.

After the FB function block is instantiated in the MAIN program, the variables defined in the function block will appear in the "FB instance variable" and can be set with initial values and power-down retention attributes.



TS600 Series Programmable Logic Controller Programming and Application Manual

🚡 MAIN 📅 FB1 📅 FB2 📅 FB3 📅 FB4 📅 add_lib 🛃 FB_GLOBALVAR							
	Variable Name	Data Type	Initial Value	Power Down	Comments		
1	₽ ADD1	FB4		No Hold			
2	add1	BOOL	OFF				
3	add2	BOOL	OFF				
4	add_sum	BOOL	OFF				
5							

- Initial value: The initial data set when the variable is executed at the beginning.
- Power-down retention: The power-down retention attribute can be set to "Hold" or "Not hold" for variables.
 - > Not hold: The variables are restored to the initial values set after repower-on.
 - > Hold: Maintain the variable's previous running value after repower-on.

Note: If the option "Clear power-down retention data after download" is selected in the download option box, the variables will be restored to the initial values during program downloading.

3.10.1.3 Example of Encapsulating Integer Addition Using FB

MAIN 📑 FB1 📑	FB2 📑 FB3 📑 FB4 *	📄 add_lib 🗳 FB	GLOBALVAR 📊 SB	R_1	
Variable Name	Variable Type	Data Type	Comments		
add1	IN	INT			
add2	IN	INT			
add_sum	OUT	INT			
	TEMP	BOOL			
<					
1					
	—[ADD #a	dd1 #	fadd2	#add_sum]

1. Editing the function blocks

2. Instantiating and calling the function blocks

After writing the FB function block program, use it in the MAIN application program by instantiating and calling the function block.

There are three methods for instantiating function blocks:

Method 1: In the ladder diagram application, directly enter the FB name directly, then input the instance name in the "??" at the top of the function block instruction to complete the instantiation of the function block.



Method 2: In the ladder diagram application, directly enter the FB name + space + instance name, then click OK to complete the instantiation of the function block.


Method 3: Under the FB node in the toolbox, double-click the FB command to add the FB command to the selected position in the ladder diagram. After adding it, enter the instance name in the graphic block command to complete the instantiation.



After the function block is instantiated, edit the command parameters in the instantiated FB command according to the program requirements, and complete the instantiation call of the function block.

3. Running the function blocks

After the FB function block is instantiated, the "Enable" of the function block is connected to the power flow network of the ladder diagram. When the Enable network flow is valid (ON), the function block program is executed, and the output of the function block is refreshed based on the input state and internal variable state. When the Enable network flow is invalid (OFF), the function block program is not executed, and the output of the function block.



The ADD_VAR function block executes when the power flow condition is ON: D2 = D0 + D1.

4. Encapsulating function blocks (Support for future iterations)

The edited and debugged FB function blocks can be encapsulated into a library, which can be imported, exported, and managed through the library of the Auto Station Pro software, achieving reuse of the same library in different programs.

3.10.2 Function (FC)


A function (FC) is an independently encapsulated function, wherein the program block can define input/output type parameters. The main characteristic of a function is that its internal variables are static, without any internal state storage. The same input parameters will always yield the same output, which is the main difference between a function (FC) and a function block (FB). Functions (FC) are commonly used for various mathematical operations, such as sin(x) and cos(x), which are typical types of functions.

The basic steps for using a function are: create a function > program the function > call the function > run the function.

3.10.2.1 Creating a New Function

You can create a new function block through the Auto Station Pro software.

- Step 1 Right-click the "{ } FC" under the project name node, select "Insert", and a new function block named "FC1" is created.
- Step 2 Right-click "FC1" to access relevant settings such as "Name", "Encryption", etc.



3.10.2.2 Function Programming

Double-click the newly created function under the "{ } FC" node to enter the function block program editing interface. The function block program editing interface has an additional window for input/output and local variable definitions compared to regular program editing. The parameters of an FC function block can be classified into Input (IN), Output (OUT), Input/Output (IN_OUT), and Local Variables (TEMP).

Note: In addition to using variables, the FC function block program can also use supported soft elements as global variables, such as D0.

Variable Name	Variable Type	Data Type	Comments
intput1	IN	INT	
intput2	IN	INT	
output2	OUT	INT	
	TEMP	BOOL	
	TEMP	BOOL	
<			
1			
	-r SUB #i	ntput1 i	fintput2 #output2]

The input/output and local variable definition window is shown below.

- Variable name: Customize the name of the variable.
- Variable type

Variable type	Category	Description
		The parameters are provided by the logic block that calls
IN	Input variable	input variables, and the input is the commands passed to the
IIN	input variable	logic block, where IN type parameters will be generated on
		the left side of the graphic block as input parameters.
		Provide parameters to the logic block that calls output
OUT	Outrout us visible	variables, indicating it outputs structured data from the logic
001	Output variable	block. OUT type parameters will be generated on the right
		side of the graphic block as output parameters.
	Input/Output	Input and output variables can not only be passed into the
INOUT	Input/Output	called logic block, but also can be modified within the called
	variables	logic block. IN_OUT type parameters serve as input and

Variable type	Category	Description
		output parameters, which can be generated on the left side,
		right side or the top of the graphic block.
TFMP	Local variables	Valid only within this logic block and cannot be accessed
IEMP	Local variables	externally.

- Data types: Variable data types supported include BOOL, INT, DINT, WORD, DWORD, and REAL (other types will be developed iteratively with each version).
- Note: Used to annotate the meaning of variables.

Note: Compared to FB function blocks, the FC functions cannot set initial values and power-off retention properties, and all local variables are not retained.


3.10.2.3 Example of Encapsulating Integer Subtraction Using FC

MAIN	FB1 📑	FB2 📊 FB3 📊 ad	ld_var <u> </u> add_lib	F FB_GL	OBALVAR	SBR_1	SUB1
Variable	Name	Variable Type	Data Typ	e Con	ments		
intput1		IN	INT				
intput2		IN	INT				
output2		OUT	INT				
		TEMP	BOOL				
		TEMP	BOOL				
<							
1							
NO	ЖЗ ⊣	-(SUB	#intput1	#int;	put2	#output2]

1. Editing the function

2. Calling the FC function

After writing the FC function block program, use it in the MAIN application program by calling the function block.



3. Running the FC function

The "Enable" of the FC function is connected to the power flow network of the ladder diagram. When the Enable network flow is valid (ON), the function block program is executed, and the output of the function block is refreshed based on the input state. When the Enable network flow is invalid (OFF), the function block program is not executed, and the output of the function block is not refreshed.

	1								
	M6								
NO	/			Enable	SVB1				
		D10	5	— input1					
		D12	3	— input2		output2 —	2	D14	
					<u> </u>	-			

The SUB1 function executes when the power flow condition is ON: D14 = D10 - D12.

4. Encapsulating the FC function (Support for future iterations)

The edited and debugged FC functions can be encapsulated into a library, which can be imported, exported, and managed through the library of the Auto Station Pro software, achieving reuse of the same library in different programs.

4 User C language

4.1 Overview

TS Series PLC supports users to use C language to write functional blocks in programming software, call them where needed, and supports common C language attribute library. Users' C language is called in ladder diagram using CALL instruction, parameters can transfer bit element M, word element D and word element R, read and write element values. And users can use C language to replace other PLC programming languages to realize complex logic and arithmetic operations, which can effectively improve the development efficiency of programmers.

4.2 Instruction Format

User C language function is called in ladder diagram by using CALL instruction, which includes CALL instruction, function name and parameters. The function name is the same as C language file name, which is defined when it is created, and the interface name cannot be changed in the file.


- CALL instruction
- Function name (ButtleSort)
- Parameters (M10 D10)



4.3 Operating Steps

Step 1 Create C language

Open the PLC editing software, choose "User C language" node in the "Project manager" toolbar on the left, right-click and select "Add source file", and the software interface will pop up the user C language interface design window.



Step 2 Design C language interface

Fill in the user C language function information in the C language source file interface design dialog box

The function name is required, and it cannot be the same as the subroutines, interrupt subroutines and other C language functions, that is, avoid using function names containing SBR_ and INT_strings; Up to 16 parameters can be added, parameters can not be left blank, must have an unique name which can not be any PLC soft element name.

	Type BIT PINT16U	Mode IT IN IT IN	Digits 1 1	Description 1	Mapping M
E	BIT				
				2	D
				ок	ОК Сал

The supported data types are as follows:

Туре	Description		
BIT	Boolean quantity		
_INT16U	16-bit unsigned integer		
_INT16S	16-bit signed integer		
_INT32U	32-bit unsigned integer		
_INT32S	32-bit signed integer		
_FP32	32-bit floating point		
_PINT16U	6U 16-bit unsigned int pointer		
_PINT16S	16-bit signed int pointer		
_PINT32U	32-bit unsigned int pointer		
_PINT32S	32-bit signed int pointer		
_PFP32S	32-bit float pointer		

Step 3 C language editing

After creation, enter the C language editing interface where users can write the functions needed to realize.

The part generated by default includes the included header file (including three header files by default: plcstdafx.h, typedef.h, bitdef.h), C language interface function body, and users do not need to manually change or delete the default header file, function interface name, return value type and function parameters, otherwise compilation errors may happen.

Click the "Design" button to re-edit the interface design, then this part will be re-produced, and the previous part needs to be manually deleted to avoid compilation errors. In the example, the function is of C language bubble sort algorithm.

• Parameter passing mode: When ladder diagram is called, the passed-in M and D are the start addresses of B and m_w1. As shown in the following figure, when the elements in the instruction ButtleSort are M0 and D0, then B[0] is M0, B[10] is M10, m_w1[0] is D0, and m_w1[10] is D10 in C language functions; If the parameters used in the ladder diagram are M100 and D100, then B[0] is M100 and m_w1[0] is D100.


	🗑 MAIN 🖏 ButtleSort	
	Design Reserved Reserved Compile Reserved Format	
Fun name	9 #include "typedef.h" 10 #include "bitdef.h" Param	^
	<pre>11 void ButtleSort BIT B, _PINT16U m_w1 13 { 13 { 14 int i, j, tem; 15 for(int i = 0; i < 5; i++) 16 { 17 int count = 0; 18 for(int j = 0; j < 4 - i; j++) 19 { 20 if(m_w1[j] < m_w1[j + 1]) 21 { 22 if(m_w1[j] = m_w1[j]; 23 if(count = 1; 24 if(count = 0) 28 if(count == 0) 29 { 30 if(count == 0) 3</pre>	
	31 - } 32 -) 33 }	× >

Step 4 Use of C language program:

User C language functions are called by CALL instructions. For example, for the bubble sort function mentioned above, the following shall be input in ladder diagram:

- CALL instruction
- Function name (ButtleSort)
- Parameters (M10 D10)

When compiling a ladder diagram, check the instruction block. If it is CALL instruction, check whether its function name is C language function (note the difference between ladder diagram subroutine and interrupt subroutine). If it is C language function, check parameters, match parameter type and quantity, and if the instruction block is correct, compile the C language file and generate an executable file.



4.4 Use Case

1. Bit element (M) pass parameter

	IAIN 🖬 demo m				
:		A 1			
	esign Reserved Reserved	Complie 1	keserved rorma	L .	
$\begin{vmatrix} 1\\2 \end{vmatrix}$	/************************************	*****		este ste ste ste ste ste ste ste	
	7,	****		, de de de de de de de de	
4	* author:				
	* notes: Word e				
6 7	C*******	******	****	**********	
8	#include "plcst	dafx.h″			
9	#include "typed	ef.h″			
10	#include "bitde	f.h			
	void demo_m(BI	ТВ)			
13	•{				
	B[100] = 1;				
15	-}				
110	M 100			123	
N13	[MOV	123	D100]
	M101				
N14	[CALL	demo_m	MO]

In the above case, setting M101 to 1 will trigger the call of C language function, in which M100 is set to 1, so that M100 element energy flow section can be executed.

Bit soft elements are used as per array, and support position 1 and bit clearing, such as B[0]=1; B[1]=0; And assignment, such as B[0]=B[1]. If the pass parameter is M0, then B[0] is M0 and B[100] is M100 when the function is called. If the pass parameter is M10, then B[0] is M10 and B[100] is M110 when the function is called.

C language function parameters Ladder diagram call parameters	B[0]	B[10]
M0	B[0]<==>M0	B[10]<==>M10
M10	B[0]<==>M10	B[10]<==>M20

2. 16-bit pointer type data and 16-bit integer data pass parameters

MAIN Cshort	∢≬×
· 设计预留 编译 预留 预留 预留	
<pre> 1 2 •/***********************************</pre>	

NO	мо	-[MOV	10101	10101 D20]	
N1	M1	-[CALL	c_short	DO	D20]
N2	M2	[MOV	100 D0	100 D10]	
		£	MOV	200 D1	200 D11]	
		ł	MOV	10101 D2	10101 D12]	

Parameter passing method: when ladder diagram is called


- When the function parameter is of pointer type, the passed-in element address is the start address of the C language function parameter.
- When the function parameter is of 16-bit integer type, the passed-in element is passed in the form of value.

As shown in the above figure, when c_short is called, D0 and D20 are passed in, where D0 is passed as a pointer and D20 is passed as a value. When the function is called, w1[0] is the address corresponding to element D0, w1[1] is the address corresponding to D1, and w1[2] is the address corresponding to D2. By assigning values to w1[0], w1[1] and w1[2] in C language functions, the values of elements D0, D1 and D2 will be changed correspondingly. w2 is the value passed, and the value is equal to the value of D20.

If the pass parameters are D10, D30, then w1[0] is D10, w1[1] is D11, w1[2] is D12 when the function is called, and the value of w2 is equal to the value of D30.

C language function parameters Ladder diagram call parameters	w1[0]	w1[10]
D0	w1[0]<==>D0	w1[10]<==>D10
D10	w1[0]<==>D10	w1[10]<==>D20

3. 32-bit pointer type data and 32-bit integer data pass parameters



Parameter passing method: when ladder diagram is called

- When the function parameter is of 32-bit pointer type, the passed-in element address is the start address of the C language function parameter.
- When the function parameter is of 32-bit integer type, the passed-in element is passed in the form of value.

As shown in the above figure, when c_int_32 is called, D30 and D40 are passed in, where D30 is passed as a pointer and D40 is passed as a value.

Because it is of 32-bit pointer type, when the function is called, w1[0] points to the address corresponding to two elements with address bits D30 and D31, and w1[1] points to the address corresponding to two elements with address bits D32 and D33. By assigning values to w1[0] and w1[1] in C language functions, the values of D30, D31 and D32, D33 will be correspondingly changed. w2 is the value passed, and the value is equal to the value formed by combining the element addresses of D40 and D41.

<u>C language function parameters</u> Ladder diagram call parameters	w1[0]	w1[10]
D0	w1[0]<==>D0D1	w1[10]<==>D20D21
D10	w1[0]<==>D10D11	w1[10]<==>D30D31

4. 32-bit float pointer type data and 32-bit floating point data pass parameters

📄 N	/AIN 🛅 demo_f					4 Þ 🗙
设	计预留编译 预留预留预	冒				
3 4 5 6 7 8 9 10 11 12	<pre>•/************************************</pre>	element ou ************************************	t of range *************			
N1	MO	RMOV	123.1230	123.1230 D10]	
	ł	RMOV	123.1230 D0	123.1230 D4]	
	ų	RMOV	1000.120 D20	1000.120 D15]	
N2	M1	CALL	demo_f	DO	D10]

Parameter passing method: when ladder diagram is called

- When the function parameter is of 32-bit float pointer type, the passed-in element address is the start address of the C language function parameter.
- When the function parameter is of 32-bit floating point type, the passed-in element is passed as a value.

As shown in the above figure, when demo_f is called, D0, D10 are passed in, where D0 is passed as a pointer and D10 is passed as a value.

Because it is of 32-bit pointer type, when the function is called, f1[0] points to the address corresponding to two elements with address bits D0 and D1, and w1[10] points to the address corresponding to two elements with address bits D20 and D21. By assigning values to f1[0] and f1[10] in C language functions, the values of D0, D1 and D20, D21 will be correspondingly changed. f2 is the value passed, and the value is equal to the value formed by combining the element addresses of D10 and D11.

<u>C language function parameters</u> Ladder diagram call parameters	f1[0]	f1[10]
D0	f1[0]<==>D0D1	f1[10]<==>D20D21
D10	f1[0]<==>D10D11	f1[10]<==>D30D31

5 Programming Language

There are three programming languages: ladder diagram (LAD), instruction list (IL) and sequential function chart (SFC).

5.1 Ladder Diagram (LAD)

5.1.1 Concept of Ladder Diagram

Ladder diagram is a common graphical PLC programming language similar to electrical (relay) control diagram.

Its main features include:

- With a left bus bar, while the right bus bar is omitted.
- All control output elements (coils) and function blocks (application instructions) have only one energy flow input.

Electrical control diagram and ladder diagram are equivalent to some extent, as shown in Figure 5-1.

Figure 5-1 Equivalent Relationship between Electrical Control Diagram and Ladder Diagram



5.1.2 Basic Programming Elements of Ladder Diagram


Several basic programming elements can be abstracted from ladder diagram according to the principle of electrical (relay) control diagram:


Element	Signification	Description
Left bus	-	Corresponding to the control bus in an electrical control diagram, it provides control power to the control loop.
Connecting line	-	It represents the electrical connection in an electrical control diagram, which is used to conduct other elements connected to each other.
Contact	┿	It represents the input contact in an electrical control diagram, and it controls the on-off of the control current in the loop and determines the direction of the control current. The connection relationship between parallel connection and series connection of contacts essentially represents the operation relationship of input logic of control circuit and controls the transmission of energy flow.
Coil	Ŷ	It represents the relay output in the electrical control diagram.
Function block	٥	Also called application instruction, it corresponds to the actuators or functional devices connected in the electrical control diagram which are used to achieve special functions, and a functional block can complete specific control functions or control calculation functions (such as data transmission, data operation, timer, counter, etc.).

5.1.3 Energy Flow

Energy flow is a very important concept in a ladder diagram program. Energy flow is used to drive coil elements and application instructions, and is similar to the output of drive coil and the control current executed by mechanism in an electrical control diagram.

In a ladder diagram, the front end of coil or application instruction must be connected with energy flow. Only when there is valid energy flow, the coil element can output and the application instruction can be effectively executed. Figure 5-2 shows the energy flow transfer in a ladder diagram and the driving effect of energy flow on coil or function block are demonstrated.





5.2 Instruction List (IL)

Instruction list is a textual user program, which is a set of instruction sequences written by users. The user program stored in the main module of PLC for execution is actually an instruction sequence that can be recognized by the main module. The system executes each instruction in the sequence one by one to realize the control function of the user program. Figure 5-3 shows an example of converting a ladder diagram into an instruction list.




Figure 5-3 Conversion of Ladder Diagram into Instruction List

5.3 Sequential Function Chart (SFC)

Sequential function chart is a graphical user program framework design language, which is usually used to realize sequential control function.

Sequential control refers to a control process that can be divided into multiple procedures (processing steps) and processed according to a certain working sequence. The structure of the user program designed according to the sequential function chart is intuitive and clear, and is consistent with the actual sequential control process. Figure 5-4 shows an example of a simple sequential function chart.




Figure 5-4 Sequential Function Chart

6 Serial Communication

Serial Communication refers to a communication mode which transmits data between peripheral devices and computers by bit through data signal lines, ground lines, control lines, etc. This communication mode uses less data lines, which can save communication cost in long-distance communication.

This chapter introduces the serial communication function of TS600 Series Small PLC in detail, including communication resources and communication protocol, and illustrations with examples.

6.1 Serial Communication Resources

Main module	Communication ports	Communication port type	Supported protocols	Note
	COM1	RS485	Modbus RTU/ASCII master	
			communication protocol,	
тесог			Modbus RTU/ASCII slave	
TS635	COM2	RS485	communication protocol,	TS635 supports two
			freeport protocol, and tag	485 and one
			communication protocol	expandable 232
TS600		D0000	Modbus RTU/ASCII slave	interfaces
CAN-232	COM3		communication protocol,	
expansion	COM3	RS232	freeport protocol, and tag	
card			communication protocol	

6.1.1 Supported Serial Communication Protocols

6.1.2 Applicable Baud Rate

Communication protocol	Applicable baud rate
Freeport protocol	115200 57600 20400 10200 0600 4000 2400 and
Modbus RTU (master, slave)	115200, 57600, 38400, 19200, 9600, 4800, 2400 and
Modbus ASCII (master, slave)	1200bps


Note: Serial protocols cannot be reused. For example, COM1 can only use one protocol rather than multiple protocols at the same time.

6.2 Link characteristics

- Physical layer: RS232, RS485
- Link layer: asynchronous transmission
- Data bit: 8-bit (RTU), 7-bit (ASCII)
- Baud rates: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200bps
- Verification method: even check, odd check or no check
- Stop bit: 1 bit or 2 bits

6.3 RS485 Power Terminal Wiring

• Pin diagram




Terminal function table

Pin	Function
A1	COM1 RS485+
B1	COM1 RS485-
A2	COM2 RS485+
B2	COM2 RS485-
GND	Power ground
24V	Power supply
PE	Protective earthing
0V	Power ground

6.4 Serial Networking Connection

The TS600 Series RS485 interface has a built-in 120Ω terminal resistor which can be selected with a toggle switch. RS485 bus networking supports up to 31 nodes with the address range of 1-247, and supports broadcast. RS485 bus networking wiring diagram is as follows:




🖉 Note:

- Shielded twisted pair is recommended for RS485 bus, and A and B are connected by twisted pair.
- 120 Ω terminal matching resistors are connected at both ends of the bus to prevent signal reflection.
- The reference ground of 485 signals at all nodes is connected together.
- The distance of each node branch line should be less than 3m.

6.5 RS232 Interface

The following figure shows the CAN-232 expansion module and its interface definition.




No.	Port type	Definition	Description
1	SD card slot	Insert MicroSD card here	Used for SD card firmware upgrade
2	RS232 Interface	RS232 bus interface	Used for RS232 communication
2	CANopen	CAN an an hun interface	See the specific definition in the later
3	interface	CANopen bus interface	sections
	4 Switch		Toggled to ON: Built-in terminal resistor
		CANopen terminal resistance	engaged
4		Switch	toggle switch
			disengaged
5	Bus snap	Connected with the main module	Connected with PLC main module
С	interface	connected with the main module	Connected with PLC main module

RS232 interface definition:

	PIN	Definition Description
	1	NC
	2	NC
$\left \left(\right) \right \left(\left(\circ 6 \circ 4 \circ 1 \right) \right) \right $	3	GND
$\left \left(\begin{array}{c} 1 \\ 2 \end{array} \right) \right $	4	RS232 RX
	5	RS232 TX
	6	NC
	7	NC
	8	NC

When the CAN-232 expansion card is properly installed, the 232 and CAN communication configuration options will appear when "CAN-232" is selected for the expansion card.



6.6 Freeport Communication Protocol


6.6.1 Brief Introduction

Freeport protocol is a communication protocol mode in a user-defined communication data format, which can transmit and receive serial data by instructions. In this mode, PLC can be used to communicate with devices in various custom formats, such as frequency converters, bar code scanners, instruments and other intelligent devices using freeport communication protocols. For a single device, PLC can communicate through RS232 or RS485. An RS485 network can also be formed with multiple devices.

Note: The FreeSerial protocol instruction can only be used if the freeport parameters in the system block are configured.

6.6.2 Setting of Freeport Parameters

Step 1 Select the corresponding "COM" option in the system block to enter the communication port setting interface.



Step 2 Select "Free port protocol" in the protocol setting pop-up window to enter the freeport parameter setting interface, as shown in the following figure.

Protoc	ol selection		
	NULL ModbusRTU master ModbusRTU slave ModbusASCII master ModbusASCII slave Free port protocol	Enable control element X0	
-COM1			
	Baud rate 19200	✓ Parity check Even Check ✓	
	Data bit 8	✓ Stop bit 1 ✓	
	Timeout time	1000 ms	
	Retry time	1	
	Frame interval	3 🔿 ms	
	Inter-character timeout	1 🔹 ms	
	Inter-frame timeout	200 💼 ms	
	Effective	Low byte valid $$	

The configurable parameters are as follows:

Options	Setting Content	Note
Baud rate	115200, 57600, 38400, 19200, 9600,	_
Dadd Tate	4800 (default: 19200)	-
Data bit	Set to 7 or 8 (default to 8)	-
Darity hit	Set to no check, odd check and	
Parity bit	even check (default to even check)	-
Stop bit	Set to 1 or 2 (default to 1)	-
Frame spacing	Default to 0	Time between transmission of each frame (ms)
Inter-character	Default to 0	Discarded when the time between two
timeout		characters received exceeds this value.
Inter-frame	Default to 200	Discarded when the time between two
timeout	Default to 200	bytes received exceeds this value.
Effective byte	Low byte active/high and low byte active	 Low byte active: When transmitting or receiving data, manipulate the low byte of a word element, if two bytes are to be transmitted, then transmit the low byte of two word elements. High and low byte active: When transmitting or receiving data, manipulate the high and low byte of a word element, if two bytes are to be transmitted, then transmit the high byte and low byte of a word element.

After the configuration is completed, you can use FreeSerial instruction to transmit and receive serial freeport data. Please refer to FreeSerial instruction in the chapter of Communication Instructions of TS600 Series Programmable Logic Controller Command Manual for detailed use.

6.7 Modbus-RTU/ASCII Master

6.7.1 Brief Introduction

TS600 Series Small PLC supports two RS485 ModbusRTU/ASCII master or slave.

6.7.2 Serial Port Setting

Step 1 Double-click the corresponding "COM" option in the system block to enter the communication port setting interface.

🖌 🖓 Sett	ing		
▶ 📰	System Block		
	EXP-CARD		
	Expansion module configuration		
1	Electronic cam		
٦	Motion control axes		
ŧ⊒	Axis group setting		
9 0	EtherCAT		
سی	COM1		
د یته	COM2		
	Ethernet1		
► 🛄	Ethernet2		
	EtherNet/IP		

Step 2 Select "ModbusRTU master" or "ModbusASCII master" as required in the pop-up window "Protocol setting".

Protoco	selection			
	NULL ModbusRTU master ModbusRTU save ModbusASCII master ModbusASCI save Free port protocol	Enable control eli	ement X0	
COM1				
	Baud rate 19200	 Parity check 	Even Check 🗸 🗸	
	Data bit 8	✓ Stop bit	1 ~	
	Timeout time	1000	▲ ms	
	Retry time	1		
	Frame interval	3	🚔 ms	
	Inter-character timeout	1	🚔 ms	
	Inter-frame timeout	200	🔹 ms	
	Station number	1	÷ 1-247	

The configurable contents are as follows:

Options	Setting Content	Note
Check the enable control elements	Enable the enable control elements	This allows users to use bit elements to control the start and stop of Modbus, which is not enabled by default
Enable control elements	X, Y, M elements	Only valid when the Enable Control Element box is checked

Options	Setting Content	Note
Baud rate	115200, 57600, 38400, 19200, 9600, 4800	Default to 19200
Data bit Modbus RTU is fixed to 8 bits and Modbus ASCII is fixed to 7 bits		-
Parity bit Set to no check, odd check or check		Default to even check
Stop bit	Set to 1 or 2, default to 1	-
Timeout time	0–65535ms	Maximum communication timeout, default to 100ms
Retry times	0–15	Number of retransmissions when communication fails

6.7.3 Master Setting

Step 1 Right-click the corresponding "COM" option in the system block and choose "Add configuration".

с С	Setti	ing				
•	88	System Block				
		EXP-CARD				
		Expansion module configuration				
	1	Electronic cam				
	İ	Motion control axes				
	ŧ⊒	Axis group setting				
	ÿ.	EtherCAT				
	<u>دن</u> ه	COM				
	 ,	co		Open(O) Add configuration(A)		
		Ethe	_	Encryption/Decryption(C)		
•		Ethe		Delete(D)		
		Ether	Net/	(IP		

Step 2 Add configuration, set the slave number communicating with the master, and up to 248 slaves can be configured (0 – 247).

COM1	×
COM:	1
Station number:	1
OK	Cancel

After configuration, the slaves are as shown in the following figure.

•

ŝ	Sett	ing
►	88	System Block
		EXP-CARD
		Expansion module configuration
	1	Electronic cam
	۵	Motion control axes
	₽₽	Axis group setting
		J . J
		EtherCAT
•	Ÿ _o	
•	Ÿ _o	EtherCAT
·	Ÿ.	EtherCAT COM1
•	Ÿ.	EtherCAT COM1 (0]COM1 Modbus Slave:1
	Ÿ.	EtherCAT COM1 © [0]COM1 Modbus Slave:1 COM2

Step 3 Double-click "COM1 Modbus Slave" to open the Modbus Master Configuration Table. See 6.7.4 Master Configuration Table for details.

6.7.4 Master Configuration Table

This interface is used to configure the detailed configuration information of Modbus master node.

[0]COM1 Modbus Slave:1	×
Slave station number: 1 Enable control element X0	
No. ·igger Modigger Conditi Function ·e Register Address Quantity ping Addr 1 Loop (ms) 1000 Read Register(03) 1 1 D0	Add
	Insert
	Delete
	Сору
	Paste
	Upward 🛛
	Downwar d
	Clear
	Import
	Export
OK Cancel	

• Details of the configuration table are as follows:

Options	Setting Content	Note
Slave node ID.	0-247	The slave number 0 represents broadcasting, and up to 247 slaves are supported
Enable control element check box	Enable the enable control elements	This allows users to use bit elements to control the activation and inactivation of Modbus slaves, where each individual slave is controlled. And this option is not used by default.
Enable control elements	X, Y, M elements	Only valid when the Enable Control Element box is checked
Retry times	0–5	Number of retransmissions when communication fails
Trigger mode	"Loop" and "Trigger" modes are supported.	Loop: Cyclic loop execution. Trigger: Bit element rising edge execution.
Trigger condition	 When the trigger mode uses "Loop": "Trigger condition" is used to set the cycle time (unit: ms), and the configuration is executed at the specified cycle. When "Trigger" is used in trigger mode: "Trigger condition" is used to set trigger condition variables/elements 	 When the trigger mode uses "Loop", the configuration is executed at the specified cycle. When "Trigger" is used in the trigger mode, the communication is triggered once by setting the trigger condition. When the communication is completed, the trigger condition will be
Function	01, 02, 03, 04, 05, 06, 15 (0x0f), 16 (0x10)	Modbus function code
Slave register	0–65535	-

Serial Communication

Options	Setting Content	Note
address		
Qty	It is determined by each function code, as shown in the following table	Number of read/write registers or coils
Mapping address	It is determined by each function code, as shown in the following table	

Note:

- If the set cycle period is less than the time required for communication, it will be executed at per the cycle of the actual communication time. For example, when the set period is 10ms but the communication actually requires an execution period of 20ms, the actual execution period is 20ms.
- When multiple Modbus instructions are configured to use the same trigger element, and when the element is triggered, the corresponding multiple Modbus instructions will be executed, and then the element will be automatically reset.
- The optional function/quantity and mapping address elements corresponding to the function code are as follows:

Function code	Function	Qty	Optional mapping address element
01(0x01)	Read coils	1-2000	М
02(0x02)	Read discrete input	1-2000	М
03(0x03)	Read save register	1–125	D, R
04(0x04)	Read input register	1–125	D, R
05(0x05)	Write single coil	1	М
06(0x06)	Write single register	1	D, R
15(0x0F)	Write multiple coils	1–1968	М
16(0x10)	Write multiple registers	1–123	D, R

6.8 Modbus-RTU/ASCII Slave

6.8.1 Brief Introduction

TS600 Series Small PLC supports two RS485 RTU/ASCII master or slave.

6.8.2 Slave Settings

Double-click the corresponding "COM" option in the system block to enter the communication port setting interface. Select "ModbusRTU slave" or "ModbusASCII slave" as required in the pop-up window "Protocol setting".

	System Block - Modbus X
▼ 🛱 Setting	Protocol selection
▶ 🧱 System Block	O NULL O ModousRTU matter
EXP-CARD	ModbusASCI instate ModbusASCI instate ModbusASCI instate ModbusASCI instate ModbusASCI instate
Expansion module configuration	recoursect are c Free port protocol
Electronic cam	COM1 Baud rate 19200 ∨ Party-check Even Check ∨
🛄 Motion control axes	Data bit 8 V Stop bit 1 V
♦ ⊒ Axis group setting	Timeout time 1000 Theory time 1 Frame interval 3 Theory time interval 3
ë 🖕 EtherCAT	Frame interval 3 © ma Inter-character timeout 1 © ma
COM1	Station number 1 247
COM2	
🛄 Ethernet1	OK Cancel Help

The configurable contents are as follows:

Options	Setting Content	Note	
Check the enable control elements	Enable the enable control elements	This allows users to use bit elements to control the start and stop of Modbus, which is not used by default	
Enable control elements	X, Y, M elements	Only valid when the Enable Control Element box is checked	
Baud rate	115200, 57600, 38400, 19200, 9600, 4800	' Default to 19200	
Data bit	Data bit RTU is fixed to 8 bits, ASCII is fixed - to 7 bits -		
Parity bit	Set to no check, odd check or even check	Default to even check	
Stop bit	Set to 1 or 2, default to 1	-	
Node number	1–247	Slave node ID	

Note: After the configuration is completed, download it to TS600 series small PLC.

6.8.3 Slave Related Information

6.8.3.1 Function Code and Element List

Function code	Name	Type of operable elements	Note
01(0x01)	Read coils	Y, X, M, S, T, C	Read bit
02(0x02)	Read discrete input	Х	Read bit
03(0x03)	Read registers	D, Z, T, C, R	Read word
05(0x05)	Write single coil	Y, M, S, T, C	Write bit
06(0x06)	Write single register	D, Z, T, C, R	Write word
15(0x15)	Write multiple coils	Y, M, S, T, C	Write bit
16(0x16)	Write multiple registers	D, Z, T, C, R	Write word

When working as a slave, the supported function codes and operable elements are as follows:

6.8.3.2 Address Binding Table

As a slave, the accessible Modbus protocol addresses are as follows:

Element	Туре	Total quantity	Protocol address	Supported function codes (Decimal)	Description
M0- M32767	Bit element	32768	0x0000-0x7FFF (0-32767)	01, 05, and 15	M0 – M999: not saved in case of power-down
S0-S4095	Bit element	4096	0x8000-0x8FFF (32768-36863)	01, 05, and 15	S0–S999: not saved in case of power-down
X0-X1777	Bit element	1024	0xA000-0xA3FF (40960-41983)	01,02	Input, octal encoded, BOOL type
Y0-Y1777	Bit element	1024	0xB000 – 0xB3FF (45056 – 46079)	01, 05, and 15	Output, octal encoded, BOOL type
T0-T399	Bit element	400	0xC000 – 0xC18F (49152 – 49551)	01, 05, and 15	 Accuracy 100ms: T0 – T199, 200 points Accuracy 10ms: T200–T299, 100 points Accuracy 1ms: T300–T399, 100 points
C0-C255	Bit element	256	0xC200 – 0xC2FF (49664 – 49919)	01, 05, and 15	 16-bit ordinary CTUD: C0 – C199, 200 points 32-bit ordinary CTUD: C200 – C255, 56 points
D0- D32767	Word element	32768	0x0000-0x7FFF (0-32767)	03, 06, and 16	-
R0-R16383	Word element	16384	0x8000-0xBFFF (32768-49151)	03, 06, and 16	R16384 – R32767 are not mapped to protocol address
Т0-Т399	Word element	400	0xE000-0xE18F (57344-57743)	03, 06, and 16	 Accuracy 100ms: T0 – T199, 200 points Accuracy 10ms: T200–T299, 100 points Accuracy 1ms: T300–T399, 100 points

Element	Туре	Total quantity	Protocol address	Supported function codes (Decimal)	Description
C0-C199	Word element	200	0xE200-0xE2C7 (57856-58055)	03, 06, and 16	 16-bit ordinary CTUD: C0 – C199, 200 points
C200-C255	Word element	56	0xE2C8-0xE337 (58056-58167)	03, 06, and 16	 32-bit ordinary CTUD: C200 – C255, 56 points Doubleword elements, every two registers corresponds to one element, and the registers can be read and written in even numbers.
Z0-Z15	Word element	16	0xE400-0xE40F (58368-58383)	03, 06, and 16	-


Note: T and C have word elements and bit elements.

6.8.3.3 Processing of Doubleword Elements

The current count value of C element is a word element or a doubleword element, and C200 – C255 are doubleword elements.

The reading and writing of C200 – C255 is also completed by the function codes (03, 16) of read/write registers. The address of every two registers corresponds to a C doubleword element, and the registers can be read and written in pair.

For example, when reading RTU frames of three C doubleword elements from C200 to C202:



In the returned data, the addresses 58056-58057 represent the contents of C200, with 58056 being the lower 16 bits and 58057 being the upper 16 bits.

Note: When reading doubleword elements, if the start address of reading is not an even, the abnormal code illegal address will be returned, and if the number of registers read is not an even, the abnormal code illegal data will be returned.

Examples of errors are as follows:

Master transmission: 01 03 E2 C9 00 04 A2 4F

The master transmits four word elements whose reading addresses start from E2 C9 (decimal 58057)

Slave response: 01 83 02 C0 F1

Slave reply: Illegal data address

Master transmission: 01 03 E2 C8 00 05 32 4F

The master reads five word elements whose addresses start from E2 C8 (decimal 58056)

Slave response: 01 83 03 01 31

Illegal data returned from the slave

6.8.3.4 Read SN code and the Model

When the PLC acts as a Modbus slave, the master can obtain the factory SN code and model information of the PLC through Modbus addresses "65500–65511" (12 words).

The communication messages are as follows:

Master transmission: 01 03 FF DC 00 0C B4 21

The master transmits 12 word elements whose reading addresses start from FF DC (decimal 65500)

Slave response: 01 03 18 54 30 36 31 39 42 30 30 30 32 39 30 00 00 54 53 36 33 35 00 00 00 00 59 45

Among them, the ASCII code "54 30 36 31 39 42 30 30 30 32 39 30" represents the 12-digit PLC SN code "T0619B000290", while "54 53 36 33 35" represents the PLC model "TS635".

6.9 Modbus-RTU Communication Application Example

6.9.1 Brief Introduction

In this example, two sets of TS635 are configured as Modbus RTU master and slave respectively, and they communicate with each other via COM1 (physical interface RS485). For convenience of description, the following example assumes that the master number is A and the slave number is B.

6.9.2 Enable Master

6.9.2.1 Serial Configuration


Double-click "COM1" in the system block, choose "Modbus RTU master" > "Baud rate 19200, 8 data bit, even check, 1 stop bit", and then click "OK" to save the configuration.

	System Block - Modbus	×
	Protocol selection ONULL ModbusRTU master ModbusRTU slave ModbusASCII master ModbusASCII slave Free port protocol	
 Setting System Block EXP-CARD Expansion module configuration Electronic cam Motion control axes Axis group setting EtherCAT COM1 	COM1 Baud rate 19200 Party check Even Check Data bit 8 Stop bit 1 Timeout time 1000 rms Retry time 1 Frame interval 3 rms Inter-character timeout 1 rms Inter-frame timeout 200 rms Station number 1 1.247	
COM2	OK Cancel	Help

6.9.2.2 Communication Parameter Configuration

Step 1 Right-click "COM1" > "Add configuration", and configure the slave numbered to 1 in the pop-up box, and it is the target with which the communication is to be established.

1	Electronic cam						
۵	Motion control axes						
ŧ⊒	Axis gro	oup setting					
ÿ <mark>s</mark>	EtherCA	т	COM1	×			
ه:::»		Open(O)	COM:	1			
ه:::•	CON	Add configuration(A)	Station nu	mber: 1			
	Ether	Encryption/Decryption(C)					
<u>ا</u>	Ethe	Delete(D)					
	EtherNe	t/IP	OK	Cancel			



٥	Motion control axes
ŧ⊒	Axis group setting
ÿ.	EtherCAT
▼ 🐨	COM1
	[0]COM1 Modbus Slave:1
<u>س</u>	COM2
	Ethernet1

Step 3 Double-click "COM1 Modbus Slave" to open "Modbus Master Configuration Table".

[0]COM1 Modbus Slave:1	×
Slave station number: 1 Enable control element XO	
No. 'igger Modiger Conditi Function 'e Register Address Quantity ping Addr 1 Loop (ms) 1000 Read Register(03) 1 1 DO	Add
	Insert
	Delete
	Copy
	Paste
	Upward 🛛
	Downward
	Clear
	Import
	Export
OK Cancel	


Note: If the same trigger variable can only trigger a single configuration, it is recommended to use different trigger variables.

Step 4 Configure the above information and download it to "TS635 PLC A" after confirmation.

6.9.3 Enable Slave

Step 1 Double-click "COM1" in the system block, choose "ModbusRTU slave" > "Baud rate 19200, 8 data bit, even check, 1 stop bit", and set the slave number to 1. Click "OK" to save the configuration.

	System Block - Modbus X
 Setting System Block EXP-CARD Expansion module configuration 	Protocol selection O NULL ModbusRTU master ModbusRTU dave ModbusASCII slave Free port protocol COM1
Electronic cam	Baud rate 19200 Parity check Even Check Data bit 8 Stop bit 1
🛄 Motion control axes	Timeout time 1000 © ms Retry time 1 ©
♦ ⊒ Axis group setting	Frame interval 3 ms
🖁 🛛 EtherCAT	Inter-character timeout I I I I I I I I I I I I I I I I I I I
COM1	
COM2	
Ethernet1	OK Cancel Help



Example: D0 increases	by 1 per	second			
SM12	↑	—(INC	DO]

Step 3 Download it to "TS635 PLC B".

6.9.4 Example Phenomenon

In the element monitoring table, it can be observed that D0 in two PLCs is added by 1 every second.

🗈 Elemer	nt mo	nitoring table				
+ x 🛛	<u>+</u>	₮ 🖉 🗄 🔂 🔂				
MT_1						
		Element Name	Data Type	Display Fo:	Current Value	New Value
1		DO	WORD	Decimal	2678	
2			WORD	Decimal		
3			WORD	Decimal		
			WORD	Decimal		
4						

7 Ethernet Communication

Ethernet is the most common communication protocol standard which includes physical layer connection, electronic signal and medium access protocol. It has the advantages of low cost, high communication rate and strong anti-interference.

This chapter introduces the Ethernet communication function of TS600 Series Small PLC in detail, including communication resources and communication protocol, and illustrations with examples.

7.1 Ethernet Communication Resources

The main module of TS600 series comes with two Ethernet communication interfaces, and the data transmission rate is as high as 100M. It can be connected with Auto Station Pro upper computer for monitoring, uploading and downloading and firmware upgrading. All Ethernet ports support ModbusTCP function, which supports up to 32 connections (the connection with the same IP and port number are regarded as one) for data exchange, and a single node can be used as master and slave at the same time.

TS600 also supports TCP free protocol instruction and UDP free protocol instruction, and can easily realize TCP/UDP data interaction with other devices in the network through socket instruction. Please refer to the communication instruction chapter in the Instruction Manual for specific steps.

Main module		Communication port type	Supported protocols	Note
	Ethernet 1		ModbusTCP (master,	
			slave), TCP free	
		Standard 100	protocol, UDP free	TS635 has two built-in
TS635	Ethernet 2	Mbps network	protocol, tag	standard Ethernet
	Ethemet 2	port	communication,	interfaces
			EtherNet/IP (master,	
			slave)	


• The Ethernet communication protocols supported by TS600 Series Small PLC are as follows:

Note: Ethernet protocol multiplexing is permitted. For example, Ethernet 1 can use Modbus TCP master, slave, TCP free protocol and UDP free protocol at the same time, as long as the port number is different.

• The specifications of Ethernet interfaces are as follows:

Item	Description
Communication	Standard Ethernet protocol
protocol	Standard Ethernet protocol
Physical layer	100BASE-TX
Communication rate	100Mbps (100Base-TX)
Duplex mode	Full duplex
Topological structure	Linear topology structure
Transmission medium	Category-5 or higher network cables
Transmission distance	The distance between two nodes is less than 100m

7.2 Ethernet Wiring Example



In the example figure, Ethernet 1 is connected to Auto Station Pro in the upper computer to upload/download programs, and Ethernet 2 is connected to HMI for data display.

7.3 Ethernet IP Address

7.3.1 Factory Default IP Address

The default IP address of the PLC is shown as follows.


Model	Default IP	address
TS611	Ethernet is no	t supported
TS620		102 100 2 10
TS630	Ethernet 1	192.168.2.10
	Ethernet 1	192.168.1.10
TS621, TS633, TS634 and TS635	Ethernet 2	192.168.2.10

If you forget the Ethernet IP address, please use USB interface to read or modify the IP address, or reset Ethernet to the factory mode. For specific operation, refer to section 7.3.2 Modify IP Address in Upper Computer Interface or 7.3.3 Modify IP address with System Variables.

7.3.2 Modify IP Address in Upper Computer Interface

1. Modify IP address via USB


Step 1 Choose "Tool" > "PLC communication" in the toolbar.



Step 2 Choose USB in "PLC", select the corresponding COM port in "USB", which is COM4 in this case, and then click the "Connect" button in the upper right corner of the interface, and the pop-up box indicating successful connection appears to indicate that USB communication has been established with PLC. Please skip step 2 and see3for subsequent operations.

- 1 1 4 2 2 2 3 6 5 7	
; ╬│→ ↓ ⊸ ♪ ╢╢╢╢║□ ╬│○ ╼ (F) ─ │ ┵ ba	
🖬 MAIN 4 ト	×
Programming port setting X FLC 105 Starent setting Nato Station Pro Fort maker: Connection successful FLC activerk port setting Number P OK Pess	~
< >	

- 2. Modify IP address via Ethernet
- Step 1 Choose "Tool" > "PLC communication" in the toolbar.



Step 2 Choose Ethernet in "PLC", and because the example physical interface is connected to Ethernet 2, so fill in the IP address of PLC network port 2, 192.168.2.10, in "Peer-to-peer IP address", and then

click the "Connect" button in the upper right corner of the interface, and a pop-up box indicating successful connection appears to indicate that Ethernet communication has been established with PLC. Please see 3 for subsequent operations.

FLC O USB B Ethernet USB port: Disconnect Disconnect Disconnect Disconnect Disconnect Disconnect Disconnect Disconnect Disconnect Disconnect Disconnect Ethernet setting Port number: 9016 Auto Station Pro Find Connection failure OK Find Connection failure OK OK Disconnect /ul>	USB setting USB port: Ethernet setting Peer-torpeer IP address: 192 .168 . 1 . 10 FINO Port number: 9016 FLC network port settin Number IP Connection failure Find Idense I	gramming port s	etting		
Peer-to-peer IP address: 192.168.1.10 PING Port number: 9016 PLC network port settin Number IP Connection failure dress	Peer-to-peer IP address: 192_168_1_1_10 PING Port number: 9016 Put number: 9016 Auto Station Pro X FLC network port settin Number IP Connection failure dress	USB setting	O USB 💿	Ethernet	
Port number: 9018 5000 5000 5000 5000 5000 5000 5000 5	Port number: 9018 5000 5000 5000 5000 5000 5000 5000 5	Ethernet setti	ing		
Port number: 9015 PLC network port settin Number IP Connection failure Adress	Port number: 9019 PLC network port settin Number IP Connection failure Idress	Peer-to-peer	: IP address:	192 . 168 . 1 . 10	PING Delay time(ms):
PLC network port settin Number IP Connection failure dress	FLC network port settin Find Number IP Connection failure dress	Port number:		9016	5000
		Number	IP	<u> </u>	idress

3. Modify IP

After establishing a connection with PLC via USB or Ethernet, double-click "Ethernet" in Project Manager to view or configure Ethernet-related information.

		PLC Ethemet setting	
	Etherne Add configuration(A)	IP address: 192 168 1 10 Read Reset IP	
3	Cross-reference table	Subnet Mask: 255 . 255 . 0 Write	
	Element monitor tabl	Gateway Address: 192 . 168 . 1 . 1 Identification device	

- Reset IP: Restore all parameters of the two network ports to the factory default values.
- Read: Read the IP address, subnet mask and gateway address of port 1 or port 2.
- Write: Write IP address, subnet mask and gateway address to port 1 or port 2.
- Identify device: Reserved function, not available now.

Note: Ethernet information can be modified in running state without stopping or restarting PLC.

7.3.3 Modify IP address with System Variables

The system variable _sENETx.CmdCtrl is the control word for network configuration. Its value means:

0: Read. In this mode, PLC reads the current network information, and the network configuration cannot be written at this time.

1: Edit. In this mode, PLC can write or edit IP address, subnet mask and gateway.

2: Write. Write IP address, subnet mask, gateway and other information of current network port system variables into PLC. After writing successfully, the control word automatically changes to 0, and when errors occur, the control word value is 3.

3: The control word is 3 when writing errors occur.

The following shows how to modify the network configuration of Ethernet 1.

Step 1 Set _sENET1.CmdCtrl to 1 to indicate that you are entering edit mode.

Step 2 Modify _sENETx.IP, _sENETx.NetMask, _sENETx.GateWay system variables. Use doublewords for IP address, subnet mask, or gateway, the variable _sENET1.IP with a value of "16#c0a8010a" in the

following figure means "192 (16#c0) .168 (16#a8) .1 (16#01) .10 (16#0a) ".

Element	monitoring table				
+ x 🛛	生 ∓ 🖉 🗄 🗄 🗄				
MT_1	Element Name	Data Type	Display Format	Current Value	New
1	sENET1. IP	DINT	Hexadecimal	16#c0a8010a	
	= senet1. MAC	INT[3]	Decimal		
3	_sENET1.MAC[0]	INT	Decimal	4327	
4	_sENET1.MAC[1]	INT	Decimal	31459	
5	_sENET1.MAC[2]	INT	Decimal	16321	
6.		DINT	Hexadecimal	16#fffff00	
7.		DINT	Hexadecimal	16#c0a80101	
•		IIIOPD	n		

- Step 3 Set _sENET1.CmdCtrl to 2, which indicates that the value of the current NIC system variable is written to PLC.
- Step 4 _sENET1.CmdCtrl automatically changes to 0 after a successful writing and 3 when an error occurs.

7.4 TCP Free protocol

TCP protocol is a connection-oriented reliable communication protocol at transport layer based on byte stream. TS600 Series Small PLC provides the relevant TCP instructions to transmit and receive TCP protocol data. For specific usage, please refer to TCP-related instructions in the chapter of communication instructions of Instruction Manual.

7.5 UDP Free Protocol

UDP is a connectionless user datagram protocol. TS600 Series Small PLC provides the relevant UDP instructions to transmit and receive UDP protocol data. For specific usage, please refer to UDP-related instructions in the chapter of communication instructions of Instruction Manual.

7.6 Modbus TCP Master

7.6.1 Brief Introduction

Modbus TCP slave is Modbus client, and TS635 Small PLC supports two Modbus TCP masters, and both Ethernet ports support checking Modbus TCP master and Modbus TCP slave at the same time.

7.6.2 Modbus TCP Master Settings

Step 1 Double-click the corresponding "Ethernet" option in the system block to enter the communication port setting interface. Check "ModbusTCP master" in the pop-up window "Protocol setting".

♦ ⊒ Axis group setting	System Block Ethernet1 - Dialog
ë stherCAT	
COM1	
COM2	
Ethernet1	Master configuration
Ethernet2	Modbus TCP master
EtherNet/IP	Enable control element X0
Cross-reference table	
Blement monitor table	
🔀 Trace	

Options	Setting Content	Note			
Check the enable control elements	Enable the enable control elements	This allows users to use bit elements to control the activation and inactivation of Modbus TCP slaves, where each individual slave is controlled. And this option is not used by default.			
Enable control elements	X, Y, M elements	Only valid when the Enable Control Element box is checked.			

The configurable content is described as follows:

Step 2 Click "Add configuration" to set the IP and port number of the slave that communicates with the master.

			>
		IP address:	192 . 168 . 1 . 11
Ethernet1		Port: 502	
Ethernet2	Open(O)		
EtherNet/i	Add configuration(A)	OK	Cancel

After configuration, the slaves are as shown in the following figure.

	INTERNET COLOWING TIGURE.
ک د	DM1
ک دی	DM2
🔻 🛄 Etl	hernet1
Ċ] [0]Ethernet1 192.168.1.11:502
🛄 Etl	hernet2
🛄 Etl	herNet/IP

Step 3 Double-click "Ethernet1 192.168.2.11:502" to open the Modbus Master Configuration Table, as detailed in section 7.6.3 Modbus-TCP Master Configuration Table.

7.6.3 Modbus TCP Master Configuration Table

This interface is used to configure the detailed configuration information of Modbus TCP master node.

0]Ethei	rnet1 1	192.168	.1.11:502											2
Slave	statio	on numbe	er: 255		Enabling c	ontrol elem	ent XO		Resend	time:	1	Timeout	time:	500
			ger Conditi		Function		er Address		ping Addr					Add
1	Loop	(ms)	1000	Rea	d Register(03)		1	1	DO				_	
														Insert
														Delete
														Copy
														copy
														Paste
														Upward
														Downward
														Downward
														Clear
														Import
														Export
						0	K	Cancel	1					

 Details of the configuration table are as follows: 	•	Details of the configuration table are as follows	:
--	---	---	---

Options	Setting Content	Note		
Slave node ID.	0–255	-		
Enable control element check box Enable control	Enable/disable enable control elements	Modbus TCP slaves, where each individual slave is controlled. Not used by default.		
elements	X, Y, M elements	Only valid when the Enable Control Element box is checked		
Retry times	0–5	Number of retransmissions when communication fails		
Trigger mode	"Loop" and "Trigger" modes are supported.	Loop: Cyclic loop execution. Trigger: Bit element rising edge execution.		
Trigger condition	 When the trigger mode uses "Loop": "Trigger condition" is used to set the cycle time (unit: ms), and the configuration is executed at the specified cycle. When "Trigger" is used in trigger mode: "Trigger condition" is used to set trigger condition variables/elements 	 When the trigger mode uses "Loop", the configuration is executed at the specified cycle. When "Trigger" is used in the trigger mode, the communication is triggered once by setting the trigger condition. When the communication is completed (the slave normally responds), the trigger condition will be automatically reset, otherwise the trigger condition will remain unchanged. If multiple configurations are triggered by the same trigger variable/element, the triggered configurations are executed after the trigger condition is set, and the triggered configurations will not be executed repeatedly. 		
Function	01, 02, 03, 04, 05, 06, 15 (0x0f), 16 (0x10)	Modbus function code		
Slave register address	0–65535	-		
Qty	It is determined by each function code, as shown in the following table.	Number of read/write registers or coils		
Mapping address	It is determined by each function code, as shown in the following table.	Address of slave coil/discrete quantity/register mapped in master		

Note:

- If the set cycle period is less than the time required for communication, it will be executed at per the cycle of the actual communication time. For example, when the set period is 10ms but the communication actually requires an execution period of 20ms, the actual execution period is 20ms.
- ♦ When multiple Modbus instructions are configured to use the same trigger element, and when the element is triggered, the corresponding multiple Modbus instructions will be executed, and then the

element will be automatically reset.

• The optional function/quantity and mapping address elements corresponding to the function code are as follows:

Function code	Function	Qty	Optional mapping address element
01(0x01)	Read coils	1-2000	М
02(0x02)	Read discrete input	1-2000	М
03(0x03)	Read save register	1–125	D, R
04(0x04)	Read input register	1–125	D, R
05(0x05)	Write single coil	1	М
06(0x06)	Write single register	1	D, R
15(0x0F)	Write multiple coils	1-1968	М
16(0x10)	Write multiple registers	1–123	D, R


7.7 Modbus TCP Slave

7.7.1 Brief Introduction

Modbus TCP slave is Modbus server, and TS635 Small PLC supports two Modbus TCP slaves, and both Ethernet ports support checking Modbus TCP master and Modbus TCP slave at the same time.

7.7.2 Modbus TCP Slave Settings

Double-click the corresponding "Ethernet" option in the system block to enter the communication port setting interface. Check "Modbus TCP slave" in the pop-up window "Protocol setting".



The configurable content is described as follows:

Options	Setting Content	Note		
		This allows users to use bit elements to		
Check the enable	Enable the enable control	control the activation and inactivation of		
control elements	elements	Modbus TCP slaves, where each individua		
		slave is controlled. Not used by default.		
Enable control	X X Malamanta	Only valid when the Enable Control Element		
elements	X, Y, M elements	box is checked		
Port number	Fixed at 502	-		

🖉 Note:

- Modbus TCP does not need to set slave number, and all slave numbers can communicate with it.
- After the configuration is completed, download it to TS600 Series Small PLC.
- Other devices can communicate with TS635 using the IP address of the corresponding Ethernet port and port number 502.

7.7.3 Slave Related Information

7.7.3.1 Function Code and Element List

Function code	Name	Type of operable elements	Note
01(0x01)	Read coils	Y, X, M, S, T, C	Read bit
02(0x02)	Read discrete input	х	Read bit
03(0x03)	Read registers	D, Z, T, C, R	Read word
05(0x05)	Write single coil	Y, M, S, T, C	Write bit
06(0x06)	Write single register	D, Z, T, C, R	Write word
15(0x15)	Write multiple coils	Y, M, S, T, C	Write bit
16(0x16)	Write multiple registers	D, Z, T, C, R	Write word

When working as a slave, the supported function codes and operable elements are as follows:

7.7.3.2 Address Binding Table

As a slave, the accessible Modbus protocol addresses are as follows:

Element	Туре	Total quantity	Protocol address	Supported function codes (Decimal)	Description
M0– M32767	Bit element	32768	0x0000-0x7FFF (0-32767)	01, 05, and 15	M0 – M999: not saved in case of power-down
S0-S4095	Bit element	4096	0x8000-0x8FFF (32768-36863)	01, 05, and 15	S0–S999: not saved in case of power-down
X0-X1777	Bit element	1024	0xA000-0xA3FF (40960-41983)	01, 02	Input, octal encoded, BOOL type
Y0-Y1777	Bit element	1024	0xB000-0xB3FF (45056- 46079)		Output, octal encoded, BOOL type
T0-T399	Bit element	400	0xC000-0xC18F (49152- 49551)	01, 05, and 15	 Accuracy 100ms: T0 – T199, 200 points Accuracy 10ms: T200–T299, 100 points Accuracy 1ms: T300–T399, 100 points
C0-C255	Bit element	256	0xC200-0xC2FF (49664- 49919)	01, 05, and 15	 16-bit ordinary CTUD: C0 – C199, 200 points 32-bit ordinary CTUD: C200 – C255, 56 points
D0– D32767	Word element	32768	0x0000-0x7FFF (0-32767)	03, 06, and 16	-
R0-R16383	Word element	16384	0x8000-0xBFFF (32768-49151)	03, 06, and 16	R16384 – R32767 are not mapped to protocol address
T0-T399	Word element	400	0xE000-0xE18F (57344- 57743)	03, 06, and 16	 Accuracy 100ms: T0 – T199, 200 points Accuracy 10ms: T200–T299, 100 points Accuracy 1ms: T300–T399, 100


Element	Туре	Total quantity	Protocol address	Supported function codes (Decimal)		Description
						points
C0-C199	2199 Word 200 0xE200-0xE2C7 03.06. and	03, 06, and 16	•	16-bit ordinary CTUD: C0 – C199,		
C0-C199	element		(57856–58055)	03, 06, and 16		200 points
C200-C255	Word element	56	0xE2C8–0xE337 (58056–58167)	03, 06, and 16	•	32-bit ordinary CTUD: C200 – C255, 56 points Doubleword elements , every two registers corresponds to one element, and the registers can be read and written in even numbers.
Z0-Z15	Word element	16	0xE400-0xE40F (58368-58383)	03, 06, and 16	-	

Note: T and C have word elements and bit elements.

7.7.3.3 Processing of Doubleword Elements

The current count value of C element is a word element or a doubleword element, and C200 – C255 are doubleword elements. The reading and writing of C200 – C255 is also completed by the function codes (03, 16) of read/write registers. The address of every two registers corresponds to a C doubleword element, and the registers can be read and written in pair.

For example, when reading RTU frames of three C doubleword elements from C200 to C202:



In the returned data, the addresses 58056 and 58057 represent the contents of C200, with 58056 being the lower 16 bits and 58057 being the upper 16 bits.

Note: When reading doubleword elements, if the start address of reading is not an even, the abnormal code illegal address will be returned, and if the number of registers read is not an even, the abnormal code illegal data will be returned.

Examples of errors are as follows:

Master transmission: 01 03 E2 C9 00 04 A2 4F

The master transmits four word elements whose reading addresses start from E2 C9 (decimal 58057)

Slave response: 01 83 02 C0 F1

Slave reply: Illegal data address

Master transmission: 01 03 E2 C8 00 05 32 4F

The master reads five word elements whose addresses start from E2 C8 (decimal 58056)

Slave response: 01 83 03 01 31

Illegal data returned from the slave

7.7.3.4 Read SN Code and the Model

When the PLC acts as a Modbus slave, the master can obtain the factory SN code and model information of the PLC through Modbus addresses "65500–65511" (12 words).

The communication messages are as follows:

Master transmission: 00 00 00 00 00 00 06 01 03 FF DC 00 0C

The master transmits 12 word elements whose reading addresses start from FF DC (decimal 65500)

Slave response: 00 00 00 00 00 1B 01 03 18 54 30 36 31 39 42 30 30 30 32 39 30 00 00 54 53 36 33 35 00 00 00 00 00 00

Among them, the ASCII code "54 30 36 31 39 42 30 30 30 32 39 30" represents the 12-digit PLC SN code "T0619B000290", while "54 53 36 33 35" represents the PLC model "TS635".

7.8 Modbus TCP Communication Application Example

7.8.1 Brief Introduction

In this example, two sets of TS635 are configured to communicate as Modbus TCP master and slave respectively. The master uses Ethernet 1 and the slave uses Ethernet 2, which are connected by network cables. For convenience of description, the following example assumes that the master number is A and the slave number is B.

7.8.2 Modbus TCP Master Settings

TS635 numbered A is used as the master, and the physical interface is Ethernet 1.

7.8.2.1 Enable TCP Master

Double-click the "Ethernet1" option in the system block to enter the Ethernet port setting interface. Check "ModbusTCP master" in the pop-up window, and then click "OK" to save the configuration.


↓ ■ Axis group setting	System Block Ethernet1 - Dialog
🟺 🔉 EtherCAT	
COM1	
COM2	
Ethernet1	Master configuration
Ethernet2	ModbusTCP master
EtherNet/IP	Enable control element
Cross-reference table	
Blement monitor table	
₩ Trace	

7.8.2.2 Communication parameter configuration

Step 1 Right-click "Ethernet1" > "Add configuration", fill in the slave IP address of 192.168.2.10 and port number of 502, and click "OK" to save the configuration.

		×
		IP address: 192 . 168 . 1 . 11
Ethernet1		Port: 502
Ethernet2	Open(O)	
	Add configuration(A)	OK Cancel
EtherNet/	r)	

The following slave appear for Ethernet 1, representing the communication with it.



Step 2 Double-click "[0]Ethernet1 192.168.2.10:502" to open the Modbus TCP Master Configuration Table.

[0]Ethernet1 192.168.1.11:502	>
Slave station number: 255 Enabling control element X0 Resend time: 1 Timeout time	e: 500
No. 'igger Modigger Conditi Function 'e Register Address Quantity ping Addr 1 Loop (ms) 1000 Read Register(03) 1 1 D0	Add
1 Loop (ms) 1000 Read Register(03) 1 1 D0	Insert
	Delete
	Copy
	Paste
	Upward
	Downward
	Clear
	Import
	Export
OK Cancel	

Step 3 Configure the above communication parameter and download it to "TS635 PLC A" after confirmation.

7.8.3 Modbus-TCP Slave Settings

TS635 numbered B is used as the slave, and the physical interface is Ethernet 2.

7.8.3.1 Modify Ethernet IP

Change the IP address of Ethernet 2 to 192.168.2.10, subnet mask 255.255.255.0, and gateway address 192.168.2.1. For specific operation, refer to section 7.3.2 Modify IP Address in Upper Computer Interface or 7.3.3 Modify IP address with System Variables.

7.8.3.2 Enable TCP Slave

Step 1 Double-click the corresponding "Ethernet" option in the system block to enter the communication port setting interface. Check "ModbusTCP slave" in the pop-up window "Protocol setting".

♦ ⊒ Axis group setting	Slave configuration		
🖗 EtherCAT	ModbusTCP slave		
COM1	Enable control element	X0	
COM2	Timeout	500	
Ethernet1		502	
Ethernet2	Slave port number:	302	
EtherNet/IP			

Step 2 Write a program to add 1 to D0 every second.



Step 3 Download it to "TS635 PLC B".

7.8.4 Example Phenomenon

In the element monitoring table, it can be observed that D0 in two PLCs is added by 1 every second.

		nitoring table				
×		▼ 2 8 6 8				
_1						
		Element Name	Data Type	Display F	o: Current Value	New Value
	4.44	DO	WORD	Decimal	765	10
2	1000		WORD	Decimal		
3			WORD	Decimal		
	2223		WORD	Decimal		
4						


8 CAN Communication

8.1 Overview

TS600 Series PLC realizes CAN communication networking through CAN-232 or CAN-2*RJ45 expansion card, and supports CANopen communication protocol and up to 30 slaves.

8.2 Hardware Interface

Take CAN-232 expansion card as an example to explain the hardware of CAN port.



No.	Port type	Definition	Description
1	SD card slot	Insert MicroSD card here	Used for SD card firmware upgrade
2	RS232 Interface	RS232 bus interface	Used for RS232 communication
3	CANopen interface	CANopen bus interface	See the specific definition in the later sections
4	Switch	CANopen terminal resistance toggle switch	Toggled to ON: Built-in terminal resistor engaged Toggled to OFF: Built-in terminal resistor disengaged
5	Bus snap interface	Connected with the main module	Connected with PLC main module

CANopen interface definition:

	PIN	Definition Description
	1	CANH
	2	CANL
	3	GND
	4	NC
	5	NC
8	6	NC
	7	NC
	8	NC


8.3 CAN Network

8.3.1 CAN Communication Networking

For CAN communication networking, all master and slave stacks require three lines (CANH, CANL, CGND) to be connected together one by one. CAN bus terminal matching resistors of 120 ohms need to be added at both ends of the bus. The terminal resistance of TS600 Series expansion card needs to be set with a toggle switch.

The schematic diagram of CAN communication networking is as follows.

Figure 8-1 Wiring Diagram of CAN Communication Networking of Multiple Devices



8.3.2 Communication Distance Corresponding to CAN Baud Rate

Baud rate (kbit/s)	Distance (m)	Minimum wire diameter (mm²)	Maximum number of access points
1000	20	0.3	18
500	70	0.3	30
250	140	0.3	30
125	280	0.5	30
100	350	0.5	30
50	700	0.7	30

The distance of CAN communication is related to its set baud rate, and the comparison table is as follows.

8.3.3 CAN Interface System Variable

TS600 Series PLC can view or monitor CAN interface status through system variable "_sCAN". "_sCAN" is a struct variable of data type "_struc_CAN" whose member definitions are shown in the following table.

Member	Data Type	Description
BaudRate	INT	Baud rate (kbps)
LoadRate	INT	Load rate (%)
RxPerSec	INT	Frames received per second (FPS)
TxPerSec	INT	Frames transmitted per second (FPS)
RxErrCnt	INT	Receive error counter
TxErrCnt	INT	Transmit error counter
		Communication protocol
Protocol	INT	0: Disabled
		1: CANopen

8.4 CANopen Communication Instruction

8.4.1 CANopen Communication Protocol

TS600 Series supports CANopen communication standard protocol DS301.

Table 8-1 CANopen Communication Protocol Standard

Software function module	Slave	Master
Supported protocols	DS301 V4.02	DS301 V4.02
Maximum TPDO number	4	64
Maximum RPDO number	4	64
Number of slave nodes	-	30
	1Mbps/20m	1Mbps/20m
	800kbps/40m	800kbps/50m
Baud rate and communication	500kbps/70m	500kbps/100m
	250kbps/140m	250kbps/140m
distance	125kbps/280m	125kbps/280m
	100kbps/350m	100kbps/350m
	50kbps/700m	50kbps/700m
Data interaction software element	R500-R531	D0–D7999 (configurable)

8.4.2 CANopen Axis Control Instruction List

The list of CANopen axis control instructions supported by TS600 Series PLC is as follows. Please refer to TS600 Series PLC Instruction Manual for detailed usage of relevant instructions.

Table 8-2 Instruction List

Instruction Name	Function
MC_Power_CO	Communication control servo axis enabled
MC_Reset_CO	Fault reset of communication control servo axis
MC_ReadStatus_CO	Communication control reads the current state
MC_ReadActualVelocity_CO	Communication control reads the current axis speed position
MC_ReadActualPosition_CO	Communication control reads the current actual axis position
MC_ReadAcceleration_CO	Communication control reads the current axis acceleration
MC_ReadDeceleration_CO	Communication control reads the current axis deceleration
MC_ReadDIStatus_CO	Communication control reads servo DI state
MC_Halt_CO	Communication control servo axis motion halted
MC_Stop_CO	Communication control servo axis stop
MC_MoveVelocity_CO	Communication control axis velocity operation mode
MC_MoveRelative_CO	Communication control axis relative positioning
MC_MoveAbsolute_CO	Communication control axis absolute positioning
MC_Home_CO	Communication control axis homing
MC_Jog_CO	Communication control axis jogging

8.4.3 Explanation of CANopen-related Terms

• NMT: Network Management

Network management services, application layer management, network status management and node ID allocation management. The service mode is master-slave communication mode: In CAN network, there can only be one NMT master and one or more slaves. Mainly used to control the status of slaves.

• SDO: Server Data Object

Service data object, which can access the data in the slave device object dictionary through index and sub-index. This is mainly used for the slave configuration process. Every frame of SDO needs to be replied and confirmed.

• PDO: Process Data Object

Process data object, mainly used to transmit data in real time. Data transmission is limited to 1 to 8 bytes. PDO data transmission is divided into two ways: synchronous and asynchronous. PDO frame is the main data interaction frame after the slave is started.

• SYNC: SynchrONous

Synchronous service adopts master-slave communication mode, where SYNC master node transmits SYNC objects regularly, and SYNC slave node executes tasks synchronously after receiving them. This frame is mainly used for synchronous transmission of PDO.

• COB-ID: CommunicatiON Object Identifier

Each CANopen frame begins with a COB-ID, which serves as the communication object identifier of the CAN frame. COB-ID is not equal to slave number. However, it is generally initialized to be associated with the slave number by default.

8.4.4 CANopen Indicators

When CANopen communicates, the user can judge the working state according to the CANopen indicator.


Table 8-3 Definition of CANopen Indicator Status

LED Indication	CAN Running (Green Light)	CAN Error (Yellow Light)
Off	None	No error
On	Working state	Bus off
Slow flash (cycle: 0.8 s)	Pre-running status	Pre-running status
Single flash (cycle: 1.2 s)	Stopped state	At least one error count of the CAN controller reaches or exceeds a warning value
Double flash (cycle: 1.6 s)	None	Error control event (heartbeat timeout)

8.5 CANopen Configuration

When "CAN-232" or "CAN-2*RJ45" is selected for the expansion card, the CAN communication configuration option will appear. When the CANopen communication protocol is enabled, the system will decide whether the local computer is the CANopen master or the CANopen slave according to whether there is CANopen configuration.

Step 1 After establishing the project, right-click "Setting>EXP" and select the corresponding physical expansion module "CAN-232" or "CAN-2*RJ45".




Step 2 Double-click "CAN" in "Setting" to pop up the following window.


CANopen communication port	Х
Station number Station 31 (1,31)	
Back end setup DIP setting	
Baud rate	
Baud rate 500 V Kbps	
Back end setup OIP setting	
Enable	
⊖CANopen ⊖CAN2.0	
Write Online Read online	
OK Cancel	

Step 3 Check to enable CANopen, and set the node number and baud rate as required, and then click "OK".


CAN, which is configured as the CANopen slave currently, can be configured as the CANopen master by right-clicking "CAN" in "Setting" and selecting "Add CAN configuration" in the pop-up menu, as shown in the following figure.




Step 4 Double-click "CANopen configuration" to open the CANopen configuration interface, as shown in the following figure.



Step 5 Double-click the device list to add the CANopen slave.



Step 6 If the slave device is not in the list, right-click on the CANopen device list and click to import EDS file (available from the device vendor).



8.5.1 Master Configuration

8.5.1.1 Master Information Interface

Set the master parameters, double-click the TS635 master in the network, and the following window appears.

laster configuration		>
Master Information Network status		
Network management		
Node ID: 31	* *	Disable SDO, 1947 access while the program is running
Baud rate: 500	- Kbps	All SDO errors continue to be configured
Synchronization		Heartbeat
Enable synchronized pr	oduction	ZEnable heartbeat production
COB-ID 16#	128	Production time (ms): 300 *
Synchronization cycle (ms):	200	*
Window length (ms):	0	
SDO timeout time		Node status monitoring
Timeout time: 500	ms	Enable site monitoring Monitor register start address (D):
Automatic assignment of PDO	mapping register	
Automatic assignment		Power-down retained register data
The mapping register start ad	ldress (D) of slave rece	eiving: 7000 Reset PDO mapping
The mapping register start a	ddress (D) of slave send	
	OK	Cancel

- 1. Network management
- "Node ID": Set the network master number.
 - ♦ When the node number is the same as the node number of the PLC itself, the PLC is initialized as the CANopen master.
 - ♦ When the node number is different from the node number of the PLC itself, the PLC is initialized as a CANopen slave.
- "Baud rate": The valid communication baud rate of the master.
- "Disable SDO, NMT access while the program is running": After checking this function, online debugging function will not be used during program running.

Note: This function only limits background software.

- "All SDO errors continue to be configured":
 - ♦ After checking this function, if SDO is configured incorrectly, it will continue to configure; This function is valid for all slaves.
 - ♦ If this function is not checked, the master will broadcast reset the slave if SDO error occurs.
- 2. Synchronous
- "Enable synchronized production": When checking this option, the node will transmit synchronization frames according to the time cycle set in "Synchronization cycle (ms)".
- COB-ID: Synchronization frame transmit ID, which defaults to 0x80 and is not allowed to be changed.
- "Synchronization cycle (ms)": The cycle period of sending synchronization frame, default to 200 (unit: ms).
- Window length (ms): This parameter defaults to 0, and is not allowed to be changed.

Note: Only one synchronous message can be sent at the same time in a CANopen network

- 3. Heartbeat
- "Enable heatbeat production": When checking this option, the node will transmit heartbeat frames according to the time cycle set in "Production time (ms)".
- "Production time (ms)": The cycle period of sending heartbeat, default to 300 (unit: ms).
 Note: The default heartbeat monitoring consumption time of the master is 2.5 times the heartbeat

production time.

4. SDO timeout

"Timeout time": SDO wait time, default to 500 (unit: ms).

SDO frames are mainly used for network configuration. If SDO does not receive the return frame on time within before timeout, the master determines the configuration timeout. This time is the waiting interval time of each frame.

5. Node status monitoring

The node's online status is updated to the system variable _sCANOpen.NodeState[64], where _sCANOpen.NodeState[0] is the local state and _sCANOpen.NodeState[站号] is the corresponding slave state.

Numerical Value	State
0	Initialization state
4	Stopped state
5	Running state
127	Pre-running status
255	Offline state

Note: This function only makes sense when the slave enables the heartbeat, because this state is fed back by the slave heartbeat.

- 6. Automatic allocation mapping register
- "Automatic assignment": This function is checked by default.
 - ♦ If this function is checked, the register address for "master-slave" data interaction will be automatically assigned.
 - ♦ If this function is not checked, the user needs to manually set the start address of data interaction (set the start address of each PDO separately).
- "The mapping register start address (D) of slave receiving": The start address of the data sent by the master is automatically allocated (it makes sense only when automatic allocation is checked).
- "The mapping register start address (D) of slave sending": The start address of the data received by the master is automatically allocated (it makes sense only when automatic allocation is checked).

8.5.1.2 Network State

ergency error	message								_			
Network			23%			:	Stop mo	nitoring				
Site					S	tatus						^
31						inning						
1 2						ffline mning						_
3					Of	ffline						- 1
4						fline						
5					01	ffline						- 1
												~
ergency error reation Time		ite	1	(Error C	Code 16#)	Error Regi	ister (Manufacture	r Error	Code	(16#)	_
		ite		(Error C	Code 16#)	Error Regi	ister (Manufacture	r Error	Code	(16#)	
		ite		(Error C	Code 16#)	Error Regi	ister (Manufacture	r Error	Code	(16#)	_ 、
		ite		(Error C	Code 16#)	Error Regi	ister (Manufacture	r Error	Code	(16#)	~
		ite		(Error C	Code 16#)	Error Regi	ister (Manufacture	r Error	Code	(16#)	
		'ite		(Error C	Code 16#)	Error Regi	ister (Manufaotur e	r Error	Code	(16#)	~
		iite		(Error C	Code 16#)	Error Regi	ister (Manufaotur e	r Error	Code	(16#)	~
		'ite		(Error C	Code 16#)	Error Reg)	ister (Manufacture	r Error	Code	(16#)	~
reation Time		ite		(Error C		Error Regi	ister (Manufacture	r Error	Code	(16#)	

- Start/Stop monitoring: Click on this item to start state monitoring for this page. When monitoring is started, click "Stop Monitoring" to exit network monitoring.
- Network load: Monitor load status of the CAN network in real time.
- Network state table: Displays the running state of the current network nodes. This state comes from the node status system variables.
- Emergency error information
 - ♦ Display the emergency error information in the current network. The PLC master only caches the latest error message. If the page is not closed, up to 5 messages can be cached in the background.
 - ♦ For details about emergency error information, see section 8.6.2.2 Emergency Error Code.
- SDO configuration
 - ♦ Node number: The incorrect node number for SDO configuration.
 - ♦ Error step number: The number of the SDO error. Check the corresponding number information in the "Service Data Object" tab of the slave with the corresponding error parameter.
 - Error code: The SDO error code. (CANopen standard error code)

8.5.2 Slave Configuration

This section takes EC-TX105 as an example to introduce the configuration process and related parameters of CANopen slaves.

8.5.2.1 General Settings

After checking "Enabling experts", the window as shown on the right below appears.

Setting of Slave Station	×	L Setting of Slave Station
Slave node Receive PDO Send PDO Service data object Debugging 1/O mapping Device information		Slave node Receive PDO Send PDO Service data object Debugging I/O mapping Device information
Replar Nede ID: 1 . [Rabling superts		Regular Reds ID:
		Error control
		Enable node protection Imable heartbeat Protection time (ms): 200 Production time (ms): 300
	N	Life cycle factors: 3 C Modify heartbeat consumption attributes
		Syndhorous generator Energency message Orable endromisation COB-10-156 Energency message Enable energency message
		Synchronization cycle (ms): 200 COB-ID: 15# 81
		Window length: 0
		Reboot check
		Check suppliers Check product ID Check version
Of Caseal		OK Curel

- 1. General
- "Node ID": The slave node number to be configured.
- "Enabling experts": Checking this function will display detailed slave configuration. Not checked by default.
- "SDO errors continue to be configured": This option is unchecked by default.
 - ♦ "Valid": Skip to the next configuration item if configuration error occurs.
 - ◇ "Invalid": The master will not proceed with the configuration if configuration error occurs, and the node will be re-configured.
- "Create all SDOs": When this option is selected, all writable object dictionaries in the EDS will be added, initialized during configuration. Not checked by default.


- 2. Error control
- "Enable heartbeat": When this option is checked, the slave will generate heartbeats. After the slave heartbeat is checked, the master monitors the heartbeat status of the slave by default.
- "Production time (ms)": The cycle time when the heartbeat is sent.
- Modify heartbeat consumption attributes": This option is not selected by default.
 - ♦ This function is used to set the heartbeats of other nodes that will be monitored by this slave.
 - ♦ This function also requires the slave to support heartbeat monitoring function.
- 3. Synchronization generator (if supported by slave)
- "Enable synchronization generator": When checking this option, the node will transmit synchronization frames according to the time cycle set in "Synchronization cycle (ms)".
- COB-ID: Synchronization frame transmit ID, which defaults to 0x80 and is not allowed to be changed.
- "Synchronization cycle (ms)": The cycle period of sending synchronization frame, default to 200 (unit: ms).
- "Window length": This parameter defaults to 0, and is not allowed to be changed.

Note: Only one synchronization frame can be sent in a CANopen network.

- 4. Emergency packets
- "Enable emergency message": If this function is checked, the COB-ID of emergency packets will be set in the configuration process, but it is not checked by default.
- 5. Check on restart
- "Check suppliers, Check product ID, Check version": When checking the corresponding function, the relevant check will be carried out before starting slave configuration. If the check fails, the node cannot be started.

8.5.2.2 Receive PDO/Transmit PDO

Click to select receive PDO/transmit PDO, and the interface will appear:



- Receive PDO: master -> slave data
- Transmit PDO: slave -> master data

8.5.3 PDO Enabling

- The check box before the number is used to select whether this PDO is valid.
- If this PDO does not contain mapping objects, it cannot be checked.
- The PDO that takes effect by default in the EDS file of the slave has been checked by default.

8.5.4 PDO Mapping Editing

Used to edit the PDO mapping through the "Add PDO mapping", "Edit" and "Delete" buttons in the window.

8.5.5 PDO Attribute Settings

The PDO attribute interface appears as follows:

PDO property		×
COB-ID(16#)	201]
Transmission type	Async (profile events) (255) V]
Synchronization number	1 ~	
Inhibit time (0-65535):	0	100us
Event timer (0-65535):	0	1ms
	OK Cancel	

- COB- ID: ID number used for PDO transmission.
- Transmission type

Туре	Data Transmission Conditions	Data Effective Conditions
Acyclic-synchronous (Type 0)	Data changes and a synchronization frame is received	
Cyclic-synchronous (Type 1-240)	The data is transmitted after receiving the synchronization frame of the corresponding "synchronization number"	It does not take effect immediately after receiving data, and it takes effect only after receiving one frame synchronization
Asynchronous-Manufacturer-specific (Type 254)	Customized by each manufacturer	Customized by each manufacturer
Asynchronous-Device Profile-specific (Type 255)	The time when data changes or meets the event, and the change frequency is less than the suppression time	Effective immediately

Note: When setting up a certain node for synchronous transmission, it is necessary to enable synchronous production of the master

• Synchronization number

Used to set the synchronization number, only valid after selecting Cyclic-synchronous (Type 1-240).


• Inhibition time

Available only after selecting Asynchronous-Device Profile-specific (Type 255). This function is invalid when set to 0; If it is not 0, it indicates the minimum interval for frame transmission.

• Event time

Available only after selecting Asynchronous-Device Profile-specific (Type 255). This function is invalid when set to 0. If it is not 0, it indicates the period of regular transmission (This transmission condition is also limited by the inhibition time).

The following figure takes Synchronous cycle-synchronous type = 2 as an example.



8.5.6 Service Data Object

The Service Data Object (SDO) tab interface is shown below (using DA200 as an example). The table automatically generates SDO configuration data based on the EDS file and user settings.

Numbe	Index	Subinde	Name	Value	Bit Len	Download \land	
1	16#1000	16#00	Device Type	0x0	32	*	
2	16#1018	16#01	Vendor ID	0x00000000	32		
3		16#02	Product code	0x00000000	32		
4	16#1018	16#03	Revision number	0x00000000	32		
5	16#1400	16#01	Disable PDO	0x80000202	32	*	
6	16#1401	16#01	Disable PDO	0x80000302	32	*	
7	16#1402	16#01	Disable PDO	0x80000402	32	*	
3	16#1403	16#01	Disable PDO	0x80000502	32	*	
9	16#1600	16#00	Clear PDO mapping	0x00	8	*	
10	16#1601	16#00	Clear PDO mapping	0x00	8	*	
11	16#1602	16#00	Clear PDO mapping	0x00	8		
12		16#00	Clear PDO mapping	0x00	8		
13		16#01	Disable PDO	0x80000182	32	*	
14		16#01	Disable PDO	0x80000282	32	*	
15	16#1802		Disable PDO	0x80000382	32	*	
16	16#1803		Disable PDO	0x80000482	32	*	
17		16#00	Clear PDO mapping	0x00	8	*	
18	16#1A01	16#00	Clear PDO mapping	0x00	8	*	
19		16#00	Clear PDO mapping	0x00	8		
20		16#00	Clear PDO mapping	0x00	8		
21		16#02	Transmission type inhibit time	0x01	8 16	*	
22 23	16#1400 16#1400	16#03 16#05	Inhibit time Eventtimer	0x0000 0x0000	16	*	
23 24	16#1400		Eventtimer Transmission type	0x0000 0x01	8	* ~	
SD	O timeou DO editor	500	dd Edit		Delete		

The SDO editing options are described as follows:

- Add: Adds user configurations. The main function is to assign initial values to the object dictionary.
- Edit: Re-edits user configuration.
- Delete: Deletes user configuration.

8.5.7 Online Debugging Function

The online debugging tab interface is displayed as follows.

e node Receive PDO Send PDC	Service data object Debugging I/O mapping Device information	
NMT command Boot node Reset node	Stop node Pre-run Stop moni	toring
Service Data Object (SDO)		
Index 16# 1000	Sub-index 16# 0	\sim
Value	Decimal V Bit 32	
Result		
	Read SDO Write SDO	
Diagnostic Online Running	SDO error 0	
Error code	555 2161	
Diagnostic		
Emergency error		
Creation Time	(Error Code 16#) Error Register (16# Manufacturer E	rror I 🔨

Note: If "Disable SDO, NMT access while the program is running" is selected in the master, this function cannot be used.

- NMT instructions
 - ♦ Start node: Send a start node instruction to the slave.
 - ♦ Stop node: Send a stop node instruction to the slave.
 - ♦ Pre-operation: Send a pre-operation instruction to the node.
 - ♦ Reset node: Send a reset node instruction to the node.
 - Reset communication: Send a reset communication instruction to the node.
- SDOs
 - ♦ Index and subindex: Only the object dictionary provided in the slave EDS can be selected.
 - ♦ Value: The data sent or returned.
 - ♦ Bit length: Obtained from the slave EDS object dictionary.
 - ♦ Result: Read and write state information.
 - ♦ Read SDO, write SDO: Perform the read and write operations of corresponding object dictionary.
- Diagnostics
 - ♦ Online state: The current state of the slave (based on heartbeats).
 - SDO error step number: The error number of SDO that occurred during the configuration process.
 This number corresponds to the number in the "Service Data Object" tab.
 - Diagnostic string: Current error message (SDO error). For details, see section 8.6.2.1 SDO Error Code.

8.5.8 I/O Mapping

The I/O mapping option interface appears as follows.

Variable	Mapping	Index: subindex	Bit len	^
D7000 D7002	Receive FDO1 mapping	16#1600	48	
D7000	RPDO	16#2100	16	
D7001	CANopen fuction	16#2100, 1	16	
D7002	CANopen write fuction	16#2100, 2	16	
∃ D7003D7006	Receive PDO2 mapping	16#1601	64	
D7003	RPDO	16#2101	16	
D7004	set_value1	16#2100, 3	16	
D7005	set_value2	16#2100, 4	16	
D7006	set_value3	16#2100,5	16	
∃ D7007D7010	Receive PDO3 mapping	16#1602	64	
D7007	set_value4	16#2100,6	16	
D7008	set_value5	16#2100, 7	16	
D7009	set_value6	16#2100,8	16	
D7010	set_value7	16#2100, 9	16	
■ D7011D7014	Receive PDO4 mapping	16#1603	64	
❶ D7400D7402	Transmit PD01 mapping	16#1a00	48	
❶ D7403D7406	Transmit PDO2 mapping	16#1 a01	64	~
B D7403D7406	Transmit PDO2 mapping	16#1 a01	64	~

This tab is used to set the data communication mapping relationship between master and slave PDO. If Automatic Allocation is not checked in the master settings, the user can double-click one of the mappings to set it, as shown in the following figure. The user can set the master register start address corresponding to each salve PDO by himself.

Mapping parameter set	ting			×
Element type	D	Data type	16 ~	
Mapping parameter	7000	Mapping bit	48	
Mapping parameter ra	nge			
Mapping parameter sta	art address	D7000		
Mapping parameter en	d address	D7002		
Number of elements us	sed for mapping	3		
[OK	Cancel		

8.5.9 Device Information

The "Device information" tab has an interface as shown below:


Setting of Slav	e Station					
Slave node Rece	ve PDO Send PDO	Service data object	Debugging	I/O mapping	Device information	
Name:	EC-TX105					
Suppliers:	shenzhen INVT	electronic co.,ltd				
Туре:	0x0					
Serial	0					
Version:	Vendor ID: 0x0	Product ID: 0				
Description:	EDS for the IN	VT CANopen				

The device information of the slave is obtained from the EDS file provided by the device manufacturer.

8.5.10 CANopen Slave Description

8.5.10.1 Slave Configuration Procedures

Step 1 After establishing the project, right-click "Setting>EXP" and select the corresponding physical expansion module "CAN-232" or "CAN-2*RJ45".



Step 2 Double-click "CAN" in "Setting" to pop up the following window.

CANopen communication port	×
Station number Station 31 (1,31)	
Back end setup DIP setting	
Baud rate	
Baud rate 500 \checkmark Kbps	
Back end setup OIP setting	
Enable	
● CANopen ○ CAN2.0 ○ Close	
Write Online Read online	
OK Cance	:1

Step 3 Check to enable "CANopen", and set the node number and baud rate as required, and then click "OK" to complete the slave configuration.

Note: Do not continue to add CAN configuration by right-clicking, otherwise this machine will act as the CANopen master.

8.5.10.2 Slave CANopen Data Interaction

The TS600 series programmable logic controller, when operating as a slave, only supports 4 TPDOs and 4 RPDOs with each PDO supporting a maximum of 8 bytes of data. The object dictionary of the slave is set with 16 16-bit mapped addresses for caching transmitted data and another 16 16-bit mapped addresses for caching received data. They are respectively bound to the corresponding slave R500–R531 elements, as shown below.

Index	Sub-index	Name	Access type	Data type	Slave bind elements
2109	1	1st Rx Buffer	RW	16	R500
2109	2	2st Rx Buffer	RW	16	R501
2109	3	3st Rx Buffer	RW	16	R502
2109	4	4st Rx Buffer	RW	16	R503
2109	5	5st Rx Buffer	RW	16	R504
2109	6	6st Rx Buffer	RW	16	R505
2109	7	7st Rx Buffer	RW	16	R506
2109	8	8st Rx Buffer	RW	16	R507
2109	9	9st Rx Buffer	RW	16	R508
2109	10	10st Rx Buffer	RW	16	R509
2109	11	11st Rx Buffer	RW	16	R510
2109	12	12st Rx Buffer	RW	16	R511
2109	13	13st Rx Buffer	RW	16	R512
2109	14	14st Rx Buffer	RW	16	R513
2109	15	15st Rx Buffer	RW	16	R514
2109	16	16st Rx Buffer	RW	16	R515

Table 8-4 Reference for Data Received

Table 8-5 Reference for Data Transmitted

Index	Sub-index	Name	Access type	Data type	Slave bind elements
2108	1	1st Tx Buffer	RW	16	R516
2108	2	2st Tx Buffer	RW	16	R517
2108	3	3st Tx Buffer	RW	16	R518
2108	4	4st Tx Buffer	RW	16	R519
2108	5	5st Tx Buffer	RW	16	R520
2108	6	6st Tx Buffer	RW	16	R521
2108	7	7st Tx Buffer	RW	16	R522
2108	8	8st Tx Buffer	RW	16	R523
2108	9	9st Tx Buffer	RW	16	R524
2108	10	10st Tx Buffer	RW	16	R525
2108	11	11st Tx Buffer	RW	16	R526
2108	12	12st Tx Buffer	RW	16	R527
2108	13	13st Tx Buffer	RW	16	R528
2108	14	14st Tx Buffer	RW	16	R529
2108	15	15st Tx Buffer	RW	16	R530
2108	16	16st Tx Buffer	RW	16	R531

8.6 Troubleshooting of CANopen Communication

8.6.1 Common Troubleshooting Steps

- Check the matching resistance
 - Disconnect the power supply of all devices, and measure the resistance between CANH and CANL at either end of the network with a multimeter, which should be about 60 Ω. If it is too small, it means that the matching resistors are not only connected at both ends of the network, but also wrongly connected at other positions which shall be disconnected.
 - If only one matching resistor is connected, it will be about 120 Ω, and the communication quality of the network will be very poor.
 - ♦ If no resistor is connected at all, the network cannot communicate. Make sure to connect the matching resistors at both ends of the network.
- Check baud rate
 - Check whether the baud rate is normal, and all nodes in the network can communicate normally only if the baud rate is set to the same level.
 - ♦ The baud rate of device will take effect only after power cycle or restart.

For the relationship between communication distance and baud rate, please refer to section 8.3.2 Communication Distance Corresponding to CAN Baud Rate.

- Check the wiring
 - ♦ The CGND terminals of all CAN devices must be connected together so that all devices share the CGND terminals of CAN communication power supply.
 - ♦ Check whether there is short circuit in communication wire, shielded wire and power supply.
- Other
 - ♦ If there is severe interference on site, please try to reduce the communication baud rate when there is no way to troubleshoot.

8.6.2 Fault Code List

8.6.2.1 SDO Error Code

Interruption code	Code function description	Interruption code	Code function description
0503 0000	Triggering bit not alternated	0601 0002	Attempts to write information to a read-only object
0504 0000	SDO protocol times out	0602 0000	Object cannot be found in the object dictionary
0504 0001	Illegal or unknown Client/Server instruction word	0604 0041	Object cannot be mapped to PDO
0504 0002	Invalid block size (Block Transfer mode only)	0604 0042	Number and length of the object to be mapped exceeds the PDO length
0504 0003	Invalid serial number (Block Transfer mode)	0604 0043	Common parameter incompatibility
0503 0004	CRC Error (Block Transfer mode)	0604 0047	Common internal incompatibility of the device
0503 0005	Memory overflow	0606 0000	Object access failure caused by

Interruption code	Code function description	Interruption code	Code function description
			hardware error
0601 0000	No access to the object	0607 0010	Data type not matched; service parameter length not matched
0601 0001	Attempts to read a write-only object	0607 0012	Data type mismatch, service parameter length is too long
0601 0002	Attempts to write information to a read-only object	0607 0013	Data type mismatch, service parameter length is too short
0602 0000	Object cannot be found in the object dictionary	0609 0011	Subindex does not exist
0604 0041	Object cannot be mapped to PDO	0609 0030	Out of value range of parameter (on write access)
0800 0000	Common error	0609 0031	Written parameter value too large
0800 0020	Data failed to be transmitted or stored in the application	0609 0032	Written parameter value too small
0800 0022	Data failed to be transmitted or stored in the application due to the current state of the device	0609 0036	Max. value less than Min. value

8.6.2.2 Emergency Error Code

Table 8-6 Main Table 1 (Hexadecimal)

Emergency Error Code	Description	Emergency Error Code	Description
00xx	Error reset or no error	50xx	Hardware error
10xx	General error	60xx	Device software
20xx	Current error	61xx	Internal software
21xx	Device input	62xx	User software
22xx	Internal equipment	63xx	Data setting
23xx	Device output	70xx	Auxiliary device error
30xx	Voltage error	80xx	Monitor error
31xx	Main power supply	81xx	Communication
32xx	Internal equipment	82xx	Protocol error
33xx	Output	90xx	External error
40xx	Temperature error	F0xx	Additional function error
41xx	Environment	FFxx	Device specific error
42xx	Device	-	-

Table 8-7 Main Table 2 (Hexadecimal)

Emergency Error	Description	Emergency Error Code	Description
0000	Error reset or no error	6300	Data setting
1000	General error	7000	Additional module error
2000	Current error	8000	Monitoring error
2100	Device input current	8100	General communication error
2200	Internal device current	8110	CAN communication overload
2300	Device output current	8120	CAN passive mode error

Emergency Error	Description	Emergency Error Code	Description
3000	Voltage error	8130	Node protection or heartbeat error
3100	Power supply voltage	8140	Bus off restore
3200	Internal device voltage	8150	CAN-ID conflict
3300	Output voltage	8200	Protocol error
4000	Temperature error	8210	PDO length error
4100	Ambient temperature	8220	PDO length overrun
4200	Device temperature	8240	Unrecognized SYNC data length
5000	Device hardware error	8250	RPDO timeout
6000	Device software error	9000	External error
6100	Internal error	F000	Additional function error
6200	User software	FF00	Special device error

8.7 CAN Free Protocol

8.7.1 Function Introduction of CAN Free Format

The TS600 PLC supports one CAN free format communication with extended frames and data frames, specifically divided into standard frames (CAN2.0A) and extended frames (CAN2.0B) according to the standard protocol types.

- The frame ID length of the standard frame is 11 bits, which means the frame ID range is 000–7FF.
- The frame ID length within the extended frame is 29 bits, which means the frame ID range is 0000000– 1FFFFFF.

The TS600 can exchange free format data with other devices in the CAN network that support the CAN2.0A or CAN2.0B protocol.


8.7.2 Communication Specifications of CAN Free Format

Item	Specification
Connector	Network port
Transmission cable	Common network cable
Course and a dama dama dama da	CAN2.0A (11-bit identifier)
Supported standard protocols	CAN2.0B (29-bit identifier)
Max. number of communication codes	64
Baud rate	20, 50, 100, 125, 250, 500, 800, 1000 kbit/s
Buffer bits	16-bit

8.7.3 CAN Free Port Configuration

When using the CAN free port, it is necessary to configure the CAN port communication method. The steps are as follows:

Step 1 Configure the corresponding CAN card.



Back end setup DIP setting Baud rate Baud rate Baud rate DIP setting OIP setting

Baud rate 500	∨ Kbps	
Back end setup	O DIP settir	Ig
Enable		
CANopen OCAN2.0	Oclose	
Write Online	Read online]
	OK	Cancel

8.7.4 CAN Free Format Data Sending and Receiving

For details, refer to section 3.23.4 "CANfree_Recv" and section 3.23.5 "CANfree_Send" in the "TS600 Series Programmable Logic Controller Command Manual."

9 EtherCAT Communication

9.1 Overview

EtherCAT is an open industrial field technology based on Ethernet, and has the characteristics of short communication refresh period, small synchronization jitter and low hardware cost. To understand the principle and related technologies of EtherCAT, please refer to the book Driver Design and Application of Industrial Ethernet Fieldbus EtherCAT, or log in to official website of EtherCAT Technical Committee at https://www.EtherCAT.org.cn.

TS600 Series supports standard EtherCAT interface (1-way RJ45 interface), up to 72 EtherCAT slaves, adopts linear topology structure, and the minimum EtherCAT fieldbus cycle can be set to 250 μs.

Entry	Specification
Transmission speed	100Mbps: 100BASE-TX
Modulation	Baseband
Topology	Line, daisy chain
Transmission medium	Twisted pair of category 5 or above or shielded twisted pair with
	aluminum foil and braided shielding
Transmission distance Distance between nodes: 100m or less	
Maximum connections 72	

Table 9-1	EtherCAT	Interface	Specification
			op 0000


9.2 Master Configuration

9.2.1 Import Device XML


Import device XML means importing the device description file (suffixed by ". XML") conforming to ETG (EtherCAT Technical Committee) standard into the programming software AutoStation Pro, and then generating EtherCAT configuration devices for users to add, delete, etc. after the files are parsed in the software.

Auto Station Pro, the programming software, integrates INVT's common-used EtherCAT slave devices which do not need to be installed separately. If a third-party EtherCAT device is required, the device description file must be installed first. Take the import process of INVT servo driver DA260 as an example.


Step 1 Create a new project, set it up, find "EtherCAT", and right-click on on "Add device ".



Step 2 Click "Import configuration", and in the pop-up dialog box, select the XML file to be added and import it.



- Step 3 The software must be restarted for the newly imported xml to take effect. If multiple devices are required to be imported, you can repeat step 2 to import them all before restarting the software.
- Step 4 You can see the newly added device after reopening the software



9.2.2 Scanning Device

Step 1 Right-click on "EtherCAT" > "Slave Scan".

🖙 Ether		
Ctrier	Open	
COM	Add device	
COM	Delete all device	
	Enable all slaves	
💸 Ether	Disable all slaves	
💸 Ether	Slave scanning	

Step 2 In the pop-up interface, click "Start Scanning".


SCAN Serial Numbe Current Slave Station List	Serial Nun Scan Slave Station List File Name	
	es the PLC to be in a stopped state.	
	C to a stopped state? Click "Yes" to and scan, and click "No" to not scan!	>
Start Scan ^① Clear reset	Update configuration Exit	

Step 3 If there are devices on the bus, the corresponding slaves will be scanned in the order of the slaves. The "Alias" can modify the device file. When you click "Update configuration," a prompt "Do you want to replace the existing slave devices?" will appear. Click "OK" to complete the configuration update while click "Cancel" to add a new device based on the existing configuration. If there are no connectable devices on the bus or the scan times out, the "Information output" window will display the message "Scan state query timedout".


Below is an example of scanning when the master is connected to two slaves:

SCAN		×
Serial N Current Slave Station List Module ID	Seria Scan Slave Station Lit File Name 1 INVT_DA200_265 INVT_DA200_Ethe 2 INVT_DA180_115 DA180_EtherCAT_	
	<	>
Starting scan Parsing scan data The number of identified connected devices is 2 The basic information of the 1 device scanned is:Vendor ID: The basic information of the 2 device scanned is:Vendor ID: Start Scan	D: 0x616, ProductCode: 0x0, Version: 0x0; D: 0x616, ProductCode: 0x3, Version: 0x64; Update configuration Exit	

Step 4 After clicking "Update configuration," the following options pop up.



Step 5 The slave has been successfully added.



🖉 Note:

- The EtherCAT slaves can be scanned only when the PLC is in stop mode.
- For situations where the same type of device has been added but there are multiple different versions of the xml file, the scanning function program selects the first device as the configuration device by default.
 - INVT_DA200_EtherCAT_V261_191025.xml
 INVT_DA200_EtherCAT_V262_200313.xml
 - INVT_DA200_EtherCAT_V265_220120.xml
 - INVT_DA260_EtherCAT_V265_220120.xml

9.2.3 Master Setting

Step 1 Right-click on "EtherCAT" > "Open".



- Step 2 "Basic setting" pops up. In the "Basic setting" interface, you can set the enable control, cycle time and synchronization offset of EtherCAT master.
 - "Enable": When the EtherCAT master is disabled, all EtherCAT slaves are disabled, and the fieldbus servo axis associated with the slaves will no longer operate.
 - Recycle": EtherCAT data frame transmission interval and cycle time of EtherCAT task.

- "Synchronization offset": Percentage of the relative offset of the EtherCAT task relative to Sync0 interrupt of the slave.
- Restart the slave: When checked, the slave will automatically restart if it is offline. When unchecked, the slave will not restart if it is offline.

Basic setting				×			
Name	EtherCAT Ma	EtherCAT Master					
Device	TS635	TS635					
Enable	○ Disable	Enable					
Recycle	1000		\sim	us			
Synchronization of	ffset	10		%			
Number of slaves		0					
Restart the slave	Auton	natic restart of slave	station				
	OK	Cancel					

9.2.4 Start-stop & Disable & Enable

• Start/stop Control

It supports the start-stop of the EtherCAT fieldbus, but does not support the start-stop of a single slave. The related operations are as follows:

- \diamond When PLC switches from STOP state to RUN state, the EtherCAT master starts to run automatically.
- ♦ When PLC switches from Run state to STOP state, the EtherCAT master stops to run automatically.
- ♦ The EtherCAT master can be stopped and started by system variables during PLC operation.

Note: The start-stop of the EtherCAT fieldbus is supported, but the start-stop of a single slave is not supported.

System variables	Data type	Function
		It stops the operation of EtherCAT master.
bStopMaster	BOOL	The EtherCAT master is stopped on the rising edge of variable input,
		and the variable is automatically reset after the stop is completed.
		It starts the operation of EtherCAT master.
bStartMaster	POOL	When the EtherCAT fieldbus fails or is in stop mode, it will
DStartmaster	BOOL	automatically reset after the EtherCAT master is restarted on the rising
		edge of variable input.

• Automatic Restart

By default, it supports the function of automatically restarting the slave.

9.2.5 Summary of System Variables

Table 9-2 EtherCAT Communication Related System Variables

System variables	Data type	Function
MasterRunState	DOOL	Operation status of EtherCAT master
	BOOL	When the EtherCAT master receives the run instruction and all

System variables	Data type	Function
		slaves start up, it becomes TRUE.
		Note: This variable is still TRUE if some of the slaves are offline
		while EtherCAT is running.
		Master link state
LinkState	BOOL	As long as there is a slave which has normal physical connection
		with the master, the variable becomes ON, otherwise it is OFF.
List of Database	DOOL	EtherCAT real-time task heartbeat
HeartBeat	BOOL	Every EtherCAT real-time task cycle is flipped once.
DelekileertDeet	DOOL	EtherCAT non-real-time task heartbeat
BolckHeartBeat	BOOL	Every EtherCAT non-real-time task cycle is flipped once.
MaxCycleTime	DINT	Maximum cycle period of EtherCAT task
MinCycleTime	DINT	Minimum cycle period of EtherCAT task
CycleTime	DINT	Cycle period of the last cycle of EtherCAT task
MaxExeTime	DINT	Maximum EtherCAT task execution time
MinExeTime	DINT	Minimum EtherCAT task execution time
ExeTime	DINT	Execution time of the last cycle of EtherCAT task
TxFrames	DINT	Total frames sent
RxFrames	DINT	Total frames received
TxFramesRates	DINT	Frame rate at which the data is transmitted (frames/second)
RxFramesRates	DINT	Frame rate at which the data is received (frames/second)
TxBytesRate	DINT	Frame rate at which the data is transmitted (bytes/second)
RxBytesRate	DINT	Frame rate at which the data is received (bytes/second)
LossFrames	DINT	EtherCAT lost data frames
ResetTime	BOOL	Reset execution time and cycle time
		It starts the operation of EtherCAT master
		When the EtherCAT fieldbus fails or is in stop mode, it wil
StartMaster	BOOL	automatically reset after the EtherCAT master is restarted on the
		rising edge of variable input.
		It stops the operation of EtherCAT master.
		The EtherCAT master is stopped on the rising edge of variable
StopMaster	BOOL	input, and the variable is automatically reset after the stop is
		completed.
DisableMaster	BOOL	Disable Master Enable
ClearFrameCounter	BOOL	Reset EtherCAT data frame counter register
		Online status of all slaves
SlavesState	INT	It is 1 when all slaves in the configuration are in the running state
Suvessitie		and 0 when only one slave is in the non-running state
		This variable is used to display the configuration location of the
FirstErrorSlave	INT	first offline slave when there is a slave failure in the configuration
Thotemorolave		(the state machine switches to a non-OP state or goes offline)
LibVersion	DINT	EtherCAT system library software version
MstVersion	DINT	EtherCAT master software version
DriveVersion	DINT	EtherCAT network adapter driver software version
TxErrorCnt	DINT	EtherCAT data frame transmit error count
		EtherCAT data frame transmit error count EtherCAT data frame receive timeout count
RxTimeoutCnt		
RxCorruptCnt	DINT	EtherCAT receive invalid frame count
RxUnmatchCnt	DINT	EtherCAT receive unmatched frame count
RxPDOLength	DINT	Total length of PDO received in configuration (bytes)
TxPDOLength	DINT	Total length of PDO transmitted in configuration (bytes)

TS600 Series Programmable Logic Controller Programming and Application Manual


System variables	Data type	Function
ConfigureState	DINT	Configuration state internal use
Delay	DINT	Adjustment value of EtherCAT master synchronous regulator
		Physical connection status of all slaves
SlavesLinkState	INT	This variable is 1 when all slaves in the configuration are
		physically connected, otherwise it is 0
DisableState	INT	Master disability state

9.3 Slave Configuration

9.3.1 General Settings

• Configuration address

The configuration address of slave refers to the sequential address in the AutoStation Pro device tree, starting from 0 and increasing sequentially. This address can be used as a subscript to a slave system variable array or as a slave address for reading and writing SDO instructions.



• Distributed clocks

This section is used to set the synchronous operation mode of the slave. The interface is as follows:

Basic information						
Status	Synchronization mode selection	DC-Synchron	\sim		🗹 ID check	
510105					Station number	
General setting	Enable DC synchronization event	1000		US	0	
Process data	Sync0					
Startup parameter	Sync0 enable					
I/O mapping	Synchronization unit cycle ×1	Cyde time	1			
	(iii) User-defined	Offset time	0			
	Sync1					
	Sync1 enable					
	○ Synchronization unit cycle ×1	Cycle time	1			
	(iii) User-defined	Offset time	0			

"Synchronization mode selection": Generally speaking, for EtherCAT slaves, FreeRun mode and DC-Synchronization mode which is synchronous with distributed clock can be chosen. The options supported by synchronization mode will vary depending on the slave selected.

Note: Customers are not recommended to modify the default configuration in DC-Synchronon mode unless they have a better understanding of EtherCAT communication principles.

• Site alias setting

Right-click on the slave and click "Rename" to rename the slave.



9.3.2 Process Data

The process data interface is used to edit PDO, as shown in the following figure.

Basic information	1	Add	Delete Ed	lit	Show all Show all	<u> </u>	~			
Status		Input/Output		Index	S Fold	nput PDO		ags	SM	Data Type
			DO Outputs	0x1600		Dutput PDO		table	2	
			Control Word	0x6040	040	10		·		UINT
General setting			Target Position	0x607a	0x0	32				DINT
			Target Velocity	0x60ff	0x0	32				DINT
D			Mode of Operation	0x6060	0x0	8				SINT
Process data			Target torque (3)	0x6071	0x0	16				INT
			Touch probe control	0x60b8	0x0	16				UINT
Startup parameter			Positive torque limit	0x60e0	0x0	16				UINT
Startup parameter		Negtive torque limit	0x60e1	0x0	16				UINT	
			Max profile velocity	0x607f	0x0	32				UDINT
I/O mapping	-	🗹 Input	DI Inputs	0x1a00	0x0	200	Edi	table	3	
			Status Word	0x6041	0x0	16				UINT
			Position Actual Value	0x6064	0x0	32				DINT
			Speed Actual Value	0x606c	0x0	32				DINT
			Torque Actual Value	0x6077	0x0	16				INT
			Operation Mode Display	0x6061	0x0	8				SINT
			Current Actual Value	0x6078	0x0	16				INT
			Touch Probe Status	0x60b9	0x0	16				UINT
			Touch Probe 1 Positive value	Ox60ba	0x0	32				DINT
			Digital inputs	0x60fd	0x0	32				UDINT

No.	Description
1	PDO edit button
2	PDO display selection area
3	PDO display area

PDO is divided into output group PDO and input group PDO according to data flow direction. The output group PDO represents the process data sent by the EtherCAT master to the EtherCAT slave, such as the control word 0x6040, and the input group PDO represents the process data sent by the EtherCAT slave to the master.

Each slave may have multiple groups of PDOs or a single group of PDOs, as shown in the above figure, the first group of input PDOs and the first group of output PDOs can be edited for addition, editing, deletion, etc.

Taking adding PDO as an example, the operating steps are as follows:

- Step 1 Select a PDO in the first group
- Step 2 Click "Add".
- Step 3 Select 6072
- Step 4 Click "OK".

TS600 Series Programmable Logic Controller Programming and Application Manual

_		. .						
Basic information	Add	Delete Edit	Sh	ow all	\sim			
Status	Input/Output		Add/Edit					
	- V Uutput	DO Outputs Control Word						
General setting	<u> </u>	Target Position	Indexe	s Subindexes	Names	Access Types	Data Types	Default Value
General setting		Target Velocity	0x410	0x0	Analog output1	RT	DINT	0x0
		Mode of Operation	0x410	1 0x0	Analog output2	RT	DINT	0x0
Process data		Target torque	0x604	0x0	Control word	RT	UINT	0x0
		Touch probe control	0x606	0x0	Operation N ode	RT	SINT	0x0
Startup parameter		Positive torque limit	0x607		Target torque	RT	INT	0x0
startup parameter		Negtive torque limit	3 0x607		Eax torque	RT	UINT	0x0
		Max profile velocity	0x607		Target Position	RT	DINT	0x0
I/O mapping	— 🔽 Input		0x607		Polarity	RT	USINT	0x0
	U Input	Status Word	0x607	f 0x0	Max profile velocity	RT	UDINT	0x0
		Position Actual Value	0x608		Profile velocity	RT	UDINT	0x0
		Speed Actual Value	0x608		Profile acceleration	RT	UDINT	0x0
		Torque Actual Value	0x608		Profile deceleration	RT	UDINT	0x0
		Operation Mode Display	0x60b		Position offset	RT	DINT	0x0
		Current Actual Value	0x60b		Velocity offset	RT	DINT	0x0
		Touch Probe Status	0x60b		Torque offset	RT	INT	0x0
		Touch Probe 1 Positive value	0x60b		Touch probe control	RT	UINT	0x0
		Digital inputs	0x60e		Positive torque limit	RT	UINT	0x0
		Digital inputs	0x60e		Megtive torque limit	RT	UINT	0x0
			0x60f	f Ox0	Target Velocity	RT	DINT	0x0
			Name					
			Index			Data type		
			Sub-ind	ex		Bit		
				(4)	OK		Cancel	

When a slave has multiple groups of PDOs, there may be mutual exclusion between these groups. For example, EC-TX508. Only one group can be selected at a time.



This mutual exclusion relationship is different from slave to slave. For example, FK1100-ECT-Copuler allows multiple groups to be checked.

Basic information	Add	Delete	Edit		Fold	~	
Status	Input/Output		Index	Subindex	Bit Length	Flags	SM
	🕂 + 🗹 Output	1616DP RxPDO-Map	0x1602	0x0	16	Editable	2
	+ 🗹 Input	1600DI TxPDO-Hap	0x1a00	0x0	32	Editable	3
General setting	+ 🗹 Input	3200DI TxPDO-Map	0x1a01	0x0	48	Editable	3
	+ 🗹 Input	1616DP TxPDO-Hap	0x1a02	0x0	32	Editable	3
Process data							

9.3.3 Startup Parameters

The startup parameters are to write PDO configuration information of the slave, manufacturer setting parameters and parameters specified by some protocols (such as 402 protocol) to the slave by writing SDO when the slave is in PreOP state.

Take DA200 as an example:

	Serial	Name	Index	Subinder	Bit Length		Value
tatus	1	Clear PDO 1C12	0x1C12	0x0	8		0x0
	2	Clear PDO 1C13	0x1C13	0x0	8		0x0
eneral setting	3	Download 1C12:1 index	0x1C12	0x1	16		0x1600
5	4	Download 1C12 count	0x1C12	0x0	8		0x1
	5	Download 1C13:1 index	0x1C13	0x1	16		0x1a00
rocess data	6	Download 1C13 count	0x1C13	0x0	8		0x1
	7	Clear PDO 0x1600	0x1600	0x0	8		0x0
tartup parameter	8	Download PDO 0x1600:1 entry	0x1600	0x1	32		0x60400010
andp parameter	9	Download PDO 0x1600:2 entry	0x1600	0x2	32		0x607a0020
	10	Download PDO 0x1600:3 entry	0x1600	0x3	32		0x60ff0020
O mapping	11	Download PDO 0x1600:4 entry	0x1600	0x4	32		0x60600008
	12	Download PDO 0x1600:5 entry	0x1600	0x5	32		0x60710010
	13	Download PDO 0x1600:6 entry	0x1600	0x6	32	(1)	0x60b80010
	14	Download PDO 0x1600:7 entry	0x1600	0x7	32	•	0x60e00010
	15	Download PDO 0x1600:8 entry	0x1600	0x8	32		0x60e10010
	16	Download PDO 0x1600:9 entry	0x1600	0x9	32		0x607£0020
	17	Download PDO 0x1600 count	0x1600	0x0	8		0x9
	18	Clear PDO 0x1A00	0x1A00	0x0	8		0x0
	19	Download PDO 0x1a00:1 entry	0x1A00	0x1	32		0x60410010
	20	Download PDO 0x1a00:2 entry	0x1A00	0x2	32		0x60640020
	21	Download PDO 0x1a00:3 entry	0x1A00	0x3	32		0x606c0020
	22	Download PDO 0x1a00:4 entry	0x1A00	0x4	32		0x60770010
	23	Download PDO 0x1a00:5 entry	0x1A00	0x5	32		0x60610008
	24	Download PDO 0x1a00:6 entry	0x1A00	0x6	32		0x60780010
	25	Download PDO 0x1a00:7 entry	0x1A00	0x7	32		0x60b90010
	26	Download PDO 0x1a00:8 entry	0x1A00	0x8	32		0x60ba0020
	27	Download PDO 0x1a00:9 entry	0x1A00	0x9	32		0x60£d0020
	28	Download PDO 0x1A00 count	0x1A00	0x0	8		0x9
	29	Roming method	0x6098	UxU	8	(2)	0x21
	30	[PU.Ub] log speed	0x2005	UxU	16	(3)	Ux10

No.	Description
1	PDO configuration parameters
2	402 protocol parameters
3	Manufacturer parameters

In this interface, users can add startup parameters according to their needs, such as adding the object dictionary 0x6099: 0x01 and modifying the value to 100. The steps are as follows:

- Step 1 Click "Add".
- Step 2 Select 6099.
- Step 3 Modify the value to 100.
- Step 4 Click "OK".

Basic information	1	Add		Edit		Delete	Hide system parameter	xadecimal display o	f current value
Status	s	erial 29	Name Homing met	Add/E	dit				
		30	[PO. 05].Tog		Indexes	Subindexes	Names	Access Types	Data Types
General setting					0x6083	0x0	Profile acceleration	BT	UDINT
-					0x6084	0x0	Profile deceleration	BT	UDINT
					0x6091	0x0	Gear ratio	BT	DT6091
rocess data					0x6091	0x1	Motor revolutions	RW	UDINT
					0x6091	0x2	Shaft revolutions	RW	UDINT
tartup parameter					0x6093	0x0	Position factor	BT	DT6093
					0x6093	0x1	Numerator	RW	UDINT
					0x6093	0x2	Feed constant	RW	UDINT
O mapping					0x6098	0x0	Homing method	BT	SINT
					0x6099	0x0	Homing speeds	BT	DT6099
				(2)	0x6099	0x1	Speed during search for switch		UDINT
					0x6099	0x2	Speed during search for zero	RW	UDINT
					0x609a	0x0	Noming acceleration	BT	UDINT
					0x60b0	0x0	Position offset	BT	DINT
					0x60b1	0x0	Velocity offset	BT	DINT
					0x60b2	0x0	Torque offset	BT	INT
					0x60b8	0x0	Touch probe control	RT	UINT
					0x60e0	0x0	Positive torque limit	RT	UINT
					0x60e1	0x0	Negtive torque limit	RT	UINT
					Ox60fe	0x0	Digital outputs	RT	DTGOFE
					0x60fe	0x1	Physical outputs	RW	UDINT
					Ox60fe	0x2	Bit mask	RW	UDINT
					0x60ff	0x0	Target Velocity	RT	DINT
						Speed during sea		ata type UDINT	
				1	Sub-index	Dx1	Bi	t 32	
					Value	0x64 3			
							OK (4)	Can	cel

9.3.4 I/O Function Mapping

Only by linking PDO data to PLC internal variables can EtherCAT slave blocks be controlled by operating variables. The I/O function mapping interface is as shown in the following figure.

	Variable	Name	Index	Subindex	Data Length
tatus	None	Control Word	0x6040	0x0	16
	None	Target Position	0x607a	0x0	32
eneral setting	None	Target Velocity	0x60ff	0x0	32
seneral setting	None	Mode of Operation	0x6060	0x0	8
	None	Target torque	0x6071	0x0	16
Process data	None	Touch probe control	0x60b8	0x0	16
	None	Positive torque limit	0x60e0	0x0	16
Startup parameter None	None	Negtive torque limit	0x60e1	0x0	16
	None	Max profile velocity	0x607£	0x0	32
	None	Status Word	0x6041	0x0	16
/O mapping	None	Position Actual Value	0x6064	0x0	32
	None	Speed Actual Value	0x606 c	0x0	32
	None	Torque Actual Value	0x6077	0x0	16
	None	Operation Mode Display	0x6061	0x0	8
	None	Current Actual Value	0x6078	0x0	16
	None	Touch Probe Status	0x60b9	0x0	16
	None	Touch Probe 1 Positive value	Ox60ba	0x0	32
	None	Digital inputs	0x60fd	0x0	32

🖍 Note:

- This automatically generated set of variables will change with the module location and the addition and deletion of PDOs.
- If a slave is associated by default with a motion control axis, such as DA200, these variables can only be controlled by axis instructions.

9.3.4.1 Associated Variables

To modify the associated variables, follow these steps (take the FK1100_ECT_Coupler slave as an example).

Step 1 Open the Variable Table and add new variables.

Basic information	Double click fo	r IO configuration Note:	: When the ty	pe of the IO n	napped variable does not match the bit length, the lower computer will filter it
	Variable	Name	Index	Subindex	Data Length
Status	DP1_OUTO	FL5005-1616DP_1 OUTO	0x700d	0x1	8
	DP1_OUT1	FL5005-1616DP_1 0UT1	0x700d	0x9	8
General setting	DP1_ERRID	FL5005-1616DP_1 ErrId	0x600d	0x1	16
General setting	DP1_INO	FL5005-1616DP_1 IN0	0x600d	0x2	8
	DP1_IN1	FL5005-1616DP_1 IN1	0x600d	Oxa	8
Process data					
Startup parameter					
Slot configuration					
I/O mapping					

Step 2 Associate variables in the I/O function mapping interface.

- 1) Open the slave device.
- 2) Select I/O mapping option.
- 3) Select the global variable table.
- 4) Select the specified variable.
- 5) Click "OK".

TS600 Series Programmable Logic Controller Programming and Application Manual

EtherCAT Communication

	Basic information	Double click for IO c	configuration No	te: When the type of the IO m	napped variable does not ma	stch the bit length, the lo	ower computer will filte	er it
▼ { } Program block		Variable	Name			Index	Subindex	
feel course	Status		FL5005-161	SDP 1 OUTO		0x700d	0x1	
MAIN		None	FL5005-161			0x700d	0x9	_
{5} SBR_1	General setting	None		6DP 1 ErrId		0x600d	0x1	-
(3) 30121	General setting	None	FL5005-1616	SDP_1 INO		0x600d	0x2	
{ } INT_1		None	FL5005-161	SDP_1 IN1		0x600d	Oza	
User C language	Process data	Dialog						×
Library	Startup parameter	DP1_OUT0				OK	Cancel]
System variable table	Slot configuration	- System varia		Element Name	Data Type	Comments		-
🗣 📳 Global variable table		SYS_C/		DP1_OUTO	WORD			
	I/O mapping (2)			2 DP1_0UT1	WORD			
Struct		SYS_EC		3 DP1_ERRID	WORD			
(iii) Software element list		SYS_ET		4 DP1_IN0 5 DP1_IN1	WORD			
Ŭ		SYS_IN		5 DIT_INI	WOLD			
C language global variable table		- Electronic ca						
Global variable table 1		- Global variab	ble table					
✓ € Setting			ariable table 1 global variable					
System Block		Elem	3)					
EXP-CARD		-Y(0-102	3)					
Expansion module configuration		- S(0-409	5)					
Electronic cam		D(0-327 R(0-327	(67)					
Motion control axes)					
Axis group setting		Z(0-15)						
EtherCAT								
INVT_DA200_262								
FK1100_ECT_Coupler								
GuoMai_ESC	~ <	<	> <				>	1

Step 3 After the association is completed, the interface is as shown in the following figure.

	Variable	Name	Index	Subindex	Data Length
Status	DP1_OUTO	FL5005-1616DP_1 OUTO	0x 700 d	0x1	8
	DP1_OUT1	FL5005-1616DP_1 OUT1	0x700 d	0x9	8
General setting	DP1_ERRID	FL5005-1616DP_1 ErrId	0x600d	0x1	16
John John John John J	DP1_INO	FL5005-1616DP_1 IN0	0x600d	0x2	8
	DP1_IN1	FL5005-1616DP_1 IN1	0x600d	Oxa	8
Process data					
Startup parameter					
Slot configuration					
I/O mapping					

9.3.4.2 Associated Elements

Method 1: Directly enter the element in the "Variables" area.

FL4003-4DA_2 A00_ErrId	D100	0x6099	0x1	16	
FL4003-4DA_2 A01_ErrId	D101	0x6099	0x2	16	
FL4003-4DA_2 A02_ErrId	D102	0x6099	0x3	16	
FL4003-4DA_2 A03_ErrId	None	0x6099	0x4	16	
RI4003-4D& 3 400 Reeld	N	0~6119	0~1	16	

Method 2: Add elements in batches by left-clicking on the components that need to be mapped to pop up the interface (only supports data that are of the same length and adjacent).

TS600 Series Programmable Logic Controller Programming and Application Manual

EtherCAT Communication

				bit length, the l	ower computer will fi	ilter it
Var Name	D10	Search OK		Index	Subindex	Data Length
	11			0x7099	0x1	16
System variable table	Element Name	Data Type Comments	<u>^</u>	0x7099	0x2	16
SYS_CAN	1 D0	WORD INT DWORD DINT RE		0x7099	0x3	16
SYS_COM	2 D1	WORD INT DWORD DINT RE		0x7099	0x4	16
SYS_ECAT	3 D2	WORD INT DWORD DINT RE		0x6015	0x1	16
SYS_ETHERNET	4 D3	WORD INT DWORD DINT RE		0x6015	0x2	16
SYS_INFO	5 D4	WORD INT DWORD DINT RE		0x6015	0x3	16
Electronic cam	6 D5	WORD INT DWORD DINT RE		0x6015	0x4	16
Motion control axis	7 D6	WORD INT DWORD DINT RE		0x6015	0x5	16
Global variable table	8 D7	WORD INT DWORD DINT RE		0x6015	0x6	
- Global variable table 1	9 D8	WORD INT DWORD DINT RE		0x6015	0x0	
- FB instance variable	10 D9	WORD INT DWORD DINT RE		0x6015	0x8	16
C language global variable tal	11 D10	WORD INT DWORD DINT RE		0x6099	0x0	
Elem	12 D11	WORD INT DWORD DINT RE		0x6099	0x1 0x2	
-X(0-1777)	13 D12	WORD INT DWORD DINT RE		0x6099	0x2 0x3	
	14 D13	WORD INT DWORD DINT RE		0x6099	0x3 0x4	
-Y(0-1777)	15 D14	WORD INT DWORD DINT RE		0x6129	0x4 0x1	32
M(0-32767)	16 D15	WORD INT DWORD DINT RE		0x6129	0x1 0x2	32
- S(0-4095)	17 D16	WORD INT DWORD DINT RE		0x6129	0x2	32
D(0-32767)	18 D17	WORD INT DWORD DINT RE		0x6129	0x3	32
- R(0-32767)	19 D18	WORD INT DWORD DINT RE		0x6129 0x6129	0x4 0x5	16
C(0-255)	20 D19	WORD INT DWORD DINT RE				
T(0-399)	21 D20	WORD INT DWORD DINT RE		0x6129	0x6	16
Z(0-15)	22 D21	WORD INT DWORD DINT RE		0x6129	0x7	16
	23 D22	WORD INT DWORD DINT RE		0x6129	0x8	16
	24 D23	WORD INT DWORD DINT RE				
	25 D24	WORD INT DWORD DINT RE				
	26 D25	WORD INT DWORD DINT RE				
	27 D26	WORD INT DWORD DINT RE				
	28 D27	WORD INT DWORD DINT RE				
	29 D28	WORD INT DWORD DINT RE				
>	30 D29	WORD INT DWORD DINT RE	~			

Method 3: Directly double-click on the variable area, and add on the small interface.

9.3.4.3 Mapping Rule

There are only six basic data types of element variables: BOOL, INT, DINT, WORD, DWORD and REAL, while there are many data types of PDO variables in EtherCAT slave. Therefore, the mapping rules in the I/O mapping interface are as follows:


EtherCAT Slave Type	Bit Length	Mapping rule
BOOL	1	BOOL
BYTE	8	 INT: The lower eight digits are valid and the higher eight digits are reserved BOOL [8]: 8-bit BOOL array
SINT	8	 INT: The lower eight digits are valid and the higher eight digits are reserved BOOL [8]: 8-bit BOOL array
USINT	8	 INT: The lower eight digits are valid and the higher eight digits are reserved BOOL [8]: 8-bit BOOL array
BITARR8	8	 INT: The lower eight digits are valid and the higher eight digits are reserved BOOL [8]: 8-bit BOOL array
BIT8	8	 INT: The lower eight digits are valid and the higher eight digits are reserved BOOL [8]: 8-bit BOOL array
INT	16	• INTBOOL [16]: 16-bit BOOL array
UINT	16	• INTBOOL [16]: 16-bit BOOL array
WORD	16	 INT: The lower eight digits are valid and the higher eight digits are reserved BOOL [16]: 16-bit BOOL array
BITARR16	16	 INT: The lower eight digits are valid and the higher eight digits are reserved BOOL [16]: 16-bit BOOL array
DINT	32	• DINTBOOL [32]: 32-bit BOOL array
UDINT	32	• DINTBOOL [32]: 32-bit BOOL array

EtherCAT Slave Type	Bit Length	Mapping rule
DWORD	32	• DINT
DWORD	32	• BOOL [32]: 32-bit BOOL array
	22	• DINT
BITARR32	32	• BOOL [32]: 32-bit BOOL array
REAL	32	• REAL

9.3.5 Start-stop/Disable/Enable

When there are more slaves in the configuration than the actually connected devices, matching can be achieved by disabling the slaves that do not exist in the configuration.

How to disable (or enable): Select the target slave, click the right mouse button, and select Disable (Enable) function.



9.3.6 Disable Slave by Instruction

- Related system variables
 - \diamond EtherCAT slave system variable that sets whether the specified slave is enabled


System variables	Data type	Function description
		Disable Enable
DisableEnable	BOOL	OFF: Disable invalid
		ON: Disable Enable
		Configuration state
DisableCtate		0: Reserved
DisableState	INT	1: Enable
		2: Disable

• EtherCAT master system variable for disabling the entire EtherCAT fieldbus


System variables	Data type	Function description
		Disable Master Enable
DisableMaster	BOOL	OFF: Disable invalid
		ON: Disable Enable
DisableState		Master disability state
	INT	0: Reserved
		1: Enable
		2: Disable

- The method is as follows:
 - When PLC is powered on and started, it initializes the DisableEnable variable according to the configuration configured in the background, then updates the configuration list according to the DisableEnable variable disable enable state of the slave, starts the master, and writes the actual disable state of the slave into the variable DisableState.


- ♦ Wait for PLC parsing program configuration.
- ♦ Reset the value of DisableEnable variable through PLC program.
- ♦ Restart the EtherCAT master through ECAT_RestartMaster_CoE instruction after setup.
- When the master is restarted, update the configuration list with the DisableEnable variable, and write the disable enable state of the slave to DisableState.
- Example
- 1. Set up the configuration by upper computer software, start EtherCAT communication, and configure one FK1100 slave and four DA200 slaves.



2. After setting the slave system variable DisableEnable to disable the two slaves of DA200, restart the master by instruction ECAT_RestartMaster_CoE.



3. Download the project to PLC, and the two DA200 slaves are disabled after starting.



Note: The ECAT_RestartMaster_Coe instruction is a rising edge instruction.To take effect, the state of the EtherCAT slave system variables must be changed before the first cycle when this instruction is enabled. If

you modify whether to enable the system register of the slave after the instruction is enabled, the instruction must be disconnected and retriggered.

9.3.7 System Variables

The system variables associated with the EtherCAT slaves are shown in the following table:

System variables	Data type	Function description
		Disable Enable
DisableEnable	BOOL	OFF: Disable invalid
		ON: Disable Enable
		Configuration state
DisableState	INT	0: Reserved
Disablestate		1: Enable
		2: Disable
bSlaveRunState	BOOL	Operation status of slave
DSIdVertunState	BOOL	TRUE when slave is in OP mode, FALSE otherwise
		Set node alias status (background specific)
SetAliasState	BOOL	TRUE: Set busy
		FALSE: Idle or the setting is completed
		Failed to set node alias (background specific)
SetAliasError	BOOL	TRUE: Failed to set node alias
		FALSE: No fault
		Set the node alias (background specific)
SetAlias	BOOL	On the rising edge of the variable, write the value of
		wTarAlias to the slave
		State of slave EtherCAT state machine
		1: INIT
ALState	INT	2: PreOP
		4: SafeOP
		8: OP
AlCode	INT	Slave state machine transition fault code, see the
Alcode		manual of each slave for details
		The actual alias of the slave, which is initialized once
ActAlias	INT	when powered on, and its modification will not take
		effect
TarAlias	INT	Node alias to write (background specific)
		Sequential address of slave, which is initialized once
StationAddress	INT	when powered on, and its modification does not take
		effect

9.4 Fault and Diagnosis

9.4.1 Fault Acquisition

EtherCAT instruction failure can obtain fault codes through ErrorID of the instruction.

The fault of EtherCAT fieldbus can be obtained through the system variable _sCurErrLst.

_sCurErrLst				OK Cancel
		Element Name	Data Type	Comments
SYS_CAN	19	WDT	DINT	Watchdog Reset Time (ms)
SYS_COM	20	Reset	BOOL	Reset Cycle Time
SYS_ECAT	21	_sCurErrLst	_stru_CUR_ERR_LST	Error information list, su
SYS ETHERNET	22	Quantity	DINT	Number of Current Errors
SYS INFO	23	🖃 sErrInfo	_stru_ERR_INF0[42]	List of Current Error Mess
	24	🖃 sErrInfo[0]	_stru_ERR_INFO	List of Current Error Mess
Motion control axes	25	SubErrorCode	INT	Sub-Error Code
- Global variable table	26	MainErrorCode	INT	Master Error Code
	27	TimStamp	DINT	Timestamp
Global variable table 1	28	sErrInfo[1]	_stru_ERR_INFO	List of Current Error Mess:
- C language global variable	29	SubErrorCode	INT	Sub-Error Code
Elem [30	MainErrorCode	INT	Master Error Code
X(0-1023)	31	TimStamp	DINT	Timestamp
···· Y(0-1023)	32	🖃 sErrInfo[2]	_stru_ERR_INFO	List of Current Error Mess
M(0-32767)	33	SubErrorCode	INT	Sub-Error Code
S(0-4095)	34	MainErrorCode	INT	Master Error Code
D(0-32767)	35	TimStamp	DINT	Timestamp
	36	= sErrInfo[3]	_stru_ERR_INFO	List of Current Error Mess
	37	SubErrorCode	INT	Sub-Error Code
T(0-399)	38	MainErrorCode	INT	Master Error Code
Z(0-15)	39	TimStamp	DINT	Timestamp
	40	= sErrInfo[4]	_stru_ERR_INFO	List of Current Error Mess
	41	SubErrorCode	INT	Sub-Error Code
	42	MainErrorCode	INT	Master Error Code
	43	TimStamp	DINT	Timestamp
	44	sErrInfo[5]	stru_ERR_INFO	List of Current Error Mess
	45	SubErrorCode	INT	Sub-Error Code

9.4.2 Fault Code

For details about fault code list, see the relevant contents of main error code 0x0090 in section 19.3.2 Fault Code List.


When the EtherCAT fieldbus fails, the main module's Err indicator flashes, and check the system variable _sCurErrLst.

• 🗙 🖪	± ∓ ℓ 🗄 🗄 🗄					
	Element Na	me Data Type	Display For	Current Value	New Value	
1	📮 _sCurErrLst	_stru_CUR_	Decimal			
2	_sCurErrLst. Qu	ant DINT	Decimal	1		
3		rI_stru_ERR_	Decimal			
4	😑 _sCurErrLst.	sEr _stru_ERR_	Decimal			
5	_sCurErrLs	t.s INT	Decimal	17		
6	_sCurErrLs	t.sINT	Decimal	144		
7	sCurErrLs	t. : DINT	Decimal	1708446389		
8	😑 _sCurErrLst.	sEr _stru_ERR_	Decimal			
9	sCurErrLs	t.sINT	Decimal	0		
10	sCurErrLs	t.sINT	Decimal	0		
11	_sCurErrLs	t. : DINT	Decimal	0		
12	sCurErrLst.	sEr _stru_ERR_	Decimal			
13	_sCurErrLs	t.s INT	Decimal	0		
14	_sCurErrLs	t.sINT	Decimal	0		
15	_sCurErrLs		Decimal	0		
16	sCurErrLst.					
17	_sCurErrLs		Decimal	0		
18	_sCurErrLs		Decimal	0		
19	_sCurErrLs		Decimal	0		
20	sCurErrLst.					_
21	_sCurErrLs	t.s INT	Decimal	0		
22	sCurErrLs	t. s INT	Decimal	0		

10 EtherNet/IP Communication

10.1 Overview

The end opening the connection is the EtherNet/IP master, and the other end is the EtherNet/IP slave, as shown in the following figure.



A small PLC with background Auto Station pro1.1.2 or above, firmware version 1.28 or above supports EtherNet/IP slave function, and its specifications are as follows:

- 1. TS635 small PLC supports one-way EtherNet/IP slave function, with fixed physical interface network port 2.
- 2. Minimum cyclic communication period (RPI) 5ms.
- 3. The maximum data volume of TS365 single connection communication is 500 bytes.
- 4. It supports creating up to 32 slave connections.
- 5. Please refer to the official standard documents of EIP-CIP-V1-1.0 and EIP-CIP-V2-1.0 for the details of protocol.


10.2 Class1 Communication

10.2.1 Slave Configuration

Step 1 Click to set Ethernet 2 and modify the network configuration.

▼ 🖵 y1234(TS635)	System Block Ethernet2 - Dialog	×	1
▼ { } Program block			
MAIN			
{ S } SBR_1			
{ I } INT_1	Master configuration Slave configuration		
{ I } INT_2			
User C language	ModbusTCP master		
Eibrary	Enable control element X0		
System variable table	Timeout 500		
Global variable table	Slave port number: 502		
▼ K Setting	PLC Ethemet setting		
System Block			
EXP-CARD	IP address: 192 168 2 10 Read Reset IP		
Expansion module configurat	Subnet Mask: 255 . 255 . 0 Write		
Electronic cam	Gateway Address: 192 . 168 . 2 . 1 Identification device		
Dotion control axes			
♦ ⊒ Axis group setting			
EtherCAT	SOCKET		
COM1	TcpClient TcpServer UdpPeer		
COM2			
Ethernet1			
Ethernet2			
EtherNet/IP		_	
Cross-reference table	OK Cancel Help	•	

Step 2 Configure connection parameters, click "Setting" > "Ethernet/IP" option, choose "Ethernet/IP Adapter" configuration option to enter the configuration interface, and select to add connections as needed, and up to 16 Connection can be added, 16 inputs and 16 outputs, totaling 32 connections.



• Connection parameter list definition

Parameter	Definition	
Connection name	The name of the connection established	
O-> T Instance ID	Actual ID from origin to target, input (slave)	
T-> O Instance ID	Actual ID from target to origin, output (slave)	
	Maximum number of bytes transferred from	
O-> T size (byte)	origin to target (maximum 500 bytes)	
	Maximum number of bytes transferred from	
T > O size (byte)	target to origin (maximum 500 bytes)	

• Slave input data set (O-> T) parameter definition table

Parameter	Definition		
Connection name	Dataset name		
Data type	Type of data transmission		
Pit Longth	Total number of bits of data transferred		
Bit Length	(bytes*8)		

• Slave input data set (T-> 0) parameter definition table

Parameter	Definition
Connection name	Dataset name
Data type	Type of data transmission
Bit Length	Total number of bits of data transferred (bytes*8)

Step 3 Configure IO mapping of dataset, click "Setting" > "Ethernet/IP" option, choose IO mapping configuration option, enter IO configuration interface, select data set to be configured under the corresponding connection, double-click the dataset, select the corresponding element (now D element and custom parameters of global variable table are supported), double-click to select the element, and after the element option is displayed at the upper left, click "OK" to complete IO mapping of dataset.


Project manager 🛛 👻 🖣 🗙	📑 MAIN 📑 EtherNet	/IP			
y1234(TS635)	Producer labels	Double-click the input/output lines to set cus	tom variables Note: All IO ma	appings need to be configu	red when compiling and distributing!
▼ { } Program block		Variable	Channel	Type	Current Value
MAIN	Information	Inputs/Outputs Connection 1			
. ,			 Conn1 Input Size0 Conn1 Output Size0 	INT (50) INT (50)	
{S} SBR_1	Status	Connectioni Outputo	 Conni Output Sizeo 	181(50)	
{I} INT_1					
{ 1 } INT_2	EtherNet/IP Adapter	Dialog			×
🔀 User C language	I/O mapping	DO			7 OK Cancel
Eibrary	3		Element Name	Data Trees	Conments
▶ 📳 System variable table		System variable table	1 D0 6	Data Type WORD [INT]DWO WORD [INT]DWO	ED DINT R
Global variable table		SYS_COM SYS_ECAT	3 D2	WORD INT DWO	RD DINT
1 V Setting		SYS_ETHERNET SYS_INFO	4 D3 5 D4	WORD INT DWO WORD INT DWO	RD DINT R
System Block		Electronic cam	6 D5 7 D6	WORD INT DWO WORD INT DWO	RD DINT R
EXP-CARD		- Global variable table	8 D7 9 D8	WORD INT DWO WORD INT DWO	
Expansion module configurat		Global variable table	10 10	WORD INT DWO	
Electronic cam		Elem	ble 11 D10 12 D11	WORD INT DWO WORD INT DWO	
A		X(0-1023)	13 D12	WORD INT DWO	
Motion control axes			14 D13	WORD INT DWO	
Axis group setting		M(0-32767)	15 D14	WORD INT DWO	
		S(0-4095)	16 D15 17 D16	WORD INT DWO WORD INT DWO	
EtherCAT		- R(0-32767)	18 D17	WORD INT DWO	
		C(0-255)	19 D18	WORD INT DWO	
COM1			20 D19	WORD INT DWO	
COM2		Z(0-15)	21 D20	WORD INT DWO	
COME		-()	22 D21	WORD INT DWO	
Ethernet1			23 D22	WORD INT DWO	
			24 023	WORD INT DWO	
Ethernet2			25 D24 26 D25	WORD INT DWO WORD INT DWO	
2 EtherNet/IP			26 J25 27 J26	WORD INT DWO	
Z EtherNet/IP			28 D27	YORD INT DWO	
Cross-reference table		<	> <		>
Element monitor table		L			

10.2.2 Use Example of Slave

10.2.2.1 Use of Connection

Realization function: The master uses KV-8000, and the slave uses TS635, to complete O > T transmission of 100 bytes and T > O transmission of 100 bytes.

- Operating steps of the master:
- Step 1 Change the master address to 192.168.2.4, then click the cell editor in the tool and choose "EtherNet/IP setting".



Step 2 Select the eds file in "EtherNet/IP setting", select "Login", and open the TS600.eds file.

	📰 Heit Editor - Edit mode				
	LtherNet/IP settings				– 🗆 X
	File(F) Edit(E) Settings(S) View(V) Convert(C) EDS file(D)	Communication(N) Tool(T) Help(H)			
L	📲 🕦 🕿 🕹 🖻 🔚 🖬 🌮 🚳 🕮 🖉 🖢 🖬	0			
h	WI-0000101 + 100 100 0 4			EtherNet/IP unit	a
				Unit list(1) Unit setting(2)	Search unit(<u>3</u>)
-			×	📑 📑 💷 🖓 🖼	
	宣扶范围(エ	: 📃 桌面 🗸 🗸	G 🏂 📂 🖽 -	Unit name	Rev. EDS fil ^
		· · · · · · · · · · · · · · · · · · ·		E Keyence Corporat	
2		现场EIP错误	^	RV-5500	1.1 KV-5500
	快速访问			wv-7500	1.1 KV-7500
	002015	n 🔚		KV-8000 Series	1.1 KV-8000
		学习笔记		KV-EP02	1.1 EtherNe
	東面	1 march 1		KV-N16ER	1.1 16-poin
				W-NIGEX	1.1 16-poin 1.1 16-poin
		SUGTE		W-NIGER	1.1 2+1ch a
2	库			RV-NSAM	1.1 2+1ch a 1.1 8-point
1		資料		KV-NSET*	1.1 8-point
	la de la companya de			KV-N8EX	1.1 8-point
	此电脑			WV-NSEXR	1.1 8+8 poi
-	2	最新国件		KV-N8EXT	1.1 8+8 poi v
	🔶 🛛 🚽			<	>
	网络	A= TS600v1.1.eds	2	· · · · · · · · · · · · · · · · · · ·	
		EDS 文件 119 KB			
Ŧ		下载 - 快捷方式			
		快捷方式			
		1.22 KB	~		
	Output	文件名(N); TS600v1.1.eds	~ 打开(0)		ņ
	R Item Ver	XITH WIT			
		文件类型(T): EDS file(*.eds; *.ez1)	→ 取消 3		

Step 3 In "EtherNet/IP setting", click on the device list, select TS600, and double-click it to generate a TS600 slave.

EtherNet/IP settings	×
File(F) Edit(E) Settings View(V) Convert(C) EDS file(D) Communication(N) Tool(T) Help(H)	
	EtherNet/IP unit #
KV-8000(0) : 192.168.2.4	Unit list(1) Unit setting(2) Search unit(3)
	Unit name Rev. EDS file
1: TS600 : 192.168.2.1 Connection1	• Keyence Corporation
	Cognex Corporation
	HMS Industrial N
	p Inovance
	TS600 1.1 TS600 EDS
	2
	< >
Output	4
Item Verification Verification	
II II	>
	Editor OK Cancel Apply
	contor Apply

Step 4 Configure the connect parameters W0-W31 as inputs and W32-W63 as outputs in "EtherNet/IP setting" with reference to Keyence instructions.

K EtherNet/IP settings					- 🗆 ×
File(F) Edit(E) Settings(S) View(V) Convert(C) EDS file(D) Commu	Connection settings - 1:TS	600	? ×		
40 1 1 1 X 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Connection list(L)		_		
	No. Connec	tion Application ty	vne	EtherNet/IP unit	
KV-8000[0] : 192.168.2.4	1 Connection1 (IN 101		100		La constante
					Search unit(<u>3</u>)
				Pe 👎 🖌	
1: TS600 : 192.168.2.1				Adapter settings	
Connection1	2			Node address	1
IN_101 (Edit) OUT_100 (Edit) W 00-031 W 032-063	Add(A) Delete(B	3		IP address	192.168.2.1
W 00-031 W 032-063				Node name	TS600
	Connection name(C)	Connection1	\sim	Product name Vendor name	TS600 shenzhen INVT electr.
	Time out(T)	RPI*16 ~ (IN:800.0ms / OUT:800.0n	ms)	Revision	snenznen invi electr
		Normal		Connection settings	<setting></setting>
	Refresh priority(F)	Normal		Transmission adap	<setting></setting>
		Setup parameter(P) Assign devi	vice(D)	Reserved adapter	No
	IN (input from adapter)			Cyclic(I/O) messa	Unit error
	Connection type	Point-to-point	~	Sensor application	
	Connection point	IN 101		Backup sensor set	
	Connection point	101		Sensor monitor	No
	Data size	50 Word		Compatibility check	
	Send trigger	Cyclic	~		
	RPI (communication cycle)	50.0 ms (5.0 to 10000.0ms)			
	Production inhibit time	ms			
	OUT (output to adapter)	·		Adapter settings	
	Connection type	Point-to-point	~		
Output	Connection point	OUT_100	~		
R Item Verification Ve	Data size	50 Word			
	RPI (communication cycle)	50.0 ms (5.0 to 10000.0ms)			
	ra r (communication cycle)		4		
		Keep consistent with IN			
		ОК	Cancel		
H + + H Message Verify Setup list		0.0			>

• Slave operating steps:

Step 1 Configure the Ethernet parameters of Network Port 2 with IP of 192.168.2.10.

▼ 🛄 y1234(TS635)	System Block Ethernet2 - Dialog	×	
▼ { } Program block			
{ M} MAIN			
{ S } SBR_1			
{I} INT_1	Master configuration Slave configuration		
{I} INT_2			
User C language	Modbus TCP master Modbus TCP slave Enable control element X0		
Eibrary	Enable control element X0		
▶ 🕃 System variable table			
Global variable table	Slave port number: 502		
✓ Q Setting	PLC Ethemet setting		
▶ 🔡 System Block			
EXP-CARD	IP address: 192 168 2 10 Read Reset IP		
Expansion module configurat	Subnet Mask: 255 . 255 . 0 Write		
Electronic cam	Gateway Address: 192 . 168 . 2 . 1 Identification device		
Motion control axes			
♦ ⊒ Axis group setting			
🖗 EtherCAT	SOCKET		
COM1	TcpClient TcpServer UdpPeer		
COM2			
Ethernet1			
Ethernet2			
EtherNet/IP		_	
Cross-reference table	OK Cancel Help		

Step 2 In "EtherNet/IP setting", configure connection1, 0 > T size to 100 bytes, and T > 0 size to 100 bytes. Input dataset data type as int type, input bits 800, with ID of 0 > T being automatically generated as 100, and ID of T > 0 being automatically generated as 101.

▼ 💻 y1234(TS635)	Producer labels	******	************************	nection******************		***************************************	
▼ { } Program block		Connection name	0->T InstanceID	T->0 InstanceID	0->T Size(byte)	T->0 Size(byte)	
MAIN	Information	Inputs/Outputs Connection 1	100	101	100	100	
<pre>{S} sbr_1</pre>	Status						
↓ INT_1	EtherNet/IP Adapter						
{I} INT_2	Landrady in Maapier						
User C language	I/O mapping	Add connection Dele	te connection Edi	it connection Expor	t EDS Double	-dick to bring up the edit dialog box	
🧮 Library							
▶ 📳 System variable table		***************************************	************Input data	a set(0->T)****************	******	**********	
Global variable table		N am e	Data Type	Bit Length	Help St	ring	
✓ <i>Ci Setting</i>		Conn1 Input Size0	INT	800			
System Block							
EXP-CARD							
Expansion module configurat							
Electronic cam					Selected cells	for adding	
Motion control axes		Add Delete	e Upwar	rd Downward	Selected cells	s for earling	
Axis group setting		***************************************	***********Output da	ta set(T->0)**************	*****	******	
EtherCAT		Name	Data Type	Bit Length	Help Str	ring	
COM1		Conn1 Output SizeO	INT	800			
COM2							
Ethernet1							
Ethernet2							
EtherNet/IP						6 hu	
Cross-reference table		Add Delete	e Upwar	rd Downward	Selected cells	for editing	

Step 3 Configure the IO dataset mapping in "EtherNet/IP setting", and configure D0-D49 as inputs and D50-D99 as outputs.

ect manager 🚽 🔻 🔻 🔻	🚡 MAIN 📑 EtherNet	:/IP				
y1234(TS635)	Producer labels	Double-dick the input/output lines to set custom	variables Note: All IO map	pings need to be configu	red when compiling and distributing!	
🖌 { } Program block		Variable	Channel	Туре	Current Value	
MAIN	Information	Inputs/Outputs Connection 1				
{S} SBR_1	Status	4 Connection1 Input0 1 Connection1 Output0 1		INT (50) INT (50)		
{I} INT_1						
. ,	EtherNet/IP Adapter	Dialog				>
{I} INT_2		1				
📘 User C language	I/O mapping	D0			7 OK	Cancel
🧮 Library	3					
▶ 📰 System variable table			Element Name	Data Type WORD [INT]DWO	Connents RD DINT R	^
Global variable table		SYS_COM	2 D1 3 D2	WORD INT DWO WORD INT DWO		
		SYS_ECAT SYS_ETHERNET	4 D3	WORD [INT]DWO	RD DINT R	
▼ 🚰 Setting		SYS_INFO	5 D4 6 D5	WORD INT DWO WORD INT DWO		
System Block		Electronic cam	7 06	WORD INT DWO		
EXP-CARD		Global variable table	8 D7 9 D8	WORD INT DWO		
Expansion module configura		Global variable table 1	10 09	WORD INT DWO WORD INT DWO		
		C language global variable	11 D10	WORD INT DWO		
🚮 Electronic cam			12 D11 13 D12	WORD INT DWO WORD INT DWO		
Motion control axes		Y(0-1023)	14 D13	WORD INT DWO		
97 1 1 1 1 1 1 1 1		M(0-32767)	15 D14	WORD INT DWO		
♦ ⊒ Axis group setting		S(0-4095)	16 D15	WORD INT DWO		
🖗 EtherCAT		5	17 D16 18 D17	WORD INT DWO WORD INT DWO		
			19 D18	WORD INT DWO		
COM1		T(0-399)	20 D19	WORD INT DWO		
COM2		Z(0-15)	21 D20	WORD INT DWO	RD DINT K	
COM2		2(0.10)	22 D21	WORD INT DWO		
Ethernet1			23 D22	WORD INT DWO		
_			24 D23	WORD INT DWO		
Ethernet2			25 D24 26 D25	WORD INT DWO WORD INT DWO		
2 EtherNet/IP			26 D25 27 D26	WORD INT DWO		
2 EtherNet/IP			28 027	WORD INT DWO		~
Cross-reference table		< >	< 201021			>
Element monitor table						

• Test steps:



			¥								Ether CAT			12635	
R	GND	Ś	¥	Eth	erCAT	Et	herNET2	1	EtherNET	1		÷¢		RUN	
	•			m				I F	111111	1	C	, ,	Side Side		RUN
	-	× 82	9									•		Vī	
	ð	À	ŮÌ	Ő	đÌ	Ő		ŐÌ	Õ	F	06	8 2 5	2	8	16000
			01- 6 6 A	0						L	17 66	5 * 3	12	10	
	Õ	è	Ő	Ő	O	O		Ő	Ô	F	06 16	05		00 🔲 🔲 10	0016DN
		B		5 B	48	O .	NB B			Ę	6		2 1	•	-

Step 2 Modify the value of W32-W63 of Keyence to change with the value of D0-D49 in TS635.

Step 3 $\,$ Modify the value of D50-D99 in TS635 to change with the value of W0-W31 of Keyence.

11 Motion Control

11.1 Brief Introduction of Motion Control Axis


11.1.1 Overview

11.1.1.1 Basic Composition and Control Logic

In a motion control system, the object of motion control is called axis. An axis is the bridge between driver and PLC instructions. The motion control axis is used to control the EtherCAT fieldbus driver conforming to 402 protocol, and can also control the local high-speed pulse output and high-speed pulse input.

In PLC, the basic structure and processing logic of axis are as follows:

Main main program, subroutine and interrupt subroutine are for users to write programs, but motion control instructions can only be called in a Main main program or subroutine rather in an interrupt subroutine.




11.1.1.2 Scheduling Mechanism of Motion Control Instruction

EtherCAT tasks are hidden tasks and are not open to users, so programming in EtherCAT tasks is not supported.

In Main main program, PLC scans all motion control instructions written in the program in turn, and stores the final results in the motion control parameter buffer according to the interrupt rules of the program. The motion control instruction is updated when EtherCAT task is executed. After the execution is completed, the execution result is put into the buffer, and the motion control instruction in the Main main program updates the instruction state according to the execution result.

For example, there are two MC_MoveAbsolute instructions in the program, the target position of the first instruction is 100, and that of the second instruction is 200. The two instructions are triggered at the same time. When scanning the program, PLC first scans the first absolute positioning instruction to obtain the target position 100, and then scans the second instruction. At this time, the target position is updated to 200. At the end of Main main task, the target position of 200 is finally written into the motion control buffer, which is executed according to the second absolute positioning parameter, and the first instruction is

interrupted. After the EtherCAT task obtains the target position of 200, it starts to execute the absolute positioning algorithm, and sets the completion flag after the positioning is completed. After the second absolute positioning instruction in Main main program obtains the completion flag, the Done signal is set to be active.



11.1.1.3 Axis Type

Axis type	Content
Fieldbus servo axis	 The axis controlled using EtherCAT slave servo driver. When the virtual axis mode is not enabled, this axis is assigned to the actual servo driver for use. The fieldbus servo axis supports several basic modes of control, such as jogging, speed and homing.
Local pulse axis	 Axis controlled by pulse driver using local high-speed IO control. It is allowed to set four local pulse axes, namely Y0/Y1, Y2/Y3, Y4/Y5 and Y6/Y7. Each pulse output channel can be set as pulse + direction, positive and negative pulse or quadrature encoded pulse. Each pulse output channel can be provided with two probe terminals at most. The local pulse axis supports several basic modes of control, such as point, speed and homing, but does not support torque mode.
Local encoder axis	See section 12 High-speed Counter.

In order to comprehensively describe the axis attributes, monitor the axis state and control the axis movement, the axis is divided into three parts:

Axis Structure	Function							
Axis configuration	Ised to configure various parameters of axis, such as gear ratio, home type,							
parameters	arameter limit, etc.							
Axis system	Ised to monitor the running status and abnormal information of the axis, such							
variable	as the current axis position, fault code, etc.							
Avia control	In the user program, the axis motion control is executed using the MC motion							
Axis control instruction	control governance							
	Axis control instructions are divided into management class (such as							

-											
Axis Structure				I	unc	tion					
	MC_Power),	motion	class	(such	as	MC_Jog)	and	state	class	(such	as
	MC ReadStat	us)									


11.1.1.4 Configuration Interface

In the project, the configuration interface of axis is as follows:

 Constraint of the setting System Block EXP-CARD Expansion module confine Electronic cam Motion control axes Axis group setting EtherCAT INVT_DA200_2612 	atio 3 Axis ID 0 Axis Type Bus servo axis				
No.	Description				
1	Motion control axis				
2	EtherCAT fieldbus driver				
3	List of axis configuration and monitoring options				
4	Axle number				
5	Associated physical driven devices				

11.1.2 PLCopen State Machine

Based on PLCopen state machine, the state and motion of the axis are managed, and different functions are completed in different state. The state transition diagram is as follows:



The detailed description is as follows.

State	Function description
Disabled	Not enabled state
ErrorStop	Fault stop state
Standstill	Enabled state
Homing	State of returning to home
Stopping	Stopped state
Discrete Motion	Discrete motion
Continuous Motion	Continuously move state
Synchronized Motion	Synchronously move state

State migration conditions:

Conversion	Conversion Condition					
1	When the fault detection logic of the axis detects a fault, it immediately					
1	switches to this state.					
2	2 When there is no fault with the axis and MC_Power.Enable is FALSE					
3	When MC_Reset is called to reset axis failure and MC_Power.Status is					
3	FASLE					
4	When MC_Reset is called to reset axis failure and MC_Power.Status is					
4	TRUE					
5	When MC_Power.Enable is TRUE and MC_Power.Status is TRUE					
C C	When MC_Stop(MC_ImmediateStop).Done is TRUE and					
6	MC_Stop(MC_ImmediateStop).Execute is FALSE					

11.1.3 Unit of Axis

Two units are used in the axis structure, namely Unit and pulse unit.

- Unit
 - The units of measurement such as millimeters, centimeters and angles used on the instruction side are called user units, which are usually expressed by Unit.
 - ♦ User coordinate system can be divided into linear coordinate system and rotating coordinate system according to different working conditions.
 - ♦ A linear coordinate system usually contains a zero point, and the target position increases to indicate forward motion, while the target position decreases to indicate reverse motion. Positive and negative soft limits can be set in the linear coordinate system.
 - A rotating coordinate system contains a zero point and a rotation period. In a rotation period, the target position increases to indicate clockwise movement and decreases to indicate counterclockwise movement.
- Pulse unit
 - ♦ The unit of measurement used on the driver side to measure the number of pulses, which is usually expressed as pulse.

11.1.4 Axis Configuration Parameters

In order to meet the needs of the motion control axis and the actual working conditions, the following axis configuration parameters are developed:

Classification	Content	Fieldbus servo axis	Local pulse axis
	Axle number	\checkmark	\checkmark
	Axis type	\checkmark	\checkmark
	Input device	×	×
Basic settings	Output device	\checkmark	\checkmark
	Automatic mapping	\checkmark	×
	Virtual axis mode	\checkmark	\checkmark
	PDO	\checkmark	×
	Number of instruction pulses for one	/	,
	revolution of motor/encoder	\checkmark	\checkmark
Unit conversion	In the background, the amount of		
	movement when the worktable	\checkmark	\checkmark
settings	rotates for one revolution		
	Numerator of gear ratio	\checkmark	\checkmark
	Denominator of gear ratio	\checkmark	\checkmark
	Encoder mode	\checkmark	×
	Linear/rotation mode settings	\checkmark	\checkmark
	Software limit	\checkmark	\checkmark
	Software error response	\checkmark	\checkmark
Mode/parameter	Axis speed setting	\checkmark	\checkmark
settings	Torque limit	\checkmark	×
	Probe setting	×	\checkmark
	Output settings	×	\checkmark
	Hardware limit logic	\checkmark	×
	Home signal	\checkmark	\checkmark
	Positive limit	\checkmark	\checkmark
	Negative limit	\checkmark	\checkmark
	Z Signal	\checkmark	×
	Homing direction	\checkmark	\checkmark
	Home input detection direction	\checkmark	\checkmark
	Homing list	\checkmark	\checkmark
Homing setting	Homing velocity	\checkmark	\checkmark
	Homing approach speed	\checkmark	\checkmark
	Homing acceleration	\checkmark	\checkmark
	Homing timeout	\checkmark	\checkmark
	Negative limit terminal setting	×	\checkmark
	Positive limit terminal setting	×	\checkmark
	Home signal settings	×	\checkmark
	Monitoring list	\checkmark	\checkmark
Online debugging	Motion debugging	\checkmark	\checkmark

11.1.5 Axis System Variable

Name	Data type	Function			
wAxisID	WORD	Axis ID			
iAxisType	INT	Axis type 0: Fieldbus servo axis 1: Fieldbus encoder axis 2: Local pulse axis			

Name	Data type	Function
		3: Local encoder axis
dwPulseData	DWORD	Number of pulses required for one revolution of the curren axis
fDistanceData	REAL	The worktable's moving distance when the current axi rotates for one revolution
diGearRatioNum	DINT	Numerator of gear ratio
dwGearRatioDen	DWORD	Denominator of gear ratio
iLineRotateMode	INT	Linear/rotation mode selection
bSWLimitEnable	BOOL	Axis soft limit switch
fRotation	REAL	Number of rotation cycles of rotating axis
fMaxPLimit	REAL	Maximum positive soft limit value of linear axis mode
fMaxNLimit	REAL	Maximum negative soft limit value of linear axis mode
fAxisErrorDec	REAL	Axis error deceleration
fMaxVelocity	REAL	Maximum axis velocity limit
fMaxAcceleration	REAL	Maximum axis acceleration limit
fMaxDeceleration	REAL	Maximum axis deceleration limit
fMaxJerk	REAL	Maximum axis jerk limit
fMaxJogSpeed	REAL	Maximum speed of axis in Jog mode
fMaxPTorque	REAL	Maximum positive torque (fieldbus servo axis)
fMaxNTorque	REAL	Maximum negative torque (fieldbus servo axis)
bHWPLimitEnable	BOOL	Hardware positive limit enable signal
iHWPLimitID	INT	Hardware positive limit terminal ID
bHWNLimitEnable	BOOL	Hardware negative limit enable signal
iHWNLimitID	INT	Hardware negative limit terminal ID
bTouchProbelD1	BOOL	Probe terminal 1 enable signal
iTouchProbeID1	INT	Probe terminal 1 ID
bTouchProbeID2	BOOL	Probe terminal 2 enable signal
iTouchProbeID2	INT	Probe terminal 2 ID
bServoError	BOOL	Servo alarm enable signal
iServoErrorID	INT	Servo alarm terminal ID
bServoEnable	BOOL	Servo enable signal
iServoEnableID	INT	Servo enable terminal ID
bClearError	BOOL	Clear servo alarm enable signal
iClearErrorID	INT	Clear servo alarm terminal ID
	INT	Pulse axis control mode
iPulseMode		0: Pulse + direction
in dischiode		1: Positive and negative pulse mode
		2: Quadrature encoded pulse mode
bVirtualMode	BOOL	Virtual axis mode
iHomeMode	INT	Homing mode selection
bHomeDirection	BOOL	Homing direction
fMaxHomeSpeed	REAL	Maximum axis homing speed limit
fMaxHomeAcc	REAL	Maximum axis homing acceleration limit
fDecModuleSpeed	REAL	Maximum speed on deceleration module when axis homes
fWaitZSpeed	REAL	Maximum speed while waiting for Z signal when axis homes
bHomeSignal	BOOL	Home enable signal
iHomeSignalID	INT	Home signal terminal ID
bZSignal	BOOL	Z signal enable signal

NameData typeFunctioniZSignalIDINTZ signal terminal IDbPowerStateBOOLAxis enable stateiPLCopenStateINTPLCOpen stateiAxisCfgStateINTAxis communication stateiAxisErrorINTAxis erroriServoErrorINTServo error	
bPowerStateBOOLAxis enable stateiPLCopenStateINTPLCOpen stateiAxisCfgStateINTAxis communication stateiAxisErrorINTAxis error	
iPLCopenStateINTPLCOpen stateiAxisCfgStateINTAxis communication stateiAxisErrorINTAxis error	
iAxisCfgState INT Axis communication state iAxisError INT Axis error	
iAxisError INT Axis error	
bMotionState BOOL Motion state	
bHardwarePLimit BOOL Hardware positive limit	
bHardwareNLimit BOOL Hardware negative limit	
bSoftwarePLimit BOOL Software positive limit	
bSoftwareNLimit BOOL Software negative limit	
bHomeState BOOL Home switch	
bMotionDirection BOOL Motion direction	
fSetPosition REAL Set position	
fActPosition REAL Actual position	
fSetVelocity REAL Set velocity	
fActVelocity REAL Actual velocity	
fSetTorque REAL Set torque	
fActTorque REAL Actual torque	
bPowerOn BOOL Enable	
bReset BOOL Reset	
bStop BOOL Stop	
blmmediateStop BOOL Immediate stop	
bSetPosition BOOL Set current position	
bHome BOOL Home	
bJogP BOOL Jog+	
bJogN BOOL Jog-	
bMoveAbs BOOL Absolute position	
bMoveRel BOOL Relative position	
bMoveVel BOOL Moving velocity	
bTorque BOOL Torque control	
bServoDebug BOOL Enter servo debugging mode	
Debug mode motion type	
0: Absolute motion	
iDebugMotionType INT 1: Relative motion	
2: Moving velocity	
3: Torque control	
fPreSetPosition REAL Pre-set position	
fPositionOffset REAL Home position offset	
fJogVelocity REAL Jog velocity	
fTargetPos1 REAL Target position	
fTargetVel1 REAL Target velocity	
fTargeAcc1 REAL Target acceleration	
fTargetDec1 REAL Target deceleration	
fTargetJerk1 REAL Target jerk	
fTargetTorque REAL Target torque	
fTargetTorqueSlop REAL Torque slop	
fLimitVelocity REAL Limit velocity	

TS600 Series Programmable Logic Controller Programming and Application Manual

Motion Control

Name	Data type	Function
fOffsetPosition	REAL	Position offset
dwPosOffsetForResiduals	DWORD	Position offset for residuals
dwTurn	DWORD	Encoder overflow times
iControlWord	INT	Control word (read-only, PDO data, 0*6040)
iStatusWord	INT	Status word (read-only, PDO data, 0*6041)
diSetPosition	DINT	Set position (read-only, PDO data, 0*607A)
diActPosition	DINT	Actual position (read-only, PDO data, 0*6064)
diSetVelocity	DINT	Set velocity (read-only, PDO data, 0*60FF)
diActVelocity	DINT	Actual velocity (read-only, PDO data, 0*606C)
diSetTorque	DINT	Set torque (read-only, PDO data, 0*6071)
diActTorque	DINT	Actual torque (read-only, PDO data, 0*6077)
diDo	DINT	Digital quantity output (read-only, PDO data, 0*60FE)
diDI	DINT	Digital quantity input (read-only, PDO data, 0*60FD)
iModeOfOperation	INT	Mode of operation (read-only, PDO data, 0*6060)
iTouchFunction	INT	Probe function setting (read-only, PDO data, 0*60B8)
diTouch1PPos	DINT	Probe 1 rising edge position (read-only, PDO data, 0*60BA)
diTouch2PPos	DINT	Probe 2 rising edge position (read-only, PDO data, 0*60BC)
diTouch1NPos	DINT	Probe 1 falling edge position (read-only, PDO data, 0*60BB)
diTouch2NPos	DINT	Probe 2 falling edge position (read-only, PDO data, 0*60BD)
iTouchStatus	INT	Probe status (read-only, PDO data, 0*60B9)

11.1.6 Axis Instruction List

Instruction	Name
MC_Power	Axis power-on instruction
MC_Reset	Axis reset instruction
MC_ReadStatus	Axis read status instruction
MC_ReadPosition	Read actual position instruction
MC_ReadVelocity	Read actual velocity instruction
MC_SetPosition	Set position instruction
MC_MoveRelative	Relative positioning instruction
MC_MoveAbsolute	Absolute positioning instruction
MC_MoveVelocity	Velocity instruction
MC_Jog	Continuous operation instruction
MC_Home	Home instruction
MC_SetOverride	Set override instruction
MC_Stop	Stop instruction
MC_Halt	Halt instruction
MC_ImmediateStop	Immediate stop instruction
MC_MoveSuperImposed	Motion Superimposed instruction
MC_TouchProbe	Probe instruction
MC_MoveFeed	Interrupt fixed-length instruction
MC_MoveBuffer	Multi-segment positioning instruction
MC_ReadAxisError	Read axis error instruction
MC_ReadDigitalInput	Read digital input instruction
MC_MoveVelocityCSV	CSV-based velocity instruction with adjustable pulse width
MC_SyncMoveVelocity	CSV-based synchronous velocity control instruction

Instruction Name		
	with adjustable pulse width	
MC_FollowPosition	Synchronous position instruction based on CSP	
	mode	
MC_SyncTorqueControl	Synchronous torque control instruction	
MC_ReadActualTorque	Read actual torque instruction	
MC_CamIn	Cam in	
MC_CamOut	Cam out	
MC_DigitalCamSwitch	Electronic cam tappet control	
MC_GearIn	Gear in	
MC_GearOut	Gear out	
MC_Phasing	Principal axis phasing	
MC_SaveCamTable	Save Cam Table	
MC_GenerateCamTable	Update Cam Table	
MC_FlyingShearIn	Flying shear in	
MC_FlyingShearOut	Flying shear out	
MC_TraceShearIn	Trace shear in	
MC_TraceShearOut	Trace shear out	
MC_MoveLiear	Linear interpolation instruction	
MC_MoveCircular2D	Planar arc interpolation instruction	
MC_GroupSetOverRide	Axis group speed regulation instruction	
MC_GroupStop	Axis group stop instruction	
MC_GroupHalt	Axis group halt instruction	
MC_GroupImmediateStop	Axis group immediate stop instruction	
MC_ReadGroupVelocity	Read axis group resultant velocity instruction	

11.2 Motion Control Axis Setting Steps

11.2.1 Create a New Project Document

This routine will create a new fieldbus servo axis and a local pulse axis, and realize simple axis control through instructions.

Step 1 Open Auto Station Pro > "New project", as shown in the following figure.

auto Station Pro V1.2.9	-	
File(F) View(V) PLC(P) Tool(T) Help(H)		
) 🕁 i
$\boxed{ \underbrace{\operatorname{New project}}_{Ctrl+N} \downarrow \downarrow }_{S} \underbrace{S}_{S} \underbrace{S}_{S} \rightarrow \downarrow \neg_{S} \underbrace{A}_{I} \\ + + + + + + + + + + + + + + + + + +$		- - { F }
Project manager • 4 ×	Instruction tree	Last Next
Messages output window		→ # ×
🔤 Compile 🔞 Communication 🕼 Conversion 🛛 Q. Find		
For help, press F1 Sconnect	Rewrit	

Step 2 Fill in "Name" and set the corresponding "Location". Select ladder diagram for the default editor, and the project description can be left blank.

New project			×
TS600 TS611 TS621 TS633 TS634 TS635	Project setting Name: Location: C:\Users\Administrator Default editor: Ladder Project description:	<pre>/Noouments/ </pre>	
		Network bus type operation control PLC	More
	Operational control capability:		<u>More</u> <u>More</u>
		8 x 200K high-speed input	<u>More</u> <u>More</u>
	Right module expansion:		<u>More</u> <u>More</u>
		2 independent network ports	<u>More</u> <u>Nore</u>
	Serial port communication: EtherCAT: axis synchronization cycleperiod:	1 channel, max 72 slaves	<u>More</u> <u>Nore</u>
		CANOper, Maximum 32 axis	<u>More</u> <u>More</u> More
	Program capacity:		<u>More</u> <u>More</u> More
	Command speed:	Simple command 20K steps 0.2ms	More
	C subroutines:	Support	<u>More</u>
●Create new project	OCreated with the project OK	Cancel	

Step 3 After the project is successfully created, click "Instruction tree".

Instruction tree instruction 🔁 Auto Station Pro V1.2.9 - [C:\Users\Administrator\Documents\test.tsp2] - [MAIN *] Ø File(F) Edit(E) View(V) Ladder(L) PLC(P) Debugging(D) Tool(T) Window(W) Help(H) 🖥 MAIN * 4 Þ 🗙 🖌 🛄 test(TS635) Find Last Next ▼ { } Program blc Contact Logic Instruction MAIN Output Control Instruction {S} SBR_1 Energy Flow Control Instruction {| INT_1 SFC Instruction User C m Flow Control I E Library nd Counting Instruction ▶ 📳 System var Transmission Instruction ▶ 🗄 Global varial nteger Arithmetic Instruction 🗸 🟠 Setting Motion control instruction of instruction tree 🛃 Auto Station Pro V1.2.9 - [C:\Users\Administrator\Documents\test.tsp2] - [MAIN] ٥ × File(F) Edit(E) View(V) Ladder(L) PLC(P) Debugging(D) Tool(T) Window(W) Help(H) {**F**} 4 Þ 🗙 × 📑 MAIN ▼ 🚍 test(TS635) Find Last ▼ { } Program blo String Processing Instruction MAIN {MAIN ▶ 🔗 Data Processing Instruction {S} SBR_1 Real-Time Clock Instruction {| INT_1 Control Calculation Instruction User C Verification Instruction 🗮 Library Axis control (pulse input) System varia control (EtherCA1& pulse out Global varial MC SetAxisConfigPara (Axis confi 🖌 🟠 Setting MC Power (Enable) 🕨 📓 System MC Reset (Reset) EXP-CAI ☐ MC_ReadStatus (Read axis status) Expansi MC ReadAxisError (Read axis err Electron MC ReadDigitalInput (Read DI stat Motic

Step 4 Edit in the main interface after the project is successfully created


	,	
auto Station Pro V1.2.9 - [C:\Users\Administrator\Documents\test.tsp2] - [MAIN]		– ø ×
		2 🖉 🔂 🔂 🙃 🔁
$\square \square \square + \downarrow \downarrow S_{2} S^{2} \frac{1}{25} \frac{9}{25} \rightarrow \downarrow \neg_{2} S^{2}$ File(F) Edit(E) View(Y) Ladder(L) PLC(P) Debugging(D) Tool(T) Window(W) Help(H)	- { 1 } + + + □ + + + + + + + + + + +	≁ ₀₽.
Project manager - P × Project manager - P ×	4 Þ × 1	nstruction tree 🔍 🕈 🗙
▼ 💭 test(TS635) 1		Find Last Next
▼ { } Program MC_Power		String Processing Instruction
{M} MAIN		Data Processing Instruction
2 {S} SBR_ Broot		Real-Time Clock Instruction
{I} INT_		Control Calculation Instruction
🔀 User		Verification Instruction
Eibrary		Axis control (pulse input)
▶ System vz	·	🛨 🥏 Axis control (EtherCAT& pulse output
▶ 📳 Global va		MC_SetAxisConfigPara (Axis configu
		MC_Power (Enable)
EXP-		MC_Reset (Reset)
Expa		MC_ReadStatus (Read axis status)
	>	< > >
riessages ouipui window Project (test) compile message		5
ELC main module[TS635] Start compiling 20064		5
NIIKA II'YYyanan FilasiAHTI STATIUNIAUta Statian ProiProisotPilasitastitastitastiYUNNMAIN III Iyan Y	2 column 11999 This register is not supported by the operand	
No.	Descriptio	on
1	Toolbar	
2	Project man	ager
3	Program editir	ng area
4	Instruction	tree
5	"Messages output	" window

11.2.2 Create Project Configuration


There are two ways to realize servo axis control, one is pulse control, the other is fieldbus control. The configuration methods of the two controls are explained below.

• For fieldbus control, add a filedbus axis


Step 1 Left-click to choose "Motion control axes" and right-click on "Add axis".



Step 2 Axis AXIS_0 is created successfully




Step 3 To create an EtherCAT slave, left-click to choose "EtherCAT" and right-click on "Add device".




Step 4 Left double-click to select "INVT_DA200_171 device".


Note: If there is no option of INVT-DA200_171, select to import the XML file of DA200.



Step 5 The DA200 servo driver slave is created, and the EtherCAT add device interface is closed



Step 6 Choose "AXIS_0" and the output device "INVT_DA200_171" to associate the axis AXIS_0 with the INVT_DA200_171 servo driver




• Pulse control

Step 1 Left-click to choose "Motion control axes" and right-click on "Add axis".




Step 2 Choose "Local pulse axis".

Auto Station Pro V1.2.9 - [C:\Users\Administrator\Doct	uments\test.tsp2] - [Axis_1 *]						
	< 1 0 €	륨 🖥 🔳 🖬 🖃 🗸 🛩 🕞 💿					
File(F) Edit(E) View(V) PLC(P) Tool(T) Window(W)	: File(F) Edit(E) View(V) PLC(P) Tool(T) Window(W) Help(H)						
Project manager 🔍 👻 🤻 🗶	MAIN 11 INVT_DA200_26	1 Axis_0 Axis_1 *					
▼ ξ ² ₂ Setting ^	Basic setting Basic	sic Setting					
System Block	Transmission ratio	Axis ID 1					
Expansion module configuration	Mode setting	Axis Type Local pulse axis Bus servo axis Input Device Local pulse axis Local pulse axis					
Electronic cam	Homing setting	Local encoder axis Output Device NULL					
x Axis_0	Online debugging	Virtual Axis Mode					
x Axis_1							
Step 3 Choose Y0/Y1 for output device.							
🧱 Auto Station Pro V1.2.9 - [C:\Users\Administrator\Docu	ments\test.tsp2] - [Axis_1 *]						
File(F) Edit(E) View(V) PLC(P) Tool(T) Window(W)	File(F) Edit(E) View(V) PLC(P) Tool(T) Window(W) Help(H)						
Project manager 🔷 👻 🗸 🗸	MAIN	51 Axis 0 Axis 1 *					




Step 4 The configuration of local pulse axis and fieldbus servo axis is completed.



11.2.3 Set Axis Parameters

11.2.3.1 Fieldbus servo axis

• Basic setting interface of fieldbus servo axis




• Fieldbus servo axis mode setting interface

Basic setting	Encoder Mode	Incremental Mode Absolute Mode
Transmission ratio	Mode Set	Linear Mode ORotation Mode
Mode setting	Software limit	
Homing setting	Software limit	Enable Positive Max Value: 1000.000 Unit Neostive Max Value: 0.000 Unit
Online debugging		Positive Max Value: 1000.000 Unit Negative Max Value: 0.000 Unit
	SoftwareErrorResponse	Servo Alarm Enable
		Axis Expire Dec: 10000.000 Unit Servo Alarm:
	Axis Speed Set	Max Speed: 1000.000 Unit/s Max Acc: 10000.000 Unit/s
		Maximum Jerk: 100000.000 Unit/s^3 Max Dec: 10000.000 Unit/s
		Jog Max Speed: 1000.000 Unit/s
	Torque Set	Max Positive Torque: 3000.000 N*m Max Negative Torque: 3000.000 N*m
Transmission ratio Mode setting Homing setting Online debugging	Positive limit:	Unassigned
		irection of the drive is negative and the position of the first Z- ected as the target zero position

Note: The drop-down box selection of home signal, Z signal, positive limit, negative limit and homing mode is temporarily invalid.

11.2.3.2 Local pulse axis

• Basic setting interface of local pulse axis




• Local pulse axis mode setting interface


🚡 MAIN 📴 INVT_DA20	0_261 🙀 Axis_0 🙀 Axis_	1					
Basic setting	Encoder Mode	Incremental N	1ode		O Absolute Mode	2	
Transmission ratio	Mode Set	Linear Mode			O Rotation Mode		
Mode setting	Software limit	Enable					
Homing setting		Positive Max Value:	1000.000	Unit	Negative Max Value:	0.000	Unit
Online debugging	SoftwareErrorResponse				Servo Alarm Er	nable	
		Axis Expire Dec:	10000.000	Unit	Servo Alarm:		1
	Axis Speed Set	Max Speed:	1000.000	Unit/s	Max Acc:	10000.000	Unit/s^2
		Maximum Jerk:	100000.000	Unit/s^3	Max Dec:	10000.000	Unit/s^2
		Jog Max Speed:	1000.000	Unit/s			
	Torque Set	Max Positive Torque:	3000.000	N*m Ma	x Negative Torque:	3000.000	N*m
			L			L	


• Local pulse axis homing mode setting


MAIN I INVT_DA200	0_261 🙀 Axis_0 * 🙀 Axis_1	4 Þ 🗙
Basic setting	BUS AXIS	
Transmission ratio		
Mode setting	Home signal: Unassigned V Z signal: Unassigned V	
line office	Positive limit: Unassigned V Negative limit: Unassigned V	
Homing setting	Home direction: Unassigned V Home mode: Homing mode03 V	
Online debugging	Home speed: 50.000 Unit/s Home approach speed: 20.000 Unit/s	
	Deceleration speed: 50.000 Unit/s Home acceleration: 50.000 Unit/s^2	
	The initial directional movement of the drive depends on the switching state of the reference point, the position of the first Z pulse to the left or right of the target zero position Index.	
	Index(home switch signal)	

11.2.4 Write a Program











Step 3 Call the MC_ReadVelocity function block



Step 4 Call the MC_ReadPosition function block



11.2.5 Download Project

After the program is compiled, please download it according to the following steps:

Step 1	Download	
		✓ ✓ ✓ ► ● ↓ ① ♀ Download (F8)
Step 2	Recompile	
	·	Auto Station Pro \times
		Whether you need to recompile before downloading (if not, then all the last compiled files will be downloaded))
		是(Y) 否(N)

Avie ID U	
Download	×
Download option Application program System block User data block	Download
Whether uploading is allowed	
● Yes ○ No	
-Clear power-down retained data O Yes () No	

Step 3 Download

The information output window shows that the execution is correct.

		— Communication	message —
W2001	Download Communication co	ommands are executed	correctly
W2001	RunCommunication command:	s are executed corre	otly

Step 4 Put PLC in RUN state

Auto Station Pro	×]
Confirm that you want to put the PLC in Run state?		
是(Y) 否(N)		

11.2.6 Basic Motion

11.2.6.1 Preparation


Click monitor to enter the RUN state, as shown in the following figure.



11.2.6.2 PLC Program Control

Step 1 Power-on control

Set M0 element to ON, observe whether the output Error of MC_Power function block of axis 0 and axis 1 is FALSE, if so, it means that the enable is successful; If it is TRUE, it means that the enable is not successful. Observe the corresponding ErrorID value and find the corresponding error.



Step 2 Double-click to select Axis 0, and click online debugging to observe the enable status and communication status of the axis

As shown in the following figure, if the enable state is StandStill and the communication state is OP, it means that the communication works normally and the axis enable is successful.

		Theoretic	cal /	Actual	Enable state	: StandStil	
Transmission ratio	Position:	0.000	0.0	Testan (Communication statu	s: OP	
Mode setting	Speed:	0.000	0.0	00	Axis error code	No Error	
Homing setting	Torque:	0.000	0.0	00	Drive error code	No Error	
Online debugging	Mo	otio	Hardware	Hardware	Software	Software	Home
	OFF	(OFF	OFF	OFF	OFF	OFF
	Enable Debug	g Mode et position	0.000	Setting		Enable	
		et position		Setting Return Ho	me		
	Pres Home posi	et position	t 0.000		me	Enable Reset Stop	

Step 3 Relative position control


Call the MC_MoveRelative function block, set the parameters as follows, and set the M1 element to ON.

HF.


Motion Control

Auto Station Pro V1.2.9 - [C:\Users\Adminis	trator\[\Documents\1111\1111.tsp2] - [MAIN]					
🕨 🖲 🕁 🗘 🙎 🖉 (A	£ £ ♀ ∨ 		o +d+ −co -	■ {F}	- 1	
File(F) Edit(E) View(V) Ladder(L) PLC(P) Del	ebugging(D) Tool(T) Window(W) Help(H)					
	, } ²	$ \circ					
Project manager 🚽 🤻 🗧	× 🖬	MAIN Axis_0 Axis_1 INVT_DA200_261-1					
▼ 🚍 1111(TS635)	<u> </u>						
▼ { } Program block		•					
MAIN	NO	MO	Enable	MC_Power			
{S} SBR_1			Inable				
{ 1 } INT_1				St	stus —	ON	Power1
User C language							
Eibrary					Busy-	ON	Power2
▶ 🛞 System variable table				2	arror —	OFF	Power3
Global variable table		0 [Axis	Err	orID —	0	PowerID
▼ to Setting							
System Block	N1	MO	Enable	MC_Power			Write ×
EXP-CARD			snabie				Bit element
Expansion module configu				St	atus —	ON	Elenent Mi
Electronic cam							
▼ Motion control axes					Busy-	ON	ON OFF
x Axis_0				F	irror —	OFF	Word element
x Axis_1		1	Axis	Err	orID —	0	Eleneni ~
Axis group setting							Bata INT V Bisplay Decimal V
🗸 🖌 EtherCAT	162	HI	N Execute	C_MoveRelative			
V INVT_DA200_261			Acourt				Value Setting
V INVT_DA200_261-1			Axis		Done -		Close
COM1		100	Position		Busy-		
COM2							
Ethernet1		10	Velocity	Åc	tive		
Ethernet2	~	10	Accelerat	ion CommandAbo	orted -		
< >	<						

While the MC_MoveRelative function block is running:



After the MC_MoveRelative function block runs:



There are two ways to observe the actual running distance of Axis 0 and Axis 1: Mode 1: Through online debugging.

Mode 2: By reading the return value of the function block.


• Online debugging

Open online debugging, and the actual running distance of Axis 0 is as follows:

Basic setting							
Transmission ratio		Theore	tical	Actual	Enable sta	te: StandStil	I
Transmission ratio	Position:	100.000	99	.999	Communication stat	us: OP	
Mode setting	Speed:	0.000	0.0	000	Axis error cod	le: No Error	
Homing setting	Torque:	0.000	0.0	000	Drive error coo	le: No Error	
Online debugging	м	lotio	Hardware	Hardware	Software	Software	Home
	OFF		OFF	OFF	OFF	OFF	OFF

• Read the return value of function block

As shown in the following figure, the running distance between Axis 0 and Axis 1 is read to be 100



11.3 Motion Control Axis Configuration

11.3.1 Comparison of Fieldbus Servo Axis and Local Pulse Axis

The local pulse output and the EtherCAT driver are controlled with the same set of instructions, and the main differences between them are listed here.

Item	Local pulse output	EtherCAT fieldbus driver
Different types of axes	Local pulse axis is required.	Fieldbus servo axis is required.
Different output devices	Local I/O terminals need to be set up in groups of Y0/Y1, Y2/Y3, Y4/Y5, and Y6/Y7, with each group containing two terminals.	
Pulse output form	It supports three ways of output, namely "pulse + direction", "positive and negative pulse" and "quadrature encoded pulse".	
Probe function	Two probes are supported, and any two points in the body X0 – X17 can be selected as probe signal input in "Mode setting".	
Homing setting	In the homing setting interface, the signals needed for local pulse homing can be selected, such as home enable signal, Z signal, positive and negative hard limit signal, etc.	It supports 1-35 homing mode setting specified in 402 protocol, and limit and home signals need to

11.3.2 Basic Settings

• The basic setting interface is as shown in the following figure.

Axis_0 Axis_1				
Basic setting	Basic Setting			
Transmission ratio		Axis ID	0	
Mode setting		Axis Type	Bus servo axis	~
Mode setting		Input Device		\sim
Homing setting		Output Device	INVT_DA200_261	\sim
Online debugging		Virtual Axis I	1ode 🗸 Automatic Mapping	

Name	Description
Axle number	• Each axis has an unique axis number, which cannot be changed manually, and is arranged in the order of adding.
Axie number	• The axis number is unique, and can be used as the input parameter of MC instruction to access the axis.
Axis type	The axis type options include fieldbus servo axis, local pulse axis and local encoder axis.
Input device	Limited to local encoder axis only.
Output device	 Valid only in fieldbus servo axis and local pulse axis mode. If it is a fieldbus servo axis, choose a EtherCAT device; If it is a local pulse axis, choose the combination of high-speed output terminals, including Y0/Y1, Y2/Y3, Y4/Y5 and Y6/Y7.
Virtual axis mode	Valid only in fieldbus servo axis and local pulse axis mode. After checking the virtual axis mode, the axis will no longer control the driver or high-speed output terminal selected by the output device, but generate a virtual servo axis internally to execute the motion control instruction.
Automatic mapping variables	Valid only in fieldbus servo mode. The EtherCAT master and slaves communicate with each other periodically based on PDO, and the axis is connected to the object dictionary of the EtherCAT slave through variables. When automatic mapping is selected, the mapping process is automatically allocated and cannot be configured manually.

• The fieldbus servo axis PDO cycle variables are as follows:

itatus	Input/Output	Name	Index	Subindex	Bit Length	Flags	SM	Data Type
status	— 🗹 Output	DO Outputs	0x1600	0x0	184	Editable	2	
		Control Word	0x6040	0x0	16			UINT
General setting		Target Position	0x607a	0x0	32			DINT
		Target Velocity	0x60ff	0x0	32			DINT
Process data		Mode of Operation	0x6060	0x0	8			SINT
Process data		Target torque	0x6071	0x0	16			INT
		Touch probe control	0x60b8	0x0	16			UINT
Startup parameter		Positive torque limit	0x60e0	0x0	16			UINT
		Negtive torque limit	0x60e1	0x0	16			UINT
		Max profile velocity	0x607f	0x0	32			UDINT
I/O mapping	— 🗹 Input	DI Inputs	0x1a00	0x0	232	Editable	3	
		Status Word	0x6041	0x0	16			UINT
		Position Actual Value	0x6064	0x0	32			DINT
		Speed Actual Value	0x606c	0x0	32			DINT
		Torque Actual Value	0x6077	0x0	16			INT
		Operation Mode Display	0x6061	0x0	8			SINT
		Current Actual Value	0x6078	0x0	16			INT
		Touch Probe Status	0x60b9	0x0	16			UINT
		Touch Probe Value	Ox60ba	0x0	32			DINT
		Digital outputs	0x60fe	0x0	32			UDINT
		Digital inputs	0x60fd	0x0	32			UDINT

TS600 Series Programmable Logic Controller Programming and Application Manual

• Parameters to be set for unit conversion.

Name	Function
Number of pulses for one	According to the encoder resolution, set the number of pulses
revolution of motor/encoder	for one revolution of motor
Is a speed change device used	Specify whether a speed change device is used
The amount of movement when the worktable rotates for one revolution	The amount of movement on the workpiece side for 1 revolution when the speed change device is used
Gear ratio on the workpiece side	Set gear ratio on the workpiece side
Gear ratio on the motor side	Set gear ratio on the motor side

When the fieldbus driver (local pulse axis) controls the motor, pulse unit is used, and common measurement units such as mm, ° and inch are used on the motion control instruction side, which are called Unit. The two units are converted to each other internally according to the configuration parameters. The mode of conversion can be divided into the following cases:

1. Without a speed change device

When no speed change device is used, the conversion formula from Unit to pulse unit is as follows:

Number of pulses (pluse)

= The number of pulses for one revolution of the motor/encoder[DINT] Movement amount of one revolution of the worktable[DINT]

× Moving distance (Unit)


Take the 23-bit encoder of INVT as an example, set the parameters as follows:

Number of pulses for one revolution of motor/encoder=8388608

The amount of movement when the worktable rotates for one revolution=1

When the target displacement given by the relative positioning instruction is 10, the actual pulse amount sent by the motion control axis is 83886080, and the motor rotates 10 revolutions at this time.

- 2. With a speed change device
 - A. Typical operating conditions in linear mode are shown in the following figure.




Where, (1) is a servo motor, (3) is a workpiece, (4) is the denominator of gear ratio, and (5) is the numerator of gear ratio.

Number of pulses (pluse)

- = The number of pulses for one revolution of the motor[DNIT] × gear ratio numerator[DINT] Movement amount of one revolution of the worktable[DINT] × Gear ratio denominator[DNIT]
- × Moving distance (Unit)

B. Typical operating conditions in circular mode are shown in the following figure.



The conversion formula from Unit to pulse unit is as follows:

Number of pulses (pluse)

- The number of pulses for one revolution of the motor[DNIT] × gear ratio numerator[DINT] Movement amount of one revolution of the worktable[DINT] × Gear ratio denominator[DNIT]
- × Moving distance (Unit)

11.3.3 Mode Setting

11.3.3.1 Configuration Interface

The mode setting interface is as follows:


Basic setting	Encoder Mode	Incremental N	Mode		Absolute Mode		
Transmission ratio	Mode Set	Linear Mode		0	Rotation Mode		
Mode setting	Software limit	Enable					
Homing setting		Positive Max Value:	-0.000	Unit Negati	ve Max Value:	0.000	Unit
Online debugging	SoftwareErrorResponse				Servo Alarm En	able	
		Axis Expire Dec:	10000.000	Unit	Servo Alarm:	~	
	Axis Speed Set	Max Speed:	1000.000	Unit/s	Max Acc:	10000.000	Unit/s^2
		Maximum Jerk:	100000.000	Unit/s^3	Max Dec:	10000.000	Unit/s^2
		Jog Max Speed:	1000.000	Unit/s			
	Torque Set	Max Positive Torque:	3000.000	N*m Max Nega	ative Torque:	3000.000	N*m

11.3.3.2 Mode Setting

According to the actual working conditions, the motion control axis can be set to linear mode and rotation mode.


- Linear mode
 - Linear mode is usually used in devices with mechanical action range in X-Y linear coordinate system. Linear mode usually contains a zero point.
 - When the feedback position increases, it indicates forward motion, otherwise it indicates reverse motion.
 - ♦ It is allowed to set positive software limit and negative software limit. When software limit is enabled, the axis can only move within the limit range.
 - Absolute positioning mode: When the target position is greater than the starting position, then move forward for the distance between the target position and the starting position; When the target position is less than the starting position, then move backward for the distance between the starting position and the target position.

- Relative positioning mode: When the target displacement is greater than 0, move forward for the distance of target displacement, and when the target displacement is less than 0, move backward for the distance of "target displacement".
- ♦ The way to process velocity instructions in linear mode: If the target speed is greater than 0, it will move forward, otherwise it will move backward.
- Rotation mode
 - The rotation mode is a mode in which a counter repeats counting infinitely in a set orientation. It is usually used in turntables or reels.
 - The rotation mode usually includes a zero point and a rotation cycle.
 - In rotation mode, if the feedback position increases, it is considered as clockwise motion, and if the feedback position decreases, it is considered as counterclockwise motion.




- ♦ There is no soft limit in rotation mode.
- Phase positioning processing: If the target displacement is greater than> 0, move the distance of target displacement clockwise, and if the target displacement is less than 0, move the distance of target displacement counterclockwise.
- ↔ How to deal with absolute positioning:

Forward: First, the target displacement is modulated against the rotation cycle, and then the axis runs clockwise from the starting position of the axis to the target position.



Reverse: First, the target displacement is modulated against the rotation cycle, and then the axis runs counterclockwise from the starting position of the axis to the target position.



- Shortest distance: Firstly, the target displacement is modulated against the rotation cycle, and then the distance of clockwise and counterclockwise movement to the target position is compared, and the direction with shorter distance is taken as the direction to run to the target position.
- ♦ Current direction: Move to the target position according to the latest movement direction of the axis, and move forward to the target position after the first power up.

11.3.3.3 Software Limit

It is allowed to set software limit in linear mode.

If the software limit is effective, the absolute position of the axis will be detected at all times during the operation of the axis when T-type deceleration is made from the current speed to 0 according to the set limit deceleration. If the absolute position of the axis exceeds the limit range, the axis will execute the soft limit deceleration algorithm and interrupt the positioning or velocity instruction that is being executed.

Software limit is invalid in homing and moment mode.

11.3.3.4 Axis Error Deceleration

If the axis must switch to the errorstop state due to the logic failure of the motion instruction itself during the operation of the axis, the axis will trigger an emergency stop, and the axis will enter the errorstop state only after the emergency stop is completed.

11.3.4 Axis Speed Setting

It is allowed to set three parameters: maximum speed, maximum acceleration and maximum jogging speed. When the target speed, acceleration deceleration and other parameters in the positioning or velocity instructions exceed the speed limit, the axis runs with the values of maximum speed, maximum acceleration and maximum jogging speed.

In the fieldbus servo axis, the maximum speed is converted into pulse unit by unit conversion, which is written into the object dictionary 0x607f of the servo driver by starting parameters.

11.3.5 Probe Setting

The local pulse axis can enable the probe terminal through probe settings.

Each local pulse axis can be configured with up to two probe terminals. The probe terminal source can be selected from X0 to X17. After the probe terminal is enabled, the local pulse axis can use the probe instruction and interrupt fixed-length instruction.

11.3.6 Output Settings

The local pulse axis allows Y0/Y1, Y2/Y3, Y4/Y5, Y6/Y7 to be set as 4 local pulse axes. The local pulse axis allows output pulses in pulse + direction, forward and reverse direction and CW/CCW format.

For the channel that has been set as the pulse axis, when pulse + direction is selected, Y0, Y2, Y4 and Y6 are pulse terminals, and Y1, Y3, Y5 and Y7 are direction terminals. When CW/CCW is selected, Y0, Y2, Y4 and Y6 are CW pulse terminals, and Y1, Y3, Y5 and Y7 are CCW terminals.

11.3.7 Home Setting

Homing is divided into fieldbus servo homing and pulse homing.

Fieldbus servo homing

Fieldbus servo homing interface:

Basic setting	BUS AXIS						
Transmission ratio				-			
Mada asttina	Home signal:	Unassigned \lor			Z signal:	Unassigned V	
Mode setting	Positive limit:	Unassigned V]		Negative limit:	Unassigned V	
Homing setting	Home direction:	Unassigned V]		Home mode:	Homing mode01 \sim	1
Online debugging	Home speed:	50.000	Unit/s	Home ap	proach speed:	20.000	Unit/s
	Deceleration speed:	50.000	Unit/s	Home	acceleration:	50.000	Unit/s^2

There are 11 supported homing modes, which are homing modes 01, 02, 03, 04, 17, 18, 19, 20, 33, 34 and 35.

For fieldbus homing setting, only the homing mode parameters are valid, and other interface parameters are invalid. The way to return to zero is determined by the homing mode, and the homing speed is determined by the relevant parameters of servo driver.

- Pulse homing
- 1. Home signal configuration

Home speed: 50.000

Deceleration speed: 50.000

Choose the mode setting option for Axis 1 and select the corresponding signal as shown below

	🕞 MAIN 📑 Axis_1 *				
	Basic setting				
	Transmission ratio	Home Set	Home Enable Signal		Z Signal Enable
	Mode setting		Home Signal:	~	Z Signal: 🗸 🗸
	Homing setting	Hardware Limit	Positive Limit Enable		Negative Limit Enable
	Online debugging		Positive Limit:	~	Negative Limit: V
Ρι	lse homing inter	face			
	PLUSE AXIS				
	Home si	gnal: Unassigned	4 ~	Z signal:	Unassigned V
	Positive	limit: Unassigned	4 ~	Negative limit:	Unassigned ~
	Home direc	tion: Unassigned		Home mode:	Homing mode03 V

Unit/s

Unit/s

The valid parameters in the current version of pulse homing interface: homing direction, homing mode, homing velocity, homing approach velocity, homing acceleration, etc. Among them, home signal, Z signal, positive limit, negative limit, etc. are used to select homing mode diagram. This function is not developed in the current version, and the decelerated running speed is invalid in the current version.

Home approach speed: 20.000

Home acceleration: 50.000


Unit/s

Unit/s^2

2.


3. Schematic Diagram of Homing Mode 3

The rising edge of the near-origin switch is detected and used as the home.




11.4 Online Monitoring


- 1. The axis state is obtained by means of instructions, such as reading the relevant information of the axis through state instructions like MC_ReadStatus, MC_ReadPosition and MC_ReadVelocity.
- MC_ReadStatus Read Axis Status



2. Acquire axis status through online debugging interface



3. Acquire axis status through axis monitoring



11.5 Axis Control Function

11.5.1 Overview

Some basic servo controls can be realized through online debugging function, such as Enable, Stop, Jog, Point Control and other functions. After confirming that the basic operation is normal, complex logic control can be realized through motion control instructions. Online debugging and PLC instruction control cannot be used at the same time, and the restrictions are as follows:

Calling MC_Stop instruction in a PLC program makes it impossible to enter online debugging mode through background when the axis is in Stop state.

The relationship between MC_Power instruction and the enable in online debugging is OR, that is, the axis can be enabled as long as one of the modes is valid.

The priority of motion instructions such as MC_MoveAbsolute is lower than that of online debugging. When the axis is in online debugging mode, calling motion instructions is invalid, and the instructions report errors, but the axis will not enter an Error state.

11.5.2 Online Debugging

The online debugging interface is as shown below, and the supported functions include homing, JOG movement, absolute positioning, relative positioning, speed control and so on.

The online debugging operating steps are as follows:

Step 1 Check "Enable Debug Mode" first.

TS600 Series Programmable Logic Controller Programming and Application Manual

	Theore	tical	Actual	Enable stat	e: StandSt	ill
smission ratio	0.000		000	1		
Position:	0.000	0.	000	Communication statu	IS: OP	
Speed:	0.000	0.	000	Axis error cod	e: No Erro	r
g setting Torque:	0.000	0.	000	Drive error cod	e: No Erro	r
e debugging M	otio	Hardware	Hardware	Software	Software	Home
OFF		OFF	OFF	OFF	OFF	OFF
Enable Debu	ıg Mode set positio	OFF	OFF			OFF
Enable Debu	set positio	OFF		g	Enable	OFF
Enable Debu Pres Home por	set positio	OFF on 0.000 set 0.000	Settin	g		OFF

Step 2 Trigger "Enable" and observe whether the axis is in Standstill state.

Enable Debug Mode						
Preset position	0.000	Set	tting	Enab	le	
Home position offset	0.000	Return	n Home	Rese		
Forward Jog	5.000	Jo	g+	Rese		
Reverse Jog	5.000	Jo	og-	Stop)	
Control Mode	Absolute pos	sitior 🗸	Targe	t Torque	0.000	
Target Position	5.000		Torqu	e Ramps	0.000	
Target Speed	100.000		Spe	eed Limit	0.000	
Target Acceleration	1000.000		Positio	n Offset	0.000	
Target Deceleration	1000.000		Remaining Positio	n Offset	0	
Target Jerk	0.000		Number of encoder of	overflow	0	
	Start			S	top	

Step 3 Observe axis state.

-					Г			StandStil	
insmission ratio		Theore	tical	Actual	L	Enable sta	ate:	StandStill	
	Position:	0.000		0.000	Con	nmunication stat	tus:	OP	
ode setting	Speed:	0.000		0.000		Axis error co	de:	No Error	
oming setting	Torque:	0.000		0.000		Drive error co	de:	No Error	
nline debugging	м	otio	Hardwar	e Hardwar	e	Software	So	ftware	Home
	OFF		055	0.55			1	-	0.55
	OFF		OFF	OFF		OFF	OF	F	OFF
	Enable Debu	set positio		Setti	-		En	able	
	Enable Debu Pres Home por	set positio	on 0.000 et 0.000	Settin Return H	Home		En		OFF

Step 4 Trigger corresponding control instructions, such as homing, JOG, absolute positioning, relative positioning, etc.

Preset position	0.000	Set	ting	[Enabl	e	
Home position offset	0.000	Return	n Home		-		
Forward Jog	5.000	Jo	g+		Rese	t	
Reverse Jog	5.000	Jo	g-		Stop		
Control Mode	Absolute pos	itior 🗸		Target	Torque	0.000	
Target Position	5.000			Torque	Ramps	0.000]
Target Speed	100.000			Spe	ed Limit	0.000	
Target Acceleration	1000.000			Position	n Offset	0.000]
Target Deceleration	1000.000		Rema	aining Position	Offset	0]
Target Jerk	0.000		Number	of encoder o	verflow	0]
				St	ор		

The options in the figure are described as follows:

Name	Description
Enable	It means calling MC_Power instruction for axis enable action
Reset	It means calling MC_Reset instruction for axis enable action
Stop	It means calling MC_Stop instruction for axis stop action
Settings	It means calling MC_SetPosition instruction for position setting
Homing	It means calling MC_Home instruction for homing
JOG+	JOG positive
JOG-	JOG negative
Absolute position	It means calling MC_MoveAbsolute instruction for absolute positioning action of axis
Relative position	It means calling MC_MoveRelative instruction for relative positioning action of axis
Speed mode	It means calling MC_MoveVelocity instruction to run the axis in speed mode

Step 5 Observe the change of axis position and axis speed

Basic setting							
Transmission ratio		Theore	tical	Actual	Enable state	StandStill	
Transmission ratio	Position:	15.000		15.000	Communication status	OP	
Mode setting	Speed:	0.000	(0.000	Axis error code:	No Error	
Homing setting	Torque:	0.000		0.000	Drive error code:	No Error	
Online debugging	M	otio	Hardware	Hardware	Software S	oftware	Home
	OFF		OFF	OFF	OFF C	FF	OFF

11.5.3 Instruction Control Rule

In PLC, the axis motion can be controlled by instructions, and the rules for calling instructions are as follows:

- Instructions do not need to be instantiated.
- In the instruction, the axis number is the unique identification to access the axis.
- The priority of motion instructions is generally lower than that of online debugging mode.
- Floating-point parameters in instructions need to meet the precision range of floating-point numbers, which are generally considered to be 7 significant digits, and can be set to 9999999 at maximum.

11.5.4 Limit Processing

It supports two kinds of limit detection: software limit detection and hardware limit detection.

- Software limit processing is only valid when calling position and velocity instructions in linear mode, but homing and torque instructions are invalid.
- Within the software limit range, call the position instructions which can be executed normally if the absolute target position does not exceed the limit; If the absolute target position exceeds the software limit, the execution of the positioning instruction is interrupted and finally stopped at the software limit.
- Within the software limit range, call the velocity instructions whose execution will be interrupted and which will stop at the software limit when the axis runs at the current speed and detects that it will exceed the soft limit.

11.5.5 Positioning Acceleration and Deceleration Curve

It supports T-type acceleration and deceleration and S-curve acceleration and deceleration, which are determined by Jerk parameter in the instruction. When Jerk parameter is 0, it indicates T-type acceleration and deceleration, and when it is greater than 0, it indicates S-curve acceleration and deceleration.

11.6 Fault Type

Axis faults are divided into instruction faults, axis faults and drive faults.

• An instruction fault is the fault caused by MC axis control instruction itself

For example, the instruction parameters are unreasonable, and the PLCOpen state machine of the axis changes during operation, which leads to instruction error. You can get the fault code by checking the ErrorID of the faulty instruction.

• An axis fault is the fault reported by the axis itself

For example, the following error is too large. It can be obtained in the background through "Axis error" in the "Online debugging" interface or through the AxisErrorID in the MC_ReadAxisError instruction.

• A driver failure is the fault of EtherCAT fieldbus driver or local pulse output axis

To get the fault of the EtherCAT fieldbus driver, 0x603F must be configured in the PDO mapping and associated with the axis. It can be obtained in the background through "Axis error" in the "Online debugging" interface or through the ServoErrorID in the MC_ReadAxisError instruction.

12 High-speed Counter

12.1 Brief Introduction of High-speed Counter Axis


In AutoStation Pro, counters are managed in the form of encoder axis. After the counter is associated with the axis, they are collectively called counter axis or encoder axis. A total of 8-axis 32-bit high-speed counters are supported.

- Counters 0 3 are high speed counters, which can realize AB phase 1/2/4 frequency doubling, CW/CCW, pulse + direction and single phase counting mode.
- 4–7 are ordinary counters, which only have a single-phase counting mode.
- The 8-axis counting signal source can be chosen from external pulse input or internal 1ms/1µs clock counting; With other input signals, the preset and latch functions of the counter can be realized.

12.2 Create a Counter Axis

Before using counters in AutoStation Pro, you need to associate them with axes.

Step 1 In the "Project manger" field, right-click the motion control axis under "Setting" and choose "Add axis" to create a motion control axis.



Step 2 Double-click the newly added axis (as shown in Figure Axis_0) to open the settings page, choose "Local encoder axis" as the axis type in the "Basic Setting" interface, and choose "High speed counter" as the input device to associate the axis with the counter. The axis number is used as the axis identification in the program to realize the control of the corresponding counter axis. (High-speed counters have multiple modes, while ordinary counters only have a single-phase counting mode)

🕞 MAIN 🚺 Axis_0 *						
Basic setting	Basic Setting					
Transmission ratio		Axis ID	0			
Mode setting		Axis Type	Local encoder axis		\sim	
		Input Device			\sim	
		Output Device	NULL High speed countingC00 High speed countingC01		<u>^</u>	
		Virtual Axis I	High speed countingC02 High speed countingC03	6	v	

12.3 Counter Axis Unit and Conversion

High-speed counters use pulse unit when decoding encoder signals, while counter instructions use common measurement units such as mm, °, inch, etc., which are called Unit. The number of pulses can be converted into unit by conversion, which can be defined as device-specific units (cm, mm, rpm, etc.) according to the actual application.

Name	Function
Number of pulses for one revolution of	According to the encoder resolution, set the
motor/encoder	number of pulses for one revolution of motor
Is a speed change device used	Specify whether a speed change device is used
The amount of movement when the motor/encoder rotates for one revolution	The amount of movement of workpiece when the
	motor rotates for 1 revolution without the speed
motor/encoder rotates for one revolution	change device
The amount of movement when the worktable	The amount of movement of workpiece when the
rotates for one revolution	worktable rotates for 1 revolution with the speed
	change device
Numerator of gear ratio	Set gear ratio on the workpiece side
Denominator of gear ratio	Set gear ratio on the motor side

The parameters to be set for unit conversion are as follows:

For example, the servo motor drives the worktable to move by connecting screw rod of reducer, and counts encoder to feedback worktable position through the PLC controller. The counter counts encoder pulse, taking pulse as unit; The counter axis indicates the worktable position, in millimeters. Therefore, in the program, Unit is used as the unit of counter axis.

The conversion relationship between Unit and pulse is as follows:

• Without a speed change device

10,000 pulses equal to the operation of 1 Unit (cm/mm/rpm), to be decided by the user as per the actual application).

MAIN Axis_0 *	
Basic setting	Transmission Ratio:
Transmission ratio	The number of pulses for one revolution of the encoder: 10000
Mode setting	No Gearbox
	The amount of movement for one revolution of the table: 1.0
	○ With Gearbox
	The amount of movement for one revolution of the table: 10.000
	Numerator of gear ratio: 1
	Denominator of gear ratio: 1
	lead Gear ratio: N/M

Calculation formula of pulse and actual distance:

The number of pulses for one revolution of $\frac{\text{motor}}{\text{encoder}}$ [DINT]

 $= \frac{\text{encoder } \cdot \quad }{\text{Amount of movement when the worktable rotates for one revolution [REAL]}} \times \text{Moving distance (Uint)}$

• With variable device

10,000 pulses, gear ratio 4:5 (cm/mm/r, to be decided by the user as per the actual configuration).

MAIN Axis_0	
Basic setting	Transmission Ratio:
Transmission ratio	The number of pulses for one revolution of the encoder: 10000
Mode setting	O No fearbox
	The amount of movement for one revolution of the table: 1.0
	With Gearbox
	The amount of movement for one revolution of the table: 1.0
	Numerator of gear ratio: 4
	Denominator of gear ratio: 5
	lead Gear ratio: N/M

12.4 Set the Working Mode

12.4.1 Linear Mode

The position of the counter axis changes between the negative limit value and the positive limit value, and after the position of the counter axis reaches the limit value, the homodromous pulse is continuously input; The counter axis reports overflow while the counter axis position remains unchanged. After the counter axis reports overflow, input reverse pulse, the counter axis counts reversely, and the overflow flag is removed.

In linear mode, you can set the negative and positive position limit values of the counter axis in the interface, and Unit is used as the position unit. The negative limit value must be smaller than the positive limit value.


Since the high-speed counter is a 32-bit counter, the negative limit value and the positive limit value must be in the range of 32-bit integers after being converted into pulse unit [-2147483648, 2147483647].

Mode setting

Mode Set	Linear Mode		O Rotation Mode	
Software limit	Inable			
	Posiive Max Value: 1000.000	Unit	Negative Max Value: 0.000	Unit


In linear mode, the high-speed counter operates in a closed interval of [negative limit value, positive limit value]. When the direction is negative, the count value decreases in the negative direction, and after reaching the negative limit value, the count value does not decrease any more; When the direction is

positive, the count value increases in the positive direction, and after reaching the positive limit value, the count value does not increase.




12.4.1.1 Positive Pulse Counting

In linear mode, input positive pulse, after the counter axis position counts up to the limit value, continue to input positive pulse, set the counter axis positive limit signal to 1, the counter axis position value remains unchanged. Input negative pulse, the counter axis position counts down, and set the positive limit signal to 0.



12.4.1.2 Negative Pulse Counting


In linear mode, input negative pulse, after the counter axis position decremental counter reaches the limit value, continue to input negative pulse, set the counter axis negative limit signal to 1, the counter axis position value remains unchanged. Input positive pulse, the counter axis position counts up, and set the negative limit signal to 0.



12.4.2 Rotation mode

The position of the counter axis changes cyclically in the rotation cycle. When the counter counts up, the position of the counter axis reaches the maximum value of the rotation cycle and then becomes 0. When the counter counts down, the position of the counter axis is 0 and then decreases from the maximum value of the rotation cycle.

In rotation mode, you can set the rotation cycle of the counter axis in the interface, and Unit is used as the cycle unit. Since the high-speed counter is a 32-bit counter, the rotation cycle must be in the range of 32-bit integers after being converted into pulse unit [-2147483648, 2147483647].



12.5 Set Counter Parameters

12.5.1 Overview

Parameter settings mainly include counting mode, reset, probe, preset and comparison output settings.

Basic setting	Mode setting			
Transmission ratio	Mode Set	Linear Mode		n Mode
Mode setting	Software limit	✓ Enable		
		Posiive Max Value: 1000.000	Unit Negative Max Value	0.000 Unit
	Counter Mode Set	Counting Mode: A/B phase 1x :	 Signal Source: 	X6-phase A,X7-phase \vee
			Time Base:	1
	Reset Set	Hardware Reset Enable	Trigger Moo	de:
		Input Terminal:	~	 Falling Edge Trigger
	Probe Set	Probe 0 Enable	Probe 1 Ena	ble
		Input Terminal: X03	✓ Input Terminal:	~
	Preset Set	Preset Enable		
		Input Terminal:		
	Compare Output Set	Compare Output Enable	Pulse Width:	1 0.1ms
	compare output bet	Input Terminal:	- Unit:	● ms ○ Pluse

12.5.2 Counting Mode

The local encoder axis supports multiple signal counting modes, A/B phase (1/2/4 frequency doubling), CW/CCW, pulse + direction, single phase counting.

Signal source: According to different counting modes, different signal sources can be selected.

Note: High-speed counters support multiple modes, while ordinary counters only support single-phase counting mode.

12.5.2.1 A/B Phase Mode


In the A/B phase mode, the encoder generates two quadrature phase pulse signals with a phase difference of 90 degrees, namely A-phase signal and B-phase signal.

- When the A-phase signal leads the B-phase signal, the counter counts up.
- When the B-phase signal leads the A-phase signal, the counter counts down.


In the A/B phase 1 frequency doubling mode, only the rising edge of the A-phase pulse is counted, as shown in the following figure.

Counter Mode Set	Counting Mode: A/B phase 1x :	
	B phase	
	+11	

In the A/B phase 2 frequency doubling mode, only the rising/falling edge of the A-phase pulse is counted, as shown in the following figure.



In the A/B phase 4 frequency doubling mode, the rising/falling edge of the A-phase pulse and B-phase pulse is counted, as shown in the following figure.




12.5.2.2 CW/CCW Mode


CW is a positive pulse signal, and CCW is a negative pulse signal.

- When the encoder rotates forward, CW outputs a pulse signal.
- When the encoder is inverted, the CCW outputs a pulse signal.

As shown in the following figure, X0 is a CW signal and X1 is a CCW signal:



In CW and CCW modes, the high-speed counter counts up the CW signal and counts down the CCW signal, as shown in the following figure.



12.5.2.3 Pulse + Direction Mode

In pulse + direction mode, when the direction signal is ON, the high-speed counter counts up, and when the direction signal is OFF, the high-speed counter counts down, as shown in the following figure.

Counter Mode Set	Counting Mode: Pulse + Directi ∨	Signal Source: X0-pulse,X1-dire	ectior 🗸
	Pulse		
	+1 ⁺¹	<u>-11</u>	

12.5.2.4 Single-phase Counting

In single-phase counting mode, the high-speed counter counts up the pulse signal, as shown in the following figure.

Counter Mode Set	Counting Mode: Single phase c ∨	Signal Source: Time Base:	x00 ~
	Pulse	+1	
	Position pulse +1+1+1+1	+1	

12.5.3 Hardware Reset Settings

Check hardware reset enable, configure external trigger IO (X0–X7, X10–X17), configure trigger edge mode, choose trigger by external hardware through ENC_Reset instruction, which can then reset counter count value through external IO.

Reset Set	Hardware Reset Enable	Trigger Mode:
	Input Terminal: X01 \checkmark	Falling Edge Trigger

12.5.4 Probe Setting

The first four high-speed counters support 2 probes, while the last four ordinary counters do not support probe function, and the current value of the counter is latched by external hardware. Check the probe enable and choose the input terminals (X0 –X7, X10–X17). Get the corresponding latched value through the instruction ENC_TouchProbe

Probe Set	Probe 0 Enable	2	Probe 1 Enable
	Input Terminal:	X03 \	/ Input Terminal:
		NULL 🗖	
		X02	
Preset Set	Preset Enable		
		X04	
	Input Terminal:	X05 X06	

12.5.5 Preset Settings

Each counter axis supports one preset function, check preset enable, configure input terminals (X0–X7, X10–X17), and choose external hardware trigger by ENC_Preset instruction, so that the preset value of the counter can be set by external hardware signal.

Preset Enable					
Input Terminal:	X02	\sim			
	X02	A .			
Compare Outp	X05 X06		Pulse Width:	1	0.1ms
Input Terminal:	X07 X 10	~	Unit:	🖲 ms 🔷 Pluse	2
	Input Terminal:	Input Terminal: X02 X02 X04 Compare Outp X05 X05 X07	Input Terminal: X02 X02 Compare Outp X05 X06 X07 X	Input Terminal: X02 X02 X02 Compare Outp X05 X06 X07 V07 V07 V08 V07 V09 V09 V09 V09 V01 V02 V02 V04 V02 V04 V02 V04 V05 V04 V05 V05 V05 V05 V05 V06 V07 V	Input Terminal: X02 X02 Compare Outp X05 X06 X07 V

12.5.6 Comparison Output Settings

The comparison output function can directly output through hardware instantaneously, and after reaching the comparison value, it can respond to the output within 5 microseconds. Each counter axis supports a hardware comparison output.

Configure the output IO (Y0 – Y7, Y10 – Y17), configure the pulse hold width (16 unsigned integers), configure the hold unit 0.1 ms (hold time = hold width * 0.1 ms) or Pulse (hold time is the number of received pulses).

Compare Output Set	Compare Output Enable		Pulse Width: 1000	0.1ms	
compare output set	Input Terminal:		~	Unit: 🖲 ms (Pluse
		Y01 Y02 Y03	^		
		Y04 Y05 Y06	¥		


12.6 Application of Encoder Axis Instruction

12.6.1 Overview

After setting the local encoder axis in Auto Station Pro, the functions of axis position ranging, speed measurement, axis position presetting, axis position latch and axis position comparison can be realized in combination with the relevant function block applications.

12.6.2 Axis Position Ranging/Speed Measurement Instruction

- 1. With ENC_Counter instruction, the encoder axis position ranging and speed measurement can be carried out.
- 2. The position of encoder axis changes within the limited range of the encoder axis according to the mode setting, and the position unit is Unit (user-defined).
- 3. The encoder axis speed is the current real-time speed, and the speed unit is Unit/S. The minimum measurable speed of the encoder axis is 1Hz pulse frequency.
- 4. If the transmission ratio of encoder axis is set to 1:100, the real-time speed of 1Hz pulse frequency corresponds to 0.01 Unit/s.




"Invert" control counting direction in the instruction, 0: count in the default direction, 1: count in the direction opposite to the actual counting direction.

The configuration parameter of the instruction is that: Enable rising edge is valid, while changing the input parameters in other hold periods is invalid. And Enable hold enables the module.

Invert	A/B Phase	Pulse + Direction	cw/ccw	Single-phase Counting
0	 A-Phase advance, B-Phase countup B-Phase advance, A-Phase countdown 	level countdown	CW countupCCW countdown	Countup
1	 A-phase advance, B-phase countdown B-Phase advance, A-Phase countup 	level countup	• CW	Countdown

12.6.3 Axis Position Preset Instruction

Enable ENC_Preset to assign the encoder axis position according to the preset mode.




"TriggerMode" as a preset condition can choose rising edge trigger, falling edge trigger, or rising or falling edge trigger.

TriggerMode	Definition			
0	Software control, Enable rising edge trigger			
1	External hardware rising edge trigger (preset function need to be configured on the system side)			
2	External hardware falling edge trigger (preset functions need to be configured on the system side)			
3	External hardware rising or falling edge trigger (preset functions need to be configured on the system side)			

12.6.4 Probe Instruction

Using the EN_TouchProbe function block instruction, the position value of the encoder axis can be latched when the corresponding external input signal reaches the trigger condition. Each encoder axis supports 2 probes, so it is necessary to check the configuration-related probe functions in the system configuration interface. (See section 12.5.4 Probe Setting for details.)



The parameter "ProbeID" indicates the probe number used by the encoder axis as follows:

ProbeID	Definition
0	It indicates the use of probe 1
1	It indicates the use of probe 2


The parameter "TriggerEdge" indicates the probe trigger edge setting, the rising edge trigger position is latched in PosPosition, and the falling edge trigger position is latched in NegPosition.

TiggerEdge	Definition
0	External hardware signal rising edge trigger
1	External hardware signal falling edge trigger
2	External hardware signal rising or falling edge
2	trigger

The parameter "TiggerMode" sets the single-trigger or continuous-trigger modes.


TiggerMode	Definition
0	Single trigger
1	Continuous trigger

In single trigger mode where rising edge trigger is adopted, function block instruction Enable is active, and when the external input signal reaches the trigger condition, the encoder axis position will be latched once, and the completion signal is output.




Rising edge single trigger mode

In continuous trigger mode where rising edge trigger is adopted, function block instruction Enable is active, and when the external input signal reaches the trigger condition, the encoder axis position will be latched, and the completion signal with effective time of 1 scanning period will be output. After the completion signal becomes OFF, the external input signal reaches the trigger condition again, and the counter axis position will continue to be latched, and the completion signal with effective time of 1 scanning period will be output. If the latch condition continues to be triggered within 1 scanning period when the completion signal is valid, the counter axis position will not be latched at this time.



12.6.5 Single-step Comparison Instruction

Instruction ENC_Compare can compare the encoder axis with a single position, and when the encoder axis reached the comparison position, the completion signal is output.




12.6.6 Continuous Comparison Instruction

Instruction ENC_StepCompare can compare the encoder axis with unit distances continuously. When the comparison is completed, the completion signal is output.



- When StartPosition <EndPosition, Step> 0, the encoder axis position is compared from StartPosition. When the comparison value is equal, the comparison position automatically increases the Step distance to start the next comparison, until the comparison position is greater than EndPosition, then the comparison is completed, and the completion signal is output. The current comparison value keeps the last comparison parameter.
- When StartPosition > EndPosition, Step < 0, the encoder axis position is compared from StartPosition. When the comparison value is equal, the comparison position automatically increases the Step distance to start the next comparison, until the comparison position is greater than EndPosition, then the comparison is completed, and the completion signal is output. The current comparison value keeps the last comparison parameter.



12.6.7 Array Comparison Instruction

Enc_ArrayCompare can realize continuous comparison between encoder axis and array at multiple positions. When Enable is valid, the encoder axis position starts comparison from the first position of the array, and after the comparison result is equal, the next position value of the array will be compared. Until the last comparison position is compared, a completion signal is output.



- "mArray" in the instruction sets the array to be compared. For example, to define the array Ar[10]; If the comparison starts from Array 0, fill in Ar[0], and if the comparison starts from Array 2, fill in Ar[2].
- In the instruction, "Size" sets the array length (the maximum value is 100). After the comparison of all array positions set by the array length is completed, the completion signal is continuously output and the continuous comparison of multiple positions is completed.
- The output parameter "Index" represents the number of completed comparisons.

Comparison position		P0	P1	Pn
comparison position				
Axis Position	$\langle 0 \times 1 \times 2 \rangle$	$\langle \langle P0 \rangle \langle P0 $	(P1) (P1)	$\langle Pn \rangle$
Done				

12.6.8 Hardware Comparison Output of Encoder Axis

The comparison instructions Enc_Compare, Enc_StepCompare and Enc_ArrayCompare all have hardware comparison output function. Setting OutputEnable to 1 can output the corresponding hardware associated when the comparison results are equal.


Take Enc_StepCompare as an example:

Step 1 Configure the relevant configuration of the encoder axis hardware comparison output in the system configuration.

Compare Output Set	Compare Outp		Pulse Width:	10	0.1ms
	Input Terminal:	Y00	\sim	Unit:	⊙ ms

Step 2 In Enc_StepCompare, the hardware comparison output function is enabled, and OutputEnable is set to 1.





12.6.9 Encoder Axis Comparison Interrupt


Enc_Compare, Enc_StepCompare and Enc_ArrayCompare all have interrupt service function. Set Interrupt to 1 – 16 (0: Not used), execute the corresponding interrupt service function.

Take Enc_Compare as an example:




		Idle interrupt		Assigned interrupt	
rogram name: INT_1	Author:	Interrupt number	Interrupt ^	Interrupt program	Interrupt nu
nterrupt event: Input c	ompare interrupt 1 (interrup	-1	Not set	Axis_1	0
nterrupt event. Input c	ompare interrupt i (interrup	4	X4 input	Axis_1	1
rogram description:		5	X5 input	Axis_1	2
		6	X6 input	Axis_1	3
		7	X7 input		
		12	X4 input		
		13	X5 input		
-		14	X6 input		
		15	X7 input		
	OK Cancel	16	Input com		
		17	Input com		
		18	Input com		
		19	Input com		
		20	Input com		
		21	Input com		
		22	Input com		
		23	Input com Y		
		<	>	<	,
		Current 16		OK	Cancel

Step 2 Write interrupt service function (INT_1).



Step 3 Configure the corresponding Interrupt number for "Interrupt" in the instruction ENC_Compare and start IE.



Step 4 When the encoder position value is equal to the comparison value, the interrupt service function INT_1 is triggered to light up Y0.

12.6.10 Modify the Gear Ratio of Encoder Axis

The instruction "Enc_SetUnit" can modify the electronic gear configuration of the axis in the system configuration parameters. Activate Enable, configure relevant parameters (PlusePerCycle: number of pulses per revolution of motor, DisPerCycle: actual distance per revolution, Numerator: the numerator of gear ratio, Denominator: the denominator of gear ratio).

M404	Enable	ENC_SetUnit				
	Enable	ENC_SetUIIIt				
0	 Axis		Done	- ON	M 90	
10000	 PlusePerCycle		Busy	- OFF	M91	
1.000000	 DisPerCycle		CommandAborted	_		
1	 Numerator		Error	- OFF	M92	
2	 Denotinator		ErrorID	- 16#0000	D60	

Corresponding system configuration parameters:

Basic setting	Transmission Ratio:	
Transmission ratio	The number of pulses for one revolution of the encoder:	10000
Mode setting	○ No Gearbox	
	The amount of movement for one revolution of the table:	1.0
	With Gearbox	
	The amount of movement for one revolution of the table:	1.0
	Numerator of gear ratio:	1
	Denominator of gear ratio:	2

Note: This instruction directly modifies the system configuration parameters. When fixed prior to application, it is necessary to close other application instructions of the encoder axis. After closing, the system parameters can be modified.

12.6.11 Modify Mode/Limit Value of Encoder Axis

The instruction "ENC_SetLineRotationMode" can modify the configuration associated with the mode in the system configuration parameters. Enter the relevant configuration, and activate Enable control terminal.

M405			Enable	ENC_SetLineRotatio	nMode			
	0		Axis					
	0	-	LineRoTate	eMode	Done	- ON	M95	
	0		SoftLimit	Enable	Busy	- OFF	M96	
	10000.00		Plimit		CommandAborted	-		
	0.000000	-	Nlimit		Error	- OFF	M97	
	360.0000	-	Rotation		ErrorID	- 16#0000	D70	

Parameter	Definition		
LingPotatoModo	0: Linear mode		
LingRotateMode	1: Selection mode		
SoftLimitEnable	0: Limit function disabled		
Sollimitenable	1: Limit function enabled		
Plimit	Positive limit		
Nlimit	Negative limit		
Rotation	Periodic value		

TS600 Series Programmable Logic Controller Programming and Application Manual

Corresponding system configuration parameters:

Mode setting		
Mode Set	Linear Mode O Rotation Mode	
Software limit	✓ Enable	
	Posiive Max Value: 1000.000 Unit Negative Max Value: 0.000 Unit	

Note: This instruction directly modifies the system configuration parameters. When fixed prior to application, it is necessary to close other application instructions of the encoder axis. After closing, the system parameters can be modified.


13 Interpolation Function

13.1 Brief Introduction of Interpolation Function


13.1.1 Basic Introduction

Interpolation adopts space rectangular coordinate system, supports linear interpolation and plane arc interpolation, and the interpolation function is realized by means of axis groups. Up to 8 axis groups can be added at the same time, and each axis group can control up to 4 motion control axes (fieldbus servo axis or local pulse axis), including X, Y and Z coordinate axes and an auxiliary axis.

When linear interpolation is adopted, the motion control axes of x, y and z coordinate axes move along the coordinate axes, and the auxiliary axis moves along the straight line from the starting point to the end point. The following schematic diagram illustrates two-axis linear interpolation:



When arc interpolation is adopted, one of XY axis plane, YZ axis plane and XZ axis plane can be selected for arc interpolation. If other axes are configured in the axis group, the other axes will not act. The following schematic diagram illustrates XY axis plane arc interpolation:




13.1.2 Instruction List


The instruction list is as follows, and the specific parameters of the instruction are detailed in the Instruction Manual.

Instruction	Chinese Instruction Name		
MC_MoveLinear	Linear interpolation		
MC_Movecircuar2D	Plane arc interpolation		
MC_GroupStop	Interpolation stop		
MC_GroupImmediateStop	Interpolation immediate stop		
MC_GroupHalt	Interpolation halt		
MC_GroupSetOverRide	Interpolation on-line speed regulation		

13.1.3 Upper Computer Axis Group Configuration Interface Configuration

Step 1 In the PLC project, choose "Setting" > "AXISGROUP", right-click on "AXISGROUP" to select to add an axis group, and then right-click on the axis group to open it, as shown in the following figure.





ct manager					
SingleMotion1	^	Basic setting			
<pre>{S} test</pre>					
{ } INT_1		Parameter setting	Axis group	0	
User C language		Online monitoring	X axis	Axis_0	~
Eibrary			Y axis	Axis_1	~
▶ 📳 System variable table			Z axis	Unassigned	~
▶ 📳 Global variable table			Auxiliary axis	Unassigned	~
🚽 🙆 Setting					

Step 3 Configure the parameters for running in the "Parameter setting" field:

• The "Interrupt deceleration to zero" option is an interpolation option when interpolation interrupts and reverse motion occurs after interruption.

If "Interrupt deceleration to zero" is chosen, the speed will first decelerate to zero as per the current speed (the deceleration of the function block will be chosen first, and if it is too small, then the fault deceleration will be used), and then accelerate to the target speed in reverse. If "Interrupt deceleration to zero" is not chosen, the speed jumps directly to the opposite direction.

- Here, "Axis group failure deceleration" refers to the deceleration used when interpolation judgment is wrong, and the maximum speed, acceleration and jerk of axis group will all limit the interpolation.
- "Maximum number of axes in the axis group" refers to the number of axes configured in axis group (only displayed, changed as per the axis configuration in the basic configuration).

	▼ ₽ ×	AXISGROUP			
{S} SingleMotion1{S} test	^	Basic setting	Interrupt deceler	ation to zero	
{ } INT_1		Parameter setting	Axis group failure deceleration:	10000	Unit/s^2
User C language		Online monitoring	Maximum number of axes in the axis group:	2	
▶ 🕃 System variable table			Maximum speed of the axis group:	100	Unit/s
Global variable table			Maximum acceleration of the axis group:	1000	Unit/s^2
▼ ∰ Setting ▶ ■ System Block			Maximum jerk of the axis group:	200	Unit/s^3
EXP-CARD			L	I	
Expansion modul	e confi				

13.1.4 Online Monitoring

On the "Online monitoring" page, observe the online parameters of axis groups, which are divided into single axis monitoring in the upper part of axis groups and axis group monitoring in the lower part.

oject manager 🛛 👻 🖣 🗙	AXISGROUP				
SingleMotion1	Basic setting				
{S} test	Online ma	nitoring			
{I} INT_1	Parameter setting	X axis	Y axis	Z axis	Auxiliary axis
User C language	Online monitoring Status	0	0	0	0
🧮 Library	Error code	0	0	0	0
▶ 🕃 System variable table	Setting po	sition 0	0	0	0
Global variable table	Feedback	position	0	0	0
	Setting sp		0	0	0
▶ 🔡 System Block	Feedback		0	0	0
EXP-CARD					
Expansion module confi	Axis grou	ıp			
Electronic cam	Status	0		0	
Motion control axes			Error code		
↓ Axis group setting	Setting spe	ed 0	Remaining distance	0	
AXISGROUP	X Center	0	Y center	0	
AXISGROUP-1	Z center	0	Radius	0	
🕨 🖗 EtherCAT	Initial angle	0			

Name	Parameter	Parameter description
		0: The axis is not enabled
		1: The axis is in fault condition
		2: The axis calls stop module
	State	3: The axis is enabled successfully
	State	4: The axis is in a point motion state
		5: The axis is in continuous motion
Single		6: The axis is in the homing state
axis		7: The axis is in synchronous motion or axis group motion state
axis	Fault code	Not enabled
	Set position	Instruction position of controller
	Feedback position	Servo feedback position
	Set velocity	Instruction speed of controller
	Feedback speed	Servo feedback speed
	State	1: There is an axis in the disable state in the axis group
		2: There is an axis in the single axis stop state in the axis group
		3: There is an axis in the homing state in the axis group
		4: There is an axis in the single axis or master-slave axes motion state in the axis group
		5: There is an axis in the error state in the axis group
		6: All axes in the axis group are enabled
		7: MC_GroupStop or MC_GroupImmediateStop is called
Axis		8: The function block of the axis group is pulled up and successfully
group		enters this state
	Fault code	Axis group error code
	Set velocity	Instruction resultant velocity
	Remaining distance	Target resultant distance minus current resultant distance
	X center	Arc interpolation mode, X axis coordinates of the center of the circle
	Y center	Arc interpolation mode, Y axis coordinates of the center of the circle
	Z center	Arc interpolation mode, Z axis coordinates of the center of the circle

Name	Parameter	Parameter description					
	Radius	Arc interpolation mode, arc radius					
	Initial angle	The initial angle at which a circle is drawn is the angle between starting tangent direction and the X axis, which is posit counterclockwise and negative clockwise					

13.2 Interpolation Operation

13.2.1 Basic Introduction

Before creating an axis group, a single axis shall be created and configured (refer to the introduction in the single axis section), and then the relevant parameters of the axis group shall be configured referring to section "13.1.3 Upper Computer Axis Group Configuration Interface Configuration".

13.2.2 State Machine of Axis Group

The state of the axis group is related to the single-axis state, and the initial state is GroupInit. Update the axis group status in the following three situations:


- In the initial state, check the status of the update axis group.
- If the axis group status is GroupErrorStop or SingleDisabled, check until the axis group status is updated to GroupStandStill when all the axes in the axis group are enabled.
- Each time the axis group module is pulled high, the state machine of the single axis is checked to switch the state machine of the axis group.

Axis Group Status	Status Code	Status Description
GroupInit	0	Initial value
SingleDisabled	1	There is an axis in the disable state in the axis group
SingleStop	2	There is an axis in the single axis stop state in the axis group
SingleHoming	3	There is an axis in the homing state in the axis group
SingleMotion	4	There is an axis in the single axis or master-slave axes motion state in the axis group
GroupErrorStop	5	There is an axis in the error state in the axis group
GroupStandStill	6	All axes in the axis group are enabled
GroupStopping	7	Axis Group Stop or Axis Group Immediate Stop is called
GroupSynchronizeMotion	8	The function block of the axis group is pulled up and successfully enters this state

There are nine cases of axis group state machines:

13.2.3 Axle Group Enable and Reset

The premise of axis group enable is that every single axis in the axis group is enabled, which can be completed by calling the MC_Power module of single axis; Similarly, every single axis needs to be reset before the axis group can be reset, which can be completed by calling the MC_Reset module of single axis. If every single axis in an axis group is switched to the StandStill state, the axis group state automatically switches to the GroupStandStill state. The following figure shows an example of use:




13.2.4 Linear Interpolation

Please use it with the explanation of instruction parameters in the Instruction Manual for the first time.

Linear interpolation calls the instruction MC_MoveLinear. Before running it, please make sure that the panels of "AXISGROUP-Basic setting" and "AXISGROUP-Basic setting" are configured, and all axes in the axis group are in the StandStill state.

The following figure is an example, where the rising edge will set the coordinate positions (X-axis, Y-axis, Z-axis, auxiliary axis) to (1000, 1000, 1000, 1000).



Note: The parameter "Position" of MC_MoveLinear is an array of length 4 with members of REAL type. The data length of D200 – D201 is also of REAL type, so you only need to assign the X-axis target value of 1000 to D200. Similarly, the Y-axis target value is assigned to D202, the Z-axis target value is assigned to D204, and the auxiliary axis target value is assigned to D206. At the same time, the next parameter "Velocity" should be allocated from the memory segment after D208.

13.2.5 Plane Arc Interpolation


Please use it with the explanation of instruction parameters in the Instruction Manual for the first time.

Linear interpolation calls the instruction MC_MoveCircular2D. Before running it, please make sure that the panels of "AXISGROUP-Basic setting" and "AXISGROUP-Basic setting" are configured, and all axes in the axis group are in the StandStill state.

The following figure shows an example of use. The X-axis and Y-axis are selected to draw a circle in the radius mode (CircMode=2), the radius is set to 100 (AuxPoint [0] = 100), and 100 > 0, so the major arc is selected to draw a circle (the central angle is greater than 180°). PathChoice uses the default value (clockwise), and the end position is (0,0). The starting position is the current axis position (100,-100).

M240 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	[MOV	0	D230] O:Select x-axis and y-axis
	-{	MOV	2	D232	<pre>1 2:Set to radius mode</pre>
	ł	DFLT	100	D234] Auxiliary point position1
	-{	DFLT	0	D236] Auxiliary point position2
	-{	DFLT	0	D238] End point position1
	-{	DFLT	0	D240] End point position2
M240			MC_Move	Circular2D	
			Incodec		
			0— AxesGroup		
			D230—CircAxes		
			D232—CircMode		
			D234—AuxPoint		
			D238-EndPoint		
			D242-PathChoice		
			D244—Velocity D246—Acceleration	-	100 / /
			D246—Acceleration D248—Deceleration		
			D240—Deceleration D250—Jerk	-	r—m242 ∶—M243
			D250—Jerk D252—AbsRelMode	CommandAborted	
			D254—BufferMode		· — #245
			D256-TransitionMode	ErrorII	
1					


According to the given parameters, the planning trajectory is as follows:



13.2.6 Axis Group Halt

The axis group calls MC_GroupHalt for halt. Only when the current axis group state is in the GroupStandStill or GroupSynchronizeMotion state can MC_GroupHalt be enabled successfully. When finished, the axis group status is set to GroupStandStill.

The example of use is shown in the following figure.



Note: MC_GroupHalt can be pulled up again to interrupt itself and will execute according to the latest module parameters. When multiple MC_GroupHalt function blocks run with the same axis, the latter function block will interrupt the previous module and the previous one will be displayed as being interrupted.

13.2.7 Axis Group Stop

The axis group calls MC_GroupStop for halt. Only when the current axis group state is in the GroupStandStill or GroupSynchronizeMotion state can MC_GroupStop be enabled successfully. When pulled up successfully, the axis group status is set to GroupStopping.

The example of use is shown in the following figure.

K310 ↓ ⊨	I† -	(DFLT	1000	D310]
M310 → ↓ ├		(DFLT	1000	D312]
M310						1
			Execute	MC_GroupStop		
					Done	M311
					Busy	M312
					Active	—M 313
		0—	AxesGroup		CommandAborted	
		D310-	Deceleration		Error	 #1315
		D312—	Jerk		ErrorID	D314
	₩310 ₩310	H H H H H H H H H H H H H H H H H H H	↑ [M310 		Image: Milling of the second seco	M310 Image: Constraint of the second se


Note:

- You need to pull the function block low to clear the GroupStopping state and switch to the GroupStandStill state. GroupStop can interrupt the running GroupHalt, but it cannot interrupt GroupImmediateStop.
- MC_GroupStop can be pulled up again to interrupt itself, but when multiple MC_GroupStop run with the same axis, the first MC_GroupStop that is successfully pulled up is valid, and the latter will report an error.

13.2.8 Axis Group Immediate Stop

The axis group calls MC_GroupImmediateStop for halt. Only when the current axis group state is in the GroupStandStill or GroupSynchronizeMotion state can MC_GroupImmediateStop be enabled successfully. When pulled up successfully, the axis group status is set to GroupStopping.

The example of use is shown in the following figure.




Note:

- If you need to pull the function block low to clear the GroupStopping state and switch to the GroupStandStill state. MC_GroupImmediateStop can interrupt the running GroupStop, GroupHalt.
- MC_GroupImmediateStop cannot be pulled up again to interrupt itself. When multiple blocks call the same axis group, only the first block takes effect, and the following ones will report an error.

13.2.9 Axle Set Speed regulation

The axis group calls "MC_GroupSetOverRide" for speed regulation, and if the current axis group status is GroupStandStill or GroupSynchronizeMotion, the module can complete the output of Done signal. After being pulled up successfully, the current interpolation speed will change to the target speed of speed regulation. If the parameter value of MC_GroupSetOverRide is modified online, the interpolation speed will change in real time. If MC_GroupSetOverRide is pulled down, the original interpolation speed will be restored.

The example of use is shown in the following figure.




Note: At present, when multiple function blocks of MC_GroupSetOverRide call an axis group number, only the first block takes effect, and the later ones will report an error.

13.2.10 Axis Group Interrupt Mechanism


The interruption mechanism of axis group is that the resultant speed is unchanged after interrupt, while the speed of single axis may jump to a certain extent. Here, a linear interpolation is taken as an example to illustrate.

1. Default: The resultant speed is unchanged. If the resultant speed direction changes, a single-axis speed jump occurs:



Note: At time T1, the linear interpolation was interrupted, and it can be seen that there was no jump in the "resultant speed" at T1;At T1, both the "x-axis speed" and "y-axis speed" experienced a jump. If a single axis needs to undergo reverse motion,Then the speed of the axis will undergo a reverse jump from positive to negative.

2. In the case where the single axis moves in reverse after interruption, a switch "Interrupt deceleration to zero" is provided in the "AXISGROUP>Parameter setting" panel. After the user selects this option, the single axis speed will be decelerated to zero first during interruption, and then it will be accelerated to the new target speed in reverse:



Note: At time T1, the function block needs to be pulled up again to interrupt itself, which is point B, and the y-axis needs to run in the opposite direction because the "interrupt deceleration to zero" is selected. Here, the y-axis and x-axis first decelerate to zero together (as shown by the dashed arrow between T1 and T2), then accelerate from T2 to the new target position, so that there is no speed jump during the speed change process.

14 Electronic Cam Function

14.1 Brief Introduction of Electronic Cam


The electronic cam essentially indicates the movement of the axis following the master axis, and the movement relationship between the master and the slave axes can be expressed by the key point data of the cam table or the electronic gear ratio.

- The electronic cam table can be used to establish the data of up to 361 key points. With the electronic gear ratio, there is only a fixed proportional relationship between the master and slave axes.
- If electronic gears are used, only the numerator and denominator of electronic gear ratio need to be set instead of the cam table data. If electronic cam is used, it is necessary to set the data of electronic cam table first.
- The programming software can configure up to 16 cam tables, and 8 electronic cams can be used at the same time in the program, and each cam table has up to 361 key points.
- In the process of cam execution, the cam table is switched online by instruction trigger.


14.2 Software Configuration

14.2.1 Overview

Choose "Project manager" > "Setting", and right-click on "Electronic cam" to add the electronic cam table.



The left side of the cam table interface is a parameter point editing area, and the right side is a graphic editing area.



14.2.2 Cam Node Setting

Users can set cam nodes in the parameter point editing area according to application requirements.

By clicking "+" in the insert option you can add a cam node data and edit the related data. You can also select the specified node data and click "-" in the delete option to delete the node.


Master length: 360.00 Export file Set the maximum phase of the master								
Slave range: -500.00 - 500.00 Import file								
Master Pos Slave Posi Speed Shape Insert Deletid								
1		0.00	DIAVE	0.00	-	Linear	TUSEL	Dererit
2		D. OO	36	50. OO		Five time	+	

🖉 Note:

- The master axis position and slave axis position of the first point default to 0 and cannot be changed.
- The master axis phase is arranged in ascending order.
- The last point of the master axis determines the maximum period of the master axis, so there is no need to set the period separately.

14.2.3 Cam Curve Setting

Users can set cam curves in the graphic editing area according to the actual application requirements, including position, speed ratio and acceleration ratio curves.




🖉 Note:

- The position curve moves the key points of the cam up and down, left and right, the speed ratio curve can only move up and down, and the acceleration ratio curve is not allowed to be changed.
- The last point is only allowed to be dragged up and down. If you need to change the size left and right, you can manually modify the master axis length.
- In the three coordinate systems, click on the line segment of two key points in any coordinate, and the line segment of two key points in the three coordinate systems is displayed in bold.

14.2.4 Import and Export


A single cam table can be exported/imported.

Choose the specified electronic cam, click export file, import file to import/export electronic cam in "txt" file format.




14.2.5 Call Instruction

Every time a user builds a cam table, the software background will assign a system variable to represent the cam table. The status of cam table can be monitored in PLC program and can be used as the parameter of MC_CamIn and other instructions.



14.3 State Machine



The state machine is described as follows:


State	Function description
Disabled	Disabled state
ErrorStop	Fault stop state
Standstill	Enabled state
Homing	State of returning to home
Stopping	Stopped state
Discrete Motion	Discrete motion state
Continuous Motion	Continuous motion state
Synchronized Motion	Synchronized motion state

Conversion	Conversion Condition
1	When the fault detection logic of the axis detects a fault, it immediately
1	switches to this state.
2	When the axis has no fault and MC_Power energy flow is OFF
2	When MC_Reset is called to reset axis failure and MC_Power energy flow
3	is OFF
4	When MC_Reset is called to reset axis failure and MC_Power energy flow
4	is ON
5	When MC_Power energy flow is ON and the output flag Status is ON
C C	When MC_Stop(MC_ImmediateStop).Done=ON and the energy flow of
6	the graphic block is OFF

14.4 Electronic Cam Operation

14.4.1 Gear Action

14.4.1.1 Basic Block Diagram



14.4.1.2 Function Description

The types of gear action master axis and slave axes are as follows:

- Master axis: fieldbus servo axis, local pulse axis, local encoder axis
- Slave axis: fieldbus servo axis, local pulse axis

Gear action function description:

- 1. Gear action is started by MC_GearIn instruction and unsynchronized by MC_GearOut instruction.
- 2. After the action is started, the speed obtained by multiplying the master axis speed by the gear ratio is taken as the target speed, and the acceleration and deceleration operation is carried out on the slave axis.
- 3. Before reaching the target speed, the phase is called Catching Phase, and after reaching it, the phase is called InGear Phase.
- 4. Gear action is executed by setting the gear ratio between master and slave axes.
- 5. When the gear ratio is positive, the slave axis runs in the same direction with the master axis; When it is negative, the slave axis runs in the opposite direction of the master axis.
- 6. Please refer to the instruction MC_GearIn in the Instruction Manual for details.

14.4.1.3 Example

Establish two new fieldbus servo axes, and the second axis perform gear action following the first axis at the gear ratio of 1:1.

The operating steps are as follows:


The operating steps are as follows:


Step 1 In the new project, establish two fieldbus servo axes, one is the master axis and the other is the slave axis.

Of the two fieldbus servo axes, Axis_0 is the master axis and Axis_1 is the slave axis.


In both servo drivers, bind INVT_DA200_171 to Axis_0 and INVT_DA200_171_1 to Axis_1.









Step 3 Call MC_Jog to control the forward and reverse motion of the master axis.



Step 4 Call MC_GearIn to execute the gear following action at the gear ratio of 1:1.




Step 5 Call MC_GearOut to touch the gear action.



14.4.2 Cam Action

Cam action means that the slave axis moves synchronously with the position of the master axis according to the cam table

14.4.2.1 Basic Block Diagram




14.4.2.2 Function Description

The master axis and slave axis types applicable to cam action are as follows:


- Master axis: fieldbus servo axis, local pulse axis and local encoder axis.
- Slave axis: fieldbus servo axis, local pulse axis.
- 1. Start the cam action or change the cam table through MC_CamIn, and cancel cam action with MC_CamOut.

2. The typical cam structure is shown in the following figure. The master axis rotates periodically, and the slave axis reciprocates in one direction under the control of the master axis.



The electronic cam just imitates this structure, where an axis is chosen as the master axis with the other axis as the slave axis, and both of them move synchronously according to the set cam curve.

3. Cam Curve



4. Cam table

The cam table is a two-dimensional coordinate system, in which the abscissa represents the phase of the master axis and the ordinate represents the displacement of the slave axis. Some key points are set in the coordinate system, and each two key points are connected with set curves (such as straight lines and quintic curves) to form a cam curve.

Phase	Shift
0	0
80	30
160	50
240	20
360	0

Note: Please refer to the instructions MC_CamIn and MC_CamOut in the Instruction Manual for details.

14.4.2.3 Example

Axis_0 serves as the master axis of the cam, and Axis_1 serves as the slave axis that follows Axis_0 to perform cam action.

The operating steps are as follows:


Step 1 Create a new project, and establish two fieldbus servo axes, one as the master axis and one as the slave axis.

Of the two fieldbus servo axes, AXIS_0 is the master axis and AXIS_1 is the slave axis.


In both servo drivers, bind INVT_DA200_171 to Axis_0 and INVT_DA200_171_1 to Axis_1.




- Step 2 Create a new cam table.
- Step 3 Call MC_Power to control the master and slave axes enable.




Step 4 Call MC_Jog to control the forward and reverse operation of the master axis.



Step 5 Call MC_CamIn to perform the cam action.



Step 6 Call MC_CamOut to cancel the cam action.



14.4.3 Cam Table

14.4.3.1 Brief Introduction of Cam Table

- 1. In the cam function module, a pair of data composed of master axis phase and slave axis displacement is defined as cam data, and the combination of multiple cam data is defined as cam table.
- 2. The phase and displacement values of the cam data in the cam table are expressed as relative quantities starting from the starting point "0.0".
- 3. In the cam action, the displacement of the slave axis is calculated according to the phase of the master axis and the set curve type, so as to control the action of the slave axis.
- 4. After creating the cam table through the cam editor of Auto Station Pro, the cam data in the cam table can also be changed through MC_GenerateCamTable in the user program.


14.4.3.2 Specification of Cam Table

When creating a cam table, the user should follow the following specifications:

Item	Description
Total number of cam key points supported by each cam table	361
Total number of cam tables supported	16
Rules of switching cam table in cam	Call MC_CamIn to switch the cam table, which will take effect
action	on the next cam cycle
Read and write of cam data	View cam table status and key point data by system variables under the name of cam table. You can directly modify the cam key point data in the cam table, and make the changes become effective through MC_GenerateCamTable, and the cam will run according to the new cam table in the next cam cycle.

14.4.3.3 Create a Cam Table

Cam table variables can only be created in the background. Every time a cam table is added in the background, a cam table variable is created by default. And enter the ID number of the cam table for CamTable.



14.4.3.4 Switching Cam Table


In the process of cam execution, the cam table can be replaced by triggering MC_CamIn. After that, the cam table is in the buffer state, and the buffered cam table will take effect in the next cam cycle.

Note: Only one cam table can be buffered. If multiple MC_CamIn instructions are repeated continuously, the first triggered cam table will be overwritten by the later triggered cam table. The following two instructions are shown:

Step 1 M100 is triggered first. After the instruction detects that the cam parameters are set correctly, M104(Busy) output becomes valid, Axis_1 will start moving according to the curve set by CAM0, and M105(Active) output becomes valid. When M110 is triggered before the end of a cam cycle, the cam table CAM1 is in a buffer state and the M113(Busy) output is active.

Step 2 When Axis_1 finishes the first cam cycle, the first cam instruction is interrupted,

M106(CommandAborted) output is valid, Axis 1 starts to move according to the cam curve set by CAM1, and M114(Active) output is valid.



14.4.3.5 Modify Cam Table Data

The cam data can be modified temporarily with the following methods:

Create a new cam node array in PLC program, and copy the values in the cam node array to the cam table with MC_GenerateCamTable, which are executed in the next cam cycle.

Cam	Tab	ام ۵
Cam	Tab	СЛ

Phase

0

50

90

130

200

0

Cam Table A

le A	Cam Table A				Cam nod	le array	
ement		after repl	acement	cr	eated in P	LC prograi	m
Shift		Phase	Shift		Phase	Shift	
0		0	0		0	0	
40		30	40	Through MC_Generate	30	40	
60		70	80	CamTable copy	70	80	
30		100	120		100	120	
0		240	200		240	200	
0		360	0		360	0	

before replace

	Variable Name	Data Type	Initial Value	Power Down
1				
2				
3	📮 CamNode	_stru_CAM_NOI	0	No Hold
4	🕀 CamNode[0]	_stru_CAM_NOI	0	No Hold
5	fPhase	REAL	0	No Hold
6	fDistance	REAL	0	No Hold
7	fVel	REAL	0	No Hold
8	fAcc	REAL	0	No Hold
9	iCurve	INT	0	No Hold
10	🕀 🗄 CamNode[1]	_stru_CAM_NOI	0	No Hold
16	🖽 CamNode[2]	_stru_CAM_NOI	0	No Hold
22	🕀 CamNode[3]	_stru_CAM_NOI	0	No Hold
28	🖃 CamNode [4]	_stru_CAM_NOI	0	No Hold
M117 ——↓ ⊢		MC_Gene Execute	rateCamTable	
				Done-M18
			EndPoint	Index —D20
		E	rrorNodePoint	Index — D22
				Busy-
	0-	-CamTable	A	ctive — M19
	CamNode[0]-	-CamNode	CommandAb	orted -
	No de Num-	-NodeNum		Error -


Examples are as follows:

Note: The CamNodeNum above is used to specify the number of nodes in the cam table in the cam node array created in the PLC program.

14.4.4 Master Axis Phase Compensation


Master axis phase compensation is to perform the phase compensation function to the running master axis (viewed from the slave axis) which is executing instructions.

By starting MC_Phasing, the phase compensation of synchronization control instruction can be carried out. MC_Phasing can specify parameters such as phase compensation amount, target velocity, acceleration, jerk and so on.



14.4.5 Motion Superposition

By calling MC_MoveSuperImPosed, the motion superposition function of the motion control axis is realized, and the motion of the axis will not be interrupted during the motion superposition process.



14.4.6 How to Handle Axis Configuration Parameters in Cam or Gear

Parameter Setting	Processing Method
Gear ratio setting	The master-slave axes of cam and gear support the modification of
Geal fatio setting	gear ratio, which is set in the "Transmission ratio" interface.
	• Cam and gear support soft limit in linear mode, and slow down
Limit Processing	and stop after reaching the limit
Linit Flocessing	• Cam and gear support hard limit in linear mode and circular mode,
	and stop immediately after reaching the hard limit
	When the instruction parameter input is abnormal, the slave axis will
Axis error deceleration	switch to the fault state and will decelerate as per the fault
	deceleration, and then enters the fault shutdown state
	• Cam instructions are not limited by the maximum speed of axis
Speed limit	• The gear is limited by the maximum speed of the axis. After the
Speed limit	maximum speed of the gear exceeds the maximum speed limit, it
	runs at the maximum speed.
	 MC_CamIn is not limited by the maximum acceleration
Acceleration limit	• MC_GearIn, MC_CamOut and MC_GearOut are limited by the
Acceleration	maximum acceleration, and run at the maximum acceleration
	(deceleration) beyond the maximum acceleration

15 Memory Formula Management

15.1 Overview

Memory management includes custom variables and soft element variable memory management. By obtaining variable memory data at a certain time as data basis for debugging and analysis, variable memory data at a certain time can also be saved as formula data for debugging parameters of different processes or formula parameters of multiple links of the same process.

Specific application scenarios are as follows:

- When the program is abnormal, the current variable memory data can be obtained to analyze the problem.
- Multiple memory data parameters of variables at a certain time are obtained and saved as formula parameter files for other machines to use (to be implemented).
- Real-time monitoring of the current value of all data in the current variable table.
- Synchronization of the variable memory data parameters at the current time to the initial value.
- When commissioning different processes for a set of programs, different formulas of parameter data can be saved (to be realized).
- When commissioning different links of the same process, different sets of formula parameters can be saved (to be realized).

15.2 Power-down Variable Keeping

15.2.1 Range of Power-down Variable Keeping

Soft elements M, S, D and R support power-down keeping of variables within a fixed range which cannot be modified, as shown in the following table:

Element Type	Name	Range of Keeping
M (0–32767)	Auxiliary	M1000-M32767
	relay	
S (0–4095)	Status relay	S1000-S4095
	Word	D1000 D227C7
D (0–32767)	element	D1000-D32767
	Word	D1000 D227C7
R (0–32767)	element	R1000-R32767
	Custom	Maximum 128k,
Custom variable (internal private address, separated from	Custom	depending on user
non-power-down keeping custom variables)	Variables	settings

Custom variables can be set as power-down keeping or non-power-down keeping according to users' needs. It supports users to keep up to 128k variables at power-down. The custom variables shown below

are selected as being kept or not being kept in the power-down keeping option.

	Variable Name	Data Type	Initial Value	Power Down	Comments	Element Ad	Current Valu	Value 1
1	test1	WORD	1	Hold			0	
2	test3	REAL	2.5	Hold			0.000000	
3	test4	WORD	0	Hold			0	
4	test2	INT	3	No Hold			0	

15.2.2 Data Retention File Upload and Download


When you need to transfer the power-off retention data from one PLC to another, or when you need to save the current power-off retention data, you can use the data retention file upload and download function.

Principle: The data of the power-off retention elements and custom retention variables can be uploaded and saved as a file on the computer, and when re-downloaded, it will refresh the current values of the data retention elements.

The operating steps are as follows:

Step 1 Connect to the PLC through the Auto Station Pro host controller communication.


Step 2 Select "Toolbar" > "PLC" > "PLC Data Hold File" > "Upload" in order.



Step 3 Choose an appropriate location to store the data retention file.

Save			×
\leftrightarrow \rightarrow \checkmark \uparrow	→ This PC → Documents	✓ Č Searc	h Documents 🔎
Organize 🔻 🛛 Ne	ew folder		☷ ▾ ?
📌 Quick access	▲ Name	No items match your se	Date modified Type
➡ Downloads i Documents i Pictures			
Music			
a OneDrive			
💻 This PC	~ <		
File name:	1		~
Save as type:	DC(*.DC;)		~
 Hide Folders 			Save Cancel

Step 4 Use the PLC data retention file download function on another PLC.



15.3 Memory Management of Custom Variable Table

15.3.1 Expand and Fold Complex Type Variables

Custom variable table contains complex type variables, namely arrays and structs. The system supports expanding and folding the sub-members of arrays and structs. Sub-members can only be edited for initial value, comment and data value column, and the values in other columns cannot be edited.

	Variable Name	Data Type	Initial Value	Power Down	Comments	Element Ad	Current Valu	Value 1
1	teset3	WORD	0	Hold				
2	teset1	BOOL	ON	No Hold				
3	📮 teset2	INT[5]	OFF	No Hold	test2			
4	teset2[0]	INT	3	No Hold	static0			
5	teset2[1]	INT	4	No Hold	staticl			
6	teset2[2]	INT	5	No Hold				
7	teset2[3]	INT	6	No Hold				
8	teset2[4]	INT	7	No Hold				

15.3.2 Monitor Variables

The variable table supports the monitoring function. Click "Download and monitor" in the user project, and the system will monitor all the variables displayed on the current variable table page without adding additional variables to the monitoring table.

	Element Name	Data Type	Display Fo:	Current Value	New Value
1	 teset4	INT	Decimal	16948	
2	 📮 teset2	INT[5]	Decimal		
3	teset2[0]	INT	Decimal	3	
4	teset2[1]	INT	Decimal	4	
5	teset2[2]	INT	Decimal	5	
6	teset2[3]	INT	Decimal	6	
7	teset2[4]	INT	Decimal	7	

15.3.3 Edit Variable Initializations and Comments

Users can edit the initial values and comments of each member data directly after expanding the variable table, and can also define them in the program custom variable box, which is equivalent to each other.

TS600 Series Programmable Logic Controller Programming and Application Manual

	Variable Name	Data Type	Initial Valu	Power Down	Comments	Element Ad	Current Valu	Value 1	Value 2
1	teset5	REAL	3.5	No Hold	test5				
2	teset4	INT	0	Hold	test4				
3	teset3	WORD	0	Hold					
4	teset1	BOOL	ON	No Hold					
5	📮 teset2	INT [5]	OFF	No Hold	test2				
6	teset2[0]	INT	3	No Hold	static0				
7	teset2[1]	INT	4	No Hold	static1				
8	teset2[2]	INT	5	No Hold					
9	teset2[3]	INT	6	No Hold					
10	teset2[4]	INT	7	No Hold					

15.3.4 Switch and Display Binary System

When managing the custom variable table, the user can switch to the display of decimal, binary and hexadecimal.

	Element Name	Data Type	Display Fo:	Current Value	New Value
1	 teset5	INT	Binary	2#100001	
2	 teset4	INT	Hexadecima	16#0	
3	 teset3	INT	Decimal	0	
4	 teset1	INT	Decimal	13	
5		WORD	Decimal		

15.4 Memory Management of Soft Elements

15.4.1 Operation Interface

The soft element table contains two functions: comments and memory management, and the operation interface is as shown in the following figure.

_SYS_INFO ^	XY	м в т с	DRZT	С						
▼ 🗄 Global variable table	0	Jump	Data 0	. 0	BOOL V	⊖ Binary ● D	ecimal O Hexade	ecim		
Struct										
	No.	Variable Name	Data Type	Initial Value	Current Value	🗹 Data Value 1	Data Value 2	Data Value 3	Data Value 4	Connents
Software element list	1	XO	BOOL							
C language global varia	2	X1	BOOL							
<u> </u>	3	X2	BOOL							
Global variable table 1	4	ХЗ	BOOL							
	5	X4	BOOL							
Global variable table 2	6	26	BOOL							
	7	16	BOOL							
-	8	27	BOOL							
System Block	9	X10	BOOL							
EXP-CARD	10	X11	BOOL							
CARD	11	X12	BOOL							
Expansion module conf	12	X13	BOOL							
	13	X14	BOOL							
The Electronic cam	14	115	BOOL							
Motion control axes	15	X16	BOOL							
Motion control axes	16	X17	BOOL							
♦ ■ Axis group setting	17	X20	BOOL							
	18	X21	BOOL							
🗳 EtherCAT	19	X22	BOOL							
COM1	20	X23	BOOL							
	21	X24	BOOL							
COM2	22	X25	BOOL							
	23	X26	BOOL							
Ethernet1	24	127	BOOL							

- 1. Switching between soft elements can operate different soft element memories and comments.
- 2. Used to batch modify the data type of the current page, simply by entering the element numbers at the beginning and end to be modified through two edit boxes respectively.
- 3. Select the data type to change in the drop-down box. For example, to switch to D element, enter 50 and 100 to indicate the data from D50 to D100, and then click the drop-down box to select REAL, then the data type of D50, D52, D54 … D100 is modified to REAL. (Note: REAL and DINT are 32 bits, so they need 2 elements).
- 4. It is a jump function, for example, when switching to D element, enter 1000, click jump or press Enter, and the page will automatically jump to the position of D999.

Note: In all input boxes, for X and Y elements you can only input octal numbers, and only a 5-digit number at maximum is allowed. If the input data exceeds the total number of elements, it will jump to the last.

5. It is to modify the display format of the data value column and the current value column. For example, clicking the hexadecimal radio box will switch all data to hexadecimal display.

15.4.2 Editing Rules for Data Types


- 1. Bit elements (X, Y, M, S, B) are only of BOOL type, and their data values can only be selected as "ON/OFF".
- 2. Word element can be of three data types: INT, DINT and REAL, in which INT is 16 bits, DINT and REAL are 32 bits.
- 3. When the data type is 32 bits, it takes up 2 word elements, so after selecting REAL and DINT types, the data value in the next row is automatically emptied, and the data type and data value columns are not editable, and the data type columns in the previous row are not editable. When reading memory, the data types are REAL and DINT, and the next row of data values is not read.

16 Expansion Module

16.1 TS600 Series Host Local Expansion Module

16.1.1 Summary of Expansion Module

TS600 can have up to 16 local expansion modules, and access the local extension through module configuration. The hardware configuration of TS600 connected to local expansion module is shown in the following figure.



The supported local expansion module models are shown in the following table:

Product Name	Description
FL1001-1600DI	16-channel digital input module
FL1002-3200DI	32-channel digital input module
FL2201-0008DR	8-channel digital relay output module
FL2102-0016DN	16-channel digital transistor output module-NPN
FL2002-0016DP	16-channel digital transistor output module-PNP
FL3003-4AD	4-channel analog input module
FL4003-4DA	4-channel analog output module
FL3101-4PT	4-channel input thermal resistance temperature detection
FLSI0I-4P1	module
FL3201-4TC	4-channel thermocouple temperature detection module
FL2003-0032DP	32-point digital source output module
FL2103-0032DN	32-point digital sink output module
FL5005-1616DP	16-input and 16-output source module
FL5105-1616DN	16-input and 16-output sink module
FL6121-1EI-DF	One-channel incremental differential input module
FL6112-2EI	Two-channel incremental encoder input module
FL6002-2ES	Two-channel absolute encoder input module

16.1.2 Expansion Module System Variables

Name	Data type	Description
_sExtModule.CfgNum	INT	User-configured module number
_sExtModule.ActNum	INT	Actually mounted module number
_sExtModule.sExtSlot[n].CfgType	INT	nth expansion module User-configured type
_sExtModule.sExtSlot[n].ActType	INT	nth expansion module Type of actual mount
_sExtModule.sExtSlot[n].Error	BOOL	nth expansion module Error flag
_sExtModule.sExtSlot[n].Disable	BOOL	nth expansion module Disable flag
_sExtModule.sExtSlot[n].SWVersion	DINT	nth expansion module Software version
_sExtModule.sExtSlot[n].LGVersion	DINT	nth expansion module Logic device version


- _sExtModule.ActNum gives feedback on how many expansion modules the user actually mounts.
- _sExtModule.sExtSlot[n].ActType feeds back what type each mounted module is.
- _sExtModule.sExtSlot[n].CfgType feeds back what type of module each user configures.

When configuration mismatches occur, you can check whether the actual mounted and the configured ones are consistent.

• The _sExtModule.sExtSlot[n].Error variable feeds back warnings and errors in the module, and the specific error types can be fed back from the system variable _sCurErrList.

16.1.3 Expansion Module Configuration

1. Double-click "Setting" > "Expansion module configuration" in Auto Station Pro.



2. Switch to the expansion module configuration interface, double-click the module on the right side to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.


🖥 MAIN 🛛 🙀 Expansio	n module configu	ration	•													٩	⊳ ×	Instruction tree
							I	-			-		-	-				 Right Expansion Modul FL1001-1600D FL1002-3200D FL201-0008DR FL202-0016DP FL202-0016DN FL2003-4AD FL4003-4DA FL3103-4PT FL302-4TC
TS635	4AD	4DA	4PT	4TC											4AD	4DA		FL2003-0032DP FL2103-0032DN
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		FL5005-1616DP
<													l				~	FL5105-1616DN
Slot No. Model No.	IO Mapping		_				-										>	FL6121-1EI-DF
D TS635 FL3003-4AD	XO-X17; YO-Y17																	FL6112-2EI
FL3003-4AD FL4003-4DA																	~	FL6002-2ES

16.1.4 Expansion Module Configuration

16.1.4.1 Digital Input Module

The digital input modules include FL1001-1600DI and FL1002-3200DI. As local expansion modules, the specific method to use is as follows:

Step 1 In the module list, select the module you want to add, double-click the module to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.



Step 2 When the local digital input expansion module is connected to the main module, double-click the module to pop up the module configuration interface, where you can configure the filter parameters and IO mapping according to the actual demand. If the mapping variable is not manually configured by the user, the input X port number on the expansion module is followed by the X port number on the main module or the previous digital input module, and is numbered in turn.

8	0 11			
Expansion Module 16	500D			×
Parameter Setting	IO Mapping			
✓ Module enable				
Filter parameter 1		(10us)		
Filter parameter 2	2 1000 •	(10us)		
			ОК	Cancel
			UK	
Expansion Module 16	500D			×
Parameter Setting	IO Mapping			
Channel Data type	Component (Variable) ma	apping		
CHO BOOL CH1 BOOL	X20 X30			
			ОК	Cancel
			UK	Cancer

🖉 Note:

- Every 8 points in the input module share a filter parameter, the unit of this filter parameter is 10μs, and 1,000 means 10ms.
- The subscript of the IO mapping bit element needs to be a multiple of 010 (octal), for example, X20, X30, X110.

Step 3 You can program with mapped variables in your program.

16.1.4.2 Digital Output Module

The digital output modules include FL2201-0008DR, FL2102-0016DN, FL2002-0016DP, FL2103-0032DN and FL2003-0032DP. As local expansion modules, the specific method to use is as follows:

Step 1 In the module list, select the module you want to add, double-click the module to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.

Expansion Module

TS600 Series Programmable Logic Controller Programming and Application Manual

MAIN	V 📑 Expansion	module configuratio	n *											4	⊳ ×	Instruction tre	e	
100	TS635						-					-	-	-		•0	000000000000000000000000000000000000000	ht Expansion Module FL1001-1600D FL1002-3200D FL2201-0008DR FL2002-0016DP FL2102-0016DN FL3003-4AD FL4003-4DA FL4003-4DA FL3103-4PT FL3203-4TC FL2003-0032DP
		1	2 3	4	5	6	7	8	9	10	11	12	13	14	15		0	FL2103-0032DN FL5005-1616DP
c															>		U	FL5105-1616DN
Slot No.	Model No.	IO Mapping													^	1	0	FL6121-1EI-DF
)	TS635	X0-X17; Y0-Y17															0	FL6112-2EI
	FL2201-0008DR	¥20-¥27															0	100112-201
	FL2002-0016DP	¥30-¥37; ¥40-¥47															0	FL6002-2ES

Step 2 When the local digital output expansion module is connected to the main module, double-click the module to pop up the module configuration interface, where you can configure the module type, post-stop output method and IO mapping according to the actual demand. If the mapping variable is not manually configured by the user, the input Y port number on the expansion module is followed by the Y port number on the main module or the previous digital output module, and is numbered in turn.

Expar	nsion Mo	dule 00	08DR			×
Pa	rameter S	Setting	IO Mapping			
	Module e	nable	Module type	Relay type	\sim	
S	top outp	ut mode	9			
	Channel	-	Output Mode	Output Pre	Dropdown selection	mode
	СНО	BitO	Output hold 🗸 🗸		bropdown screetron	moue
	СНО	Bit1	Output hold			
	СНО	Bit2	Output clear	_		
	СНО	Bit3	Output preset			
	СНО	Bit4	Output hold			
	СНО	Bit5	Output hold			
	CHO	Bit6	Output hold			
	СНО	Bit7	Output hold			
					ОК Са	ncel

Exp	pansion	Module 00	08DR						×
	Paramet	er Setting	IO Mapping						
		Data type	Component (/ariable)	mapping				
4	СНО	BOOL	¥20						
I									
						(ОК	Ca	ancel

🖍 Note:

- The subscript of the IO mapping bit element needs to be a multiple of 010 (octal), for example, Y20, Y30, Y110.
- After configuring the post-stop output mode, the PLC will output according to the configured STOP output mode and STOP output preset value after entering the STOP state.

Step 3 You can program with mapped variables in your program.

16.1.4.3 Analog Input Module

The analog input module includes FL3003-4AD. As local expansion modules, the specific method to use is as follows:

Step 1 In the module list, select the module you want to add, double-click the module to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.



Step 2 When the local analog input expansion module is connected to the main module, double-click the module to pop up the module configuration interface, and configure the channel setting, conversion mode and IO mapping according to the actual demand.

Expansion Module

TS600 Series Programmable Logic Controller Programming and Application Manual

Expansion Module 4A	D			>
Parameter Setting	IO Mapping			
✓ Module enable Channel 0 ✓ Channel enable	Disconnect detection	Overlimit detection	Over-range detection	Enhanced filtering
	0~5V (0~20000)		Filtering parameter 8	(0~20000)
Channel 1 Channel enable Switching mode	Disconnect detection	Overlimit detection	Over-range detection	☐ Enhanced filtering ★ (0~20000)
Channel 2 Channel enable Switching mode	Disconnect detection	Overlimit detection	Over-range detection	Enhanced filtering
Channel 3 Channel enable Switching mode	Disconnect detection	Overlimit detection	Over-range detection Filtering parameter 8	Chanced filtering Coverage OK Cancel

	eter Setting		_							
Channe!	l Data type	Compon	nt (Va	ariable)	mapping					
HO	INT	D100								
:H1	INT	D102								
H2	INT	D104				 	 	 	 	
снз	INT	D104 D106				 	 	 	 	

🖍 Note:

- Channel Enable: Channel enable disabled for unused channels to save scanning time.
- When the channel interference is serious, the enhanced filtering is preferentially enabled, and then the filtering parameters are adjusted. The larger the filtering parameters, the better the filtering effect and the larger the corresponding lag.
- Disconnection detection is not supported when the switching mode is current mode.
- Overrun detection: When the external sampling signal exceeds ± 25V, the module outputs a warning, the Error of the module is set to 1 in the system variables, and an error code can be read in the system variable error list.
- Overrange detection: When the external sampling signal exceeds the range of the conversion mode, the module outputs a warning, the Error of the module is set to 1 in the system variables, and an error code can be read in the system variable error list.

Step 3 You can program with mapped variables in your program.

The correspondence between the mapping and the actual input analog value is as follows:

Input Type	Enter the Rated Range	Rated Corresponding Digital Quantity				
	-10V-10V	-20000-20000				
Analogyaltagainnut	0V-10V	0-20000				
Analog voltage input	-5V–5V	-20000-20000				
	0V-5V	0-20000				
	-20mA–20mA	-20000-20000				
Analog current input	0mA-20mA	0–20000				
	4mA–20mA	0–20000				

16.1.4.4 Analog Output Module

The analog output module includes FL4003-4DA. As local expansion modules, the specific method to use is as follows:

Step 1 In the module list, select the module you want to add, double-click the module to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.



Step 2 When the local analog output expansion module is connected to the main module, double-click the module to pop up the module configuration interface, and configure the channel setting, conversion mode and IO mapping according to the actual demand.

· · · ·	ion Module 4 meter Setting	IDA IO Ma	nnina		×
_	odule enable	10 110	pp ng		
Cha	annel 0			Channel 1	
	🗹 Channel en	able	Output fault detection	🗹 Channel enable 🗌 Ou	utput fault detection
	Switching mo	de	0~5V (0~20000) V	Switching mode 4~20	0mA (0~20000) 🛛 🗸
	Output state a	fter sto	pping	Output state after stopping	
	Hold output	t		Hold output	
	Output clea	ar		O Output clear	
	Output pre	set valu	e 0 (0~20000)	O Output preset value 0	(0~20000)
Cha	annel 2			Channel 3	
	Channel en	able	Output fault detection	Channel enable Ou	utput fault detection
	Switching mo		0~5V (0~20000) V		V (0~20000) V
	Output state a	fter sto	pping	Output state after stopping	
	Hold output	t		Hold output	
	Output clea	ar		 Output clear 	
	Output pre	set valu	e 0 (0~20000)	Output preset value 0	(0~20000)
					OK Cancel
Expansi	on Module 4	DA			;
Param	neter Setting	IO Map	pping		
Channe	el Data type	Compon	ent (Variable) mapping		
СНО	INT	D200			
CH1 CH2	INT INT	D202 D204			
СНЗ	INT	D206			

Note:

- Channel Enable: Channel enable disabled for unused channels to save scanning time.
- After configuring the post-stop output mode, the PLC will output according to the configured STOP output mode and STOP output preset value after entering the STOP state.

ОК

Cancel

Step 3 You can program with mapped variables in your program.


The correspondence between the mapping and the actual output analog value is as follows:

Input Type	Rated Output Range	Rated Corresponding Digital Quantity
	-10V-10V	-20000-20000
	0V-10V	0-20000
Analog voltage output	-5V–5V	-20000-20000
	0V-5V	0-20000
Analog ourrent output	0mA-20mA	0–20000
Analog current output	4mA–20mA	0–20000

16.1.4.5 Hybrid Module

The hybrid module includes FL5005-1616DP and FL5105-1616DN. As local expansion modules, the specific method to use is as follows:

Step 1 In the module list, select the module you want to add, double-click the module to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.



Step 2 When the hybrid expansion module is connected to the main module, double-click the module to pop up the module configuration interface. In the "Parameter Setting" interface, configure the "Filter parameter 1," "Filter parameter 2," and "Stop output mode" according to actual needs. In the "IO Mapping" interface, configure the "IO Mapping."

Expansio	n Modu	ule_16	616DN								\times
Paramet	ter Setti	na Ta	O Mapping	a							
		5 -		5				_			
✓ Mod	lule ena	ble	Module	e type	Leack	age type		/			
Filter pa	aramete	r 1	1000		 T 	(10us)					
Filter pa	aramete	r 2	1000		▲ ▼	(10us)					
Stop o	output n	node									
Char	nel Ou	tout	E Output 1	Mode	Out	put Pres					
CH0		t0	Output 1		out	put lie:				^	
CHO	Bi		Output								
CHO		t2	Output								
CHO		t3	Output 1								
CH0		t4	Output 1								
CH0	Bi	t5	Output 1	hold							
CH0	Bi	t6	Output 1	hold							
CH0		t7	Output 1								
CH1		t0	Output 1								
CH1	Bi	t1	Output 1	hold							
								ОК	(Cancel	
Expansio	n Modu	ıle 16	16DN								\times
		-									
Paramet	er Settir	ng IC	O Mapping	9							
Channe1	Data t	vpe	Componen	t mappi	ng		 				
CH0-X	BOOL		X40								
CH1-X	BOOL		X50								
CH0-Y	BOOL		Y40								
CH1-Y	BOOL		Y50								
								ОК		Cancel	

16.1.4.6 Temperature Sampling Module

The temperature sampling modules include FL3101-4PT and FL3201-4TC. As local expansion modules, the specific method to use is as follows:

Step 1 In the module list, select the module you want to add, double-click the module to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.

MAIN Expansion module confi	guration *						4 Þ 🗙 🛙	nstruction tree
								 Right Expansion Module FL1001-1600D FL1002-3200D FL201-0008DR FL2002-0016DP FL2102-0016DN FL2102-0016DN FL3003-4AD FL4003-4DA FL3103-4PT FL3203-4TC
TS635 4	РТ 4ΤС							O FL2003-0032DP
	2 3	4 5	67	8 9 10	11 12 13	14 15 16		O FL2103-0032DN
	2 3	4 5	67	8 9 10	11 12 13	14 15 16		O FL5005-1616DP
<							>	O FL5105-1616DN
Slot No. Model No. IO Mapping								FL6121-1EI-DF
0 TS635 X0-X17; Y0-Y1 1 FL3103-4PT	1							O FL6112-2EI
2 FL3203-4TC								O FL6002-2ES

Step 2 When the local temperature sampling expansion modules are connected to the main module, double-click the module to pop up the module configuration interface, and configure the temperature unit, channel setting, conversion mode and IO mapping according to the actual demand.

rameter setting (Cl	nannei 0 ~ 1							
Module enable	Celsius(°	°C) O Fahrenheit	t(°F)					
Channel_0 Channel enable			Hotline mode	2-wire	03-1	wire	◯ 4-wire	
Filtering parameter	8	▲ (1~255)	Over-range dete		000		0.1.110	
Temperature offset value	0.0	▲ (-204.8~204.7 °C)	Upper limit of ten	nperature	850.0	×	(-200.0~850.0 °	°C)
Switching mode	PT1000	~	Lower limit of ter	nperature	-200.0	*	(-200.0~850.0 °	°C)
Channel_1			_					
Channel enable	8	* (1 255)	Hotline mode	2-wire	⊖ 3- v	vire	O 4-wire	
Filtering parameter	0	÷ (1~255)	Over-range dete	ction				
Temperature offset value	0.0	(-204.8~204.7 °C)	Upper limit of tem	perature	850.0	÷ ((-200.0~850.0 °(C)
Switching mode	PT1000	\sim	Lower limit of ten	nperature	-200.0	÷ (-200.0~850.0 °C	.)
		Parameter setting (Cha	nnel 2 ~ 3) IO Mappin	g			ОК	Cance
ansion Module 4TC arameter setting (Ch] Module enable		_		g			ОК	Cancel
arameter setting (Ch	nannel 0 ~ 1)	_		g			ОК	Cancel
arameter setting (Ch] Module enable Channel_0 🖸 Channel enable	nannel 0 ~ 1)	C) O Fahrenheit (°F)	-			OK	Cancel
arameter setting (Ch] Module enable Channel_0 ☑ Channel enable Filtering parameter	O Celsius(°C	C) ○ Fahrenheit(-			ОК	Cancel
arameter setting (Ch] Module enable Channel_0 🖸 Channel enable	nannel 0 ~ 1)	C) O Fahrenheit (°F)	ion	70.0	. (-270	ОК	Cancel
arameter setting (Ch double enable Channel_0 Channel enable Filtering parameter Temperature offset value	O Celsius(°C	C) ○ Fahrenheit(°F)	ion ature 137	70.0			Cancel
arameter setting (Ch double enable Channel_0 Channel enable Filtering parameter Temperature offset value	Celsius(°C 8 0.0	C) ○ Fahrenheit(°F) Over-range detect Upper limit of temper	ion ature 137			0.0~1370.0 ℃)	Cancel
arameter setting (Ch Module enable Channel_0 ☑ Channel enable Filtering parameter Temperature offset value Switching mode	Celsius(°C 8 0.0	C) ○ Fahrenheit(°F) Over-range detect Upper limit of temper	ion ature 137			0.0~1370.0 ℃)	Cancel
arameter setting (Ch Module enable Channel_0 I Channel enable Filtering parameter Temperature offset value Switching mode Channel_1	Celsius(°C 8 0.0	C) ○ Fahrenheit(°F) Over-range detect Upper limit of temper	ion ature 13 ature -27			0.0~1370.0 ℃)	Cancel
arameter setting (Ch Module enable Channel_0 I Channel enable Filtering parameter Temperature offset value Switching mode Channel_1 I Channel enable	 e Celsius(°C 8 0.0 K type therm 	C) ○ Fahrenheit(°F) Over-range detect Upper limit of temper Lower limit of temper	ion ature 13; rature -27 on		. (-270	0.0~1370.0 ℃)	Cancel


Note:

- Channel Enable: Channel enable disabled for unused channels to save scanning time.
- The upper and lower temperature limits are related to the sensor type, and the corresponding upper and lower temperature limits need to be adjusted after the conversion mode is configured.
- The temperature offset value is used to correct the measurement error caused by the internal heating of the module.
- The wiring of PT modular thermal resistance needs to be consistent with the actual wiring mode, otherwise the measurement will have errors.
- Step 3 In the program, the mapped variables can be used for programming, and the values measured by the temperature measurement module are floating-point numbers.

16.1.4.7 Counter module

The counter modules include FL6121-1EI-DF, FL6112-2EI and FL6002-2ES. As local expansion modules, the specific method to use is as follows:

Step 1 In the module list, select the module you want to add, double-click the module to automatically expand it on the expansion rack, or drag it to the expansion rack with the left mouse button.



Step 2 When the counter expansion modules are connected to the main module, double-click the module to pop up the module configuration interface, and configure the parameters and IO mapping according to the actual demand.

Parameter Setting IO Mapping Counter Configuration Parameters //B phase quadruple Channel Mode Configuration //B phase quadruple Frequency Measurement Period //B phase quadruple DI0 edge latch count value enable Disable Compare Consistent output pulse withs Ims D00 Compare Output Mode Compare consistent outputs D01 compare Output Mode S D01 compare Output Mode S A/B/Z port filtering parameters 5 S x10ns (1~65535) D1 port filter parameters 5 S x10ns (1~65535) Resolution 10000	Expansion Module FL6121-1EI-DF		×	< Expansion Module	FL6121-1EI-DF		 		×
Counter Configuration Parameters	Parameter Setting IO Mapping			Parameter Settin	IO Mapping				
Channel Mode Configuration //B phase quadruple //B phase quadruple Control word Control word Control word Control word Diff D10 edge latch count value enable Disable Control word Diff Control word Diff Compare consistent output pulse with Ims Control word Diff Control word Diff D00 compare Output Mode Compare consistent outputs Control word Diff Control word Diff A/B/Z port filtering parameters 5 x10ns (1~65535) Stores Stores Stores		Modu	ule Enable			Data tona	 -1		
Channel Mode Configuration A/B phase quadruple IDT IDT IDT Frequency Measurement Period 20ms IDT IDT IDT D10 edge latch count value enable Disable IDT IDT IDT Compare consistent output puise widths IDT IDT IDT IDT D00 compare output Mode IDT IDT IDT IDT D00 compare output Mode Compare consistent outputs IDT IDT Compare consistent output puise widths IDT IDT IDT D00 compare output Mode Compare consistent outputs IDT IDT Compare consistent outputs Compare consistent outputs IDT IDT Compare output Mode Compare consistent outputs IDT IDT Compare constent outputs S x10ns (1~65535) IDT DI put filter parameters 5 x10ns (1~65535) IDT	Counter Configuration Parameters						 n		
DI0 edge latch count value enable Disable Counter 1 comparison value DINT D11 edge latch count value enable biable Counter value DINT Compare consistent output pulse widths ims Counter value DINT D00 compare Output Mode Compare consistent outputs Counter value DINT Compare Consistent output Mode Compare consistent outputs Counter latch value 1 DINT A/B/Z port filter parameters 5 x10ns (1~65535) Ims Ims Ims	Channel Mode Configuration	A/B phase quadruple	~						
Dife degle acch count value enable Disable Counter ounting status feedback VORD Dife degle acch count value enable Disable Counter ounting status feedback VORD Compare consistent output pulse widths Ims Counter value D00 Compare Output Mode Compare consistent outputs Diff Opport filtering parameters 5 x10ns (1~65535) DI port filter parameters 5 x10ns (1~65535)	Frequency Measurement Period	20ms	~						
D11 edge latch count value enable Disable Counter value DIIT Compare consistent output pulse widths Ims Counter value DIIT D00 Compare Output Mode Compare consistent outputs Counter value DIIT D01 compare Output Mode Compare consistent outputs Counter value DIIT A/B/Z port filtering parameters 5 x10ns (1~65535) DI port filter parameters 5 x10ns (1~65535)	DI0 edge latch count value enable	Dirable	~						
Compare consistent output pulse widths Ims Compare consistent outputs IIIIT Compare consistent outputs D00 Compare Output Mode Compare consistent outputs Compare consistent outputs DIIIT Compare consistent outputs A/B/Z port filtering parameters 5 x10ns (1~65535) E Ims Ims			-		status feedback		 		
Combine Consider Output Mode Imb Commer consistent outputs Commer consistent outputs D01 Compare Output Mode Compare consistent outputs Commer frequency D000 Compare Consistent outputs A/B/Z port filter parameters 5 x10ns (1~65535) DI port filter parameters 5 x10ns (1~65535)	DI1 edge latch count value enable	Disable	\sim						
D00 Compare Output Mode Compare consistent outputs Compare consistent outputs D01 Compare Output Mode Compare consistent outputs Compare consistent outputs A/B/Z port filtering parameters 5 x10ns (1~65535) DI port filter parameters 5 x10ns (1~65535)	Compare consistent output pulse widths	1ms	~				 		
DD1 Compare Output Mode Compare consistent outputs Compare consistent outputs A/B/Z port filter parameters 5 x10ns (1~65535) DI port filter parameters 5 x10ns (1~65535)	DOD Compare Output Mode	Comment and interest outputs							
A/B/Z port filtering parameters 5 x10ns (1~65535) DI port filter parameters 5 x10ns (1~65535)		Compare consistent outputs	~		y				
DI port filter parameters 5 x10ns (1~65535)	DO1 Compare Output Mode	Compare consistent outputs	\sim	Counter speed		REAL	 		
	A/B/Z port filtering parameters	5 x10ns (1~65	5535)						
Resolution 10000 (1~65535)	DI port filter parameters	5 x10ns (1~65	5535)						
	Resolution	10000 (1~65535)							
				-					
OK Cancel OK Cancel		ок	Cancel				0	K C	ancel

16.2 Basic Operation of Local Expansion Module

16.2.1 Module Enable

1. In the module list, select the module to be enabled, double-click it, and check "Module enable" in the pop-up configuration interface.

xpansion Mo	odule_001	6DN				
Parameter	Setting	IO Mapping				
Module (enable	Module type	Leackage typ	e	\sim	
Stop outp	out mode					
Channel	Output 1	Output Mode	Output Pre			^
СНО	BitO	Output hold				
СНО	Bit1	Output hold				
СНО	Bit2	Output hold				
CHO	Bit3	Output hold				
CHO	Bit4	Output hold				
CHO	Bit5	Output hold				
СНО	Bit6	Output hold				
СНО	Bit7	Output hold				
	Bit7 Bit0	Output hold Output hold				
СНО		-				

2. It will take effect after compilation without error and after the program is successfully downloaded.

16.2.2 Module Disable

1. In the module list, select the module to be disabled, double-click it, and uncheck "Module enable" in the pop-up configuration interface.

pansion Mo	dule_001	I6DN				
Parameter S	Setting	IO Mapping				
Module e	enable	Module type	Leackage ty	pe	\sim	
Stop outp	out mode					
Channel	Output 1	Output Mode	Output Pre			~
СНО	Bi tO	Output hold				
СНО	Bit1	Output hold				
СНО	Bit2	Output hold				
СНО	Bit3	Output hold				
СНО	Bit4	Output hold				
СНО	Bit5	Output hold				
СНО	Bit6	Output hold				
СНО	Bit7	Output hold				
010		Output hold				
CH1	Bit0	Output noia				
	Bit0 Bit1	Output hold				v


2. It will take effect after compilation without error and after the program is successfully downloaded.

Note: When the local expansion module is disabled, it is also necessary to ensure that the actual physical connection and configuration are consistent.

16.2.3 Get Physical Configuration

After TS series PLC is connected to the expansion module, the actual number of connected modules and configuration sequence can be obtained from PLC information.


Click "PLC" > "PLC Info" on the toolbar, and check the actual physical configuration in the pop-up PLC information box.



17 Subroutine, Library


17.1 Subroutine

The execution logic and cyclic scanning mode of main program and subroutines are shown in the following figure.



Subroutine nesting layer

Subroutines support up to 6 layers of nesting, with the main program calling the subroutine as the first layer. A layer of nesting is added for each call. If the nest returns, the nesting layer is not increased. See the figure below.



17.2 General Subroutine Application

A subroutine is an independent program body, which can be called by the main program or other subroutines. Subroutines are optional components of user programs.

Writing user programs using subroutines has the following advantages:

- It can reduce the size of the user program, the repeated user program code segment with the same function, and can be written as a subroutine repeatedly called.
- It makes the structure of the program clearer, especially simplifies the structure of the main program.
- It improve the portability of user programs.

17.2.1 Matters Needing Attention in the Use of General Subroutines

When writing or calling subroutines, you should pay attention to the following matters:

 The mosaic call of subroutines is supported, and the maximum number of mosaic call layers is 6. The following example demonstrates a legal 6-layer mosaic call relationship:
 MAIN → SBR1 → SBR2 → SBR3 → SBR4 → SBR5 → SBR6.

(It represents calling the corresponding subroutine using the CALL instruction)

• Recursive and circular calls to subroutines are not supported.

The following two examples demonstrate illegal subroutine call relationships:

- ♦ MAIN \rightarrow SBR0 \rightarrow SBR0 (recursive call, illegal)
- ♦ MAIN \rightarrow SBR0 \rightarrow SBR1 \rightarrow SBR0 (loop call, illegal)
- A user program can define up to 64 subroutines.
- A subroutine can define up to 16 bit-type and 16 WORD variables in the variable table.
- When calling a subroutine, it should be noted that the attributes of operands filled in the CALL instruction should match the attributes of variables defined in the variable table of the subroutine, and the compiler will check the correctness of the matching.
- No subroutine is allowed to be called in the interrupt program.

17.2.2 Definition of General Subroutine Variable Table

Attributes of Subroutine Variables

The subroutine variable table is to declare interface parameters and local variables (collectively referred to as variables) of subroutines, and specify their use attributes.

Description of Attribute Items of Subroutine Variables

The interface parameters and local variables (collectively called variables) of subroutines have the following attributes:

• Variable address

Each subroutine interface parameter or local variable is assigned with a fixed LM element or V element address. The address is automatically assigned to subroutine interface parameters or local variables by programming software according to the data type of variables and the principle of address continuity.

• Variable

You can name a variable (alias) of subroutine interface parameters or local variables, and you can use this variable name in programs by reference to it.

• Variable type

Subroutine interface parameters or local variables are divided into IN type, OUT type, IN_OUT type and TEMP type:

- ♦ An IN variable is used to pass the input value of a subroutine when it is called.
- ♦ An OUT variable is used to pass the call return value for a subroutine when it returns.
- ♦ An IN_OUT variable is used to pass the input value when the subroutine is called. When the subroutine returns, it is used to pass the call return value.
- ♦ An TEMP type variable is used only as a valid local variable within the scope of subroutines.
- Variable data type

The variable data type attribute specifies the data width and data scope of variables. The following table lists the variable data types:

Variable Data Type	Data Type Description	Occupy LM/V Element Address					
BOOL	Bit-type variable	It occupies 1 LM element address					
INT	Signed integer variable	It occupies 1 V element address					
DINT	Signed long integer variable	It occupies 2 consecutive V element addresses					
WORD	Unsigned integer variable	It occupies 1 V element address					
DWORD	Unsigned long integer variable	It occupies 2 consecutive V element addresses					
REAL	Floating-point variable	It occupies 2 consecutive V element addresses					

Table 17-1 Variable Data Type

17.2.3 General Subroutine Parameter Passing

When calling a subroutine in the main program, if local input and output variables are defined in the subroutine, the interface parameters of the subroutine should be filled with corresponding numerical values or global/temporary variable elements.

Note: The data types of local variables and interface parameters should be consistent.

17.2.4 Examples of Using General Subroutines

Here is an example to show how to write and call subroutines

Introduction to Sample Functions

Call the subroutine SBR_1 in the main program, and allow the subroutine SBR_1 to complete the addition operation (3 +2) of two integer constants, and assign the operation result 5 to D0.

Example Operation Steps

Step 1 Create a subroutine in the project and name it SBR_1.

Step 2 Write the subroutine SBR_1.

- A. Establish a call operand interface of subroutine in the variable table of subroutine SBR_1.
 - Define variable 1: Name the variable IN1, which is an IN-type parameter and is used as INT-type data, and it is assigned a V-element address V0 in sequence.
 - Define variable 2: Name the variable IN2, which is an IN-type parameter and is used as INT-type data, and it is assigned a V-element address V1 in sequence.
 - Define variable 3: Name the variable OUT1, which is an OUT-type parameter and is used as INT-type data, and it is assigned a V-element address V2 in sequence.
- B. Write the implementation code of subroutine SBR_1:

LD SM0

ADD # IN1 # IN2 # OUT1

The following figure illustrates the process of writing subroutine SBR_1:

TS600 Series Programmable Logic Controller Programming and Application Manual

File(F) Edit(E) View(V) Ladder(L)	PLC(P)	ebugging(D) Tool(T) Window(W)	Help(H)					
oject manager	→ ₽ ×	📑 MAIN 📑 SBR_	1						
🖌 🖵 y1234(TS635)		Variable Address	Variable Name	Variable Type	Data Type	Comments			
▼ { } Program block			tes1	IN	INT				
		V1	tes2	IN	INT				
MAIN				IN_OUT	BOOL				
{S} SBR_1		V2	tes3	OUT	INT				
				TEMP	BOOL				
{] INT_1				TEMP	BOOL				
🗽 User C language									
Eibrary									
System variable table		1							
▶ 📳 Global variable table		SM0	[ADD VO	I	V1	₩2]	
🔻 🖓 Setting		Running mo	nitori						
System Block		ng bit							
EXP-CARD									

Step 3 Write the main program and call the subroutine.

In the main program, use CALL instruction to call subroutine SBR_1.

The code of the whole main program is as follows:

LD M0

Pro

CALL SBR_132 D0

You can use parameters to pass the corresponding relationship table and fill in the parameters brought in or returned when calling the subroutine.

- Bring in the parameter IN1 and pass the constant integer 3.
- Bring in the parameter IN2 and pass the constant integer 2.
- The return value OUT1 is passed to D0

See the picture below:

	$\delta $ $\delta $ $\frac{1}{2}$	_^ -1⊦ -1/⊦		-C) 🕳 {F}	- +	DEL
File(F) Edit(E) View(V) Ladder(L) PLC(P	Debugging(D) Tool(T) Window(W) Help	o(H)				
	× 🕞 MAIN * 📑 SBR_1					
y1234(TS635) √ { } Program block		LL SBR_1	3	2	DO]
{M} MAIN	Running monitori ng bit					
{SBR_1						
 {Ⅰ} INT_1 Iser C language 						
Library						
▶ 📳 System variable table						
Global variable table						2
v 🖉 Setting						20

Step 4 Compile, download and run the user program to verify the logical correctness of the subroutine.

• Sample execution results

When M0=ON, the subroutine SBR_1 is called, and the operands IN1 and IN2 are passed with values 3 and 2, and then the addition operation returns a value 5, and finally D0=5.

17.3 Interrupt Subroutine Application

17.3.1 External Interrupt Subroutine

External interrupt subroutine is suitable for the scenario where the external input signal triggers and the program needs to be executed immediately to respond. External interrupt subroutines are not affected by scanning periods. The specific application steps are as follows:


Step 1 Click "Project manager", and right-click "Program block" to choose "Insert interrupt subroutine".

Project manager	→ ₽ ×	MAIN 📑 SBR	1 * 📴 INT_1			
		Variable Address	Variable Name	Variable Type	Data Type	Comments
······		VO	tes1	IN	INT	
	Insert subroutine(S		tes2	IN	INT	
{M} MAIN				IN_OUT	BOOL	
	Inser interrupt sub	routine(i)	tes3	ovr	INT	
{S} SBR_1	Export library(E)			TEMP	BOOL	
{I} INT_1				TEMP	BOOL	
. ,						
📘 User C lan	guage					
Eibrary		ļ				
▶ 📳 System variable	e table	1				
🕨 🔚 Global variable	table					
▼ 🛱 Setting						
🕨 🧱 System Blo	ock					
EXP-CARD)					

- Step 2 Right-click the inserted interrupt subroutine (INT_001 in the figure) and select "Attribute" to open the interrupt subroutine setting page as shown in the following figure.
- Step 3 Click the icon after the "Interrupt event" field to enter the interrupt selection interface. Select the corresponding external interrupt. For example, after selecting X0 input interrupt, you need to select the attributes of interrupt, including rising edge and falling edge.


Interrupt number	Interrupt ^	Inter	rupt program	Interrupt nu
-1	Not set			
0	XO input			
1	X1 input			
2	X2 input			
3	X3 input			
4	X4 input			
5	X5 input			
6	X6 input			
7	X7 input			
8	XO input			
9	X1 input			
10	X2 input			
11	X3 input			
12	X4 input			
13	X5 input			
14	X6 input			
15	X7 input 🎽			
<	>	<		>

Step 4 Write interrupt subroutines in INT_001.



Step 5 Start EI in the main program, and when the external interrupt condition is met, the corresponding interrupt subroutine will be triggered to execute.

Т



17.3.2 Timer Interrupt Subroutine

The specific application steps are as follows:

Step 1 Click "Project manager", and right-click "Program block" to choose "Insert interrupt subroutine".

Project manager	→ ╄ ×	MAIN 📑 SBR	MAIN 🕞 SBR_1* 📴 INT_1						
🚽 🛄 y1234(TS635)		Variable Address	Variable Name	Variable Type	Data Type	Comments			
	V0	tes1	IN	INT					
	Insert subroutine(S)	tes2	IN	INT				
{M} MAIN	Inser interrupt sub	routine(l)		IN_OUT	BOOL				
			tes3	OVT	INT				
{S} SBR_1	{SBR_1 Export library(E)			TEMP	BOOL				
{ } INT_1				TEMP	BOOL				
User C lang Library E System variable Global variable E System Blog EXP-CARD	table table	1							

Step 2 Right-click the inserted interrupt subroutine (INT_001 in the figure) and select "Attribute" to open the interrupt subroutine setting page as shown in the following figure.

Step 3 Click the icon after the "Interrupt event" field to enter the interrupt selection interface.


Step 4 Select the timer interrupt, and select the timing duration of the timer interrupt in ms, ranging from 1 to 1000ms.

nterrupt number	Interrupt ^	Interrupt program	Interrupt n
:0	Input com	INT_1	0
1	Input com		
2	Input com		
3	Input com		
4	Input com		
5	Input com		
:6	Input com		
27	Input com		
8	Input com		
9	Input com		
0	Input com		
1	Input com		
2	Timed Int		
13	Timed Int		
4	Timed Int		
5	Power fai		
	×		
	>	<	>

Step 5 After that, you can write interrupt subroutines in INT_001.

1				
SMO ────{	INC	DO]	
Running monitori ng bit				

Step 6 Start EI in the main program, and the corresponding interrupt subroutine will be triggered to execute when the timer interrupt condition is met.



18 Application of Custom Variable Communication

18.1 Overview

The address of the variable in the custom variable function is a dynamically changing address, so the external devices cannot access it directly through the address. Currently, custom variables can be accessed in two ways:

Method 1: Bind custom variables to soft elements. Achieving Modbus communication between external devices and TS600 series controllers through Modbus address mapping.

Method 2: Tag communication. Tag communication is a proprietary protocol for communication between our TS600 series controllers and our touch screens, allowing users to efficiently and quickly access the internal variables of TS600 series controllers through the touch screen.

18.2 Example Project

Write a TS600 series bit operation program, and display the corresponding bit elements and control word status on the INVT touch screen.


18.2.1 Accessing Custom Variables via Binding to Elements

18.2.1.1 PLC Programming


- Step 1 Create a new PLC project, see 2.4 Programming and Debugging for details.
- Step 2 Assign variable address, double-click "Global variable table 1" in the project management bar to enter the global variable table interface, and assign soft element address for custom variables.
 Variables light1 light8 are BOOL-type arrays, and will occupy a total of 8 bit elements, namely M1 M7 if chosen to map to M1.

ect manager	▼ # ×	MAIN	😫 Global variable table 1	•					
ttt2(TS635)	^		Variable Name	Data Type	Initial Valu	Power Down	Connents		Ad Current Valu
▼ { } Program block		1	light1	BOOL	OFF	No Hold		M1	
		2	light2	BOOL	OFF	No Hold		112	
MAIN		3	light3	BOOL	OFF	No Hold		M3	
{S} SBR_1		4	light4	BOOL	OFF	No Hold		114	
{ 5 } SBK_1		5	light5	BOOL	OFF	No Hold		105	
{] INT_1		6	light6	BOOL	OFF	No Hold		16	
		7	light?	BOOL	OFF	No Hold		NC7 ND9	
🔀 User C language		8 9	light8	BOOL YORD	OFF	No Hold No Hold		1020	
🧮 Library		3	Control	AOVD	0	No nord		1020	hund
Global variable table Global variable table Global variable table Global variable table C language global variable table									
C ⊂ Language global variable dat B Global variable table 1 ✓ ∰ Setting ► B System Block									
EXP-CARD	- 11								

Step 3 The program is as shown in the following figure, in which light1 – light8 are the eight BOOL variables created in the previous step, and Control is the WORD variable for HMI display.



Elements are used directly for custom variables, so in actual use, the interface displays the element name.



Step 4 For communication configuration, double-click "Ethernet 1" to check "ModbusTCP slave" communication in slave configuration.

	a company and a co		
C Expansion module conliguration			
Electronic cam			
Dotion control axes			
♦■ Axis group setting	Master configuration	Slave configuration	
🖗 etherCAT	ModbusTCP master	ModbusTCP slave	
COM1		Enable control element	X0
COM2	Enable control element X0	Timeout	500
Ethernet1		Slave port number:	502
Ethernet2			
EtherNet/IP	PLC Ethemet setting		


18.2.1.2 Touch Screen Programming

Create a touch screen project and set the corresponding mapping variables.

TS600 Series Programmable Logic Controller Programming and Application Manual

Application of Custom Variable Communication

Communication Port Properties ? X	Communication Port Properties ? X
General Parameter	General Parameter
Link ID:1	Commected equipment ip Other Address 192 168 1 10 HMI Address: 0 ÷
Link Name: Link1	
.ink Interface: Ethernet	Plc station: 1 manunication time: 5 (ns)
HMI Site: Local V Setting)M port (master-slave mode) port: 1	Overtime time 1: 1000 🔹 (ns)
rtion Services: invt Y IS600 ICP Series	Overtime time 2:5 ‡ (ms)
	Retries: 3 V
HMI IP	Address mode: Standard M 🗸
Ip: 192 168 100	LC address interval: 32
Subnet mask: 255 255 0	
Gateway: 192 168 1 1	Spare set parameters
010001, 102 , 100 , 1 , 1	are parameter 1:0 :pare parameter 3:0
	are parameter 2: 0 Spare parameter 4: 0
ok cancel	ok cancel
88888	
E Bit Lar	
	t Lanp
	0000 Shape State: 1 0
View-	order Color:
	FG Color:
	BG Color:
	Pattern: Transparent
	Data Type: Bit
Prompt	Monitor Address: M1 📰 🗌 Offset
· · · · · · · · · · · · · · · · · · ·	
o 88888 o	
Numentric Display	? ×
Element type	General Picture Advanced Visibility
ON ON ON ON UN	Shape
	Border Color:
	FG Color:
	BG Color:
88886	Text Color: Pattern: Solid
	Data Type: 16-Bit Unsigned Int 🗸 🗌 Unit
	Display Type: 16-Bit Unsigned Decime
Prompt	Monitor Address: D20
	Font: 宋体 Alignment Justification 〇 Left ④ Zero-suppressic
	Font Size: 10
Function: Monitor Register value	Total Digits: 5 🗧 🖲 Center 🔿 Zero Header
while change	actional Digits: 0 🖨 🔿 Right 🔿 Space Header
	Ok Cancel Help
C	
85	



18.2.2 Accessing Custom Variables via Tag Communication

18.2.2.1 Version Restrictions

Note: The following software version requirements must be met for the tag communication function to operate properly.

Software	Minimum version number
Auto Station Pro	V1.3.2
HMITOOL	V7.1-010-build20240515
PLC firmware: TS600_MCU_XXX	V1.41.00
HMI firmware: GUI version number	7.1.5.42


18.2.2.2 PLC Programming

Step 1 Create a new PLC project, see section 2.4 Programming and Debugging for details.

Step 2 Defi	ne custom variables.
-------------	----------------------

File(F) Edit(E) View(V) PLC(P) Tool(T) Window(W) H	lelp(H)					
🕒 🖻 🔚 🗂 👗 🗅	C 5	C 1 Q E] 🖻 🗸 🖋	
	5 Y		-> _	/ -		- d+ -C> - ■ { F } -
Project manager 🛛 🔻 👎		Global variable table 1				
<u>н</u> = не не не не (не кест)	^	Variable Name	Data Type	Initial Valu	e Power Down Comments	Element Ad
{ } Program block	1	light1	BOOL	OFF	No Hold	M1
MAIN	2	light2	BOOL	OFF	No Hold	M2
{s} SBR 1	3	light3	BOOL	OFF	No Hold	M3
{I} INT 1	4	light4	BOOL	OFF	No Hold	M4
User C language	5	light5	BOOL	OFF	No Hold	М5
	6	light6	BOOL	OFF	No Hold	M6
{ } FB	7	light7	BOOL	OFF	No Hold	M7
{ } FC	8	light8	BOOL	OFF	No Hold	M8
🧮 Library	9	Control	WORD	0	No Hold	D20
System variable table	10					
- E Global variable table	11					
器 Struct						
Software element list						
E FB instance variable						
🔚 C language global variable ta						
🗄 Global variable table 1						
🗸 🚱 System blocks settings						
Basic settings						
P im busic settings						

Step 3 Compile the program and click "Export HMI variable" file, then save it in an appropriate location on your computer.



Step 4 Communication configuration; double-click "Ethernet1", select "Tag Communication Server" in the "Tag Communication Setting", and configure the port number as "9018."

TS600 Series Programmable Logic Controller Programming and Application Manual

Application of Custom Variable Communication

	Master configuration	Slave configuration
Project manager ♥ ₽ × Image: Struct Image: Struct	ModbusTCP master ModbusTCP master Enable control element X0	ModbusTCP slave Enable control element X0 Timeout 500 Slave port number: 502
 Basic settings EXP-CARD Expansion module configurat Electronic cam Motion control axis Axis group setting EtherCAT COM1 COM2 Ethernet1 Ethernet2 EtherNet/IP 	6 7 7 Tag Communication Setting 8 ✓ Tag Communication Server 9 10 10 PLC Ethernet setting 11 IP address: 192 168 1 10 Subnet Mask: 255 255 0 0 Gateway Address: 192 168 1 1	Port: 9018 Read Reset IP Write Identification device
Cross-reference table	SOCKET	TcpServer UdpPeer

Step 5 Compile the program and download it to the controller, then run it.

18.2.2.3 Touch Screen Programming

Step 1	Create a new HMI	project in the HMITOOL	host controller.

New Link			
Link ID: 1			
Link Name: Ethernet			
Link Interface: Ethernet	t.	*	
Device Service: invt		TS Label TCP	*

Step 2 Tag communication configuration; fill in the "IP Address" of the PLC and the "Port number" of the tag communication.

TS600 Series Programmable Logic Controller Programming and Application Manual

Application of Custom Variable Communication

Connected equipmen	tipOther	
12002011 (
IP Address: 192 .	168 • 1 • 10 HMI Address: 0	*
Port number: 9018	Plc station: 1	÷
	Communication time: 5	(ms)
	Overtime time 1: 1000	(ms)
	Overtime time 2: 5	(ms)
	Retries: 3	*
	Address mode: Standard Mode	*
	PLC address interval: 32	*
Spara act parameter		
Spare set parameters Spare parameter 1:		ΞÌ.

Step 3 Click "Import Protocol tags" and select the XML file exported from the Auto Station Pro host controller.

Seneral	Param	otor -						
Link ID:	1							
Link Inter	face:	Etherr	net					¥
Link Nan	ne: T	S Labe	I TCP					
HMI Site	Loca	al		*	Setting	CC	M port (ma	ster-slave mode) port:1
Connecti	on Sei	vices:	invt			Ŧ	TS Label 1	rcp 👻
	lp:	192	. 168		1		. 100	
Subnet n	naski	255	. 265		255		. 0	Import Protocol tags
Gate	eway:	192	. 168		1		- 1	
			Switch 1+3 Fu the <remote c<="" td=""><td></td><td></td><td></td><td></td><td>utton>or use rameters of the 4G/WIFI</td></remote>					utton>or use rameters of the 4G/WIFI

Step 4 Define the "Numeric Input" control and configure it as shown below to monitor the Control variable of the TS600 series.

		Border	Color:						-	Shap
NEO			Color:		Text Color:					onup
v			Color:		Text Color.					
				7						
1	ŝ		attern:							
99999					nsigned Int					
99999			1 (065) Ju	IG-BIT U	nsigned Decimal				- Keybo	
	2	Offs	ddress:	-						
				ess Ider	ntical to Write Address					
	-4		sWord in							
mpt ction:Monitor the			Address							
ster values		Offs		t: Arial		-	-Alignment		Justification	
		F	Font Size	-		*	O Left	A 01	Zero-suppression	
			ital Digits			\$	Center		O Zero Header	
			nal Digits			\$	 Right 		Space Header	
		Scrip				-	(0	
			se Scrip	t						
			se Scrip	t					Canaal	LL-1
Addr	ess [se Scrip	t						He
MaddrStand			se Scrip	t		,	Address library			
	lard -		se Scrip	t	~)[□,	Address library			
Stand	lard - net	Entry	se Scrip	t 			Label			
Stand	lard - net	Entry	se Scrip	t 	·*)		1000 Y 200 C 20			
Stand	lard - net abel	Entry	ise Scrip			5	Label			
Stand Ether TS L	lard - net abel	Entry	ise Scrip		*	5	Label Address			
Stand Ether TS L	lard - net abel	Entry	4	5	*	5	Label Address			
Stand Ether TS Li Contr	lard net abel rol	Entry			•	5	Label Address			
Stand Ether TS La Contr	lard - net abel rol 2	Entry TCP	4	5	<pre> CLR </pre>	5	Label Address			Hel

Step 5 Define a "Bit Switch" control and configure it as shown below to monitor the light1 variable of the TS600 series.

Bit Switch	Ge	enaral	Appeara	ance Advance	Visibility			
ID: BB0		Sta	te:	1	0			
D. 000		order Col						Shape
View							-	onapo
		BG Col				(and the last		10
		FG Col	or:		Pattern:	Solid		Y
OFF		Function	-					
	3	Function	Invert					
		Mode	Press	execute				*
0	w	/rite Addr	ess:					Offse
Prompt Function: ON / OFF	~	Monitor	r ^{is}		Monitor Addre	ess Identical to Write Ac	Idress	
status monitoring	M	lonitor Ac	Idress:					Offset
	1	Requi	red the o	operator confirm				
	1	Wait Tim	ie: 3	\$ Second	s)			
	1							
	C	Script	I.—					-
	-							
🚍 Addr		try			(Ok Cancel	×	help
Addr		try			Address library	Ok Cancel		help
the second	lard —	try			Address library -	Ok Cancel		help
Stand	lard —			*	and the second sec	Ok Cancel		help
Stand	lard net abel T(Label	Ok Cancel		help
Stand Ether	lard net abel T(Label:	Ok Cancel		help
Stand Ether TS L light	lard — net abel TC	CP		*	Label:	Ok Cancel		help
Stand Ether	lard — net abel TC		5		Label:	Ok Cancel		help
Stand Ether TS L light	lard net abel TC	CP	5	*	Label:	Ok Cancel		help
Stand Ether TS L light	ard abel TC	CP 3 4		CLR	Label:	Ok Cancel		help
Stand Ether TS L light	ard net abel TC 2 7 8	CP 3 4 8 9	0	CLR BS	Label:	Ok Cance		help

- Step 6 Compile and download the touch screen program.
- Step 7 Properly connect the Ethernet cable between the touch screen and the PLC.
- Step 8 Read and write custom variables on the PLC via the touch screen.

19 Fault Diagnosis

19.1 Panel Diagnosis

19.1.1 Indicator

The status definition of TS600 series panel indicators is shown in the following table. When the error indicator is on, the PLC is in the STOP state, and the error level is "serious error". When the error indicator blinks, the PLC is in the RUN state, and the error level is "general error".

Port Type	Interface Sign	Definition	Indicator Color	Description
10 indicator	1600D	INPUT state display	Yellowish green	 Steady On: The input is valid or at high-speed Off: There is no input Flashing: A pulse is being input
IO indicator	0016DN	OUTPUT state display	Yellowish green	 Steady On: The output is valid or at high-speed Off: There is no output Flashing: A pulse is being output
	PWR	Power status indication	Yellowish green	On: The power supply is normal.Off: Abnormal power supply
	RUN	Running status indication	Yellowish green	 Steady On: The user program is running Off: The user program stops
	ERR	Running error indication	Red	 Off: No error Steady On: Serious error Flash: Common error Slow flash: The device needs to be powered on again
Running state indicator	EtherNET1	EtherNET1 connection	Yellow, yellowish green	 Yellowish green light is steady on: The link has been established successfully Yellowish green light and yellow light are flashing: Communication is in progress Off: The link is not established
	EtherNET2	EtherNET2 connection	Yellow, yellowish green	 Yellowish green light is steady on: The link has been established successfully Yellowish green light and yellow light are flashing: Communication is in progress Off: The link is not established
	EtherCAT	EtherCAT connection	Yellow, yellowish green	 Yellowish green light is steady on: The link has been established successfully Yellowish green light and yellow light are flashing: Communication is in progress Off: The link is not established

19.2 Software Diagnosis

19.2.1 Get the Basic Information of PLC

• You can click on the "PLC" on the toolbar to check PLC information, which displays the number of errors and the status of the indicators.

🖃 Version		
CPV type	TS635	
Hardware version number	1.00.00	
Software version number	1.39.00	
FPGA version number	3.07.00	
🖃 Program capacity		
Program capacity	200K step	
🖃 Scanning rate(ms)		
Current	0.500ms	
Maximum value	0.600ms	
Minimum value	0.400ms	
- Error message		
Number of error	2	
🖃 Operation status indicati	ion	
Running light	On	
Error light	On	

• Users can click the toolbar 😟 button to enter the monitoring mode. After entering the monitoring mode, check the error information, corresponding main error codes and subcodes through the element monitoring table.

Elemen	Element monitoring table								
+ × 0	3 ± ∓ 🖉 🗄 🗄 🖶								
EMT_1									
	Element Name	Data Type	Display Fo:	Current Value	Nev	^			
1	🗏 _sCurErrLst. sErrInfo	_stru_ERR_	Decimal						
2		_stru_ERR_	Decimal						
3	_sCurErrLst. sErrInfo[0]. Sub	INT	Decimal	17					
4	_sCurErrLst. sErrInfo[0]. Mai	INT	Decimal	144					
5	sCurErrLst. sErrInfo[0]. Tim	DINT	Decimal	1269630207					
6		_stru_ERR_	Decimal						
7	_sCurErrLst. sErrInfo[1]. Sub	INT	Decimal	19					
8	_sCurErrLst. sErrInfo[1]. Mai	INT	Decimal	144					
9	_sCurErrLst. sErrInfo[1]. Tim	DINT	Decimal	1269630207					
10		_stru_ERR_	Decimal						
11	_sCurErrLst. sErrInfo[2]. Sub	INT	Decimal	0					
12	_sCurErrLst. sErrInfo[2]. Mai	INT	Decimal	0					
13	sCurErrLst. sErrInfo[2]. Tim	DINT	Decimal	0					

19.2.2 View Error Log

The user can click the menu "PLC" and then select the PLC log file in the drop-down box to upload log information from PLC as follows:

PLC Info							\times
Las	t Next Page 1				OChina	● English	
No.	Timestamp	Ma	Su	Error			^
40	2010-03-26 18:59:41	144	17	slave pdo off line.			
39	2010-03-26 18:59:40	144	19	ethercat net not link signed.			
31	2010-03-26 18:59:36	17	28	mcError_BusAxisNotEnterOpStatus			
32	2010-03-26 18:59:36	17	3	mcError_PLCOpenStateIsUnReasonable			
33	2010-03-26 18:59:36	17	3	mcError_PLCOpenStateIsUnReasonable			
34	2010-03-26 18:59:36	17	3	mcError_PLCOpenStateIsUnReasonable			
35	2010-03-26 18:59:36	17	3	mcError_PLCOpenStateIsUnReasonable			
36	2010-03-26 18:59:36	17	3	mcError_PLCOpenStateIsUnReasonable			
37	2010-03-26 18:59:36	17	3	mcError_PLCOpenStateIsUnReasonable			
38	2010-03-26 18:59:36	144	21	communication timeout.			
26	2010-03-26 18:58:52	17	3	mcError_PLCOpenStateIsUnReasonable			
27	2010-03-26 18:58:52	17	3	mcError_PLCOpenStateIsUnReasonable			
28	2010-03-26 18:58:52	17	3	mcError_PLCOpenStateIsUnReasonable			
29	2010-03-26 18:58:52	17	3	mcError_PLCOpenStateIsUnReasonable			
30	2010-03-26 18:58:52	17	3	mcError_PLCOpenStateIsUnReasonable			
21	2010-03-26 18:58:11	17	3	mcError_PLCOpenStateIsUnReasonable			~
<						2	>

19.3 Fault Code List

19.3.1 Fault Code Classification

Device			Main Fault	Main Fault Code
Category	Device Type	Module Type	Code (HEX)	(DEC)
		Hardware fault	0001	1
	System-related	System fault	0002	2
	System-related	Program fault	0003	3
		Reserved fault	0004-0007	4~7
	System	Clock system component fault	0008	8
	component-related	IP system component fault	0009	9
CPU		Reserved fault	000A-000F	10~15
		Codesys motion control fault	0010	16
	Functional	Autonomous motion control fault	0011	17
	component-related	High speed input fault	0012	18
		CANopen axis control fault	0013	19
		Reserved fault	0014-0017	20~23
	Process library	Reserved fault	0018-002F	24~47
		CPU IO failure	0030	48
		Digital quantity fault	0031	49
		Analog quantity fault	0032	50
Backplane bus	Backplane bus-related	Fault of temperature measuring module	0033	51
		Encoder input fault	0034	52
		Reserved fault	0035-003F	53~63
		Modbus RTU/ASCII Master 1	0040	64
		Modbus RTU/ASCII Master 2	0041	65
		Modbus RTU/ASCII Master 3	0042	66
		Modbus RTU/ASCII Slave 1	0043	67
		Modbus RTU/ASCII Master 2	0044	68
		Modbus RTU/ASCII Master 3	0045	69
		Serial freeport 1	0046	70
	Serial port-related	Serial freeport 2	0047	71
		Serial freeport 3	0048	72
Fieldbus		Modbus RTU /ASCII master command 1	0049	73
		Modbus RTU /ASCII master command 2	004A	74
		Reserved fault	004B-004F	75~79
		CANopen	0050	80
		CANfree	0051	81
	CAN-related	CANnet	0052	82
		Reserved fault	0053-0057	83~87
		PROFIBUS DP	0058	88
	PROFIBUS	Reserved fault	0059-005F	89~95
	Reserved	Reserved fault	0060-006F	96~111

Fault Diagnosis

Device	Device Type	Module Type	Main Fault	Main Fault Code		
Category	Denice Type		Code (HEX)	(DEC)		
	Profinet-related	PROFINET	0070	112		
	FIOIMELFIElaleu	Reserved fault	0071-007F	113~127		
	Ethernet/ID related	Ethernet/IP	0080	128		
	Ethernet/IP-related	Reserved fault	0081-008F	129~143		
		EtherCAT	0090	144		
		ET-Digital quantity	0091	145		
		ET-Analog quantity	0092	146		
	EtherCAT-related	ET-Temperature measuring module	0093	147		
		ET-Encoder input	0094	148		
		Reserved fault	0095-009F	149~159		
Industrial		Modbus TCP	00A0	160		
Ethernet	Modbus TCP-related	Master(Ethernet1)	0040			
		Modbus TCP 0041		00A1	161	
		Master(Ethernet2)	UUAI	101		
		Modbus TCP Slave(Ethernet1)	00A2	162		
		Modbus TCP Slave(Ethernet2)	00A3	163		
		Reserved fault	00A4-00AF	164~175		
	TCP-related	ТСР	00B0	176		
	TCP-related	Reserved fault	00B1-00B7	177~183		
	UDP-related	UDP	00B8	184		
	ODP-related	Reserved fault	00B9-00BF	185~191		
	OPC UA	OPC UA	00C0	192		
	Reserved	Reserved fault	00C1-00EF	193~239		
Expansion	IoT card	4G expansion card	00F0	240		
card	Reserved	Reserved fault	00F1-00F3	241~243		
Other	Other	Reserved fault	00F4-00FF	244~255		

19.3.2 Fault Code List

Note: The main/sub fault codes are in hexadecimal format, with the corresponding decimal values shown in parentheses.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
0.0001(1)	0x0001(1)	General error	Button cell is not installed or battery voltage is too low	Check the battery.
0x0001(1)	0x0002(2)	General error	Device supply voltage is too low (less than 19V)	Check the power supply.
	0x0001(1)	Serious error	Hardware initialization error	Check whether the peripheral device works normally and whether the driver is loaded successfully
0x0002(2)	0x0002(2)	Serious error	Failed to open GPIO	Check whether the driver and hardware work properly
	0x0003(3)	Serious error	Failed to write GPIO	Check whether the driver and hardware work properly
	0x0004(4)	Serious error	Failed to read GPIO	Check whether the driver and hardware work properly

Main fault	Sub fault	Error		
code	code	level	Meaning of error	Solutions
	0x0005(5)	Serious error	Failed to open FPGA FMC	Check whether the driver and hardware work properly
	0x0006(6)	Serious error	SPI operation failed	Check whether the driver and hardware work properly
	0x0007(7)	Serious error	Failed to update FPGA firmware read signal	Check whether the driver and hardware work properly
	0x0008(8)		ů – – – – – – – – – – – – – – – – – – –	Check whether the file exists or is corrupted
	0x0009(9)	Serious error	Failed to open I2C device	Check whether the driver and hardware work properly
	0x000A(10)	Serious error	Failed to write to I2C device	Check whether the driver and hardware work properly
	0x000B(11)	Serious error	Failed to read I2C device	Check whether the driver and hardware work properly
	0x000C	Serious	Failed to write FMC device	Check whether the driver or FPGA is
	(12) 0x000D (13)	error Serious error	Failed to read FMC device	working properly Check whether the driver or FPGA is working properly
	0x000E(14)	Serious	Failed to open USB device	Check whether the driver and hardware work properly
	0x000F(15)	error Serious error	Failed to create USB epoll	Check whether the system is working properly
	0x0010(16)	Serious error	Programming port TCP initialization failed	Check whether the driver and hardware work properly
	0x0011(17)	Serious error		Check whether the driver and hardware work properly
	0x0012(18)	Serious error		Check whether the element type and address are correct
	0x0013(19)	Serious error	Failed to open configuration file	Check whether the configuration file
	0x0014(20)	General error	Power-down keeping configuration parsing failed	Check whether the profile data is correct
	0x0015(21)			Check whether the profile data is correct
	0x0016(22)	General error	v , v	Check whether the profile data is correct
	0x0017(23)	General error	· · · · · ·	Check whether the profile data is correct
	0x0018(24)	General error		Check whether the profile data is correct
	0x0019(25)	General error		Check whether the profile data is correct
	0x001A(26)	General		Check whether the profile data is correct
	0x001B(27)	General	r	Check whether the profile data is correct
	0x001C	General	r	Check whether the profile data is

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	(28)	error	parsing failed	correct
	0x001D	General	Serial port 2 configuration	Check whether the profile data is
	(29)	error	parsing failed	correct
	0.0045(00)	General	Serial port 232 configuration	Check whether the profile data is
	0x001E(30)	error	parsing failed	correct
	0.0045(04)	General	Modbus RTU Master 1	Check whether the profile data is
	0x001F(31)	error	configuration parsing failed	correct
		General	Modbus RTU Master 2	Check whether the profile data is
	0x0020(32)	error	configuration parsing failed	correct
		General	Ebus serial port 1 configuration	Check whether the profile data is
	0x0021(33)	error	parsing failed	correct
		General	Ebus serial port 2 configuration	Check whether the profile data is
	0x0022(34)	error	parsing failed	correct
		General		Check whether the profile data is
	0x0023(35)	error	configuration parsing failed	correct
		General		Check whether the profile data is
	0x0024(36)	error	configuration parsing failed	correct
		General	· · · ·	Check whether the profile data is
	0x0025(37)	error	parsing failed	correct
		General		Check whether the profile data is
	0x0026(38)	error	parsing failed	correct
			· · · · ·	Check whether the profile data is
	0x0027(39)	error	configuration parsing failed	correct
			· · · · · · · · · · · · · · · · · · ·	Check whether the profile data is
	0x0028(40)	error	configuration parsing failed	correct
		General	· · · ·	Check whether the profile data is
	0x0029(41)	error	parsing failed	correct
				Check whether the profile data is
	0x002A(42)		failed	correct
				Check whether the profile data is
	0x002B(43)	error	configuration parsing failed	correct
	0x002C	General	,	Check whether the profile data is
	(44)	error	parsing failed	correct
	0x002D	General	· · · · ·	Check whether the profile data is
	(45)	error	configuration parsing failed	correct
	(43)		· · · · · · · · · · · · · · · · · · ·	Check whether the profile data is
	0x002E(46)	General	Encoder axis configuration parsing failed	correct
		error	· · · ·	
	0x002F(47)			Check whether the profile data is
		error	parsing failed	correct
	0x0030(48)	General	-	Check whether the profile data is
		error	parsing failed	correct
	0x0031(49)	General		Check whether the profile data is
		error	failed	correct
	0x0032(50)	General		Check whether the profile data is
		error	configuration parsing failed	
	0x0033(51)	General		Check whether the profile data is
		error	parsing failed	correct

Main fault	Sub fault	Error	Manufactor	Oslations
code	code	level	Meaning of error	Solutions
	0x003F(63)	Serious error	Failed to allocate profile memory	Check system free memory
	0x0040(64)	General error	Configuration parsing overrun failed	Check whether the profile data is correct
	0x0041(65)	Serious error	Failed to start application due to undervoltage	Check whether the power supply voltage is normal
	0x0042(66)	Serious error	Power failure detected	Check whether the power supply voltage is normal
	0x0043(67)	Serious error	Failed to open power-down keeping file	Check whether the power-down keeping file or file directory exists
	0x0044(68)	Serious error	· · · ·	Check whether the power-down keeping file is damaged
	0x0045(69)	Serious error	· · · ·	Check the file size and whether the system is normal
	0x0046(70)	Serious error	Failed to release the power-down keeping file mapping	
	0x0047(71)	Serious error		Check whether the power-dowr keeping file is damaged
	0x0048(72)	Serious error	Error in detecting power-down keeping file length	Check whether the power-dowr keeping file is damaged
	0x0049(73)	Serious error	Error in detecting power-down keeping file tail	Check whether the power-dowr keeping file is damaged
	0x004A(74)	Serious error	Error in detecting power-down keeping file CRC	Check whether the power-dowr keeping file is damaged
	0x0050(80)	Warning	Watchdog timeout	Check whether the user program is running correctly
	0x0051(81)	Warning	Error message mismatch	Check whether the error message is filled in correctly
	0x0052(82)	Serious error	Failed to open RND file	Check whether the system is working properly
	0x0053(83)	Serious error	Failed to create thread	Check whether the system is working properly
	0x0054(84)	Serious error	Failed to open instruction library	Check whether the system is working properly
	0x0055(85)	Serious error	Failed to open user program	Check whether the system is working properly
	0x0056(86)	Serious error	Device model does not match fieldbus axis number	Check device model and use program fieldbus number
	0x0057(87)	Serious error		Check whether the PLC output matches the device.
	0x0058(88)	General error		Check whether the configuration code is set correctly.
	0x0059(89)	Serious error		Check the interrupt registration function.
	0x005A(90)	Warning	The interrupt function is undefined.	Check the interrupt function.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x005B(91)	Warning	Exceeding interrupt source number.	Check the range of the interrupt source number.
	0x005C(92)	General error	The mapping address of the expansion module is empty.	Check the module mapping address.
	0x0030(48)	General error	Illegal instruction system parameter	Please recompile and download the user program
	0x0031(49)	General error	Parameter is out of limit address range	Check whether the parameter variable data length of the instruction is out of range
	0x0032(50)	General error	Illegal instruction user parameters	Check whether the parameters of the instruction are in the wrong order or the size is set incorrectly
	0x0033(51)	General error	Wrong PID sampling time	
	0x0034(52)	General error	Wrong PID filter constant	
	0x0035(53)	General error	Wrong PID proportional gain	
	0x0036(54)	General error	Wrong PID integration time	
	0x0037(55)	General error	Wrong PID differential gain	1. Stop PID operation and che
	0x0038(56)	General error	Wrong PID differential time	whether the parameters are set correctly
0x0003(3)	0x0039(57)	General error	Wrong PID manual output PID value	
	0x003A(58)	General error	The PID setting target value exceeds the upper/lower limit of the setting value	
	0x003B(59)	General error	PID mode is not supported	
	0x003C (60)	General error	PID process value out of range error	
	0x003D	General	PID temperature sudden	
	(61)	error	change error	
	0x003E(62)	General		Check whether the control period is
		error	period is unreasonable	larger than the PID sampling time
	0x003F(63) error	TPID mode auto-tuning failed	 Limit cycle method: Try to lowe the set temperature value and increase the sampling cycle, ther rerun the program for autotuning. Ascending curve method: Try to increase the sampling cycle and se the target temperature value at leas 30°C higher than the process temperature value. If self-tuning is not possible for a 	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				the control device and sensors are abnormal
	0x0050(80)	General error	Illegal ASCII code conversion value	Confirm whether the ASCII code to be converted conforms to the ASCII code specification
	0x0051(81)	General error	Clock chip read-write error	If the upper computer clock can be read normally, recompile and download the program. If the clock of the upper computer cannot be read, check whether the hardware is damaged or the battery is exhausted
	0x0052(82)	General error	Stack definition error	Check whether the stack data is normal
	0x0053(83)	General error	The divisor in the division operation is 0	Check whether the divisor in the division operation is 0
	0x0054(84)	General error	String instruction or data error	Check whether the string instruction or string data is illegal
	0x0055(85)	General error	Override between source and target operands	Check for overlap between source and target operands
	0x0080 (128)	Warning	Invalid upper and lower limit setting range	Check whether the lower limit is greater than the upper limit, and exchange the upper/lower limit operation in this case
	0x0081 (129)	Warning	-	-
	0x0082 (130)	Warning	PID deviation out of range	The calculated value of PID deviation exceeds-32768 – 32767
	0x0083 (131)	Warning	PID proportional term out of range	The calculated value of PID proportional term exceeds-32768 – 32767
	0x0084 (132)	Warning	PID integral term out of range	The calculated value of PID integral term exceeds-32768 – 32767
	0x0085 (133)	Warning	PID differential term out of range	The calculated value of PID differential term exceeds-32768 – 32767
	0x0086 (134)	Warning	PID operation result out of range	PID calculation result exceeds-32768 – 32767
	0x0087 (135)	Warning	Instruction fetches ID number incorrectly	Check the compilation ID of the upper computer
	0x0001(1)	Serious error	Failed to open RTC device	Check whether the driver and hardware work properly
	0x0002(2)	Serious error	Failed to write RTC device	Check whether the driver and hardware work properly
0x0008(8)	0x0003(3)	Serious error	Failed to read RTC device	Check whether the driver and hardware work properly
	0x0004(4)	General error	Failed to read the real time of the system	Check whether the system works normally in real time
	0x0005(5)	Warning	Failed to read RTC time of	Check whether FPGA and RTC work

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			FPGA	properly
	0x0006(6)	Warning	Failure to write RTC time of FPGA	Check whether FPGA and RTC work properly
	0x0001(1)	General error	The IP segments of IP1 and IP2 repeat error	Misconfigure the network segments of IP1 and IP2.
	0x0011(17)	General error	Read: IP1 moduleOpen file to report error	Check whether network driver runs
	0x0012(18)	General error	Read: IP1 moduleUnable to get IP information	normally.
	0x0013(19)	General error		Check whether the data in the IP segment is valid (0-255).
	0x0014(20)	General error		Check whether the mask data is valid (0–255).
	0x0015(21)	General error	Write: IP1 moduleGateway configuration error	Check whether the gateway data is valid (0–255).
	0x0016(22)	General error		Ensure that the IP1 network segment is separated from the USB network segment (TM700192.168.3.x).
0x0009(9)	0x0017(23)	General error	gateway not in the same	The IP segment and gateway must be configured to the same network segment.
	0x0021(33)	General error	Read: IP2 moduleOpen file to report error	Check whether network driver runs
	0x0022(34)	General error	Read: IP2 moduleUnable to get IP information	normally.
	0x0023(35)	General error	Write: IP2 moduleIP address error	Check whether the data in the IP segment is valid (0–255).
	0x0024(36)	General error	Write: IP2 moduleMask error	Check whether the mask data is valid (0–255).
	0x0025(37)	General error	Write: IP2 moduleGateway error	Check whether the gateway data is valid (0–255).
	0x0026(38)	General error	Write: IP2 moduleUSB network segment repeat error	Ensure that the IP2 network segment is separated from the USB network segment (TM700192.168.3.x).
	0x0027(39)	General error		The IP segment and gateway must be configured to the same network segment.
	0x0001(1)	General error	The current axis ID is not in the valid range	Check whether the axis ID parameter setting is reasonable.
0x0011(17)	0x0002(2)	General error	The current function block ID is not in the valid range	Check whether the ID parameter setting of the upper computer function block is reasonable.
0,0011(17)	0x0003(3)	Warning	unreasonable and the current	Check whether the current axis state satisfies the PLCopen state machine switching process when the current instruction is triggered.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0004(4)	Warning	Axis configuration failed	Check whether the axis configuration is successful
	0x0005(5)	Warning	PDO parameter Digitallput address is NULL	1. Check whether the parameter is mapped in the slave station IO
	0x0006(6)	General error	Current axis error/servo error	If the axis/servo fails, you can call the MC_Reset instruction or restart the MC_Power instruction to clear the error.
	0x0007(7)	Warning		Switch to the Stanstill state by calling the MC_Power instruction axis.
	0x0008(8)	General error	Axis positive hard limit triggered	Call the reset instruction to switch the axis state from ErrorStop state to Standstill state
	0x0009(9)	General error	Axis negative hard limit triggered	Call the reset instruction to switch the axis state from ErrorStop state to Standstill state
	0x000A(10)	General error	Axis positive soft limit triggered	Call the reset instruction to switch the axis state from ErrorStop state to Standstill state
	0x000B(11)	General error	Axis negative soft limit triggered	Call the reset instruction to switch the axis state from ErrorStop state to Standstill state
	0x000C (12)	Warning	Pulse axis has no output device selected	Check whether the output device is selected for the pulse axis.
	0x000D (13)	Warning	Fieldbus has no output device selected.	Check whether the output device has been selected for fieldbus.
	0x000E(14)	Warning	The current instruction does not support repeated call technology.	The current instruction does not support repeated calls to function blocks, please avoid this situation intentionally.
	0x000F(15)	Warning	Axis type setting error	Check whether the axis type matches the instruction type.
	0x0010(16)	Warning	The fieldbus base PDO address is NULL	It is not recommended to map PDO parameters in slave device description file I/O mapping
	0x0011(17)	Warning	Positive hard limit ID configuration failed	Check whether the current pulse axis input and output points are reused
	0x0012(18)	Warning	Negative hard limit ID configuration failed	Check whether the current pulse axis input and output points are reused
	0x0013(19)	Warning	Probe ID1 configuration failed	Check whether the current pulse axis input and output points are

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				reused
	0x0014(20)	Warning	Probe ID2 configuration failed	Check whether the current pulse axis input and output points are reused
	0x0015(21)	Warning	Servo error ID configuration failed	Check whether the current pulse axis input and output points are reused
	0x0016(22)	Warning	Homing signal ID configuration failed	Check whether the current pulse axis input and output points are reused
	0x0017(23)	Warning	Z signal ID configuration failed	Check whether the current pulse axis input and output points are reused
	0x0018(24)	Warning	Axis enable ID configuration failed	Check whether the current pulse axis input and output points are reused
	0x0019(25)	Warning	Clear servo error ID configuration failed	Check whether the current pulse axis input and output points are reused
	0x001A(26)	Warning	The axis address is NULL	Check whether the axis is configured successfully
	0x001B(27)	Warning	Fieldbus axis enable failed	Fieldbus axis enable timeout, check whether EtherCAT communication and feedback status word are normal
	0x001C (28)	General error	Fieldbus does not enter Op state	Check whether EtherCAT communication is in OP state
	0x001D (29)	Warning	The current function block execution is invalid.	The current instruction function is not available yet, and it is invalid to use.
	0x001E(30)	Warning	Current axis communication timeout	Check whether EtherCAT communication is in OP state. Check whether the EtherCAT communication return value is normal.
	0x001F(31)	Warning	Under the current axis configuration, the EtherCAT synchronization period cannot be less than 1ms.	Check whether the setting of the synchronization cycle of the EtherCAT master station is less than 1ms (in case of mixed use of bus axis and pulse axis, the EtherCAT synchronization cycle cannot be less than 1 ms).
	0x0020(32)	Warning	PLC is not running.	Check whether the PLC toggle switch is set to Stop.
	0x0021(33)	Warning	Axis trigger software does not decelerate to stop.	The current axis is in the process of soft limit deceleration and stop, and the execution of the current trigger instruction is invalid.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0022(34)	Warning	The current instruction parameter address is NULL.	The current instruction parameter address is NULL, please give ar input variable or contact INVT technical service.
	0x0023(35)	General error	During the pulse axis movement, the pulse frequency of the current interpolation period is greater than or equal to 200K.	The maximum operating frequency of pulse axis is not allowed to exceed 200K, so it is recommended to reduce the speed of operation.
	0x0024(36)	Warning	Pulse axis FPGA cache reaches limit value.	Prompt only
	0x0025(37)	General error	The PDO data address in EtherCAT is NULL	Check whether the EtherCA ⁻ communication is normal.
	0x0026(38)	General error	The current servo axis is not online.	Check whether EtherCA ⁻ communication is normal; Check whether the current servo axis is plugged into the network cable connection
	0x0027(39)	Warning	Current axis communication failed	During running, EtherCA communication failed, chec EtherCAT communication status
	0x0028(40)	Warning	The PDO parameter StatusWord value is 0	Check whether the EtherCA communication is normal.
	0x0029(41)	Warning	PDO parameter ErrorCode address is NULL	 Check whether the EtherCA⁻ communication is normal. Check whether the PDC parameter is configured.
	0x002A(42)	Warning	Torque control is not supported on the current axis.	Check axis type configuration, an torque control only supports fieldbu axis.
	0x0065 (101)	Warning	Enable instruction status exception	Enable instruction status i abnormal, please contact INV technical service.
	0x0066 (102)	Warning	Reset instruction status exception	Reset instruction status is abnorma please contact INVT technica service.
	0x0067 (103)	Warning	Reset timeout	Axis reset timed out, please chec whether EtherCAT communication i normal.
	0x0068 (104)	Warning	Motion superposition is not supported in the current axis state.	If the current axis state does no support the superimposed motio command, refer to the specifi commands for using the command.
	0x0069 (105)	Warning	Input parameter error	Instruction input parameter is not i the valid range
	0x006A (106)	Warning	MC_Stop instruction repeated call error	Please check whether the same axi is called more than once
	0x006B	Warning	MC_ImmediateStop instruction	Please check whether the same axi

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	(107)		repeated call error	is called more than once
	0x006C (108)	General error	MC_Stop instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x006D (109)	General error	MC_Halt instruction input parameter is not in the valid range	Check whether the command parameters are within the valid
	0x006E (110)	Warning	MC_SetOverride instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x006F (111)	General error	MC_MoveVelocity instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0070 (112)	General error	MC_MoveRelative instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0071 (113)	General error	MC_MC_MoveAbsoulte instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0072 (114)	General error	MC_Jog instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0073 (115)	General error	MC_Inch instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0074 (116)	General error	MC_Home instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0075 (117)	Warning	MC_SetPosition instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0076 (118)	Warning	Invalid trigger of MC_SetOverride instruction in current axis state	The current axis is in the process of commutation, and the speed regulation is not effective.
	0x0077 (119)	Warning	operation of the axis group.	Run the axis after the axis group completes running.
	0x0078 (120)	Warning	Axis state is not in StandStill state.	Please switch the axis state to StandStill state before triggering the

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				current instruction.
	0x0079 (121)	Warning	Invalid MC_Reset instruction reset	The current axis state is not in ErrorStop state, and the reset is invalid.
	0x007A (122)	Warning	Invalid interpolation period value setting	Check EtherCAT synchronization cycle settings.
	0x007B (123)	Warning	Invalid trigger of MC_Stop instruction	Check whether the current axis state can trigger the instruction
	0x007C (124)	Warning	Invalid trigger of MC_Halt instruction	Check whether the current axis state can trigger the instruction
	0x007D (125)	Warning	Invalid trigger of MC_ImmediateStop instruction	Check whether the current axis state can trigger the instruction
	0x007E (126)	Warning	MC_TouchProbe instruction input parameter is not in the valid range	Please check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state.
	0x007F (127)	Warning	MC_MoveSuperImosed instruction input parameter is not in the valid range	Please check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state.
	0x0080 (128)	Warning	MC_Home instruction is called repeatedly	Please check whether the homing function block is called more than once on the same axis.
	0x0081 (129)	General error	MC_MoveFeed instruction input parameter is not in the valid range.	Please check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state.
	0x0082 (130)	Warning	The probe channel used is not configured	Check whether PDO data in "Process data" of the configuration interface of servo axis of upper computer has been added. (Possible mappings: 0x60B8, 0x60B9, 0x60BA, 0x60BB, 0x60BC, and 0x60BD)
	0x0083 (131)	Warning	Interrupt fixed-length function, when Mode=0 or 1, the probe signal has not arrived when the first segment is finished.	Check whether the probe signal is triggered correctly.
	0x0084 (132)	Warning	When the probe function is	Check the probe channels for
	0x0085 (133)	Warning	Ũ	Check whether the axis configuration index parameter is in the valid range
	0x0086 (134)	Warning	The axis parameter entered by	Please check whether the axis setting parameters are within the

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			range	
	0x0087 (135)	General error	MC_MoveBuffer instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0088 (136)	General error	MC_SyncMoveVelocity instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x0089 (137)	General error	MC_MoveVelocityCSV instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x008A (138)	General error	MC_SyncTorqueControl instruction input parameter is not in the valid range	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x008B (139)	Warning	PDO data used is not configured	The process data 0x6060 and 0x6061 in the servo configuration of the upper computer are not configured
	0x008C (140)	Warning	PDO data used is not configured	The process data 0x606C is not configured in the servo configuration of the upper computer
	0x008D (141)	Warning	PDO data used is not configured	The process data 0x60FF is not configured in the servo configuration of the upper computer.
	0x008E (142)	Warning	PDO data used is not configured	The process data 0x6071 and 0x607F are not configured in the servo configuration of the upper computer.
	0x008F (143)	Warning	PDO data used is not configured	The process data 0x6083 and 0x6084 are not configured in the servo configuration of the upper computer.
	0x0090 (144)	Warning	function is not supported in the	Check the current axis status and whether it meets the requirements of speed regulation function.
	0x0091 (145)	Warning		Check whether the current axis type is configured as bus axis.
	0x0092 (146)	General error	MC_TorqueControl instruction input parameter is not in the valid range	Check whether the instruction parameters are within the valid range, and call the MC_Reset instruction to reset the axis state.
	0x0093 (147)	Warning	empty	Check whether 0x6077 or 0x6087 is mapped in the servo "process data".
	0x0094 (148)	Warning	Failed to switch to the target control mode	Check whether the bus communication is normal.

ain fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0095 (149)	Warning	Failed to write SDO parameters	Check whether the bus communication is normal
	0x0096 (150)	General error	MC_Homing instruction input parameter is not in the valid range	Check whether the instruction parameters are within the valid range, and call the MC_Reset instruction to reset the axis state.
	0x0097 (151)	Warning	MC_Homing instruction triggered repeatedly with error	Check whether the same axis has been called more than once
	0x0098 (152)	Warning	MC_Homing/MC_Home instruction timeout error	Check whether the Max. homing time setting is correct.
	0x0099 (153)	Warning	Control mode is switching	Check whether the bus communication is normal.
	0x00C9 (201)	Warning	The master and slave axes use the same axis ID	Check whether the master and slave axes are the same.
	0x00CA (202)	General error	Input parameter error of MC_GearOut function block	Check whether the input parameters of GearOut are within the constraint range of the command parameter list.
	0x00CB (203)	Warning	Invalid trigger of MC_GearOut function block	Check whether the slave axis is in gear action, and check whether the slave axis is in gear engagement action
	0x00CC (204)	General error	Input parameter error of MC_GearIn function block	Check whether the input parameters of MC_GearIn are within the constraint range of the command parameter list.
	0x00CD (205)	Warning		Check whether the master axis state meets the requirements; Run the MC_Phasing instruction to check whether the current axis is in cam or gear action
	0x00CE (206)	Warning	The master axis has not reached the target velocity.	Check whether the current master axis has reached the target velocity.
	0x00CF (207)	General error	Input parameter error of MC_CamOut function block	Check whether the input parameters of MC_CamOut are within the constraint range of the command parameter list.
	0x00D0 (208)	Warning	Invalid trigger of MC_CamOut function	Check whether the slave axis is in cam action, and check whether the slave axis is in cam engagement action
	0x00D1 (209)	General error	Input parameter error of MC_CamIn function block	Check whether the input parameters of MC_CamIn are within the constraint range of the command parameter list.
	0x00D2 (210)	Warning	The current CamTable ID is not within the valid range.	Check whether the CamTable ID is within the constraint range of the command parameter list.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x00D3 (211)	Warning	Setting error of StartPosition or MasterStartDistance in MC_CamIn command	Check whether MasterStartDistance and StartPosition are in the current master axis running direction in absolute position mode
	0x00D4 (212)	Warning	The MC_CamIn instruction is in absolute position mode, with StartPosition ahead of MasterStartDistance	Check whether StartPosition is ahead of MasterStartDistance in the absolute position mode.
	0x00D5 (213)	General error	The input parameters of the MC_Phasing command are not within the valid range.	Check whether the input parameters of MC_Phasing are within the constraint range of the command parameter list.
	0x00E1 (225)	Warning	Master axis phase setting error	Check whether the master axis phases of two adjacent keypoints are less than or equal to 0.001 in the user-defined cam table of the MC_GenerateCamTable command.
	0x00E2 (226)	Warning		Check whether the positions of the master and slave axes at the start point of the cam are set to non-zero in the user-defined cam table of the MC_GenerateCamTable command.
	0x00E3 (227)	Warning	The current NodeNum parameter cannot be set to 0	Check whether the MC_NodeNum parameter is set to 0 in the current mode in the GenerateCamTable command.
	0x00E4 (228)	Warning		Check whether the MC_NodeNum parameter is set within the constraint range of the command parameter list in the current mode in the GenerateCamTable command.
	0x00E5 (229)	Warning	Curve type setting error in cam table	Check whether the cam curve type settings are within the constraint range of the command parameters list. They only support 0 (which represents straight lines) and 1 (which represents quintic curves).
	0x00E6 (230)	Warning	The cam table is empty	Check whether the cam table is configured
	0x00E7 (231)	Warning	Encoder master axis enable failed	Check whether the count instruction ENC_Counter is enabled when the encoder master axis is being used.
	0x00E8 (232)	Warning	The length of the user-defined cam table is not within the valid range	Check that the length of the user-defined cam table array must be 32 in the MC_GenerateCamTable command
	0x00E9 (233)	Warning	Custom tappet switch is not in the valid range	Check that the length of the user-defined switch array must be

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				32 in the MC_DigitalCamSwitch command.
	0x00EA (234)	Warning		Check whether the ReferenceType parameter setting is in the valid range for the current instruction.
	0x00EB (235)	Warning	Channel parameter setting is not in the valid range	Check whether the current instruction and Channel parameter setting are within the valid range.
	0x00EC (236)	Warning	The Number parameter setting is not in the valid range.	Check whether the Number parameter setting of the current instruction is within the valid range.
	0x00ED (237)	Warning	The Switches parameter address is NULL.	Check whether the Switches parameter of the current instruction has a given variable.
	0x00EE (238)	Warning	In the tappet switch, the position is not ascending.	Check whether the Position in the Switches parameter is ascending in the current instruction, if not, please modify it
	0x00EF (239)	Warning	The current axis state does not support the use of tappet instruction.	Check whether the axis state is in the homing state.
	0x00F0 (240)	Warning	Action setting is not in the valid range in tappet switch.	Check whether the Action in the Switches parameter of the current instruction is within the specified valid range.
	0x00F1 (241)	Warning	The Channel is currently in use.	Check whether the Channel is reused.
	0x00F2 (242)	Warning		Check whether the Position in the Switches parameter of the current instruction exceeds the rotation period value in the rotating axis mode.
	0x00F3 (243)	General error	The input parameters of the MC_CombineAxes instruction are not within the valid range.	Check whether the command parameters are within the valid range, and call the MC_Reset command to reset the axis state
	0x00F4 (244)	Warning	Phase of the MC_GetCamTableDistance command is not within the valid range between the start and end points.	Check whether the input parameter Phase of this command is within the valid range between the start and end points.
	0x00F5 (245)	Warning	CurveType parameter setting is not in a valid range	Check whether the CurveType parameter setting is in the valid range for the current instruction.
	0x00F6 (246)	Warning	MC_GetCamTableDistance	Check if the phase difference between the start and end points for this command is less than 0.001 Check whether Phase in CamTable

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			ascending order.	is in ascending order
	0x00F7 (247)	Warning		Check the reason why the master axis has entered the ErrorStop state.
	0x00F8 (248)	Warning	-	Check whether the user program uses multiple cam tables to save instructions on the same axis.
	0x00F9 (249)	Warning	update is not completed and	Check whether the user program has not completed the cam table update command and has called the cam table save command instead.
	0x012D (301)	General error	Function block input parameter error	In plane arc interpolation mode 2, if the distance between the start and end points is greater than twice the radius, check and correct the parameters.
	0x012E (302)	General error	Axis group ID settings exceeds the range	Check and correct the axis group ID
	0x012F (303)	General error	Two or more identical axis IDs are configured in the axis group	Check and correct the duplicated axis IDs in the axis group configuration interface
	0x0130 (304)	General error	to the circle center is not equal to that from the end point to the	In plane arc interpolation mode 1, check and modify the distance from the start point to the circle center and that from the and end point to the circle center.
	0x0131 (305)	General error	and end point are on the same	In planar arc interpolation mode 0, the starting point, the auxiliary point and the ending point are in a straight line.
	0x0132 (306)	General error		In plane arc interpolation mode 2, ensure that the start point is equal to the end point.
	0x0133 (307)	General error		For the same axis group, the second immediate axis group stop module reports error.
	0x0134 (308)	General error	Axis group is in GroupImmediateStopping state	Pull down the MC_GroupImmediateStop module first, and then pull up the MC_GourpStop module.
	0x0135 (309)	General error	this function block once, and	For the same axis group, the second

N	lain fault code	Sub fault code	Error level	Meaning of error	Solutions
		0x0136 (310)	General error	The configured velocity parameters are not within a reasonable range	Check the corresponding parameters
		0x0137 (311)	General error	The configured acceleration parameters are not within a reasonable range	Check the corresponding parameters
		0x0138 (312)	General error	The configured deceleration parameters are not within a reasonable range	Check the corresponding parameters
		0x0139 (313)	General error	The configured Jerk parameters are not within a reasonable range	Check the corresponding parameters
		0x013A (314)	General error	The configured AbsRelMode parameters are not within a reasonable range	Check the corresponding parameters
		0x013B (315)	General error		De-select the rotation mode option in the single axis configuration interface
		0x013C (316)	General error	Interpolation is not allowed as there a single axis is in the debugging mode in the axis group	De-select the debugging model
		0x013D	General	The radius parameter is not	Check the corresponding
		(317)	error	allowed to be zero	parameters
		0x013E	General	The parameter CircAxes is not	Check the corresponding
		(318)	error	within the allowed range	parameters
		0x013F	General	The parameter CircMode is not	
	·	(319)	error	within the allowed range	parameters
		0x0140	General	The parameter PathChoice is	
		(320) 0x0141 (321)	error General error	not within the allowed range The array parameters passed in by the upper computer are incorrect	parameters Enable upper computer error protection
		0x0142 (322)	General error	-	Interrupt the arc interpolation first, and then modify the parameter CircAxes
		0x0143 (323)	General error		The current state does not allow axis group velocity regulation, including moderate axis group deceleration
		0x0144 (324)	General error	An unconfigured axis group number has been used	Configure an axis group number for the used axis group in the "Axis Group Settings" list on the upper computer
		0x0145 (325)	General error	There is a pulse axis velocity exceeding 200kHz	There is a pulse axis velocity exceeding 200kHz
		0x0146 (326)	General error	Two axis groups use the same axis, so that when one axis group is in motion state, the	Modify the reused axis, or run two axis groups at different times.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			other axis group cannot enter	
-			the motion state.	
	0x0147 (327)	Warning	Multiple cam table save instructions are used in the same cam table.	Check the cam table sav instructions in the ladder diagram.
	0x0148 (328)	Warning	The instruction update is not completed and the save instruction is called.	Check the order of calling the updat instruction and save instruction.
	0x0101 (257)	General error	System configuration-Code header frame configuration error	
	0x0102 (258)	General error	System configuration-Code length configuration error	
-	0x0103	General	System configuration-Code	
	(259)	error	module type configuration error	
-	0x0104 (260)	General error	System configuration-Code	Update the corresponding version the host controller or conta technical support.
	0x0105 (261)	General error	System Configuration-Parameter module type configuration error	
	0x0106 (262)	General error	System Configuration-Parameter module length configuration error	
	0x0201 (513)	Warning	Counter reset module-Axis ID exceeds maximum value	
0x0012(18)	0x0202 (514)	Warning	Counter reset module-This axis does not belong to encoder axis	
-	0x0203 (515)	Warning	Counter reset module-Axis number not configured	
-	0x0301 (769)	Warning	Comparator reset module-Axis ID exceeds maximum value	
(0) (0) (1 0) (1 0)	0x0302 (770)	Warning	Counter reset module-This axis does not belong to encoder axis	Configure the correct axis ID.
	0x0303 (771)	Warning	Counter reset module-Axis number not configured	
	0x0401 (1025)	Warning	Preset module-Axis ID exceeds maximum value	
	0x0402 (1026)	Warning	Preset module-This axis does not belong to encoder axis	
	0x0403 (1027)	Warning	Preset module-No axis number configured	
	0x0404 (1028)	Warning	Preset module-TrigerMode trigger mode parameter exception	Configure the correct TrigerMoor range parameter (0–3).

code	code	Error level	Meaning of error	Solutions
	0x0405 (1029)	Warning	Preset module-Preset position out of range	Configure preset positions within th specified range.
	0x0406 (1030)	Warning	Preset module-No preset position configured	Configure the preset position.
	0x0501 (1281)	Warning	Counter module-Axis ID exceeds maximum value	
	0x0502 (1282)	Warning	Counter module-This axis does not belong to encoder axis	
	0x0503 (1283)	Warning	Counter module-Axis number not configured	
	0x0601 (1537)	Warning	Comparator module-Axis ID exceeds maximum value	Configure the correct axis ID.
	0x0602 (1538)	Warning	Comparator module-This axis does not belong to encoder axis	
	0x0603 (1539)	Warning	Comparator module-Axis number not configured	
	0x0604 (1540)	Warning	Comparator module-Comparison position out of limit	Configure comparison values with the specified range.
	0x0605 (1541)	Warning	Comparator module-No comparison position configured	Configure comparison values.
	0x0606 (1542)	Warning	Comparator module-System does not enable hardware comparison output for this axis	Enable hardware comparison outp in the axis setting interface.
	0x0607 (1543)	Warning	Comparator module-Interrupt number out of range	Configure the interrupt numb within the range of 0-16.
	0x0608 (1544)	Warning	Comparator module-Undefined interrupt function	Generate the correspondir interrupt function in the program.
	0x0701 (1793)	Warning	One-dimensional step length comparison module-Axis ID exceeds maximum value	
	0x0702 (1794)	Warning	One-dimensional step length comparison module-This axis does not belong to encoder axis	
	0x0703 (1795)	Warning	One-dimensional step comparison module-Axis number not configured	
	0x0704 (1796)	Warning	One-dimensional step length comparison module-Starting position out of range	
	0x0705 (1797)	Warning	One-dimensional step length comparison module-End position out of range	Configure the position value with the specified range.
	0x0706 (1798)	Warning	One-dimensional step length comparison module-Single	

Main fault	Sub fault	Error		
code	code	level	Meaning of error	Solutions
	(1799)		comparison module-Starting	
			position not configured	
	0x0708		One-dimensional step	
	(1800)	0) Warning	comparison module-End	
	(,		position not configured	
	0x0709		One-dimensional step length	
	(1801)	Warning	comparison module-Single	
			step position not configured	
	0x070A		One-dimensional step	Enable hardware comparison output
	(1802)	Warning	comparison module-System does not enable hardware	
	(1802)		comparison output for this axis	in the axis setting interface.
			One-dimensional step length	
	0x070B	Warning	comparison module-Interrupt	Configure the interrupt number
	(1803)	, runnig	number out of range	within the range of 0–16.
			One-dimensional step length	
	0x070C	Warning	comparison module-Undefined	Generate the corresponding
	(1804)		interrupt function	interrupt function in the program.
			Linear mode-The starting	-
	0x070D	14/	position is less than the ending	The starting position is less than the
	(1805)	Warning	position, and the single step	ending position, and the single step position is positive.
			position is positive	
			Linear mode-The starting	The starting position is greater than
	0x070E	Warning	position is greater than the	the ending position, and the
	(1806)	, runnig	ending position, and the	single-step position is negative.
			single-step position is negative	
	0x0801		Linear array comparison	
	(2049)	Warning	module-Axis ID exceeds	
			maximum value	
	0x0802	Warning	Linear array comparison module-This axis does not	Configure the correct axis ID
	(2050)	warning	belong to encoder axis	Configure the correct axis iD.
			Linear array comparison	
	0x0803	Warning	module-Axis number not	
	(2051)	j	configured	
	0x0804		Linear array comparison	
	(2052)	Warning	module-Array not configured	Configure array position.
	0x0805			The length of the array is less than
	(2053)	Warning	module-Array greater than 100	100.
	00000		Linear array comparison	The length of the survey is to di
	0x0806	Warning	module-Array size out of array	The length of the array is less than
	(2054)		range	array boundary.
	0x0807		Linear array comparison	
	(2055)	Warning	module-Array size not	Configure array size.
	(2000)		configured	
	0x0808		Linear array comparison	Enable hardware comparison output
	(2056)	Warning	module-System does not	in the axis setting interface.
	(2000)		enable hardware comparison	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			output for this axis	
	0x0809 (2057)	Warning	Linear array comparison module-Interrupt number out of range	Configure the interrupt number within the range of 0–16.
	0x080A (2058)	Warning	Linear array comparison module-Undefined interrupt function	Generate the corresponding interrupt function in the program.
	0x080B (2059)	Warning	Array size ≤ 0	Array length is greater than 0.
	0x0901 (2305)	Warning	Probe module-Axis ID exceeds maximum value	
	0x0902 (2306)	Warning	Probe module-This axis does not belong to encoder axis	Configure the correct axis ID.
	0x0903 (2307)	Warning	Probe module-No axis number configured	
	0x0904 (2308)	Warning	Probe module-Probe number parameter error	Probe number range: 0–1.
	0x0905 (2309)	Warning	Probe module-No probe number configured	Configure probe number.
	0x0906 (2310)	Warning	Probe module-Edge parameter error	Edge parameter range: 0–2
	0x0907 (2311)	Warning	Probe module-Edge parameters not configured	Configure edge parameters.
	0x0908 (2312)	Warning	Probe module-Trigger mode parameter error	Mode parameter range: 0–1
	0x0909 (2313)	Warning	parameter out of range	Configure position parameters withir the specified range.
	0x090A (2314)	Warning	parameter out of range	Configure position parameters withir the specified range.
	0x090B (2315)	Warning	enabled	Enable probe in the axis setting interface.
	0x090C (2316)	Warning	In linear mode, the initial value is greater than or equal to the end value	In linear mode, the initial value is less than the end value.
	0x0A01 (2561)	Warning	Linear mode configuration-Axis ID exceeds maximum value	
	0x0A02 (2562)	Warning	Linear mode configuration-This axis does not belong to encoder axis	Configure the correct axis ID.
	0x0A03 (2563)	Warning	Linear mode configuration-No axis number configured	
	0x0A04 (2564)	Warning	Linear mode configuration-Mode selection parameter error (0–1)	Mode selection parameter 0–1
	0x0A05 (2565)	Warning	Linear mode configuration-Mode selection parameter not configured	Mode parameters are no configured.
	0x0A06	Warning		Configure software limit paramete

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	(2566)		configuration-Software limit enable parameter not configured	
	0x0A07 (2567)	Warning	Linear mode configuration-Positive limit configuration out of range value	
	0x0A08 (2568)	Warning	Linear mode	Configure the position value within the specified range.
	0x0A09 (2569)	Warning	Linear mode configuration-Period value position out of range value	
	0x0A0A (2570)	Warning	Linear mode configuration-Positive limit parameter not configured	Configure positive limit parameters.
	0x0A0B (2571)	Warning	Linear mode configuration-Negative limit parameter not configured	Configure negative limit parameters.
	0x0A0C (2572)	Warning	Linear mode configuration-Period value parameter not configured	Configure cycle values.
	0x0A0D (2573)	Warning	The period value is zero	Cycle values must not be zero.
	0x0A0E (2574)	Warning	Negative limit is greater than positive limit	Positive limit is greater than negative limit.
	0x0B01 (2817)	Warning	Gear ratio mode configuration-Axis ID exceeds maximum value	
	0x0B02 (2818)	Warning	Gear ratio mode configuration-This axis does not belong to encoder axis	
	0x0B03 (2819)	Warning	Gear ratio mode configuration-No axis number configured	
	0x0B04 (2820)	Warning	Gear ratio mode configuration-Parameters for one revolution of encoder not configured	Configure parameters for one
	0x0B05 (2821)	Warning	Gear ratio mode	Configure parameters for one
	0x0B06 (2822)	Warning	Gear ratio mode configuration-Maximum value of gear ratio numerator parameter not configured	
	0x0B07	Warning	Gear ratio mode	Configure gear ratio denominator

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	(2823)		denominator parameter not	parameter.
	0x0001(1)	Warning	configured Axle number out of range	Check the axis number setting.
	0x0002(2)		Axis number does not exist in CANopen configuration or PDO configuration error	Check CANopen configuratio setting.
	0x0003(3)	Warning	Absolute position instruction speed ≤ zero	
	0x0004(4)	Warning	Absolute position instruction speed ≤ zero	Check the speed parameter in th
	0x0005(5)	Warning	Speed mode instruction speed ≤ zero	instruction.
	0x0006(6)	Warning	Jog instruction speed ≤ zero	
	0x0007(7)	Warning	Absolute position instruction	Check the DEC speed parameter i the instruction.
	0x0008(8)	Warning	-	Check the DEC speed parameter i the instruction.
	0x0009(9)	Warning		Check the DEC speed parameter i the instruction.
	0x000A(10)	Warning	Jog instruction DEC speed ≤ zero	Check the DEC speed parameter i the instruction.
	0x000B(11)	Warning	Homing failed	Check whether disconnectio occurred.
0x0013(19)	0x000C (12)	Warning	Homing timeout	Check CANopen configuration PD setting.
	0x000D (13)	Warning	The axis is not enabled, and the current instruction cannot be executed	
	0x000E(14)	Warning	Not in "Fault Stop State", the reset axis error instruction cannot be executed	
	0x000F(15)	Warning	The axis is in the "Stop" state, and the current instruction cannot be executed	
	0x0010(16)	Warning	The axis is homing, and the current instruction cannot be executed	
	0x0011(17)	Warning	The axis is moving continuously, and the current instruction cannot be executed	Check the axis state.
	0x0012(18)	Warning	The axis is positioning, and the current instruction cannot be executed	
	0x0013(19)	Warning	The axis is in the "Fault Stop" state, and the current instruction cannot be executed	
	0x0014(20)	Warning	Axis enable timeout	Check whether CANope

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0015(21)	Warning	CANopen is not configured	configuration setting is correct.
	0x0016(22)	Warning	Fault reset timeout	
	0x0017(23)		SDO write timeout	Check whether the line connection is
	0x0018(24)	Warning	SDO read timeout	normal
	0x0019(25)		SDO instruction error	
	0x001A(26)	Warning	Software limit reached in axis operation	Check the software limit settings.
	0x001B(27)	Warning	Axis absolute positioning failure	Check whether the line connection i
	0x001C (28)	Warning	Axis relative positioning failure	normal
	0x001D (29)	Warning	Homing speed set incorrectly	Check whether the instruction spee parameters are set correctly.
	0x001E(30)	Warning	Axis halt instruction execution timeout	Check whether the line connection i normal
	0x001F(31)	Warning	Homing approach speed is set incorrectly	Check whether the homing approach speed parameters are se correctly in the CANoper configuration.
	0x0020(32)	Warning	Homing acceleration set incorrectly	Check whether the homing ACC parameters are set correctly in the CANopen configuration.
	0x0021(33)	Warning	Speed operation instruction execution failure	Check whether the line connection i
	0x0022(34)	Warning	Jog instruction execution failure	normal
	0x0023(35)	Warning		Check whether the Power instructio is called twice for the same axi number.
	0x0024(36)	General error	The slave corresponding to the axis is offline	Check the communication state of the slave or whether the slave i enabled.
0x0030(48)	0x0001(1)	General error	Module configuration fault	Check whether the networ configuration corresponds to th physical configuration of the module
	0x0002(2)	Warning	Incorrect module parameter setting	Check module paramete configuration
	0x0001(1)	General error	Digital input module configuration fault	Check whether the networ configuration corresponds to th physical configuration of the module
	0x0002(2)	Warning	Digital input module parameter configuration failure	Check module paramete configuration
0x0031(49)	0x2001 (8193)	General error	Digital output module configuration failure	Check whether the networ configuration corresponds to th physical configuration of the module
	0x2002 (8194)	Warning	Digital output module parameter configuration failure	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	(8195)		port power supply failure	supply
	0x2004 (8196)	Warning	Digital output module output failure	Check whether the module outpu port load exceeds the specification range
	0x0001(1)	General error	Analog input module configuration failure	Check whether the networ configuration corresponds to th physical configuration of the module
	0x0012(18)	Warning	Analog input channel 0 parameter configuration failure	Check channel 0 paramete configuration
	0x0015(21)	Warning	Analog input channel 0 signal source open circuit fault	Check the physical connection c Channel 0 signal source
	0x0016(22)	Warning	Analog input channel 0 sampling signal out of limit fault	Check whether the channel sampling signal exceeds the chi limit
	0x0017(23)	Warning	5 1	Check whether the channel sampling signal exceeds the upper range
	0x0018(24)	Warning	5 1	Check whether the channel sampling signal exceeds the lowe range
	0x0022(34)	Warning	Analog input channel 1 parameter configuration failure	Check channel 1 paramete configuration
	0x0025(37)	Warning	Analog input channel 1 signal source open circuit fault	Check the physical connection of Channel 1 signal source
0x0032(50)	0x0026(38)	Warning	Analog input channel 1 sampling signal out of limit fault	Check whether the channel sampling signal exceeds the chi limit
	0x0027(39)	Warning	0	Check whether the channel sampling signal exceeds the upper range
	0x0028(40)	Warning	Analog input channel 1	Check whether the channel sampling signal exceeds the lowe range
	0x0032(50)	Warning	Analog input channel 2 parameter configuration failure	Check channel 2 paramete configuration
	0x0035(53)	Warning	Analog input channel 2 signal source open circuit fault	Check the physical connection of Channel 2 signal source
	0x0036(54)	Warning	Analog input channel 2 sampling signal out of limit fault	Check whether the channel sampling signal exceeds the chi limit
	0x0037(55)	Warning	0	Check whether the channel sampling signal exceeds the upper range
	0x0038(56)	Warning	Analog input channel 2	Check whether the channel sampling signal exceeds the lower range
	0x0042(66)	Warning		Check channel 3 paramete

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0045(69)	Warning		Check the physical connection of
			source open circuit fault	Channel 3 signal source
	00040(70)	\ A /	Analog input channel 3	Check whether the channel 3
	0x0046(70)	Warning	sampling signal out of limit fault	sampling signal exceeds the chip limit
			Analog input channel 3	Check whether the channel 3
	0x0047(71)	Warning	sampling signal exceeds upper	sampling signal exceeds the upper
			limit fault	range
			Analog input channel 3	Check whether the channel 3
	0x0048(72)	Warning	sampling signal exceeds the	sampling signal exceeds the lowe
			lower range	range
	0x2001	General	Analog output module	Check whether the network
	(8193)	error	configuration fault	configuration corresponds to the
				physical configuration of the module
	0x2003	Warning		Check the module output port power
	(8195) 0x2012		port power supply failure Analog output channel 0	supply Check channel 0 parameter
	(8210)	Warning	Analog output channel 0 parameter configuration failure	•
	0x2014		Analog output channel 0 output	-
	(8212)	Warning	fault	short/open circuit
	0x2022			Check channel 1 parameter
	(8226)	Warning	parameter configuration failure	
	0x2024	10/	Analog output channel 1 output	Check channel 1 output for
	(8228)	Warning	fault	short/open circuit
	0x2032	Warning	Analog output channel 2	Check channel 2 parameter
	(8242)	wanning	parameter configuration failure	•
	0x2034	Warning	Analog output channel 2 output	•
	(8244)		fault	short/open circuit
	0x2042 (8258)	Warning	Analog output channel 3 parameter configuration failure	Check channel 3 parameter
	0x2044		Analog output channel 3 output	•
	(8260)	Warning	fault	short/open circuit
				Check whether the network
	0x0001(1)	General	Temperature sampling module	configuration corresponds to the
		error	configuration failure	physical configuration of the module
			Temperature sampling channel	Check channel 0 paramete
	0x0012(18)	Warning	0 parameter configuration	configuration
			failure	comparation
			Temperature sampling channel	Check the physical connection o
0x0033(51)	0x0015(21)	Warning	0 signal source open circuit	Channel 0 signal source
			fault	
	0.001-1			Check whether the channel (
	0x0017(23)	Warning		sampling signal exceeds the upper
			upper range	range
	0x0018(24)	Warning	Temperature sampling channel	Check whether the channel C sampling signal exceeds the lower
	0,0010(24)	wanning	lower range	range
			Temperature sampling channel	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			1 parameter configuration failure	configuration
	0x0025(37)	Warning	Temperature sampling channel 1 signal source open circuit fault	Check the physical connection c Channel 1 signal source
	0x0027(39)	Warning		Check whether the channel sampling signal exceeds the upper range
	0x0028(40)	Warning		Check whether the channel sampling signal exceeds the lowe range
	0x0032(50)	Warning	Temperature sampling channel 2 parameter configuration failure	Check channel 2 paramete configuration
	0x0035(53)	Warning	Temperature sampling channel 2 signal source open circuit fault	Check the physical connection Channel 2 signal source
	0x0037(55)	Warning		Check whether the channel sampling signal exceeds the upport range
	0x0038(56)	Warning	Temperature sampling channel 2 sampling signal exceeds the lower range	Check whether the channel sampling signal exceeds the low range
	0x0042(66)	Warning	Temperature sampling channel 3 parameter configuration failure	Check channel 3 paramet
	0x0045(69)	Warning	Temperature sampling channel 3 signal source open circuit fault	Check the physical connection Channel 3 signal source
	0x0047(71)	Warning	Temperature sampling channel 3 sampling signal exceeds the upper range	Check whether the channel sampling signal exceeds the upp range
	0x0048(72)	Warning	Temperature sampling channel 3 sampling signal exceeds the lower range	Check whether the channel sampling signal exceeds the low range
	0x0001(1)	General error	Module configuration does not match	Check whether the module netwo configuration corresponds to th physical configuration
	0x0002(2)	Warning	Module parameter configuration fault	Check the module configuration parameters
0x0034(52)	0x0003(3)	Warning	Module output port power supply fault	Check the module output port pow supply
(- 7	0x0004(4)	Warning	Module output port fault	Check the module output port
	0x0012(18)	Warning	Module channel 0 parameter configuration fault	Check the parameter configuration of module channel 0
	0x0014(20)	Warning	Module channel 0 output fault	Check the output of module chann 0
	0x0015(21)	Warning	Module channel 0 signal	Check the physical connection

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
coue	code	level	source open circuit fault	channel 0 signal source
	0x0016(22)	Warning	Module channel 0 sampling signal out of limit fault	Check whether the sampling signa of module channel 0 exceeds the limit
	0x0017(23)	Warning	Module channel 0 sampling signal exceeds the upper range	Check whether the sampling signal of module channel 0 exceeds the upper range
	0x0018(24)	Warning	Module channel 0 sampling signal exceeds the lower range	Check whether the sampling signa of module channel 0 exceeds th lower range
	0x0022(34)	Warning	Module channel 1 parameter configuration fault	Check the parameter configuratio of module channel 1
	0x0023(35)	Warning	Module channel 1 output fault	Check the output of module channe 1
	0x0024(36)	Warning	Module channel 1 signal source open circuit fault	Check the physical connection or channel 1 signal source
	0x0025(37)	Warning	Module channel 1 sampling signal out of limit fault	Check whether the sampling signa of module channel 1 exceeds th limit
	0x0026(38)	Warning	Module channel 1 sampling signal exceeds the upper range	Check whether the sampling signa of module channel 1 exceeds th upper range
	0x0027(39)	Warning	Module channel 1 sampling signal exceeds the lower range	Check whether the sampling signa of module channel 1 exceeds th lower range
	0x0028(40)	Warning	Module output port power supply fault	Check the module output port powe supply
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning		Check whether the addres configuration accessed by th master connected with PLC is legal
	0x0003(3)	Warning	,	Check whether the value included in the master's query to the server (of the slave) is not allowed.
0x0040(64)	0x0004(4)	Warning	,	Check whether the maste connected with the PLC configured correctly
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connectio is normal
	0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection i normal
	0x0008(8)	Warning		Check whether the baud rate, dat bit and parity bit are configure correctly

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, data bit and parity bit are configured correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	Check the element address
	0x000B(11)	Warning	•	Check the master connected wit PLC
	0x000C (12)	Warning	The received slave address does not match the requested slave address	Check the slave connected with PL
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PL
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuratio of the upper computer; Re-downloa the program
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning		Check whether the addres configuration accessed by th master connected with PLC is legal
	0x0003(3)	Warning	exception code 03, illegal data	Check whether the value included i the master's query to the server (o the slave) is not allowed.
	0x0004(4)	Warning		Check whether the maste connected with the PLC i configured correctly
0x0041(65)	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connectio is normal
	0x0007(7)	Warning	-	Check whether the line connection i normal
	0x0008(8)	Warning		Check whether the baud rate, dat bit and parity bit are configure correctly
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, dat bit and parity bit are configure correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or	Check the element address

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			sent exceeds the storage space of the element)	
	0x000B(11)	Warning	The length of data received does not conform to the protocol or the number of	Check the master connected with PLC
	0x000C (12)	Warning	The received slave address does not match the requested slave address	Check the slave connected with PLC
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PL
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the upper computer; Re-downloan the program
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning	,	Check whether the addres configuration accessed by th master connected with PLC is lega
	0x0003(3)	Warning	exception code 03, illegal data	Check whether the value included the master's query to the server (the slave) is not allowed.
	0x0004(4)	Warning	,	Check whether the mast connected with the PLC configured correctly
0x0042(66)	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connection
	0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection normal
	0x0008(8)	Warning		Check whether the baud rate, da bit and parity bit are configure correctly
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, da bit and parity bit are configure correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	Check the element address
	0x000B(11)	Warning	The length of data received does not conform to the protocol or the number of	Check the master connected wire PLC

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			elements exceeds the maximum limit specified by the function code	
	0x000C (12)	Warning	The received slave address	Check the slave connected with PLC
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PLC
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the upper computer; Re-download the program
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning	,	Check whether the addres configuration accessed by th master connected with PLC is legal
	0x0003(3)	Warning		Check whether the value included in the master's query to the server (of the slave) is not allowed.
	0x0004(4)	Warning	,	Check whether the master connected with the PLC configured correctly
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connection
	0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection normal
0x0043(67)	0x0008(8)	Warning		Check whether the baud rate, dat bit and parity bit are configure correctly
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, dat bit and parity bit are configure correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	Check the element address
	0x000B(11)	Warning	The length of data received does not conform to the protocol or the number of	Check the master connected with PLC
	0x000C (12)	Warning	The received slave address does not match the requested	Check the slave connected with PL

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			slave address	
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PLC
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the upper computer; Re-download the program
	0x0001(1)	Warning	Standard Modbus error,	Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning	exception code 02, illegal	Check whether the address configuration accessed by the master connected with PLC is legal
	0x0003(3)	Warning	exception code 03, illegal data	Check whether the value included in the master's query to the server (or the slave) is not allowed.
	0x0004(4)	Warning	Standard Modbus error, exception code 04, slave device failure	Check whether the master connected with the PLC is configured correctly
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connection
	0x0007(7)	Warning		Check whether the line connection is normal
0x0044(68)	0x0008(8)	Warning		Check whether the baud rate, data bit and parity bit are configured correctly
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, data bit and parity bit are configured correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	Check the element address
	0x000B(11)	Warning	•	Check the master connected with PLC
	0x000C (12)	Warning	slave address	Check the slave connected with PLC
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PLC
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				of the upper computer; Re-download the program
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning		Check whether the address configuration accessed by the master connected with PLC is legal
	0x0003(3)	Warning		Check whether the value included in the master's query to the server (or the slave) is not allowed.
	0x0004(4)	Warning	Standard Modbus error, exception code 04, slave device failure	Check whether the master connected with the PLC is configured correctly
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connection is normal
	0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection is normal
	0x0008(8)	Warning		Check whether the baud rate, data bit and parity bit are configured correctly
0x0045(69)	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, data bit and parity bit are configured correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	Check the element address
	0x000B(11)	Warning		Check the master connected with PLC
	0x000C (12)	Warning	The received slave address does not match the requested slave address	Check the slave connected with PLC
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PLC
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the upper computer; Re-download the program
0x0046(70)	0x0001(1)	Warning	COM port parameters not configured	Choose the serial freeport in the upper computer and configure the parameters of the serial port

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0002(2)	Warning	-	Check the transmit length or receive length
	0x0003(3)	Warning	Element address overflow (the	Check the receive or transmit buffer element address and the transmit or receive length of instruction parameters
	0x0004(4)	Warning	Port setting error	Check whether the Port setting in the instruction is correct
	0x0005(5)	Warning	Transmit instruction execution failed	Retry
	0x0006(6)	Warning	Receive instruction execution failed	Retry
	0x0007(7)	Warning	Incomplete received data	Check the length of data transmitted by the sender
	0x0008(8)	Warning	Receive data timeout	Check whether the serial line connection is normal
	0x0009(9)	Warning	Instruction execution failed	Retry
	0x0001(1)	Warning	COM port parameters not configured	Choose the serial freeport in the upper computer and configure the parameters of the serial port
	0x0002(2)	Warning	-	Check the transmit length or receive length
	0x0003(3)	Warning		Check the receive or transmit buffer element address and the transmit or receive length of instruction parameters
0x0047(71)	0x0004(4)	Warning	Port setting error	Check whether the Port setting in the instruction is correct
	0x0005(5)	Warning	Transmit instruction execution failed	Retry
	0x0006(6)	Warning	Receive instruction execution failed	Retry
	0x0007(7)	Warning	Incomplete received data	Check the length of data transmitted by the sender
	0x0008(8)	Warning	Receive data timeout	Check whether the serial line connection is normal
	0x0009(9)	Warning	Instruction execution failed	Retry
	0x0001(1)	Warning	COM port parameters not configured	Choose the serial freeport in the upper computer and configure the parameters of the serial port
	0x0002(2)	Warning	Transmit length or receive length setting error	Check the transmit length or receive length
0x0048(72)	0x0003(3)	Warning		Check the receive or transmit buffer element address and the transmit or receive length of instruction parameters
	0x0004(4)	Warning	Port setting error	Check whether the Port setting in the instruction is correct

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0005(5)	Warning	Transmit instruction execution failed	Retry
	0x0006(6)	Warning	Receive instruction execution failed	Retry
	0x0007(7)	Warning	Incomplete received data	Check the length of data transmitted by the sender
	0x0008(8)	Warning	Receive data timeout	Check whether the serial line connection is normal
	0x0009(9)	Warning	Instruction execution failed	Retry
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning		Check whether the address configuration accessed by the master connected with PLC is legal
	0x0003(3)	Warning		Check whether the value included in the master's query to the server (or the slave) is not allowed.
	0x0004(4)	Warning		Check whether the master connected with the PLC is configured correctly.
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user.	Check whether the serial connection
	0x0007(7)	Warning		Check whether the line connection is normal.
0x0049(73)	0x0008(8)	Warning		Check whether the baud rate, data bit and parity bit are configured correctly.
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, data bit and parity bit are configured correctly.
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element).	Check the element address.
	0x000B(11)	Warning	The length of data received does not conform to the protocol or the number of	Check the master connected with PLC.
	0x000C(12)	Warning	The received slave address does not match the requested slave address.	Check the slave connected with PLC.
	0x000D(13)	Warning	The received function code does not match the requested	Check the slave connected with PLC.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			function code.	
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the host controller. Re-download the program.
	0x000F(15)	Warning	The input port number is out of range.	Check whether the input port number of the function block corresponds to the actual port.
	0x0010(16)	Warning	The serial port is not opened.	Check whether the corresponding port for ModbusRTU master is checked in the configuration tree on the right side.
	0x0011(17)	Warning	Slave address setting error	The slave address setting is not within the range of 0 to 255.
	0x0012(18)	Warning	Function code setting error	The function code setting does not meet the Modbus requirements; check whether the function code setting is correct.
	0x0013(19)	Warning	-	The data count set by this function code does not meet the Modbus requirements.
	0x0014(20)	Warning	Data buffer cache size setting error	Check the size of the defined data buffer cache to ensure that it is not less than the required amount of data.
	0x0015(21)	Warning	Two function blocks are enabled simultaneously on the same port.	Check whether the function blocks are enabled simultaneously.
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning		Check whether the address configuration accessed by the master connected with PLC is legal
	0x0003(3)	Warning		Check whether the value included in the master's query to the server (or the slave) is not allowed.
0x004A(74)	0x0004(4)	Warning		Check whether the master connected with the PLC is configured correctly.
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connection is normal.
	0x0007(7)	Warning	The communication connection is disconnected.	Check whether the line connection is normal.
	0x0008(8)	Warning		Check whether the baud rate, data bit and parity bit are configured correctly.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, data bit and parity bit are configured correctly.
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element).	Check the element address.
	0x000B(11)	Warning		Check the master connected with PLC.
	0x000C(12)	Warning	The received slave address does not match the requested slave address.	Check the slave connected with PLC.
	0x000D(13)	Warning	The received function code does not match the requested function code.	Check the slave connected with PLC.
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the host controller. Re-download the program.
	0x000F(15)	Warning	The input port number is out of range.	Check whether the input port number of the function block corresponds to the actual port.
	0x0010(16)	Warning	The serial port is not opened.	Check whether the corresponding port for ModbusRTU master is checked in the configuration tree on the right side.
	0x0011(17)	Warning	Slave address setting error	The slave address setting is not within the range of 0 to 255.
	0x0012(18)	Warning	Function code setting error	The function code setting does not meet the Modbus requirements; check whether the function code setting is correct.
	0x0013(19)	Warning	-	The data count set by this function code does not meet the Modbus requirements.
	0x0014(20)	Warning	Data buffer cache size setting error	Check the size of the defined data buffer cache to ensure that it is not less than the required amount of data.
	0x0015(21)	Warning	Two function blocks are enabled simultaneously on the same port.	Check whether the function blocks are enabled simultaneously.
0x0050(80)	0x0001(1)	General error	CANopen communication error	Please check whether the CAN network line connection is normal, ensure that there is no reverse

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				connection, short connection or open circuit between CANH and CANL, and check whether the terminal resistance is connected correctly, and whether the baud rate of CAN communication matches.
	0x0002(2)	General error	CANopen configuration error	Check whether the upper computer configuration matches the actual situation
	0x0003(3)	Warning	CANopen load rate is too high	Detect whether too many PDOs are configured, and there are devices on the fieldbus that transmit CAN messages autonomously, such as CAN analyzers or multiple CANopen masters. This situation may lead to poor communication status, data loss and other problems.
	0x0001(1)	Serious error	Internal error in CAN module	Restart the PLC or contact technical support.
	0x0002(2)	General error	CAN free port instruction parameter setting is incorrect.	Check the input parameters of the function block.
	0x0003(3)	General error	CAN free port data sending timeout	 Check whether the CAN baud rate configuration is correct. Check whether the CAN hardware connection is normal. Check the terminal matching resistor.
0x0051(81)	0x0004(4)	General error	CAN free port data receiving timeout	 Check whether the CAN baud rate configuration is correct. Check whether the CAN hardware connection is normal. Check the terminal matching resistor.
	0x0005(5)	General error	CAN bus error	 Reduce environmental interference. Check the baud rate configuration. Check the terminal matching resistor.
	0x0006(6)	General error	CAN free port is not configured.	Please configure CAN 2.0 communication in the CAN options.
0x0080 (128)	0x1020 (4128) 0x1040	Serious error Serious	Wrong number of module matches Connection 0 module length	Update the version of the host controller or contact technical
	(4160)	error	matching exception	support.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x1041	Serious	Connection 1 module lengt	h
	(4161)	error	matching exception	
	0x1042	Serious	Connection 2 module lengt	h
	(4162)	error	matching exception	
	0x1043	Serious	Connection 3 module lengt	h
	(4163)	error	matching exception	
	0x1044	Serious	Connection 4 module lengt	h
	(4164)	error	matching exception	
	0x1045	Serious	Connection 5 module lengt	h
	(4165)	error	matching exception	
	0x1046	Serious	Connection 6 module lengt	h
	(4166)	error	matching exception	
	0x1047	Serious	Connection 7 module lengt	h
	(4167)	error	matching exception	
	0x1048	Serious	Connection 8 module lengt	h
	(4168)	error	matching exception	
	0x1049	Serious	Connection 9 module lengt	h
	(4169)	error	matching exception	
	0x104A	Serious	Connection 10 module lengt	h
	(4170)	error	matching exception	
	0x104B	Serious	Connection 11 module lengt	h
	(4171)	error	matching exception	
	0x104C	Serious	Connection 12 module lengt	h
	(4172)	error	matching exception	
	0x104D	Serious	Connection 13 module lengt	h
	(4173)	error	matching exception	
	0x104E	Serious	Connection 14 module lengt	h
	(4174)	error	matching exception	
	0x104F	Serious	Connection 15 module lengt	h
	(4175)	error	matching exception	
	0x1060	Serious	Connection 0 module input	It
	(4192)	error	length exception	
	0x1061	Serious	Connection 1 module input	It
	(4193)	error	length exception	
	0x1062	Serious	Connection 2 module input	It
	(4194)	error	length exception	
	0x1063	Serious	Connection 3 module input	It
	(4195)	error	length exception	
	0x1064	Serious	Connection 4 module input	11
	(4196)	error	length exception	
	0x1065	Serious	Connection 5 module input	It
	(4197)	error	length exception	
	0x1066	Serious	Connection 6 module input	11
	(4198)	error	length exception	14
	0x1067	Serious	Connection 7 module input	
	(4199)	error	length exception	14
	0x1068 (4200)	Serious	Connection 8 module inpute length exception	,

Main fault	Sub fault	Error	Meaning of error	Solutions
code	code	level	Connection 0 medule input	
	0x1069	Serious	Connection 9 module input	
	(4201)	error	length exception	
	0x106A	Serious	Connection 10 module input	
	(4202)	error	length exception	
	0x106B	Serious	Connection 11 module input	
	(4203)	error	length exception	
	0x106C	Serious	Connection 12 module input	
	(4204)	error	length exception	
	0x106D	Serious	Connection 13 module input	
	(4205)	error	length exception	
	0x106E	Serious	Connection 14 module input	
	(4206)	error	length exception	
	0x106F	Serious	Connection 15 module input	
	(4207)	error	length exception	
	0x1080	Serious	Connection 0 module output	
	(4224)	error	length exception	
	0x1081	Serious	Connection 1 module output	
	(4225)	error	length exception	
	0x1082	Serious	Connection 2 module output	
	(4226)	error	length exception	
	0x1083	Serious	Connection 3 module output	
	(4227)	error	length exception	
	0x1084	Serious	Connection 4 module output	
	(4228)	error	length exception	
	0x1085	Serious	Connection 5 module output	
	(4229)	error	length exception	
	0x1086	Serious	Connection 6 module output	
	(4230)	error	length exception	
	0x1087	Serious	Connection 7 module output	
	(4231)	error	length exception	
	0x1088	Serious	Connection 8 module output	
	(4232)	error	length exception	
	0x1089	Serious	Connection 9 module output	
	(4233)	error	length exception	
	0x108A	Serious	Connection 10 module output	
	(4234)	error	length exception	
	0x108B	Serious	Connection 11 module output	
	(4235)	error	length exception	
	0x108C	Serious	Connection 12 module output	
	(4236)	error	length exception	
	0x108D	Serious	Connection 13 module output	
	(4237)	error	length exception	
	0x108E	Serious	Connection 14 module output	
	(4238)	error	length exception	
	0x108F	Serious	Connection 15 module output	
	(4239)	error	length exception	
	0x10A0	Serious	Connection 0 element	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
code			matching execution	
	(4256)	error	matching exception	
	0x10A1	Serious	Connection 1 element	
	(4257)	error	matching exception	
	0x10A2	Serious	Connection 2 element	
	(4258)	error	matching exception	
	0x10A3	Serious	Connection 3 element	
	(4259)	error	matching exception	
	0x10A4	Serious	Connection 4 element	
	(4260)	error	matching exception	
	0x10A5	Serious	Connection 5 element	
	(4261)	error	matching exception	
	0x10A6	Serious	Connection 6 element	
	(4262)	error	matching exception	
	0x10A7	Serious	Connection 7 element	
	(4263)	error	matching exception	
	0x10A8	Serious	Connection 8 element	
	(4264)	error	matching exception	
	0x10A9	Serious	Connection 9 element	
	(4265)	error	matching exception	
	0x10AA	Serious	Connection 10 element	
	(4266)	error	matching exception	
	0x10AB	Serious	Connection 11 element	
	(4267)	error	matching exception	
	0x10AC	Serious	Connection 12 element	
	(4268)	error	matching exception	
	0x10AD	Serious	Connection 13 element	
	(4269)	error	matching exception	
	0x10AE	Serious	Connection 14 element	
	(4270)	error	matching exception	
	0x10AF	Serious	Connection 15 element	
	(4271)	error	matching exception	
	0x3000	Warning	Connection 0 connection not	
	(12288)	wanning	established	
	0x3001	Warning	Connection 1 connection not	
	(12289)	wanning	established	
	0x3002 (12290)	Warning	Connection 2 connection not established	
	0x3003(1229	Warning	Connection 3 connection not established	
	1)			
	0x3004 (12292)	Warning	Connection 4 connection not established	
	0x3005		Connection 5 connection not	
	(12293)	Warning	established	
	0x3006			
	(12294)	Warning	Connection 6 connection not established	
			Connection 7 connection not	
	0x3007 (12295)	Warning	established	

Main fault	Sub fault	Error	Mooning of orror	Solutions
code	code	level	Meaning of error	3010110115
	0x3008	Warning	Connection 8 connection not	
	(12296)	Warning	established	
	0x3009	Warning	Connection 9 connection not	
	(12297)	5	established	
	0x300A	Warning	Connection 10 connection not	
	(12298)		established	
	0x300B	Warning	Connection 11 connection not	
	(12299)		established	
	0x300C	Warning	Connection 12 connection not	
	(12300)		established	
	0x300D	Warning	Connection 13 connection not	
	(12301)	_	established	
	0x300E	Warning	Connection 14 connection not	
	(12302)		established	
	0x300F	Warning	Connection 15 connection not	
	(12303)	_	established	
	0x3020	Warning	Connection 0 path error	
·	(12320)			
	0x3021	Warning	Connection 1 path error	
	(12321)			
	0x3022	Warning	Connection 2 path error	
	(12322)			
	0x3023	Warning	Connection 3 path error	
	(12323)			
	0x3024	Warning	Connection 4 path error	
	(12324)			
	0x3025	Warning	Connection 5 path error	
	(12325)			
	0x3026 (12326)	Warning	Connection 6 path error	
·	,			
	0x3027 (12327)	Warning	Connection 7 path error	Check the configuration path
	0x3028			Check the configuration path.
	(12328)	Warning	Connection 8 path error	
	0x3029			
	(12329)	Warning	Connection 9 path error	
	0x302A			
	(12330)	Warning	Connection 10 path error	
	0x302B			
	(12331)	Warning	Connection 11 path error	
	0x302C			
(12332) 0x302D		Warning	Connection 12 path error	
	Warning	Connection 13 path error		
	0x302E			
	(12334)	Warning	Connection 14 path error	
	0x302F	Warning	Connection 15 path error	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
code		level		
	(12335)		Organization of the training	
	0x3040	Warning	Connection 0 transmission	
	(12352)		data size mismatch	
	0x3041	Warning	Connection 1 transmission	
	(12353)		data size mismatch	
	0x3042	Warning	Connection 2 transmission	
	(12354)		data size mismatch	
	0x3043	Warning	Connection 3 transmission	
	(12355)	Ű	data size mismatch	
	0x3044	Warning	Connection 4 transmission	
	(12356)		data size mismatch	
	0x3045	Warning	Connection 5 transmission	
	(12357)		data size mismatch	
	0x3046	Warning	Connection 6 transmission	
	(12358)		data size mismatch	
	0x3047	Warning	Connection 7 transmission	
	(12359)	Training	data size mismatch	Check the size of the data matching
	0x3048	Warning	Connection 8 transmission	between the sender and receiver.
	(12360)	warning	data size mismatch	
	0x3049	Warning	Connection 9 transmission	
	(12361)	warning	data size mismatch	
	0x304A	Warning	Connection 10 transmission	
	(12362)	warning	data size mismatch	
	0x304B	Warning	Connection 11 transmission	
	(12363)	warning	data size mismatch	
	0x304C	Warning	Connection 12 transmission	
	(12364)	warning	data size mismatch	
	0x304D	Warning	Connection 13 transmission	
	(12365)	warning	data size mismatch	
	0x304E	Warning	Connection 14 transmission	
	(12366)	warning	data size mismatch	
	0x304F	Warning	Connection 15 transmission	
	(12367)	warning	data size mismatch	
	0x3060	Warning	Connection 0 other errors	
	(12384)	Warning		
	0x3061	Morning	Connection 1 other errors	
	(12385)	warning	Connection 1 other errors	
	0x3062		Connection 2 other errors	
	(12386)	Warning	Connection 2 other errors	
	0x3063	14/		
	(12387)	Warning	Connection 3 other errors	Contact technical support.
	0x3064	\\\	Orange etilege (f. 1)	
	(12388)	Warning	Connection 4 other errors	
	0x3065			
	(12389)	Warning	Connection 5 other errors	
	0x3066			
1	(12390)	Warning	Connection 6 other errors	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x3067		.	
	(12391)	Warning	Connection 7 other errors	
	0x3068			
	(12392)	vvarning	Connection 8 other errors	
	0x3069	Worping	Connection Q other errors	
	(12393)	Warning	Connection 9 other errors	
	0x306A	Warning	Connection 10 other errors	
	(12394)	warning		
	0x306B	Warning	Connection 11 other errors	
	(12395)	······································		
	0x306C	Warning	Connection 12 other errors	
	(12396)			
	0x306D	Warning	Connection 13 other errors	
	(12397)			
	0x306E	Warning	Connection 14 other errors	
	(12398) 0x306F			
	(12399)	Warning	Connection 15 other errors	
	0x30A0		Connection 0 communication	
	(12448)	Warning	timeout	
	0x30A1	Warning	Connection 1 communication	
	(12449)		timeout	
	0x30A2	Warning	Connection 2 communication timeout	
	(12450)			
	0x30A3	\A/	Connection 3 communication	
	(12451)	Warning	timeout	
	0x30A4	Warning	Connection 4 communication	
	(12452)	warning	timeout	
	0x30A5	Warning	Connection 5 communication	
	(12453)	· · · · · · · · · · · · · · · · · · ·	timeout	
	0x30A6	Warning	Connection 6 communication	
	(12454)		timeout	Check the cables, connection ports,
	0x30A7	Warning	Connection 7 communication	connection mode, and attribute ID.
	(12455)		timeout	
	0x30A8	Warning	Connection 8 communication	
	(12456) 0x30A9		timeout Connection 9 communication	
·	(12457)	Warning	timeout	
	0x30AA		Connection 10 communication	
	(12458)	Warning	timeout	
-	0x30AB		Connection 11 communication	
	(12459)	Warning	timeout	
	0x30AC		Connection 12 communication	
	(12460)	Warning	timeout	
	0x30AD	Morning	Connection 13 communication	
	(12461)	Warning	timeout	
	0x30AE	Warning	Connection 14 communication	

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	(12462)		timeout	
	0x30AF		Connection 15 communication	
	(12463)	Warning	timeout	
	0x4020	Serious	Network configuration	
	(16416)	error	exception	
	0x4040	Serious	Notwork initialization evention	
	(16448)	error	Network initialization exception	
	0x4060	Serious	Thread attribute initialization	
	(16480)	error	failed	
	0x4080	Serious	Thread request stack failure	
	(16512)	error		Contact technical support.
	0x40A0	Serious	Thread setting scheduling	
	(16544)	error	policy failed	
	0x40C0	Serious	Thread priority setting failed	
	(16576)	error		
	0x40E0	Serious	Failed to set parent thread	
	(16608)	error	inheritance policy	
	0x4100	Serious	Failed to create thread	
	(16640)	error		
	0x0001(1)	General error	Failed to apply for master	Check whether the card software matches the background version Restart PLC
	0x0002(2)	General error	Wrong master version	Check whether the single board software matches the background version
	0x0003(3)	General error	The number of PDO entries sent exceeds the maximum limit.	Check whether the number of PDOs sent exceeds the maximum limit.
	0x0004(4)	General error		Check whether the number of PDC configuration objects sent exceeds the maximum limit.
0x0090	0x0005(5)	General error		Check whether the number of PDOs entries received exceeds the maximum limit.
(144)	0x0006(6)	General error	The number of PDO configuration objects received exceeds the maximum limit	Check whether the number of PDC configuration objects received exceeds the maximum limit.
	0x0007(7)	General error		Check whether the number o startup parameters exceeds the maximum limit.
	0x0008(8)	General error	The number of servos exceeds the maximum limit	Check whether the number o configured servos exceeds the maximum limit.
	0x0009(9)	General error	The number of slaves exceeds the maximum limit	Check whether the number o configured slaves exceeds the maximum limit.
	0x000A(10)	General error	Wrong configuration type	Reserved

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x000B(11)	General error	•	Check whether the actual number of connected slaves is less than the configured number of slaves.
	0x000C (12)	General error	DC mode is not supported by slaves	Reserved
	0x000D (13)	General error	Wrong Slave type	Check whether the devices in the configuration match the actual connected devices
	0x000E(14)	General error	The number of mapped slaves exceeds the set value	Check whether the actual number of connected slaves is greater than the configured number of slaves.
	0x000F(15)	General error	Mapping slave transmit PDO communication exception	Reserved
	0x0010(16)	General error	Mapping slave receive PDO communication exception	Reserved
	0x0011(17)	General error	The slaves have been detected to be offline	Check whether the network among slaves is disconnected; Check whether the slaves are powered off
	0x0012(18)	General error	Failed to initialize slave parameters	Contact the manufacturer.
	0x0013(19)	General error	Network connection failure	Check whether the slaves are connected; Check whether all slaves are powered off
	0x0014(20)	General error	Unable to identify the number of slaves	Reserved
	0x0015(21)	Warning	Aperiodic communication timeout	Reserved
	0x0016(22)	Serious error	Failed to apply for master	Contact the manufacturer.
	0x0017(23)	Serious error	Illegal IO mapping	Reserved
	0x0018(24)	General error	Failed to write the homing parameters.	Check whether the values of the homing parameters are reasonable.
	0x0019(25)	General error	Failed to write the user startup parameters.	Check whether the values of the user startup parameters are reasonable.
	0x001A(26)	General error	The received frame check failed	 Check whether the network cable is category 6 or above. Investigate whether there are factors in the field that may cause communication interference.
	0x001B(27)	General error	Communication timeout for the master to read the slave state	 Check whether the slave is disconnected. Check whether the CPU load rate is too high.
	0x001C(28)	General error	Master exception reset	1. Check whether the slave state machine is abnormal.

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				2. Check whether the slave is offline.
	0x0001(1)	Warning	exception code 01, illegal	Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning	Standard Modbus error, exception code 02, illegal	Check whether the address configuration accessed by the master connected with PLC is legal
	0x0003(3)	Warning	exception code 03, illegal data	Check whether the value included in the master's query to the server (or the slave) is not allowed.
	0x0004(4)	Warning		Check whether the master connected with PLC is configured correctly
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connection
	0x0006(6)	Warning	Modbus TCP master-slave connection timeout	Check whether the connection of network cable is normal, and whether the ip and port number are set correctly
	0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection is normal
0x00A0 (160)	0x0008(8)	Warning		Check whether the baud rate, data bit and parity bit are configured correctly
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, data bit and parity bit are configured correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	Check the element address
	0x000B(11)	Warning	The length of data received does not conform to the protocol or the number of	Check the master connected with PLC
	0x000C (12)	Warning	The received slave address does not match the requested slave address	Check the slave connected with PLC
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PLC
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the upper computer; Re-download the program

Fault Diagnosis

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0011(17)	Warning	Slave ID setting error	Check whether the SlaveID parameter configuration of the instruction is correct.
	0x0012(18)	Warning	Function code setting error	Check whether the FunCode parameter configuration of the instruction is correct.
	0x0013(19)	Warning		Check whether the FunCode and DataCounts parameter configuration of the instruction is correct.
	0x0014(20)	Warning	The setting of data buffer size is incorrect.	Check whether the DataBuffe parameter configuration of the instruction is correct.
	0x0001(1)	Warning		Check whether the configuration of function code accessed by master connected with PLC is legal
	0x0002(2)	Warning		Check whether the addres
	0x0003(3)	Warning	Standard Modbus error, exception code 03, illegal data	Check whether the value included i the master's query to the server (o the slave) is not allowed.
	0x0004(4)	Warning	Standard Modbus error, exception code 04, slave device failure	Check whether the master connected with the PLC configured correctly
	0x0005(5)	Warning	Communication timeout, the	Check whether the serial connectio
	0x0006(6)	Warning	-	Check whether the connection on network cable is normal, an whether the ip and port number ar set correctly
	0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection normal
	0x0008(8)	Warning		Check whether the baud rate, dat bit and parity bit are configure correctly
	0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, dat bit and parity bit are configure correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	Check the element address
0x00A1 (161)	0x000B(11)	Warning	The length of data received	Check the master connected wit PLC

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
			maximum limit specified by the function code	
	0x000C (12)	Warning	The received slave address does not match the requested slave address	Check the slave connected with PL
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PL
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the upper computer; Re-downloan the program
	0x0011(17)	Warning	Slave ID setting error	Check whether the Slavel parameter configuration of the instruction is correct.
	0x0012(18)	Warning	Function code setting error	Check whether the FunCom parameter configuration of the instruction is correct.
	0x0013(19)	Warning		Check whether the FunCode an DataCounts parameter configuration of the instruction is correct.
	0x0014(20)	Warning	The setting of data buffer size is incorrect.	Check whether the DataBuff parameter configuration of the instruction is correct.
	0x0001(1)	Warning		Check whether the configuration function code accessed by mast connected with PLC is legal
	0x0002(2)	Warning		Check whether the addrest configuration accessed by the master connected with PLC is lega
	0x0003(3)	Warning	Standard Modbus error,	Check whether the value included the master's query to the server (the slave) is not allowed.
0x00A2 (162)	0x0004(4)	Warning		Check whether the mast connected with the PLC configured correctly
	0x0005(5)	Warning	Communication timeout, the communication time exceeds the maximum communication time set by the user	Check whether the serial connection is normal
	0x0006(6)	Warning		Check whether the connection network cable is normal, an whether the ip and port number a set correctly
	0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection normal
	0x0008(8)	Warning		Check whether the baud rate, da bit and parity bit are configure correctly

Fault Diagnosis

0,0000(0)			
0x0009(9)	Warning	CRC/LRC check error	Check whether the baud rate, data bit and parity bit are configured correctly
0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	
0x000B(11)	Warning	does not conform to the protocol or the number of	Check the master connected with PLC
0x000C (12)	Warning		Check the slave connected with PLC
0x000D (13)	Warning		Check the slave connected with PL
0x000E(14)	Warning	Instruction execution failed	Check the parameter configuratio of the upper computer; Re-downloa the program
0x0001(1)	Warning		Check whether the configuration of function code accessed by maste connected with PLC is legal
0x0002(2)	Warning		Check whether the addres configuration accessed by the master connected with PLC is legal
0x0003(3)	Warning		Check whether the value included i the master's query to the server (c the slave) is not allowed.
0x0004(4)	Warning		Check whether the maste connected with the PLC i configured correctly
0x0005(5)	Warning		Check whether the serial connectio is normal
0x0006(6)	Warning	Modbus TCP master-slave connection timeout	Check whether the connection on network cable is normal, an whether the ip and port number ar set correctly
0x0007(7)	Warning	The communication connection is disconnected	Check whether the line connection i normal
0x0008(8)	Warning		Check whether the baud rate, dat bit and parity bit are configure correctly
	0x000B(11) 0x000C (12) 0x000D (13) 0x000E(14) 0x0002(2) 0x0003(3) 0x0003(3) 0x0004(4) 0x0005(5) 0x0006(6) 0x0007(7)	Nome Nome 0x0000B(11) Warning 0x0000C (12) Warning 0x0000D (13) Warning 0x0000E(14) Warning 0x0001(1) Warning 0x0002(2) Warning 0x0003(3) Warning 0x0003(5) Warning 0x0003(6) Warning 0x0003(8) Warning	Dx000A(10)Warning sentsent exceeds the storage space of the element)Dx000B(11)WarningThe length of data received does not conform to the protocol or the number of elements exceeds the maximum limit specified by the function codeDx000C (12)WarningThe received slave address does not match the requested slave addressDx000D (13)WarningThe received function code does not match the requested function codeDx000E(14)WarningInstruction execution failedDx0001(1)WarningStandard modbus error, exception code 01, illegal function code 02, illegal register addressDx0002(2)WarningStandard Modbus error, exception code 02, illegal register addressDx0003(3)WarningStandard Modbus error, exception code 03, illegal data valueDx0005(5)WarningCommunication timeout, the communication time exceeds the maximum communication time set by the userDx0006(6)WarningModbus TCP master-slave connection timeoutDx0007(7)WarningThe communication connection is disconnectedDx0008(8)WarningThe received data frame does not conform to the Modbus protocol

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
				bit and parity bit are configured correctly
	0x000A(10)	Warning	Element address overflow (the amount of data received or sent exceeds the storage space of the element)	
	0x000B(11)	Warning	•	Check the master connected with PLC
	0x000C (12)	Warning	The received slave address does not match the requested slave address	Check the slave connected with PLC
	0x000D (13)	Warning	The received function code does not match the requested function code	Check the slave connected with PLC
	0x000E(14)	Warning	Instruction execution failed	Check the parameter configuration of the upper computer; Re-download the program
	0x0001(1)	General error	Client connection failed	Check whether the server side is turned on; Check whether the IP address set by the client is the IP address of the server; Check whether the network cable connection is loose
0x00B0	0x0002(2)	General error	Instruction parameter setting error	Check whether the data quantity setting value is less than or equal to 0
(176)	0x0003(3)	General error	Instruction parameter element number setting error	The amount of data sent or received exceeds the capacity of the data transmitting or receiving area
	0x0004(4)	General error	Server listening failed	Server socket not created, recreate server socket
	0x0005(5)	General error	Transmit instruction execution failed	Check the network connection
	0x0006(6)	General error	Receive instruction execution failed	Check the network connection
0x00B8 (184)	0x0002(2)	General error	Instruction parameter setting error	Check whether the data quantity setting value is less than or equal to 0
	0x0003(3)	General error	Instruction parameter element number setting error	The amount of data sent or received exceeds the capacity of the data transmitting or receiving area
	0x0005(5)	General error	Transmit instruction execution failed	Check the network connection

Main fault code	Sub fault code	Error level	Meaning of error	Solutions
	0x0006(6)	General error	Receive instruction execution failed	Check the network connection
	0x0001(1)	Serious error	The system version is too low to start the IoT card	Update system firmware version
	0x0002(2)	Serious error	Serious error in starting the IoT module	Check whether the driver and hardware work properly
	0x0003(3)	Warning	Abnormal signal strength	Check whether the driver and hardware work properly
0x00F0 (240)	0x0004(4)	Warning	No port or port read-write error	Check whether the driver and hardware work properly
	0x0005(5)	Warning	Dial activation failed	Check whether the driver and hardware work properly
	0x0006(6)	Warning	No SIM card inserted.	Check whether the SIM card is installed correctly.
	0x0007(7)	Warning	SIM card has no data flow, Vpn error, etc.	Change another SIM card.

20 Firmware Burning and Upgrade

20.1 Upper Computer Firmware Upgrade


Step 1 When users use Ethernet or USB to connect PLC, they can enter the firmware upgrade interface in the toolbar "Tool" > "Firmware upgrade".

PLC Set upgrade password Clear upgrade password Communication setting Read PLC information PLC type TS635 PLC version 1.39.00 Upgrade package upgrade package Enter verification Verification code 0491 Upgrade Document	Firmware upgrade	×
upgrade package file Enter verification Verification code 0491 Upgrade	Set upgrade password Clear upgrade password Communication setting	
	upgrade package file Enter verification Verification code 0491 Upgrade	
Current status: Ready	Document Unrent status: Ready	

Step 2 Select the firmware version to be upgraded, enter the verification code, and click the Upgrade button.

irmware upgrade		Х
PLC		
Set upgrade password	Clear upgrade password	Communication setting
Read PLC information	PLC type TS635	PLC version 1.39.00
Upgrade package		
upgrade package file	E:\TS_share\TS600_MCU_1	.3900. tar. gz
Enter verification	Verification co	de 088C Upgrade
Document		
Current status: Ready		

Step 3 At this point, a prompt regarding update precautions will pop up.



Step 4 Click the "OK" button and wait for the pop-up "Download successfully" prompt box to complete the firmware upgrade.

Firmware upgrade X
PLC Set upgrade password Clear upgrade password Communication setting Read PLC information PLC type TS635 PLC version 1.39.00
Up grade Auto Station Pro X up gra Enter v Downloaded successfully, please re-power up the PLC.
Document
Current status: Downloade

Note:

- After the upgrade is successful, it is necessary to manually power off and restart the PLC. After manual power off and restart, you can check the version information through PLC information to verify whether the upgrade is successful.
- If the upgrade is successful and the PLC is restarted, the red indicator on the PLC flashes slowly, indicating that the project in the PLC is incompatible with the firmware. You need to set the PLC's switch to the STOP position, power off and restart the PLC, then recompile the project and download the PLC program, and finally set it to the RUN position.

20.2 SD Card Firmware Upgrade

20.2.1 Step of Generating PLC Application Upgrade Package

Use a SD card to upgrade PLC application function, which means that PLC project can compile, generate the download project files, which is convenient for users to download without opening the original project. Use an SD card for batch updating or upgrading PLC projects, or use Auto Station Pro backend software to update PLC projects.

G

Before downloading the project file, you need to generate and download the project file through Auto Station Pro in the background. The specific operation steps are as follows:

Step 1 Open the PLC project and click "PLC>PLC executable package (A)>Generate" menu bar.

enerate executable package		
Option Project source code Application program POV information System block CANOPEN module Vser data block	OK Close	
Whether to support open project No Yes		

- Step 2 Set the attributes of the downloaded file in the "Generate executable package" interface that pops up in the system, and then click "OK".
 - Options: Check "Project source code", "Application program", "POU information", "System block" and "User data block".
 - \diamond "Project source code": Support to open the project, required
 - ♦ "Application program": Executable applications
 - ♦ "POU information": POU information
 - ♦ "System block": System related data configuration
 - ♦ "User data block": User related data configuration
 - Whether to support opening the project, check: "No", "Yes".
 - No: The generation package file cannot open application project through AutoStation Pro, source upload is not supported, and the file format is *. cmf.
 - ♦ Yes: The generate package file can open the application project through AutoStation Pro, the source code upload is supported, and the file format *. upcmf.
- Step 3 Generate the PLC application name in the standard format of TS*_PROJECT_*. cmf or TS*_PROJECT_*. upcmf file for customer upgrade, where * is variable multiple characters, the former * is the product model, and the latter * is usually the project name.

20.2.2 SD Card Upgrading Steps

Step 1 Prepare a SD card with the storage capacity up to 32G, and it cannot be partitioned.

Step 2 Create the directory to be upgraded in SD card root directory.

- The PLC application upgrade directory is named PLCProject
- The PLC firmware upgrade directory is named PLCFirmware
- The system firmware upgrade directory is named SYSFirmware

PLCFirmware	2/22/2024 2:15 PM	File folder
PLCProject	2/22/2024 2:26 PM	File folder
SYSFirmware	2/22/2024 2:15 PM	File folder

Note: Only the directories that need to be upgraded are created, and the directories that do not need to be upgraded may not be created.

Step 3 Copy the PLC application package, or PLC firmware, or system firmware to the corresponding

directory. The file is provided by the manufacturer and the name cannot be changed at will.

 The standard format of PLC application name is: TS*_PROJECT_*. cmf or TS*_PROJECT_*. upcmf, where * is variable multiple characters, the former * is the product model, and the latter * is usually the project name.

Note: This package file is generated by the Auto Station Pro software. For details, see section 20.2.1 Step of Generating PLC Application Upgrade Package.

• The standard format of PLC firmware name is: TS600_MCU_*.tar.gz, where * is variable multiple characters, usually 5 digits to indicate the version.

Note: This firmware file is provided by the manufacturer.

• The standard format of system firmware name is: TS600_ARM_*.patch, where * is variable multiple characters, usually 5 digits to indicate the major version and P+3 digits for the patch version.

Note: This firmware file is provided by the manufacturer.

Step 4 There is only one file in each directory that needs to be upgraded. More than one file may cause unexpected problems.

• PLC firmware file

🔒 > Th	> This PC > Local Disk (F:) > PLCFirmware				ρs
	Name	Date modified	Туре	Size	
SS	TS600_MCU_13900.tar.gz	2/4/2024 1:59 PM	GZ File	1,105 KB	

• System firmware file

→ This PC → Local Disk (F:) → SYSFirmware				ٽ ~	,∕⊃ S€
	Name	Date modified	Туре	Size	
SS	TS600_ARM_10700_P000.patch	2/22/2024 2:00 PM	PATCH File	6,840 KB	

• Application package file

> This PC > Local Disk (F:) > PLCProject		~	5	Search PLCProject
Name	Date modified	Туре		Size
TS635_PROJECT_TS600_PROJECT_liangwanmask.cmf	2/22/2024 2:18 PM	CMF File		18 KB
TS635_PROJECT_TS600_PROIECT_liangwanmask.upcmf	2/22/2024 2:18 PM	UPCMF Fil	e	35 KB

Step 5 Power off the PLC controller, and insert a SD card.

Step 6 Power up the PLC controller, and wait for the upgrade to complete.

If the upgrade is successful, the run indicator will flash for about 4 seconds, then the error indicator will flash slowly, waiting for the controller to turn off power.

Step 7 Power off the PLC controller, remove the SD card, and wait for the upgrade to complete.

You can check whether the SD card upgrade is successful through the log.

• The successful upgrade of PLC firmware and system firmware is as shown in the figure below.

33	2023-09-21 13:34:26	0	0	INFO:PLC firmware upgrade success
32	2023-09-21 13:34:24	0	0	INFO:system firmware upgrade success
31	2023-09-21 13:34:16	0	0	INFO:TS600 start run

• Upgrade failure log descriptions are as follows.

65	2023-09-22 11:38:15	0	0	INFO:system firmware upgrade fail! because of: Ox101
66	2023-09-22 11:38:15	0	0	INFO:plc firmware upgrade fail! because of: Ox111

Note: SD card upgrade is only detected during power-on, and upgrade is no longer detected during operation. After successful upgrade, remove the SD card in time, otherwise the controller will not run normally.

Upgrade success and failure are displayed in the log file through information. If the upgrade fails, the controller runs normally and will not report errors. You need to view the reasons for the upgrade failure in the log file.

Upgrade Failure Error Code	Cause of Failure	Solution
0x101	The patch file could not	Check whether the file exists and whether the file
00101	be found	has a standard name
0v100	Failed to get local version	Chack system files
0x102	number	Check system files
0x103	Patch version is too low to	System version greater than or equal to version
0X105	upgrade	1.05
0x104	Deplication failed	Usually caused by insufficient storage space and
0X104	Replication failed	insufficient memory
0x105	Check failure	Check the file for corruption

• System firmware upgrade failure error code

• PLC firmware upgrade failure error code

Upgrade Failure Error Code	Cause of Failure	Solution
0x111	PLC firmware file not found	Check whether the file exists and whether the file has a standard name
0x112	Failed to copy file	Usually caused by insufficient storage space and insufficient memory
0x113	Failed to create directory extract file	General file corruption
0x114	Script execution failed	Usually the file is corrupted, or the firmware does not meet manufacturer standard

• PLC application upgrade failure error code

Upgrade Failure Error Code	Cause of Failure	Solution
0x121	Upgrade package file not	Check whether the file exists and whether
0X121	found	the file has a standard name
0,122	Tailad to convitile	Usually caused by insufficient storage space
0x122	Failed to copy file	and insufficient memory
0x124	Failed to enout the file	Usually the upgrade package file is corrupt
0X124	Failed to open the file	or the file does not exist
0x125	Failed to allocate memory	Usually caused by insufficient memory
		Usually the upgrade package file is corrupt
0x126	File header error	or in a non-standard upgrade package
		format
0x127	Failed to write file	Usually caused by file unpacking failure, or

Upgrade Failure Error Code	Cause of Failure	Solution
		there is a system problem
0x128	CRC verification failed	Usually files corrupt, or in non-standard upgrade package format

20.3 Upgrade of Upper Computer Applications or Open the Project

20.3.1 Upgrade Applications with Upgrade Pack

Click on "PLC>PLC executable package (A)>Download" menu bar in the upper computer toolbar. The following dialog box pops up.

Select the file *. cmf or *. upcmf to upgrade. Where *. cmf is the source upgrade package that cannot be uploaded, and *. upcmf is the source file package that can be uploaded. After successful download, click Run to run the downloaded application.

^	名称	修改日期	类型	大小
	TS635_PROJECT_blank.upcmf	2025/2/17 16:29	UPCMF 文件	
	TS635_PROJECT_blankmask.upcmf	2025/2/17 16:29	UPCMF 文件	
	TS635_PROJECT_blanknm.cmf	2025/2/17 16:21	CMF 文件	
÷.	TS635_PROJECT_liangwannm.cmf	2025/2/17 16:24	CMF 文件	
~ <				
			.cmf;.upcmf(*.cmf;*.u	(nemfi)
ile nan	ne:	× 1	ann, apenne ann, a	ipenii,) «

20.3.2 Open a Project with Upgrade Pack

Click on the "File>Open project" menu bar in the upper computer toolbar. The following dialog box pops up and select the file *. upcmf to open.

∠Note: Only the upgrade pack in *. upcmf format supports opening the project file.

^ ²	28称	修改日期	类型	大小
] TS635_PROJECT_blank.upcmf	2025/2/17 16:29	UPCMF 文件	81 KB
] TS635_PROJECT_blankmask.upcmf	2025/2/17 16:29	UPCMF 文件	81 KB
L				
~				
File name:	TS635_PROJECT_liangwannm.cmf		~ *.cmf;*.u	upcmf(*.cmf;*.upcmf;)
			Oper	n 🔽 Cancel

21 4G IoT Expansion Card

21.1 Overview

The TS-4G expansion card is a kind of functional expansion card applicable to INVT' s TS600 Series PLC products. It supports 4G Internet of Things, which can help customers realize remote data collection, remote upload/download and remote debugging.

The status of this 4G expansion card can be obtained from 4G module system variables or logs.

21.2 User Login of IoT Monitoring Platform

The PLC can be monitored and operated remotely after adding devices by using the IoT monitoring platform.

Enter iot.invt.com in the address bar of Google Browser and press Enter to visit the login page of the industrial IoT application platform. As shown in the following figure, enter the account number and password to complete the login.

IWoSce INVT industrial IOT monit		
Login Tel Login		
A Login name		
f password		
Remember login	English	•
Login		
	E Forgot pass	word

∠Note:

- To obtain the account number and password, please contact the industry administrator.
- The account number and password are the authentication credentials of INVT Industrial IoT Platform. After logging in, the device management function is available. Users should keep them properly and take adequate preventive measures to prevent others from stealing them. If the user name and password are stolen, great losses may be caused.
- Before using the device for remote operation, users should communicate with the site to ensure safety in advance, otherwise heavy losses may be caused.

- The IoT sim card is forced to be bound to a device, which means a sim card can only be used on the device that is powered on and connected to the Internet with this card for the first time. Users should not insert the IoT sim card into other devices, otherwise the sim card will be locked.
- This product is an industrial IoT product. INVT has taken necessary technical measures to ensure data security, but there may still be network security risks beyond our control or responsibility, such as hacking. If it is not for the harm caused by the quality defects of this product itself, our company shall not be responsible for any losses.

21.3 Add a Device Type

After logging in successfully, the home page will be displayed. Click on "Equipment center" > "Type management" > "Add", and a dialog box for adding device type will pop up.

	et industry application Search	adapter number, menu, devi	ce name, device barcode, device	e type r	nglish _e *	• ?	comm_01	107713
📴 Monitor 🛛 🗸 🖓	《 ① Type managem	ent ×					>>	\sim
🕂 Equipment center 🗠 1	Type management							l
8 Type management 2	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,							-1
S Function code	Device typename	Q Search				3	+ Add	
🗚 Video management								
Regional management	Device type name	Founder	Create time		Op	peration		11
Fence management								- 1
R Device group				to 1 page	go 1 in t	otal	10 / page	~
🖀 After sales center 🗸 🗸								
😵 Business Center 🗸 🗸								
🕌 User center 🛛 🗸								

Fill in the corresponding device type name and select the corresponding industry and click "Save".

>	ζ
TS635	
▼	
please select 👻	
multi addresses separated by English ';'	
Used for 3-party-inter to push data	
Save Cancel	
	TS635

21.4 Add Devices to IoT Platform

Return to the homepage of the IoT business platform, enter the adapter code (referring to the module ID, which is the barcode of the PLC), key and device alias in the "Add devices quickly" section on the homepage, select the device type according to the monitoring type, and then click "Submit" after confirming the input is correct.


TS600 Series Programmable Logic Controller Programming and Application Manual

4G IoT Expansion Card


Industrial Internet	et industry application	n platform			Search adapter number, me	nu, device name, device bar	rcode, device type r	English 🔻 🦉 鼻 🤶) comm_0107454 Logout Version: V2.6.29
📴 Monitor 🛛 🔿	< 🖒 Main pag	e							» ~
🖾 Real time monit 📃	Common menu	+			Overview		• • • •	Login information	
Large screen display		2	96	a	Total equipment	Online der	vices	Login times	47
 device joint control Equipment center 	Equipment	Users	Type mana	_	3	0		Registration time	2023-08-02 16:20:56
After sales center v		(+)			Abnormal devices	Remind M	laintain	Last login time	2024-10-22 11:01:31
😻 Business Center 🗸 🗸	Remote up	\odot			0	0		Add devices quickly	
🛎 User center 🛛 🗸	Data Overview							Please enter the ada	pter r ⑦ Please enter secret key ⑦
System center V				Recent Mon	th User Added			Device Type	 Please enter device name
Message center	1							ICA400/413	√ 485 √
 Configuration ce 	0. 8							Submit	
📸 data center 🛛 🗸	0.6								
	0. 4							Real time monitoring	
	0.2							0.00%	Online Ratio


21.5 Device Installation & Wiring

- Step 1 Slide out the SIM card holder of 4G module and insert the SIM card into the card holder.
- Step 2 Install the 4G antenna correctly and place the 4G antenna in a position with strong signal.
 - **Note:** It is forbidden to place the 4G antenna in the box with signal shielding effect.
- Step 3 Gently pry open the cover plate snaps with a tool on the side of the product (in the order of positions 1 and 2); Slide the cover plate to the left horizontally and take it out.



Step 4 Slide the expansion card into the guide slot horizontally, and then press the snap positions on the upper and lower sides of the expansion card hard until the expansion card is snapped tightly (there is obvious snap sound after it is installed in place).





Step 5 Power on and start PLC.


Step 6 When the NET indicator flashes at a frequency of 75ms, the network is ready and data transmission begins.

21.6 Establish VPN Transparent Transmission Channel

Note: At present, VPN transparent transmission is only used in China.

VPN transparent transmission is a method of downloading and monitoring PLC remotely through Auto Station Pro upper computer. The following tutorial describes how to use this function in Auto Station Pro.

Step 1 Right-click on "EXP-CARD", select "4G", and the 4G button will pop up.



- Step 2 Download the configuration to PLC and toggle the toggle switch to set it to RUN state.
- Step 3 Double-click "4G" to open the VPN Tool. Before establishing the VPN transparent transmission channel, please ensure that the network adapter on the PC side does not have a manually set IP, otherwise please set it to automatically obtain IP. If the relevant network adapter is disabled, enable it.



Step 4 Enter the account number and password of the IoT monitoring platform to log in (the account & password mentioned in the first step to log in to the web platform) and enter the main interface of the tool.

으 User login			?	\times
U	ser			
P;	assword			
1	Login	Logout		
(Note: Please log in with Thi		and password of tl plication platform		nternet of

Step 5 Log in to enter the main interface, select the corresponding ID of the module, and check the device IP to be equal to the gateway IP. The device IP, gateway IP and local IP of the IoT module are automatically obtained, and users do not need to fill them.

2.Server setting Operation information Operation information Image: Connect VPN Output: Operation information Image: Connect VPN Operation information Image: Connect VPN Output: Operation information Image: Connect VPN Operation information Image: Connect VPN Operation information Image: Connect VPN Operatin informatin Image: Connect VPN	으 VPDN Tool V1.1.0.0		-		\times
Indule ID S616 jkS616 j VPN status Offline Device IP 192 + 168 + 225 + 2 Gateway IP 192 + 168 + 225 + 2 Setting Image: Setting Image: Setting Image: Setting Image: Setting Get IP timeout Get IP timeout Image: Setting Image: Setting Image: Setting Get IP timeout Get IP timeout Operation information Image: Setting IP Operation information Image: Setting IP Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Operation information Image: Setting IP Image: Setting IP Image: Setting IP Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Output: Disconnect VPNI Disconnect VPNI Image: Setting IP Image: Setting IP Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal gateway IP, but not the same) Device IP equal	Installing the drive Help Documents Restart the module About				
2.Server setting Operation information Operation information Image: Connect VPN Output: Operation information Image: Connect VPN Operation information Image: Connect VPN Output: Operation information Image: Connect VPN Operation information Image: Connect VPN Operation information Image: Connect VPN Operatin informatin Image: Connect VPN	1.Module selection				
ocal IP 192 + 168 + 225 + 3 Connect VPN Disconnect VPN Operation information Operation information	Addule ID 8616 jk8616 j V VPN status Offline Device IP 192 • 168 • 225 • 2	Sateway IP	192 · 168 ·	225 · 2	Setting
Disconnected Internet status Disconnected Internet Disconne	2.Server setting				
Disconnected Internet status Disconnected Internet Disconne		2			
Operation information	Local IP 192 · 168 · 225 · 3 Connect VPN Disconnect VPN	Ŷ	Get IP timeo	ut	
Operation information 2024-02-20 16:34:10:030, Virtual network card adapter obtained successfur; 以太网 7 2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25, 0, dns = 10.111.0 2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25, 0, dns = 10.111.0 2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25, 0, dns = 10.111.0 2024-02-20 16:34:10:23, 19:919, Model-VPI connection:status: on status: on sta	Disconnected Intern	et status			
Operation information 2024-02-20 16:34:10:030, Virtual network card adapter obtained successfur; 以太网 7 2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25, 0, dns = 10.111.0 2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25, 0, dns = 10.111.0 2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25, 0, dns = 10.111.0 2024-02-20 16:34:10:23, 19:919, Model-VPI connection:status: on status: on sta	Note: The local IP needs to be in the same network segment as the device IP and gateway IP, but no	t the same)		evice IP equ	al gatewa
2024-02-20 16:34:10:030, Virtual network card adapter obtained successfue; 以太阴 7 2024-02-20 16:34:10:031, Ip = 10.111.1.2, mask=255.255.255.0, dns = 10.111.1.0 2024-02-20 16:34:19-319, Moduley PR connection:tatus unstraurs0, vpnIP:, deviceIP:192.166, 133, Gentral IP, 2024 02:20 16:34:19-319, Moduley PR connection straus unstraurs0, vpnIP:, deviceIP:192.166, 225.2 (an IP:192.166, 225.2 (an IP:		i die sonie,		encen equ	angurenn
2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25,0, dns = 10.111.1.0 2024-02-20 16:34:18:541, Getting IP 2024-02-20 16:34:18:541, Getting IP 2024-02-20 16:34:18:541, Getting IP 2024-02-20 16:34:30:261, Getting IP 2024-02-20 16:34:30:261, Getting IP 2024-02-20 16:34:30:261, Getting IP 2024-02-20 16:34:30:263, Module VPR connection status vpnStatus:0, vpnIP:, deviceIP:192.166.225.2, IanIP:192.166.225.2 2024-02-20 16:34:36:236, Module VPR connection status vpnStatus:0, vpnIP:, deviceIP:192.166.225.2, IanIP:192.166.225.2 2024-02-20 16:34:36:236, Module VPR connection status vpnStatus:0, vpnIP:, deviceIP:192.166.225.2, IanIP:192.166.225.2 2024-02-20 16:34:41:329, Getting IP 2024-02-20 16:34:41:329, Getting IP 2024-02-20 16:34:41:329, Getting IP	Operation information				
2024-02-20 16:34:10:031, ip = 10.111.1.2, mask=255.255.25,0, dns = 10.111.1.0 2024-02-20 16:34:18:541, Getting IP 2024-02-20 16:34:18:541, Getting IP 2024-02-20 16:34:18:541, Getting IP 2024-02-20 16:34:30:261, Getting IP 2024-02-20 16:34:30:261, Getting IP 2024-02-20 16:34:30:261, Getting IP 2024-02-20 16:34:30:263, Module VPR connection status vpnStatus:0, vpnIP:, deviceIP:192.166.225.2, IanIP:192.166.225.2 2024-02-20 16:34:36:236, Module VPR connection status vpnStatus:0, vpnIP:, deviceIP:192.166.225.2, IanIP:192.166.225.2 2024-02-20 16:34:36:236, Module VPR connection status vpnStatus:0, vpnIP:, deviceIP:192.166.225.2, IanIP:192.166.225.2 2024-02-20 16:34:41:329, Getting IP 2024-02-20 16:34:41:329, Getting IP 2024-02-20 16:34:41:329, Getting IP	2024.02.20 16:24:10:020 Virtual network card adapter obtained successfully: [1] 大岡 7	-			
2024-02-01-63-41:18-54.1. Getting IP 2024-02-02 16:34-1:18-54.1. Getting IP 2024-02-02 16:34-31:29-19, Model VPI competitoristative, profession 11:25:20, Jan Pietro 12:25:20,		1			
20249 29 45:41:19:91 Module VN connection status on spirit device IP:19:2.16.225.2, IanIP:19:2.168.225.2 2024 22:20 16:34:45:20, Getting IP 2024 22:20 16:34:35:20, Getting IP 2024 22:20 16:34:35:703, Getting IP 2024 22:20 16:34:41:323, Getting IP 2024 22:20 16:34:4		•			
2024 Drail 624 25 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2034-92-20 16:34:19:919. Module-VBN connection-status vonStatus:0. voniP: deviceiP:192.14.1390.1	module	is conne	ected	
2024 Drail 624 25 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2024 02120 16 3 24 Sparent transmission status.	convor	after be	ina	
2004-02-015-034-036-0374-04-034-034-034-034-034-034-034-034-034	2024 47-20-16:34 95:161, Mbdula VPN toppnection status upt/Status: P. von/91, device/Pr192.168.225.2, T	anIP:192.168	225.2	ing	
2004-02-015-034-036-0374-04-034-034-034-034-034-034-034-034-034	2024-02-20 16:34:30:261, Getting P	ed on, i	it will be	displa	yed
2024-02-20 16:34:36:326, Module VPN connection status vpnStatus:0, vpnIP:, deviceIP:192.168.225.2, lanIP:192.168.225.2 2024-02-20 16:34:41:329, Getting IP 2024-02-20 16:34:41:727, Module IP acquisition failed 2024-02-20 16:34:42:352, Module VPK connection status vpnStatus:0, vpnIP:, deviceIP:192.168.225.2, lanIP:192.168.225.2	2014-00-2016 34@01702.34@01707.001@00 Status:0, vpnIP:, deviceIP:192.168,225,2.	aniP:192.168	.225.2		
2024-02-20 16:34:41:329, Getting IP 2024-02-20 16:34:41:727, Module IP acquisition failed 2024-02-20 16:34:42:352, Whot ransit has been disconnected 2024-02-20 16:34:42:352, Module VPK connection status ypnStatus:0, ypnIP:, deviceIP:192.168.225.2, lanIP:192.168.225.2	2024-02-20 16:34:35:703, Getting IP	en			
2024-02-20 16:34:41:272, Module IP acquisition failed 2024-02-20 16:34:42:352, VPN transit has been disconnected 2024-02-20 16:34:42:352, Module VPK connection status ypnStatus:0, ypnIP:, deviceIP:192.168.225.2, lanIP:192.168.225.2	2024-02-20 16:34:36:326, Module VPN connection status vpnStatus:0, vpnIP:, deviceIP:192.168.225.2, l	anIP:192.168	.225.2		
2024-02-20 16:34:42:352, VPN transit has been disconnected 2024-02-20 16:34:42:352, Module VPN connection status vpnStatus:0, vpnIP:, deviceIP:192.168.225.2, lanIP:192.168.225.2	2024-02-20 16:34:41:329, Getting IP				
2024-02-20 16:34:42:352, Module VPN connection status vpnStatus:0, vpniP:, deviceIP:192.168.225.2, lanIP:192.168.225.2	2024-02-20 16:34:41:727, Module IP acquisition failed				
	2024-02-20 16:34:42:352, VPN transit has been disconnected				
2024-02-20 16:34:42:586, Module disconnected VPN connection	2024-02-20 16:34:42:352, Module VPN connection status vpnStatus:0, vpnIP:, deviceIP:192.168.225.2, la	anIP:192.168	.225.2		
	2024-02-20 16:34:42:586, Module disconnected VPN connection				
					-
			_		_

Step 6 Click the button to establish VPN transparent transmission and the connection progress will be displayed. After the progress bar reaches 100%, the transparent transmission is successfully established.

@ VPDN Tool V1.1.0.0	_		\times
Installing the drive Help Documents Restart the module About			
1.Module selection			
Module ID 8616 jk8616 j 🗸 VPN status Transmitting Device IP 192 · 168 · 225 · 2 Gateway IP 192	• 168 • 1	225 · 2	Setting
2.Server setting			
Local IP 192 · 168 · 225 · 3 Connect VPN Disconnect VPN Connect VPN Generated	: IP timeou	t	5
(Note: The local IP needs to be in the same network segment as the device IP and gateway IP, but not the same)	√ D	evice IP equ	al gateway
Operation information			
			~
2024-02-20 16:48:14:042, IP location			
2024-02-20 16:48:14:042, Configuring VPN			
2024-02-20 16:48:14:345, Current module version: ICA417-TS600_001			
2024-02-20 16:48:14:768, Module is connecting to VPN			
2024-02-20 16:48:14:769, vpnHostStr			
2024-02-20 16:48:14:769, vpdn.iwocloud.com			
2024-02-20 16:48:14:770, vpnHostStr			
2024-02-20 16:48:25:205, Successfully connected to VPN server			
2024-02-20 16:48:25:493, Selected virtual network card:TAP-Windows Adapter V9, port number:4			
2024-02-20 16:48:25:647, Virtual network card adapter obtained successfully:以太网 7			
2024-02-20 16:48:25:648, ip = 10.111.1.5,mask=255.255.255.255.0,dns = 10.111.1.0			
2024-02-20 16:48:33:860, Getting IP			
2024-02-20 16:48:34:287, Module VPN connection status vpnStatus:2, vpnIP:10.111.1.6, deviceIP:192.168.225.2, lanIP:1	92.168.225	5.2	
2024-02-20 16:48:34:581, After configuration, VPN transparent transmission is in progress			
			\sim
	Ð	port	Clear
Information:comm_0107713(Industry user)			

21.6.1 Connect PLC Remotely through VPN

After completing the above steps, PLC can be operated remotely.

Open the Auto Station Pro upper computer software, fill in the IP address of the device automatically obtained in VPN Tool in the remote IP address field, and then click "Connect" to connect to PLC remotely.

Programming por	rt setting			×
PLC USB setting USB port:	O USB @) Ethernet	Connect	
Ethernet sett Peer-to-pee Port number FLC network p	er IP address:	192 . 168 . 225 9016	5000	(ms):
th			Mac address address ly obtained	

21.6.2 FAQ

You can view module system variables or logs to obtain current module information. The following are answers to some common questions.

1. After power-on, the POWER indicator does not flash or illuminate.

Answer: Check whether the device is installed correctly.

2. When using 4G to surf the Internet, the network status indicator (NET) always flashes slowly, and a window indicating MQTT connection abnormality pops up when establishing VPN transparent transmission.

Answer: (1) The sim card is not installed in place. Please reinstall it after power off to ensure good contact.

- (2) Move the 4G antenna to a place where the signal strength is good.
- (3) Inquire whether the sim card is activated and whether there is a balance.

3. Interruption happens when VPN transparent transmission tool establishes VPN transparent transmission.

Answer: (1) Check whether the module is online.

- (2) Check whether the computer has installed the required network adapter driver (named TAP-Windows Adapter V9). Please click the installation driver at the top left of VPN transparent transmission tool to install it.
- 4. It is impossible to ping the device after VPN transparent transmission is established normally.

Answer: (1) The network cable connection between the module and the transparent transmission device is abnormal, so ensure the normal connection.

(2) The local network adapter has a manually set IP address, and set the IPV4 of the network adapter to be acquired automatically.

- (3) The local IP of the transparent transmission device and the device IP of the module are not in the same network segment, modify the device IP of the module in the VPN transparent transmission tool or make modifications in the upper computer software of the transparent transmission device to put them in the same network segment.
- (4) The gateway IP of the transparent transmission device is inconsistent with that of the module, so

modify the gateway IP of the module in the VPN transparent transmission tool or make modifications in the upper computer software of the transparent transmission device to make sure they use the same gateway IP.


21.7 Web Page Monitoring

Note: VPN transparent transmission and web page monitoring cannot be used at the same time.

The web page monitoring function uploads PLC element values to our IoT cloud server, and users can check the historical data in the web page to know the historical running status of PLC. At present, only monitoring Modbus address is supported. The following tutorial will help you monitor PLC elements on web pages.

First, you need to configure the elements to be monitored in the Auto Station Pro upper computer.

Step 1 Right-click on EXP-CARD, select "4G", and the "IoT Web Monitoring" button will pop up.



Step 2 Right-click on "IoT Web Monitoring" > "Add configuration" to add the IoT web page monitoring configuration file.



Step 3 Double-click the "Web monitoring configuration" button to pop up the web monitor configuration bar.

()	Motion control axes
4	Axis group setting
ę	EtherCAT
•	COM1
4	COM2
- 8	IoT Web Monitoring
	Web monitoring configuration
•	⊅ 4G
6	Ethernet1

Step 4 Click the add button to add a configuration. In this case we select Monitoring D0–D15, and the sampling time is 30 seconds.

Web monitoring configuration								
Timeout: 2	1~30s		Retry time: 3 1~10					
Word element Bit e	lement		Add Delete					
Element	Start Address	End Address	Sampling Time (s)					
1 D	0	15	5					
]				
Tip: Word element rar	Tip: Word element range limit D0~D32767, R0~R16383, T0~T399, C0~C255!							
	Bit element range limit M0~M32767,S0~S4095,X0~X1777,Y0~Y1777,T0~T399,C0~C255!							
-	X,Y element range limit MUMM32767,50~5405,X0~X1777,10~1777,10~1355,C0~C255!							
Apr content die e	and a string oct							
Ger	Generate configuration file Cancel							

The configurable contents are as follows:

Options	Setting Content	Note
Samplingtime	1 1900	The time when the element data is uploaded
Sampling time	1–1800s	to the cloud server periodically
Timesuttime	1 20-	Wait timeout when the communication with
Timeout time	1-30s	cloud server fails
Detrectioner	1 10 times	The number of retries required when the cloud
Retry times	1–10 times	server fails to collect.

Step 5 After the configuration is completed, click "Generate configuration file", then download this project to PLC, and set PLC to RUN state.

At this point, you have configured the elements to be monitored, and you can view these elements in the industrial IoT monitoring platform.

Step 1 On the homepage of the IoT monitoring platform, click online devices to enter the device monitoring page.

E IOT Industrial Internet industry application platform	Search adapter number, menu, device name,	device barcode, device type r	English 🔻 🕫 🖡	comm_0107713 Logout
Constant And	×			» ~
Real time monit E Common menu +	Overview		Login information	
Large screen display				
Monitoring overview	Total equipment	Online devices	Login times	43
🕎 Equipment center 🗸	2	1	Registration time	2023-08-02 16:20:24
atter sales center 🛛 👻	Abnormal devices	Remind Maintain	Last login time	2024-02-20
🐲 Business Center 🛛 👻	0	0		16:47:21
👪 User center 🗸 🗸			Add devices quickly	Add device type
Data Overview			Please enter the ada	
Se Customization C	Recent Month User Added		Please enter the ada	pter nur
(前) Operation center ∨			Please enter secret.)	ey
0.8 © Configuration ce ~			Please enter device	name
ata center v			Device Type	Submit
0.4				

Step 2 Select the device currently in use on the device monitoring page and click its adapter code to move to the next tier of device monitoring page.

TS600 Series Programmable Logic Controller Programming and Application Manual


	met industry application platform	Search adapter number	, menu, device name, device baro	code, device type r $\bigcirc_{\scriptscriptstyle h}$	English 🔻 🤞 🐥	⊘ comm_0107713 Logout
📴 Monitor 🛛 🔿	≪ ☆ Equipment monit	oring ×				» ~
☑ Real time monit Ξ	Equipment monitoring	a				
Large screen display	Equipment monitoring	9				
D Monitoring overview	Adapter code	device name	Device Type	✓ Device model	Qs	earch
JEquipment center V	More Conditions					_
🗥 After sales center 🗸						
Susiness Center V	Add device Template do		istorical data export Export			
👪 User center 🗸 🗸	device name	Adapter code	Latest data upda	▼ Founder	Device type	 Network state
System center V	me 202312233866	8616jk8616js	2024-02-20 17:1			T.ill China Mobile
📚 Customization C 🗸						China Wobie
創 Operation center ~				1 b to	1 page go	1 in total 10 / page 🗸
\bigcirc Configuration ce $$						
🕁 data center 🛛 🗸						

Step 3 Click "Param manage" on this page.

IOT Industrial Internet industry	search adapter number, menu, device name, device barcode, device type r 🔍 English 🔻 🖈 🌒 🕜 comm_0107713	Logout
🕮 Monitor 💦 🔦 🗘	Equipment monitoring ×	~
🖾 Real time monit 🛛 🗏		
Large screen display	er code 8616jk8616js 👻 Search Search Other Device Return)
Monitoring overview	ms backup Offline data Param manage Param labels Historical data export Jump to map Jump to remote upgrade	
📮 Equipment center 🗸 🗸		
After sales center ~ C	Chart Param details	
😻 Business Center 🗸 🗸		- 1
👪 User center 🗸 🗸		
System center V		
Scustomization C V		
窗 Operation center ~		
⑦ Configuration ce ∨ Esse	tential information Operation record Fault overview params modification record remote upgrade record Maintain record	
📸 data center 🛛 🗸		
https://iot.invt.com/device/jkxq?deviceId=222748adaptorCode=8616jk8616	vice number: foatspecked/dz device name: me Device type: 123 Device model:	

Step 4 Click "Add" to configure a monitor.

Param nan	me	pl	ease selec	tParam type	▼ r	nodbus addr	ess	Q	Search		
Export	Temp	late downlo	ad	Batch import	+	Add					
Sort	Par	Par	Dev	Unit	mod	Ope	Par	Fou	Cre	Fun	Ope
					暫う	し数据					
						\triangleleft	⊳ to	1 pa	ge go	0 in total	10 / page
											4



- When monitoring D0 element, the Modbus address is filled in "0".
- When monitoring R0 element, the Modbus address is filled in "32768".

Add			3	×
	* Param name(Chinese)	DO		
	Param name(English)	This parammater is mandatory and the value cannot be space or null		
	* Industry owned		Ŧ	
	* Device type			
	Param type	Running param Writable Curve data Float number(2 byte addr) Display value in hex	¢.	
	Function code	Multiple function codes are separated by English colon: (can be automatically converted to modbus address)		
	* modbus address 🧿	O Slave station: range:1-25€ acquisition cycle: 30sec Bit index.		

The following table shows the Modbus addresses, and you can query the elements to be monitored according to the following table.

Element	Туре	Total quantity	Modbus address
M0-M32767	Bit element	32768	m0-m32767
S0-S4095	Bit element	4096	m32768-m36863
X0-X1777	Bit element	1024	m40960-m41983
Y0-Y1777	Bit element	1024	m45056-m46079
T0-T399	Bit element	400	m49152-m49551
C0-C255	Bit element	256	m49664-m49919
D0-D32767	Word element	32768	0-32767
R0-R16383	Word element	32768	32768-49151
T0-T399	Word element	400	57344-57743
C0-C255	Word element	256	57856-58111
Z0-Z15	Word element	16	58368-58383

- When monitoring bit elements, the rule for filling in the Modbus address is: "m"+"Modbus address". Example: When monitoring M0 bit elements, the Modbus address is filled in "m0".
- When monitoring coil elements, such as S0, the Modbus address is filled with m32768. (m represents the read-write coil followed by the Modbus address)

đ							
* Param name(Chinese)	S0						
Param name(English)	This parammater is ma	ndatory and the value can	not be space or	null			
* Industry owned							
* Device type							
Param type	Running param	* 🔽 Writable	Curve dat	a 📃 Float number	(2 byte addr)	Display value in hex	
Function code	Multiple function codes	are separated by English	colon: (can be a	utomatically converted	to modbus address	i)	
* modbus address	m32768	Slave station:	range:1-25€	acquisition cycle:	30sec	Ψ.	

Step 6 At this time, the value of D0 can be monitored in the monitoring parameters.


E IOT Industrial Internet industry application platform		Search adapter number, menu, device name, device ba	rcode, device type r 🔍 English 👻 🖈 🌲 🕐 comm_0107713	Logout Version: V2.6.16
🖼 Monitor 🔷 🛠 🗘 Equipment monitoring	×			» ~
Real time monit Adapter code 8616jk8616js	 Search Search Other Device 	Return		
Large screen display Adapter code Bollopkolotops Monitoring overview params backup Offline data Pi		imp to map Jump to remote upgrade		
Equipment center				
After sales center V Monitoring parameters Ch	art Param details			
Business Center ~				
Als User center v D0				
System center v	Z			
S Customization C V				
📸 Operation center 🗸 👂				
ⓒ Configuration ce ∨				
📸 data center 🗸 🗸				
Essential information Operat	ion record Fault overview params modification r	record remote upgrade record Maintain re-	cord	
Device number: 202312233866	device name: me	Device type: 123	Device model:	
device barcode:	Founder: 1809#6	Create time: 2023-12-23 09:59:51	Device address: Shajiang Road, Bao'an District, Shenzhen City, Province $\widehat{\mathbf{Q}}$	Guangdong
Adapter code: 8616jk8616js	SIM card serial number: 898604D81023D0134397	inverter/PLC barcode:	inverter/PLC model:	

Step 7 Click the Write button in the lower right corner to write the element value.

IOT Industrial Internet Industry application platform	Search adapter number, menu, device name, device barcode, device type r 🔍 English 👻 🤌 🄅) comm_0107713 Logout Version: V2.6.16
🐯 Monitor 🔹 🛠 🟠 Equipment monitoring 🛛		» ~
Real time monit Ξ		
Large screen display Adapter code 8616jk8616js	rch Search Other Device Return	 Ø
23 Monitoring overview params backup Offine data Param manage Param	n labels Historical data export Jump to map Jump to remote upgrade	
₽ Equipment center V		
After sales center V Monitoring parameters Chart Param deta	ails	
Business Center Do		
48 User center v		
System center V		
S Customization C V	[D0] value modify X	
Operation center V	4	
⊙ Configuration ce ∨		
😭 data center 🗸 🗸	Unce: \$2596	
Essential information Operation record Fault of	overview params modification record remote upgrade record Maintain record	
Device number: device name: me 2023/2233966	Device type: 123 Device model:	5

21.8 Module Interface Description

See the following table for the meaning of 4G module interface.



No.	Port type	Interface sign	Definition	Description
1	SD card socket	SD	Micro SD	Standard definition
		NET	Network indicator	Slow flash: No sim card/registering in the network/network register failure Flash: Data link established
	la di sata u	SIG	Signal indicator	Steady On: Good signal Slow flash: The signal is average Off: Poor signal
2	2 Indicator	RUN	Operation status indicator	Steady On: MQTT login Flash at an interval of 3s: MQTT login failed Off: Abnormal operation Flash at an interval of 1s: VPN on
		PWR	Power indicator lamp	Power on: ON Power off: Off
3	4G antenna interface	4G	4G antenna interface	-
4	SIM card interface	-	Micro SIM card	-
5	Board-to-board interface	-	Communicate with the host	Only applicable to TS600 Series PLC host

22 Appendix

22.1 Modbus Protocol

22.1.1 Modbus RTU

When the device uses RTU (Remote Terminal Unit) mode to communicate on Modbus serial link, each 8-bit byte in the message contains two 4-bit hexadecimal characters. The main advantages of this mode are higher data density and higher throughput than ASCII mode at the same baud rate. Each message must be sent in a continuous character stream.

The format of each byte (11 bits) of RTU mode is:

• Coding system: 8-bit binary

Each 8-bit byte in the message contains two 4-bit hexadecimal characters (0 – 9, A – F)

• Bits per Byte: 1 start bit

8 data bits, the least significant bit is sent first

1 bit as parity bit

1 stop bit, and 2 stop bits are required when there is no check bit

The data frame format is as follows:

Start	Slave Address	Function code	Data	CRC Check	End
≥ 3.5	1 character	1	0 – 252	2 character	≥ 3.5
characters	1 character	1 character	characters	2 character	characters

22.1.2 Modbus ASCII

When devices on the Modbus serial link is configured to communicate using an ASCII (American Standard Code for Information Interchange) mode, each 8-bit byte in the message is sent with two ASCII characters. This mode is used when the communication link or device cannot comply with the timing management of RTU mode. *Note:* Because one byte requires two characters, this mode is less efficient than RTU.

Example: Byte 0X5B is encoded as two characters: 0x35 and 0x42 (ASCII code 0x35 = "5", 0x42 = "B").

The format of each byte (10 bits) in ASCII mode is:

• Coding system: Hexadecimal, ASCII characters 0 – 9, A – F

Each ASCII character in the message contains 1 hexadecimal character

• Bits per Byte: 1 start bit

7 data bits, the least significant bit is sent first

1 bit as parity bit

1 stop bit, and 2 stop bits are required when there is no check bit


The data frame format is as follows:


Beginning Character	Slave Address	Function code	Data	LRC Check	End
1 character":"	2 character	2 character	0–2x252 characters	2 character	2 characters: CR, LF

22.1.3 Modbus TCP

Modbus messaging service provides client/server communication between devices connected in the same Ethernet TCP/IP network.

Modbus protocol defines a simple Protocol Data Unit (PDU) independent of the underlying communication layer. Modbus protocol mapping on a particular fieldbus or network can introduce some additional domains on application data units (ADU).





The data frame format is as follows:

MBAP Header	Function code	Data	
7 bytes	2 bytes	0 – 252 bytes	

Data frame format description:

Domain	Length	Master	Slave	Description
1 character":"	2 character	0–2x252 characters	2 character	2 character
Transaction meta identifier	2 bytes	Master startup	Slave replication	Modbus requests/responds to the identification code of the transaction, and the master identifies the identifier after sending the request to confirm that the identifiers of the master and slave are consistent
Protocol identifier	2 bytes	Master startup	Slave replication	Modbus protocol: 0
Length	2 bytes	Master startup	Slave startup	Number of subsequent messages (bytes)
Unit identifier	1 bytes	Master startup	Slave replication	Slave identification code/slave address
Transaction meta identifier	2 bytes	Master startup	Slave replication	Modbus requests/responds to the identification code of the transaction, and the master identifies the identifier after sending the request to confirm that the identifiers of the master and slave are consistent

22.1.4 Modbus Function Code

Function code	Name	Note
01(0x01)	Read coils	Read bit
02(0x02)	Read discrete input	Read bit
03(0x03)	Read save register	Read word
04(0x04)	Read input register	Read word

TS600 Series Programmable Logic Controller Programming and Application Manual

Appendix

Function code	Name	Note
05(0x05)	Write single coil	Write bit
06(0x06)	Write single register	Write word
15(0x15)	Write multiple coils	Write bit
16(0x16)	Write multiple registers	Write word

22.1.5 Example of Modbus Message Parsing

The request and response messages for reading a register with the above three Modbus protocols are given below.

22.1.5.1 Modbus-RTU

• Master request message

Slave Address	Function code	Start address (high)	Start address (low)	Quantity (high)	Quantity (low)	CRC Check
0x01	0x03	0x00	0x01	0x00	0x01	0xD5 0xCA

• Slave response message

Slave Address	Function code	Number of Bytes	Register Value (High)	Register Value (High) (Low)	
0x01	0x03	0x02	0x00	0x00	0xB8 0x44

22.1.5.2 Modbus-ASCII

• Master request message

Start	Slave Address	Slave Address	Function code	Function code	Start address (high)	Start address (high)	Start Address (Low)	Start Addre ss (Low)
0x3A	0x30	0x31	0x30	0x33	0x30	0x30	0x30	0x31
Quantity	Quantity	Quantity	Quantity	LRC	LRC	End	End	
(high)	(high)	(low)	(low)	Check	Check	Character	Character	
0x30	0x30	0x30	0x31	0x46	0x41	0x0D	0x0A	

• Slave response message

Start	Slave Address	Slave Address	Function code	Function code	Number of Bytes	Number of Bytes	Register Value (High)	Register Value (High)
0x3A	0x30	0x31	0x30	0x33	0x30	0x32	0x30	0x30
Register Value (Low)	Register Value (Low)	LRC	LRC Check	End Character	End Character			
0x30	0x30	0x46	0x41	0x0D	0x0A			

22.1.5.3 Modbus-TCP

• Master request message

TS600 Series Programmable Logic Controller Programming and Application Manual

Transaction Identifier (High)	Transaction Identifier (Low)	Protocol identifier	Protocol identifier	Length (Height)	Length (Low)
0x00	0x00	0x00	0x00	0x00	0x06
Unit identifier	Function code	Start address (high)	Start address (low)	Quantity (high)	Quantity (low)
0xFF	0x03	0x00	0x01	0x00	0x01

• Slave response message

Transaction Identifier (High)	Transaction Identifier (Low)	Protocol identifier	Protocol identifier	Length (Height)	Length (Low)
0x00	0x00	0x00	0x00	0x00	0x05
Slave Address	Function code	Number of Bytes	Register Value (High)	Register Value (Low)	
0xFF	0x03	0x02	0x00	0x00	

22.1.6 Modbus Abnormal Response

The Modbus abnormal response code is as follows:

Function code	Name	Note
01	Illegal function code	The slave response function code is
		incorrect
02	Invalid data address	Illegal slave response data address
03	Invalid data	Illegal slave response data
04	Slave device failure	Slave device error

Your Trusted Industry Automation Solution Provider



Shenzhen INVT Electric Co., Ltd. Address: INVT Guangming Technology Building, Songbai Road, Matian, Guangming District, Shenzhen, China

INVT Power Electronics (Suzhou) Co., Ltd. Address: No. 1 Kunlun Mountain Road, Science & Technology Town,

Gaoxin District, Suzhou, Jiangsu, China





Copyright© INVT. Manual information may be subject to change without prior notice.





INVT mobile website

INVT e-manual