


环境	条件
环境温度	◇ -10~+50℃； ◇ 当环境温度超过 40℃ 后，请按照 1℃ 降额 1% 的比例降额； ◇ 我们不建议在 50℃ 以上的环境中使用变频器； ◇ 为了提高机器的可靠性，请在温度不会急剧变化的场所使用变频器； ◇ 在控制柜等封闭空间内使用时，请使用冷却风扇或冷却空调进行冷却，以避免内部温度超过条件温度； ◇ 温度过低时，在长时间断电后再上电运行，需增加外部加热装置，消除内部结冰现象，否则容易导致机器损坏。
湿度	◇ 空气的相对湿度小于 90%； ◇ 不允许凝露； ◇ 在存在腐蚀性气体的空间中，最大相对湿度不能超过 60%。
运行环境条件	请将变频器安装在如下场所： ◇ 远离电磁辐射源的场所； ◇ 无油污、腐蚀性气体、易燃性气体、无放射性物质、无有害气体及液体的场所； ◇ 金属粉末、尘埃、油、水等异物不会进入变频器内部的场所（请不要把变频器安装在木材等易燃物上面）； ◇ 盐份少的场所； ◇ 无阳光直射的场所。
海拔高度	◇ 1000m 以下； ◇ 当海拔高度超过 1000m 以上，请按照 100m 降额 1% 的比例降额； ◇ 当海拔高度超过 3000m，请与当地英威腾经销商或办事处联系，咨询详细信息。
振动	最大加速度不超过 5.8m/s ² (0.6g)
安装方向	为了不使变频器的散热效果降低，请垂直安装



端子符号	端子名称	功能描述
R (L)	三相（单相）主回路 电源输入	三相（单相）交流输入端子，与电网连接
S (N)		
T		
U	变频器输出	三相交流输出端子，一般接电机
V		
W		
P1	直流电抗器端子	◇ P1、(+) 外接直流电抗器端子 ◇ (+)、(-) 外接制动单元端子/共直流母线端子 ◇ PB、(+) 外接制动电阻端子
(+)	直流电抗器端子、 制动单元端子	
(-)	制动单元端子	
PB	制动电阻端子	
⊕	安全保护接地端子 (PE)	每台机器 PE 端子必须可靠接地




图 3-1 基本控制回路接线图

表 3-2 基本控制回路端子说明


端子名称	说明	
+10V	本机提供 10V 电源	
AI _n	AI 为模拟量输入，默认为电压输入，可通过跳线帽/拨码开关/参数设置为电流输入。	
GND	+10V 的参考零电位	
AOn	模拟量输出范围：0~10V 电压或 0~20mA 电流；	
ROnA	继电器输出；ROnA 常开，ROnB 常闭，ROnC 公共端； 触点容量：3A/AC250V，1A/DC30V。	
ROnB		
ROnC		
HDO	开关容量：50mA/30V； 输出频率范围：0~50kHz；	
COM	+24V 的公共端	
CME	开路集电极输出的公共端，出厂时与 COM 短接	
Y1~Yn	开关容量：50mA/30V； 输出频率范围：0~1kHz。	
485+	485 通讯端口，485 差分信号端口，标准 485 通讯接口请使用双绞线屏蔽线，	
485-	485 通讯的 120Ω 终端匹配电阻通过拨码开关或跳线选择接入。	
PE	接地端子	
PW	由外部向内部提供输入开关量工作电源。	
24V	变频器提供用户电源，最大输出电流 200mA。	
S1~Sn	开关量输入	1. 内部阻抗：3.3kΩ 2. 可接受 12~30V 电压输入 3. 该端子为双向输入端子，支持 NPN 和 PNP 接法 4. 最大输入频率：1kHz 5. 全部为可编程数字量输入端子，用户可通过功能码设定端子功能
HDIA	除有关量输入功能外，还可作为高频脉冲输入通道；	
HDIB	最大输入频率：50kHz； 占空比：30%~70%； 支持正交编码器输入，具有测速功能。（只有同时有 HDIA 和 HDIB 才支持正交编码器输入）	
+24V—H1	STO 输入 1	1、安全转矩停止(STO)冗余输入，外接常闭触点，触点断开时 STO 动作，变频器停止输出；
+24V—H2	STO 输入 2	2、安全输入信号线使用屏蔽线，接线长度控制在 25 米以内； 3、出厂时 H1、H2 端子均与+24V 短接，使用 STO 功能时需要将端子上的短接片拆除。

注意：

- n 为自然数。
- 详细端子接线示意图参见对应系列正版完整电子说明书，请扫描本手册第 8 章节或变频器机身二维码获取。

	◇ 请确认所有的端子已正确紧固连接。 ◇ 请确认电机与变频器功率是否匹配。
---	--

接线及电源检查确认无误后，合上变频器输入侧交流电源的空气开关，给变频器加电，以带 LED 键盘变频器为例（其他键盘参见对应系列完整版说明书），键盘首先显示“8.8.8.8.”，当数码管显示字符变为设定频率（例如 50.00）时，表明变频器已初始化完毕，变频器处于待机状态。



快速运行操作如下图所示:





表 5-1 LED 键盘简介

名称		说明				
状态指示灯		灯灭时表示变频器处于停机状态；灯闪烁表示变频器处于参数自学习状态；灯亮时表示变频器处于运转状态；				
		正反转指示灯；灯灭表示处于变频器正转状态；灯亮表示变频器处于反转状态。				
		键盘操作，端子操作与远程通讯控制的指示灯。 灯灭表示键盘操作控制状态；灯闪烁表示端子操作控制状态；灯亮表示处于远程操作控制状态				
		故障指示灯；当变频器处于故障状态下，该灯点亮；正常状态下为熄灭；当变频器在预报警状态下，该灯闪烁。				
单位指示灯	表示键盘当前显示的单位。					
		Hz	频率单位			
		RPM	转速单位			
		A	电流单位			
		%	百分数			
数码显示区	5 位 LED 显示，显示设定频率、输出频率等各种监视数据以及报警代码。					
	显示字母	对应字母	显示字母	对应字母	显示字母	对应字母
	0	0	1	1	2	2
	3	3	4	4	5	5
	6	6	7	7	8	8
	9	9	A	A	B	B
	C	C	d	d	E	E
	F	F	H	H	I	I
	L	L	N	N	n	n
	o	o	P	P	r	r
	S	S	t	t	U	U
	v	v	.	.	-	-
	数字电位器	调节频率。请参考功能码 P08.41 的内容。				
按钮区		编程键	一级菜单进入或退出，快捷参数删除			
		确定键	逐级进入菜单画面、设定参数确认			

Environment	Condition
Ambient temperature	✧ -10—+50°C ✧ When the temperature exceeds 40°C, derate by 1% for every increase of 1°C. ✧ Do not use the VFD when the ambient temperature exceeds 50°C. ✧ In order to improve reliability, do not use the VFD in the places where the temperature changes rapidly. ✧ When the product is used in a closed space, such as control cabinet, use a cooling fan or air conditioner for cooling, preventing the internal temperature from exceeding the temperature required. ✧ When the temperature is too low, if you want to use the product that has been idled for a long time, install an external heating device before the use to eliminate the freeze inside the product. Otherwise, the product may be damaged.
Humidity	✧ RH: less than 90% ✧ Condensation is not allowed. ✧ The max. RH cannot exceed 60% in the environment where there are corrosive gases.
Running environment	Install the VFD in a place: ✧ Away from electromagnetic radiation sources

Environment	Condition
	✧ Away from places with oil mist, corrosive gases, combustible gases, radioactive material, or harmful gas or liquid ✧ Without the chance for foreign objects such as metal powder, dust, oil and water to fall into the VFD (do not install the VFD onto combustible objects such as wood) ✧ With low salt content. ✧ Without direct sunlight.
Altitude	✧ Lower than 1000m ✧ When the altitude exceeds 1000m, derate by 1% for every increase of 100m. ✧ When the installation site altitude exceeds 3000m, consult the local INVT dealer or office.
Vibration	The max. amplitude of vibration cannot exceed 5.8m/s^2 (0.6g).
Installation direction	Install the VFD vertically to ensure good heat dissipation performance.





Terminal symbol	Terminal name	Function description
R (L)	3PH (or 1PH) main circuit Power input	3PH (or 1PH) AC input terminals, connected to the grid
S (N)		
T		
U		
V	VFD outputs	3PH AC output terminals, connected to the motor usually
W		
P1	DC reactor terminal	✧ P1 and (+) connect to external DC reactor terminals.
(+)	DC reactor terminal, Braking unit terminal	✧ (+) and (-) connect to external braking unit terminals or the shared DC bus terminals.
(-)	Braking unit terminal	✧ PB and (+) connect to external braking resistor terminals.
PB	Braking resistor terminal	
⊕	Grounding terminal for safe protection (PE)	The PE terminals of each machine must be grounded reliably.


Terminal name	Description	
+10V	Locally provided 10V power supply	
AI _n	AI is an analog input, defaults to a voltage input, and can be set to a current input via a jumper cap/DIP switch/parameter.	
GND	Reference zero potential of +10V	
AOn	Analog output range: 0~10V or 0~20mA	
ROnA	Relay output. ROnA: NO; ROnB: NC; ROnC: common; Contact capacity: 3A/AC250V, 1A/DC30V	
ROnB		
ROnC		
HDO	Switch capacity: 50mA/30V Output frequency range: 0~50kHz	
COM	Common terminal of +24V	
CME	Common terminal of open collector output; short connected to COM by default	
Y1~Yn	Switch capacity: 50mA/30V Output frequency range: 0~1kHz	
485+	RS485 communication port, RS485 differential signal port and standard RS485 communication port must use twisted shielded pairs; 120Ω terminal matching resistor for RS485 communication is connected through the DIP switch or jumper.	
485-		
PE	Grounding terminal	
PW	External power input terminal for digital input circuits.	
24V	User power supply provided by the VFD. Max. output current: 200mA	
S1~Sn	Digital input	1. Internal impedance: 3.3kΩ 2. 12~30V voltage input is acceptable. 3. Bi-direction input terminal, supporting both NPN and PNP 4. Max. input frequency: 1kHz 5. All are programmable digital input terminals, the functions of which can be set through function codes
HDIA	In addition to digital input functions, the terminal can also act as a high frequency pulse input channel. Max. input frequency: 50kHz Duty ratio: 30%~70% Supporting quadrature encoder input; with the speed measurement function (only support for quadrature encoder input when both HDIA and HDIB are available)	
HDIB		
+24V—H1	STO input 1	1. Safe torque off (STO) redundant input, connected to the external NC contact. When the contact opens, STO acts and the VFD stops output. 2. Safety input signal wires use shielded wires whose length is within 25m. 3. The H1 and H2 terminals are short connected to +24V by default. Remove the short connectors from the terminals before using STO function.
+24V—H2	STO input 2	

- N is a natural number.
- For detailed terminal wiring diagrams, please refer to the full e-manual for the corresponding series which can be obtained by scanning part 8 of this manual or the QR code of the VFD.

	✧ Ensure that all terminals have been securely connected. ✧ Ensure that the motor power whether matches the VFD power.
---	--

After confirming the wiring and power are correct, close the air switch of the AC power at the VFD input side to power on the VFD. Using a LED keypad for example, the keypad displays 8.8.8.8.8 upon power-on and then the set frequency (50.00 in the example), indicating the VFD is initialized and ready to run. (For details about other series of keypad, see the corresponding product manual of full version.)



Name	Description					
Status indicator	RUN/TUNE	VFD running status indicator. LED off: The VFD is stopped. LED blinking: The VFD is autotuning parameters. LED on: The VFD is running.				
	FWD/REV	FWD/REV running indicator. Off: The VFD is running forward. On: The VFD is running reversely.				
	LOCAL/REMOT	Indicates whether the VFD is controlled through the keypad, terminals, or communication. Off: The VFD is controlled through the keypad. Blinking: The VFD is controlled through terminals. On: The VFD is controlled through remote communication.				
	TRIP	Fault indicator. On: in fault state. Off: in normal state. Blinking: in pre-alarm state				
Unit indicator	Unit displayed currently					
		Hz	Frequency unit			
		RPM	Rotation speed unit			
		A	Current unit			
		%	Percentage			
		V	Voltage unit			
Digital display zone	Five-digit LED displays various monitoring data and alarm codes such as the frequency setting and output frequency.					
	Display	Means	Display	Means	Display	Means
	0	0	1	1	2	2
	3	3	4	4	5	5
	6	6	7	7	8	8
	9	9	A	A	B	B
	C	C	d	d	E	E
	F	F	H	H	I	I
	L	L	N	N	n	n
	o	o	P	P	r	r
	S	S	t	t	U	U
	v	v	.	.	-	-

