

## Goodrive28 系列变频器快速使用指南

本指南简要介绍了 Goodrive28 系列变频器（简称 GD28）的外围接线、端子、键盘、快速运行、常用功能参数设置、常见故障对策、产品尺寸和能效数据。

拨打服务热线 400-700-9997 或访问 [www.invt.com.cn](http://www.invt.com.cn) 获取更多信息及资源下载。保修条款详见完整版电子说明书。



- 警告**
- 本指南仅包含基本的安装调试信息。若不遵守相关文档中的安全说明和安装调试说明，可能导致设备损坏、人身伤害、甚至人员死亡等事故。
  - 只有培训合格的专业人员才允许进行相关操作。

- 危险**
- 禁止在电源接通的情况下进行接线、检查或更换器件等作业。进行这些作业前，须确认所有输入电源已断开，并等待不短于变频器上标注的时间。

| 至少等待时间 | 变频器机型                                                                        |
|--------|------------------------------------------------------------------------------|
| 5 分钟   | 1PH 220V 0.2~4kW; 3PH 220V 0.2~15kW;<br>3PH 380V 0.4~22kW; 3PH 575V 0.4~22kW |

### 1 外围接线





图 2-1 变频器典型接线




### 3 端子功能说明

表 3-1 变频器端子说明

| 端子标识                | 功能说明                                                                                                                                                                                                                    |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 主回路端子               |                                                                                                                                                                                                                         |
| L1, L2, L3 (L1, L2) | 三相（或单相）交流输入端子，与电网连接                                                                                                                                                                                                     |
| U, V, W (+)         | 三相（或单相）交流输出端子，一般接电机                                                                                                                                                                                                     |
| (+)                 | (+), (-) 共直流母线端子                                                                                                                                                                                                        |
| (-)                 | (+), (-) 共直流母线端子                                                                                                                                                                                                        |
| PB                  | 外接制动电阻端子                                                                                                                                                                                                                |
| PE                  | PE 端子，每台机器 PE 端子必须可靠接地                                                                                                                                                                                                  |
| 控制回路端子              |                                                                                                                                                                                                                         |
| +10V                | 本机提供+10V 电源，最大输出电流 50mA                                                                                                                                                                                                 |
| AI1                 | 输入范围：0~10V/0~20mA<br>输入阻抗：电压输入时 33kΩ，电流型输入 250Ω<br>电压或电流输入由拨动开关 AI1(I/V)切换设定，同时功能码 P05.76 需做设置<br>分辨率：全量程 1%精度                                                                                                          |
| AI2                 | 输入范围：-10~10V/0~20mA<br>输入阻抗：电压输入时 33kΩ，电流型输入 250Ω<br>电压或电流输入由拨动开关 AI1(I/V)切换设定，同时功能码 P05.76 需做设置<br>分辨率：全量程 1%精度                                                                                                        |
| AO1                 | 输出范围：0~10V/0~20mA<br>电压或电流输出由拨动开关 AO1(I/V)设定<br>分辨率：全量程 1%精度                                                                                                                                                            |
| RO1A, RO1B, RO1C    | 继电器输出：RO1A 常开，RO1B 常闭，RO1C 公共端<br>触点容量：3A/AC 250V, 1A/DC 30V                                                                                                                                                            |
| GND                 | +10V 电源参考地和模拟信号参考地                                                                                                                                                                                                      |
| HDO1                | 开关容量：50mA/30V；输出频率范围：0~50kHz<br>可作普通 DO 端子，推挽输出，功能码 P06.00 配置选择                                                                                                                                                         |
| 485+                | 485 差分信号通信端口，标准 485 通信接口请使用屏蔽双绞线，485 通信的 120Ω 终端匹配电阻通过拨动开关 485(ON/OFF)选择接入                                                                                                                                              |
| 485-                |                                                                                                                                                                                                                         |
| USB                 | Type-C 接口，可直接连接 PC，通信协议为 Modbus RTU。变频器不接主电源时，可修改、保存、导入与导出参数；变频器接主电源时，可以控制变频器运行、监控变频器运行参数                                                                                                                               |
| +24V                | 变频器提供对外输出用户电源，最大输出电流 100mA<br>可作 DI 端子外部 NPN 模式电源输入（接码需打到 NPN 档位）                                                                                                                                                       |
| COM                 | +24V 数字参考地，可用作外部 PNP 模式输入（拨动开关必须设置在 PNP 位置）                                                                                                                                                                             |
| DI1~DI4 (PTC)       | DI1~DI4 数字量功能：<br>有效输入高电平范围：10~30V<br>有效输入低电平范围：0~5V<br>最大输入频率：1kHz<br>可编程数字量输入端子，用户可通过功能码设定端子功能<br>可通过拨动开关选择 NPN/PNP 模式，可支持外部电源接法<br>PTC 功能：仅 DI4 端子可配置为 PTC 过温保护功能，功能码 P05.04=57 及拨动开关打到 PTC 位置设置，过温阻值 3.6kΩ，恢复 1.5kΩ |
| HDI1                | 满足 NPN 和 PNP 切换，除具有开关量输入功能外，还可作为高频脉冲输入通道<br>最大输入频率：50kHz<br>占空比：30%~70%                                                                                                                                                 |
| STO1                | 安全转矩停止 (STO) 输入<br>STO 冗余输入，外接常闭触点，触点断开时 STO 动作，变频器停止输出<br>安全输入信号线使用屏蔽线，接线长度控制在 25 米以内<br>出厂时 STO1、STO2 均与+24V 短接，使用 STO 功能时需将端子上的短接线拆除                                                                                 |
| STO2                |                                                                                                                                                                                                                         |
| 通信扩展卡端子             |                                                                                                                                                                                                                         |
| +24E                | 外部接入 24V，可用于通信调试                                                                                                                                                                                                        |
| COM                 |                                                                                                                                                                                                                         |
| EC IN               | 支持 5 种总线类型：PROFINET、EtherCAT、EtherNet IP、Modbus TCP、EtherNet UDP；EtherCAT 为 IN 端口，其它协议不区分方向                                                                                                                             |
| EC OUT              | 支持 5 种总线类型：PROFINET、EtherCAT、EtherNet IP、Modbus TCP、EtherNet UDP；EtherCAT 为 OUT 端口，其它协议不区分方向                                                                                                                            |

### 4 键盘



LED 键盘显示器对应内容

| 显示 | 对应 | 显示 | 对应 | 显示 | 对应 | 显示 | 对应 |
|----|----|----|----|----|----|----|----|
| 0  | 0  | 1  | 2  | 2  | 3  | 3  | 3  |
| 4  | 4  | 5  | 6  | 6  | 7  | 7  | 7  |
| 8  | 8  | 9  | 9  | A  | b  | b  | b  |
| C  | C  | d  | E  | E  | F  | F  | F  |
| H  | H  | I  | L  | L  | N  | N  | N  |
| n  | n  | O  | P  | P  | r  | r  | r  |
| S  | S  | t  | U  | U  | v  | v  | v  |
| .  | .  | -  |    |    |    |    |    |

| 指示灯         | 状态                                                                                              | 含义            |      |
|-------------|-------------------------------------------------------------------------------------------------|---------------|------|
| RUN/TUNE    |  常亮           | 变频器处于运转状态     |      |
|             |  闪烁          | 变频器处于参数自学习状态  |      |
| FWD/REV     |  常亮          | 变频器处于待机状态     |      |
|             |  常灭          | 变频器反转         |      |
| LOCAL/REMOD |  常亮          | 变频器正转         |      |
|             |  常灭          | 变频器使用通信运行指令通道 |      |
| LOCAL/REMOD |  闪烁          | 变频器使用端子运行指令通道 |      |
|             |  常灭          | 变频器使用键盘运行指令通道 |      |
| RUN/TUNE    |  同时常亮且显示故障代码 | 变频器处于故障状态     |      |
| FWD/REV     |  同时闪烁        | 变频器处于预报警状态    |      |
| LOCAL/REMOD |                                                                                                 |               |      |
| 单位指示灯       | 亮显示键盘当前显示的单位。                                                                                   |               |      |
|             |              | Hz            | 频率单位 |
|             |              | RPM           | 转速单位 |
|             |              | A             | 电流单位 |
|             |              | %             | 百分数  |
|             |              | V             | 电压单位 |



## 7 常见故障及对策

| 故障代码 | 故障类型   | 可能的原因                                                                                                                                                                                                                                                                              | 故障解决方法                                                                                                                                                                                                                                                                                                                                                                              |
|------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E4   | 加速过电流  | <ul style="list-style-type: none"> <li>● 加速时间设置过短</li> <li>● 负载过大或负载突变</li> <li>● 在电机旋转过程中启动</li> <li>● 三相输出电流不平衡</li> <li>● 电机控制方式为无 PG 矢量控制方式时，没有进行参数自学习</li> <li>● 电机控制方式为 V/F 控制时，V/F 曲线设置异常</li> <li>● 外部存在强干扰源（系统有接触器切换、系统接地不良）</li> <li>● 电网电压偏低</li> <li>● 硬件故障</li> </ul> | <ul style="list-style-type: none"> <li>● 增加加速时间，或通过 P11.06 降低软件限流点；若工艺要求急加速，则增大变频器容量</li> <li>● 增大变频器容量，确保电机无堵转，负载设备无异常</li> <li>● 待电机停稳后启动，或通过参数 P01.00 选择转速追踪启动</li> <li>● 检查变频器输出电压和电机阻抗，确保三相平衡</li> <li>● 按电机铭牌设置额定参数，通过 P00.15 进行参数自学习</li> <li>● 重新调整 V/F 曲线设定的频率和电压关系，降低频率对应的电压值</li> <li>● 避免存在强干扰现象，电机线远离接触器、系统可靠接地</li> <li>● 改善用电质量，或增大变频器容量</li> <li>● 更换变频器</li> </ul> |
| E5   | 减速过电流  | <ul style="list-style-type: none"> <li>● 减速时间设置过短</li> <li>● 软件限流点设置过高</li> <li>● 负载过大或负载突变</li> <li>● 三相输出电流不平衡</li> <li>● 电机控制方式为无 PG 矢量控制方式时，没有进行参数自学习</li> <li>● 电机控制方式为 V/F 控制时，V/F 曲线设置异常</li> <li>● 外部存在强干扰源（系统有接触器切换、系统接地不良）</li> <li>● 硬件故障</li> </ul>                    | <ul style="list-style-type: none"> <li>● 增加减速时间，或通过 P11.06 降低软件限流点若工艺要求急减速，则可以尝试增大变频器容量</li> <li>● 降低 P11.06 软件限流点</li> <li>● 增大变频器容量，确保电机无堵转，负载设备无异常</li> <li>● 检查变频器输出电压和电机阻抗，确保三相平衡</li> <li>● 按电机铭牌设置额定参数，通过 P00.15 进行参数自学习</li> <li>● 重新调整 V/F 曲线设定的频率和电压关系，降低频率对应的电压值</li> <li>● 避免存在强干扰现象，电机线远离接触器、系统可靠接地</li> <li>● 更换变频器</li> </ul>                                        |
| E6   | 恒速过电流  | <ul style="list-style-type: none"> <li>● 负载过大或负载突变</li> <li>● 软件限流点设置过高</li> <li>● 三相输出电流不平衡</li> <li>● 电机控制方式为无 PG 矢量控制方式时，没有进行参数自学习</li> <li>● 电机控制方式为 V/F 控制时，V/F 曲线设置异常</li> <li>● 外部存在强干扰源（系统有接触器切换、系统接地不良）</li> <li>● 电网电压偏低</li> <li>● 硬件故障</li> </ul>                      | <ul style="list-style-type: none"> <li>● 增大变频器容量，确保电机无堵转，负载设备无异常</li> <li>● 降低 P11.06 软件限流点</li> <li>● 检查变频器输出电压和电机阻抗，确保三相平衡</li> <li>● 按电机铭牌设置额定参数，通过 P00.15 进行参数自学习</li> <li>● 重新调整 V/F 曲线设定的频率和电压关系，降低频率对应的电压值</li> <li>● 避免存在强干扰现象，电机线远离接触器、系统可靠接地</li> <li>● 改善用电质量，或增大变频器容量</li> <li>● 更换变频器</li> </ul>                                                                       |
| E7   | 加速过电压  | <ul style="list-style-type: none"> <li>● 加速时间过短</li> <li>● 电网电压偏高</li> <li>● 在电机旋转过程中启动</li> <li>● 负载存在较大能力回馈</li> <li>● 过压失速功能设置不合理</li> </ul>                                                                                                                                    | <ul style="list-style-type: none"> <li>● 增加加速时间或开启过压失速功能。</li> <li>● 改善用电质量，符合变频器输入电压规格（见产品规格）</li> <li>● 待电机停稳后启动，或通过参数 P01.00 选择转速追踪启动</li> <li>● 加装制动单元、能量回馈单元，或排除外力拖动负载发电的因素</li> <li>● 通过 P11.03 开启过压失速保护功能，降低 P11.04 过压失速保护电压值</li> </ul>                                                                                                                                     |
| E8   | 减速过电压  | <ul style="list-style-type: none"> <li>● 减速时间过短</li> <li>● 电网电压偏高</li> <li>● 负载存在较大能力回馈</li> <li>● 过压失速功能设置不合理</li> </ul>                                                                                                                                                          | <ul style="list-style-type: none"> <li>● 增加减速时间；若工艺要求急减速，则可以加装制动单元、能量回馈单元或使用磁通制动功能</li> <li>● 改善用电质量，符合变频器输入电压规格（见产品规格）</li> <li>● 加装制动单元、能量回馈单元，或排除外力拖动负载发电的因素</li> <li>● 通过 P11.03 开启过压失速保护功能，降低 P11.04 过压失速保护电压值</li> </ul>                                                                                                                                                      |
| E9   | 恒速过电压  | <ul style="list-style-type: none"> <li>● 电网电压偏高</li> <li>● 负载存在较大能力回馈</li> <li>● 过压失速功能设置不合理</li> </ul>                                                                                                                                                                            | <ul style="list-style-type: none"> <li>● 改善用电质量，符合变频器输入电压规格（见产品规格）</li> <li>● 加装制动单元、能量回馈单元，或排除外力拖动负载发电的因素</li> <li>● 通过 P11.03 开启过压失速保护功能，降低 P11.04 过压失速保护电压值</li> </ul>                                                                                                                                                                                                           |
| E10  | 直流母线欠压 | <ul style="list-style-type: none"> <li>● 电网电压偏低</li> <li>● 母线电压显示异常</li> <li>● 缓冲接触器吸合异常</li> <li>● 输入缺相时带重载运行</li> </ul>                                                                                                                                                          | <ul style="list-style-type: none"> <li>● 调高电网输入电压</li> <li>● 联系厂家</li> <li>● 联系厂家</li> <li>● 检查输入电源是否正常和输入线芯是否松动</li> </ul>                                                                                                                                                                                                                                                         |

-7-

| 故障代码 | 故障类型            | 可能的原因                                                                                                                                                                          | 故障解决方法                                                                                                                                                                              |
|------|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E11  | 电机过载            | <ul style="list-style-type: none"> <li>● 电网电压过低</li> <li>● 电机额定电流设置不正确</li> <li>● 电机堵转或负载突变过大</li> </ul>                                                                       | <ul style="list-style-type: none"> <li>● 调高电网输入电压</li> <li>● 重新设置电机参数组的电机额定电流</li> <li>● 检查负载，调节转矩提升量</li> </ul>                                                                    |
| E12  | 变频器过载           | <ul style="list-style-type: none"> <li>● 加速太快</li> <li>● 对旋转中的电机实施再启动</li> <li>● 电网电压过低</li> <li>● 负载过大</li> <li>● 变频器功率选型偏小</li> </ul>                                        | <ul style="list-style-type: none"> <li>● 增大加速时间</li> <li>● 避免停机再启动</li> <li>● 调高电网输入电压</li> <li>● 选择功率更大的变频器</li> </ul>                                                             |
| E13  | 输入侧缺相           | <ul style="list-style-type: none"> <li>● 输入 L1, L2, L3 缺相或者波动大</li> <li>● 输入侧螺丝松动</li> </ul>                                                                                   | <ul style="list-style-type: none"> <li>● 检查输入电源是否正常和输入线缆是否有松动</li> <li>● 可选择设置 P11.00 参数屏蔽</li> </ul>                                                                               |
| E14  | 输出侧缺相           | <ul style="list-style-type: none"> <li>● 输出线缆有破损或对地短路</li> <li>● 输出 U, V, W 缺相 (或负载三相严重不对称)</li> </ul> <p><b>备注:</b> 输出缺相检测时间至少需要 2.5s, 在缺相后容易失稳, 可能先报过流、过压过载和速度偏差故障。</p>      | <ul style="list-style-type: none"> <li>● 检查输出线缆是否有松动或破损</li> <li>● 检查负载是否波动大和电机三相阻抗是否平衡</li> </ul>                                                                                  |
| E16  | 逆变模块过热          | <ul style="list-style-type: none"> <li>● 风道堵塞或风扇损坏</li> <li>● 环境温度过高</li> <li>● 长时间过载运行</li> </ul>                                                                             | <ul style="list-style-type: none"> <li>● 疏通风道或更换风扇</li> <li>● 保持现场通风顺畅, 降低环境温度</li> <li>● 选择功率更大的变频器</li> </ul>                                                                     |
| E17  | 外部故障            | <ul style="list-style-type: none"> <li>● DI 端子外部故障输入信号动作</li> </ul>                                                                                                            | <ul style="list-style-type: none"> <li>● 检查外部设备输入是否正常</li> </ul>                                                                                                                    |
| E18  | Modbus/TCP 通信故障 | <ul style="list-style-type: none"> <li>● 波特率设置不当</li> <li>● 通信线路故障</li> <li>● 通信地址错误</li> <li>● 通信受到强干扰</li> </ul>                                                             | <ul style="list-style-type: none"> <li>● 设置合适的波特率</li> <li>● 检查通信接口配线连接是否正常</li> <li>● 设置正确通信地址</li> <li>● 建议更换使用屏蔽线缆, 提高抗扰性</li> </ul>                                             |
| E19  | 电流检测故障          | <ul style="list-style-type: none"> <li>● 电机线或电机绝缘异常</li> </ul>                                                                                                                 | <ul style="list-style-type: none"> <li>● 拆除电机线进行验证</li> <li>● 联系厂家</li> </ul>                                                                                                       |
| E20  | 电机自学习故障         | <ul style="list-style-type: none"> <li>● 电机容量与变频器容量不匹配, 相差 5 个功率等级以上容易出现此故障</li> <li>● 电机参数设置不当</li> <li>● 自学习出的参数与标准参数偏差过大</li> <li>● 自学习超时</li> <li>● 脉冲电流设置值是否过大</li> </ul> | <ul style="list-style-type: none"> <li>● 更换变频器型号, 或者采用 VF 模式控制</li> <li>● 检查电机接线, 电机类型和参数设置</li> <li>● 使电机空载, 重新辨识</li> <li>● 检查上限频率是否大于额定频率的 2/3</li> <li>● 适当减小脉冲电流设置值</li> </ul> |
| E21  | EEPROM 操作故障     | <ul style="list-style-type: none"> <li>● 控制参数的读写发生错误</li> <li>● EEPROM 损坏</li> </ul>                                                                                           | <ul style="list-style-type: none"> <li>● 按 STOP/RST 复位</li> <li>● 更换控制板</li> </ul>                                                                                                  |
| E22  | PID 反馈断线        | <ul style="list-style-type: none"> <li>● PID 反馈断线</li> <li>● PID 反馈源消失</li> </ul>                                                                                              | <ul style="list-style-type: none"> <li>● 检查 PID 反馈信号线</li> <li>● 检查 PID 反馈源</li> </ul>                                                                                              |
| E23  | 制动单元故障          | <ul style="list-style-type: none"> <li>● 制动线路故障或制动管损坏;</li> <li>● 外接制动电阻阻值偏小</li> </ul>                                                                                        | <ul style="list-style-type: none"> <li>● 检查制动单元, 更换新制动管</li> <li>● 增大制动电阻</li> </ul>                                                                                                |
| E24  | 运行时间到达          | <ul style="list-style-type: none"> <li>● 变频器实际运行时间大于内部设定运行时间</li> </ul>                                                                                                        | <ul style="list-style-type: none"> <li>● 联系厂家</li> </ul>                                                                                                                            |
| E25  | 电子过载            | <ul style="list-style-type: none"> <li>● 变频器按设定值进行过载预警</li> </ul>                                                                                                              | <ul style="list-style-type: none"> <li>● 检查过载预警点设置是否合理</li> </ul>                                                                                                                   |
| E27  | 参数上传错误          | <ul style="list-style-type: none"> <li>● 键盘线接触不良或断线</li> <li>● 键盘线太长, 受到强干扰</li> <li>● 键盘或主板通信部分电路故障</li> </ul>                                                                | <ul style="list-style-type: none"> <li>● 检查键盘线, 重新插拔键盘线确认故障是否存在</li> <li>● 检查环境, 排除干扰源</li> <li>● 更换硬件, 寻求维修服务</li> </ul>                                                           |
| E28  | 参数下载错误          | <ul style="list-style-type: none"> <li>● 键盘线接触不良或断线</li> <li>● 键盘线太长, 受到强干扰</li> <li>● 键盘中存储数据错误</li> </ul>                                                                    | <ul style="list-style-type: none"> <li>● 检查环境, 排除干扰源</li> <li>● 更换硬件, 寻求维修服务</li> <li>● 确定键盘备份参数的控制板软件版本是否与变频器的控制板软件版本是否一致</li> </ul>                                               |
| E30  | 以太网通信故障         | <ul style="list-style-type: none"> <li>● 通信卡与上位机 (或 PLC) 之间没有数据传输</li> </ul>                                                                                                   | <ul style="list-style-type: none"> <li>● 检查通信卡接线是否松动或掉线</li> </ul>                                                                                                                  |
| E32  | 地对地短路故障         | <ul style="list-style-type: none"> <li>● 变频器输出与地短接</li> <li>● 电流检测电路出故障</li> </ul>                                                                                             | <ul style="list-style-type: none"> <li>● 检查电机对地是否短路, 接线是否正常</li> <li>● 拆除电机线是否正常</li> <li>● 更换主控制板</li> </ul>                                                                       |
| E34  | 速度偏差故障          | <ul style="list-style-type: none"> <li>● 负载过重或者被堵转</li> </ul>                                                                                                                  | <ul style="list-style-type: none"> <li>● 检查负载是否正常或过重, 增加速度偏差检出时间或把加减速时间加长</li> <li>● 电机参数设置是否正确, 重新做电机参数自学习</li> <li>● 检查速度环控制参数是否合适</li> </ul>                                     |
| E35  | 失调故障            | <ul style="list-style-type: none"> <li>● 负载异常</li> <li>● 同步电机参数设置不当</li> <li>● 电机自学习参数不准</li> <li>● 变频器未接电机</li> <li>● 弱磁应用</li> </ul>                                         | <ul style="list-style-type: none"> <li>● 检查负载是否正常、过重、堵转</li> <li>● 检查电机参数设置是否正确, 反电动势设置是否正确</li> <li>● 重新做电机参数自学习</li> <li>● 增加失调检出时间</li> <li>● 适当调整弱磁系数, 电流环参数</li> </ul>         |
| E36  | 欠载故障            | <ul style="list-style-type: none"> <li>● 变频器按设定值进行欠载预警</li> </ul>                                                                                                              | <ul style="list-style-type: none"> <li>● 检测负载和欠载预警点</li> </ul>                                                                                                                      |
| E40  | STO 安全转矩停止      | <ul style="list-style-type: none"> <li>● 外部能使安全转矩停止功能</li> </ul>                                                                                                               | -                                                                                                                                                                                   |

-8-

| 故障代码 | 故障类型                    | 可能的原因                                                                                                         | 故障解决方法                                                                                                       |
|------|-------------------------|---------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| E41  | STO 通道 1 安全回路异常         |                                                                                                               | <ul style="list-style-type: none"> <li>● 检查 STO 功能端子接线是否正确、牢固</li> <li>● 检查 STO 功能外部开关是否正常</li> </ul>        |
| E42  | STO 通道 2 安全回路异常         | <ul style="list-style-type: none"> <li>● STO 功能接线不正确</li> <li>● STO 功能外部开关故障</li> <li>● 通道安全回路硬件故障</li> </ul> | <ul style="list-style-type: none"> <li>● 更换控制板</li> <li>🔗 注意：此故障后，需断电后重新上电才能消除此故障。</li> </ul>                |
| E43  | STO 通道 1 和通道 2 同时异常     | ● STO 功能电路硬件故障                                                                                                | ● 更换驱动板                                                                                                      |
| E44  | STO 安全代码 FLASH CRC 校验故障 | ● 驱动板故障                                                                                                       | ● 更换驱动板                                                                                                      |
| E57  | PROFINET 通信超时故障         | ● 通信卡与上位机（或 PLC）之间没有数据传输                                                                                      | ● 检查通信卡接线是否松动或掉线                                                                                             |
| E59  | 电机过温故障                  | <ul style="list-style-type: none"> <li>● 设备或环境温度过高</li> <li>● AIAO 测温不准确</li> <li>● DI4 端子输入电机过温信号</li> </ul> | <ul style="list-style-type: none"> <li>● 降低设备或环境温度</li> <li>● 更换测温电阻</li> <li>● 检查外部测温端子信号</li> </ul>        |
| E60  | 通信卡识别失败                 | <ul style="list-style-type: none"> <li>● 通信扩展卡接口有数据传输，但无法识别到该卡类型</li> </ul>                                   | <ul style="list-style-type: none"> <li>● 确认是否插入了不支持该卡槽内的扩展卡</li> <li>● 掉电后，稳固扩展卡接口，并重新上电确认是否还存在故障</li> </ul> |
| E63  | 通信卡通信超时故障               | ● 通信扩展卡接口没有数据传输                                                                                               | <ul style="list-style-type: none"> <li>● 检测插卡口或卡槽是否损坏，若损坏，掉电后换一个插卡口或卡槽</li> </ul>                            |
| E66  | EtherCAT 通信超时故障         | ● 通信卡与上位机（或 PLC）之间没有数据传输                                                                                      | ● 检查通信卡接线是否松动或掉线                                                                                             |
| E92  | AI1 断线                  | <ul style="list-style-type: none"> <li>● AI1 输入过低</li> <li>● AI1 断线断开</li> </ul>                              | ● 用 5V 电压（或 10mA 电流）源来检查输入是否正常                                                                               |
| E93  | AI2 断线                  | <ul style="list-style-type: none"> <li>● AI2 输入过低</li> <li>● AI2 断线断开</li> </ul>                              | ● 检查接线或更换导线查看是否正常                                                                                            |
| E94  | AI3 断线                  | <ul style="list-style-type: none"> <li>● AI3 输入过低</li> <li>● AI3 断线断开</li> </ul>                              |                                                                                                              |
| E95  | EtherNet IP 通信超时故障      | ● 通信卡与上位机（或 PLC）之间没有数据传输                                                                                      | ● 检查通信卡接线是否松动或掉线                                                                                             |
| E96  | 无升级引导程序                 | ● 升级引导程序丢失                                                                                                    | ● 联系厂家                                                                                                       |
| E587 | 双 CPU 通信故障 1            | ● 双 CPU 通信故障 1                                                                                                | ● 联系厂家                                                                                                       |
| E588 | 双 CPU 通信故障 2            | ● 双 CPU 通信故障 2                                                                                                |                                                                                                              |

## 8 产品尺寸

图 8-1 外形结构 A、B 的尺寸和孔位




表 8-1 外形结构 A、B 的尺寸和孔位

| 产品型号         | 外形结构 | 外形尺寸 (mm) |     |     | 安装孔位 (mm) |     | 安装孔径 (mm) |
|--------------|------|-----------|-----|-----|-----------|-----|-----------|
|              |      | W1        | H1  | D1  | W2        | H2  |           |
| GD28-0R2G-S2 | A    | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R4G-S2 |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R7G-S2 |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R2G-2  |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R4G-2  |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R7G-2  |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R4G-4  |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R7G-4  |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-1R1G-4  |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R4G-5  |      | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-0R7G-5  | B    | 60        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-1R1G-S2 |      | 70        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-1R5G-S2 |      | 70        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-2R2G-S2 |      | 70        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-1R1G-2  |      | 70        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-1R5G-2  |      | 70        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-2R2G-2  |      | 70        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-1R5G-4  |      | 70        | 190 | 155 | 36        | 180 | Ø5        |
| GD28-2R2G-4  |      | 70        | 190 | 155 | 36        | 180 | Ø5        |

-9-

| 产品型号        | 外形结构 | 外形尺寸 (mm) |     | 安装孔位 (mm) |    | 安装孔径 (mm) |    |
|-------------|------|-----------|-----|-----------|----|-----------|----|
|             |      | W1        | H1  | D1        | W2 |           | H2 |
| GD28-003G-4 | B    | 70        | 190 | 155       | 36 | 180       | Ø5 |
| GD28-004G-4 |      | 70        | 190 | 155       | 36 | 180       | Ø5 |
| GD28-1R5G-5 |      | 70        | 190 | 155       | 36 | 180       | Ø5 |
| GD28-2R2G-5 |      | 70        | 190 | 155       | 36 | 180       | Ø5 |
| GD28-004G-5 |      | 70        | 190 | 155       | 36 | 180       | Ø5 |
|             |      |           |     |           |    |           |    |

图 8-2 外形结构 C 的尺寸和孔位




表 8-2 外形结构 C 的尺寸和孔位

| 产品型号         | 外形结构 | 外形尺寸 (mm) |     |     | 安装孔径 (mm) |    |     | 安装孔径 (mm) |
|--------------|------|-----------|-----|-----|-----------|----|-----|-----------|
|              |      | W1        | H1  | D1  | W2        | W3 | H2  |           |
| GD28-004G-S2 | C    | 90        | 235 | 155 | 70        | 72 | 220 | Ø6        |
| GD28-004G-2  |      | 90        | 235 | 155 | 70        | 72 | 220 | Ø6        |
| GD28-5R5G-2  |      | 90        | 235 | 155 | 70        | 72 | 220 | Ø6        |
| GD28-5R5G-4  |      | 90        | 235 | 155 | 70        | 72 | 220 | Ø6        |
| GD28-7R5G-4  |      | 90        | 235 | 155 | 70        | 72 | 220 | Ø6        |
| GD28-5R5G-5  |      | 90        | 235 | 155 | 70        | 72 | 220 | Ø6        |
| GD28-7R5G-5  |      | 90        | 235 | 155 | 70        | 72 | 220 | Ø6        |

图 8-3 外形结构 D 尺寸和孔位





表 8-3 外形结构 D 尺寸和孔位

| 产品型号        | 外形结构 | 外形尺寸 (mm) |     |     | 安装孔位 (mm) |     | 安装孔径 (mm) |
|-------------|------|-----------|-----|-----|-----------|-----|-----------|
|             |      | W1        | H1  | D1  | W2        | H2  |           |
| GD28-7R5G-2 | D    | 130       | 250 | 185 | 100       | 237 | Ø6        |
| GD28-011G-2 |      | 130       | 250 | 185 | 100       | 237 | Ø6        |
| GD28-011G-4 |      | 130       | 250 | 185 | 100       | 237 | Ø6        |
| GD28-015G-4 |      | 130       | 250 | 185 | 100       | 237 | Ø6        |
| GD28-011G-5 |      | 130       | 250 | 185 | 100       | 237 | Ø6        |
| GD28-015G-5 |      | 130       | 250 | 185 | 100       | 237 | Ø6        |
|             |      | 130       | 250 | 185 | 100       | 237 | Ø6        |

图 8-4 外形结构 E 尺寸和孔位



-10-

| 产品型号        | 外形结构 | 外形尺寸 (mm) |     |     | 安装孔位 (mm) |     | 安装孔径 (mm) |
|-------------|------|-----------|-----|-----|-----------|-----|-----------|
|             |      | W1        | H1  | D1  | W2        | H2  |           |
| GD28-015G-2 | E    | 160       | 300 | 190 | 130       | 287 | Ø6        |
| GD28-018G-4 |      | 160       | 300 | 190 | 130       | 287 | Ø6        |
| GD28-022G-4 |      | 160       | 300 | 190 | 130       | 287 | Ø6        |
| GD28-018G-5 |      | 160       | 300 | 190 | 130       | 287 | Ø6        |
| GD28-022G-5 |      | 160       | 300 | 190 | 130       | 287 | Ø6        |

## 附录A 能效数据

表 A-1 能耗和 IE 等级

| 产品型号         | 相对损耗 (%) |        |         |         |         |          |         |          | 待机损耗 (W) | IE 等级 |
|--------------|----------|--------|---------|---------|---------|----------|---------|----------|----------|-------|
|              | (0;25)   | (0;50) | (0;100) | (50;25) | (30;50) | (50;100) | (90;50) | (90;100) |          |       |
| GD28-0R2G-S2 | 2.45     | 2.78   | 2.98    | 2.8     | 3.01    | 3.26     | 3.08    | 3.29     | 7        | IE2   |
| GD28-0R4G-S2 | 1.96     | 2.24   | 2.54    | 2.05    | 2.4     | 2.65     | 2.52    | 2.81     | 7        | IE2   |
| GD28-0R7G-S2 | 1.48     | 1.68   | 1.84    | 1.54    | 1.84    | 2.54     | 1.93    | 2.71     | 7        | IE2   |
| GD28-1R1G-S2 | 1.39     | 1.61   | 2.21    | 1.68    | 1.9     | 2.55     | 2.03    | 2.71     | 7        | IE2   |
| GD28-1R5G-S2 | 1.41     | 1.44   | 1.91    | 1.69    | 1.91    | 2.35     | 1.92    | 2.59     | 7        | IE2   |
| GD28-2R2G-S2 | 1.12     | 1.42   | 2.02    | 1.38    | 1.68    | 2.41     | 1.75    | 2.95     | 7        | IE2   |
| GD28-004G-S2 | 1.33     | 1.65   | 2.34    | 1.47    | 1.84    | 2.74     | 2.04    | 3.09     | 11       | IE2   |
| GD28-0R2G-2  | 2.39     | 2.69   | 2.97    | 2.66    | 2.95    | 3.2      | 3.02    | 3.24     | 7        | IE2   |
| GD28-0R4G-2  | 1.95     | 2.19   | 2.5     | 2.13    | 2.38    | 2.74     | 2.45    | 2.81     | 7        | IE2   |
| GD28-0R7G-2  | 1.48     | 1.67   | 2.26    | 1.59    | 1.84    | 2.5      | 1.9     | 2.62     | 7        | IE2   |
| GD28-1R1G-2  | 1.28     | 1.52   | 2.08    | 1.56    | 1.77    | 2.23     | 1.84    | 2.42     | 7        | IE2   |
| GD28-1R5G-2  | 1.36     | 1.44   | 1.77    | 1.68    | 1.73    | 1.94     | 1.87    | 2.34     | 7        | IE2   |
| GD28-2R2G-2  | 1.31     | 1.37   | 1.72    | 1.6     | 1.73    | 1.95     | 1.82    | 2.2      | 7        | IE2   |
| GD28-004G-2  | 1.45     | 1.63   | 1.93    | 1.51    | 1.72    | 2.1      | 1.9     | 2.26     | 11       | IE2   |
| GD28-5R5G-2  | 0.79     | 1.32   | 1.99    | 0.87    | 1.34    | 2.22     | 1.41    | 2.39     | 11       | IE2   |
| GD28-7R5G-2  | 0.62     | 0.9    | 1.76    | 0.8     | 1.15    | 2.04     | 1.46    | 2.28     | 14       | IE2   |
| GD28-011G-2  | 0.54     | 0.78   | 1.87    | 0.77    | 1.18    | 2.09     | 1.23    | 2.48     | 14       | IE2   |
| GD28-015G-2  | 0.92     | 0.93   | 0.95    | 1.06    | 1.37    | 1.49     | 2.6     | 2.98     | 16       | IE2   |
| GD28-0R4G-4  | 2.13     | 2.28   | 2.59    | 2.2     | 2.54    | 2.81     | 2.54    | 2.94     | 9        | IE2   |
| GD28-0R7G-4  | 1.41     | 1.64   | 2.11    | 1.67    | 1.86    | 2.29     | 1.92    | 2.43     | 9        | IE2   |
| GD28-1R1G-4  | 1.45     | 1.61   | 1.83    | 1.64    | 1.94    | 2.16     | 2.03    | 2.29     | 9        | IE2   |
| GD28-1R5G-4  | 1.25     | 1.34   | 1.52    | 1.41    | 1.63    | 2.01     | 1.62    | 2.15     | 9        | IE2   |
| GD28-2R2G-4  | 1.27     | 1.29   | 1.61    | 1.56    | 1.77    | 2.12     | 1.61    | 2.23     | 9        | IE2   |
| GD28-003G-4  | 1.19     | 1.27   | 1.55    | 1.48    | 1.65    | 2.01     | 1.59    | 2.11     | 9        | IE2   |
| GD28-004G-4  | 1.11     | 1.21   | 1.46    | 1.34    | 1.62    | 1.83     | 1.54    | 2.35     | 9        | IE2   |
| GD28-5R5G-4  | 1.22     | 1.37   | 1.56    | 1.46    | 1.77    | 2.12     | 1.77    | 2.26     | 11       | IE2   |
| GD28-7R5G-4  | 0.76     | 0.96   | 1.54    | 0.98    | 1.17    | 1.91     | 1.22    | 2.04     | 11       | IE2   |
| GD28-011G-4  | 0.79     | 0.89   | 1.79    | 0.78    | 0.9     | 1.77     | 0.93    | 1.8      | 20       | IE2   |
| GD28-015G-4  | 0.7      | 1.01   | 1.98    | 0.74    | 1.02    | 1.87     | 1.17    | 2.23     | 20       | IE2   |
| GD28-018G-4  | 0.53     | 0.76   | 1.23    | 0.56    | 0.86    | 1.73     | 0.86    | 2.01     | 20       | IE2   |
| GD28-022G-4  | 0.63     | 0.71   | 1.38    | 0.6     | 0.9     | 1.73     | 1.02    | 1.95     | 20       | IE2   |
| GD28-0R4G-5  | 1.29     | 1.48   | 1.76    | 1.48    | 1.72    | 2.13     | 2.05    | 2.51     | 12       | IE2   |
| GD28-0R7G-5  | 1.26     | 1.41   | 1.74    | 1.42    | 1.67    | 2.07     | 2.01    | 2.44     | 12       | IE2   |
| GD28-1R5G-5  | 1.20     | 1.35   | 1.66    | 1.39    | 1.63    | 1.99     | 1.92    | 2.24     | 13       | IE2   |
| GD28-2R2G-5  | 1.17     | 1.32   | 1.62    | 1.34    | 1.59    | 1.95     | 1.85    | 2.24     | 13       | IE2   |
| GD28-004G-5  | 1.14     | 1.29   | 1.57    | 1.28    | 1.55    | 1.91     | 1.83    | 2.17     | 13       | IE2   |
| GD28-5R5G-5  | 1.11     | 1.27   | 1.51    | 1.20    | 1.48    | 1.87     | 1.78    | 2.07     | 15       | IE2   |
| GD28-7R5G-5  | 1.06     | 1.24   | 1.48    | 1.17    | 1.47    | 1.85     | 1.73    | 2.02     | 15       | IE2   |
| GD28-011G-5  | 0.88     | 1.18   | 1.40    | 1.03    | 1.44    | 1.82     | 1.69    | 1.97     | 32       | IE2   |
| GD28-015G-5  | 0.73     | 0.97   | 1.34    | 0.89    | 1.31    | 1.72     | 1.52    | 1.94     | 32       | IE2   |
| GD28-018G-5  | 0.70     | 0.88   | 1.24    | 0.85    | 1.25    | 1.68     | 1.50    | 1.85     | 36       | IE2   |
| GD28-022G-5  | 0.68     | 0.85   | 1.25    | 0.79    | 1.21    | 1.56     | 1.36    | 1.77     | 36       | IE2   |

表 A-2 额定规格 (重/轻载)

| 产品型号         | 重载                |                  |                 |                    | 轻载                |                  |                 |                    | 额定电源<br>频率 (Hz)                    | 额定电源<br>电压 (V)      |
|--------------|-------------------|------------------|-----------------|--------------------|-------------------|------------------|-----------------|--------------------|------------------------------------|---------------------|
|              | 视在<br>功率<br>(kVA) | 电机<br>功率<br>(kW) | 输出<br>电流<br>(A) | 最高工<br>作温度<br>(°C) | 视在<br>功率<br>(kVA) | 电机<br>功率<br>(kW) | 输出<br>电流<br>(A) | 最高工<br>作温度<br>(°C) |                                    |                     |
| GD28-0R2G-S2 | 0.7               | 0.2              | 1.5             | 50°C               | 0.94              | 0.4              | 2               | 40°C               | 50Hz 或<br>60Hz,<br>允许范围<br>47~63Hz | AC 1PH<br>220V~240V |
| GD28-0R4G-S2 | 1.15              | 0.4              | 2.5             | 50°C               | 1.52              | 0.75             | 3.3             | 40°C               |                                    |                     |
| GD28-0R7G-S2 | 1.88              | 0.75             | 4.2             | 50°C               | 2.26              | 1.1              | 5.1             | 40°C               |                                    |                     |
| GD28-1R1G-S2 | 2.28              | 1.1              | 6.5             | 50°C               | 2.85              | 1.5              | 7.5             | 40°C               |                                    |                     |
| GD28-1R5G-S2 | 3.35              | 1.5              | 7.5             | 50°C               | 4.37              | 2.2              | 9.8             | 40°C               |                                    |                     |
| GD28-2R2G-S2 | 4.35              | 2.2              | 10              | 50°C               | 5.44              | 4                | 12.5            | 40°C               |                                    |                     |
| GD28-0O4G-S2 | 6                 | 4                | 16              | 50°C               | -                 | -                | -               | 40°C               |                                    |                     |
| GD28-0R2G-2  | 0.69              | 0.2              | 1.5             | 50°C               | 0.91              | 0.4              | 2               | 40°C               | 50Hz 或<br>60Hz,<br>允许范围<br>47~63Hz | AC 3PH<br>200~240V  |
| GD28-0R4G-2  | 1.16              | 0.4              | 2.5             | 50°C               | 1.51              | 0.75             | 3.3             | 40°C               |                                    |                     |
| GD28-0R7G-2  | 1.91              | 0.75             | 4.2             | 50°C               | 2.29              | 1.1              | 5.1             | 40°C               |                                    |                     |
| GD28-1R1G-2  | 3.06              | 1.1              | 6.5             | 50°C               | 3.53              | 1.5              | 7.5             | 40°C               |                                    |                     |
| GD28-1R5G-2  | 3.54              | 1.5              | 7.5             | 50°C               | 4.63              | 2.2              | 9.8             | 40°C               |                                    |                     |
| GD28-2R2G-2  | 4.71              | 2.2              | 10              | 50°C               | 5.88              | 4                | 12.5            | 40°C               |                                    |                     |
| GD28-0O4G-2  | 6.1               | 4                | 16              | 50°C               | 8                 | 5.5              | 21              | 40°C               |                                    |                     |
| GD28-5R5G-S2 | 8.24              | 5.5              | 20              | 50°C               | 9.9               | 7.5              | 26              | 40°C               | 50Hz 或<br>60Hz,<br>允许范围<br>47~63Hz | AC 3PH<br>200~240V  |
| GD28-7R5G-S2 | 14.69             | 7.5              | 30              | 50°C               | 21.5              | 11               | 39              | 40°C               |                                    |                     |
| GD28-011G-2  | 19.95             | 11               | 42              | 50°C               | -                 | -                | -               | 40°C               |                                    |                     |
| GD28-015G-2  | 21                | 15               | 55              | 50°C               | 26.7              | 22               | 64              | 40°C               |                                    |                     |



产品资料可能有所改动，恕不另行通知。版权所有，仿冒必究。

202601 (V1.4)



## Goodrive28 Series VFD Quick Start Guide

This guide briefly describes the external wiring, terminals, keypad, quick running, common function parameter settings, common faults and solutions, product dimensions, and energy efficiency data of Goodrive28 (GD28 for short) series variable-frequency drive (VFD).

Visit [www.invt.com](http://www.invt.com) for more information and source download. For details, see the full version of corresponding product e-manual.



### Warning


- This guide only provides the basic installation and commissioning information. Failure to comply with the safety instructions and installation and commissioning instructions in the relevant documentation may result in accidents such as equipment damage, personal injury, or even death.
- Only trained and qualified professionals are allowed to carry out related operations.

### Danger


- Do not perform any operations including wiring, inspection, or component replacement when power supply is applied. Before performing these operations, ensure all the input power supplies have been disconnected, and wait for at least the time designated on the VFD.

| Minimum waiting time | VFD model                                                                    |
|----------------------|------------------------------------------------------------------------------|
| 5 minutes            | 1PH 220V 0.2~4kW; 3PH 220V 0.2~15kW;<br>3PH 380V 0.4~22kW; 3PH 575V 0.4~22kW |

## 1 External wiring



## 2 Electrical wiring





| Function code | Name                              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Default | Modify |
|---------------|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|--------|
| P23.18        | Sent PZD7                         | 5: Output current                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 0       | ○      |
| P23.19        | Sent PZD8                         | 6: Actual output torque                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 0       | ○      |
| P23.20        | Sent PZD9                         | 7: Actual output power                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | 0       | ○      |
| P23.21        | Sent PZD10                        | 8: Rotational speed                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 0       | ○      |
| P23.22        | Sent PZD11                        | 9: Linear speed                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 0       | ○      |
| P23.23        | Sent PZD12                        | 10: Ramp reference frequency                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 0       | ○      |
|               |                                   | 11: Fault code                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | 0       | ○      |
|               |                                   | 27: VFD status word 2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 0       | ○      |
| P24.00        | Expansion card protocol selection | 1: EtherCAT<br>3: EtherNet IP<br>5: EtherNet UDP<br>6: PROFINET + EtherNet UDP<br>7: EtherCAT + EtherNet UDP<br>15: No communication expansion card<br>0: No card<br>36: All-in-one expansion card—PROFINET communication card<br>41: All-in-one expansion card—EtherCAT communication card<br>43: All-in-one expansion card—EtherNet IP communication card<br>44: All-in-one expansion card—Modbus TCP communication card<br>45: All-in-one expansion card—Ethernet communication card<br>46: All-in-one expansion card—PROFINET + EtherNet communication card<br>47: All-in-one expansion card—EtherCAT + EtherNet communication card | 15      | ◎      |
| P29.00        | Expansion card type               | 0: No card<br>36: All-in-one expansion card—PROFINET communication card<br>41: All-in-one expansion card—EtherCAT communication card<br>43: All-in-one expansion card—EtherNet IP communication card<br>44: All-in-one expansion card—Modbus TCP communication card<br>45: All-in-one expansion card—Ethernet communication card<br>46: All-in-one expansion card—PROFINET + EtherNet communication card<br>47: All-in-one expansion card—EtherCAT + EtherNet communication card                                                                                                                                                        | 0       | ●      |

7 Common faults and solutions

| Fault code | Fault type                                | Possible cause                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E4         | Overcurrent during ACC                    | ● ACC time too short.<br>● Load too large or sudden change of load.<br>● Start during motor rotating.<br>● 3PH output current imbalance.<br>● When sensorless vector control is used for motor control, parameter autotuning is not performed.<br>● When V/F control is used for motor control, V/F curve setting is abnormal.<br>● There are strong external interference sources (contactor switchover or improper grounding).<br>● Grid voltage too low.<br>● Hardware fault. | ● Increase the ACC time, or reduce the software current limit point through P11.06; if the process requires rapid ACC, increase the VFD capacity.<br>● Increase the VFD capacity to ensure that the motor does not experience stalling, and that the load equipment functions without any exception.<br>● Start after the motor stops, or select speed tracking start through P01.00.<br>● Check the VFD output voltage and motor resistance to ensure three-phase balance.<br>● Set the rated parameters according to the motor nameplate, and perform parameter autotuning through P00.15.<br>● Adjust the frequency and voltage relationship set by the V/F curve, and reduce the voltage corresponding to the frequency.<br>● To avoid strong interference, keep the motor cables away from contactors and ensure reliable grounding of the system.<br>● Improve the power quality, or increase the VFD capacity.<br>● Replace the VFD. |
| E5         | Overcurrent during DEC                    | ● DEC time too short.<br>● Software current limit point setting too high.<br>● Load too large or sudden change of load.<br>● 3PH output current imbalance.<br>● When sensorless vector control is used for motor control, parameter autotuning is not performed.<br>● When V/F control is used for motor control, V/F curve setting is abnormal.<br>● There are strong external interference sources (contactor switchover or improper grounding).<br>● Hardware fault.          | ● Increase the DEC time, or reduce the software current limit point through P11.06; if the process requires rapid DEC, increase the VFD capacity.<br>● Reduce the software current limit point through P11.06.<br>● Increase the VFD capacity to ensure that the motor does not experience stalling, and that the load equipment functions without any exception.<br>● Check the VFD output voltage and motor resistance to ensure three-phase balance.<br>● Set the rated parameters according to the motor nameplate, and perform parameter autotuning through P00.15.<br>● Adjust the frequency and voltage relationship set by the V/F curve, and reduce the voltage corresponding to the frequency.<br>● To avoid strong interference, keep the motor cables away from contactors and ensure reliable grounding of the system.<br>● Replace the VFD.                                                                                   |
| E6         | Overcurrent during constant speed running | ● Load too large or sudden change of load.<br>● Software current limit point setting too high.<br>● 3PH output current imbalance.<br>● When sensorless vector control is used for motor control, parameter autotuning is not performed.<br>● When V/F control is used for motor control, V/F curve setting is abnormal.<br>● There are strong external interference sources (contactor switchover or improper grounding).<br>● Hardware fault.                                   | ● Increase the VFD capacity to ensure that the motor does not experience stalling, and that the load equipment functions without any exception.<br>● Software current limit point setting too high.<br>● 3PH output current imbalance.<br>● When sensorless vector control is used for motor control, parameter autotuning is not performed.<br>● When V/F control is used for motor control, V/F curve setting is abnormal.<br>● There are strong external interference sources (contactor switchover or improper grounding).<br>● Hardware fault.                                                                                                                                                                                                                                                                                                                                                                                         |

| Fault code | Fault type                                | Possible cause                                                                                                                                                                                                         | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------------|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E7         | Overvoltage during ACC                    | ● ACC time too short.<br>● Grid voltage too high.<br>● Start during motor rotating.<br>● The load has a significant energy feedback.<br>● Improper setting of overvoltage stall protection.                            | ● Check the VFD output voltage and motor resistance to ensure three-phase balance.<br>● Set the rated parameters according to the motor nameplate, and perform parameter autotuning through P00.15.<br>● When V/F control is used for motor control, V/F curve setting is abnormal.<br>● There are strong external interference sources (contactor switchover or improper grounding).<br>● Grid voltage too low.<br>● Hardware fault.                                                                                                        |
| E8         | Overvoltage during DEC                    | ● Deceleration time too short.<br>● Grid voltage too high.<br>● The load has a significant energy feedback.<br>● Improper setting of overvoltage stall protection.                                                     | ● Increase the DEC time; if the process requires rapid DEC, braking units, energy feedback units can be added, or the magnetic flux braking function can be used.<br>● Improve the power quality to comply with the VFD input voltage specifications (refer to product specifications).<br>● Install a braking unit and energy feedback unit, or remove external factors that cause the load to generate power.<br>● Enable overvoltage stall protection through P11.03, and lower the overvoltage stall protection voltage value of P11.04. |
| E9         | Overvoltage during constant speed running | ● Grid voltage too high.<br>● The load has a significant energy feedback.<br>● Improper setting of overvoltage stall protection.                                                                                       | ● Improve the power quality to comply with the VFD input voltage specifications (refer to product specifications).<br>● Install a braking unit and energy feedback unit, or remove external factors that cause the load to generate power.<br>● Enable overvoltage stall protection through P11.03, and lower the overvoltage stall protection voltage value of P11.04.                                                                                                                                                                      |
| E10        | DC bus undervoltage                       | ● Grid voltage too low.<br>● Abnormal bus voltage display.<br>● Abnormal precharge contactor closing.<br>● Running under heavy load in the event of input phase loss.                                                  | ● Increase grid input voltage.<br>● Contact us.<br>● Check for abnormal input power and loose input cables.                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| E11        | Motor overload                            | ● Grid voltage is too low.<br>● Motor rated current is set incorrectly.<br>● Motor stall or load jumps violently.                                                                                                      | ● Increase grid input voltage.<br>● Reset the motor rated current in the motor parameter group.<br>● Check the load and adjust torque boost.                                                                                                                                                                                                                                                                                                                                                                                                 |
| E12        | VFD overload                              | ● ACC is too fast.<br>● The motor is restarted during rotating.<br>● Grid voltage is too low.<br>● Load is too heavy.<br>● VFD power is too small.                                                                     | ● Increase ACC time.<br>● Avoid restart after stop.<br>● Increase grid input voltage.<br>● Select a VFD with larger power.                                                                                                                                                                                                                                                                                                                                                                                                                   |
| E13        | Input side phase loss                     | ● Phase loss or significant fluctuations in input L1, L2, or L3.<br>● Input-side screws are loose.                                                                                                                     | ● Check for abnormal input power and loose input cables.<br>● Set P11.00 to screen out the fault.                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| E14        | Output side phase loss                    | ● Output cables are broken or short connected to the ground.<br>● UVW phase loss (or the three phases of load are seriously asymmetrical).<br>Note: The output phase loss detection time requires at least 2.5s. After | ● Check for loose or broken output cables.<br>● Check for sharp load fluctuation and motor 3PH resistance imbalance.                                                                                                                                                                                                                                                                                                                                                                                                                         |

| Fault code | Fault type                            | Possible cause                                                                                                                                                                                  | Solution                                                                                                                                                                                                                                                                                                          |
|------------|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E16        | Inverter module overheat              | ● Air duct is blocked or fan is damaged.<br>● Ambient temperature is too high.<br>● Long-time overload running.                                                                                 | ● Ventilate the air duct or replace the fan.<br>● Keep good ventilation to lower ambient temperature.<br>● Select a VFD with larger power.                                                                                                                                                                        |
| E17        | External fault                        | ● DI terminal external fault input signal acted.                                                                                                                                                | ● Check whether external device input is normal.                                                                                                                                                                                                                                                                  |
| E18        | Modbus/Modbus TCP communication fault | ● Incorrect baud rate.<br>● Communication line fault.<br>● Incorrect communication address.<br>● Communication suffers from strong interference.                                                | ● Set a proper baud rate.<br>● Check the communication port wiring.<br>● Set the communication address correctly.<br>● You are recommended to use shielded cables to improve anti-interference.                                                                                                                   |
| E19        | Current detection fault               | ● Abnormal motor cable or motor insulation.<br>● Motor capacity does not match with the VFD capacity. This fault may occur if the capacity difference exceeds five power classes.               | ● Remove motor cables to check.<br>● Contact us.                                                                                                                                                                                                                                                                  |
| E20        | Motor autotuning fault                | ● Incorrect motor parameter setting.<br>● The parameters gained from autotuning deviate sharply from the standard parameters.<br>● Autotuning timeout.<br>● Pulse current setting is too large. | ● Change the VFD model, or adopt V/F mode for control<br>● Check motor wiring, motor type, and parameter settings.<br>● Empty the motor load and re-perform autotuning.<br>● Check whether the upper limit frequency is larger than 2/3 of the rated frequency.<br>● Decrease the pulse current setting properly. |
| E21        | EEPROM operation fault                | ● Error in reading or writing control parameters<br>● EEPROM damaged.                                                                                                                           | ● Press STOP/RST to reset.<br>● Replace the control board.                                                                                                                                                                                                                                                        |
| E22        | PID feedback offline                  | ● PID feedback offline.<br>● PID feedback source disappears.                                                                                                                                    | ● Check PID feedback signal wires.<br>● Check PID feedback source.                                                                                                                                                                                                                                                |
| E23        | Braking unit fault                    | ● Braking circuit fault or braking pipe damage.<br>● External braking resistor with small resistance.                                                                                           | ● Check the braking unit, and replace with new braking pipe<br>● Increase the braking resistance.                                                                                                                                                                                                                 |
| E24        | Running time reached                  | ● Actual VFD running time longer than internally set running time.                                                                                                                              | ● Contact us.                                                                                                                                                                                                                                                                                                     |
| E25        | Electronic overload                   | ● The VFD reports overload pre-alarm according to the setting.                                                                                                                                  | ● Check whether the overload pre-alarm point is set properly.                                                                                                                                                                                                                                                     |
| E27        | Parameter upload error                | ● Keypad cable connected improperly or disconnected.<br>● Keypad cable too long, causing strong interference.<br>● Keypad or mainboard communication circuit error                              | ● Check the keypad cable and re-plug to determine whether a fault occurs.<br>● Check the surroundings to rule out interference source<br>● Replace the hardware and seek maintenance services.                                                                                                                    |
| E28        | Parameter download error              | ● Keypad cable connected improperly or disconnected.<br>● Keypad cable too long, causing strong interference.<br>● Keypad data storage error                                                    | ● Check the surroundings to rule out interference source<br>● Replace the hardware and seek maintenance services.<br>● Check whether the version of the control board software of keypad backup parameter copy is the same as the version of the control board software of the VFD.                               |
| E30        | Ethernet communication fault          | ● No data transmission between the communication card and the host controller (or PLC).                                                                                                         | ● Check whether the communication card wiring is loose or disconnected.                                                                                                                                                                                                                                           |
| E32        | To-ground short-circuit fault         | ● The output of the VFD is short circuited to the ground.<br>● Current detection circuit fault.                                                                                                 | ● Check whether the motor is short circuited to the ground and wiring is normal.<br>● Check whether the motor wiring is normal.<br>● Replace the main control board.                                                                                                                                              |
| E34        | Speed deviation fault                 | ● Load too heavy or stalled.                                                                                                                                                                    | ● Check for overload, increase speed deviation detection time, or prolong ACC/DEC time.<br>● Check motor parameter settings and re-perform motor parameter autotuning.<br>● Check speed loop control parameter settings.                                                                                          |
| E35        | Mal-adjustment fault                  | ● Load exception.<br>● Incorrect SM parameter settings.<br>● Autotuned motor parameters are inaccurate.<br>● The VFD is not connected to the motor.                                             | ● Check for overload or stalling.<br>● Check motor parameter and counter EMF settings.<br>● Re-perform motor parameter autotuning.<br>● Increase the maladjustment detection time.<br>● Adjust flux weakening coefficient                                                                                         |

| Fault code | Fault type                                     | Possible cause                                                                                                                        | Solution                                                                                                                                                                         |
|------------|------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E36        | Underload fault                                | ● Flux weakening application.<br>● The VFD reports underload pre-alarm according to the setting.                                      | ● Check the load and overload pre-alarm threshold.                                                                                                                               |
| E40        | Safe torque off                                | ● Safe torque off function is enabled by external forces.                                                                             | -                                                                                                                                                                                |
| E41        | Safety circuit exception of STO channel 1      | ● The wiring of STO is improper.<br>● Fault occurred to external switch of STO.                                                       | ● Check whether terminal wiring of STO is proper and firm enough.<br>● Check whether the external switch of STO can work properly                                                |
| E42        | Safety circuit exception of STO channel 2      | ● Channel safety circuit hardware fault.                                                                                              | ● Replace the control board.<br>Note: Re-power on is required to clear the fault.                                                                                                |
| E43        | Exception to both STO channel 1 and channel 2  | ● Hardware fault occurred to STO circuit.                                                                                             | ● Replace the drive board.                                                                                                                                                       |
| E44        | STO safety code FLASH CRC check fault          | ● Drive board fault.                                                                                                                  | ● Replace the drive board.                                                                                                                                                       |
| E57        | PROFINET communication timeout                 | ● No data transmission between the communication card and the host controller (or PLC).                                               | ● Check whether the communication card wiring is loose or disconnected.                                                                                                          |
| E59        | Motor overtemperature fault                    | ● Equipment or ambient temperature too high.<br>● AI/AO detected temperature inaccurate.<br>● DI4 input motor overtemperature signal. | ● Lower the equipment or ambient temperature.<br>● Replace the temperature measuring resistor.<br>● Check the external temperature measuring terminal signal.                    |
| E60        | Communication card identifying failure         | ● There is data transmission in communication card interface, but the card type cannot be identified.                                 | ● Check whether the expansion card in the slot is supported.<br>● Stabilize the expansion card interface after power-off, and check whether the fault persists at next power-on. |
| E63        | Communication card communication timeout fault | ● No data transmission in the communication card interface.                                                                           | ● Check whether the insertion port or card slot is damaged. If yes, replace the insertion port or card slot after power-off.                                                     |
| E66        | EtherCAT communication timeout                 | ● No data transmission between the communication card and the host controller (or PLC).                                               | ● Check whether the communication card wiring is loose or disconnected.                                                                                                          |
| E92        | AI1 disconnection                              | ● AI1 input too low.<br>● AI1 wiring disconnected.                                                                                    | ● Connect a 5V or 10mA power source to check whether the input is normal.                                                                                                        |
| E93        | AI2 disconnection                              | ● AI2 input too low.<br>● AI2 wiring disconnected.                                                                                    | ● Check the wiring or replace the cable.                                                                                                                                         |
| E94        | AI3 disconnection                              | ● AI3 input too low.<br>● AI3 wiring disconnected.                                                                                    | ● Check the wiring or replace the cable.                                                                                                                                         |
| E95        | EtherNet IP communication timeout fault        | ● No data transmission between the communication card and the host controller (or PLC).                                               | ● Check whether the communication card wiring is loose or disconnected.                                                                                                          |
| E96        | No upgrade bootloader                          | ● Upgrade bootloader missing.                                                                                                         | ● Contact us.                                                                                                                                                                    |
| E587       | Dual CPU communication fault 1                 | ● Dual CPU communication fault.                                                                                                       | ● Contact us.                                                                                                                                                                    |
| E588       | Dual CPU communication fault 2                 | ● Dual CPU communication fault.                                                                                                       | ● Contact us.                                                                                                                                                                    |

8 Product dimensions

Figure 8-1 Dimensions and hole positions for VFDs in frames A and B




Table 8-1 Dimensions and hole positions for VFDs in frames A and B

| Product model | Frame | Outline dimensions (mm) |     |     | Mounting hole distance (mm) |     | Mounting hole diameter (mm) |
|---------------|-------|-------------------------|-----|-----|-----------------------------|-----|-----------------------------|
|               |       | W1                      | H1  | D1  | W2                          | H2  |                             |
| GD28-0R2G-S2  | A     | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R4G-S2  |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R7G-S2  |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R2G-2   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R4G-2   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R7G-2   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R4G-4   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R7G-4   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R1G-4   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R4G-5   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R7G-5   |       | 60                      | 190 | 155 | 36                          | 180 | Ø5                          |

| Product model | Frame | Outline dimensions (mm) |     |     | Mounting hole distance (mm) |     | Mounting hole diameter (mm) |
|---------------|-------|-------------------------|-----|-----|-----------------------------|-----|-----------------------------|
|               |       | W1                      | H1  | D1  | W2                          | H2  |                             |
| GD28-1R1G-S2  | B     | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R5G-S2  |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-2R2G-S2  |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R1G-2   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R5G-2   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-2R2G-2   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R5G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-2R2G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-003G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-004G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R7G-2   | C     | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R1G-2   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R5G-2   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-2R2G-2   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-003G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-004G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-0R7G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-1R5G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-2R2G-4   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |
| GD28-004G-5   |       | 70                      | 190 | 155 | 36                          | 180 | Ø5                          |

Figure 8-2 Dimensions and hole positions for VFDs in frame C




Table 8-2 Dimensions and hole positions for VFDs in frame C

| Product model | Frame | Outline dimensions (mm) |     |     | Mounting hole distance (mm) |    | Mounting hole diameter (mm) |
|---------------|-------|-------------------------|-----|-----|-----------------------------|----|-----------------------------|
|               |       | W1                      | H1  | D1  | W2                          | H2 |                             |
| GD28-004G-S2  | C     | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-004G-2   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-5R5G-2   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-1R5G-5   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-2R2G-5   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-004G-5   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-0R7G-5   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-1R5G-5   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-2R2G-5   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |
| GD28-004G-5   |       | 90                      | 235 | 155 | 70                          | 72 | Ø6                          |

Figure 8-3 Dimensions and hole positions for VFDs in frame D




Table 8-3 Dimensions and hole positions for VFDs in frame D

| Product model | Frame | Outline dimensions (mm) |     |     | Mounting hole distance (mm) |     | Mounting hole diameter (mm) |
|---------------|-------|-------------------------|-----|-----|-----------------------------|-----|-----------------------------|
|               |       | W1                      | H1  | D1  | W2                          | H2  |                             |
| GD28-7R5G-2   | D     | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-011G-2   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-011G-4   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-015G-4   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-011G-5   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-015G-5   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-011G-5   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-015G-5   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-011G-5   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |
| GD28-015G-5   |       | 130                     | 250 | 185 | 100                         | 237 | Ø6                          |

Figure 8-4 Dimensions and hole positions for VFDs in frame E




Table 8-4 Dimensions and hole positions for VFDs in frame E

| Product model | Frame | Outline dimensions (mm) |     |     | Mounting hole distance (mm) |     | Mounting hole diameter (mm) |
|---------------|-------|-------------------------|-----|-----|-----------------------------|-----|-----------------------------|
|               |       | W1                      | H1  | D1  | W2                          | H2  |                             |
| GD28-015G-2   | E     | 160                     | 300 | 190 | 130                         | 287 | Ø6                          |
| GD28-018G-4   |       | 160                     | 300 | 190 | 130                         | 287 | Ø6                          |
| GD28-022G-4   |       | 160                     | 300 | 190 | 130                         | 287 | Ø6                          |
| GD28-018G-5   |       | 160                     | 300 | 190 | 130                         | 287 | Ø6                          |
| GD28-022G-5   |       | 160                     | 300 | 190 | 130                         | 287 | Ø6                          |
| GD28-015G-5   |       | 160                     | 300 | 190 | 130                         | 287 | Ø6                          |
| GD28-018G-5   |       | 160                     | 300 | 190 | 130                         | 287 | Ø6                          |

Appendix A Energy efficiency data

| Table A-1 Power loss and IE class |                   |        |         |         |         |          |         |          |                  |          |
|-----------------------------------|-------------------|--------|---------|---------|---------|----------|---------|----------|------------------|----------|
| Product model                     | Relative loss (%) |        |         |         |         |          |         |          | Standby loss (W) | IE class |
|                                   | (0;25]            | (0;50] | (0;100] | (50;25] | (50;50] | (50;100] | (90;50] | (90;100] |                  |          |
| GD28-0R2G-S2                      | 2.45              | 2.78   | 2.98    | 2.8     | 3.01    | 3.26     | 3.08    | 3.29     | 7                | IE2      |
| GD28-0R4G-S2                      | 1.96              | 2.24   | 2.54    | 2.05    | 2.4     | 2.65     | 2.52    | 2.81     | 7                | IE2      |
| GD28-0R7G-S2                      | 1.48              | 1.68   | 1.84    | 1.54    | 1.84    | 2.54     | 1.93    | 2.71     | 7                | IE2      |
| GD28-1R1G-S2                      | 1.39              | 1.61   | 2.21    | 1.68    | 1.9     | 2.55     | 2.03    | 2.71     | 7                | IE2      |
| GD28-1R5G-S2                      | 1.41              | 1.44   | 1.91    | 1.69    | 1.91    | 2.35     | 1.92    | 2.59     | 7                | IE2      |
| GD28-2R2G-S2                      | 1.32              | 1.42   | 2.02    | 1.38    | 1.68    | 2.41     | 1.75    | 2.95     | 7                | IE2      |
| GD28-004G-S2                      | 1.23              | 1.65   | 2.34    | 1.47    | 1.84    | 2.74     | 2.04    | 3.09     | 11               | IE2      |
| GD28-0R2G-2                       | 2.39              | 2.69   | 2.97    | 2.66    | 2.95    | 3.2      | 3.02    | 3.24     | 7                | IE2      |
| GD28-0R4G-2                       | 1.95              | 2.19   | 2.5     | 2.13    | 2.38    | 2.74     | 2.45    | 2.81     | 7                | IE2      |
| GD28-0R7G-2                       | 1.48              | 1.67   | 2.26    | 1.59    | 1.84    | 2.5      | 1.9     | 2.62     | 7                | IE2      |
| GD28-1R1G-2                       | 1.28              | 1.52   | 2.08    | 1.56    | 1.77    | 2.23     | 1.84    | 2.42     | 7                | IE2      |
| GD28-1R5G-2                       | 1.36              | 1.44   | 1.77    | 1.68    | 1.73    | 1.94     | 1.87    | 2.34     | 7                | IE2      |
| GD28-2R2G-2                       | 1.31              | 1.37   | 1.72    | 1.6     | 1.73    | 1.95     | 1.82    | 2.2      | 7                | IE2      |
| GD28-004G-2                       | 1.45              | 1.63   | 1.93    | 1.51    | 1.72    | 2.1      | 1.9     | 2.26     | 11               | IE2      |
| GD28-5R5G-2                       | 0.79              | 1.32   | 1.99    | 0.87    | 1.34    | 2.22     | 1.41    | 2.39     | 11               | IE2      |
| GD28-7R5G-2                       | 0.62              | 0.9    | 1.76    | 0.8     | 1.15    | 2.04     | 1.46    | 2.28     | 14               | IE2      |
| GD28-011G-2                       | 0.54              | 0.78   | 1.87    | 0.77    | 1.18    | 2.09     | 1.23    | 2.48     | 14               | IE2      |
| GD28-015G-2                       | 0.92              | 0.93   | 0.95    | 1.06    | 1.37    | 1.49     | 2.6     | 2.98     | 16               | IE2      |
| GD28-0R4G-4                       | 2.13              | 2.28   | 2.59    | 2.2     | 2.54    | 2.81     | 2.54    | 2.94     | 9                | IE2      |
| GD28-0R7G-4                       | 1.41              | 1.64   | 2.11    | 1.67    | 1.86    | 2.29     | 1.92    | 2.43     | 9                | IE2      |
| GD28-1R1G-4                       | 1.45              | 1.61   | 1.83    | 1.64    | 1.94    | 2.16     | 2.03    | 2.29     | 9                | IE2      |
| GD28-1R5G-4                       | 1.25              | 1.34   | 1.52    | 1.41    | 1.63    | 2.01     | 1.62    | 2.15     | 9                | IE2      |
| GD28-2R2G-4                       | 1.27              | 1.29   | 1.61    | 1.56    | 1.77    | 2.12     | 1.61    | 2.23     | 9                | IE2      |
| GD28-003G-4                       | 1.19              | 1.27   | 1.55    | 1.48    | 1.65    | 2.01     | 1.59    | 2.11     | 9                | IE2      |
| GD28-0R4G-4                       | 1.11              | 1.21   | 1.46    | 1.34    | 1.62    | 1.83     | 1.54    | 2.35     | 9                | IE2      |
| GD28-0R6G-4                       | 1.22              | 1.37   | 1.56    | 1.46    | 1.77    | 2.12     | 1.77    | 2.26     | 11               | IE2      |
| GD28-7R5G-4                       | 0.6               | 0.96   | 1.54    | 0.78    | 1.17    | 1.91     | 1.26    | 2.01     | 11               | IE2      |
| GD28-011G-4                       | 0.79              | 0.89   | 1.79    | 0.75    | 1.09    | 1.7      | 1.93    | 8        | 20               | IE2      |
| GD28-015G-4                       | 0.7               | 1.01   | 1.98    | 0.74    | 1.02    | 1.87     | 1.17    | 2.23     | 20               | IE2      |
| GD28-018G-4                       | 0.53              | 0.76   | 1.23    | 0.56    | 0.86    | 1.73     | 0.86    | 2.01     | 20               | IE2      |
| GD28-022G-4                       | 0.63              | 0.71   | 1.38    | 0.6     | 0.9     | 1.73     | 1.02    | 1.95     | 20               | IE2      |
| GD28-0R4G-5                       | 1.29              | 1.48   | 1.76    | 1.48    | 1.72    | 2.13     | 2.05    | 2.51     | 12               | IE2      |
| GD28-0R7G-5                       | 1.26              | 1.41   | 1.74    | 1.42    | 1.67    | 2.07     | 2.01    | 2.44     | 12               | IE2      |
| GD28-1R5G-5                       | 1.20              | 1.35   | 1.66    | 1.39    | 1.63    | 1.99     | 1.92    | 2.24     | 13               | IE2      |
| GD28-2R2G-5                       | 1.17              | 1.32   | 1.62    | 1.34    | 1.59    | 1.95     | 1.85    | 2.24     | 13               | IE2      |
| GD28-004G-4                       | 1.14              | 1.29   | 1.57    | 1.28    | 1.55    | 1.91     | 1.83    | 2.17     | 13               | IE2      |
| GD28-5R5G-5                       | 1.11              | 1.27   | 1.51    | 1.20    | 1.48    | 1.87     | 1.78    | 2.07     | 15               | IE2      |
| GD28-7R5G-5                       | 1.06              | 1.24   | 1.48    | 1.17    | 1.47    | 1.85     | 1.73    | 2.02     | 15               | IE2      |
| GD28-011G-5                       | 0.88              | 1.18   | 1.40    | 1.03    | 1.44    | 1.82     | 1.69    | 1.97     | 32               | IE2      |
| GD28-015G-5                       | 0.73              | 0.97   | 1.34    | 0.89    | 1.31    | 1.72     | 1.52    | 1.94     | 32               | IE2      |
| GD28-018G-5                       | 0.70              | 0.88   | 1.24    | 0.85    | 1.25    | 1.68     | 1.50    | 1.85     | 36               | IE2      |
| GD28-022G-5                       | 0.68              | 0.85   | 1.25    | 0.79    | 1.21    | 1.56     | 1.36    | 1.77     | 36               | IE2      |